


Control Self Diagnostics

Control prompts will only display when a fault or alarm condition exists.

ALARM Codes "S.ERR" & "- - - -"



Indicates Input Error

Check to make sure Thermocouple wiring is connected securely

ALARM Code "E333"



Indicates Internal Circuit Error

Turn Controller OFF and On. If problem remains, replace Controller

ALARM Code "E111"



Indicates Internal Memory Error

Turn Controller OFF and On. If problem remains, replace Controller

Common Replacement Components

All replacement components are readily available and are easily replaced in the field.

COMPONENT	MODEL	VOLTAGE	PART #	COMPONENT	MODEL	VOLTAGE	PART #
Digital Controller	All	All	101-1230	Acrylic Door/Hinge	10-140AE	All	401-1010
Relay	All	All	401-1235	Acrylic Door/Hinge	12-140AE	All	401-1211
Push Button Switch	All	115V	401-2213	Motor w/ Fan & Brkt	All	115V	401-2025
Push Button Switch	All	230V	401-2213-1	Motor w/ Fan & Brkt	All	230V	401-2025-1
Thermocouple	All	All	401-1231	FUSE (3 AMP) 250V FA 5 X 20 mm	10-140AE-1 12-140AE-1	230V	Q-1196
Magnetic Catch (set)	All	All	401-1214	FUSE (5 AMP) 250V FA 5 X 20 mm	10-180AE-1 12-180AE-1	230V	Q-1193
Aluminum Shelf	10-140AE 10-180AE	All	401-6033	Fuse Holder (Black)	All	All	Q-1197
Aluminum Shelf	12-140AE 12-180AE	All	F-6043A	Fuse Holder (Red)	All	All	Q-1198
Shelf Supports (2)	10-140AE 10-180AE	All	101-1001	6' Cord & Plug	All	115V	101-1803
Shelf Supports (2)	12-140AE 12-180AE	All	101-3001	6' Cord & Plug	All	230V	101-1603-1

Maintenance / Control Calibration / Cleaning Procedures

To clean interior and exterior surfaces, use a damp cloth with or without an all-purpose cleaner. Avoid commercially available oven cleaners. The acrylic door should only be cleaned using a lint-free cloth, with or without water. Paper towels can mar the surface of the acrylic door. Use of any commercial cleansers on the acrylic door will cause crazing and cracking of the surface of the acrylic over time. Periodically, check the accuracy of the control's temperature display against a known accurate or calibrated device. This should be done with an empty chamber after the set temperature becomes steady (typically after 45 - 60 minutes). Calibrate the control in the control's function menu, level 3 (see page 3).

- If liquid is spilled inside the unit, disconnect it from the power supply and have it checked by a competent person.
- It is the user's responsibility to carry out the appropriate decontamination if hazardous material is spilled on or inside the unit.
- It is the user's responsibility not to use decontamination or cleaning agents that could cause a hazard as a result of a reaction with parts of the equipment or with material contained in it.

If unsure of the compatibility of decontamination or cleaning agents consult the manufacturer.

Technical Support

If you have any questions or need technical assistance, please contact Quincy Lab Tech Support at:

Email: information@quincylab.com
Voice: 800-482-HEAT (4328)
Fax: 773-622-2282

Quincy Lab, Inc.
1925 N Leamington Ave
Chicago, Illinois 60639


Limited Warranty

Quincy Lab, Inc. warrants to the original purchaser that this product will be free from defects in material and workmanship under normal use throughout the warranty period. The standard warranty period for this

instrument is eighteen months from date of shipment. The instrument warranty is supplemented with a three year warranty on the heating element. Please refer to your invoice or shipping documents to determine the active warranty period. This warranty covers parts & labor (labor at factory only) and shipping cost for replacement parts.



Model Series 140AE-1 & 180AE-1 (230 Volt) General Purpose Incubators OPERATING MANUAL



Model 12-140AE-1
230 Volt



Model 10-180AE-1
230 Volt



SPECIFICATIONS

	MODEL 10-140AE-1	MODEL 12-140AE-1	MODEL 10-180AE-1	MODEL 12-180AE-1
Interior Dimensions				
INCHES W x H x D	12x10x10	16x15.5x12	12x10x10	16x15.5x12
(CM) W x H x D	31x25x25	46x41x30	31x25x25	46x41x30
Exterior Dimensions				
INCHES W x H x D	13x15x11	19x21x13	13x15x11	19x21x11
(CM) W x H x D	33x38x28	48x53x33	33x38x28	48x53x33
Weight (lbs)	23 lbs	39 lbs	23 lbs	39 lbs
Cubic Foot Capacity	.7 ft ³	1.72 ft ³	.7 ft ³	1.72 ft ³

Standard Electrical	MODEL 10-140AE-1	MODEL 12-140AE-1	MODEL 10-180AE-1	MODEL 12-180AE-1
VOLTS / WATTS	230 / 200	230 / 295	230 / 365	230 / 465
FREQUENCY (Hz)	50/ 60	50/ 60	50/ 60	50/ 60

Temperature Range	MODEL 10-140AE-1	MODEL 12-140AE-1	MODEL 10-180AE-1	MODEL 12-180AE-1
Ambient +8°C to:	62°C	62°C	94°C	94°C

Common Unit Specifications

Operating Environment:	Indoor use, altitude to 6,500 ft. (2,000m) Installation Category II, Pollution Degree 2, ambient temperature 10°C/50°F to 35°C/95°F, 80% RH maximum.
Storage Temperature:	-10°C/14°F to 70°C/158°F, 70% RH maximum.
Approvals:	Underwriter's Laboratory Listed, Laboratory Equipment, C/UL United States/Canadian. E212550 (115VAC models only)
Compliance:	UL Standard 61010-1, IEC 61010-1, 2nd Edition.

Common Unit Construction

Exterior: Powder-Coated Steel	Interior: Aluminum
Insulation: Fiberglass	Door: 140AE-1: Acrylic, 180AE-1: Steel Insulated
Thermo-control: PID Microprocessor	Heater: Resistive-Tubular Incoloy

Issue Rev A 0519
Copyright Quincy Lab Inc. 2019

Quincy Lab, Inc. 1925 N. Leamington Ave. Chicago, Illinois 60639 1-800-482-HEAT (4328)

Safety Precautions **Read Operating Instructions Thoroughly Prior to Operation**

- Read Operating Instructions thoroughly prior to operation and observe the following safety precautions:
- Use only a grounded outlet that is rated for your model's electrical requirement.
 - Do not modify the oven or factory control settings to operate the oven above the stated maximum operating temperature.
 - Exterior surfaces on the 180AE-1 models may become hot to the touch when operating at higher set temperatures.
 - Conduct periodic maintenance as required.

WARNING: Do not place volatile or combustible materials into incubators.
CAUTION: This unit is not intended for use with any flammable liquids or vapors, or with chemicals that produce toxic gases.

Set-up & Installation

Position unit in its ultimate operating location. Keep a minimum of 3" of airspace around the unit and a minimum of 6" above the unit. The port hole at the top of the unit will expel a small amount of warm air through natural convection. This port can also be used as an access way for external temperature measurement of a solution for example.




FIG. 1

Install adjustable shelf by placing the ends of the wire shelf bracket into the corresponding holes located on the inner sides of the oven at the desired height. Push the ends of the bracket into the holes until the first bends in the bracket are against the wall, then rotate the bracket down. Place the shelf on the brackets. (FIG 1)

Place drip tray on lower shelf.
 Plug the unit into a grounded outlet for your unit's rated voltage.

General Operation

The unit is ready for your immediate use. All control parameters, calibration and tuning has been done at the factory, no adjustments are necessary.

Push the illuminated power button. All LED's on the temperature control will light up and display the current chamber temperature and the set temperature.

Set temperature is constantly displayed in the lower right-hand corner of the display. To change the set temperature, simply press either the up arrow key or the down arrow key until desired set temperature is reached. (FIG 2) The temperature control is set at the factory to read in 1/10 degree F, or Fahrenheit units. To change Controller functions see: Menu Level Functions (page 3).

Once the unit nears the desired temperature, allow the unit to cycle for 20 minutes at set point before temperature becomes fully stable.

NOTE: FLASHING YELLOW LIGHT INDICATES NORMAL OPERATION.



- Enter/Exit Menu
- Menu Scroll
- Increase/Decrease Setpoint (PRESS)

FIG. 2

Upon each initial powering-up, the control may typically overshoot the set temperature by 1 or 2 degrees, especially if the temperature set point is close to the operating ambient temperature. After equilibrium is achieved the control will hold set temperature within 1 unit degree.

Chamber Loading

Article processing times and temperature uniformity are largely dependent on load density and positioning. Load the incubator so that air circulation within the incubator is not impaired. Here are some general guidelines:

Leave a space between articles on a shelf to allow the unit's horizontal air flow to circulate around each article. (FIG. 3)

Don't block the return air port located at the back of the lower plenum/shelf.

Avoid extremely large (in quantity or size) or high-density loads. This will show by non-uniform processing and long or impossible "heat-through" times. To help determine a large load's suitability, use the set-point recovery time (the time it takes for the temperature to recover to the original set temperature once load is placed), as a guide. To reduce recovery time, reduce load proportionally. When possible, measure large loads or solution temperatures directly with an ancillary thermometer or probe. Probes can be inserted at top port.




FIG. 3

Menu Level Functions Guide

To access menu for common menu functions, please refer to the easy-to-use **Menu Guide** below: Menu setting changes are quick and easy with our new 5-button digital microprocessor. Through the use of these controls you can:

- Set the operating temperature
- Select either degrees Fahrenheit or Centigrade
- Calibrate your unit to your independent temperature-sensing device
- Lock the set-temperature
- Auto-tune your Incubator for maximum efficiency

MENU GUIDE

Digital Controller Function Buttons

Enter / Exit MENU	MENU Scroll	Changes digit cursor on set temperature	Decrease	Increase

To set setpoint temperature

		Up and down arrow keys (shown left) are used to increase or decrease set-point control temperature as desired by user
Decrease	Increase	

To adjust control to read in C or F temperature units

		When at the d-U "Degree Units" prompt, you can change the temperature units to F for Fahrenheit, or C for Celcius, by using the buttons.
Hold 3 sec	View	Default set to F

To lock setpoint temperature

			Lock setpoint by changing to '3' Default set to 0
Hold together 3 seconds			

To calibrate control to independent probe/sensor

			To calibrate unit add (or subtract) the temperature differential, to the existing iNS value shown at prompt
Hit ONCE	Hit ONCE	Use keys to enter temperature shift in degrees	

To Auto-tune oven

		All units are Auto-tuned at the factory using the 'At-1' option for faster response time. You may, however, want to Auto-tune your oven to your specific application. To do this, once at the 'At' prompt (at left), use arrow keys to initiate either Auto-tune option: 'At-1' (for 40% Auto-tune), or 'At-2' (for 100% Autotune). The 40% Auto-tune (At-1), will stabilize the oven temperature quicker and with less 'overshoot' than the 100%, but will be somewhat less precise. The 100% Auto-tune (At-2), will take longer to stabilize oven temperature but will be more precise, and take a little longer to complete the Auto-tune process.
Hit ONCE	Use keys to change setting	Default set to 40%

Returning to Main Display and Clearing Controller Safety Alarm

After **most** changes to the configuration, return to normal operating mode by holding the enter/exit key for 3 seconds.

For returning from setting the **set-point temperature lock**, hold **both** and for 3 seconds.

ALARM "Over Maximum Temperature"

When the oven exceeds its maximum operating temperature by 3°C a safety alarm in the controller will cut power to the heating elements. Allow the units temperature to drop below its maximum temperature and/or cool before reset. To reset unit, power OFF and ON to clear alarm status. If problem remains, please contact technical support for assistance.

