

# SUBARU

SERIES

# Subaru Sambar English Factory Service Manual

Truck & Van

**SAMBAR  
660**

1990~2006

V-KS3

V-KS4

V-KVS

V-KV4

2WD & 4WD

James L. Danko

# **Subaru Sambar English Factory Service Manual**

**English Version**

**Full Version**

**Truck & Van  
Sambar 660cc  
2WD &4WD**

**AT-MT Models**

**Subaru Kei Vehicles Series**

**Written By,  
James Danko**

**Yokohama, Japan  
First Edition 2008**

Copyright © 2008 by James Danko

All rights reserved. All text and graphics in this publication if the author, unless otherwise noted or credited. It is unlawful to reproduce-or copy in anyway-resell, or redistribute this information without the express written permission of the publisher.

This book is an independent publication, and the author and/or publisher thereof are not in anyway associated with, and are not authorized to act on behalf of any of the manufactures listed in this book. All registered trademarks are the property of their owners. The publisher reserves the right to revise this publication or change its content from time to time without obligation to notify any persons of such revision or changes.

Edited By: James L. Danko

Artwork: James L. Danko© 2008

Layout By: James L. Danko

Computer Assistance: Yoshiro ([www.yoshiro.com](http://www.yoshiro.com))

Printed in U.S.A

Publisher LuLu.com

ISBN: 978-0-557-02780-4

Second Edition 2008

All translations from original Japanese text to English completed by James Danko.

Disclaimer: All translations from one language to another can involve technical errors. The author has found mistakes in the original Japanese text. The best suitable English vocabulary has been chosen by the author.

Credits: I would like to thank the Subaru Motors Corporation (Japan) for their part in supplying required information.

Credits: I would like to thank Yoshiro for all his computer technology to make these books happen. His computer graphics and technology is simply the best. [www.yoshiro.com](http://www.yoshiro.com)

Subaru™ Sambar© and all copyrights of said trademarks are property of Subaru Corp, Japan. Subaru is a division of Fuji Heavy Industries Co. Ltd.

## Introduction

Due to the high request for English version manuals on Japanese mini trucks & Vans, we are publishing wide variety information to provide the mini truck community with the ability to maintain their vehicles.

Japanese mini trucks & vans are produced only for the Japanese market. Therefore, all original manuals are only available in Japanese. This is the first of these books written in English.

Service manuals are not sold to the public in Japan, as in many countries. You must be a new car dealer to receive them. We have a few hundred in stock. We do not sell manuals from our own library. We will start publishing them in English (Translated) and our own original versions.

Translating from Japanese is by no way an easy task. It is a very time consuming effort. This book due to its high volume of diagrams took one year to complete.

This book or manual is for the professional mechanic. Simple items as how to change a spark plug, or an air-filter are not in this book. It is written in Factory Service Manual style. It is full of diagrams and schematics that are easily understood by a professional mechanic. How to do an engine overhaul using the correct parts sizes, measurements, torque, etc. Complete diagrams of all major parts, including body. You will have the same information as the Subaru Factory techs have. This book is written by a mechanic, for mechanics.

We have manuals for all Japanese manufactures. It's a time consuming process, please check our web page frequently as we post more information.

For more information please visit our home page at [www.yokohamamotors.com](http://www.yokohamamotors.com)  
Comments or information on this book please email to [info@yokohamamotors.com](mailto:info@yokohamamotors.com)

# Contents

## Chapter 1

Vehicle Identification.....Page 11~19

1. VIN Class Breakdown
2. Engine & Transmission Decoding
3. Engine-Transmission Combination Charts
4. VIN & Code Locations
5. Jacking Positions
6. Tire Size & Air Pressure Guide

## Chapter 2

General Maintenance & Tune Up.....Page 20~35

1. Engine Specifications
2. Testing Equipment
3. Battery & Coolant
4. Oil & Filter Including Supercharger
5. Air & Fuel Filter
6. Spark Plugs
7. V- Belts
8. Valve Adjustment
9. Vacuum Hose
10. Distributor Point Settings
11. Timing
12. Idle Setting
13. CO-HC Levels and Adjustment
14. Engine Vacuum & Troubleshooting
15. Main Relay Location Guide

(Continued)

## Chapter 3

Suspension.....Page 37~46

1. Front Suspension Components
2. Rear Suspension Components
3. Front and Rear Alignment
4. Camber & Caster Settings
5. Front Strut Removal & Replacement
6. Traverse Link
7. Rear Shock Absorber Remove & Replace

## Chapter 4

Steering.....Page 47~60

1. Specifications and Diagram
2. Exploded Component View (Steering Column)
3. Exploded Component View (Rack & Pinion)
4. Steering Column Removal/Disassembly/Assemble/Install
5. Steering Gear Box
6. Rack & Pinion Overhaul
7. Tie Rods

## Chapter 5

Brake System.....Page 61~76

1. Bleeding Brake System (Air)
2. Parking Brake Adjustment
3. Master Cylinder System
4. Brake Booster
5. Disk Brake & Caliper Overhaul
6. Rear Brake Drum System Overhaul
7. Parking Brake Cable System
8. Complete Brake Line System

(Continued)

## Chapter 6

Engine Coolant & Cooling System.....Page 77~88

1. Coolant System Specifications and Capacities
2. Coolant System Components Diagram
3. Coolant System Radiator Components Diagrams
4. Engine Room Fan System
5. Troubleshooting Chart
6. Coolant Line Diagrams (Chassis Mount)
7. Water Pump
8. Engine Room Fan Circuit
9. Cooling Master Control Unit & Circuit

## Chapter 7

Air – Fuel System – Exhaust .....Page 89~106

1. Air Intake System (Carbureted)
2. Air Intake System (Fuel Injected-Supercharged)
3. Air Cleaner and Air Intake Sensor
4. Intake Manifold (Carbureted)
5. Complete Fuel System Specifications
6. Carburetor Adjustments and Breakdown
7. Fuel Tank
8. Fuel System EMPi (Fuel Injected Vehicles)
9. Fuel Pump-Pressure Regulator-Knock Sensor
10. Fuel Injection-Air/Water Temp Sensors-O2 Sensor
11. Exhaust Truck-Van

## Chapter 8

Starter & Alternator.....Page 107~112

1. Starter Specifications –Hitachi Series-Mitsubishi Series
2. Starter Overhaul Diagrams
3. Alternator Specifications- Mitsubishi Series-Denso Series
4. Alternator Diagram

(Continued)

## Chapter 9

Engine & Transmission Removal.....Page 113~122

1. Complete Engine and Transmission Removal

## Chapter 10

Engine Overhaul.....Page 123~148

1. Engine Disassembly
2. Block Inspection
3. Cylinder Inspection
4. Piston Inspection Including Oversize Pistons
5. Block Deck-Journal and Bore Sizes
6. Piston Rings and Installation Positioning
7. Connecting Rods
8. Crankshaft & Journals
9. Journal Details and Clearances
10. Crankshaft Oil Seals
11. Block Assembly
12. Piston Installation
13. Oil Pump
14. Cylinder Head and Timing Belt System
15. Valve Rocker Assembly
16. Camshaft Specifications and Clearances
17. Camshaft Installation & Oil Seal
18. Cylinder Head – Valve Springs- Valves
19. Valve Guides- Valve Details
20. Oil Pump Overhaul
21. Oil Pressure Switch

(Continued)



## Chapter 11

Transmission and Differential 2WD – 4WD.....Page 149~170

1. Gear Shift System
2. TM 60 Series 2WD Clutch Housing – Main Case – Side Case
3. TM 60 Series 2WD Main Shaft-Drive Pinion- Reverse Idler Shaft
4. TM 60 Series 2WD Shift & Select System
5. TM 60 Series 2WD Differential
6. TM 60 Series Selective 4WD Transmission Case Assembly
7. TM 60 Series Selective 4WD Shifter and Selector System
8. TM 60 Series Selective 4WD Drive Pinion-Main Shaft-Reverse Idler
9. TM 60 4WD Differential
10. TM 60 4WD Diff-Lock Differential Option
11. TM 60 4WD Diff-Lock Side Cover Assembly
12. TM 60 Selective 4WD Transfer Extension
13. Clutch & Pressure Plate Specifications
14. Clutch System Diagram
15. Clutch Cable Adjustment
16. Release Bearing and Fork
17. Clutch Disk – Flywheel – Pressure Plate
18. Clutch Assembly
19. Axle Shaft System
20. Axle Shaft Identification and Type

## Chapter 12

Electrical Diagrams and Schematics.....Page 171~

1. General Harness Locations
2. Truck Full Main Harness and Connection Codes
3. Connection Codes Explained (Truck-Van)
4. Van Full Main Harness and Connection Codes
5. Engine & Transmission Harness and Connections
6. Engine & Transmission Harness Code Breakdown
7. Front Component (Main) Harness Dash-Front Lighting
8. Front Component (Main) Connector Breakdown

(Continued)

## Electrical Schematic Breakdowns

1. Turn Signal & Hazard
2. Stop Lamp Circuit
3. Lighting Circuit (Headlights-Running Lights)
4. Lighting Circuit Tail Assemblies & Illumination Lamps
5. Engine Control and Fuel Pump Circuits
6. Charging System
7. Engine Room and Radiator Fan (Van & Special Trucks)
8. Engine Radiator Fan (Basic Vehicle)
9. Radio (Audio) Circuits and Cigarette Lighter
10. Fuel Gage & Sending Unit
11. Full Time 4WD Control Circuits
12. Selective 4WD Control Circuits
13. Diff-Lock Control Circuits
14. EMPi Engine Control Management System Part 1 (Fuel Injection)
15. EMPi Engine Control Management System Part 2 (Fuel Injection)
16. Windshield Wiper System Front and Rear
17. Rear Defogger Circuit


# Chapter 1

## Vehicle Identification

1. VIN Class Breakdown
2. Engine & Transmission Decoding
3. Engine-Transmission Combination Charts
4. VIN & Code Locations
5. Jacking Positions
6. Tire Size & Air Pressure Guide

## VIN Class Brakedown


### Subaru Truck-Van Series K-Vehicles




YokohamaMotors.com [English]

## Engine & Transmission Series

### Engine Decoding



### Transmission Decoding



www.yokohamamorots.com [English]

## Engine & Transmission Combinations Truck and Van

Vehicle Type			Series	Engine	Trans	Drive	Vehicle Code	Engine Code	Trans Code	Added Notes		
T R U C K	N O R M A L	STD	V-KS3	NA	5MT	2WD	KS3A11M	EN07CVN1AO	TM601AA1AA			
			V-KS3				KS3A31M	EN07CVN1AO	"			
			V-KS4		EL+5MT	4WD	KS4A31N	EN07CVU1AO	TW601BA1AA TW601BA1DA	D/L+A/F		
		SDX	V-KS3	NA	5MT	2WD	KS3A32M	EN07CVN1AO	TM601AA1AA			
			V-KS4		EL+5MT	4WD	KS4A32N	EN07CVU1AO	TW601BA1AA TW601BA1DA	D/L+A/F		
			Bis Use		V-KS3	NA	5MT	2WD	KS3A3AM	EN07CVN1AO	TM601AA1AA	
	R O O F	SDX   SC	V-KS3	SC	5MT	2WD	KS3A32K	EN07YVN1AO	TM601AB1AA			
			V-KS3		ECVT	2WD	KS3A32L	EN07YVD1AO	TB401NB1AA			
			V-KS4		EL+5MT	4WD	KS4A32J	EN07YVU1AO	TW601BB1AA TW601BB1DA	D/L+A/F		
	H R O O F	SDX	V-KS3	NA	5MT	2WD	KS3H32M	EN07CVN1AO	TM601AA1AA			
			V-KS4		EL+5MT	4WD	KS4H32N	EN07CVU1AO	TW601BA1AA TW601BA1DA	D/L+A/F		
	Panel Van High-Roof		STD	V-KV3	NA	5MT	2WD	KV3H81M	EN07CVN1AO	TM601AA1AA		
V-KV4				EL+5MT		4WD	KV4H81N	EN07CVU1AO	TW601BA1AA			
V A N	N O R M A L	2Seat	V-KV3	NA	5MT	2WD	KV3A5JM	EN07CVN1AO	TM601AA1AA			
			V-KV3				KV3A51M	EN07CVN1AO	TM601AA1AA			
			V-KV4		EL+5MT	4WD	KV4A51N	EN07CVU1AO	TW601BA1AA			
		4Seat	SDX	V-KV3	NA	5MT	2WD	KV3A52M	EN07CVN1AO	TM601AA1AA		
			2 Seat	STD	V-KV3	NA	5MT	2WD	KV3H5JM	EN07CVN1AO	TM601AA1AA	
				5 Door	SDX	V-KV3	NA	5MT	2WD	KV3H52M	EN07CVN1AO	TM601AA1AA
	V-KV4	EL+5MT	4WD			KV4H52N		EN07CVU1AO	TW601BA1AA			
	R O O F	5 Door	SDX   SC	V-KV3	SC	5MT	2WD	KV3H52K - W	EN07YVN1AO	TM601AB1AA		
				V-KV3		ECVT		KV3H52L - W	EN07YVD1AO	TB401NB1AA		
			V-KV4	SC	EL+5MT	P/T 4WD	KV4H 52J	EN07YVU1AO	TW601BA1AA			
			V-KV4		ECVT	F/T 4WD	KV4H52S	EN07YVR1AO	TT401PB1AA			


## Engine & Transmission Combinations

Vehicle Type		Series	Engine	Trans	Drive	Vehicle Code	Engine Code	Trans Code	Added Notes	
T R Y	H I G H T  R O O F	R J	V-KV3	NA	5MT	2WD	KV3H54M	EN07CVN1AO	TM601AA1AA	
								EN07CVN1AD	TM601AA1AA	Ultra Heater
					KV3HC4M	EN07CVN1AO	TM601BA1AA	Dias-II		
						EN07CVN1AD	TM601BA1AA	PRD Roof U Heater		
			V-KV4	EL+ 5MT	P/T 4WD	KV4H54N	EN07CVU1AO	TW601BA1AA		
						KV4HC4N	EN07CVU1AO	TW601BA1AA	Dias-II	
						TW601BA1DA		D/L+A/F		
			X S	V-KV3	SC	5MT	2WD	KV3H56K	EN07YVN1AO	TM601AB1AA
		KV3HC6K						EN07YVN1AO	TM601AB1AA	Dias-II
		ECVT				KV3H56L	EN07YVD1AO	TB401NB1AA		
						KV3HC6L	EN07YVD1AO	TB401NB1AA	Dias-II	
		V-KV4		EL+ 5MT	F/T 4WD	KV4H56R	EN07YVU1AO	TY601CB1AA		
						KV4HC6R	EN07YVU1AO	TY601CB1AA	Dias-II	
						ECVT	KV4H56S	EN07YVR1AO	TT401PB1AA	
							KV4HC6S	EN07YVR1AO	TT401PB1AA	Dias-II
		X V	V-KV3	SC	5MT	2WD	KV3HC7K-J	EN07YVN1AO	TM601AB1AA	Production Roof
ECVT	KV3HC7L-J						EN07YVD1AO	TB401NB1AA	Production Roof	
V-KV4	EL+ 5MT		F/T 4WD		KV4HC7R-J	EN07YVU1AO	TY601CB1AA	Production Roof		
					ECVT	KV4HC7S-J	EN07YVR1AO	TT401PB1AA	Production Roof	

W : Rear Wiper                      Maker    { D/L : Rear Diff Lock  
 J : Two Tone + Bronze Glass      Option   { A/F : Free Axle

www.yokohamamotors.com [English]


## Vehicle VIN Engine & Transmission Number Location




Vehicle Series	Trans Code Series #
KS 3 001301	TM60 953208~
KS 4 001301	TW60 953210~
KV 3 001301	TY 60 953211~
KV 4 001301	TB 40 136141~
	TT 40 136137~



## Jacking Locations



## Jacking Positions



# Tires

## Wheel Balancing - Tire Pressure - Tire Rotation

**Wheel Balance Weights**


**Note: Weight Increments Below**

Weight (G)	Balance Weight Part#
5	723141290
10	723141300
15	723141310
20	723141320
25	723141330
30	723141340
35	723141350
40	723141360
45	723141370
50	723141380


**Note: All Weight Mesurments In Grams**

**Tire Rotation**

**Bias Ply Tires Rotation**



**Radial Tire Rotation**



## Tire Pressure

Tire Air Pressure Chart				(kg/cm <sup>2</sup> )			
Vehicle Type			Tire Size	Normal		Maximum	
				Front	Rear	Front	Rea
Truck	350kg	2 WD	5.00-12- 4 PR/6PR	2.0	2.2	2.2	3.0
		4 WD	145R12- 6 PR	2.0	2.2	2.2	3.0
VAN	350kg	2 WD	5.00-12- 4 PR/ 6 PR	2.0	2.4	2.2	3.0
		4 WD	145R12- 6 PR	2.0	2.2	2.2	3.0
Try	200kg	2 WD	145SR12	2.0	2.0	2.2	2.2
		4 WD	155SR12	1.8	2.0	2.0	2.2

www.yokohamamotors.com [English]

## Chapter 2


### General Maintenance & Tune Up

16. Engine Specifications
17. Testing Equipment
18. Battery & Coolant
19. Oil & Filter Including Supercharger
20. Air & Fuel Filter
21. Spark Plugs
22. V- Belts
23. Valve Adjustment
24. Vacuum Hose
25. Distributor Point Settings
26. Timing
27. Idle Setting
28. CO-HC Levels and Adjustment
29. Engine Vacuum & Troubleshooting
30. Main Relay Location Guide


## Engine Basic Specifications

Specifications		
Series	EN07C (NA)	EN07Y (SC)
Cylinder	4	←
CAM	SOHC	←
Engine (cc)	658	←
Bore/Stroke (mm)	56.0×66.8	←
Compression	9.8	8.3
HP Rating (PS/rpm)	40/6,500	55/6,200
Torque (kg-m/rpm)	5.5/3,500	7.1/3,800
Fuel	Carburated	EFI
Ignition	STD	Crank Sensor ECU Controlled
Firing Order	# 1 - 3 - 4 - 2	←
Forced Induction	—	Super Charged

**EN07C**



**EN07Y**




www.yokohamamotors.com [English]

## Engine Inspection & Testing Tools

ST	4985454000	Oil Filter Wrench	Oil Filter Replacement
	-----	Battery Tester	
	GU-51C	Compression Gage	Engine Compression
	-----	Timing Light	Engine Timing
	498307900	Subaru Select Monitor	Engine Test
	498348300	Cartridge	For Select Monitor
	-----	Thickness Gage	Valve Adjustment
	NA	NA	NA

ST= Service Tool




# Maintenance Check

## Battery


### Battery Maintenance Check

1. Remove Battery Cover
2. Disconnect Battery Terminals
3. Remover Batter
4. Inspect Side of Battery for High-Low Level
5. Fill to Proper Level
6. Use Battery Tester To Check Volt 11.5~14V
7. Use Battery Fluid Tester
8. Clean Battery Terminals
9. Install Battery
10. Start Vehicle




## Coolant

### VAN



### Truck



### Coolant Inspection

1. Check Reserve Tank for Proper Level  
Note: If Tank is Dirty Remove and Flush
2. Fill Tank to Proper Level  
Note: If Coolant Replacement is Scheduled Drain Entire System & Replace with New Coolant. Never Re-Use Coolant.

### Coolant-Water Ratio

	2WD	4WD
Coolant	30%	50%
Temperature Range	-8°C (-15°C)	-28°C (-35°C)


### Coolant Inspection

Check	Monthly
Replace	40,000K or 2 Years

# Maintenance Check

## Oil Level and Oil Change Including Filter


1. Open Engine Cover
2. Pull Out Engine Oil Dip Stick (Handle Yellow)
3. Wipe Off Oil and Repeat
4. Check Oil Level and Must be between L&F
  - Note: If Oil is Below "L" or Dirty Proceed to Change Oil.
  - Note: If Oil is Clean and a Bit Low Add Fresh Oil to Proper Level



### Engine Oil

Use Straigh 30W For Multi-Season  
 Note: For Cold Weather Areas Use 7.5~30W  
 Note: Do NOT Use Heavy Weight 50W+


Oil Capacity  
 Oil Only: 2.8 Liters (MT) 2.9 Liters (ECTV)  
 Oil & Filter: 3.0 L (MT) 3.1 L (ECTV)



### Oil Filter Part

Subaru Part Number  
 #15208-KA0120 #15208-KA010  
 Cross Number  
 Mitsubishi #MD134953  
 Mazda #B6Y1-14-302

## Super Charger Oil Inspection



1. Remove Plug "B" First to Ceck Oil Level.  
 Note: If Oil Level is In Range it is Not Necessary to Remove Plug "A"



Oil	Shell MSC Gear Oil
Plug A Torque	2.5±0.2kg-m
Plug B Torque	1.2±0.2kg-m



## Maintenance Check

### Air Filter

1. Remove Engine Cover
2. Un-Clip Plastic Air Cleaner Cover
3. Remove Air Cleaner



4. Vacuum or Wipe Out Air Cleaner Case
5. Use an Air Pressure Cleaner to Clean Filter

Note: Filter Should be Changed Every 20,000 Kilometers or Every 6 Months.

### Fuel Filter


Note: Fuel Filters Should be Changed Once a Year or 20,000 Kilometers

Caution: EFI vehicles Fuel System is Under High Pressure.


EFI Engines: Disable Fuel Pump, Start Engine and Run Until Out of Fuel. Disconnect (-) Battery Connection. Remove and Replace Filter. Engage Fuel Pump and Re-Connect (-) Battery Connection. Start Engine and Observe For any Leaks.

Carbureted Engines: Remove & Replace Filter  
Caution: Never Smoke Around Fuel, No Open Flames Within 50 Meters

Carbureted Vehicle



EFI Vehicle




Fuel Filter

# Maintenance

## Spark Plugs

Spark Plugs are Recommended to be Changed Every 10,000 Kilometers.

Spark Pugs Can be Your Best Indication of the Inside of Your Engine.




### Appearance Indicators

**Normal:** Gayish Color-Replace at Recommended Time Period

**Oil Deposits:** Oily or wet Appearance  
Remove Engine and Overhaul


**Burnt:** Visually Burnt or Insulator Cracked  
Incorrect Heat Range

### Gap Measurement Using a Feeler Gage



Note: Make Sure Engine Is Cool When Removing Spark Plugs

1. Open Engine Cover
2. Remove (One Wire at a Time) Plug Wire
3. Remove Old Plug (Discard)
4. Set Gap to New Plug and Install
5. Repeat Step for all 4 Cylinders



NGK	Nippon Denso	Gap (mm)
ZFR 6 G	K20DTR-S11	1.0~1.1
ZFR 5 G	K16DTR-S11	1.0~1.1

Note: Due to Engine Constant High Revelutions It is Recommended to Change Spark Plugs Every 10,000 Kilometers


# Maintenance

## V-Belts


All V-Belts Should be Periodically Inspected for Cracks and Wear.

Note: All V-Belts Must be Changed at 100,000 Kilometers



Carbureted Engine (No Accesories)




Carbureted Engine: AC Option



EFI Equiped Engines



EFI Supercharged Engine




# Maintenance


## Valve Adjustment

Set the Crankshaft Timing Mark to Zero Degrees on the Compression Stroke as Indicated on the Picture Diagrams Below.


Carbureted (No Options)



Carbureted AC Equipped




EFI Supercharged



Note: Set Valve Adjustment With Engine Cold (Ambient Temperature)

1. Make Sure Engine is at TDC Compression Stroke.
2. Remove Valve Cover
3. Loosen Adjustment Nuts
4. Using a Screwdriver Loosen Intake and Exhaust Adjustment Screws

Set Cold	
Intake	$0.15 \pm 0.02\text{mm}$
Exhaust	$0.20 \pm 0.02\text{mm}$
Nut Torque	$0.9 \pm 0.1\text{kg-m}$



Thickness Gage

5. Set #1 Intake and Exhaust, #2 Intake, #3 Exhaust.
6. Turn the Engine One Rotation.
7. Set Remaining Valves to Specifications
8. Torque Retainer Nuts
9. Using a New Gasket Attach Valve Cover
10. Drain Oil and remove Oil Filter
11. Add New Oil and Filter
12. Run Engine at Various Idle Speeds 10 Min.
13. Test Drive


## Maintenance

### Non-AC Vehicle Vacuum Hose and Point Settings

#### Vacuum Hose Inspection

Note: Vacuum Hoses Over The Years Become Dry and Cracked. This Leads to System Balance Trouble. It is an Important Step To Follow The Provided Diagrams Per Vehicle. Look for the Sticker Near The Engine Compartment

Vacuum Hose Diagram (Per Vehicle)



Note: Points Should be Changed Every 24,000 Kilometers or 2 Years

#### Point Dwell

Limit	Mitsubishi	49° ~ 55°
	DENSO	49° ~ 55°

#### Point Gap (mm)

Limit	Mitsubishi	0.45 ~ 0.55mm
	DENSO	0.4 ~ 0.5mm

Note: When Changing Points Make Sure To Grease The Cam With Fresh Lithium White Grease.

#### Point Spring Lift Pressure

Limit (Range)	Mitsubishi	450 ~ 600g
	DENSO	400 ~ 550g

#### Condensor


Limit (Range)	Mitsubishi	0.243 ~ 0.297 $\mu$ F
	DENSO	0.225 ~ 0.275 $\mu$ F

Note: Condensers Should Be Changed Every 48,000 Kilometers or 4 Years


# Maintenance

## Timing Carbureted Vehicle

- Caution: Beware of Moving Fan**
1. Loosen Distributor Hold Down Bolt
  2. Warm Engine
  3. Remove and Plug Vacuum Hose
  4. Using Timing Light Check Timing
  5. Adjust as Necessary
  6. Tighten Hold Down Bolt
  7. Attach Vacuum Hose




Non-AC Vehicle Timing Light




Engine Rotation

AC Equipped Vehicle



Engine Rotation



Distributor Rotation L~R

Timing	(BTDC /rpm)
NA Carb	6° /800

**Note: If Timing is Erratic Check Points and Distributor Cap. Also Check For Bad spark Plug Wires**

**Spark Plug Wires: Must be Changed Every 60,000 Kilometers**

**Point Adjustment: Every 12,000 Kilometers**

**Cap Replacement: Every 24,000 Kilometers**


## Maintenance

### Non-AC vehicle Idling and CO-HC Levels

#### Idling Setting

1. Warm Engine to Operating Temperature
2. Confirm Timing is Set Correct  
(See Timing Settings in Previous Steps)
3. Set Idle By Adjusting Idle Screw

Idle RPM	800±50rpm
----------	-----------



Throttle Adjustment Screw


**Caution:** Always Beware of The Fan With The Engine Running

#### CO-HC Levels

Note: Setting The Adjustment Screw Can Take Up To 5 Min to Take Effect

#### CO-HC Level Chart

CO(%)	1.5±0.5
HC(ppm)	1000 or Below



Idle Adjustment Screw

1. Warm Engine To Operating Temperature
2. Put CO-HO Tail Pipe Sniffer and Check Reading
3. If Adjustment is Required Wait up to 5 Min For a Reading to Take Effect.

Note: If All Timing Specifications Are Correct and CO-HC Can Not be Adjusted by The Idle Adjustment Screw The Carburetor Must be Replaced or Rebuilt.

Note: See The Following Page For More Setting Information

# Maintenance

## Carbureted

### CO-HC (Continued)

Part	RPM	CO Level
Idle Adjustment Screw	Turn Right	Lower
	Turn Left	Higher

Note: Idle Adjustment Screw Has a CO Adjustment Level of 1.5(+/-) 0.5%


## AC Equipped Carbured Vehicle

### Fast Idle

AC Equipped Fast Idle Circuit is Set to 1050 (+/-) 50 RPM

Note: Make Sure AC Switch is [ON]

Fast Idle Adjustment Screw	Turn	Engine RPM
Fast Idle Adjustment Screw	Turn Right	Idle Up
	Turn Left	Idle Down




Fast Idle Screw

## EFI Supercharged

### Timing

Note: EFI Engine Timing is Set by Computer Hand Held Computer is Necessary


Read Memory Connector (Black)



Test Mode Connector (Green)

Select Monitor Connector (Yellow)

Note: The Timing Light Method Can be Used by By-Passing the Computer. If Setting the Timing Directly The Computer May Re-set Itself.



Set To: BTDC 10° /800rpm

Note: Most Timing Errors On Computer Controlled vehicles Are Vacuum Issues. Check for Leaks in Vacuum Lines. The Computer Will Re-Adjust Itself If a Vacuum Line is Found Broken and Repaired.




# Maintenance

## Idle Vacuum


1. Warm Engine to Operating Temperature
2. AC Equiped Vehicles, Attach Vacuum Gage to AC Idle Nipple. 4WD Vehicles Attach Gage to Actuator Nipple.
3. Take Measurements and Compare to Chart Listed Below.

NA Vehicle



AC Fast Idle Nipple

SC Vehicle



4WD Actuator Nipple

### Vacuum Specifications

Vacuum (mmHg)	NA Vehicle		430~530
	EFI	MT	350~470
	SC	ECVT	330~450













Note: Vacuum measurements Below The Readings Above Signify a Leak in The System

### Troobleshooting

Vacuum Level	Cause
Too Low	<ol style="list-style-type: none"> <li>1. Intake Gasket Leak</li> <li>2. Ignition Timing</li> <li>3. Valve Guide Worn</li> <li>4. Valve Seat Worn</li> <li>5. Bypass Valve Gasket</li> <li>6. Supercharger Gasket (SC)</li> <li>7. Carburetor Base Gasket</li> <li>8. Carburetor</li> <li>9. Vacuum Hose Leak</li> </ol>
Too High	Timing Setting or Valve Adj
Fluctuation	Timing Miss or Bad Carb

# Maintenance

## Main Relay Locations

 <p>Turn-Hazard Wiper INT Unit</p>	 <p>Cooling Fan Unit</p>	 <p>Main Relay Fuel Pump Relay (Van-Try)</p>
 <p>Relay 4WD Diff-Lock</p>	 <p>ECVT Unit Shift Lock Unit</p>	 <p>EMPi Unit (VAN-Try)</p>
 <p>AC Control Unit</p>	 <p>Fuel Pump Relay Main Relay (Truck)</p>	 <p>Rear Wiper Unit (Van-Try)</p>
 <p>Door Lock Timer</p>	 <p>EMPi Unit (Truck)</p>	 <p>Sun Roof Unit (Van)</p>

[www.yokohamamotors.com](http://www.yokohamamotors.com) [English]

## Chapter 3


### Suspension

8. Front Suspension Components
9. Rear Suspension Components
10. Front and Rear Alignment
11. Camber & Caster Settings
12. Front Strut Removal & Replacement
13. Traverse Link
14. Rear Shock Absorber Remove & Replace

**Note:** Steering Components and Gear Box Located in Steering Chapter 4


# Suspension

## Components (Front)



# Suspension

## Components (Rear)



# Suspension

## Alignment

### Front Alignment Specifications

Camber	1° +-.45'
Caster	3° 50' +-.1°
Toe-In	IN 1+-3
Side Slip	0+-3


### Rear Alignment Specifications

Camber	0'50' +-.12
Caster	IN 1+-3
Toe-In	IN +-.3

Note: Make Sure Tires Are Properly Inflated Before Working on Alignment Settings

1. Loosen Tie Rod Lock Nut
2. Adjust to the Above Chart Diagram
3. Tighten Lock Nuts

### Front Toe-In




Tie Rod Torque = 7+-1kg.cm

### Rear Toe-Out

Note: See Chart to Left For Toe Settings

Lock Nut Torque = 6+-1kg.cm




# Suspension

## Camber and Caster Setting

Note: Before Setting Caster & Camber Make Sure Tires Are Properly Inflated

Use Service Tool ST 922640000 Camber Gage Adapter




	Front	Rear
Camber	1' ± 45'	0' 50' ± 45'
Caster	3' 50' ± 1'	—


# Suspension

## Front Strut

1. Set Side Brake
2. Jack Vehicle, Remove Tire
3. Remove Brake Hose From Strut




4. Remove Housing Support Bolt



5. Pull Down on Housing to Separate Strut. Use Rubber Hammer.


6. Remove Upper Attachment Bolts
7. Remove Strut




### Strut Disassembly

Caution: Spring is Under Extream Pressure

1. Use a Coil Spring Compressor and Compress Coil Spring.



2. Use a Hexagon Wrench to Hold Strut Rod While Using a Box End Wrench to Loosen.



3. Seperate Mount
4. Slowly Release Coil Spring Compressor and Remove Coil Spring

Note: Wear Saftey Glasses When Working With Coil Springs

5. Remove Upper Spring Seat and Dust Cover



# Suspension


## Front Strut Assembly

### Assembly


Note: Make Sure All Surfaces Are Clean Before Assembly. Dirt Can Scratch Piston Surfaces Destroying The New Strut

Note: Do Not Re- Use Self-Lock Nut Replace With New Nut


Assemble With Marks Lined Up



Self Lock Nut	$6.5 \pm 0.5 \text{ kg-m}$
---------------	----------------------------




### Install Strut





T  $5.5 \pm 1 \text{ kg-m}$

Place Lock Mark Seal




# Suspension


## Transverse Link




T  $3.0 \pm 0.5 \text{ kg-m}$



T  $4.5 \pm 1 \text{ kg-m}$



T  $12.0 \pm 1.5 \text{ kg-m}$




T  $10.5 \pm 1.5 \text{ kg-m}$

# Suspension

## Rear Shock


### Removal

1. Remove Rear Axel Shaft




2. Jack Rear of Vehicle
3. Remove Tire
4. Remove Shock Attachment Bolts

Upper Bolt



### Inspection & Replacement


Note: Inspect Shocks for Oil Leaks  
Leak Detected Replace



1. Replace Shock
2. Attach Bolts and Set Torque
3. Attach Drive Axel
4. Attach Tire
5. Lower Vehicle and Test Drive

$T2$   $6 \pm 1$  kg-m

$T1$   $4 \pm 0.8$  kg-m



## Chapter 4


### Steering

8. Specifications and Diagram
9. Exploded Component View (Steering Column)
10. Exploded Component View (Rack & Pinion)
11. Steering Column Removal/Disassembly/Assemble/Install
12. Steering Gear Box
13. Rack & Pinion Overhaul
14. Tie Rods

## Steering

### Specifications


G E A R  B O X	Steering Wheel	Outer (mm)	$\phi 370$		
		Turns	3.8		
	Angle	Inner	$36^{\circ} 25'$		$+ 1^{\circ} 30'$ $- 2^{\circ} 30'$
		Outer	$33^{\circ} 10'$		$+ 1^{\circ} 30'$ $- 2^{\circ} 30'$
	Turning Radius (Meters)		3.9		
	Steering Type		Rack & Pinion		
	Ratio		19.8		
	Lubrication Grease		Bearing Grease		



Steering Diagram


# Steering

## Exploded View



# Steering


## Exploded View (Rack & Pinion)




# Steering

## Steering Column Removal


1. Disconnect (-) Battery Connection
2. Remove Steering Wheel Center Pad




3. Center the Wheel and Remove Hold Down Nut.  
Note: Make Note of Aignment Marks




4. Remove Wheel and Then Remove Column Cover Attachment Screws




5. Disconnect Combination SW Electrical Connectors
6. (ECTV Vehicle)  
Remove AT key Interlock Solinoid Electrical Connector



7. Remove SW Assemblies



8. Remove U-Joint Cover






# Steering

## Steering Column Removal (Continued)


9. Remove U-Joint Lower Bolt




10. Remove Upper Column Attachment Bolts and Remove Column

### Shaft Removal


1. Remove U-Joint Attachment Bolt



2. Remove Snap Ring and Separate Parts



3. Separate Parts, Clean and Inspect




# Steering

## Assembly


Note: Assemble in Reverse Order  
Use Torque Guild as Listed

Assembly Grease: Lithium or Bearing Grease



T  $2.4^{+0.1}_{-0.2}$  kg-m


## Steering Assembly




# Steering

## Steering Gear Box

1. Remove Floor Cover (3) Screws




2. Remove Rubber Coupling Nuts




3. Raise Vehicle

4. Remove Under Cover




### Removal

5. Remove Drag Link From Yoke



6. Remove Air-Vent Tube From GearBox Nipple

7. Remove Gear Box Attachment Bolts and Take Out Gear Box




# Steering


## Rack & Pinion Rebuild

Note: Use Paint to Mark Pinion Location


1. Carefully Place Unit in a Vise and Pinch Yoke. Remove Yoke.




2. Remove Boot Cover and Discard  
Note: Always Replace Boot With New Parts
3. Remove Stopper




4. Slowly Back Out Adjustment Screw and Remove Parts. Place in Cleaning Tray



5. Remove Oil Seal
6. Remove Snap Ring



7. Slowly Pull Out Pinion Assembly
8. Remove Rack From housing




## Steering


### Rack & Pinion (Continued)

#### Pinion Bearing

9. Remove Snap Ring



10. Using a Press, Press Out Pinion From Bearing. Discard Bearing. Use Only New Bearing for Assembly



Note: Do Not Re-Use Snap Rings, Oil Seals, or Bearings.


# Steering

## Rake & Pinion (Assembly)

### 1. Press On New Bearing

Note: Use Only New Bearings and Rubber Seals

### 2. Cover Unit in Light Bearing Grease. Place Snap Ring in Place.




### 3. Grease Up the Gear Box Inside Before Assembling Parts


### 4. Grease Rack Unit and Slide Into Place

### 5. Take Care Not to Damage Pinion Gear Teeth While Assembling.

Assemble Unit and Check For any Binding Issues. Make Sure Unit is Dirt Free and All Surfaces Covered With Fresh Bearing Grease



### 6. Take Caution When Assembling Pinion Unit. Pay Attention to Alignment Marks.




# Steering


## Rack and Pinion Assembly

### 9. Attach New Oil Seal and Snap Ring

Note: Do Not Re-Use Oil Seal & Snap Ring




### 10. Use a Dial Gage and Check for Free Travel. Allowance: 10 Kilograms=0.3mm



Limit	0.3mm
-------	-------

### 11. Assemble Unit and Set Initial Back Lash to within: 0.083 (mm)



Lock Nut Torque  $\boxed{T}$  3.0~5.0kg-m


# Steering

## Assembly


### Final Assembly

Note: Never Re-Use Boots or Other Rubber Seals

Attach New Boots and Clean Unit For Installation




Place In a Vise and Install Yoke




Attach Unit Assembly and Torque To Spec Listed Below

Attach Vent Tube



Attach Drag Link And Yoke, Torque to Spec.






# Steering


## Tie Rod Ends

1. Lift Front of Vehicle and Remove Tires
2. Remove Under Cover and Guard




3. Remove Inner Tie Rod Cotter Pin and Castle Nut.


Note: Cotter Pin Can Not Be Re-Used



4. Use a Puller or Similar Tie Rod Removal Tool to Remove Tie Rod End



Note: Tie Rod Maximum Measurement as in Diagram Below is 389.6mm



Note: After any Modifications and or Repairs to Front End Components Will Require Front End Alignment Check

Note: Tie Rod Ends do Not Have Grease Nipples. Maintenance Free

# Chapter 5


## Brake System

9. Bleeding Brake System (Air)
10. Parking Brake Adjustment
11. Master Cylinder System
12. Brake Booster
13. Disk Brake & Caliper Overhaul
14. Rear Brake Drum System Overhaul
15. Parking Brake Cable System
16. Complete Brake Line System

# Brake System

## Air Bleeding


**Caution:** G-Valve Equipped Vehicles Will Need Bypass Before Bleeding Rear Brakes. See Below Diagram Reference (A). Turn 1 Rotation Open.




**Note:** 2 People Required

Use Chart Below For Order Of Bleeding Valves.

One Service Engineer Pumps Pedal 3 Times, Hold, Bleed Repeat. Repeat Procedure Until Air is Out.




Bleed Air Series Order




## Parking Brake Lever

Parking Brake Lever Has 7~9 Inch Travel Allowance.

Force to Engage No More Than 20kg



**Note:** Remove Side Brake Cover To Access Adjustment Screw




## Brake System

Tools	Snap Ring Pliers	Snap Ring Removal
	Dial Gage	Disk Rotor
	Micrometer	Disk Rotor Thickness
	Air Duster	
Oil	DOT3 - DOT4	

### Master Cylinder

Exploded View



# Brake System



## Master Cylinder Removal

1. Drain Brake Fluid By Attaching Hose To FRONT and REAR Bleed Valves and Pump Master Cylinder Until Dry.

Note: Make Sure Old Brake Fluid Is Disposed of Properly. Never Re-Use Brake Fluid

2. Remove Steering Column  
(See Steering Section)


3. Remove Brake Lines From Assembly




4. Remove Attachment Nuts and Slide Out Master Cylinder

5. Disconnect Feeder Hoses (Wrap With Plastic Bag)


6. Remove Piston Stopper Screw




7. Disassemble Complete Unit and Clean and Inspect. If Cracks are Found Discard Complete Unit



## Brake System




## Brake System




# Brake System

## Brake Booster Replacement

1. Drain Brake Fluid from Reserve Tank
2. Remove Steering Column if Necessary
3. Disconnect Brake Lines to Master Cylinder
4. Remove Master Cylinder
5. Disconnect Brake Pedal




6. Remove the 4 Retaining Bolts
7. Remove Booster



**Note: Brake Boosters Can NOT be Repaired  
They Must be Replace With New**

**Note: Only Adjustment Can be Made to  
Actuator Yoke Length**




Adjustment Bolt



## Brake System

Front Disk Brake Expoded View



- 1. Disk Rotor
- 2. Key
- 3. Key Spring
- 4. Outer Pad
- 5. Pad Cover
- 6. Inner Pad
- 7. Cap

- 8. Air Bleeder Screw
- 9. Lock Pin Bolt
- 10. Caliper Cover
- 11. Outer Sleeve Boots
- 12. Sleeve
- 13. O Ring
- 14. Caliper


- 15. Inner Sleeve Boots
- 16. Oil Seal
- 17. Piston
- 18. Piston Boot
- 19. Boot Retainer

# Brake System

## Caliper Removal -Pad Replacement- Caliper Disassembly

### Caliper Removal

1. Jack Vehicle and Remove Front Tires
2. Remove Union Bolt and Place Hose End into Plastic Bag and Seal.
3. Remove Lock Pin Bolts




Lock Pin Bolts (2)

4. Remove Caliper


### Pad Replacement

1. Remove Pad Cover
2. Remove Key Spring and Key Pad Pin
3. Clean Caliper With Brake Cleaner
4. Replace Brake Pads
5. Assemble
6. Bleed Air From Brake System




### Caliper Disassembly

1. Follow Removal of Caliper Instructions
2. Remove Retainer Key and Pads
3. Place On Wood Block (Not in Vise)
4. Use Air Gun to Push Out Piston
5. Remove Piston and Related Parts
6. Check Cylinder Bore For Cracks or Pitting  
Note: If Pitting or Cracks Found Replace Caliper
7. Clean Thoroughly
8. Use Caliper Rebuild Kit Containing All Necessary Parts




### Exploded View of Caliper



# Brake System

## Brake Pad Inspection -Disk Rotor Inspection

### Brake Pad Thickness




Measure Here

#### Limitations

Pad Thickness	Pass	15mm
	Fail	8 mm


### Disk Run-Out Limits

Note: Set Dial Gage 5mm From Top of Rotor



Brake Disk Run-Out Limit (mm)	0.1
-------------------------------	-----

Note: Measure Thickness 5mm From Top




	Rotor Thickness
Fine	18.0mm
Limit	16.0mm

www.yokohamamotors.com [English]

# Brake System

## Rear Drum Brakes

Exploided View




1. Hold Down Pin
2. Back (Dust) Plate
3. Adjust Hole
4. Wheel Cylinder
5. Auto-Adjust Assembly
6. Adjusting Lever
7. Lever Spring
8. Spring Washer
9. Lever Spring
10. Leading (F) Shoe

11. Upper Shoe Spring
12. Lower Shoe Spring
13. Hold Down Spring Clip
14. Trailing Shoe
15. Parking Lever

# Brake System

## Brake Shoe Inspection

Note: Brake Shoes Should Be Inspected Every 24,000 Kilometers



### Thickness Limitations

Fine	4.4mm
Fail	1.7mm

Fail= Replace


# Brake System

## Wheel Cylinder

## Brake Drum

### Wheel Cylinder Replacement

1. Jack Vehicle
2. Remove Tire
3. Remove Drum
4. Remove Brake Pads
5. Remove Wheel Cylinder Attachment Bolts



6. Rebuilt Wheel Cylinder With Replacement Kit

Note: If Cylinder Bore is Scratched Use Brake Cylinder Hone.


Note: If Cracked Replace Complete Unit

7. Assemble in Reverse Order
8. Bleed Brake System

Note: Never Re-Use Brake Oil

### Brake Drum Diameter

Center Point




### Brake Drum Measurements

Limit	180mm
Fail	182mm

Fail= Replace


# Brake System

## Parking Brake Cable System



### Parking Cable Replacement


1. Remove Rear Consol
2. Back Off Adjustment Screw Until Cable Bracket Is Loose. Separate Cables



Bracket (Cable Retention)

3. Jack up Vehicle Rear End, Remove Tires, Brake Drums
4. Remove Brake Shoes

Parking Lever




Parking Brake Cable

5. Disconnect Cable From Brakes
6. Remove Cables From Vehicle
7. Replace With New Cables

Note: Cables Can NOT be Repaired

# Brake System

Brake Line Full Diagram



[www.yokohamamotors.com](http://www.yokohamamotors.com) [English]



## Chapter 6

### Engine Coolant & Cooling System

10. Coolant System Specifications and Capacities
11. Coolant System Components Diagram
12. Coolant System Radiator Components Diagrams
13. Engine Room Fan System
14. Troubleshooting Chart
15. Coolant Line Diagrams (Chassis Mount)
16. Water Pump
17. Engine Room Fan Circuit
18. Cooling Master Control Unit & Circuit

## Engine Coolant System

### Specifications

Vehicle Type		Carburetor		SC Vehicle		
		Truck	Van	MT	ECTV	
Coolant System Type		Water- Cooled + Electric Fan Assist				
W A T E R  P U M P	Pump Type		Impeller Type			
	Water Output RPM 85°C	2000RPM	20 ℓ /min			
		5000RPM	50 ℓ /min			
		7000RPM	100 ℓ /min			
	Impeller Measurement		φ62			
	Blades		8			
	Pulley		1.05			
	Thermostat					
	Opening Temp *C		78			
	Full Open Temp*C		93			
Valve Total Lift (mm)		8				
Coolant		Subaru Coolant				
Coolant Capacity		6.5 Liters				
Electric Fan Watt (W)		70	80	←	110	
Outer Fan Demension+Blades		φ270 × 5				
R A D I A T O R	Radiator Type		Cross-Flow			
	(Kcal/H)		22500	21000	28000	29500
	Tank		Steel	Steel	←	←
	Core Material		Aluminum	Copper	←	←
	Core Dimensions		273 × 400 × 16	268 × 400 × 16	268 × 400 × 32	←
	Fan		Corrugated			
	Cap Pressure (kg/cm <sup>2</sup> )		0.9+ -0.15 -0.05 Below			
	Oil Cooler		No	←	←	Yes
	Size	Pipe Dia	φ22	←	φ28	←
		Hoes Dia	φ21 × φ28	←	φ27 × φ35	←


www.yokohamamotors.com [English]

# Coolant System

## Engine Related Components

Exploded View


T=Torque kg.cm



# Coolant System

## Truck Carbureted Vehicle


1. Radiator Fan
2. Shroud
3. Fan Motor
4. Upper Bracket
5. Radiator
6. Support RH
7. Lower Bracket RH
8. Drain Plug
9. Support LH
10. Lower Bracket LH
11. Air Vent Hose
12. Inlet Hoes
13. Hose
14. Outlet Hose



# Coolant System


SC Vehicle

1. Radiator Fan
2. Shroud
3. Fan Motor
4. Upper Bracket
5. Radiator
6. Lower Bracket RH
7. Lower Bracket LH
8. Drain Plug
9. Air Vent Hose
10. Air Vent Hose #2
11. Inlet Hose
12. Hose
13. Outlet Hose



# Coolant System

## Engine Room Fan System



## Coolant System


### Troubleshooting

	Cause	Remedy
O V E R  H E A T	Coolant Low Water Pump Pulley Water Pump Not Functioning Correctly Electric Fan  Thermostat Coolant Leaking Radiator Leak (Do Not Use Stop Leak) Water Pump Will Fail Engine Oil Low Clutch Slippage Transmission Oil Low Water In Oil Brake Engaged (Side Brake)	Add Coolant Check Belt Change Pump Check Relay-Check Fan  Change Change Gasket Repair Radiator  Add Oil Repair Clutch Add Oil Head Gasket Release
Too Cool	Thermostat Stuck Open or Missing	Replace Thermostat
O T H E R S	Inlet Hose Leaking Outlet Hose Leaking Water Pump Noise Intake Manifold Water Water From Tailpipe	Replace Hose & Clamp Replace Hose and Clamp Replace Pump Replace Gasket Replace Head Gasket

# Coolant System

## Engine Coolant System Diagram

### Hose & Pipe Routing






# Coolant System


## Water Pump

### Removal & Replace

1. Remove Engine From Vehicle
2. Remove Alternator Belt, Tensioner, if Equipped Super Charger Belt, Crank Pulley
3. Remove Dip Stick Tube
4. Remove Timing Belt Cover #2 & #3



5. Loosen Tensioner and Remove Timing Belt
6. Remove the (6) Water Pump Retaining Bolts




7. Remove Water Pump
8. Clean All Surfaces and Install New Water Pump

### Inspection


Note: This Section is For Inspection Purposes It is Highly Recommended to Simply Replace the Pump

#### End Play

Limit	0.5mm
-------	-------




Clearance (mm)	Limit	0.3~0.9
	Replace	1.1



# Cooling System




## Engine Room Fan Circuit



# Cooling System

## Control Unit Circuit

Note: See Electrical Diagram Section For More Information and Details




## Chapter 7

### Air – Fuel System – Exhaust

12. Air Intake System (Carbureted)
13. Air Intake System (Fuel Injected-Supercharged)
14. Air Cleaner and Air Intake Sensor
15. Intake Manifold (Carbureted)
16. Complete Fuel System Specifications
17. Carburetor Adjustments and Breakdown
18. Fuel Tank
19. Fuel System EMPi (Fuel Injected Vehicles)
20. Fuel Pump-Pressure Regulator-Knock Sensor
21. Fuel Injection-Air/Water Temp Sensors-O2 Sensor
22. Exhaust Truck-Van


# Air Intake System

Carbureted Vehicle



# Air Intake System

SC Vehicle




## Air Intake System

### Air Cleaner Case and Sensor


**Note:** Change Air Element Every 12,000K  
Clean Air Cleaner Case Every 6 Months

Air Cleaner (Element)



**Caution:** The Air Intake Charge Temperature Sensor is Located in The Lower Case of The Air Cleaner Unit. Take Care Not to Damage the Sensor or System Balance Trouble Will Occur

Air Intake Temp Sensor




**Note:** Do Not Forget to Connect Sensor if Air Cleaner Unit is Removed

## Intake Manifold (Carbureted)

---

1. Disconnect (-) Negative Battery Terminal
2. Drain Coolant System
3. Remove Coolant Pipe in Below Diagram




4. Remove any Hoses Necessary and Mark (Label) With Tape

See Diagram Below

5. Disconnect Carburetor Linkage, Vacuum Hoses, Fuel Line, etc.
6. Remove Carburetor
7. Remove Intake Manifold
8. Clean All Surfaces Before Re-Assembly

Note: Never Re-Use Gaskets






## Fuel System Specification (Carbureted)

Vehicle Type	Carbureted Vehicle			
Fuel Tank	Capacity	40 ℓ		
	Location	Under Rear Floor Decking		
Fuel Pump Specifications	Type	Plunger (Van-Try)	Diaphragm (Truck)	
	Output Press	0.15 ± 0.03kg/m <sup>2</sup>	←	
	Output Volume	15 ℓ /h	←	
	Amp Draw	1.5A	←	
	Min Voltage	9V	←	
	Hz	17Hz	—	
Fuel Filter Type	Cartridge			
Fuel Return System (Yes-No)	Yes			
Fuel Separator System (Yes-No)	No			
Fuel Vent System Type	Charcoal Canister Type			
Carburetor	Model	HVB32		
	Maker	Hitachi		
	Fuel Inlet Dia	Inner φ46	φ50 Outer	
	Fuel Outlet Dia	φ32		
	Venturi	Yes		
	Needle Valve Dia	φ1.4		
	Float Bowl Vent	Open Vent, Inner Vent Solenoid (Vent SW OP)		
	Main Nozzle	1	φ2.8	φ4
		2	φ2.5	φ3.5
	Secondary	1	φ3	φ4
		2	φ3.5	φ4.5
	Idle Hole Dia	φ1.3		
	Bypass Hole Dia	φ0.7-φ1.0	ℓ = 3.8mm	
	Power Valve Nozzle	φ0.4 × 1.9cc/10		
	Float Level	Float Chamber Surface Up 2.5(mm)		
Carb Weight	2.8kg			
Notes				
www.yokohamamotors.com [English]				


## Fuel System

Carburetor Diagram



# Fuel System


## Adjustment Screws



# Fuel System

## Carburetor Removal


1. Remove (-) Battery Connection
2. Disconnect Pipe Bracket Below



3. Remove the (2) Carburetor Covers
4. Drain Coolant System (See Coolant)
5. Mark Hoses and Remove


Caution: Fuel is Dangerous

6. Disconnect Accelerator Cable as Shown in the Diagram Below.




Accelerator Cable

7. Remove Air- Cleaner Duct



8. Remove the (2) Nuts Attaching The Carburetor to the Intake Manifold
9. Disconnect Throttle Cut-Off Solenoid Connector as in the Diagram Below



Connector

10. Remove Carburetor

Note: Always Use New Gaskets

Torque For Intake to Carburetor Nuts

$\overline{T}$  3.4 ± 0.3 kg-m




# Fuel System

Carburetor Brakedown

HVB32 Series

Note: Order Rebuild Kit For Hitachi HVB32

Detailed Instructions Included in Rebuild Kit  
This Diagram for Reference Only



Note: Rebuild Kit Has Up To Date Specifications  
This Page for General Reference


# Fuel System

## Caburetor Float Bowl Measurement

HVB32-1 Series  
HVB32-1A Series


### Float Measurement

High Point	14mm
------------	------




### Float Measurement

Low Point	24.6~25.5mm
-----------	-------------



# Fuel System

## Fuel Tank




Note: Do Not Over Torque Attachment Bolts

## Fuel System (EMPi)

### Fuel Pump - Pressure Regulator - Knock Sensor

#### Fuel Pump



1. Disconnect Connector
2. Start Engine to Burn Fuel in Line and Relieve Fuel Pressure
3. Stop Engine Disconnect (-) battery Post
4. Disconnect From Bracket
5. Disconnect Fuel Lines
6. Remove Pump
7. Install new Pump
8. Connect Lines
9. Connect to Bracket
10. Connect Battery
11. Connect Pump Electrical Connector
12. Turn Key to ON Position 5 Seconds and OFF
13. Turn Key to Start and RUN Engine
14. Check for Leaks

#### Fuel Pump Pressure


Fuel Pump Output Pressure IG SW ON

Normal	3.1kg/cm <sup>2</sup>
--------	-----------------------

Fuel Pump Pressure at IDLE

Normal	2.6kg/cm <sup>2</sup>
--------	-----------------------


#### Pressure Regulator



Pressure Regulator Regulates to 3.1kg.cm

To Replace: Remove Lines and (2) Attachment Bolts

#### Knock Sensor




Knock Sensor: Detailed Schematic See Electrical Section of this Book



## Fuel System (EMPi)

### Fuel Injector - Air and Water Temp Sensor - O2 Sensor



**Note:** Rough Idle or No Idle Can Be Caused By Bad Injector(s)  
First Check Ignition System Before Changing Injector(s)

#### Injector Test

1. Start Engine and Warm to Idle
2. Use a Stethoscope to Listen to Each Injector.  
You Should Hear Each Injector Make a Chi Chi Chi Sound. If an Injector is "Dead" Unplug the Connector and Plug Again.


**Note:** Quick Check of Connector Circuit Live or Dead Connect to a Injector That is Known Live. If you Hear The Chi Chi Chi Sound You Know The Circuit is Good. Return Connector to Original Injector.

**Note:** If All Injectors Live Spray Water Mist Around Injectors to Check For Vacuum Leak. If Leak Found Change Seals

3. Change Bad Injector(s) and Seals


**Note:** Change ALL Seals

#### Air Temp and Water Temp



**Note:** See Electrical Section of this Book for Detailed Information on these Circuits

#### O2 Sensor



Sensor

**Note:** O2 Sensor Detailed Information in The Electrical Section of this Book

1. Disconnect Electrical Connector
2. Remove and Replace Sensor

## Exhaust System

### Manifold and O2 Sensor

**1.** Exhaust Manifold (Carbureted Vehicle)  
**2.** Exhaust Manifold (SC Vehicle)  
**3.** O2 Sensor  
**4.** Gasket  
**5.** Heat Shield

**Manifold Torque Sequence**

$T = 3.5 \pm 0.5 \text{ kg-m } 2x$

**O2 Sensor**


- Connector
- Body
- Protector

**Note: NEVER Splice Wires on an O2 Sensor**  
**You Cut it, its Trash**

# Exhaust System

Truck Van Carbureted


Muffler System



# Exhaust System

SC Vehicles

Muffler System



# Chapter 8


## Starter & Alternator

5. Starter Specifications –Hitachi Series-Mitsubishi Series
6. Starter Overhaul Diagrams
7. Alternator Specifications- Mitsubishi Series-Denso Series
8. Alternator Diagram

## Starter Specifications


Subaru 660cc

Maker	Hitachi	Mitsubishi Electric		
Makers Part Number	S114-435	M <sub>2</sub> T <sub>3</sub> 7281	M <sub>2</sub> T <sub>4</sub> 2581	
Voltage	12V	12V	←	
Voltage Draw	0.65kW	0.65kW	0.75kW	
Turn Direction	Left	Left	←	
Pinion Teeth	8	8	←	
Body Length	211.5mm	204mm	209mm	
Yoke	φ90mm	φ90	←	
Unit Weight	3.5kg	3.2kg	3.6kg	
Motor	Volt Draw	11.5V	←	←
	AMP	40A(Less)	53A(Less)	←
	RPM	5000RPM	7000RPM	6000RPM





English Diagram

# Starter Motor




## Alternator

Vehicle Type	NA Vehicle		SC Vehicle
Maker	Mitsubishi	Denso	Denso
Regulator Type	Internal IC	←	←
Battery	12V	←	←
Output	12V45A	←	12V50A
Ground	⊖	←	←
Spin Direction	Right	←	←
RPM	5000rpm	←	←
13.5v RPM Range	1150rpm	1020rpm	1200rpm
Maximum Output	14.5±0.3V	14.5±0.5	←
Pulley Size	65φ	←	52.5
Max AMP RPM Output	5000-43A	←	5000-50A
Unit Weight kg	3.6	3.2	3.9
NA Vehicle			SC Vehicle 



# Alternator

Exploded View




## **Chapter 9**

### **Engine & Transmission Removal**


#### **Complete Engine and Transmission Removal**

## Engine Removal

ST	89990 4100	Straight Pin	For DOJ Model Spring Pin
	49960 5400	Engine Hanger	Engine and or Transmission Removal



## Engine Removal



1. Disconnect Fuel Pump Connction (Above)
2. Start Engine Until Run Out of Fuel
3. Diconnect Battery (-) Terminal
4. Remove Engine COVER Trap Door
5. Remove Rear Bumper and Rear Hood  
[Truck] Disconnect Back Lamp Etc.


Continued

## Engine Removal


6. Remove Air Cleaner Case
  1. Remove Hose From Air Cleaner
  2. Remove Entire Unit
7. Jack Up Vehicle
8. Remove Diagonal Member R & L
9. Remove Muffler
  1. Remove Exhaust Pipe Cover
  2. Remove Heat Shield (Rear)
  3. Remove Heat Shield (Front)
  4. Remove Exhaust Manifold Plate
  5. Remove Hanger Bracket
  6. Remove (4) Bolts from Muffler Cover
  7. Disconnect Temp Sensor
  8. Remove Remaining Attachment Muffler Components
10. Remove Caburetor Cover (NA Vehicle) or Throttle Body Protector (SC) Vehicle

NA Vehicle

Caburetor Covers




SC Vehicle



Throttle Body Cover


Transmission Harness




Starter Motor

## Engine Removal


(3). Disconnect Main Harness and Thermo SW




(4). Disconnect Alternator Connections




(5). Disconnect Ignition Coil  
 (6). Disconnect Distributor Harness  
 (7). Disconnect Resistor CON



(8). Remove Coil Wire and IGN Coil




(9). Disconnect Engine Ground Cable




SC Vehicle

(1). Remove Starter Cable (+) and Harness CON  
 (2). Disconnect Transmission CON




## Engine Removal

(3) Remove O2 Sensor CON




(4). ECVT Vehicle: Remove Brush CON




(5). Remove Engine Main Harness (2pc) and Thermo-Sw CON

(6). Remove ALT Terminal CON




(7). Disconnect Distributor and Ignitor CON



(8). Remove Ignition COil  
(9). Remove Engine Ground


(12) Cable Removal  
(1) Remove Speedometer Cable



# Engine Removal

NA Vehicle


(2) Remove Accelerator Cable



Accelerator Cable

SC Vehicle


Bracket



Accelerator Cable


(3) Remove Shift Control Cable and Select Control Cable from Trans (MT)

MT Vehicle




Bracket

Select Control Cable




ECVT Vehicle

(4) Remove Complete Bracket and Cable



(5) Remove Clutch Cable from Fork Lever. Remove Cable Bracket from Tranny

MT Vehicle



## Engine Removal

(6). Remove Speedometer Cable

Caution: Secure Cables with Tape to the Body During Engine Removal

(13). Hose Removal


Caution: Mark Hoses by Function

NA Vehicle


(1). Remove Vacuum Hoses

(2). Remove Evap Hose from Carburetor

(3). Remove Fuel Hose from Both Delivery and Return




(4). 4WD Vehicles: Separate Hoses (2pc) at The Check Valve Location. Diagram Below.




SC Vehicle

(1). Remove Brake Booster Hose from Supercharger

(2). Remove Evap Hose from Throttle Body



(3). Remove Fuel Hoses. See Below Diagram



Disconnect Fuel Hose Here

(4). Separate 4WD Actuator Vacuum Hoses (2pc).




# Engine Removal

- (5). ECVT Vehicle: Remove Oil Cooler Hose  
(2) Lines


Caution: Plug the Lines After Removal

ECVT Oil Cooler Hose




Plug

- (6) Remove Pressure Sensor Hose




Pressure  
Sensor

- (7). Remove ISC (2) Hoses



ISC Hose


- (14). Jack Up Rear  
(15). Remove Diff-Lock Actuator From  
Transmission (4WD Vehicle Only)



Diff-Lock Actuator


- (16). Drain Coolant

Note: Never Re-Use Coolant



Use Hose to Drain

- (17). Remove Splash Guard



Splash Guard

## Engine Removal


(18). Separate Drive Shaft From Transmission  
(4WD Only)

- (1). Remove Attachment Bolts
- (2). Drain Differential
- (3). Pull Shaft Out

Caution: Place Bucket Under Differential as Oil Will Leak Out.

Caution: Wrap Ends of Drive Shaft to Prevent Scratches to the Surface.


(19). Remove Pitching Stopper. See Diagram Below.



Pitching Stopper


(20). Remove Radiator and Heater Hoses

NA Vehicle  
Remove Hoses




SC Vehicle  
Remove Hoses

Oil Cooler Hose




(21). Remove L & R Axle Shafts from Tranny

Caution: Be Careful Not to Damage Boots




## Engine Removal

(22). Remove Front Mount Bolts




(23). ECVT Vehicle: Make Sure (2) Engine Oil Cooler Lines are Disconnected




(24). Lower Vehicle


(25). Remove Radiator Vent Hose from Engine




(26). Place Engine Jack Under Engine



(27). Remove Engine Cross Member Bolts (4)



(28). Remove Engine and Cross Member Combined.



# Chapter 10


## Engine Overhaul

- 22. Engine Disassembly
- 23. Block Inspection
- 24. Cylinder Inspection
- 25. Piston Inspection Including Oversize Pistons
- 26. Block Deck-Journal and Bore Sizes
- 27. Piston Rings and Installation Positioning
- 28. Connecting Rods
- 29. Crankshaft & Journals
- 30. Journal Details and Clearances
- 31. Crankshaft Oil Seals
- 32. Block Assembly
- 33. Piston Installation
- 34. Oil Pump
- 35. Cylinder Head and Timing Belt System
- 36. Valve Rocker Assembly
- 37. Camshaft Specifications and Clearances
- 38. Camshaft Installation & Oil Seal
- 39. Cylinder Head – Valve Springs- Valves
- 40. Valve Guides- Valve Details
- 41. Oil Pump Overhaul
- 42. Oil Pressure Switch

## Engine Overhaul

---

Note: Use ST 499815500 Engine Stand



Note: Before Disassembly Steam Clean or Power Wash Unit  
Make Sure All Electrical Components Have Been  
Removed First



# Engine Overhaul

## Engine Disassembly


1. Remove All Electrical Accessories
2. Remove Crank Pulley, Clutch, Flywheel

Note: Use Flywheel Holding Tool Below ST 49827-5800

3. Remove Cylinder Head and Components




Two-Way Tool (Loose-Tight)




4. Strip Front of Engine Including Water Pump
5. Remove Oil Filter and Oil Cooler (SC Vehicle)

Water Pump Removal



6. Place Block Up-Side Down on Clean Piece of Wood or Plastic

Scraper




7. Remove Oil Pan Bolts and Use Gasket Scraper to Separate Gasket From Pan. Lift Up Pan.


# Engine Overhaul

## Engine Disassembly


8. Remove Block Stiffener Plate



9. Remove Oil Pump Body




Note: Use Caution Not To Brake Casing



10. Remove Rod End Caps  
(Mark Cap Cylinder #)


11. Remove Crankshaft End Caps  
(Mark Cap)

12. Remove Crankshaft



13. Remove Crankshaft Oil Seal

14. Remove Thrust Bearings




# Engine Overhaul

## Disassembly and Block Inspection

### 15. Remove Pistons From Block


Note: Use Wood Handle to Push Out the Pistons



Note: Have Block Cleaned


### Piston and Connecting Rod

1. Remove Circle Clip
2. Separate Piston from Connecting Rod



Note: Circle Clips Can Not Be Re-Used

1. Use a Straight Edge (Not Ruler) and A Thickness Gage to Check Block] Deck For Straightness



Normal	0.05mm
Limit	0.15mm

Note: Over 0.16mm Block Must be Milled

Note: If Block is Out of Specifications The Cylinder Head May Also be Affected. Check Cylinder Head Carefully.




# Engine Overhaul


## Block and Piston Inspection

### Cylinder Inspection

Note: Check Cylinder Bores Visually for Any Visible Damage or Cracks. If Crack is Located Discard Block




Measurement Points 1-2-3




Crankshaft Direction

Cylinder Inside Dia	56.0~56.02mm
Circum Limit	0.05mm
Taper	0.05mm
Cylinder Dai Limit	Below 56.5mm

### Piston Inspection



Micrometer



A  
NA: 10mm  
SC: 8.7mm

Piston Measurement 20 Degrees C


Normal Limit	Size Div 1	55.975~55.985mm
	Size Div 2	55.986~55.995mm
	Oversize 0.25	56.225~56.245mm
	Oversize 0.5	56.475~56.495mm

Cylinder to Piston Gap

Normal	0.015~0.035mm
Limit	0.06mm

# Engine Overhaul


## Cylinder Bore & Piston Clearance




# Engine Overhaul

## Piston Rings and Piston Angle


Piston Ring Inspection



	Normal	Limit
Top Ring	0.035~0.075mm	0.15mm
Secondary	0.025~0.065mm	0.15mm
Oil Ring	0	—



Piston Ring Position




		Normal	Limit
Top Ring	NA	0.15~0.3mm	0.8mm
	SC	0.15~0.25mm	0.7mm
Secondary		0.15~0.3mm	0.8mm
Oil Ring		0.1~0.6mm	0.8mm

# Engine Overhaul


## Connecting Rod Inspection

Side Clearance




Side Clearance	Limit
0.07~0.33mm	0.4mm

Expoded Parts Diagram



Note: See Next Page for Details


Connecting Rod Alignment Board



Alignment Limit	0.1mm
-----------------	-------

# Engine Overhaul

## Crankshaft Inspection




Normal	0.025~0.060mm
Limit	0.065 mm

Bearing Size	Bearing Thickness	Crank Pin Outer Dia
Normal	1.488~1.498	30.989~31.000
0.03 Undersize	1.506~1.510	30.959~30.970
0.05 Undersize	1.516~1.520	30.939~30.950
0.25 Undersize	1.616~1.620	30.739~30.750

Con Rod to Piston Pin	0.007~0.029mm
Limit	0.035mm

### Crankshaft Journal Round-Out



Limit	0.03 mm
-------	---------

Note: Undersize Bearings



Degree	0.03mm
Taper	0.02mm

Availability: 0.03, 0.05, 0.25 (3 Types)  
Check Parts Department for Stock or Special Order

# Engine Overhaul

## Clearances

### Journal Measurement



Thickness Gage

Side Clearance	Normal	Limit
	0.05~0.222	0.30

### Torque Setting

Bearing Cap	4.0±0.3kg-m
-------------	-------------

### Oil Clearance

		Normal	Limit
Normal Size	#1, #2, #4, #5 Journal	0.021~0.039	0.055
	#3 Journal	0.027~0.045	0.060
Under-Size	0.03 Under	Same	Same
	0.05 Under		
	0.25 Under		

### Journal - Crankshaft - Bearing

Size Division		Crank Journal		Crank Pin
		#1, #2, #4, #5 Journal	#3 Journal	
Normal	Diameter	41.973~41.991	41.967~41.985	30.989~31.000
	Thickness	1.494~1.512	←	1.488~1.498
0.03 Undersize	Diameter	41.943 ~41.963	41.937~41.955	30.959~30.970
	Thickness	1.515~1.518	←	1.515~1.518
0.05 Undersize	Diameter	41.923~41.941	41.917~41.935	30.939~30.950
	Thickness	1.525~1.528	←	1.525~1.528
0.25 Undersize	Diameter	41.723~41.741	41.717~41.735	30.739~30.750
	Thickness	1.625~1.628	←	1.625~1.628


www.yokohamamotors.com [English]

# Engine Overhaul

## Crankshaft Oil Seal


Note: Oil Seals Can Not be Re-Used  
Coat all Seals With 30W Engine Oil

Rear Oil Seal



Oil Seal Guide  
498725500  
498725600  
Press Oil Seal


Front Oil Seal Installation



ST 49958 6200  
Guide Oil Seal

## Engine Block Assembly

Note: Before Assembly Make Sure All Parts Are Clean and Plenty of Engine Oil For Coating Rotating Parts



Caution: Make sure Thrust Bearings in Correct Direction

### Preparation

1. Gather All Related Parts
2. Coat All Moving Parts Heavily With 30W Engine Oil
3. Oil Seals Will Require a Coating of Light Grease or Assembly Grease if Available

### Assembly

1. Install Crankshaft into Block
2. Attach Main Bearing Caps  
Torque: 4.0+/-0.3Kg-m


Rotate Assembly And Check for Any Friction Points. If Binding is Detected Disassemble and Locate Problem

No Issues: Re-Torque Caps

# Engine Overhaul

## Block Assembly

3. Coat Bearing Cap Seal With 1/3 Bead of 3Bond or Equivalent Bonding Material




4. Assemble Pistons and Connecting Rods for Installation.


Note: Use the Chart in This Chapter of The Book For Ring Configuration

5. Use a Spring Compressor to Install Pistons into Their Respective Bores


Note: Use a Vacuum Hose and Cover Rod End Bolts to Prevent Crank Damage




6. Attach Bearings and Caps  
Torque to Specifications Below



7. Attach Rear Oil Seal



8. Attach Oil Pump







# Engine Overhaul

## Special Tools


Engine Stand




Engine Stand Adapter



Crankshaft pulley Wrench




Bolt (Puller)



# Engine Overhaul

## Cylinder Head and Timing Belt Components



# Engine Overhaul

## Timing Belt


Note: Set Engine to TDC Compression Stroke

### Preparation

1. Remove Engine Cover
2. Jack Up Vehicle and Remove Rear Right Tire
3. Remove Rear RH Wheel Housing Inside Engine Cover.

### Removal


1. Remove Accessories: Alternator Etc V-Belts
2. SC Vehicle: Remove Supercharger Belt
3. Use ST Crankshaft Pulley Remover and Remove Crankshaft Pulley
4. Remove Timing Belt Cover
5. Remove Oil Dip Stick Tube Unit
6. Remove Timing Belt Cover #2, #3



7. Remove Timing Belt


Note: Never Re-Use a Timing Belt

Change: Every 60,000 Kilometers




8. Install New Belt and Line Up With GREEN Marks. Set Tensioner and Torque Spec

Caution: Be Careful Of Tensioner Spring  
Tensioner Sprocket



# Engine Overhaul


## Valve Rocker Assembly



1. Remove Valve Cover
2. Loosen Valve Adjustment Screws
3. Remove (5) Rocker Shaft Attachment Bolts
4. Remove Rocker Arm Assembly


Note: Inspect Arms for Extream Wear or Cracks. If Found Discard Unit and Replace

### Inspection



### Specification [Rocker Arm+Shaft]

Rocker Arm & Shaft Clearance	Fine	0.016~0.052
	Limit	0.1
Rocker Arm (IN Dia)	Fine	16.0~16.018
Rocker Shaft (Out Dia)	Fine	15.984~15.966




5. Replace Rocker Arm Shaft and Set Torque.
6. Set Valve Adjustment (Begining of this book).
7. Check Timing


# Engine Overhaul

## Camshaft Specifications

### Camshaft Journal Measurement





Journal		26.0~26.021mm
Camshaft Journal(Outer)		25.939~25.955mm
Journal Opening	Ok	0.045~0.082mm
	Out	0.1mm



### Camshaft Lobe Measurement

Cam "H" Limit	31.42~31.52mm
Replace	31.20mm




Side Clearance	0.02~0.22mm
Over Limit	0.5mm

# Engine Overhaul

---


## Camshaft Oil Seal

---



**Note: Never Re-Use Oil Seals, Replace With New Parts**


**Use: Oil Seal Guide Tools for Proper Installation**



**Note: Lubricate Seal With Engine Oil Before Installation**

**Note: Tap Lightly When Installing Oil Seal**

**Guide Oil Seal (Cover Cup)**




**Brass Hammer**

# Engine Overhaul

## Cylinder Head - Valve Spring - Valve


Torque=3.0+-0.3kg-m

Cylinder Head Torque Sequence



Note:

Use Cylinder Head Cradle Holder Tool ST 49976-5600 To Hold Head In Place for Spring Removal and Installation Procedures




Use Above Combination for Removal and Installation of Valves and Springs

### Valve Spring Specifications

Specifications		IN & EX
Free Length (mm)		43.46
Set	Pressure (kg)	18.2
	Spring Length	36.5
Lift	Pressure (kg)	44.9
	Spring Length	29.0

### Valve Seat Specifications




Valve Seat	Intake	Exhaust
"W"	1.3mm	1.2mm

# Engine Overhaul

## Valve - Valve Spring - Valve Guide

### Valve Specifications




Valve Stem		IN	EX
"H"	Ok	41.3mm	41.4mm
	Fail	41.8mm	41.9mm
Side Clearance Limit		0.5mm	0.5mm

Valve Guide	Intake	Exhaust
Valve Stem (OP)	0.030~0.060	0.040~0.070
Opening Deg	0.130	0.150
V Guide (Out)	5.452~5.470	5.442~5.460
V Guide Limit	5.50 ~5.512	5.50 ~5.512
Head Clearance	0.060~0.027	0.060~0.027


### Specialty Tools

Part #	Part Name
49976 5600	Cylinder Head Cradle
49976 5700	Ream Bar Valve Guide
49976 5800	Adjuster Valve Guide
49976 5900	Reamer Valve Guide

Use Service Tools For Guide Replacement



### Valve Guide Adjuster Tool






## Engine Overhaul


---

### Valve Oil Stem Seal



Note: Replacement Oil Stem Seals are Marked and or Have a Color Code.

### Valve Face Angle




		Intake	Exhaust
Valve Head "H"	Ok	1.0mm	1.0mm
	Limit	0.5mm	0.5mm
Valve Face		$\phi$ 26mm	$\phi$ 23mm
Valve Length		94.6mm	94.6mm

# Engine Overhaul

## Oil Pump System


### Oiling System Exploded View



# Engine Overhaul

## Oil Pump


Brakedown of Parts




Inner to Outer Clearance

Clearance	Norm	0.05~0.18mm
	Out	0.2mm

Thickness Gage




Radial Clearance



Radial Clearance

Radial	Norm	0.12~0.19mm
	Fail	0.25mm

Thickness Gage



Side Clearance


Side Clearance	Norm	0.03~0.07mm
	Out	0.15mm

Out=Replace


# Engine Overhaul

## Oil Pump Assembly


Attach Pump Assembly to Block



Install New Oil Seal




## Oil Pressure Switch



Oil Pressure Switch

Note: Oil Pressure Switch Details See in This Book (Electrical Diagrams)

Oil Pressure Switch




# Chapter 11

## Transmission and Differential 2WD - 4WD

21. Gear Shift System
22. TM 60 Series 2WD Clutch Housing - Main Case - Side Case
23. TM 60 Series 2WD Main Shaft-Drive Pinion- Reverse Idler Shaft
24. TM 60 Series 2WD Shift & Select System
25. TM 60 Series 2WD Differential
26. TM 60 Series Selective 4WD Transmission Case Assembly
27. TM 60 Series Selective 4WD Shifter and Selector System
28. TM 60 Series Selective 4WD Drive Pinion-Main Shaft-Reverse Idler
29. TM 60 4WD Differential
30. TM 60 4WD Diff-Lock Differential Option
31. TM 60 4WD Diff-Lock Side Cover Assembly
32. TM 60 Selective 4WD Transfer Extension
33. Clutch & Pressure Plate Specifications
34. Clutch System Diagram
35. Clutch Cable Adjustment
36. Release Bearing and Fork
37. Clutch Disk – Flywheel – Pressure Plate
38. Clutch Assembly
39. Axle Shaft System
40. Axle Shaft Identification and Type


# Transmission

## Gear Shift System




## TM 60 Series 2WD

### Clutch Housing - Main Case - Side Case



## TM 60 Series 2WD


### Main Shaft - Drive Pinion Shaft - Reverse Idler Shaft






## TM 60 Series 2WD

### Shift & Select




## TM 60 Series 2WD

### Differential



# TW 60 Series Selective 4WD


## Transmission Case Brakedown



# TW 60 Series Selective 4WD


## Shifter and Selector

1. Transmission Cover CP
2. Reverse Check Cam
3. Reverse Check Spring
4. Air Breather Tube
5. Clip
6. 1~2 Gear Shifter Fork
7. 1~2 Shifter Rod
8. Spring Pin
9. 3~4 Shifter Fork
10. 3~4 Shifter Rod
11. 5th Release Shifter Rod
12. 5th Release Shifter Cam
13. EL Shifter Fork
14. Neutral Set Spring
15. 5th Reverse Shifter Fork
16. Spring Retainer
17. Spring Ring
18. Shifter Shaft
19. Shifter Arm
20. Inter Lock Plate
21. Check Spring
22. Reverse Return Spring Retainer
23. Reverse Return Spring
24. Check Ball
25. Snap Ring
26. O Ring
27. Washer
28. Needle Set Spring Retainer
29. Washer
30. Selector Shaft
31. Selector Lever
32. Shifter Lever
33. Aluminum Gasket
34. Check Ball Plug
35. Check Ball Spring
36. Interlock Bolt
37. Bracket
38. Washer
39. Washer




## TW 60 Series Selective 4WD

### Drive Pinion - Main Shaft - Reverse Idler Shaft



# TW 60 Series Select 4WD


## Differential



# TW 60 Series Select 4WD

## Diff- Lock Differential

1. Drive Gear
2. Differential Case
3. Pinion Shaft
4. Bevel Pinion
5. Side Gear B
6. Side Gear A
7. No.2 Differential Pinion Shaft
8. Joint
9. Washer (Shim)
10. Straight Pin
11. Ball Bearing
12. Washer (Shim)
13. Ball Bearing
14. Axle Drive Shaft
15. C Clip
16. Washer
17. Oil Seal




# TW 60 Selective 4WD

Differential Side Cover

Diff-Lock Vehicle

Diff-Lock Option Vehicle




- 15. Diff-Lock Actuator
- 16. Pin
- 17. Snap Pin



# TW 60 Selective 4WD

## Transfer Extension

1. Transfer Cover CP
2. Gasket
3. Check Ball Spring
4. Check Ball
5. 4WD Switch
6. Aluminum Gasket
7. Transfer Diaphragm Outer Cover
8. Transfer Diaphragm & Rod
9. Aluminum Gasket
10. Transfer Diaphragm Inside Cover
11. Clasp Spacer
12. Backlash Shim
13. Bearing Case
14. Lock Washer



15. Lock Nut
16. Ball Bearing
17. Ball Bearing
18. Transfer Shift
19. Bushing
20. Ball Bearing
21. Woodruff Key
22. Synchronizer Hub
23. Shifting Inside Retainer (Free Axle Vehicle)
24. Synchro Spring (Free Axle Vehicle)
25. Extension
26. Bushing
27. Oil Seal
28. Spring Pin
29. Transfer Shifter Fork
30. Drive Bevel Gear
31. Stay (Free Axle Vehicle)
32. Support (Free Axle)
33. Transfer Driven Gear
34. Syncho Ring

35. Backlash Shim
36. Transfer Bevel Gear
37. O Ring
38. Shifting Inside (Fee Axel)
39. Syncho Sleeve
40. Transfer Synchro Hub
41. Washer
42. Snap Ring

43. Washer
44. O Ring
45. Oil Seal
46. Transfer Side Cover Pin
47. Oil Seal

YokohamaMotors.com [Englsih]

## Clutch System Specifications

---

### Clutch Pressure Plate & Disk

---


Specifications Chart

Engine Type		EN07				
Transmission		2WD	SC	Select 4WD	SC	Free Axel
		TM60	←	TW60	←	TY60
Clutch	Type	Single Disk	←	←	←	←
	Control	Mechanical	←	←	←	←
Clutch Pedal	Type	Suspended	←	←	←	←
	Pedal Ratio	4.5	←	←	←	←
	Stroke (mm)	115~120	130~135	115~120	130~135	←
Pressure Plate (Cover)	Type	Push	←	←	←	←
	Engage Load Kg	190	210	170	210	←
Clutch Disk	Dimensions	160×125×3.5	180×125×3.5	←	←	←
	Contact Area(cm2)	106	131	←	←	←
	Spline Teeth	23	←	←	←	←
	Plate Thickness	8.35±0.4mm	←	←	←	←
	Material	Non-Asbestos	←	←	←	←

## Clutch System

Clutch System Diagram

- |                                 |                                   |
|---------------------------------|-----------------------------------|
| 1. Clutch Disk (2WD NA Vehicle) | 8. Spring                         |
| 2. Clutch Disk (All Others)     | 9. Release Fork                   |
| 3. Clutch Cover                 | 10. Release Lever                 |
| 4. Spring Washer                | 11. Clutch Housing                |
| 5. Release Bearing              | 12. Pilot Bearing                 |
| 6. O Ring                       | 13. Flywheel (4WD SC Vehicle)     |
| 7. Straight Pin                 | 14. Flywheel (4WD and All Others) |




## Transmission


### Clutch Cable

#### Removal

1. From the Transmission side, loosen Wing Nut
2. Remove Outer End Joint Clip Behind Clutch Pedal. Remove Cables from Pedal Bracket.
3. Remove Clutch Pedal Joint
4. Remove Front Under Cover and Remove Cable Retaining Clip from Under The Steering Gear Box
5. Remove Other Retaining Clips Along Cable Path (If Equiped).
6. Remove Transmission Cable Attachment Bracket
7. Remove Return Spring and Clutch Cable From Release Lever
8. Remove Grommet from Cab Floor. Pull Out Cable.



Clutch Pedal Stroke



Clutch Cable Attachment Point

# Transmission

## Release Bearing & Release Fork

Note: Transmission Removed

### Removal

1. Remove the (2) Springs from The Release Fork
2. Use ST 3987917000 Straight Pin Remover to Pull Out Straight Pin
3. Remove Clutch Release Fork and Clutch Release Lever CP


Caution: Bearing is Greasless Encapsulated Type. Do NOT Use Solvent to Clean

### Bearing Inspection

Note: Bearing Shall Be Replaced Over 60,000 Kilometers

4. Inspect for Damage
5. Check for Rotation Smoothness

Note: Best Practice is to Change All Clutch Parts as a Set. Including Bearing-Disk-Pressure Plate



# Transmission

## Clutch Assembly

1. Use Clutch Disk Guide ST 499745400 To Prevent Disk From Falling Out During Removal
2. Remove Clutch Cover Mounting Bolts From Flywheel
3. Install Flywheel Stop Tool
4. Remove Bolts and Remove Flywheel

ST 498275800 (Flywheel Stopper)

### Clutch Cover Inspection

Note: Be Careful Not To Spill Oil On Pressure Plate and Disk Surfaces

Note: Clutch Disk With Oil Saturation Must Be Discarded and Replaced


1. Inspect Backlash of Thrust Rivets (Slipage) and or Cracks. Missing Rivets Can Not Be Replaced. Unit Must be Discarded

Diaphragm Plate



Thrust Rivets

2. Inspect for Galling, Pitting or Other Damage.




3. Inspect For Heat Damage or Warping
4. Check Strap Plates For Damage

### Clutch Disk Inspection

1. Check Surface for Visible Damage

Normal	1.4mm
Limit	0.3mm



2. Measure Countersink Rivet to Disk Plate Surface (Specifications Above)


# Transmission

## Clutch Disk - Flywheel

### 5. Clutch Disk Flutuation Limit


Limit	0.5mm
-------	-------

Measurement Point	TM60	150φ
	TM60 TW60 • TY60	170φ



### Flywheel Inspection


1. Inspect for Galling, Pitting, Heat Damage
2. Check Flywheel Teeth for Cracked or Missing Teeth




Note: Missing or Damage Teeth Have New Ring Gear Welded and Re-Balance

Note: One Piece Flywheel Units Can Not Be Repaired

### Flywheel



3. Attach Flywheel and Flywheel Stopper Set Torque




Torque To Specifications


# Transmission

## Clutch Assembly

1. Place Clutch Disk This Side Up




2. Place Pressure Plate Over The Top




3. Use ST Tool 499745400 for NA Vehicles  
ST 4997455000 For SC 4WD Vehicles

Place The Tool Through The Pressure Plate

4. Install Disk and Plate



5. Torque Bolts to Specifications




6. Remove Service Tool



## Drive Axel


### Axel Shaft System



1. BJ
2. Boot Band (Large)
3. Dust Boot
4. Boot Band (Small)
5. Circle Clip
6. Snap Ring
7. DOJ
8. Inner Oil Seal
9. TJ

# Drive Axel

## Drive Axel Types and Identification



## Chapter 12



### Harness Diagrams

1. General Harness Locations
2. Truck Full Main Harness and Connection Codes
3. Connection Codes Explained (Truck-Van)
4. Van Full Main Harness and Connection Codes
5. Engine & Transmission Harness and Connections
6. Engine & Transmission Harness Code Breakdown
7. Front Component (Main) Harness Dash-Front Lighting
8. Front Component (Main) Connector Breakdown

### Electrical Schematic Breakdowns

9. Turn Signal & Hazard
10. Stop Lamp Circuit
11. Lighting Circuit (Headlights-Running Lights)
12. Lighting Circuit Tail Assemblies & Illumination Lamps
13. Engine Control and Fuel Pump Circuits
14. Charging System
15. Engine Room and Radiator Fan (Van & Special Trucks)
16. Engine Radiator Fan (Basic Vehicle)
17. Radio (Audio) Circuits and Cigarette Lighter
18. Fuel Gage & Sending Unit
19. Full Time 4WD Control Circuits
20. Selective 4WD Control Circuits
21. Diff-Lock Control Circuits
22. EMPi Engine Control Management System Part 1 (Fuel Injection)
23. EMPi Engine Control Management System Part 2 (Fuel Injection)
24. Windshield Wiper System Front and Rear
25. Rear Defogger Circuit


## General Information



1. Front Harness
2. Rear Harness
3. Inner Panel Harness
4. Roof Hrness
5. Back door Harness
6. Transmission Line
7. Engine Harness
8. Rear Combination

# Sambar Main Harness


## Pickup Truck



[www.yokohamamotors.com](http://www.yokohamamotors.com)

# Main Harness Location

## Van



**Main Harness Connector Code  
Breakdown  
Truck & Van**

No.	Color	Function
R1	Black	Front Wiring Harness
R2	Black	Same
R3		Front wiring harness (SC)
R4		Front wiring harness
R5	Yellow	Select Monitor
R6	Blue	Front AC Harness
R7	Green	Test Mode Connector
R8	Black	Read Memory Connector
R9	Black	Diode (AC)
R10	Black	Radiator Fan
R11	Gray	Free Axel Solenoid
R12	Gray	High Press Cut Switch
R13	Black	Condenser Fan
R16	Yellow	EMPi Unit
R17	Yellow	EMPi Unit
R18	Yellow	EMPi Unit
R19	Brown	EMPi Main Relay
R20	Brown	Fuel Pump Relay
R21	Gray	4WD Solenoid
R22	Gray	Diff-Lock Solenoid
R23		Fuel Unit
R24		Fuel Pump
R25		Engine Room Fan
R26		VSV (Air-conditioning)
R27	Gray	Engine Harness
R28	Gray	Engine Harness
R29	Black	Thermo-Switch
R30	Black	Gas Temp Switch
R31	Black	Magnetic Clutch
R32		Rear Combination

		Lamp(RH)
R33		Rear Gate Cord
R34		Rear Gate Cord
R35	Black	Rear Wiper Relay
R36	Green	Pressure Sensor
R37	Green	Alternator
R38		Alternator B
R39	Blue	ISC Valve
R40	Green	Distributor
R41	Gray	Igniter
R42	Black	Noise Condenser
R43		O2 Sensor
R44		Transmission Connector
R45		Starter Mg
R46		Back Switch
R47	Black	Electric Clutch
R48	Blue	Temp Sensor
R49	Gray	Thermostat
R50	Black	Rear Combination Connection
R52		Backup Warning Horn
R53	Black	Over speed cutoff
R55	Gray	Contact Breaker
R56	Black	Thermo Switch
R58		Resistor
R59	Black	Ignition Coil
R60		Ultra Heater Solenoid
R61		Rear Washer Motor
R62		Rear Combination Lamp (LH)
R64		Front Wiring Harness F6
R65		Room Lamp
R71	Green	Front Wiring Harness F8
R74		Rear Defroster
R75		Rear Wiper Motor




R76		License Lamp
R77		Back Door Opener
R78	Black	Back Door Switch
R79		Rear Defroster
R80	Black	Main Motor
R81		Sunroof Switch
R82	Gray	Luggage Compartment Lamp
R83		Sunroof Switch
R84		Sunroof Switch
R85		Limit Switch (Sunroof)
R90		Ds Range Solenoid
R109	Red	Jumper Wire (EMPi Unit)


Complete Main Codes

## Engine Harness & Transmission Harness


Trnasmision Harness



● NA



● SC




## Engine & Transmission Harness Connector Codes

No.	Color	Description
R27	Gray	Rear Harness
R28	Gray	Rear Harness
R44		Rear Harness to Transmission Connection
R46		Backup Lamp Switch
R87	Brown	EL Switch (Selective 4WD)
R88	Brown	Diff-Lock Switch (Selective 4WD)
R89	Brown	2WD-4WD Switch (4WD)
R91	Gray	Injector #1
R92	Gray	Injector #2
R93	Gray	Injector #3
R94	Gray	Injector #4
R95		Oil Pressure Switch
R96	Brown	Knock-Sensor
R97	Gray	Throttle Sensor
R98	Black	Charge Sensor
R99	Black	Thermo-meter
R100	Green	Water Temp Sensor
R101	Gray	Carburetor IG Power

Complete Engine & Trans Connector Codes

# Front Component (Main)



**Front Component (Main) Harness  
Truck & Van  
Connector Code Breakdown**

No.	Color Codes	Description (Function)
F1	Black	Headlight (RH)
F2		Front Turn signal Lamp (RH)
F3		Front Combination Lamp (RH)
F4		Accelerator SW (ECVT)
F5	Black	Brake Fluid
F6	Black	R64 Roof Wiring
F7	Blue	R63 Roof Wiring
F8	Green	R71 Roof Wiring
F9		Line End Check
F10	Black	Stop Lamp Switch
F11	Black	Key Lock Solenoid
F12	Pink	Ignition Key Switch
F13	Black	Key Switch
F14	Black	Combination Switch
F15	Black	Combination Switch
F16		Combination Meter
F17		Combination Meter
F18		Combination Meter
F19		(OP)
F20		Panel Harness
F21		Panel Harness
F22		Backup PWR (Clock)
F23		Fuse Box #2 (AC Fuse)
F24	Blue	4WD Relay
F25	Green	Diff-Lock Relay
F26	Black	Free Axle Relay
F27		Fuse Box #1
F28	Black	R4 rear Wiring Harness

F29	Black	4WD Diode
F30		Diff-Lock Diode
F31		Rear Wiring Harness
F32	Black	Rear Wiring Harness
F33		Rear Wiring Harness(SC)
F34		Inhibitor Switch
F35		4WD Switch
F36		Parking Brake Switch
F37		Door Switch (RH)
F38		Door Switch (LH)
F39		Front Washer Motor
F40		Horn
F41		Heater Blower
F42	Brown	Heater Resister
F43		Front Wiper Motor
F44		Engine Room Fan (SC)
F45	Blue	AC Harness
F46	Blue	Accelerator Switch AC
F47	Black	Shift Lock Unit
F48	Yellow	ECVT Unit
F49	Black	Headlamp (LH)
F50		Front Turn Signal Lamp(LH)
F51		Front Combination Lamp (LH)
F52	Black	Parking Switch
F53	Black	Shift Lock Solenoid
F54	Blue	Injector
F55		Side Door Lock
F59		Switch
F61		Side Door SW (RH)
F62		Side Door (LH)
F63		Side Door Switch (Room Light)
F64	Brown	Rear Heater Switch
F65	Black	Plug Socket
F66	Gray	Rear Heater Blower
F67		Battery

<b>F68</b>		<b>Side Door Lock Unit</b>
<b>F69</b>		<b>Side Door Lock (LH)</b>
<b>F71</b>	<b>Black</b>	<b>AC Harness</b>
<b>F72</b>		<b>Starter Relay</b>
<b>F73</b>		<b>(OP)</b>
<b>F74</b>		<b>IG PWR</b>
<b>F75</b>	<b>Black</b>	<b>ACC PWR</b>
<b>F81</b>		<b>AC Harness Connection</b>
<b>F82</b>	<b>Black</b>	<b>Resister</b>
<b>F83</b>	<b>Blue</b>	<b>Rear Harness AC</b>

Completed


## Electrical Schematics

Use the following Color Codes that will be used throughout this section.


Color Symbol	Color Name
L	Blue
B	Black
Y	Yellow
G	Green
R	Red
W	White
Br	Brown
Lg	Light Green
Gr	Gray
P	Pink
Or	Orange
Lb	Light Blue
SA	Shielded Line (Inner)
SB	Shielded Line (Outer)




# Turn Signal & Hazard Diagram




## Stop Lamp Circuit





# Lighting Circuit Part 1




## Lighting Circuit Part 2




Illumination Lamps




# Engine Control & Fuel Pump System




# Engine Control Sensor Circuits Continued



# Charging System




# Engine Compartment Cooling Engine Room Fan Radiator Fan






## Radiator Fan Motor Circuit Basic Model









## Fuel Gage & Sender Unit



# Full Time 4WD Control Circuit




# Selective 4WD Circuits






# EMPi Engine Control Management System Part 1




# EMPi Engine Control Management System Part 2







# Front Washer & Wiper Motor



# Rear Defogger System



# Rear Wiper & Washer



**Thank You!**

**For More information on other publications visit us at  
[www.yokohamamotors.com](http://www.yokohamamotors.com)**

**Suzuki**

**Subaru**

**Mitsubishi**

**Daihatsu**

**Honda**

**Toyota**

**Nissan**

**Others**

# SUBARU

## SERIES

Full Mechanical Version Including  
Identification and Codes  
General Maintenance & Tune-Up  
Suspension  
Steering  
Brake System  
Engine Cooling System  
Air - Fuel - Exhaust  
Carburetor - Fuel Injection  
Starter & Alternator  
Engine & Transmission Removal  
Engine Overhaul  
Transmission TM 60 Series 2WD-4WD  
Diff-Lock System  
Clutch System  
Drive Axels  
Electrical Diagrams  
Much More!  
Over 200 Pages of Easy to Use Diagrams

Van  
Truck  
2WD  
4WD  
V-KS3  
V-KS4  
V-KVS  
V-KV4



# SUBARU

## SERIES

Full Mechanical Version Including  
Identification and Codes  
General Maintenance & Tune-Up  
Suspension  
Steering  
Brake System  
Engine Cooling System  
Air - Fuel - Exhaust  
Carburetor - Fuel Injection  
Starter & Alternator  
Engine & Transmission Removal  
Engine Overhaul  
Transmission TM 60 Series 2WD-4WD  
Diff-Lock System  
Clutch System  
Drive Axels  
Electrical Diagrams  
Much More!  
Over 200 Pages of Easy to Use Diagrams

Van  
Truck  
2WD  
4WD  
V-KS3  
V-KS4  
V-KVS  
V-KV4

LuLu Publishing Retail \$69.95

ISBN 978-0-557-02780-4 90000



9 780557 027804