


D4-10

Direct Drive



Owner's Manual

BUSH HOG
INCORPORATED

SHAW MFG. CO. - GALESBURG, KANSAS
Division of Bush Hog, Inc. - Selma, Alabama

Warranty

Bush Hog Tractors are warranted to the original retail purchaser to be free from manufacturing defects under normal use and service for one year from the date of purchase or for 90 days, if the tractor is used for commercial or rental purposes. The Bush Hog Company will replace defective parts free of charge, except items warranted by the original manufacturer such as engines or other products that carry a separate warranty. When defective parts are returned, they

must be prepaid.

This warranty will not apply to Bush Hog products repaired or altered outside of a Bush Hog dealer service station. Neither will the warranty apply on any failure resulting from misuse, negligence or accident.

The placing on a Bush Hog product of any part or attachment not approved by the Company shall void the warranty.

INTRODUCTION

The Direct-Drive tractor is manufactured to the traditionally high standards of Bush Hog, Inc. It has many quality features which have been designed with you, the customer, in mind.

Your dealer is sincerely interested in your new tractor and has the desire to help you get the most value from it. After reading this manual thoroughly, you will find that you can do many of the regular service jobs quickly and easily. However, when you are in need of parts or major service, be sure to see your dealer.

When you are in need of parts, be prepared to give your dealer both the tractor and engine serial numbers.

DEALER SERVICES

Your dealer offers complete tractor service. His trained personnel have access to accurate, detailed service information. Some of these dealer services are listed below.

1. Testing battery and electrical components.
2. Cleaning and adjusting carburetor.
3. Cleaning out engine carbon.
4. Testing engine compression.
5. Replacing motor-generator brushes, cleaning Commutator.
6. Adjusting Engine Governor speed.

SPECIFICATIONS

DIMENSIONAL DATA - ALL MODELS

	TRACTION TIRES	HIGH FLOTATION TIRES
WHEEL THREAD		
Front	29 inches	29 inches
Rear	24½ or 30½ inches	24½ or 30½ inches
TIRE SIZES		
Front	16 x 6.50 x 8	16 x 6.50 x 8
Rear	23 x 8.50 x 12	23 x 8.50 x 12
TIRE INFLATION		
Front	12 psi	8 psi
Rear	6 psi	5 psi
DIMENSIONS		
Wheel Base	49 inches	49 inches
Overall length	68 inches	68 inches
Overall Height	38¾ inches	38¾ inches
Overall width (max.)	36 inches	39 inches
(min.)	33 inches	33 inches
Weight	700 lbs.	

BRAKES

Double acting foot operated

CLUTCH

Automotive Disc Type

STEERING

Open Gear 6.4 to 1

WHEEL BEARINGS

FRONT- Taper Roller
REAR- Sealed Ball

GROUND SPEEDS MPH

GEAR	ENGINE RPM
1 Low	3600- 1.99
2 Low	3600- 3.23
R Low	3600- 3.89
1 High	3600- 5.86
2 High	3600- 9.66
R High	3600- 9.66

ENGINE

Manufacturer	Wisconsin
Model	TRA10D
Cylinders	One
Cycle	Four
Bore and Stroke	3 1/8 x 2 7/8"
Displacement	22.05 cu. in.
Speeds	1600 to 3600 rpm
Horsepower	10.10 at 3600
Compression Ratio	7.00 to 1
Valve Clearance (Intake)	
Cold	.006
Valve Clearance (Exhaust)	
Cold	.012

TRANSMISSION

TYPE TRANSAXLE
4 FWD, 1 Rev.

LUBRICANT
4 pints Shell Micoma
No. 72 the equivalent
90 wt. trans. lubricant

CAPACITIES

FUEL TANK
1 US Gal.

CRANKCASE
1 Quart

ELECTRICAL SYSTEM

BATTERY
45 AMP 12 Volt
20 hr. rating

STARTER MOTOR
Delco Remy

IGNITION
Key Type


STARTER SWITCH
Key Type

SPARK GAP
.030

GENERATOR
Delco Remy

BREAKER POINT GAP
.020

CONTROLS



IMPORTANT : For all instructions pertaining to the operation of the tractor engine, refer to your instruction book for the Wisconsin Air Cooled Heavy Duty Engine TRA-10D.

FUELS

FILLING FUEL TANK

Raise tractor hood to fill the fuel tank. To keep dirt out of the tank while filling, wipe the dust and dirt from around the tank cover before removing it. Use a regular grade gasoline of a recognized brand. White gas may be used only if the octane rating is at least 75. Never use premium gasoline. **NOTE :** Do not mix oil with gasoline. Be sure fuel containers are absolutely clean.

LUBRICANTS

ENGINE CRANKCASE

Oil used in the engine crankcase should have an American Petroleum Institute (API) SAE classification of service MS.

According to the prevailing air temperature, use oil of viscosity as shown in the following chart.

Air Temperature Season	Single - Viscosity Oil
30° to 90° F. summer	SAE 30
-0° to 30° F. winter	SAE 10W
Below 0° F.	SAE 5W-20

Use of SAE 5W-20 oil may cause some increase in oil consumption. Check oil level more often when you are using this oil.

Do not fill engine crankcase above full mark.

TRANSMISSION

1. All Transaxles are filled with four pints of Mobil Oil C-90.
2. For refill or make-up oil in the field, we recommend SAE 90 weight oil.

Do not attempt to dismantle any part of your tractor transmission. See your dealer for all transmission service.

LUBRICATION AND PERIODIC SERVICE

The recommended lubrication and service periods for your tractor are as follows :

1. Daily, or every 5 hours of operation
2. Every 50 hours of operation
3. Every 100 hours
4. Every 500 hours of operation or each spring and fall season

The following procedures are in order of frequency.

DAILY OR EVERY 5 HOURS OF OPERATION

ENGINE CRANKCASE OIL LEVEL

Raise tractor hood, wipe off dust and dirt, and unscrew oil dipstick. If necessary, add sufficient oil of the proper viscosity to bring oil level up to the full(F) mark on the dipstick when the dipstick is screwed in tight. **NOTE :** Oil should not be over the full mark. Be sure the tractor is on level ground and engine is stopped before you check oil level.

FLYWHEEL SCREEN

Make a visual check of the outside screen. The engine is air cooled and must have an ample supply of air to prevent the engine from overheating. Clear away all dirt or debris covering any of the screen.

To be sure the screen is never completely blocked with dry grass clippings, check screen often, especially when mowing or mulching leaves.

BATTERY

Check battery, making sure liquid is up to filler ring in each cell. If necessary, add distilled water. Check battery terminals to be sure they are clean and free from corrosion.

TIRE PRESSURE

Inflate tires to pressures shown in chart below :

TIRE	ALL PURPOSE TRACTION TIRES	HIGH FLOTATION TIRES
Front	12 psi	8 psi
Rear	6 psi	5 psi

AIR CLEANER

See engine manual.

EVERY 50 HOURS OF OPERATION

Repeat all 5 hour service checks and perform additional service as follows :

ENGINE CRANKCASE

Drain engine oil every 50 hours of operation under normal conditions or every 20 hours of operation under very dusty conditions.

If it is possible, park tractor on slight incline with the front of the tractor lower than the rear. Raise the hood and remove the front grille. Remove drain plug and allow oil to drain into a container. Replace drain plug and refill crankcase with the proper grade oil to the proper oil level.

NOTE : The best time to drain the crankcase is at the end of a day's operation. At this time the oil is hot, and all foreign material in the crankcase is in suspension.

EVERY 100 HOURS OF OPERATION

Repeat all 5 and 50 hour service checks and perform additional service as follows :

ENGINE SHROUDS

Be sure the engine cooling fins and the shrouds

which enclose them are clean at all times. Dirt, oil and other debris which may have entered the screens could lodge on cooling fins thereby restricting the normal air flow. This causes serious damage to engine parts because of over heating.

Remove the bolts which hold the engine shroud in place and brush out all dirt from the cooling fins. Clean the inside of the shroud thoroughly. Soak off all oil deposits with a safe solvent. Caution : Do not run engine with shrouds removed.

Remove rotating screen and check for oil or dirty fins on the flywheel. Be sure screen is clean and not damaged.

TRANSMISSION OIL LEVEL

Remove oil level (filler) plug with stick type gauge. When required, use a pressure oil can to add transmission lubricant through filler hole until oil shows on dipstick. Be sure the tractor is on a level surface when checking.

EVERY 500 HOURS OF OPERATION OR EACH SPRING AND FALL SEASON

If the tractor is to be placed in storage, each fall and again in the spring the following service should be performed :

Repeat all 5, 50, and 100 hour service checks and perform additional service as follows-

LUBRICATION OF FRONT AXLE AND STEERING SECTOR

Use pressure gun grease to lubricate steering column and front axle fittings with SAE (seasonal grade) multi-purpose type grease. Wipe fittings clean after lubrication.

SERVICE

HOOD AND GRILLE

Engine and related parts are easily accessible by lifting and raising the hood. The hood will remain open after you raise it to a near vertical position. To remove the grille for access to the ignition points, oil drain, etc., release the spring clamps and lift the grille out. When you are replacing the grille, be sure the guide pins on the grille bottom are in place.

FUEL SYSTEM

Proper inspection and service of your fuel system are important to continued successful operation of your tractor.

ELECTRICAL SYSTEM

ADJUSTING POINTS

Disconnect spark plug cable to prevent accidental starting of the engine. Remove the ignition point cover and rotate engine flywheel until the points are fully open.

Check point gap with a .020 inch Feeler gauge. If an adjustment is required, loosen locking screw

and move screwdriver in V-slot until the points are properly set.

After tightening the locking screw, recheck the point gap. To replace points, remove screws. Be sure lockwashers are in place before reassembly.

SPARK PLUG GAP

Check spark plug gap and condition of electrodes after every 100 hours of operation. Distance between electrodes should be .025 inch. Bend the outer electrode only for proper gap.

If electrodes have burned short or have become pitted, install a new spark plug. Use a spark plug wrench to replace plug. Always use a new spark plug gasket when replacing plug. Tighten plug to at least 27 ft. - lbs. torque.

BATTERY

Your tractor has a 12 volt electrical system. When you are replacing the battery, use a 12 volt 45 amp- 20 hour rating. CAUTION : To prevent accidental operation of the starter or engine, always disconnect the spark plug cable when working on the electrical system. Also do this when you are making adjustments to the engine or other moving parts.

CLEANING BATTERY

Remove battery cables and use a wire brush to remove corrosion from around the battery terminals. Wash terminals with a solution consisting of one part baking soda to four parts water. Do not allow cleaning solution to run into battery cells.

Connect battery cables and coat terminals with petroleum jelly. Be sure the cables are tight.

Wipe and wash entire battery case, platform and hold down straps with clear water. Be sure top and bottom vent holes in each cell cap are open.

CHECKING BATTERY WATER LEVEL

Check the liquid level of each cell by removing the cap. Water should completely cover the cells at all times. Fill each cell to ring level inside filler hole with distilled water. Use clean distilled water when possible to fill battery. When absolutely necessary, clean drinkable water may be used.

Keeping the liquid at proper level during winter or freezing weather is especially important. Also the battery must be kept fully charged to prevent freezing.

IMPORTANT : When adding water to the battery during freezing weather, be sure the engine is running and continues to run until the water has had a chance to mix thoroughly. This running time should be at least one hour.

Battery connections should be tight at all times, especially when batteries are being charged. Loose cables will cause arcing and pitting of the connections and cause eventual failure.

NOTE ; Be careful not to allow sparks or flames near a charged battery.

TROUBLE SHOOTING

HARD STARTING

A. FAULTY IGNITION

Check for presence of spark by disconnecting high tension wire from the plug and holding the wire close to the cylinder head while cranking the engine with the starter. If there is no spark, check to see if:

1. Breaker point gap is incorrect.
2. Breaker points are worn or pitted. Replace
3. Spark plug gap is incorrect.
4. Spark plug electrodes are pitted or fouled. Replace plug.
5. If the foregoing fails to correct the problem, see your dealer.

B. FAULTY CARBURETION

1. Gasoline may not be getting to the carburetor because of an air lock in the line. Lines may be gummed and plugged.
2. Carburetor may be dirty or out of adjustment.

If the engine can be turned over slowly by hand with little effort, there is a loss of compression. See your dealer or serviceman.

ENGINE MISSING UNDER LOAD

- A. Check spark plug for proper gap.
- B. Check for lean fuel mixture. Adjust the carburetor high speed screw.
- C. Check for dirty (fouled) spark plug or an improper type plug.
- D. Pitted or worn Breaker Points should be replaced with a new set.
- E. See your serviceman for proper ignition and carburetion adjustments.

BACK FIRING

- A. Check carburetor for lean fuel mixture.
- B. Check for sticky intake valve or improper ignition. See your serviceman or dealer.

KNOCKING

- A. Check fuel supply for low octane rating. Use only quality grade of a regular gasoline.
- B. Check engine for overheating. See overheating below.
- C. Check crankcase oil level. Fill to (F) mark on dipstick. NOTE: If an engine knock has developed because of lack of crankcase oil, have your dealer check condition of the piston rod and cap.
- D. See your serviceman for possible loose connecting rod, improper timing or excessive carbon in combustion chamber.

LOSS OF ENGINE POWER

A. OVERHEATING

1. Check and clean screens and engine shrouds.
2. Using premium gasoline with high octane rating. Use regular gas only.
3. Check carburetor for lean fuel mixture.
4. Check oil dipstick for excessive oil in engine crankcase. Do not fill above oil level mark.
5. Check breaker points for proper gap.

B. DIRTY AIR CLEANER

1. Drain oil from the cleaner.
2. Rinse the cleaner with kerosene.
3. Replace the oil.

C. PARTLY CLOSED CHOKE

1. Check to be sure the choke control cable is not jammed.
2. Choke must be completely open (choke lever down) after engine is warmed up except on extremely cold days.

ENGINE OPERATING ERRATICALLY

Check the following:

- A. Carburetor set too lean
- B. Clogged fuel line
- C. Water in fuel
- D. Faulty choke control
- E. Loose electrical connections
- F. Air leaks in carburetor connections or gasket
- G. Carburetor jet clogged
- H. Loose throttle cable

ENGINE WILL NOT IDLE

- A. Check carburetor adjustments
- B. Check for dirty carburetor
- C. Check and set spark plug gap
- D. Check carburetor for air leaks in gasket
- E. See your serviceman for possible leaky valves or faulty condenser.

TRANSMISSION WILL NOT STAY IN GEAR

- A. Shift gear firmly without letting gears grind before engaging.
- B. See your serviceman to replace worn gears

BRAKES NOT EFFECTIVE

- A. Adjust brake linkage
- B. Replace brake shoes if they are worn excessively. See your serviceman

IMPROPER STEERING OR EXCESSIVE FRONT

TIRE WEAR

Check wheel alignment and toe-in

CLUTCH HARD TO OPERATE

Check linkage control and springs

STARTER INOPERATIVE OR WILL NOT TURN ENGINE

- A. Check for discharged battery
- B. If rotary mower drive is engaged, disengage. See mower operator's manual
- C. Tighten motor-generator belt
- D. Check electrical connections

TRACTOR WILL NOT MOVE WITH ENGINE RUNNING


- A. Be sure tractor is in gear
- B. Check drive coupling
- C. Check axles. If they are turning, look for sheared key.

USE OF DRAWBAR HITCH

The dual purpose drawbar hitch can be attached to the drawbar as shown for general use, or it can be reversed on the drawbar with the clevis to the rear for use with a plow or cultivator.

If the hitch is to be used with a plow or cultivator, remove the hitch by loosening the two setscrews and removing the drawbar pin and the spacer. Attach the hitch to the drawbar so that the clevis end of hitch can be used. Tighten the two setscrews. You may also attach the hitch at any point on the drawbar by loosening the setscrews and moving the hitch to the desired position.

Use the attachment lift lever (page 8) to raise and lower all rear mounted attachments.




HITCH FOR REAR ATTACHMENTS

REAR WHEELS

Rear wheels are factory assembled in the narrow (27-inch) tread. Wheels can be turned around on the hubs for a wide (33-inch) wheel tread for greater stability. Remove wheel bolts, turn wheel around with valve stem inward, and reassemble on hub.

FRONT AND REAR TIRE SELECTION

1. Use suburban 8.50 x 12 rear and 16-6.50 x 8 front for travel over soft ground or areas where tire tracks may be objectionable.
2. Use traction tire 16-6.50 x 8 front and 8.50 x 12 rear for greater traction when working heavier loads.



ADJUSTMENT OF IMPLEMENT CLUTCH S2371

The implement clutch on your tractor was set at the factory and should not need adjusting. However, in case of excessive wear, it is easily adjusted.

1. If clutch does not disengage when lever is pulled back, the nut on the control rod needs to be tightened. (Do all work with tractor shut off). With the control lever in the forward position, tighten nut 3 to 4 full turns. Put lever in back position. With your hand turn clutch pulley, if pulley turns freely of drive pan, your clutch is now in adjustment. CAUTION: Do not tighten nut more than necessary.

2.If the above instructions fail to give satisfactory results the next step is to check nuts on front of clutch. Loosen locknuts and tighten back nut one full turn. Tighten locknuts. See if clutch will operate. If not, repeat above instructions. NOTE: A maximum of 5 turns on each nut. Tighten all nuts the same amount of turns.

Should the clutch still fail to operate there is a chance you have a defective or worn part. Take the clutch to your local dealer for servicing.

NOTE: For longer clutch life it is recommended that when tractor is being used without attachments on the clutch that the clutch be engaged at all times.

ATTACHMENT LIFT LEVER

When the attachment lift lever is in the forward position, the attachment is in the raised position. Moving the lever backward lowers the attachment. Press thumb release and move lever until attachment operates at desired height. Removing pressure from the thumb release locks the operating lever and the attachment in desired position.

To set the lever in float position, press thumb release. Lock in position with lock lever.

FRONT WHEEL TOE-IN

Measure distances A and B (page 9). The tractor

has proper toe-in or alignment when dimension A is 3/16 inch less than dimension B. When it is necessary, remove ball joint on either end of Rod C and adjust till proper toe-in is obtained. Tighten jamb nut firmly.

TRACTOR CLUTCH ADJUSTMENT

Right and left directions in this adjustment section are determined by looking in the direction of forward travel.

- 1.Remove the quick pin from the clevis.
- 2.If gears do not mesh easily, shorten the adjusting rod by turning the clevis to the left. This will raise the clutch pedal and allow the gears to mesh easily.
- 3.Replace quick pin through clevis as it was before you made the adjustment.


BRAKE ADJUSTMENT

- 1.The brake cable is attached to the brake pedal by a clevis. To adjust, remove pin from clevis and turn clevis clockwise to tighten.
- 2.To adjust emergency brake lock turn 1/4" nut on locking knob rod.

SEE YOUR DEALER FOR ADDITIONAL CLUTCH AND BRAKE ADJUSTMENTS.


STORAGE

If your tractor will not be used for a period of



SEAT ADJUSTMENT

The tractor seat may be adjusted into different positions. Loosen the thumb screws and adjust the seat to a comfortable position. Tighten thumb screws. The back rest can also be adjusted to the desired height. NOTE: The D-4-10 tractor has a tool box for your convenience.



FRONT WHEEL TOE-IN

time such as through the winter season, perform the following operations:

Drain the gasoline tank and crank the engine to burn gas in carburetor.

Remove spark plug and pour in one tablespoon of SAE 30 oil. Turn engine over manually at least two times and replace spark plug.

1. Remove battery and store it where it will not freeze. Check water level and refill battery if necessary.
2. Clean tractor exterior thoroughly, removing all mud, dirt, grease and other materials.
3. To prevent rust, touch up all unpainted and exposed surfaces with paint.
4. Check all visible moving parts for wear, breakage or damage. Now is the time to order any parts required and make necessary repairs to avoid needless delay when you use the tractor again next season.
5. Block up tractor to take weight off tires. If it

is possible, store tractor in a cool, dark place to prevent excessive tire deterioration.

6. Remove belt tension from all belts. Loosen motor generator.

Your dealer is equipped to give your tractor a complete service check and make recommendations for replacing parts which are in need of attention.

PREPARING TRACTOR FOR USE AFTER STORAGE

ENGINE

1. Drain and refill tractor crankcase with proper weight and grade oil.
2. Clean spark plug and set gap.
3. Check ignition point gap.

TRACTOR


1. Reinstall Battery. Check liquid level.
2. Check transmission oil level.
3. Check tire inflation.

TRANSAXLE S2155

Part No.	Description	Part No.	Description
S98	Shim, Pinion Adjusting	S2775	Hand Grip
S592	Key, Woodruff	S2046	Gasket, Main Housing
S1007	Gear	S2047	Gasket, Cover
S1008	Gear	S2048	Gasket, PTO Cover
S1009	Gear, Cluster	S2051	Shaft, Detent
S1013	Collar, Shift	S2052	Bearing, Ball
S1014	Shaft, PTO	S3407	Lever Assembly
S1019	Ball, Detent	S2057	Housing, Shift
S1020	Spring	S2058	Retainer, Shift
S1036	Cone, Roller Bearing	S2078	Housing, Main
S1039	Bearing, Ball	S2079	Housing, Aux.
S1041	Housing, Differential	S2080	Cover, Aux. Housing
S1042	Pin Gear	S2081	Ring, Snap
S1043	Differential Assembly	S2082	Ring, Retaining
S1044	Shaft, differential retainer	S2083	Ring, Retaining
S1045	Shaft, differential cross	S2084	Seal, Oil
S1046	Pin, Retainer	S2085	Ring, "O"
S1047	Gear, Side	S2096	Ring, Quad
S1048	Gear, Ring	S2097	Ring, Snap
S1049	Gear	S2156	Bolt, Ring Gear
S1056	Gear	S2182	Seal, Axle
S1057	Collar, pinion shaft clutch	S2237	Bearing, Ball
S1059	Bearing, Ball	S2240	Plug, Magnetic Pipe
S1060	Cup	S2253	Spacer Washer
S1061	Ring, Snap	S2254	Spacer
S1062	Pinion, Bevel	S2255	Bushing
S1069	Bearing, Roller	S2257	Shifter, High-low
S1072	Ring, Snap	S2278	Fork, PTO Shift
S1073	Ring, Snap	S2279	Arm, PTO Shaft
S1074	Ring, Snap	S2280	Arm, High-low
S1075	Ring, Snap	S2446	Roll Pin
S1076	Bearing, Ball	S2700	Seal
S1077	Gear	S2766	Snap Ring
S1078	Shaft	S3324	Shifter Block
S1079	Bearing, Ball	S3321	Shifter Plate
S1082	Bearing, Ball	S3562	Shifter Assembly
S1083	Dipstick	S3563	L.H. Axle Assembly
S1086	Dowell Pin	S3564	R.H. Axle Assembly
S1087	Retainer, Pinion Shaft	296	Cotter Pin
S1089	Seal, Oil	947	Capscrew
S1092	Key, Pinion Shaft	1239	Capscrew
S1993	Shaft, Axle	15066	Capscrew
S1996	Housing, Axle	15110	Setscrew
S2013	Key, Woodruff	15392	Pin, Roll
S2026	Plate, PTO Cover	15523	Nut, Pinion Shaft Bearing
S2044	Gasket, Shifter	15567	Nut, Slotted
S2045	Gasket, Axle Housing	15800	Lockwasher
	15801	Lockwasher	
	15808	Lockwasher	
	15812	Lockwasher	
	15903	Lockwasher	
	15910	Flatwasher	
	19097	Capscrew	


HOOD, GRILL, AND HEADLIGHT ASSEMBLY

Part No.	Description	Qty.	Part No.	Description	Qty.
S540	Hood	1	15528	Nut 5/16-18 UNC	2
S548	Pipe Bushing	2	15531	Nut 1/4-20 UNC	8
S919	Headlight	2	15568	Nut 3/16-24 UNC	1
S951	Hood Trim, side	2	15802	Lockwasher 3/8 med.	1
S952	Hood Trim, top	1	15807	Lockwasher 1/4 med.	8
S956	Trim Bracket	4	15808	Lockwasher 5/16 med.	2
S1117	Grill Latch	1	15812	Lockwasher 3/8 med.	4
S1401	Grill Top	1	15907	Flatwasher 5/16 std.	2
S1405-1	Grill Side, L.H.	1	19007	Bolt 1/4-20 UNC x 3/4	8
S1405-2	Grill Side, R.H.	1	19049	Bolt 5/16-18 UNC x 1 3/4	2
S1983	Battery Box	1	19100	Bolt 3/8-13 UNC x 3/4	4
S1782	Hood Brace	1	19414	Stove Bolt & Nut	14
S1812	Grill	1	S2442	Tail Light	1
743	Nut 3/8-24 UNF	2			




FRONT AXLE ASSEMBLY

Part No.	Description	Qty.
119	Flatwasher 3/4"	2
120	Nut, castellated	2
258	Key, 1/4 x 3/4	1
449	Grease Fitting	3
743	Hex Nuts 3/8"	2
1239	Capscrew	1
15108	Setscrew	2
15545	1" Hex Nut	1
15912	Bushing	2
15977	Cotter Pin 5/32 x 1 1/2	2




Part No.	Description	Qty.
S209	Set Collar	1
S518	Tie Rod	1
S528	Bushing	6
S590	Ball Joints	2
S1788	Spindle R.H.	1
S2758	Pivot Bolt	1
S3036	Steering Arm	1
S3101	Spindle L.H.	1


BATTERY CLAMP AND CONTROL CABLES



Part No.	Description	Qty.
S639	Throttle Control	1
S882	Choke Control	1
S1386	Battery Clamp	1
15526	Wing Nut	2
15807	Lockwasher	2




FRONT WHEEL ASSEMBLY 4.00 x 4.80 - 8



ALL PURPOSE TIRE 4.00 x 4.80-8

Part No.	Description	Qty.
22	Bearing Cone	2
170	Bearing Cup	2
S805	Inner Tube	1
S806	Tire 4.00 x 4.80-8 rib buttress	1
59	Dust Cap	1
S948	Grease Seal	1
S1517	Rim	1
6407	Hub	1
15143	Hub Bolt	4
15522	Lug Nut 7/16-20 UNF	4
S1127	Wheel & Tire Assy.	1





TRACTION THREAD TIRE 16 x 6.50 - 8

FRONT WHEEL ASSEMBLY 16 x 6.50 - 8

Part No.	Description	Qty.
22	Bearing Cone	2
170	Bearing Cup	2
S885	Tire 16 x 6.50-8 traction	1
S886	Valve TR413	1
S879	Rim	1
59	Dust Cap	1
S948	Grease Seal	1
6407	Hub	1
15143	Hub Bolt	4
15522	Lug Nut 7/16-20 UNF	4
S1175	Wheel & Tire Assy.	1

Part No.	Description	Qty.	Part No.	Description	Qty.	Part No.	Description	Qty.	Part No.	Description	Qty.
S207	Hand Grip	1	S2446	Roll Pin	1	15516	Locknut 5/8 - 18 UNF	4	15516	Locknut 5/8 - 18 UNF	4
S524	Rivet	1	S3003	Lift Lever Shaft	1	15527	Locknut 3/8 x 16 UNC	2	15527	Locknut 3/8 x 16 UNC	2
S364	Lock, Lift	1	S3004	Crank Unit	1	15531	Hex Nut 1/4 - 20 UNC	4	15531	Hex Nut 1/4 - 20 UNC	4
S576	Lift Bar	2	S3006	Lift Assist Crank	1	15130	Setscrew 1/2-13 UNC x 1 1/4	2	15130	Setscrew 1/2-13 UNC x 1 1/4	2
S592	Key, Woodruff 3/16 x 3/4	1	S3229	Lift Lever	1	15807	Hex Nut 3/8-16 UNC	9	15807	Hex Nut 3/8-16 UNC	9
S1420	Bracket, Front Lift L.H.	1	1239	Capscrew 5/16 x 18 UNC x 1	1	1582	Lockwasher 1/4	4	1582	Lockwasher 1/4	4
S1420	Bracket, Front Lift R.H.	1	1273	Presto Pin	1	15812	Lockwasher 3/8	9	15812	Lockwasher 3/8	9
S1421	Bracket, Rear Lift	2	7108	Hitch Pin	1	15907	Flatwasher 5/16	1	15907	Flatwasher 5/16	1
S1462	Bearing	1	15030	Capscrew 5/8 x 18 UNF x 1 1/2	2	15908	Flatwasher 5/8	1	15908	Flatwasher 5/8	1
			S2174	Lift Rod	1	15981	Cotter Pin	1	15981	Cotter Pin	1
			S2175	Bearing	1	19007	Capscrew 1/4 x 20 UNC x 3/4	4	19007	Capscrew 1/4 x 20 UNC x 3/4	4
			S2287	Front Lift	1	19409	Presto Pin	1	19409	Presto Pin	1
				Lift Strap	1						






TRANSAXLE S2155


S3563 L.H.
S3564 R.H.

NOTE
RING GEAR S1048 AND PINION SHAFT S1062 ARE SOLD ONLY AS A UNIT AS THEY ARE MATCHED PAIRS.



Wiring Diagram

Part No.	Description	Qty.
S917	Light Switch	1
S1303	Ammeter	1
S1809	Ignition Switch	1
S1810	Solenoid	1
S1850	Ground Cable	1
S2191	Voltage Regulator	1




Clutch and Brake Pedal Assembly

Part No.	Description	Qty.	Part No.	Description	Qty.
S655	Spring	1	296	Cotter Pin 1/8 x 1 1/2	2
S767	Clevis	1	15528	Hex Nut 5/16 - 18 UNC	6
S1369	Adjusting Rod	1	15582	Hex Nut 3/8-16 UNC	1
S1515	Pedal Pivot	2	15608	Locknut 1/4-20 UNC	2
S1796	Brake Pedal	1	15808	Lockwasher 5/16	6
S1797	Clutch Pedal	1	15812	Lockwasher 3/8	1
S2894	Spring Kit	1	15908	Flatwasher 5/8	2
S2895	Angle Bracket	1	15980	Cotter Pin 1/16 x 3/4	3
S2896	Spring Anchor	1	19102	Capscrew 5/16-18 UNC x 1	6
S2897	Eye Bolt	1	19106	Capscrew 3/8 - 16 UNC x 1 1/2	1
S2898	Spring	1	19433	Presto Pin No. 16	1
S3206	Park Brake Cable	1	19434	Clevis Pin 1/4 x 1	1
S3207	Brake Cable	1	19445	Clevis Pin 1/4 x 3/4	2
S3231	Knob	1			

S2319 IS USED ON D-4-10 ONLY.
S2400 IS USED ON D-4-7 & H-10 ONLY

PART NO.	DESCRIPTION	QTY.	PART NO.	DESCRIPTION	QTY.
H4	HAND GRIP	1	S2370	RETAINER RING	1
S684	KEY	1	S2373	CONTROL STRAP	1
S2262	CLUTCH PULLEY	1	S2374	LEVER WELD.	1
S2288	CLUTCH FINGER	3	S2375	STABILIZER STRAP	1
S2296	PRESSURE BUTTON	1	S2398	BEARING & COLLAR	1
S2297	CLUTCH DISC	1	S2399	MOUNT PLATE	1
S2319	CLUTCH HUB WELD.	1	S2400	CLUTCH HUB WELD.	1
S2320	SPRING	1	I5527	HEX NUT 3/8 - 16UNC	2
S2342	BEARING & COLLAR	1	I5584	HEX NUT 1/4 - 20UNC	3
S2343	CONTROL ROD	1	I5915	FLATWASHER 3/8	1
S2345	PLUNGER	1	I5979	COTTER PIN 1/8 x 3/4	1
S2369	SPRING	3	I9504	LOCKNUT 1/4-20UNC	3


S2371 Clutch Assembly 1



BRAKE ASSEMBLY


Part Qty. Description
No.


S205	1	Retaining Ring
S588	1	Brake Drum
S709	1	Brake Cam
S710	2	Brake Shoe
S716	2	Brake Spring
S718	1	Brake Lever
S722	1	Spacer Washer
S642	1	Mounting Plate
947	1	Bolt 1/4-20 UNC x 3/4
1214	3	Capscrew 5/16-18 UNC x 3/4
15800	1	Lockwasher 1/4 med.
15801	2	Lockwasher 5/16 med.
15907	1	Flatwasher 5/16
15911	1	Flatwasher 1/4




SEAT, FRAME, FENDER, AND DASH ASSEMBLY

Part No.	Description	Qty.	Part No.	Description	Qty.
S571	Cushion - Back	1	15581	Nut 1/2-13 UNC	2
S572	Cushion - Lower	1	15582	Nut 3/8 - 16 UNC	10
S1409-1	Foot Rest L.H.	1	15595	Thumbscrew 5/16 UNC x 3/4	2
S1409-2	Foot Rest R.H.	1	15806	Lockwasher 1/2	2
S1453-1	Fender L.H.	1	15807	Lockwasher 1/4	12
S1453-2	Fender R.H.	1	15812	Lockwasher 3/8	10
S1500	Battery Box	1	19007	Capscrew 1/4 UNC x 3/4	10
S1607	Seat	1	19100	Capscrew 3/8 UNC x 3/4	10
S1633	End, Frame	1	19106	Capscrew 3/8 UNC x 1 3/4	4
S2310	Mount Plate	1	S2425-1	Fender Skirt R.H.	1
S1783	Base Frame	1	S2425-2	Fender Skirt L.H.	1
15527	Locknut 3/8-16 UNC	4	19102	Capscrew 5-16" UNC x 1	4
15531	Nut 1/4-20 UNC	12	15528	Nut 5/16 - 18UNC	4
			15808	Lockwasher 5/16	4







Part No.	Description	Qty.
S960	Tire, Tube & Rim Assy.	2
S606	Tube	1
S894	Rim	1
S958	Tire 6 x 12 Suburban	1
S748	Hub	2
15412	Hub Bolt	5
15522	Hub Nut	5



Part No.	Description	Qty.
S785	Tire, Valve Stem & Rim Assy.	2
S889	Valve Stem	1
S887	Rim	1
S888	Tire 8.50 x 12 Suburban	1
S748	Hub	2
15412	Hub Bolt	5
15522	Hub Nut	5




Part No.	Description	Qty.
S1313	Tire, Tube & Rim Assy.	2
S611	Tire 6 x 12 Traction	1
S606	Tube	1
S894	Rim	1
S2106	Hub	2
15412	Hub Bolt	5
15522	Hub Nut	5




<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QTY.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
S3529	ACCESS PLATE	1	S605	RETURN SPRING	1
S8-1	PRESSURE PLATE, REAR	1	947	CAPSCREW 1/4-20UNC X 3/4	2
S8-2	PRESSURE PLATE PIN	3	1239	CAPSCREW 5/16-18UNC X 1	6
S8-3	LEVER ARM BRACKET	3	S1243	CLUTCH SHAFT	1
S8-4	LEVER ARM PIN	3	S2590-1	BEARING RETURN SPRING L.H.	1
S8-6	PRESSURE SPRING	3	S2590-2	BEARING RETURN SPRING R.H.	1
S8-7	LEVER ARM	3	S2664	CLUTCH YOKE	1
*S8-8	THROW-OUT BEARING SLEEVE	1	S2753	CLUTCH SHAFT WELDED ASSY.	1
*S8-9	THROW-OUT BEARING	1	I5066	CAPSCREW 3/8-16UNC X 1	2
*S8-17	THROW-OUT BEARING ASSEMBLY	1	I5067	CAPSCREW 3/8-16UNC X 1 1/2	2
S8-18	CLUTCH DISC	1	I5110	SETSCREW 1/4-20UNC X 1/4	1
S3358	CLUTCH HOUSING, REAR	1	I5112	SETSCREW 3/8-16UNC X 1 1/4	2
S3359	CLUTCH HOUSING, FRONT	1	I5503	NUT 3/8-16UNC	8
S206	RETAINER RING	1	I5517	NUT 5/16-18UNC	6
S507-2	BEARING HOLDER	1	I5807	LOCKWASHER 1/4 MED.	2
S534	PILOT BUSHING	1	I5801	LOCKWASHER 5/16 MED.	6
S600	PRESSURE PLATE-FRONT	1	S592	WOODRUFF KEY 3/16 X 3/4	2
S602	DRIVE SHAFT BEARING	1	I5468	COTTER PIN 3/32 X 1/2	3
S603	KEY 1/4 X 1/4 X 2	1	I9029	CAPSCREW 3/8-16UNC X 1 3/4	4
S1242	COUPLING	2	S2446	DRIVE PIN 1/4 X 1 1/4	3
S1229	DRIVE SHAFT	1			

T FACTORS, BEGINNING WITH
SERIAL NR 8300



Part No.	Description	Qty.
S205	Snap Ring	1
S590	Tie Rod Ends	2
S592	Woodruff Key 3/16 x 3/4	1
S1025	Spring	1
S2326	High-Low Rod	2
S2327	PTO Rod	1
S2336	Clevis	1
S2349	Clutch Lock	2
S2365	Spring Rod	1
S2619	Steering Housing	2
S2620	Bearing Retainer	1
S2627	Steering Stabilizer	1
S2636	Steering Wheel	1
S2637	Inspection Cover	1
S2642	Steering Cap	1
S2657	Shift Lever	1
S2668	Quadrant	2
S2669	Steering Shaft Housing	1
S2670	Steering Arm	1
S2676	Hood Latch (complete assy.)	1
S2686	Needle Bearing	2
S2688	Thrust Washers	4
S2690	Steering Gear	3
S2691	Bearing, Steering Housing (complete assembly)	1
S2693	Pivot Shaft	1
S2696	Hand Grips	1
S2697	Snap Ring	2
S2727	Dash Panel	4
S2731	Steering Shaft	1
S2741	Drag Link	1
S2772	Shifter Decal	1
S2971	Steering Wheel Decal	1
S3360	Wire Loom	1
3	Grease Fitting	1
1239	Capscrew 5/16-18 x 1	1
1507	Capscrew 3/8-16 x 3/4	2
15140	Setcrew 5/16-18 x 3/8 Skt. Hd.	4
15140	Roll Pin 1/4 x 1 3/4	4
15461	Locknut 3/8-16	1
15527	Hex Nut 5/16-18	1
15528	Locknut 3/8 - 24	2
15535	Lockwasher 5/16	2
15808	Lockwasher 3/8	5
15812	Flatwasher 1/4	1
15911	Cotter Pin 3/32 x 1	2
15976	Capscrew 5/16-18 x 1 1/2	4
19078	Capscrew 5/16-18 x 3/4	1
19079	Capscrew 5/16-18 x 3/4	3

S3775 Hydraulic Lift Kit For D4-10



Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	S586	1	Knob	25	S3840	1	Cylinder Lift Bar
2	S1960	1	Pin	26	S3847	1	Shaft Stop
3	S2125	1	1/2" Pipe Plug	27	S3855	1	Belt
4	S3663	1	Control Valve	28	S3864	1	Cylinder Mount Weldment
5	S3664	1	Pump	29	295	1	Cotter Pin 1/8" x 1 1/4"
6	S3715	1	Pulley	30	15389	1	Roll Pin 1/4" x 1"
7	S3744	1	Angle Left Front (Long)	31	15501	1	Hex Nut 5/16" - 24UNF
8	S3753	1	Tank Weldment	32	15508	2	Hex Nut 1/2" - 13UNC
9	S3755	1	Angle Right (Short)	33	15539	5	Hex Nut 3/8" - 16UNC
10	S3756	1	Angle Left Rear (Notched)	34	15552	5	Hex Nut 1/4" - 20UNC
11	S3757	1	Control Rod	35	15806	2	Lockwasher 1/2"
12	S3758	1	Control Valve Mount	36	15807	5	Lockwasher 1/4"
13	S3761	1	Control Lever	37	15808	3	Lockwasher 5/16"
14	S3767	1	Cylinder	38	15812	4	Lockwasher 3/8"
15	S3790	1	Generator Pulley	39	15907	3	Flatwasher 5/16"
16	S3799	1	Generator Nut	40	15911	3	Flatwasher 1/4"
17	S3818	1	Clamp	41	15978	2	Cotter Pin 3/32" x 3/4"
18	S3820	1	Hose 64 5/8" with Spring Guard	42	19092	2	Capscrew 1/2" - 13UNC x 2"
19	S3821	1	Hose 52 1/2"	43	19106	2	Capscrew 3/8" - 16UNC x 1 1/2"
20	S3822	1	Hose 11" with Spring Guard	44	19117	3	Capscrew 3/8" - 16UNC x 1"
21	S3823	1	Hose 11 1/2"	45	19433	1	Presto Pin
22	S3824	1	Hose 19"	46	20008	3	Capscrew 1/4" - 20UNC x 1"
23	S3825	4	Adapters	47	20015	2	Capscrew 1/4" - 20UNC x 2 1/4"
24	S3834	1	Floating Lift Bar	48	15528	3	Hex Nut 5/16" - 18UNC