

BUSH[®] HOG


INCORPORATED
SELMA, ALABAMA

VARI-DRIVE BELT DRIVEN TRACTORS

V3-6

V4-6

V4-7



OPERATORS MANUAL

INDEX

	PAGE
SPECIFICATIONS -----	27-1
OPERATION -----	27-3
FUELS AND LUBRICANTS -----	27-4
LUBRICATION AND PERIODIC SERVICE -----	27-9
SERVICE -----	27-10
TROUBLE SHOOTING -----	27-12
STORAGE -----	27-15

INTRODUCTION

THE VARI-DRIVE TRACTOR IS MANUFACTURED TO THE TRADITIONALLY HIGH STANDARDS OF BUSH HOG, INC. IT HAS MANY QUALITY FEATURES WHICH HAVE BEEN DESIGNED WITH YOU, THE CUSTOMER, IN MIND.

YOUR DEALER ALSO IS SINCERELY INTERESTED IN YOUR NEW TRACTOR AND HAS THE DESIRE TO HELP YOU GET THE MOST VALUE FROM IT. AFTER READING THIS MANUAL THOROUGHLY, YOU WILL FIND THAT YOU CAN DO MANY OF THE REGULAR SERVICE JOBS QUICKLY AND EASILY. HOWEVER, WHEN IN NEED OF PARTS OR MAJOR SERVICE, BE SURE TO SEE YOUR DEALER.

WHEN IN NEED OF PARTS, BE PREPARED TO GIVE YOUR DEALER BOTH THE TRACTOR AND ENGINE SERIAL NUMBERS.

WARRANTY

BUSH HOG TRACTORS ARE WARRANTED TO THE ORIGINAL RETAIL PURCHASER TO BE FREE FROM MANUFACTURING DEFECTS UNDER NORMAL USE AND SERVICE FOR ONE YEAR FROM THE DATE OF PURCHASE OR FOR 90 DAYS, IF USED FOR COMMERCIAL OR RENTAL PURPOSES. THE BUSH HOG COMPANY WILL REPLACE DEFECTIVE PARTS FREE OF CHARGE, EXCEPT ITEMS WARRANTED BY THE ORIGINAL MANUFACTURER SUCH AS ENGINES OR OTHER PRODUCTS THAT CARRY A SEPARATE WARRANTY. WHEN DEFECTIVE PARTS ARE RETURNED, THEY MUST BE PREPAID.

THIS WARRANTY WILL NOT APPLY TO BUSH HOG PRODUCTS REPAIRED OR ALTERED OUTSIDE OF A BUSH HOG DEALER SERVICE STATION. NEITHER WILL THE WARRANTY APPLY ON ANY FAILURE RESULTING FROM MISUSE, NEGLIGENCE, OR ACCIDENT.

THE PLACING UPON A BUSH HOG PRODUCT OF ANY PART OR ATTACHMENT NOT APPROVED BY THE COMPANY SHALL VOID THE WARRANTY.

	MODELS		
	VE-4-7 VR-4-7	VE-4-6 VR-4-6	VE-3-6 VR-3-6
ENGINE			
MANUFACTURER	WISCONSIN	TECUMSEH	TECUMSEH
MODEL	S-7D	HH-60	HH-60
CYLINDERS	ONE	ONE	ONE
CYCLE	4	4	4
BORE & STROKE	3 x 2 5/8	2 5/8 x 2 1/2	2 5/8 x 2 1/2
DISPLACEMENT	18.6 CU. IN.	13.5 CU. IN.	13.5 CU. IN.
SPEEDS	1600-3600 RPM	2400-3600 RPM	2400-3600 RPM
HORSEPOWER	7 1/4 AT 3600	6 AT 3600	6 AT 3600
COMPRESSION RATIO	7.00 TO 1	7.30 TO 1	7.30 TO 1
VALVE CLEARANCE (INTAKE)COLD	.006	.010	.010
VALVE CLEARANCE (EXHAUST)COLD	.012	.010	.010
CAPACITIES			
FUEL TANK	1 US GAL.	1 US GAL.	1 US GAL.
CRANK CASE	1 QUART	22 OUNCES	22 OUNCES
TRANSMISSION			
TYPE TRANSAXLE	4 FWD, 1 REV.	4 FWD, 1 REV.	3 FWD, 1 REV.
LUBRICANT	4 PINTS SHELL MICOMA No. 72 THE EQUIVALENT 90 WT. TRANS. LUBRICANT	4 PINTS SHELL MICOMA No. 72 THE EQUIVALENT 90 WT. TRANS. LUBRICANT	2 PINTS SHELL MICOMA No. 72 THE EQUIVALENT 90 WT. TRANS. LUBRICANT
GROUND SPEEDS MPH			
1 ST GEAR	VARIABLE .55 TO .90	VARIABLE .55 TO .90	VARIABLE 1.50 TO 2.75
2 ND GEAR	1.50 TO 2.75	1.50 TO 2.75	3.00 TO 4.75
3 RD GEAR	3.00 TO 4.75	3.00 TO 4.75	4.50 TO 6.90
4 TH GEAR	4.50 TO 6.90	4.50 TO 6.90	
REVERSE	2.00 TO 3.25	2.00 TO 3.25	2.25 TO 3.75
ELECTRICAL SYSTEM			
BATTERY	VE-4-7 45 AMP 12 VOLT 20 HR RATING	VE-4-6 45 AMP 12 VOLT 20 HR RATING	VE-3-6 45 AMP 12 VOLT 20 HR RATING
IGNITION	KEY TYPE SWITCH	KEY TYPE SWITCH	KEY TYPE SWITCH
STARTER SWITCH	PUSH BUTTON	PUSH BUTTON	PUSH BUTTON
STARTER MOTOR	DELCO REMY	BENDIX TYPE 12 VOLT DC	BENDIX TYPE 12 VOLT DC
GENERATOR	DELCO REMY	MAGNETO ALTERNATOR CIRCUIT WITH RECTIFIER PANEL	MAGNETO ALTERNATOR CIRCUIT WITH RECTIFIER PANEL

CONTINUED

PAGE 2


	VE-4-7	VE-4-6	VE-3-6
	VR-4-7	VR-4-6	VR-3-6
SPARK GAP	.025	.025	.025
BREAKER POINT GAP	.020	.020	.030
BRAKES	DOUBLE ACTING FOOT OPERATED CLUTCH & BRAKE	DOUBLE ACTING FOOT OPERATED CLUTCH & BRAKE	DOUBLE ACTING FOOT OPERATED, CLUTCH & BRAKE
CLUTCH	V-BELT PEDAL OPERATED	V-BELT PEDAL OPERATED	V-BELT PEDAL OPERATED
STEERING	OPEN GEAR 6.4 TO 1	OPEN GEAR 6.4 TO 1	OPEN GEAR 6.4 TO 1
WHEEL BEARINGS			
FRONT	TAPER ROLLER	TAPER ROLLER	TAPER ROLLER
REAR	SEALED BALL	SEALED BALL	SEALED BALL

**DIMENSIONAL DATA
ALL MODELS**

WHEEL TREAD	ALL PURPOSE AND TRACTION TIRES	HIGH FLOTATION TIRES
FRONT	28 INCHES	29 INCHES
REAR	24 1/2 OR 30 1/2	24 1/2 OR 30 1/2
TIRE SIZES		
FRONT	4.80/4.00 x 8	16 x 6.50 -8
REAR	6.00 x 12	23 x 8.50 - 12
TIRE INFLATION		
FRONT	12 PSI	8 PSI
REAR	6 PSI	5 PSI
DIMENSIONS		
WHEEL BASE	49 INCHES	49 INCHES
OVERALL LENGTH	68 INCHES	68 INCHES
OVERALL HEIGHT	38 3/4 INCHES	38 3/4 INCHES
OVERALL WIDTH		
(MAXIMUM)	36 INCHES	39 INCHES
(MINIMUM)	33 INCHES	33 INCHES

OPERATION

OPERATING CONTROLS



FUELS AND LUBRICANTS

FUELS

FILLING FUEL TANK -

RAISE TRACTOR HOOD TO FILL FUEL TANK. WIPE DUST AND DIRT FROM AROUND TANK COVER BEFORE REMOVING IT TO KEEP DIRT OUT OF THE TANK WHILE FILLING. USE REGULAR GRADE GASOLINE OF RECOGNIZED BRAND, WHITE GAS MAY BE USED ONLY IF THE OCTANE RATING IS AT LEAST 75. NEVER USE PREMIUM GASOLINE. NOTE: DO NOT MIX OIL WITH GASOLINE. BE SURE FUEL CONTAINERS ARE ABSOLUTELY CLEAN.

LUBRICANTS

ENGINE CRANKCASE -

OIL USED IN THE ENGINE CRANKCASE SHOULD HAVE AN AMERICAN PETROLEUM INSTITUTE (API)/SAE CLASSIFICATION OF SERVICE MS.

DEPENDING ON PREVAILING AIR TEMPERATURE, USE OIL OF VISCOSITY AS SHOWN IN THE FOLLOWING CHART.

AIR TEMPERATURE - SEASON	SINGLE-VISCOSITY OIL
30 TO 90 F. SUMMER	SAE 30
-0 TO 30 F. WINTER	SAE 10W
BELOW 0 F.	SAE 5W-20

USE OF SAE 5W-20 OIL MAY CAUSE SOME INCREASE IN OIL CONSUMPTION. CHECK OIL LEVEL MORE OFTEN WHEN USING THIS OIL.

DO NOT FILL ENGINE CRANKCASE ABOVE FULL MARK.

TRANSMISSION

1. ALL TRANSAXLES ARE FILLED WITH 4 PINTS OF SHELL MACOMA No. 72 OIL.
2. FOR REFILL OR MAKE-UP OIL IN THE FIELD, WE RECOMMEND SAE 90 WEIGHT OIL.

DO NOT ATTEMPT TO DISMANTLE ANY PART OF YOUR TRACTOR TRANSMISSION. SEE YOUR DEALER FOR ALL TRANSMISSION SERVICE.

OPERATING THE ENGINE

BREAK-IN AND GET-ACQUAINTED PERIOD

YOUR NEW TRACTOR SHOULD BE SUBJECTED TO A BREAK-IN PERIOD BEFORE IT IS OPERATED AT FULL LOAD. DRIVE THE TRACTOR FOR SEVERAL HOURS TO GET THE FEEL OF ITS OPERATION. ACTUATE THE VARI - DRIVE SPEED CONTROL LEVER THROUGH ITS FULL RANGE DURING THE GET-ACQUAINTED PERIOD. DO NOT LOWER OR OPERATE ANY ATTACHMENTS.

NO SPECIAL BREAK-IN OIL IS REQUIRED. HOWEVER, BE SURE TO CHANGE OIL AFTER FIRST 5 HOURS OF OPERATION.

PRE-STARTING INSPECTION

BEFORE STARTING THE ENGINE EACH DAY, PERFORM THE FOLLOWING CHECKS AND SERVICES -

1. CHECK FUEL SUPPLY. USE REGULAR GASOLINE ONLY.
2. BE SURE OIL IN ENGINE CRANKCASE IS AT THE PROPER LEVEL. ADD OIL AS NEEDED TO MAINTAIN INDICATED LEVEL. CAUTION: NEVER OVERFILL WITH OIL.
3. BE SURE SCREEN COVERING ENGINE FLYWHEEL IS CLEAN. A SCREEN FILLED WITH GRASS CLIPPINGS OR DIRT WILL CAUSE ENGINE TO OVERHEAT.
4. BE SURE AIR CLEANER IS FREE OF OBSTRUCTIONS AND EXCESSIVE DIRT.

STARTING THE ENGINE

1. DEPRESS CLUTCH-BRAKE PEDAL AND APPLY BRAKING PRESSURE.
2. PLACE SHIFT LEVER IN NEUTRAL (N) POSITION.
3. ADVANCE THROTTLE LEVER APPROXIMATELY HALF-WAY.
4. PULL CHOKE BUTTON IF NECESSARY. EXPERIENCE WILL SOON TELL YOU WHEN CHOKING IS NECESSARY. GENERALLY, A COLD ENGINE WILL REQUIRE A SLIGHT CHOKE. STARTING IN EXTREMELY COLD WEATHER REQUIRES MORE CHOKE.
5. TURN IGNITION KEY TO THE RIGHT AS FAR AS POSSIBLE TO START ENGINE. IF ENGINE DOES NOT START AFTER 3 OR 4 ATTEMPTS, REFER TO "TROUBLE SHOOTING," PAGES 27-12 IN THIS MANUAL.
6. LOWER CHOKE LEVER WHEN ENGINE STARTS AND RUNS. NOTE: FOR EXTREMELY COLD WEATHER, IT MAY BE NECESSARY TO LEAVE CHOKE $1/3$ OR $1/4$ OPEN UNTIL ENGINE WARMS UP. ALWAYS ALLOW ENGINE TO WARM UP BEFORE APPLYING LOAD.

STOPPING THE ENGINE

1. BEFORE STOPPING THE ENGINE, REMOVE LOAD AND ALLOW ENGINE TO IDLE FOR A FEW MINUTES BEFORE TURNING IT OFF. SUDDEN STOPPING OF A HOT ENGINE CAN CAUSE DAMAGE TO ENGINE PARTS.
2. MOVE VARI-DRIVE SPEED CONTROL LEVER TO REAR (SLOW SPEED) POSITION OR DEPRESS CLUTCH-BRAKE PEDAL.
3. TURN IGNITION KEY ALL THE WAY TO THE LEFT TO STOP ENGINE. CAUTION: BE SURE KEY IS TURNED COMPLETELY OFF (VERTICAL POSITION) BEFORE LEAVING TRACTOR.
4. REMOVE KEY. THIS IS IMPORTANT. DEVELOP THE HABIT OF REMOVING THE KEY EACH TIME YOU LEAVE THE TRACTOR.

OPERATING THE TRACTOR


PROPER GROUND SPEED WILL DEPEND ON (1) THE TYPE OF ATTACHMENT USED ON THE TRACTOR AND (2) FIELD, GARDEN OR YARD CONDITIONS.

WHEN USING ENGINE DRIVEN ATTACHMENTS SELECT THE TRANSMISSION GEAR THAT WILL GIVE A SAFE GROUND SPEED WHEN THE ENGINE IS OPERATING AT FULL THROTTLE.

THE TRACTOR HAS A 3 OR 4 FORWARD GEAR AND 1 REVERSE GEAR. DEPRESS CLUTCH PEDAL, AND POSITION SHIFT LEVER IN DESIRED GEAR. IMPORTANT: TRACTOR MUST BE COMPLETELY STOPPED BEFORE SHIFTING GEARS. THE COMBINATION CLUTCH-BRAKE PEDAL MAKES THIS EASY. WHEN SHIFTING GEARS, USE STRONG, STEADY MOTION TO SLIDE GEARS FIRMLY INTO MESH. NEVER ALLOW GEARS TO GRIND WHILE SHIFTING.


NOTE: MOVE SHIFT LEVER FORWARD AS FAR AS IT WILL GO BEFORE SHIFTING INTO 3RD AND 4TH GEAR. MOVE SHIFT LEVER BACK ALL THE WAY BEFORE SHIFTING INTO REVERSE OR 1ST AND 2ND GEAR.

HITCH FOR REAR ATTACHMENTS



THE ATTACHMENT LIFT LEVER IS USED TO RAISE AND LOWER REAR MOUNTED ATTACHMENTS.

SEAT ADJUSTMENT




TRACTOR SEAT MAY BE ADJUSTED INTO DIFFERENT POSITIONS. LOOSEN THUMB SCREW AND ADJUST TO COMFORTABLE POSITION.


REAR WHEELS

REAR WHEELS ARE FACTORY ASSEMBLED IN THE NARROW (27-INCH) TREAD. WHEELS CAN BE TURNED AROUND ON THE HUBS FOR A WIDE (33-INCH) WHEEL TREAD FOR GREATER STABILITY. REMOVE WHEEL BOLTS, TURN WHEEL AROUND WITH VALVE STEM INWARD, AND REASSEMBLE ON HUB.


FRONT AND REAR TIRE SELECTION



1



2



3

1. HIGH FLOTATION- 8.00 x 12 REAR AND 16-6.50 x 8 FRONT FOR TRAVEL OVER SOFT GROUND OR AREAS WHERE TIRE TRACKS MAY BE OBJECTIONABLE.
2. TRACTION TIRE - 4.80/4.00 x 8 FRONT AND 6.00 x 12 REAR FOR GREATER TRACTION WHEN WORKING HEAVIER LOADS.
3. ALL PURPOSE- 4.80/4.00 x 8 FRONT AND 6.00 x 12 REAR FOR GENERAL USE AND NORMAL LOAD APPLICATIONS.


EVERY 500 HOURS OF OPERATION OR EACH SPRING AND FALL SEASON

EACH FALL AND, AGAIN IN THE SPRING THE FOLLOWING SERVICE SHOULD BE PERFORMED. IF THE TRACTOR IS TO BE PLACED IN STORAGE,

REPEAT ALL 5 HOUR, 25 HOUR AND 100 HOUR SERVICE CHECKS AND PERFORM ADDITIONAL SERVICE AS FOLLOWS -

LUBRICATION OF FRONT AXLE AND STEERING COLUMN

USE PRESSURE GREASE GUN TO LUBRICATE STEERING COLUMN AND FRONT AXLE FITTINGS WITH SAE (SEASONAL GRADE) MULTIPURPOSE-TYPE GREASE. WIPE FITTINGS CLEAN AFTER LUBRICATION.



DEALER SERVICES

YOUR DEALER OFFERS COMPLETE TRACTOR SERVICE. HIS TRAINED PERSONNEL HAVE ACCESS TO ACCURATE, DETAILED SERVICE INFORMATION. SOME OF THESE DEALER SERVICES ARE LISTED BELOW

1. TESTING BATTERY AND ELECTRICAL COMPONENTS.
2. CLEANING AND ADJUSTING CARBURETOR.
3. CLEANING OUT ENGINE CARBON.
4. TESTING ENGINE COMPRESSION.
5. REPLACING MOTOR-GENERATOR BRUSHES, CLEANING COMMUTATOR.
6. ADJUSTING ENGINE GOVERNOR SPEED.

LUBRICATION AND PERIODIC SERVICE

27-9

THE RECOMMENDED LUBRICATION AND SERVICE PERIODS FOR YOUR TRACTOR ARE AS FOLLOWS

DAILY OR EVERY 5 HOURS OF OPERATION.
WEEKLY OR EVERY 25 HOURS OF OPERATION.
EVERY 100 HOURS.
EVERY 500 HOURS OR EACH SPRING AND FALL SEASON.

THE FOLLOWING PROCEDURES ARE GIVEN IN THE ORDER OF FREQUENCY.

DAILY OR EVERY 5 HOURS OF OPERATION

ENGINE CRANKCASE OIL LEVEL -

RAISE TRACTOR HOOD, WIPE OFF DUST AND DIRT AND UNSCREW OIL DIPSTICK.

IF NECESSARY, ADD SUFFICIENT OIL OF THE PROPER VISCOSITY TO BRING OIL LEVEL UP TO THE FULL (F) MARK ON THE DIPSTICK WHEN THE DIPSTICK IS SCREWED IN TIGHT. NOTE OIL SHOULD NOT BE OVER FULL MARK. BE SURE TRACTOR IS ON LEVEL GROUND AND ENGINE IS STOPPED BEFORE CHECKING OIL LEVEL.

FLYWHEEL SCREEN

MAKE A VISUAL CHECK OF THE OUTSIDE SCREEN. THE ENGINE IS AIR COOLED AND MUST HAVE AMPLE SUPPLY OF AIR TO PREVENT ENGINE FROM OVERHEATING. WIPE ALL DIRT OR BEDRIS COVERING ANY OF THE SCREEN.

CHECK SCREEN OFTEN, ESPECIALLY WHEN MOWING OR MULCHING LEAVES, TO BE SURE SCREEN IS NEVER COMPLETELY BLOCKED WITH DRY GRASS CLIPPINGS.

BATTERY

CHECK BATTERY, MAKING SURE LIQUID LEVEL IS UP TO FILLER RING IN EACH CELL. IF NECESSARY, ADD DISTILLED WATER.

CHECK BATTERY TERMINALS TO BE SURE THEY ARE CLEAN AND FREE FROM CORROSION.

TIRE PRESSURE

INFLATE TIRES TO PRESSURES SHOWN IN CHART BELOW -

TIRE	TIRE INFLATION	
	ALL PURPOSE AND TRACTION TIRES	HIGH FLOTATION TIRES
FRONT	12 PSI	8 PSI
REAR	6 PSI	5 PSI

DRIVE BELT TENSION

TURN OFF ENGINE. CHECK UNDERSIDE OF TRACTOR FOR GENERAL BELT CONDITION. REPLACE ALL BELTS SHOWING EXCESSIVE WEAR.

AIR CLEANER

SEE ENGINE MANUAL.

ENGINE CRANKCASE

PARK TRACTOR ON SLIGHT INCLINE IF POSSIBLE, WITH THE FRONT OF THE TRACTOR LOWER THAN THE REAR.

RAISE HOOD AND REMOVE FRONT GRILLE. REMOVE DRAIN PLUG AND ALLOW OIL TO DRAIN INTO CONTAINER.

REPLACE PLUG AND REFILL CRANKCASE WITH PROPER GRADE OIL TO PROPER OIL LEVEL.

CHANGE OIL EVERY EIGHT HOURS WHEN WORKING IN EXTREMELY DUSTY CONDITIONS.

NOTE THE BEST TIME TO DRAIN CRANKCASE IS AT END OF A DAY'S OPERATION AT WHICH TIME THE OIL IS HOT AND ALL DIRT AND FOREIGN MATERIAL IN CRANKCASE IS IN SUSPENSION.

EVERY 100 HOURS OF OPERATION

REPEAT ALL 5 HOURS AND 25 HOUR SERVICE CHECKS AND PERFORM ADDITIONAL SERVICE AS FOLLOWS-

ENGINE SHROUDS

BE SURE THE ENGINE COOLING FINS AND THE SHROUDS WHICH ENCLOSE THEM ARE CLEAN AT ALL TIMES. DIRT, OIL AND OTHER DEBRIS WHICH MAY HAVE ENTERED THROUGH THE SCREENS MAY LODGE ON COOLING FINS THEREBY RESTRICTING THE NORMAL AIR FLOW. THIS CAUSES SERIOUS DAMAGE TO ENGINE PARTS BECAUSE OF OVERHEATING.

REMOVE BOLTS HOLDING ENGINE SHROUD IN PLACE AND BRUSH OUT ALL DIRT FROM COOLING FINS. CLEAN INSIDE OF SHROUD THOROUGHLY. SOAK OFF OIL DEPOSITS WITH SAFE SOLVENT. **CAUTION** DO NOT RUN ENGINE WITH SHROUDS REMOVED.

REMOVE ROTATING SCREEN AND CHECK FOR OIL OR DIRTY FINS ON THE FLYWHEEL. BE SURE SCREEN IS CLEAN AND NOT DAMAGED.

TRANSMISSION OIL LEVEL

REMOVE OIL LEVEL (FILLER) PLUG AND PUSH TRACTOR FORWARD ABOUT SIX INCHES. TRANSMISSION RING GEAR WILL CAUSE OIL TO SPILL OUT OIL LEVEL HOLE IF TRANSMISSION IS FULL.

WHEN REQUIRED, USE PRESSURE OIL CAN TO ADD TRANSMISSION LUBRICANT THROUGH FILLER HOLE UNTIL OIL SPILLS OUT. BE SURE TRACTOR IS ON LEVEL SURFACE WHEN CHECKING.

SERVICE

HOOD AND GRILLE

ENGINE AND RELATED PARTS ARE EASILY ACCESSIBLE BY LIFTING AND RAISING THE HOOD. HOOD WILL REMAIN OPEN AFTER RAISING TO A NEAR VERTICAL POSITION.

TO REMOVE GRILLE FOR ACCESS TO IGNITION POINTS, OIL DRAIN, ETC., RELEASE SPRING CLAMPS AND LIFT GRILLE OUT. WHEN REPLACING, BE SURE GUIDE PINS GRILLE BOTTOM ARE IN PLACE.

FUEL SYSTEM

PROPER INSPECTION AND SERVICE OF YOUR FUEL SYSTEM IS IMPORTANT TO CONTINUED SUCCESSFUL OPERATION OF YOUR TRACTOR.

ELECTRICAL SYSTEM

ADJUSTING POINTS

DISCONNECT SPARK PLUG CABLE TO PREVENT ACCIDENTAL STARTING OF THE ENGINE. REMOVE IGNITION POINT COVER AND ROTATE ENGINE FLYWHEEL UNTIL POINTS ARE FULLY OPEN.

CHECK POINT GAP WITH A .020 -INCH FEELER GAUGE. IF ADJUSTMENT IS REQUIRED, LOOSEN LOCKING SCREW AND MOVE SCREWDRIVER IN V-SLOT UNTIL POINT ARE PROPERLY SET.

AFTER TIGHTENING LOCKING SCREW, RECHECK POINT GAP.

TO REPLACE POINTS REMOVE SCREWS. BE SURE LOCK WASHERS ARE IN PLACE BEFORE REASSEMBLY.

SPARK PLUG GAP

CHECK SPARK PLUG GAP AND CONDITION OF ELECTRODES AFTER EVERY 100 HOURS OF OPERATION. DISTANCE BETWEEN ELECTRODES SHOULD BE .025 INCH. BEND THE OUTER ELECTRODE: ONLY FOR PROPER GAP.

IF ELECTRODES HAVE BURNED SHORT OR HAVE BECOME PITTED, INSTALL A NEW SPARK PLUG.

USE A SPARK PLUG WRENCH TO REMOVE PLUG. ALWAYS USE A NEW SPARK PLUG GASKET WHEN REPLACING PLUG. TIGHTEN PLUG TO 27 FT.-LBS. TORQUE.

BATTERY

YOUR TRACTOR HAS A 12 -VOLT ELECTRICAL SYSTEM. WHEN REPLACING BATTERY, USE A 12-VOLT, 45-AMP-20 HOUR RATING.

CAUTION: PREVENT ACCIDENTAL OPERATION OF THE STARTER OR ENGINE. ALWAYS DISCONNECT SPARK PLUG CABLE WHENEVER WORKING ON THE ELECTRICAL SYSTEM. ALSO DO THIS WHEN MAKING ADJUSTMENTS TO THE ENGINE OR OTHER MOVING PARTS.

CLEANING BATTERY

REMOVE BATTERY CABLES AND USE A WIRE BRUSH TO REMOVE CORROSION AROUND BATTERY TERMINALS. WASH TERMINALS WITH A SOLUTION CONSISTING OF ONE PART BAKING SODA TO FOUR PARTS WATER. DO NOT ALLOW CLEANING SOLUTION TO RUN INTO BATTERY CELLS.

COAT TERMINALS WITH PETROLEUM JELLY AND CONNECT BATTERY CABLES. BE SURE THEY ARE TIGHT.

WIPE AND WASH ENTIRE BATTERY CASE, PLATFORM AND HOLD-DOWN STRAPS WITH CLEAR WATER.

BE SURE TOP AND BOTTOM VENT HOLES IN EACH CELL CAP ARE OPEN.

CHECKING BATTERY WATER LEVEL

CHECK THE LIQUID LEVEL OF EACH CELL BY REMOVING THE CAP. WATER SHOULD COMPLETELY COVER THE CELLS AT ALL TIMES. FILL EACH CELL TO RING LEVEL INSIDE FILLER HOLE WITH DISTILLED WATER.

USE CLEAN DISTILLED WATER WHEN POSSIBLE TO FILL BATTERY. WHEN ABSOLUTELY NECESSARY,

CLEAN DRINKABLE WATER MAY BE USED.

KEEPING THE LIQUID AT PROPER LEVEL DURING WINTER OR FREEZING WEATHER IS ESPECIALLY IMPORTANT. THE BATTERY MUST BE KEPT FULLY CHARGED ALSO TO PREVENT FREEZING.

IMPORTANT : WHEN ADDING WATER TO BATTERY DURING FREEZING WEATHER BE SURE THE ENGINE IS RUNNING AND CONTINUES TO RUN UNTIL WATER HAS HAD A CHANCE TO MIX THOROUGHLY. THIS SHOULD BE AT LEAST AN HOUR.

BATTERY CONNECTIONS SHOULD BE TIGHT AT ALL TIMES, ESPECIALLY WHEN CHARGING BATTERIES. LOOSE CABLES WILL CAUSE ARCING AND PITTING OF THE CONNECTIONS AND CAUSE EVENTUAL FAILURE.

NOTE : BE CAREFUL NOT TO ALLOW SPARKS OR FLAMES NEAR A CHARGED BATTERY.

TROUBLE SHOOTING

HARD STARTING

A. FAULTY IGNITION

CHECK FOR PRESENCE OF SPARK BY DISCONNECTING HIGH TENSION WIRE FROM PLUG AND HOLDING WIRE CLOSE TO CYLINDER HEAD WHILE CRANKING ENGINE WITH STARTER. IF NO SPARK, CHECK-

1. BREAKER POINT GAP IS INCORRECT.
2. BREAKER POINTS ARE WORN OR PITTED. REPLACE POINTS.
3. SPARK PLUG GAP IS INCORRECT.
4. SPARK PLUG ELECTRODES ARE PITTED OR FOULED. REPLACE PLUG.
5. IF THE FOREGOING FAILS TO CORRECT PROBLEM, SEE YOUR DEALER.

B. FAULTY CARBURETION

1. GASOLINE MAY NOT BE GETTING TO THE CARBURETOR BECAUSE OF AN AIR LOCK IN THE LINE. LINES MAY BE GUMMED AND PLUGGED.
2. CARBURETOR MAY BE DIRTY OR OUT OF ADJUSTMENT.

C. COMPRESSION LOSS

IF ENGINE CAN BE TURNED OVER SLOWLY BY HAND WITH LITTLE EFFORT THERE IS A LOSS OF COMPRESSION. SEE YOUR DEALER OR SERVICE MAN.

ENGINE MISSING UNDER LOAD

- A. CHECK SPARK PLUG FOR PROPER GAP.
- B. CHECK FOR LEAN FUEL MIXTURE. ADJUST CARBURETOR HIGH SPEED SCREW.

- C. CHECK FOR DIRTY (FOULED) SPARK PLUG OR IMPROPER TYPE PLUG.
- D. PITTED OR WORN BREAKER POINTS SHOULD BE REPLACED WITH A NEW SET.
- E. SEE YOUR SERVICEMAN FOR PROPER IGNITION AND CARBURETION ADJUSTMENTS.

BACKFIRING

- A. CHECK CARBURETOR FOR LEAN FUEL MIXTURE.
- B. STICKY INTAKE VALVE OR IMPROPER IGNITION. SEE YOUR SERVICEMAN OR DEALER.

KNOCKING

- A. CHECK FUEL SUPPLY FOR LOW OCTANE RATING. USE ONLY QUALITY GRADE OF REGULAR GASOLINE.
- B. CHECK ENGINE FOR OVERHEATING. SEE OVERHEATING BELOW.
- C. CHECK CRANKCASE OIL LEVEL. FILL TO (F) MARK ON DIPSTICK. NOTE: IF ENGINE KNOCK HAS DEVELOPED BECAUSE OF LACK OF CRANKCASE OIL, HAVE YOUR DEALER CHECK CONDITION OF PISTON ROD AND CAP.
- D. SEE YOUR SERVICEMAN FOR POSSIBLE LOOSE CONNECTING ROD, IMPROPER TIMING OR EXCESSIVE CARBON IN COMBUSTION CHAMBER.

LOSS OF ENGINE POWER

- A. OVERHEATING
 - 1. CHECK AND CLEAN SCREENS AND ENGINE SHROUDS.
 - 2. USING PREMIUM GASOLINE WITH HIGH OCTANE RATING, USE REGULAR GAS ONLY.
 - 3. CHECK CARBURETOR FOR LEAN FUEL MIXTURE.
 - 4. CHECK OIL DIPSTICK FOR EXCESSIVE OIL IN ENGINE CRANKCASE, DO NOT FILL ABOVE OIL LEVEL MARK.
 - 5. CHECK BREAKER POINTS FOR PROPER GAP.
- B. DIRTY AIR CLEANER
 - 1. CHECK AND CLEAN AIR CLEANER.
- C. CHOKE IS PARTLY CLOSED
 - 1. CHECK TO BE SURE CHOKE CONTROL CABLE IS NOT JAMMED. CHOKE MUST BE COMPLETELY OPEN (CHOKE LEVER DOWN) AFTER ENGINE IS WARMED UP EXCEPT ON EXTREMELY COLD DAYS.

ENGINE OPERATING ERRATICALLY

CHECK THE FOLLOWING -

- (A) CARBURETOR SET TOO LEAN (B) CLOGGED FUEL LINE (C) WATER IN FUEL (D) FAULTY CHOKE CONTROL (E) LOOSE ELECTRICAL CONNECTIONS (F) AIR LEAKS IN CARBURETOR CONNECTIONS OR GASKET (G) CARBURETOR JET CLOGGED (H) LOOSE THROTTLE CABLE.

ENGINE WILL NOT IDLE

- (A) CHECK CARBURETOR ADJUSTMENTS (B) DIRTY CARBURETOR (C) CHECK AND SET SPARK PLUG GAP (D) CHECK CARBURETOR FOR AIR LEAKS IN GASKET (E) SEE YOUR SERVICEMAN FOR POSSIBLE LEAKY VALVES OR FAULTY CONDENSER.

TRANSMISSION WILL NOT STAY IN GEAR

- (A) SHIFT GEAR FIRMLY WITHOUT LETTING GEARS GRIND BEFORE ENGAGING, (B) SEE YOUR SERVICEMAN TO REPLACE WORN GEARS.

BRAKES NOT EFFECTIVE

- (A) ADJUST BRAKE AND CLUTCH LINKAGE, (B) REPLACE BRAKE BAND IF WORN EXCESSIVELY. SEE SERVICEMAN.

IMPROPER STEERING OR EXCESSIVE
FRONT TIRE WEAR

- (A) CHECK WHEEL ALIGNMENT AND TOE-IN.

CLUTCH HARD TO OPERATE

- (A) MOVE SPEED CONTROL LEVER TO REAR (SLOW SPEED POSITION) BEFORE APPLYING CLUTCH PRESSURE. (B) DIRT ON VARIATOR SHEAVE HUB-CLEAN HUB. (C) START ENGINE BEFORE DEPRESSING CLUTCH-BRAKE PEDAL.

STARTER INOPERATIVE OR
WILL NOT TURN ENGINE

- (A) CHECK FOR DISCHARGED BATTERY (B) ROTARY MOWER DRIVE IS ENGAGED. DISENGAGE, SEE MOWER OPERATOR'S MANUAL. (C) TIGHTEN MOTOR-GENERATOR BELT. (D) CHECK ELECTRICAL CONNECTIONS

TRACTOR WILL NOT MOVE
WITH ENGINE RUNNING

- (A) BE SURE TRACTOR IS IN GEAR. (B) MOVE SPEED CONTROL LEVER TO FAST SPEED POSITION. (C) ADJUST TRACTOR LINKAGE.

EXCESSIVE TRACTOR VIBRATION

- (A) WORN OR LUMPY V-BELT. REPLACE V-BELTS (B) DIRT IN VARIATOR SHEAVES, CLEAN SHEAVES AND HUB (C) CHECK SHEAVES FOR EXCESSIVE WEAR AND WOBBLE.

STORAGE

27-15

IF YOUR TRACTOR WILL NOT BE USED FOR A PERIOD OF TIME SUCH AS THROUGH THE WINTER SEASON, PERFORM THE FOLLOWING OPERATIONS.

DRAIN GASOLINE TANK AND CRANK ENGINE AND BURN GAS IN CARBURETOR.

REMOVE SPARK PLUG AND POUR IN ONE TABLESPOONFUL SAE 30 OIL. TURN ENGINE OVER MANUALLY AT LEAST TWO TIMES AND REPLACE SPARK PLUG.

1. REMOVE BATTERY AND STORE WHERE IT WILL NOT FREEZE. CHECK WATER LEVEL AND REFILL IF NECESSARY.
2. CLEAN TRACTOR EXTERIOR THOROUGHLY, REMOVING ALL MUD, DIRT, GREASE AND OTHER MATERIAL.
3. TOUCH UP ALL UNPAINTED AND EXPOSED SURFACES WITH PAINT TO PREVENT RUST.
4. CHECK ALL VISIBLE MOVING PARTS FOR WEAR, BREAKAGE OR DAMAGE. NOW IS THE TIME TO ORDER ANY PARTS REQUIRED AND MAKE NECESSARY REPAIRS TO AVOID NEEDLESS DELAY WHEN STARTING AGAIN NEXT SEASON.
5. BLOCK UP TRACTOR TO TAKE WEIGHT OFF TIRES. STORE TRACTOR IN COOL, DARK AND DRY PLACE IF POSSIBLE TO PREVENT EXCESS TIRE DETERIORATION.
6. WIPE AND CLEAN BELTS WITH A DRY CLOTH.
7. REMOVE BELT TENSION FROM ALL BELTS. BLOCK UP SECONDARY IDLER AND LOOSEN MOTOR-GENERATOR. DISENGAGE CLUTCHES ON BELT DRIVEN ATTACHMENTS.

YOUR DEALER IS EQUIPPED TO GIVE YOUR TRACTOR A COMPLETE SERVICE CHECK AND MAKE RECOMMENDATIONS FOR REPLACING PARTS IN NEED OF ATTENTION.

PREPARING TRACTOR FOR USE AFTER STORAGE

ENGINE

1. DRAIN AND REFILL TRACTOR CRANKCASE WITH PROPER WEIGHT AND GRADE OIL.
2. CLEAN SPARK PLUG AND SET GAP.
3. CHECK IGNITION POINT GAP.

TRACTOR

1. REINSTALL BATTERY, CHECK LIQUID LEVEL.
2. CHECK TRANSMISSION OIL LEVEL.
3. CHECK TIRE INFLATION.
4. ADJUST V-BELT TENSION.

V-BELT CARE AND MAINTENANCE

THE V BELT IN YOUR TRACTOR TRANSMIT POWER BY FRICTION AND A WEDGING ACTION AGAINST THE SHEAVES. BELTS ARE THEREFORE SUBJECT TO WEAR THROUGH PERIODIC HEAVY LOAD AND SHOULD BE CHECKED OFTEN TO BE CERTAIN BELT WEAR IS NORMAL. ALL BELTS AND SHEAVES WEAR WITH USE. NORMAL WEAR CAN BE RECOGNIZED AS EVEN WEAR—BOTH ON THE BELT AND SIDES OF THE SHEAVES.

DIRTY SHEAVES

CHECK TO BE SURE DIRT HAS NOT LODGED AND PACKED IN SHEAVE V-GROOVE. CHECK ESPECIALLY THE VARIATOR SHEAVE. EXCESSIVE TRACTOR VIBRATION MAY BE CAUSED BY DIRT COLLECTING INSIDE THE VARIATOR SHEAVE. LOOSEN DIRT SO IT WILL FALL OUT WHEN TRACTOR IS STARTED.

VIBRATION CAN ALSO BE CAUSED BY LUMPY V-BELTS. CHECK PRIMARY AND SECONDARY BELTS FOR SWELLS AND LUMPS. USE ONLY FACTORY RECOMMENDED V-BELTS OF THE PROPER LENGTH WHEN REPLACING.

V-BELT INSTALLATION

WHENEVER UNUSUAL V-BELT WEAR, TEAR OR OTHER FAILURE OCCURS, CHECK IMMEDIATELY FOR THE CAUSE. AFTER CORRECTING THE CAUSE, REPLACE V-BELTS BY FIRST LOOSENING IDLER, LOOSENING MOUNTING BOLTS, OR REMOVING SHEAVE.

IMPORTANT : NEVER PRY BELT OVER EDGE OF SHEAVE AS THIS MAY RUPTURE BELT CORDS AND SHORTEN BELT LIFE. PLACE THE BELT IN THE SHEAVE GROOVE BY HAND.

V-BELT CLEANING

CLEAN BELTS BY WIPING THEM WITH A CLEAN CLOTH. IMMEDIATELY WIPE OFF ANY SPILLED OIL OR GREASE. AVOID USE OF SOLVENTS, SINCE THIS WILL SOFTEN THE MATERIALS AND CAUSE THE CLUTCH TO GRAB.

DO NOT USE BELT DRESSINGS. DRESSINGS OFTEN GIVE ONLY TEMPORARY GRIPPING ACTION WHILE SOFTENING THE BELT AND CAUSING EVENTUAL DETERIORATION, AND SHORTENING OF THE BELT LIFE. DRESSINGS ALSO WILL CAUSE A GRABBY CLUTCH.

V-BELT TENSION ADJUSTMENT

V-BELT TENSION SHOULD BE ADJUSTED IF—

- A. TRACTOR ENGINE FAILS TO TURN OVER WHEN IGNITION SWITCH IS TURNED ON AND STARTER IS RUNNING.
- B. CLUTCH-BRAKE PEDAL STRIKES THE BOTTOM OF FOOTREST WHEN SPEED CONTROL LEVER IS IN THE FORWARD POSITION.
- C. TRACTOR DOES NOT MOVE WHEN SPEED CONTROL LEVER IS IN 1ST NOTCH (REAR POSITION).
- D. SECONDARY BELT STRANDS OPERATE LESS THAN $3/4$ -INCHES APART.

ADJUST V-BELTS AS FOLLOWS FOR EACH CONDITION A THROUGH D.

A. MOTOR-GENERATOR BELT TENSION

THE MOTOR-GENERATOR BELT WILL REQUIRE TIGHTENING WHENEVER THE ENGINE FAILS TO TURN OVER WHEN THE IGNITION IS TURNED ON AND STARTER IS RUNNING.

WHEN BELT SLIPPAGE IS FIRST NOTICED, TIGHTEN BELT IMMEDIATELY TO PREVENT EXCESSIVE BELT WEAR. DO SO BY LOOSENING CAP SCREW ON BRACKET AND MOVING MOTOR-GENERATOR BACK UNTIL A 10-POUND PRESSURE MIDWAY BETWEEN THE SHEAVES DEFLECTS THE BELT $\frac{1}{4}$ -INCH.

TIGHTEN CAP SCREW TO HOLD MOTOR-GENERATOR IN THIS POSITION TO MAINTAIN PROPER TENSION.

B-C. PRIMARY BELT TENSION

IF AT ANY TIME THE CLUTCH-BRAKE PEDAL STRIKES THE BOTTOM OF THE FOOTREST OR IF THE TRACTOR DOES NOT MOVE WITH THE SPEED CONTROL LEVER IN THE FIRST NOTCH (REAR POSITION) THE TRACTOR LINKAGE WILL REQUIRE ADJUSTING.


IF, AFTER MAKING THE ADJUSTMENT THE TRACTOR IS STILL INOPERATIVE WITH THE SPEED CONTROL LEVER IN THE FIRST NOTCH ON THE QUADRANT INSTALL A NEW PRIMARY BELT.

D. SECONDARY BELT TENSION

IF EXCESSIVE BELT STRETCHING ALLOWS THE IDLER TO RUB ON THE LOWER BELT STRAND, ADDITIONAL BELT TENSION CAN BE OBTAINED BY REMOVING CAPSCREWS A, LOOSENING SCREWS B, AND MOVING TRANSMISSION REARWARD.

INSERT CAP SCREWS A THROUGH REAR HOLES AND TIGHTEN. ALSO, TIGHTEN SCREWS B.

AFTER MOVING TRANSMISSION, BE SURE TO READJUST BRAKE ROD LINKAGE. TIGHTEN NUTS FIRMLY.



TO REPLACE WORN OR BROKEN SECONDARY BELT, REMOVE THREE CAP SCREWS FROM INPUT SHEAVE AND REMOVE SHEAVE AND OLD BELT.

INSTALL NEW BELT AROUND VARIATOR SHEAVE. BLOCK UP SECONDARY IDLER TO REMOVE BELT TENSION AND ASSEMBLE BELT AND INPUT SHEAVE.

NOTE: IF TRANSMISSION HAS BEEN MOVED FORWARD, TO TAKE UP SECONDARY BELT SLACK PRIOR TO BELT REPLACEMENT, LOOSEN BOLTS AND MOVE TRANSMISSION FORWARD BEFORE INSTALLING NEW SECONDARY BELT. TIGHTEN BOLTS HOLDING TRANSMISSION.

READJUST BRAKE ROD FOR PROPER LENGTH AFTER MOVING TRANSMISSION.

V-BELT REPLACEMENT


CAUTION: Be sure to remove spark plug cable before removing belts to prevent accidental starting of the engine.

MOTOR GENERATOR BELT

Replace motor-generator belt by removing belt guard. Loosen cap screw on bracket to allow motor-generator to pivot forward. Install belt and adjust tension. Replace guard.

PRIMARY BELT

First remove belt guide and secondary belt from variator.



Remove mower drive belt, if installed, belt guards and right hand tractor panel.


Remove cap screws and primary belt guide.


Depress clutch-brake pedal to hold variator forward. Lift belt off variator and engine sheave.

Reverse above procedure to install new belt. Assemble all guides and guards in place.

IMPORTANT: After replacing primary belt readjust tractor linkage as instructed.

SECONDARY BELT





THE VARI-DRIVE SPEED CONTROL LEVER MAY BE MOVED THROUGH ITS FULL RANGE WITHOUT DEPRESSING THE CLUTCH OR STOPPING THE TRACTOR. MOVE LEVER FORWARD TO INCREASE GROUND SPEED AND BACK TO DECREASE GROUND SPEED.

AFTER SELECTING TRANSMISSION GEAR, PRESS THUMB RELEASE AND MOVE INDEPENDENT GROUND SPEED CONTROL LEVER FORWARD UNTIL DESIRED SPEED IS ATTAINED. THIS FEATURE IS ESPECIALLY VALUABLE WHEN LOAD IS NOT UNIFORM. WHEN ENGINE-DRIVEN ATTACHMENTS ARE OVERLOADED, SUCH AS WITH HEAVY LAWN MOWING OR DEEP SNOW THROWING, THE GROUND SPEED MAY BE REDUCED WITH THE INDEPENDENT GROUND SPEED CONTROL LEVER TO RELIEVE THE LOAD WHILE THE ATTACHMENT CONTINUES TO OPERATE AT FULL SPEED.

CLUTCH BRAKE PEDAL

TRACTOR SPEED MAY ALSO BE REGULATED WITH FOOT ACTION ON THE CLUTCH-BRAKE PEDAL. MOVE THE SPEED CONTROL LEVER TO THE FORWARD POSITION. WITH ENGINE RUNNING AND TRACTOR IN GEAR, DEPRESS CLUTCH-BRAKE PEDAL TO SLOWLY REDUCE GROUND SPEED. RELEASE CLUTCH-BRAKE PEDAL TO INCREASE SPEED.

OPERATE THE VARI-DRIVE SPEED CONTROL LEVER AND CLUTCH PEDAL WHILE ENGINE IS RUNNING.

CLUTCH, BRAKE, AND VARI-DRIVE SPEED CONTROL.

VARI-DRIVE SPEED CONTROL LEVER

WHEN THE VARI-DRIVE SPEED CONTROL IS MOVED FORWARD, THE PRIMARY BELT MOVES DEEPER INTO THE GROOVE OF THE VARIATOR SHEAVE. SINCE THE OUTSIDE SHEAVE IS FREE TO MOVE ON ITS SHAFT, THE SECONDARY BELT IS FORCED HIGHER ON THE SHEAVE, THEREBY CAUSING THE TRACTOR TO OPERATE AT MAXIMUM SPEED.

WHEN THE VARI-DRIVE SPEED CONTROL LEVER IS MOVED TO THE REAR POSITION, THE SECONDARY BELT IS FORCED DEEPER INTO THE VARIATOR SHEAVE, CAUSING THE PRIMARY BELT TO RIDE HIGHER ON THE SHEAVE, THEREBY DECREASING SPEED.

CLUTCH AND BRAKE


BY DEPRESSING THE CLUTCH-BRAKE PEDAL, THE BRAKE BAND IS TIGHTENED AND AT THE SAME TIME THE VARIATOR SHEAVE IS MOVED FORWARD CAUSING THE ENGINE PRIMARY BELT TO LOOSEN, THEREBY DISENGAGING THE DRIVE.

LINKAGE ADJUSTMENT

ALL MECHANICAL LINKAGES USED TO ENGAGE THE CLUTCH, BRAKE, AND VARI-DRIVE SPEED DRIVE ARE FACTORY ADJUSTED AND WILL NOT NORMALLY REQUIRE ADJUSTING. HOWEVER, AFTER A PERIOD OF TIME, NORMAL BELT WEAR, AND STRETCH MAY MAKE ADJUSTMENT NECESSARY.

WHEN TRACTOR LINKAGE IS PROPERLY ADJUSTED, THE VARI-DRIVE SPEED CONTROL LEVER WILL INCREASE TRACTOR SPEED WHEN MOVED FORWARD FROM QUADRANT NOTCH I THROUGH NOTCH 5. LINKAGE ADJUSTMENT IS NECESSARY WHEN BELT WEAR AND STRETCH CAUSES TRACTOR TO BE INOPERATIVE WHEN VARI-DRIVE SPEED CONTROL LEVER IS IN NOTCH I. WHEN THIS HAPPENS, ADJUSTMENT IS NECESSARY AS FOLLOWS.

1. MOVE VARI-DRIVE SPEED CONTROL LEVER TO THE FIFTH NOTCH FROM THE FRONT OF THE QUADRANT.
2. REMOVE SPRING LOCKING PINS AND LINK RODS D, E, F, A, B, C.
3. DISCONNECT SPARK PLUG CABLE AND TURN ENGINE WITH STARTER SEVERAL REVOLUTIONS.
4. ADJUST ROD A UNTIL CLUTCH AND BRAKE PEDAL IS ABOUT ONE INCH FROM FRAME WITH PRESSURE APPLIED. LOCK IN POSITION WITH SPRING, LOCKING PIN D.
5. WITH PEDAL RELEASED, HOLD CLEVIS CONNECTED TO ROD C UP SO BOLT H IS IN BOTTOM OF SLOT. ADJUST ROD C UP OR DOWN UNTIL IF CAN BE EASILY INSERTED IN POSITION. LOCK IN POSITION WITH SPRING LOCKING PIN F.
6. WITH PEDAL RELEASED, ADJUST ROD B UNTIL IT CAN BE EASILY INSERTED AND LOCK IN POSITION WITH SPRING LOCKING PIN E.
7. REPLACE SPARK PLUG CABLE. START ENGINE AND MOVE VARI-DRIVE SPEED CONTROL LEVER TO ALL POSITIONS. IF TRACTOR DOES NOT OPERATE CORRECT, IT IMAY BE NECESSARY TO REPLACE PRIMARY BELT AND RESET LINKAGE B AND C.




ATTACHMENT LIFT LEVER


WHEN THE ATTACHMENT LIFT LEVER IS IN THE FORWARD POSITION THE ATTACHMENT IS IN THE RAISED POSITION. MOVING THE LEVER BACKWARD LOWERS THE ATTACHMENT. PRESS THUMB RELEASE AND MOVE LEVER UNTIL ATTACHMENT OPERATES AT DESIRED HEIGHT. REMOVING PRESSURE FROM THUMB RELEASE LOCKS OPERATING LEVER AND ATTACHMENT IN DESIRED POSITION.

A PIN LOCK -OUT IS PROVIDED ON THE LOWER END OF THE LIFT LEVER TO HOLD THE THUMB RELEASE IN THE LOWERED POSITION. IN THIS POSITION, THE LIFT LEVER AND ATTACHMENTS ARE FREE TO FLOAT WITH THE GROUND CONTOUR.

TO SET LEVER IN FLOAT POSITION, PRESS THUMB RELEASE. PLACE SPRING STEEL PIN IN HOLE AS SHOWN.




FRONT WHEEL TOE-IN



MEASURE DISTANCES A AND B ABOVE. THE TRACTOR HAS PROPER TOE-IN OR ALIGNMENT WHEN DIMENSION A IS $\frac{3}{16}$ -INCH LESS THAN DIMENSION B. WHEN NECESSARY REMOVE BALL JOINT ON EITHER END OF ROD C AND ADJUST TILL PROPER TOE-IN IS OBTAINED. TIGHTEN JAMB NUT FIRMLY.

V-BELT IMPLEMENT CLUTCH


THE V-BELT IMPLEMENT CLUTCH COMES MOUNTED ON THE VARI-DRIVE TRACTOR AND IS READY FOR USE WITH YOUR BELT DRIVEN ATTACHMENTS. THIS CLUTCH IS HAND OPERATED FROM THE SEAT WITH A CABLE CONTROL MOUNTED IN THE DASH.



PARTS LIST


IMPLEMENT CLUTCH ASSEMBLY

REF. No.	PART No.	DESCRIPTION	QTY.	REF. No.	PART No.	DESCRIPTION	QTY.
1	SI673	SWIVEL ANCHOR	1	22	SI671	BEARING	2
2	SI672	SETScrew	1	23	S206	WIRE RING	2
3	SI695	SPRING	1	24	SI677	PULLEY	2
4	I5554	LOCKNUT 1/2-13 UNC	2	25	SI684	BELT GUIDE-BOTTOM	1
5	I5519	JAMB NUT 1/2-13 UNC	1	26	SI685	BELT GUIDE-TOP	1
6	I5804	LOCKWASHER 1/2	1	27	SI698	ANCHOR	1
7	SI688	BOLT 1/2-13 UNC x 2 1/4	1	28	SI670	RETAINING RING	2
8	I5057	BOLT 3/8-16 UNC x 3/4	4	29	SI668	KEY 1/4 x 7/8 WOODRUFF	2
9	I5802	LOCKWASHER 3/8	5	30	SI699	JACKSHAFT	1
10	936	FLATWASHER 1/2	2	31	I5066	BOLT 3/8 -16 UNC x 1	1
11	I5539	NUT 3/8-16 UNC	5	32	SI700	SHIELD, JACKSHAFT	1
12	I5096	BOLT 1/2-13 UNC x 3	1	33	I5553	NUT 5/16 -18 UNC	2
13	SI495	SPRING	1	34	SI669	BELT	1
14	I5517	NUT 5/16 - 18 UNC	4	35	I5808	LOCKWASHER 5/16	2
15	741	FLATWASHER 3/8	2	36	SI532	PULLEY	1
16	SI678	LEVER CLUTCH CONTROL	1	37	I9007	BOLT 1/4 x 3/4	2
17	SI675	PULLEY, IDLER	1	38	I5807	LOCKWASHER 1/4	2
18	SI693	STRAP, CLUTCH	1	39	I5531	NUT 1/4	2
19	SI682	MOUNTING PLATE, WELDMENT	1	40	SI658	CLAMP ENGAGING CABLE	1
20	SI683	HOUSING, WELDMENT	1				
21	SI676	PULLEY	1				



REAR WHEEL ASSEMBLY

6 - 12




ALL PURPOSE TIRE 6-12

NUMBER	DESCRIPTION	QTY.
S894	RIM	1
S606	INNER TUBE	1
S611	TIRE 6-12	1
I5412	HUB BOLT 7/16-20 UNF x 1 1/4	5
I5522	LUG NUT 7/16-20 UNF	5
S1110	HUB	1
810	SETScrew 3/8-16 UNC x 3/4	2

REAR WHEEL ASSEMBLY


23 X 8.50 - 12



FLOTATION TIRE 23 x 8.50 x 12

NUMBER	DESCRIPTION	QTY.
I5412	HUB BOLT 7/16 UNF x 1 1/4	5
I5522	LUG NUT 7/16-20 UNF	5
S1110	HUB	1
S887	RIM	1
S888	TIRE -TUBLESS 23 x 8.50-12	1
S889	VALVE TR415	1
810	SETScrew 3/8-16 UNC x 3/4	2


FRONT WHEEL ASSEMBLY
4.00 X 4.80 - 8



ALL PURPOSE TIRE 4.00 x 4.80 - 8

NUMBER	DESCRIPTION	QTY.
22	BEARING CONE	2
170	BEARING CUP	2
S805	INNER TUBE	1
S806	TIRE 4.00 x 4.80 - 8 RIB BUTTRESS	1
59	DUST CAP	1
S948	GREASE SEAL	1
S1517	RIM	1
6407	HUB	1
15412	HUB BOLT 7/16-20 UNF x 1 1/4	4
15522	LUG NUT 7/16-20 UNF	4

FRONT WHEEL ASSEMBLY
16 X 6.50 - 8




RIB TREAD TIRE 16 X 6.50 - 8

NUMBER	DESCRIPTION	QTY.
22	BEARING CONE	2
170	BEARING CUP	2
S885	TIRE 16 x 6.50 - 8 RIB TERRA	1
S886	VALVE TR413	1
S879	RIM	1
59	HUB CAP	1
S948	GREASE SEAL	1
6407	HUB	1
15412	HUB BOLT 7/16-20 UNF x 1 1/4	4
15522	LUG NUT 7/16-20 UNF	4


STEERING ASSEMBLY

NUMBER	DESCRIPTION	QTY.	NUMBER	DESCRIPTION	QTY.
S1720	STEERING ARM	1	S625	ROLL PIN 3/16 x 1 3/8	1
S518	TIE ROD	1	S659	BUSHING	1
S1447	DRAG LINK	1	S684	KEY 3/16 x 3/16 x 3/4	1
S526	DRIVEN GEAR	1	S1522	PIPE SPACER	4
S527	PINION GEAR	1	S1611	TOP PLATE	1
S560	AXLE ARM LINK	1	S1612	BOTTOM PLATE	1
S578	STEERING WHEEL	1	734	NUT 3/8-24 UNF	8
S1417	STEERING SHAFT	1	I5083	CAPSCREW 3/8-24 UNF x 2 1/2 CAD. PL.	4
S590	BALL JOINT	4	I5127	SETSCREW 3/8-16 UNC x 1/2	2
S604	KEY 1/4 x 1/4 x 3/4	1	I5597	NUT 3/8-24 UNF CAD. PL.	8
S621	ROLL PIN 3/16 x 2	1	I5802	LOCKWASHER 3/8 MEDIUM	4
S622	ROLL PIN 3/16 x 1	1	I5812	LOCKWASHER 3/8 CAD. PL.	8





GENERATOR BRACKET, CHOKE BRACKET
BELT GUARDS AND DRIVE PULLEY

PART No.	DESCRIPTION	QTY.
SI465	ADJUSTING BRACKET	1
SI526	DRIVE PULLEY	1
SI527	KEY	1
SI528	BELT GUARD	1
SI601	CHOKE BRACKET	1
SI604	BELT GUIDE-WISCONSIN	1
SI609	GENERATOR BRACKET	1
SI615	GUARD BRACKET	1
I5517	NUT 3/16	1
I5528	NUT 5/16	3
I5801	LOCKWASHER 3/16	1
I5808	LOCKWASHER 5/16	3
I5812	LOCKWASHER 3/8	3
I9007	BOLT 1/4 x 3/4	1
I9100	BOLT 3/8 x 3/4	3
I9102	BOLT 5/16 x 1	4



BATTERY CLAMP AND CONTROL CABLES

PART No.	DESCRIPTION	QTY.
S639	THROTTLE CONTROL	1
S882	CHOKE CONTROL	1
SI386	BATTERY CLAMP	1
SI390	HOLD DOWN ROD	2
SI529	IMPLEMENT CLUTCH ENGAGING CABLE	1
I5526	WING NUT	2




VARIATOR AND BRAKE ASSEMBLY

PART No.	DESCRIPTION	QTY.
S207	HAND GRIP	1
S592	WOODRUFF KEY	2
SI113	BEARING VARIATOR DRIVE	1
SI116	BEARING	1
SI144	BRAKE PULLEY	1
SI329	VARIATOR PULLEY	1
SI355	EYE BOLT	1
SI356	SPRING BRACKET (BRAKE)	1
SI358	CLEVIS	1
SI359	EYE BOLT	1
SI360	EYE BOLT	1
SI363	SPRING (IDLER BRACKET)	1
SI364	SPRING (VARIATOR)	1
SI365	SPRING (BRAKE PEDAL)	1
SI366	PIPE VARI-DRIVE LEVER	1
SI367	PIPE BOTTOM	1

PART No.	DESCRIPTION	QTY.
SI461	ROD	1
SI498	THUMB BOTTON	1
SI510	SPRING	1
SI512	IDLER SPRING BRACKET	1
SI513	PIN	1
SI515	BRACKET (BRAKE PEDAL)	1
SI516	IDLER PULLEY	1
SI520	SETSCREW	1
SI521	BRAKE SHOE	1
SI600	BRACKET (VARIATOR BRACKET)	2
SI799	SPACER	1
I5065	BOLT 3/8 x 2 UNF	1
I5066	BOLT 3/8 x 1 UNC	3
I5067	BOLT 3/8 x 1 1/2 UNC	2
I9409	PRESTO PIN	4
I5466	ROLLED PIN	1


SI368	THUMB RELEASE ROD	1	I5527	LOCKNUT 3/8 UNC	2
SI369	ROD	1	I5528	NUT 3/8 UNC	7
SI381	VARIATOR CONTROL BRACKET	1	I5531	NUT 1/4 UNC	9
SI382	SPEED ADJUSTING BRACKET	1	I5535	LOCKNUT 3/8 UNF	1
SI411	FLANGE (OUTSIDE)	2	I5582	NUT 3/8 UNC	2
SI412	FLANGE (CENTER)	1	I5585	LOCKNUT 1/2	1
SI422	ROD (BRAKE)	1	I5807	LOCKWASHER 1/4	7
SI434	YOKE (BRAKE ROD)	1	I5808	LOCKWASHER 5/16	7
SI437	HANGER BRAKE SHOE	1	I5812	LOCKWASHER 3/8	3
SI439	IDLER SPACER	1	I5911	FLATWASHER 1/4	4
SI440	BUSHING (IDLER)	1	I5976	COTTER PIN	2
SI444	HANGER (VARIATOR)	1	I9007	BOLT 1/4 x 3/4 UNC	2
SI457	IDLER BRACKET	1	I9092	BOLT 1/2 x 2 UNC	6
SI459	BEARING	1	I9102	BOLT 5/16 x 1 UNC	7



LIFT ASSEMBLY

PART No.	DESCRIPTION	QTY.
S207	HAND GRIP	1
S524	RIVET	1
S564	LOCK, LIFT	1
S576	LIFT BAR	2
S592	KEY WOODRUFF 3/16 x 3/4	1
S649	LIFT ROD	1
SI399	ROD ADJUSTING LEVER	1
SI420-1	BRACKET, FRONT LIFT L.H.	1
SI420-2	BRACKET, FRONT LIFT R.H.	1
SI421	BRACKET, REAR LIFT	2
SI428	LIFT ARM BOTTOM	1
SI462	BEARING	1
SI498	THUMB BUTTON	1
SI510	SPRING	1
SI617	LEVER SHAFT	1
SI773	CLEVIS	1
SI775	HITCH TUBE	1
SI779	DRAWBAR	1
SI884	ROD LOCK	1
SI887	BEARING	1

PART No.	DESCRIPTION	QTY.
SI920	QUADRANT	1
I239	CAPSCREW 5/16-18 UNC x 1	1
I273	PRESTO PIN	1
7108	HITCH PIN	1
15030	CAPSCREW 5/8-18 UNF x 1 1/2	2
15032	CAPSCREW 5/8-18 UNF x 2	2
15137	SETSCREW 1/2-13 UNC x 1	2
15466	ROLL PIN	1
15516	LOCKNUT 5/8-18 UNF	4
15531	HEX NUT 1/4-20 UNC	6
15807	LOCKWASHER 1/4	6
15812	LOCKWASHER 3/8 MED.	8
15907	FLATWASHER 5/16	1
15915	FLATWASHER	2
15916	FLATWASHER	1
15976	COTTER PIN	3
15981	COTTER PIN	1
19007	CAPSCREW 1/4-20 UNC x 3/4	6
19100	CAPSCREW 3/8-16 UNC x 3/4	8





HOOD, GRILL, AND HEADLIGHT ASSEMBLY

PART No.	DESCRIPTION	QTY.	PART No.	DESCRIPTION	QTY.
S540	HOOD	1	S1540	FACE PLATE, HEADLIGHT	2
S548	PIPE BUSHING	2	S1541	LOCKING CLIP	6
S951	CHROME TRIM	2	743	NUT	2
S952	CHROME TRIM	1	I5528	NUT	2
S956	HOOD TRIM BRACKET	4	I5568	NUT	1
S1117	GRILL LATCH	1	I5582	NUT	4
S1310	CHAIN	1	I5802	LOCKWASHER	2
S1401	GRILL TOP	1	I5807	LOCKWASHER	4
S1405-1	GRILL SIDE L.H.	1	I5808	LOCKWASHER	2
S1405-2	GRILL SIDE R.H.	1	I5812	LOCKWASHER	4
S1432	GRILL	1	I5907	FLATWASHER	1
S1535	HOUSING, HEADLIGHT	2	I9007	BOLT	4
S1536	REFLECTOR, HEADLIGHT	2	I9080	BOLT	2
S1537	BULB 12 - VOLT	2	I9100	BOLT	4
S1538	GASKET	2	I9414	STOVE BOLT & NUT	14
S1539	LENS, HEADLIGHT	2			

TAIL LIGHT ASSEMBLY
NO. 918

PART No.	DESCRIPTION	QTY.
S914	BULB-12 VOLT	1
S915	HOUSING	1
S916	LENS	1
I5413	STOVE BOLT - No. 10	2
I5476	MACHINE SCREW -No. 8	2






Model S232

TRANSAXLE MODEL NO. S232
FOUR SPEED

REF. No.	PART No.	DESCRIPTION	REF. No.	PART No.	DESCRIPTION
1	SI64	LEVER & HOUSING ASSY. SHIFT (INCL. 2 THRU 7)	39	SI45	SHAFT, INPUT
2	SI08	RING, SNAP	40	SI46	SPUR GEAR, INPUT SHAFT
3	SI09	RING, QUAD.	41	SI47	WASHER, THRUST
4	SI10	PIN, ROLL	42	SI48	SEAL & RETAINER ASSY. OIL (INCL. NO. 45)
5	SI11	HOUSING, SHIFT LEVER	43	SI49	GEAR, OUTPUT
6	SI12	KEEPER, SHIFT LEVER	44	SI50	PINION, OUTPUT
7	SI13	LEVER, SHIFT	45	SI51	SEAL, OIL
8	SI14	ROD ASSY. SHIFT (INCL. 9 THRU 12 & 24)	46	SI52	HOUSING, AXLE
9	SI15	SPRING	47	SI53	COVER ASSY. TRANSAXLE (INCL. 54, 55, 57, 59, & 63)
10	SI16	BALL, STEEL	48	SI54	CASE ASSY. TRANSAXLE (INCL. 54, 55, 57, & 63)
11	SI17	FORK, SHIFTER	49	SI55	SCREW, SOCKET HD. CAP 1/4 -20 X 3/4
12	SI18	ROD, SHIFTER(3RD & 4TH)	50	SI56	PIN, DOWEL
13	SI19	ROD ASSY. SHIFT (INCL. 9, 10, 11, & 14)	51	SI57	SCREW, HEX HD 5/16 - 18 X 7/8
14	SI20	ROD, SHIFTER (LOW)	52	SI58	PLUG, MAGNETIC DRAIN
15	SI21	AXLE	53	SI59	LOCKWASHER, SPLIT 5/16
16	SI22	WASHER, THRUST	54	SI60	BEARING, NEEDLE
17	SI23	SCREW, HEX HD. CAP 1/4-20 X 2 1/2	55	SI61	BEARING, NEEDLE
18	SI24	LOCKWASHER, 1/4	56	SI62	BEARING, BALL
19	SI25	GEAR, RING	57	SI65	BEARING, NEEDLE
20	SI26	PIN, DRIVE	58	SI66	BEARING, BALL
21	SI27	BLOCK DRIVE	59	SI67	BEARING, NEEDLE
22	SI28	PINION, BEVEL	60	SI68	SEAL, OIL
23	SI29	SHAFT & GEAR, BRAKE	61	SI69	WASHER
24	SI30	RING, SNAP	62	SI70	SHAFT & PINION
25	SI31	SHAFT & BEARING ASSY. PINION (INCL. NO. 26)	63	SI71	BEARING, NEEDLE
26	SI32	BEARING	64	SI72	SHAFT, REVERSE IDLER
27	SI33	GEAR CLUSTER ASSY. (INCL. NO. 28)	65	SI73	SPACER, REVERSE IDLER
28	SI34	BUSHING	66	SI74	IDLER, REVERSE
29	SI35	STOP, SHIFTER	67	SI75	SPUR GEAR (22 TEETH)
30	SI36	GASKET, CASE & COVER	68	SI76	BEARING, THRUST
31	SI37	GASKET, SHIFT LEVER HOUSING	69	SI77	CARRIER ASSY. DIFFERENTIAL (INCL. NO. 71)
32	SI38	GEAR, SHIFTING(3RD & 4TH)	70	SI78	CARRIER ASSY. DIFFERENTIAL (INCL. NO. 71)
33	SI39	GEAR, SHIFTING(1ST, 2ND, & REV.)	71	SI79	BUSHING
34	SI40	GEAR, BEVEL	72	SI80	O RING
35	SI41	GEAR, IDLER	73	SI81	WASHER, THRUST
36	SI42	GEAR CLUSTER ASSY. (INCL. NO. 28)	74	SI82	WASHER, THRUST
37	SI43	SPACER	75	SI83	PLUG, PIPE
38	SI44	RING, SNAP			




MODEL S233

TRANSAXLE MODEL NO. S233
THREE SPEED

REF. No.	PART No.	DESCRIPTION	REF. No.	PART No.	DESCRIPTION
1	SI84	LEVER & HOUSING ASSY., SHIFT (INCL. NO. 2 THRU 7)	35	S202	SPACER
2	SI08	RING, SNAP	36	S203	GEAR, SPUR (22 TEETH)
3	SI09	RING, QUAD.	37	S204	SPACER
4	SI10	PIN, ROLL	38	S208	GEAR, SPUR (16 TEETH)
5	SI85	HOUSING, SHIFT LEVER	39	SI45	SHAFT, INPUT
6	SI12	KEEPER, SHIFT LEVER	40	SI46	SPUR GEAR, INPUT SHAFT
7	SI86	LEVER, SHIFT	41	SI69	WASHER
8	SI87	ROD ASSY., SHIFT (INCL. NO. 9 THRU 12)	42	S213	SPACER
9	SI15	SPRING	43	SI49	GEAR, OUTPUT
10	SI16	BALL, STEEL	44	S214	PINION, OUTPUT
11	SI17	FORK, SHIFTER	45	S215	SEAL, OIL
12	SI88	ROD, SHIFTER	46	SI56	HOUSING, AXLE
13	SI89	ROD ASSY., SHIFT (INCL. NO. 9, 10, 11, 14, & 61)	47	S216	COVER ASSY., TRANSAXLE (INCL. NO. 54, 57, & 63)
14	SI18	ROD, SHIFTER	48	S217	CASE ASSY., TRANSAXLE (INCL. NO. 54, 56, & 63)
15	SI90	AXLE	49	SI55	SCREW, SOCKET HD. CAP 1/4-20 x 3/4
16	SI91	WASHER, THRUST	40	SI56	PIN, DOWEL
17	SI23	SCREW, HEX HD. CAP 1/4-20 x 2 1/2	51	S218	SCREW, HEX HD. CAP 5/16 -18 x 3/4
18	SI24	LOCKWASHER 1/4	52	SI83	PLUG, PIPE
19	SI25	GEAR, RING	53	S219	LOCKWASHER 5/16
20	SI26	PIN, DRIVE	54	S220	BEARING
21	SI27	BLOCK, DRIVE	55	S221	RING, SNAP
22	SI92	PINION, BEVEL	56	S222	BEARING
23	SI93	PINION & BUSHING ASSY. IDLER	57	S223	BEARING
24	SI94	GEAR, BEVEL	58	S224	BEARING
25	SI95	SHAFT & BEARING ASSY., SHIFTER (INCL. NO. 26)	59	SI51	SEAL, OIL
26	SI32	BEARING	60	S212	SEAL, OIL
27	SI96	GEAR, IDLER	61	S225	RING, SNAP
28	S97	SHAFT, IDLER	63	S226	BEARING
29	SI98	STOP, SHIFTER	64	S227	SHAFT, REVERSE IDLER
30	SI99	GASKET, CASE & COVER	65	S228	SPACER, REVERSE IDLER
31	S200	GASKET, SHIFT LEVER HOUSING	66	SI74	IDLER, REVERSE
32	SI38	GEAR, SHIFTING(2ND & HIGH)	68	S229	BEARING, THRUST
33	SI39	GEAR, SHIFTING(1ST & REV.)	69	S235	CARRIER, DIFFERENTIAL
34	S201	GEAR, SPUR(26TEETH)	70	S231	CARRIER, DIFFERENTIAL


FRONT AXLE ASSEMBLY

PART No.	DESCRIPTION	QTY.
I19	FLATWASHER 3/4	2
I20	NUT CASTELLATED	2
449	GREASE FITTING	3
I5108	SETSCREW	1
I5509	NUT 5/8-18 UNF	1
I5805	LOCKWASHER	1
I5912	BUSHING	2
I5977	COTTER PIN 5/32 x 1 1/2	1
S209	SETCOLLAR	1
S1788-1	SPINDLE L.H.	1
S1788-2	SPINDLE R.H.	1
S528	BUSHING	4
S533	BUSHING	2
		2
S708	BOLT	
I5067	BOLT	2
I5812	LOCKWASHER	2
I5582	NUT	2
SI526	PLATE TOP (AXLE STOP)	1
SI527	PLATE BOTTOM (AXLE STOP)	1



SEAT, FRAME, FENDER, AND
DASH ASSEMBLIES

PART No.	DESCRIPTION	QTY.	PART No.	DESCRIPTION	QTY.
S211	GREASE FITTING	1	15595	THUMB SCREW 5/16 UNC x 3/4	2
SI370	END FRAME	1	15807	LOCKWASHER 1/4 CAD. PL.	10
SI409-1	FOOT REST - L.H.	1	15808	LOCKWASHER 5/16 CAD. PL.	8
SI409-2	FOOT REST - R.H.	1	15812	LOCKWASHER 3/8 CAD. PL.	10
SI453-1	FENDER - L.H.	1	19007	CAPSCREW 1/4 UNC x 3/4 CAD. PL.	10
SI453-2	FENDER - R.H.	1	19100	CAPSCREW 3/8 UNC x 3/4 CAD. PL.	6
SI496	BASE FRAME	1	19102	CAPSCREW 5/16 UNC x 1 CAD. PL.	8
SI497	DASH ASSEMBLY	1	19103	CAPSCREW 1/2 UNC x 1 1/4 CAD. PL.	2
SI499	TRANSMISSION MOUNT	1	19106	BOLT 3/8 x 1 3/4	4
SI500	BATTERY BOX	1	S953	DASH TRIM	1
SI607	SEAT	1	S626	RUBBER TRIM	1
I5527	LOCKNUT	4	SI530	RUBBER WASHER	4
I5528	NUT 5/16 UNC CAD. PL.	8	I5489	STOVE BOLT (INCLUDED NUT)	2
I5531	NUT 1/4 UNC CAD. PL.	10	SI389	HANGER REAR	2
I5582	NUT 3/8 UNC CAD. PL.	10	I5066	BOLT 3/8 x 1 UNC	4
I5585	LOCKNUT 1/2 UNC CAD. PL.	2	S571	CUSHION - BACK	1
			S572	CUSHION - LOWER	1



SERVICE



BULLETIN

BUSH HOG INC.

SELMA, ALABAMA

P.O. BOX 1039

BULLETIN NO.

DATE

6 - 66

2 - 14 - 66

INSTALLATION

1. JACK UP REAR OF TRACTOR.
2. INSTALL 4 CARRIAGE BOLTS IN OUTER SET OF HOLES.
3. PLACE SPACER RING OVER BOLTS AND ATTACH OTHER WHEEL WITH LOCKWASHER AND NUT. (AS SHOWN)


SUBJECT: DUAL WHEELS

EFFECTIVE DATE: FEBRUARY 1, 1966

NOTE: WHEN ORDERING

ORDER DW-2
FOR VARI-DRIVE
AND DIRECT DRIVE
WITH OFFSET WHEELS.

1313 SURE GRIP
S785 WIDE SUBURBAN
S960 NARROW SUBURBAN



* WHEN ORDERING TIRE ASSEMBLIES SPECIFY
TYPE OF TREAD DESIGN.

()


()

()

SERVICE

BUSH HOG INC.
BULLETIN NO.

8 - 66



SELMA, ALABAMA

BULLETIN

P.O. BOX 1039

DATE

3 - 8 - 66

SUBJECT: TO PREVENT SCALPING BY MOWERS
EFFECTIVE: MARCH 1, 1966

NOTE!! WHEN ORDERING,
ORDER KIT NO. S2295 FOR
M-32A AND M-42.


S2271

19007


1. CUT OUT AND FOLD TEMPLATE AS INSTRUCTED ON TEMPLATE SHEET ENCLOSED.
2. FROM BOTTOM OF MOWER DECK AND INSIDE OF HANGER, CENTER PUNCH LOCATION OF HOLES AND DRILL 5/16 AS INDICATED ON TEMPLATE.
3. PLACE SKID S2271 INSIDE HANGER AND FASTEN WITH CAPSCREW 19007, LOCKWASHER 15807, AND NUT 15531.

KIT NO. S2295		
S2271	SKID	2
19007	CAPSCREW	4
15807	LOCKWASHER	4
15531	NUT	4

DRILL TEMPLATE



SERVICE



BULLETIN

BUSH HOG INC.

BULLETIN NO.

9 - 66

SELMA, ALABAMA

P.O. BOX 1039


DATE

3 - 18 - 66

SUBJECT: WIDE SUBURBAN TIRES FOR TRACTORS PRIOR TO SERIAL NO. 7183.
EFFECTIVE: MARCH 15, 1966

TO AVOID CHANGING SHORT SPINDLES ON TRACTORS PRIOR TO SERIAL NO. 7183 THE S2311 TIRE IS AVAILABLE. THIS S2311 TIRE WILL MOUNT ON THE NARROW RIM. IT USES THE S805 TUBE THAT IS USED IN THE S806 TIRE.

NOTE // THIS IS FOR DIRECT DRIVE TRACTORS



()

1
1

()

1
1

()