



Installation and Maintenance Manual

IM 987-1

Group: **Applied Air Systems**

Part Number: **IM 987**

Date: **November 2015**

RoofPak™ Applied Rooftop Systems Air Handling Units

RAH 047C–077C: 12,000 to 50,000 cfm

RDS 800C–802C: 4,000 to 20,000 cfm

with MicroTech® III Unit Controllers



Introduction	3	Unit Options	62
Gas Burner Nameplate	3	Control Actuators	62
Hazardous information messages	3	Check, Test, and Start Procedures	76
Typical Component Locations	4	Economizer Start-up	77
Control Locations	4	Heating System Startup	78
Control Panel	4	Air Balancing	78
Mechanical Installation	10	Drive Belt Alignments	79
Receiving Inspection	10	Final Control Settings	84
Unit Clearances	10	MicroTech III Controller Operation	86
Ventilation Clearance	11	Using the Keypad/Display	86
Overhead Clearance	11	Maintenance	101
Roof Curb Assembly and Installation	12	Servicing Control Panel Components	101
IBC Seismic Compliant Units	14	Planned Maintenance	101
Post and Rail Arrangement	16	Unit Storage	102
Field Refrigerant Piping and Charging of DX Coils	22	Gas Furnace	102
Unit Piping	25	Bearing Lubrication	103
Piping for Steam, Hot Water/Chilled Water Coils	26	Control Panel Components	108
Vestibule Assembly Instructions	31	Manual Motor Protector (MMP)	108
Damper Assemblies	33	Replacement Parts List	113
Installing Ductwork	37	Service and Warranty	114
Preparing Unit for Operation	40	In-Warranty Return Material Procedure	114
Electrical Installation	43	Limited Product Warranty (North America)	114
Field Power Wiring	43	Rooftop Equipment Warranty Registration	115
Field Control Wiring	47	Quality Assurance Survey	120
Sequences of Operation	48		
Power-up	48		
Fan Operation	49		
Economizer Operation	50		
Heating	50		
Wiring Diagrams	51		

This manual provides general information about the “C” vintage Daikin Applied RoofPak applied rooftop unit, models RDS and RAH. In addition to an overall description of the unit, it includes mechanical and electrical installation procedures, commissioning procedures, sequence of operation information, and maintenance instructions. For further information on the optional forced draft gas-fired furnace, refer to [IM 684](#) or [IM 685](#).

The MicroTech III applied rooftop unit controller is available. For a detailed description of the MicroTech III components, input/output configurations, field wiring and information on using and programming the MicroTech III unit controller, refer to [OM 920](#).

For a description of operation and information on using the keypad to view data and set parameters, refer to the appropriate program-specific operation manual (see [Table 1](#)).

Table 1: Program Specific Rooftop Unit Literature

	Rooftop Unit Control Configuration	Operation Manual Number
VFD	Daikin Applied 208–460 V	OM 844
		OM 1190
	Daikin Applied 575 V	OM 895
		OM 1191
Non-Daikin Applied	See vendor manuals	

Gas Burner Nameplate

On units that include gas heat, the nameplate is located on the lower right corner of the main control box door. It includes the burner model number, minimum/maximum input, maximum temperature rise, and minimum cfm.

Hazardous information messages

CAUTION

Cautions indicate potentially hazardous situations, which can result in personal injury or equipment damage if not avoided.

WARNING

Warnings indicate potentially hazardous situations, which can result in property damage, severe personal injury, or death if not avoided.


DANGER

Dangers indicate a hazardous situation which will result in death or serious injury if not avoided.

NOTICE

Notices give important information concerning a process, procedure, special handling or equipment attributes.

Figure 1: Nomenclature



Typical Component Locations

Figure 2 shows a typical unit with locations of major components. These figures are for general information only. See the project's certified submittals for actual specific dimensions and locations.

Control Panel

The unit control panels and their locations are shown in the following figures. These figures show a typical unit configuration. Specific unit configurations may differ slightly from these figures depending on the particular unit options.

Control Locations

All controls are optional. If controls are ordered, Figure 2 shows the locations of the various control components mounted throughout the units. See Figure 3 for the locations of control components mounted in control panels. Additional information is included in the wiring diagram legend, which is included in Wiring Diagrams on page 51. Figure 2 shows the blow-through heat and the blow-through coil sections.

Figure 2: Control Locations




Figure 3: Control Panel Locations




Figure 5: Typical Main Control Panel, Size 047C, 460 Volt

MBX1




Figure 6: Typical Main Control Panel, Size 077C, 460 Volt

MBX1




Figure 7: Typical Gas Heat Panel, 1000 MBH




Figure 9: FD Bypass Panel, 40 Hp, 460 Volt




Figure 8: Typical Propeller Exhaust Panel, 3 Fans, 460 Volt




Figure 10: Electric Heat Panel, Sizes 800C, 802C




Figure 11: Electric Heat Panel, Size 047C




Figure 13: Harness Plug Connector Detail





Figure 12: Electric Heat Panel, Size 077C



CAUTION

Sharp edges on sheet metal and fasteners can cause personal injury. This equipment must be installed, operated, and serviced only by an experienced installation company and fully trained personnel.

NOTE: The installation of this equipment shall be in accordance with the regulations of authorities having jurisdiction and all applicable codes. It is the responsibility of the installer to determine and follow the applicable codes.

Receiving Inspection

When the equipment is received, all items should be carefully checked against the bill of lading to be sure all crates and cartons have been received. **If the unit has become dirty during shipment (winter road chemicals are of particular concern), clean it when received.**

All units should be inspected carefully for damage when received. Report all shipping damage to the carrier and file a claim. In most cases, equipment ships F.O.B. factory and claims for freight damage should be filed by the consignee. Before unloading the unit, check the unit nameplate to make sure the voltage complies with the power supply available.

Unit Clearances

Service Clearance

Allow an approximate service clearance as indicated in [Figure 14](#). Also, Daikin Applied recommends providing a roof walkway to the rooftop unit as well as along two sides of the unit that provide access to most controls and serviceable components.

Figure 14: Service Clearances, Unit with Housed DWDI Supply Fan





Figure 15: Service Clearances, Unit with SWSI Plenum Supply Fan



Ventilation Clearance

Below are minimum ventilation clearance recommendations. The system designer must consider each application and provide adequate ventilation. If this is not done, the unit will not perform properly.

Unit(s) surrounded by a screen or a fence:

1. The bottom of the screen or fence should be at least 1 ft. (305 mm) above the roof surface.
2. The distance between the unit and a screen or fence should be as described in [Figure 15](#).
3. The distance between any two units within a screen or fence should be at least 120" (3048 mm).


Unit(s) surrounded by solid walls:

1. If there are walls on one or two adjacent sides of the unit, the walls may be any height. If there are walls on more than two adjacent sides of the unit, the walls should not be higher than the unit.
2. The distance between the unit and the wall should be at least 96" (2438 mm) on all sides of the unit.
3. The distance between any two units within the walls should be at least 120" (3048 mm).

Do not locate outside air intakes near exhaust vents or other sources of contaminated air.

If the unit is installed where windy conditions are common, install wind screens around the unit, maintaining the clearances specified ([Figure 17](#)). This is particularly important to prevent blowing snow from entering the outside air intake and to maintain adequate head pressure control when mechanical cooling is required at low outdoor air temperatures.

Figure 17: Overhead Clearances




Overhead Clearance

NOTICE

On units with side discharge, access to plenum-mounted components becomes difficult once ductwork is installed. Installer must provide access in the ductwork for plenum mounted controls

1. Unit(s) surrounded by screens or solid walls must have no overhead obstructions over any part of the unit.
2. The following restrictions must be observed for overhead obstructions above the air handler section (see [Figure 17](#)):
 - a. There must be no overhead obstructions above the furnace flue, or within 9" (229 mm) of the flue box.
 - b. Overhead obstructions must be no less than 96" (2438 mm) above the top of the unit.
 - c. There must be no overhead obstructions in the areas above the outside air and exhaust dampers that are farther than 24" (610 mm) from the side of the unit.

Figure 16: Side Discharge



Roof Curb Assembly and Installation

WARNING

Mold can cause personal injury. Some materials such as gypsum wall board can promote mold growth when damp. Such materials must be protected from moisture that can enter units during maintenance or normal operation.

Locate the roof curb and unit on a portion of the roof that can support the weight of the unit. The unit must be supported to prevent bending or twisting of the machine.

If building construction allows sound and vibration into the occupied space, **locate the unit over a non-critical area. It is the responsibility of the system designer to make adequate provisions for noise and vibration in the occupied space.**

Install the curb and unit level to allow the condensate drain to flow properly and allow service access doors to open and close without binding.

Integral supply and return air duct flanges are provided with the RAH roof curb, allowing connection of duct work to the curb before the unit is set. The gasketed top surface of the curb flanges seals against the unit when it is set on the curb. These flanges must not support the total weight of the duct work. Assembly of a typical RAH roof curb is shown in Figure 18. Parts A through H are common to all units having bottom return openings. Depending on the unit length, Parts L and M may be included with the roof curb kit to create the correct overall curb length.

Assembly instructions

1. Set curbing parts **A** through **H** per dimensions shown over roof opening or on a level surface (Figure 18). Note location of return and supply air openings.
2. If applicable, set other curbing parts (**D**, **L**, **M**, etc.) in place making sure that the orientation complies with the assembly instructions (see Detail A). Check alignment of all mating bolt holes.
3. Bolt curbing parts together using fasteners provided. Tighten all bolts finger tight.
4. Square entire curbing assembly and securely tighten all bolts.
5. Position curb assembly over roof openings. Curb must be level from side to side and over its length. Check that top surface of the curb is flat with no bowing or sagging.
6. Weld curbing in place. Caulk all seams watertight. Remove backing from 0.25" (6 mm) thick x 1.50" (38 mm) wide gasketing and apply to surfaces shown by cross-hatching.
7. Flash curbing into roof as shown in detail view B (Figure 19 on page 13).
8. Parts **E** and **F** are not required on units with no return shaft within the curb perimeter.
9. Parts **G** and **H** are not required on units with no supply shaft within the curb perimeter.
10. Be sure that electrical connections are coordinated (Figure 26 on page 17).

Figure 18: RAH Roof Curb Assembly Instructions




Figure 19: RDS Roof Curb Assembly Instructions





Table 2: RDS Roof Curb Assembly Instructions

Unit size	Fan	X	Y	XX	YY	Unit size	Return fan	X	Y	XX	YY
		in (mm)	in (mm)	in (mm)	in (mm)			in (mm)	in (mm)	in (mm)	in (mm)
800-802C	None	24.0 (610)	82.0 (2083)	6.8 (173)	1.5 (38)	800-802C	None	24.0 (610)	82.0 (2083)	6.8 (173)	1.5 (38)
	(2) 15" FC	24.0 (610)	82.0 (2083)	6.8 (173)	1.5 (38)		(2) 15" FC	24.0 (610)	82.0 (2083)	6.8 (173)	1.5 (38)
	30" AF	30.0 (762)	76.0 (1930)	6.8 (173)	4.5 (114)		30" AF	30.0 (762)	76.0 (1930)	6.8 (173)	4.5 (114)
	40" AF	36.0 (914)	78.0 (1981)	14.8 (376)	3.5 (89)		40" AF	36.0 (914)	78.0 (1981)	14.8 (376)	3.5 (89)

Figure 20: Roofing Detail "B"



IBC Seismic Compliant Units

⚠ IMPORTANT

An acceptable IBC seismic installation provides a direct positive attachment to both the building structure and the roof mounted equipment. Refer to the roof curb manufacturer's submittal drawings for actual roof curb assembly, attachment details and rigging instructions for both roof curb and post and rail arrangements.

It is important to follow these installation instructions for all IBC Seismic compliant Daikin Applied Rooftop units.

IBC Seismic compliant Daikin Applied Rooftop units can be mounted to either a roof curb or a post and rail setup. If using a roof curb, it must be specifically designed for seismic restraint and be IBC seismic compliant (spring isolated or non-isolated type seismic roof curbs are available). Typical construction of a seismic rated roof curb is from structural steel framing and contains seismic hold down brackets for attachment of the rooftop unit (Figure 21). Post and rail arrangements rated for seismic applications are also available (spring isolated or non-isolated).

Roof Curb Arrangement

⚠ CAUTION

When welding unit to the curb, do not damage wiring (control panel side). Weld ONLY in the specified zone in the acceptable weld zone. Welding must comply with weld fillet size, etc. as indicated in Figure 22 on page 15.

1. Set the rooftop unit on the roof curb (Daikin Applied Rooftop units are designed to overhang from the roof curb).
2. Adjust the seismic hold down brackets so they come into contact with the unit base per Figure 22 and Figure 23 on page 15.
 - a. The seismic hold down brackets should be adjustable and accommodate the overhang of the rooftop unit.
 - b. If the hold down bracket cannot reach the unit base, use a shim spacer. See Figure 23.
3. Weld each seismic hold down bracket (and shim spacer, if required) to the unit base as shown in the acceptable weld zone detail in Figure 22.

NOTE: High temperature insulation is installed at the factory to allow for field welding along the lower front edge region of the unit base.

Figure 21: Typical Seismic Roof Curb (Spring Isolated)




Figure 22: Welding of Hold Down Brackets—Unit Base, Cross-Sectional View





Figure 23: Shim Spacers on Hold Down Brackets



Post and Rail Arrangement

CAUTION

When welding unit to the curb, do not damage wiring (control panel side). Weld ONLY in the specified zone in the acceptable weld zone. Welding must comply with weld fillet size, etc. as indicated in Figure 24.

1. Set the rooftop unit on the rails. The rails should run lengthwise and support the entire unit base.
2. Weld both sides of the unit directly to each rail as shown in Figure 24 and Figure 25. The total number of welds required is dependent on the length of the unit.
 - a. Make the fillet welds 2 inches long, spaced 48 inches apart on centers.
 - b. Place the end welds 6 to 12 inches from the unit edge.

NOTE: High temperature insulation is installed at the factory to allow for field welding along the lower front edge region of the unit base.

Figure 24: Welding of Unit to Rail—Unit Base, Cross-Sectional View




Figure 25: Weld Locations for Rail Arrangement






Figure 26: Typical Power Wire Entrance, Curb View (RDS 800C-802C Shown, for exact values, refer to submittal)



Detail A



Post and Rail Mounting

CAUTION

The unit must be level side to side and over the entire length. Equipment damage can result if the unit is not level.

CAUTION

Lifting points may not be symmetrical to the center of gravity of the unit. Ballast or unequal cable lengths may be required.


WARNING

Use all lifting points. Improper lifting can cause severe personal injury and property damage.

When mounting by post and rail, run the structural support the full length of the unit. Locate the structural member at the base of the unit as shown in Figure 27, assuring the I-beam is well supported by the structural member.

If resilient material is placed between the unit and the rail, insert a heavy steel plate between the unit and the resilient material to distribute the load. Seal cabinet penetrations (electrical, piping, etc.) properly to protect against moisture and weather.

Figure 27: Post and Rail Mounting



* Maximum recommended width for structural member is 5" (127mm) to allow for adequate space for duct connections and electrical entry

Rigging and Handling

Lifting brackets with 2" (51 mm) diameter holes are provided on the sides of the unit.

Use spreader bars, 96" to 100" (2438 to 2540 mm) wide, to prevent damage to the unit cabinet. Avoid twisting or uneven lifting of the unit. The cable length from the bracket to the hook should always be longer than the distance between the outer lifting points.

If the unit is stored at the construction site for an intermediate period, follow these additional precautions:

1. Support the unit well along the length of the base rail.
2. Level the unit (no twists or uneven ground surface).
3. Provide proper drainage around the unit to prevent flooding of the equipment.
4. Provide adequate protection from vandalism, mechanical contact, etc.
5. Securely close the doors.
6. If there are isolation dampers, make sure they are properly installed and fully closed to prevent the entry of animals and debris through the supply and return air openings.
7. Cover the supply and return air openings on units without isolation dampers.

Figure 28 shows an example of the rigging instruction label shipped with each unit.

Figure 28: Rigging and Handling Instruction Label

Rigging and Handling Instructions

Unit has either four or six lifting points (four-point shown below).

Caution: All lifting points must be used.

Note: Rigging cables must be at least as long as distance "A"

The diagram shows a 3D perspective of the unit with four lifting points. Two spreader bars are shown connecting the lifting points. A dimension line labeled 'A' indicates the distance between the outer lifting points. The text 'Lift only as indicated' is written below the diagram.

Caution: Lifting points may not be symmetrical to center of gravity of unit. Ballast or unequal cable lengths may be required.

Lifting Points

To determine the required lifting cable lengths and whether four-point or six-point lifting is required, use [Table 3](#) and [Table 4](#) and [Figure 29](#).

Referring to [Figure 29](#), note that dimension A is the distance between the outer lifting points. The four outer rigging cables must be equal to or longer than dimension A. Dimension B shows the minimum distance between the outer and the inner lifting points for six-point lifting. Use this to roughly determine the required length of the middle cables for sixpoint lifting. Determine dimension A by subtracting dimensions X and Y from dimension Z (e.g., $A = Z - X - Y$).

Where:

- Z = Total unit length in inches (refer to certified drawings for this dimension)
- X = Outdoor/return air section length (refer to [Figure 29](#) and [Table 5](#) for this dimension)
- If $A \leq 288"$ (7315 mm), 4-point lifting is sufficient
- If $A > 288"$ (7315 mm), 6-point lifting is required



Table 3: RAH Economizer Section "X" Dimension (See [Figure 29](#))

Type of economizer section	047C	077C
100% OA	0	0
Plenum	48" (1219 mm)	72" (1829 mm)
0–30% OA	48" (1219 mm)	72" (1829 mm)
0–100% economizer	72" (1829 mm)	96" (2438 mm)
0–100% economizer with return fan	72" (1829 mm)	96" (2438 mm)

Table 4: RDS Outdoor/Return Air Section "X" Dimension (See [Figure 29](#))

Outdoor/return air section	800C	802C
100% OA	0	0
Plenum	40" (1016 mm)	52" (1321 mm)
0–30% OA	40" (1016 mm)	52" (1321 mm)
0–100% economizer	40" (1016 mm)	52" (1321 mm)
0–100% economizer with 15" return fan	62" (1575 mm)	—
0–100% economizer with 30" return fan	52" (1321 mm)	52" (1321 mm)
0–100% economizer with 40" return fan	—	80" (2032 mm)

Figure 29: Unit Type RAH Lifting Points



- RDS 800: B Min. = 62" (1515 mm)
- RDS 802: B Min. = 84" (2134 mm)
- RAH 47: B Min. = 96" (2438 mm)
- RAH 77: B Min. = 120" (3048 mm)

Split Units

Although units typically ship from the factory as complete units, they can be factory split at the supply fan bulkhead and connected later on the roof. This configuration is ordered if the shipping length or a weight limitation prevents ordering a packaged unit.

A single nameplate is attached to the air handler section and power is supplied to both sections through the optional main control box as in a packaged unit.


RAH Factory Split at Fan

Field reassembly of an RAH unit that shipped split at the fan takes place in three phases: (1) setting the sections, (2) mechanically recoupling the cabinet, and (3) reconnecting power and control wiring.

Phase I. Set sections

1. Remove top cap and save for Phase II, Step 1.
2. Remove screws on fan panel, leaving retainer clips in place to secure bulkhead. Save screws for Phase II, Step 5.
3. Remove plywood and retaining angles from unit and discard.
4. Carefully lower both sections of unit (fan end and discharge end) into place, making sure the roof curb engages the recesses in the unit base.


Figure 30: Set Sections



Phase II. Reassemble cabinet (Figure 31)

1. Reinstall top cap removed in Phase I, Step 1.
2. Caulk (watertight) ends of splice cap.
3. Caulk (watertight) vertical seam.
4. Install #10 screws (provided).
5. Install screws (0.25–20 × 0.75) removed in Phase I, Step 2.
6. Install splice cover (provided).

Figure 31: Reassemble Cabinet



Phase III. Reconnect power and control wiring


⚠ CAUTION

Connect the power block correctly and maintain proper phasing. Improper installation can cause severe equipment damage.

Once the sections are physically reconnected, the ends of the power harness are fed back through the unit base into the junction box, per the unit's electrical schematics.

1. Make electrical connections and reinstall inner raceway cover as shown in [Figure 32](#).
2. When power wire reconnection is complete, reinstall the inner raceway cover in the blank or heat section. [Figure 32](#) shows a typical installation of the raceway cover.
3. Run the control harnesses by removing the external raceway covers on either side of the unit split.
4. Remove the excess harness length from the external raceway on the downstream side of the split; then route along the raceway, through the bushed hole in the fan section and into the junction box where control wiring terminal blocks are provided for reconnection.
5. Make all electrical connections per the unit's electrical schematics.
6. Reinstall the external raceway covers after routing of the control wires is complete.

Figure 32: Electrical Connections and Raceway Cover Installation



Field Refrigerant Piping and Charging of DX Coils

⚠ CAUTION

For any cabinet penetrations, tightly seal the holes to prevent water or air leakage.

⚠ CAUTION

The pounds of refrigerant in the system may exceed the capacity of the condenser, depending on the amount of refrigerant in the liquid lines between the DX coil and the condensing unit.

Refer to condenser manufacturer for information about refrigerant capacity. Suitable means of containing the refrigerant is required.

⚠ CAUTION

To prevent liquid return and damage to the compressor on systems with optional hot gas bypass, it is important to locate the bypass solenoid valve at the condensing unit and not at the DX coil.

Units that ship from the factory with DX coils installed do not include refrigerant piping or refrigerant controls. The coil assembly is ready for field connections at the distributors and at the suction headers. Piping kits that provide the necessary liquid and hot gas piping and control components are available for field installation. Field-installed refrigerant piping may exit the unit cabinet at one of the following locations:

- Through the floor of the unit.
- Through the discharge and bulkhead of the unit.
- Through a cabinet door near the DX coil that is not required for service areas.

In preparing for field piping, remove the plastic plugs on the distributors and unsweat the copper caps at the suction header connections.

Follow piping design, sizing, and installation information presented in ASHRAE handbooks in the design and installation of interconnecting piping. The DX coil and condensing unit are intended to be set at the same elevation, as close as possible to each other to minimize refrigerant pressure drop. Design piping to prevent liquid refrigerant carryover to the compressor and to provide a continuous return of compressor oil from the system.

Piping Recommendations

1. Use type K or L clean copper tubing. Thoroughly clean or braze all joints with high temperature solder. Base piping sizes on temperature/pressure limitations as recommended in the following paragraphs. Under no circumstances should pipe size be based strictly upon coil or condensing unit piping connection size.
2. Do not exceed suction line piping pressure drop equivalent to 2°F (1°C), 3 psi (20.7 kPa) per 100 feet (30.5 m) of equivalent pipe length. After the suction line size is determined, check the vertical suction risers to verify that oil will be carried up the riser and back to the compressor. Pitch the suction line(s) in the direction of refrigerant flow and make sure they are adequately supported. Lines should be free draining and fully insulated between the evaporator and the compressor. Install a trap on the vertical riser to the compressor.
3. To determine the minimum tonnage required to carry oil up suction risers of various sizes, check the vertical suction risers using [Table 5](#). Insulate suction lines inside the unit cabinet to prevent condensation.
4. Size the liquid line for a pressure drop not to exceed the pressure equivalent of 2°F (1°C), 6 psi (41.4 kPa) saturated temperature.

Table 5: Minimum Tonnage (R-410A) to Carry Oil up Suction Riser at 40°F Saturated Suction

Line size O.D.	Minimum tonnage
1-1/8"	1.5
1-3/8"	2.5
1-5/8"	3.8
2-1/8"	7.6
2-5/8"	13.10
3-1/8"	20.4
3-5/8"	29.7
4-1/8"	41.3

Leak Testing

WARNING

Do not use oxygen or air to build up pressure. Explosion hazard can cause severe personal injury or death.

In the case of loss of the nitrogen holding charge, the unit should be checked for leaks prior to charging the complete system. If the full charge was lost, leak testing can be done by charging the refrigerant into the unit to build the pressure to approximately 10 psig and adding sufficient dry nitrogen to bring the pressure to a maximum of 125 psig (R-407C) and 238 psig (R-410A). The unit should then be leak tested with halide or electronic leak detector. After making any necessary repair, the system should be evacuated as described in the following paragraphs.

Experience in the field has shown that R-407C systems can be “topped off” after a leak has been repaired and operate normally. There is no need, except in the case of a critically charged systems, to replace the entire charge after a leak has been repaired.

For R-407C and R-410A

Evacuation

CAUTION

Before replacing refrigerant sensors or protective devices, see [Refrigerant Charge on page 24](#) for an important warning to prevent an abrupt loss of the entire charge.

After determining the unit is tight and there are no refrigerant leaks, evacuate the system. Use a vacuum pump with a pumping capacity of approximately 3 cu.ft./min. and the ability to reduce the vacuum in the unit to at least 1 mm (1000 microns).

1. Connect a mercury manometer or an electronic or other type of micron gauge to the unit at a point remote from the vacuum pump. For readings below 1 millimeter, use an electronic or other micron gauge.
2. Use the triple evacuation method, which is particularly helpful if the vacuum pump is unable to obtain the desired 1 mm of vacuum. The system is first evacuated to approximately 29" (740 mm) of mercury. Then add enough refrigerant vapor to the system to bring the pressure up to 0 pounds (0 microns).
3. Evacuate the system again to 29" (740 mm) of vacuum. Repeat his procedure three times. This method is most effective by holding system pressure at 0 pounds (0 microns) for a minimum of 1 hour between evacuations. The first pulldown removes about 90% of the noncondensables; the second removes about 90% of that remaining from the first pulldown. After the third pulldown, only 1/10 of 1% of noncondensables remains.

Table 6 shows the relationship between pressure, microns, atmospheres, and the boiling point of water.

The quality of vacuum is measured using a suitable micron gauge that has been calibrated. The vacuum level reading should be taken directly from the sealed system, not at the vacuum pump. The minimum vacuum level is 300 microns Hg. The vacuum pump should be isolated from the system and the observed. Decay should not be greater than 500 microns after 15 minutes.

The crankcase heaters should be on during the evacuation procedure. This will help boil any dissolved refrigerant in the oil.

R410A is a zeotropic refrigerant that is made up of more than one compound. It must be charged as a liquid from the canister.

Table 6: Pressure-Vacuum Equivalents

Absolute pressure above zero		Vacuum below 1 atmosphere	Approximate fraction of 1 atmosphere	H ₂ O boiling point at each pressure (°F)
Microns	PSIA	Mercury – Inches (mm)		
0	0	29.921 (760.00)	—	—
50	0.001	29,920 (759.95)	1/15,200	-50
100	0.002	29.920 (759.90)	1/7,600	-40
150	0.003	29.920 (759.85)	1/5,100	-33
200	0.004	29.910 (759.80)	1/3,800	-28
300	0.006	29.910 (759.70)	1/2,500	-21
500	0.009	29.900 (759.50)	1/1,520	-12
1,000	0.019	29.880 (759.00)	1/760	1
2000	0.039	29.840 (758.00)	1/380	15
4,000	0.078	29.760 (756.00)	1/189	29
6000	0.117	29.690 (754.00)	1/127	39
8,000	0.156	29.600 (752.00)	1/95	46
10,000	0.193	29.530 (750.00)	1/76	52
15,000	0.290	29.330 (745.00)	1/50	63
20,000	0.387	29.130 (740.00)	1/38	72
30,000	0.580	28.740 (730.00)	1/25	84
50,000	0.967	27.950 (710.00)	1/15	101
100,000	1.930	25.980 (660.00)	2/15	125
200,000	3.870	22.050 (560.00)	1/4	152
500,000	9.670	10.240 (260.00)	2/3	192
760,000	14.697	0	1 atmosphere	212

Charging the System

CAUTION

Adding refrigerant to the suction always risks liquid-related damage to the compressor.

Units are leak tested at the factory and shipped with a nitrogen holding charge. If the holding charge has been lost due to shipping damage, charge the system with enough refrigerant to raise the unit pressure to 30 psig after first repairing the leaks and evacuating the system.

Take special care to add refrigerant slowly enough to the suction to prevent damage. Adjust the charging tank hand valve so liquid leaves the tank but vapor enters the compressor.

1. After all refrigerant piping is complete and the system is evacuated, it can be charged as described in the paragraphs following. Connect the refrigerant drum to the gauge port on the liquid shutoff valve and purge the charging line between the refrigerant cylinder and the valve. Then open the valve to the mid position.
2. If the system is under a vacuum, stand the refrigerant drum with the connection up, open the drum, and break the vacuum with refrigerant gas.
3. With a system gas pressure higher than the equivalent of a freezing temperature, invert the charging cylinder and elevate the drum above the condenser. With the drum in this position and the valves open, liquid refrigerant flows into the condenser. Approximately 75% of the total requirement estimated for the unit can be charged in this manner.
4. After 75% of the required charge enters the condenser, reconnect the refrigerant drum and charging line to the suction side of the system. Again, purge the connecting line, stand the drum with the connection side up, and place the service valve in the open position.

Important: At this point, interrupt the charging procedure and do prestart checks before attempting to complete the refrigerant charge.

NOTE: Stamp the total operating charge per circuit on the unit nameplate for future reference.

Refrigerant Charge

Factory-installed DX coils are designed to use R-407C and R-410A. The total charge per circuit is the sum of the following three values:

- Condenser section charge. Refer to manufacturer's data
- Evaporator coil charge
- Charge for length of interconnecting piping installed by field

NOTE: Factory-installed DX coils are intended for one refrigerant circuit on unit size 800C and two refrigerant circuits containing identical weights of refrigerant on all other sizes. The values shown in [Table 7](#) and [Table 8](#) are for each circuit.

The total operating charge per circuit should not exceed the pumpdown capacity per circuit.

Table 7: Approximate DX Coil Refrigerant Charge per Circuit

Unit size	DX Coil R-410A charge (lbs./circuit)	
	Flat coil	Staggered coil
047C	3 × No. of DX rows	3.5 × No. of DX rows
077C	5 × No. of DX rows	6.5 × No. of DX rows

Table 8: Approximate Refrigerant Charge Per Circuit

Unit size	Evaporator coil (lbs/ckt/coil row)
802	3.30
802C*	2.45

* The RDS 802C unit has two refrigerant circuits.


Unit Piping

Condensate Drain Connection

WARNING
 Drain pans must be cleaned periodically. Material in uncleaned drain pans can cause disease. Cleaning should be performed by qualified personnel.

- The unit is provided with a 1.5" male NPT condensate drain connection. Refer to certified drawings for the exact location. For proper drainage, level the unit and drain pan side to side and install a P-trap
- Units may have positive or negative pressure sections. Use traps in both cases with extra care given to negative pressure sections. In Figure 57, dimension "A" should be a minimum of 8" (203 mm). As a conservative measure to prevent the cabinet static pressure from blowing or drawing the water out of the trap and causing air leakage, dimension A should be two times the maximum static pressure encountered in the coil section in inches wc
- Draining condensate directly onto the roof may be acceptable; refer to local codes. Provide a small drip pad of stone, mortar, wood, or metal to protect the roof against possible damage
- If condensate is piped into the building drainage system, pitch the drain line away from the unit a minimum of 1/8" per foot. The drain line must penetrate the roof external to the unit. Refer to local codes for additional requirements. Sealed drain lines require venting to provide proper condensate flow
- Where the cooling coils have intermediate condensate pans on the face of the evaporator coil, copper tubes near both ends of the coil provide drainage to the main drain pan. Check that the copper tubes are in place and open before the unit is put into operation
- On units with staggered cooling coils, the upper drain pan drains into the lower coil drain pan through a copper tube near the center of the drain pan. Check that this tube is open before putting the unit into operation and as a part of routine maintenance
- Because drain pans in any air conditioning unit have some moisture in them, algae, etc. will grow. Periodically clean to prevent this buildup from plugging the drain and causing the drain pan to overflow. Clean drain pans to prevent the spread of disease. Cleaning should be performed by qualified personnel

Figure 33: Condensate Drain Connection



Gas Piping

See the "Installation" section of the gas-fired furnace installation manual, [IM 684](#) or [IM 685](#).

Piping for Steam, Hot Water/Chilled Water Coils

CAUTION

Seal all holes in the unit floor to prevent water leakage into the building.


Factory-installed chilled water coils are installed in a coil section that can be designed to accept a factory-installed heating coil immediately upstream. The coil section can be ordered in either the draw-through or blow-through position. All chilled water piping can be done internal to the unit without requiring a piping vestibule (except on sizes 800–802 when heating coils are included in the cooling coil section).

Steam and hot water coils can be factory installed in either a heat section, or in the combination coil section. These sections can be located either in the draw-through or blow-through position. When a steam or hot water coil is installed in the heat section, all piping can be done internal to the unit without requiring a piping vestibule. Refer to [Figure 35](#) and [Figure 37](#) on page 27.

When a steam or hot water coil is installed in the combination coil section, the coil connections project to the inside surface of the door panel. Holes can be cut in the door panels to connect the piping to the coils, or an accessory piping vestibule can be added to the unit to provide piping space. Refer to the section on vestibule assembly instructions. The piping can then be routed back within the unit as shown in [Figure 35](#).

To avoid piping penetrations through the roof external to the curb, holes can be cut through the floor of the unit at the locations specified on the certified drawings.

Figure 34: Hot Water Heat Section (Shown with Factory Valve and Piping)



Hot Water Piping

CAUTION

Coil freeze possible. Can damage equipment. Follow instructions for mixing antifreeze solution used. Some products have higher freezing points in their natural state than when mixed with water. The freezing of coils is not the responsibility of Daikin Applied International. Refer to [Winterizing Water Coils on page 107](#).

Hot water coils are provided without valves for field piping or piped with three-way valves and actuator motors. With the factory piping and valve package, the two coils are piped in parallel and controlled through a single three-way valve. Field piping connections are of the same NPT size as the valve-male threads at the supply connection, female threads at the return connection.

Hot water coils are not normally recommended for use with entering air temperatures below 40°F (4°C). No control system can guarantee a 100% safeguard against coil freeze-up. Glycol solutions or brines are the only freeze-safe media for operation of water coils at low entering air temperature conditions. Refer to the [Maintenance](#) section of this manual for more on winterizing coils. The hot water section consists of two stacked coils, as shown in [Figure 34](#).

When no factory piping or valve is included, the coil connections are 1.625" ODM copper on 800 and 802C, and 2.125" ODM copper on 047 and 077C.

With the factory piping and valve package, the two coils are piped in parallel and controlled through a single three-way valve. Field piping connections are of the same NPT size as the valve-male threads at the supply connection, female threads at the return connection.

The valve actuator spring returns to a stem up position upon power failure. This allows full flow through the coil. Refer to the certified drawings for the recommended piping entrance locations. Seal all piping penetrations to prevent air and water leakage.

NOTE: Factory-installed water valves and piping are bronze, brass, and copper. Dissimilar metals within the plumbing system can cause galvanic corrosion. To avoid corrosion, provide proper di-electric fittings as well as appropriate water treatment.

Steam Coil Piping (All Units)

The steam heat section consists of two stacked coils pitched at 1/8" (3 mm) per foot (305 mm) as shown in Figure 35 to provide positive condensate removal. When no factory piping or valve is included, the coil connections are 2.5" male NPT iron pipe.

With the factory piping and valve package, the two coil supplies are piped in parallel and controlled through a single two-way valve. The field supply connection is of the same female NPT size as the valve. Field return connections are made at the 2.5" male NPT fittings on each of the two stacked coils.

NOTE: The valve actuator spring returns to a stem up position upon power failure. This allows full flow through the coil.

Refer to the sections on steam coil piping and trap recommendations for additional information. The valve actuator spring returns to a stem up position upon power failure. This allows full flow through the coil.

Figure 35: Steam Heat Section (Shown with Factory Valve and Piping)





Figure 36: Two-Way Valve Package




Steam Piping Recommendations

1. Be certain that adequate piping flexibility is provided. Stresses resulting from expansion of closely coupled piping and coil arrangement can cause serious damage.
2. Do not reduce pipe size at the coil return connection. Carry return connection size through the dirt pocket, making the reduction at the branch leading to the trap.
3. Install vacuum breakers on all applications to prevent retaining condensate in the coil. Generally, the vacuum breaker is to be connected between the coil inlet and the return main. However, if the system has a flooded return main, the vacuum breaker to the atmosphere; the trap design should allow venting of the large quantities of air.
4. Do not drain steam mains or takeoffs through coils. Drain mains ahead of coils through a steam trap to the return line.
5. Do not attempt to lift condensate when using modulating or ON-OFF control.
6. Pitch all supply and return steam piping down a minimum of 1" (25 mm) per 10 feet (3 m) of direction of flow.

Steam Trap Recommendations

1. Size traps in accordance with manufacturers' recommendations. Be certain that the required pressure differential will always be available. Do not undersize.
2. Float and thermostatic or bucket traps are recommended for low pressure steam. Use bucket traps on systems with on-off control only.
3. Locate traps at least 12" (305 mm) below the coil return connection.
4. Always install strainers as close as possible to the inlet side of the trap.
5. A single tap may generally be used for coils piped in parallel, but an individual trap for each coil is preferred.

Figure 37: Heating Coil Piping with Vestibule



Steam Coil Freeze Conditions

If the air entering the steam coil is below 35°F (2°C), note the following recommendations:

1. Supply 5 psi (34.5 kPa) steam to coils at all times.
2. Modulating valves are not recommended. Control should be by means of face and bypass dampers.
3. As additional protection against freeze-up, install the tap sufficiently far below the coil to provide an adequate hydrostatic head to ensure removal of condensate during an interruption on the steam pressure. Estimate 3 ft. (914 mm) for each 1 psi (7 kPa) of trap differential required.
4. If the unit is to be operated in environments with possible freezing temperatures, an optional freeze-stat is recommended. See [Freeze Protection on page 64](#) for additional information.

Figure 38: Valve Assembly





Figure 39: Steam Valve Package



Chilled Water Piping

Chilled water coils are provided without valves for field piping, or piped with three-way valves with motor actuators. [Table 9](#) provides information on units with factory installed piping and valve packages. The table also provides field sweat connection information for units not furnished with factory installed piping and valve packages.

With the factory piping and valve package, the coil assembly is controlled through a single three-way valve. When two coils are included in the assembly, they are piped in parallel. Field connections are male NPT, sized as shown in [Table 9](#). Refer to [Figure 40](#) for a typical cooling coil with factory valve and piping.

Figure 40: Chilled Water Coil (with Factory Valve and Piping)




Table 9: Piping Connection Sizes/Valve Size Options for Chilled Water Piping

Cabinet size	Application code	Coil size H × 83" (2108 mm) long	Face area sq. ft. (sq. m)	Available rows (available with 8, 10, 12 fins/in)	Available circuiting									
					5WH		5WL		5WS		5WM		5WD	
					Columns (see page 46 for explanation)									
					1	2	1	2	1	2	1	2	1	2
047C	Blow-thru or draw-thru small coil section	33 + 33 (2 coils) (838 + 838 mm)	38.0 (3.53 m ²)	3	D	R	D	Q	—	—	A	Q	A	P
				4	D	R	D	Q	B	Q	B	Q	B	P
				5	D	R	D	Q	—	—	B	Q	A	P
				6	D	R	D	Q	B	Q	B	Q	A	P
	Blow-thru or draw-thru large coil section	39 + 39 (2 coils) (991 + 991 mm)	45.0 (4.18 m ²)	3	D	R	C	Q	—	—	A	Q	A	P
				4	D	R	C	Q	C	Q	C	Q	B	P
				5	D	R	C	Q	—	—	C	Q	A	P
				6	D	R	C	Q	C	Q	C	Q	A	P
	Face and bypass section with small coil	48 (1219 mm)	27.7 (2.57 m ²)	3	F	U	E	T	—	—	A	S	A	S
				4	F	U	E	T	C	S	C	S	C	S
				5	F	U	E	T	—	—	C	S	A	S
				6	F	U	E	T	C	S	C	S	A	S
	Face and bypass section with large coil	39 + 39 (2 coils) (991 + 991 mm)	45.0 (4.18 m ²)	3	D	R	C	Q	—	—	A	Q	A	P
				4	D	R	C	Q	C	Q	C	Q	B	P
				5	D	R	C	Q	—	—	C	Q	A	P
				6	D	R	C	Q	C	Q	C	Q	A	P
077C	Blow-thru or draw-thru small coil section	45 + 45 (2 coils) (1143 + 1143 mm)	51.9 (4.82 m ²)	3	C	R	C	Q	—	—	A	P	A	P
				4	C	R	C	Q	C	P	B	P	B	P
				5	C	R	C	Q	—	—	B	P	A	P
				6	C	R	C	Q	C	P	B	P	A	P
	Blow-thru or draw-thru large coil section	63 + 63 (2 coils) (1600 + 1600 mm)	72.6 (6.74 m ²)	3	B	Q	B	P	—	—	A	P	A	P
				4	B	Q	B	P	B	P	B	P	B	P
				5	B	Q	B	P	—	—	B	P	A	P
				6	B	Q	B	P	B	P	B	P	A	P
	Face and bypass section with small coil	63 (1600 mm)	36.3 (3.37 m ²)	3	E	T	C	S	—	—	A	S	A	S
				4	E	T	C	S	C	S	C	S	C	S
				5	E	T	C	S	—	—	C	S	A	S
				6	E	T	C	S	C	S	C	S	A	S
	Face and bypass section with large coil	54 + 54 (2 coils) (1372 + 1372 mm)	62.3 (5.74 m ²)	3	C	R	C	Q	—	—	A	P	A	P
				4	C	R	C	Q	B	P	B	P	B	P
				5	C	R	C	Q	—	—	B	P	A	P
				6	C	R	C	Q	B	P	B	P	A	P
800 or 802	Blow-thru or draw-thru cooling only coil section	48 + 78 (1220 + 1981 mm)	26.0 (2.42 m ²)	3	G	T	G	T	—	—	—	—	—	—
				4	G	T	G	T	G	T	—	—	—	—
				5	G	T	G	T	—	—	—	—	—	—
				6	G	T	G	T	G	T	—	—	—	—
	Blow-thru or draw-thru unit coil section	48 + 78 (1220 + 1981 mm)	26.0 (2.42 m ²)	3	G	T	G	T	—	—	—	—	—	—
				4	G	T	G	T	G	T	—	—	—	—
				5	G	T	G	T	—	—	—	—	—	—
				6	G	T	G	T	G	T	—	—	—	—
	Face and bypass section with small coil	30 + 79 (763 + 2006 mm)	16.5 (2.57 m ²)	3	—	L	—	M	—	—	—	N	—	N
				4	—	L	—	M	—	M	—	N	—	N
				5	—	L	—	M	—	—	—	N	—	N
				6	—	L	—	M	—	M	—	N	—	N
				8	—	L	—	M	—	M	—	N	—	N
				10	—	L	—	M	—	—	—	N	—	N
	Blow-thru or draw-thru contractor coil section	36 + 79 (915 + 2006 mm)	19.8 (4.18 m ²)	3	—	L	—	M	—	K	—	N	—	N
				4	—	L	—	M	—	—	—	N	—	N
5				—	L	—	M	—	K	—	N	—	N	
6				—	L	—	M	—	K	—	N	—	N	
8				—	L	—	M	—	K	—	N	—	N	
10				—	L	—	M	—	K	—	N	—	N	

Table 9 Available Circuiting Legend

Column 1:

These units are available with a factory installed package consisting of a three-way water valve and connecting piping.

- A = This combination is not available with a factory-installed piping and valve package.
- B = 300, 2.50, or 200 inch three-way valves can be specified
- C = 300, 2.50, 2.00, or 150 inch three-way valves can be specified
- D = 250, 200, or 150 inch three-way valves can be specified
- E = 250, 200, 150, or 1.25 inch three-way valves can be specified
- F = 200, 1.50, or 125 inch three-way valves can be specified
- G = 1.25, 1.50, 2.00 or 2.50 inch three-way valves can be specified

Field supply and return female NPT connection sizes are the same as the valve size.

Column 2:

The following letters designate units that are not furnished with the factory installed piping/valve package. Required are field sweat

connections, at one or two coils, to male copper tubing for the supply and return water piping.

- K = A single 2.00 inch NPT supply and return if fin height is 21–30 inches and 2.50 inches of fin height is 30–36 inches
- L = A single 1.50 inch NPT supply and return
- M = A single 2.00 inch NPT supply and return if fin height is 21–30 inches
- N = A single 2.50 inch NPT supply and return
- P = Two 3.12 inch O.D. supply and two 3.12 O.D. return connections
- Q = Two 2.62 inch O.D. supply and two 2.62 O.D. return connections
- R = Two 2.12 inch O.D. supply and two 2.12 O.D. return connections
- S = One 3.12 inch O.D. supply and one 3.12 O.D. return connections
- T = One 2.62 inch O.D. supply and one 2.62 O.D. return connections
- U = One 2.12 inch O.D. supply and one 2.12 O.D. return connections

Vestibule Assembly Instructions


An accessory vestibule is available to provide additional piping space for coils installed in a four-foot section. A vestibule is required to maintain door access on a combination heating and cooling section. Assemble the vestibule to the unit part by part as shown in [Figure 41](#).

NOTE: The door, hinge, and latch assemblies from the unit are used on the vestibule.

Step 1

1. Remove door from section where vestibule is to be located by removing screws holding hinges to upright support (leave hinges on door). Set door aside and save for Step 4.
2. Remove door latch assembly from other side upright support. Use offset Phillips screwdriver or a wrench to remove screws holding latch assembly in place. Save door latch assembly, screws and bushings for Step 4.


Figure 41: Removing the Door from the Section



Step 2

1. Remove gasketing around door flange and save for use on vestibule. See Step 4.
2. Remove door and save for Step 4.


Figure 42: Removing Gasketing



Step 3

1. Assemble side panels A and B to uprights using #10 drill screws supplied. Make certain side panels are flush against uprights before securing into place.
2. Fasten bottom panel D to base channel using #10 drill screws and to side panels A and B using #10 screws supplied.
3. Set top panel C in place and fasten to side panels A and B using #10 screws and to top panel using #10 screws supplied.

Figure 43: Assembling the Vestibule Sides




Step 4

1. Reassemble access door to vestibule by screwing hinges into side panel using screws saved from Step 1. (Access door must be attached to the vestibule in the same opening direction as it was on the unit.)
2. Remove and discard latch handle locking screws and retaining washer. Fasten door latch assembly to side panel using screws and bushings saved from Step 1. (Latch must be fastened on the same side as when located on the unit.)
3. Fasten upright angles to vestibule using #10 screws supplied.
4. Seal between unit and vestibule with silicone sealant along top and sides as shown.

NOTE: Any holes cut in the floor of the unit must be sealed to prevent water leakage.

Figure 44: Final Assembling of Vestibule



Damper Assemblies

The optional damper assemblies described in this section normally are ordered with factory-installed actuators and linkages. The following sections describe operation and linkage adjustment of the factory option.

Economizer Dampers


Outside air intake is provided on both sides of the unit, and the return air path is at the center of the damper set. As the single actuator modulates the outside air dampers open, the return air dampers close. Exhaust air exits the unit through the gravity relief dampers provided at the end of the economizer section.

The outside air return air damper assembly (economizer) comes with manually adjustable linkage. This adjustable linkage also can be used for connecting a damper operator. The damper is set so that the crankarm moves through a 90-degree angle to bring the economizer dampers from full open to full close (Figure 45). Access to the actuator and linkage is from the filler section. Mechanical stops are placed in the crankarm mounting bracket. Do not remove stops. Driving the crankarm past the stops results in damage to the linkage or damper. The unit ships with a shipping bolt securing the linkage crankarm. Remove shipping bolt before use.

NOTE: For good airflow control, adjust linkages so damper blades do not open beyond 70 degrees. Opening a damper blade beyond 70 degrees has little effect on its airflow.

Do not “over close” low leak damper blades. The edge seal should just lightly contact the adjoining blade. The blades will lock up if they are closed so far the seal goes over center.

Figure 45: Economizer Dampers



Intake Hood Damper (0% to 30% outside air)


These dampers are intended to remain at a fixed position during unit operation, providing fresh air quantities from 0 to 30% of the total system airflow, depending on the damper setting. This setting is made at the linkage rod on units with manually adjustable linkages.

On units provided with MicroTech III controls, the damper position may be set at the controller keypad. During unit operation, the two-position actuator drives the damper to the position set on the keypad. During the OFF cycle, the damper is automatically closed.

No unit-mounted exhaust dampers are provided with this option.

NOTE: Figure 46 shows the RAH 47–77 (The linkage is on the RH side). The RDS 800–802 are the same except the linkage is on the LH side.


Figure 46: Intake Hood Damper, 0% To 30% Outside Air



Intake Hood Damper (0% to 100% outside air, RAH 047C–077C only)

Units requiring 100% outside air are provided with a rain hood and dampers that can be controlled by a single actuator. The actuator provides two-position control for opening the dampers fully during unit operation and closing the dampers during the off cycle. No unit mounted exhaust dampers are provided.

Figure 47: Intake Hood Damper Adjustments, 0% to 100% Outside




Mixing Box (RAH 047C–077C only)

This section uses an outside air damper and a return air damper. Using these dampers allows outside air to blend with return air. Synchronized operation of the dampers is accomplished by interconnecting rods. As one damper section opens, the other section is closed. A total of 100% cfm is always drawn from this section. Damper positioning can be manually or automatically adjusted. With a field-installed controller, automatic operation can be obtained.

These dampers provide a similar function to economizer dampers. This option differs from an economizer in that no unit mounted exhaust dampers are provided.

NOTE: For good airflow control, adjust linkages so damper blades do not open beyond 70 degrees. Opening a damper blade beyond 70 degrees has little effect on its airflow. Do not “over close” low leak damper blades. The edge seal should just lightly contact the adjoining blade. The blades lock up if they are closed so far that the seal goes over center.

Figure 48: Mixing Box Adjustments



Face and Bypass Dampers

Face and bypass dampers are available in a flat arrangement for use with heating coils and standard face area cooling coils, as well as a staggered arrangement for large face area cooling coils. The damper sets are linked through a jack shaft for connection to a single actuator (factory or field installed).

Figure 49: Face and Bypass Dampers, RDS 800C–802C Only




Figure 50: Face and Bypass Dampers, Staggered Arrangement—RAH 047C–077C Only





Figure 51: Face and Bypass Dampers, Flat Arrangement—RAH 047C–077C Only



Cabinet Weather Protection

⚠ CAUTION

Transportation, rigging, or maintenance can damage the unit's weather seal. Periodically inspect the unit for leakage. Standing moisture can promote microbial growth, disease, or damage to the equipment and building.

This unit ships from the factory with fully gasketed access doors and cabinet caulking to provide weather resistant operation. After the unit is set in place, inspect all door gaskets for shipping damage and replace if necessary.

Protect the unit from overhead runoff from overhangs or other such structures.

Recaulk field-assembled options such as external piping or vestibules per the installation instructions provided with the option.

Installing Ductwork

⚠ WARNING

Mold can cause personal injury. Materials such as gypsum wall board can promote mold growth when damp. Such materials must be protected from moisture that can enter units during maintenance or normal operation.

ⓘ NOTICE

Installer must provide access in the ductwork for plenum-mounted controls. Once duct work is installed in units with side discharge, access to plenum-mounted components is difficult.

On bottom-supply/bottom-return units, if a Daikin Applied roof curb is not used, the installing contractor should make an airtight connection by attaching field-fabricated duct collars to the bottom surface of either the roof curb's duct flange or the unit's duct opening. Do not support the total weight of the duct work from the unit or these duct flanges (Figure 52).

Units with optional back return, side discharge, or end discharge all have duct collars provided. To expose the discharge duct collars on a side discharge unit, remove the plenum section access door and the door gasketing.


Use flexible connections between the unit and ductwork to avoid transmission of vibration from the unit to the structure.

To minimize losses and sound transmission, design duct work per ASHRAE and SMACNA recommendations.

Where return air ducts are not required, connect a sound-absorbing T or L section to the unit return to reduce noise transmission to the occupied space.

Ductwork exposed to outdoor conditions must be built in accordance with ASHRAE and SMACNA recommendations and local building codes.

Figure 52: Installing Duct Work



Installing Duct Static Pressure Sensor Taps

For all VAV units, field install and connect duct static pressure taps to the pressure sensors in the unit. Sensor SPS1 is standard; additional sensor SPS2 is optional. These sensors are located in the main control panel (see "Control Panel", page 5).

Carefully locate and install the duct static pressure sensing tap. Improperly locating or installing the sensing tap causes unsatisfactory operation of the entire variable air volume system. Below are pressure tap location and installation recommendations. The installation must comply with local code requirements

1. Install a tee fitting with a leak-tight removable cap in each tube near the sensor fitting. This facilitates connecting a manometer or pressure gauge if testing is required.
2. Use different colored tubing for the duct pressure (HI) and reference pressure (LO) taps, or tag the tubes. Daikin Applied recommends 1/4" plastic tubing.
3. Locate the duct pressure (HI) tap near the end of a long duct to ensure that all terminal box take-offs along the run have adequate static pressure.
4. Locate the duct tap in a nonturbulent flow area of the duct. Keep it several duct diameters away from take-off points, bends, neckdowns, attenuators, vanes, or other irregularities.
5. Use a static pressure tip (Dwyer A302 or equivalent) or the bare end of the plastic tubing for the duct tap. (If the duct is lined inside, use a static pressure tip device.)
6. Install the duct tap so that it senses only static pressure (not velocity pressure). If a bare tube end is used, it must be smooth, square (not cut at an angle) and perpendicular to the airstream (Figure 54).
7. Locate the reference pressure (LO) tap somewhere near the duct pressure tap within the building (Figure 53). If the reference tap is not connected to the sensor, unsatisfactory operation will result.
8. Route the tubes between the curb and the supply duct, and feed them into the unit through the knockout in the bottom of the control panel (Figure 53). Connect the tubes to appropriate barbed fittings in the control panel. (Fittings are sized to accept 1/4" plastic tubing.)

Figure 53: Static Pressure Tubing Entrance Location






Figure 54: Pressure Sensing Tubing Installation



Installing Building Static Pressure Sensor Taps

CAUTION

Fragile sensor fittings.

If you must remove tubing from a pressure sensor fitting, use care. Do not use excessive force or wrench the tubing back and forth to remove; the fitting can break off and damage sensor.

If a unit has direct building static pressure control capability, you must field install and connect static pressure taps to pressure sensor SPS2 in the unit. This sensor is located at the bottom of the main control panel next to terminal block TB2.

Carefully locate and install the two static pressure sensing taps. Improper location or installation of the sensor taps causes unsatisfactory operation. Below are pressure tap location and installation recommendations for both building envelope and lab, or "space within a space" pressure control applications. The installation must comply with local code requirements.

Building Pressurization Applications

1. Install a tee fitting with a leak-tight removable cap in each tube near the sensor fitting. This facilitates connecting a manometer or pressure gauge if testing is required.
2. Locate the building pressure (HI) tap in the area that requires the closest control. Typically, this is a ground level floor that has doors to the outside.
3. Locate the building tap so it is not influenced by any source of moving air (velocity pressure). These sources may include air diffusers or outside doors.
4. Route the building tap tube between the curb and the supply duct and feed it into the unit through the knockout in the bottom of the control panel ([Figure 53 on page 38](#)). Connect the tube to the 1/4-inch HI fitting for sensor SPS2.
5. Locate the reference pressure (LO) tap on the roof. Keep it away from the condenser fans, walls, or anything else that may cause air turbulence. Mount it high enough above the roof so it is not affected by snow. Not connecting the reference tap to the sensor results in unsatisfactory operation.
6. Use an outdoor static pressure tip (Dwyer A306 or equivalent) to minimize the adverse effects of wind. Place some type of screen over the sensor to keep out insects. Loosely packed cotton works well.
7. Route the outdoor tap tube out of the main control panel through a small field-cut opening in the edge of the control wiring raceway cover ([Figure 53](#)). Cut this "mouse hole" in the vertical portion of the edge. Seal the penetration to prevent water from entering. Connect tube to the 1/4-inch LO fitting for sensor SPS2.

Lab Pressurization Applications

1. Install a "T" fitting with a leak-tight removable cap in each tube near the sensor fitting. This facilitates connecting a manometer or pressure gauge if testing is required.
2. Use different colored tubing for the controlled space pressure (HI) and reference pressure (LO) taps, or tag the tubes.
3. Regardless whether the controlled space is positive or negative with respect to its reference, locate the HI pressure tap in the controlled space (the setpoint can be set between -0.2 and 0.2" wc).
4. Locate the reference pressure (LO) tap in the area surrounding the controlled space. Not locating the reference tap to the sensor results in unsatisfactory operation.
5. Locate both taps so they are not influenced by any source of moving air (velocity pressure). These sources may include air diffusers or doors between the high and low pressure areas.
6. Route the building tap tube between the curb and the supply duct and feed it into the unit through the knockout in the bottom of the control panel ([Figure 53](#)).
7. Connect the tube to the 1/4-inch HI fitting for sensor SPS2.

Preparing Unit for Operation

WARNING

Warnings indicate potentially hazardous situations, which can result in property damage, severe personal injury, or death if not avoided.

Spring Isolated Fans

Releasing Spring Mounts

The optional spring-mounted supply and return fans are locked down for shipment. Hold-down fasteners are located at each spring mount. Remove these fasteners before operating the fans. Figure 58 shows a typical spring mount. Note that the 3/8" hold-down bolt securing the fan base to the unit cross channel must be removed.

After removing the hold-down fasteners, rock the fan assembly by hand to check for freedom of movement.

Figure 55: RAH Spring Mount Hold Down Fasteners






Figure 56: Spring Mounted Hold-down Fasteners, All Units

This bracket is added, and these 3/8" tie downs are used for RDS 800C.



This bracket is added, and these 3/8" tie downs are used for RDS 800C.

Figure 57: Fan Spring Mount Adjustment*



* Grossly out-of-adjustment thrust restraints can affect this dimension. Recheck after thrust restraints are adjusted.

Adjusting Spring Mounts

To change spring compression:

1. Loosen the 5/8-18 UNF hex nut.
2. Place some additional weight on the fan sled frame (use a lever to slightly compress the spring/or raise the sled) to allow the bolt to turn freely.
3. Place one or two drops of oil on the threads if needed. Use a wide, flat-blade, socket drive bit with a recommended 1/2" drive handle. Ensure that as the slotted bolt is turned, the upper-rebound plate also turns. This action allows the bolt to compress/decompress the compression plate, while having the same affect on the spring. If the spring is compressed too much, lift the sled before turning. If the spring is not compressed enough, place weight on the sled corner to force it down before turning.
4. Re-adjust the position of the lower-rebound plate so that the sled has at least 3/4" travel and no more than 1-1/4" travel.

Figure 58: Spring Mount



WARNING

Moving machinery hazard. Can cause severe injury or death. Start the fans for the first time according to the [Check, Test, and Start Procedures on page 76](#). If this is not done, equipment damage, severe personal injury, or death can occur.


Relief Damper Tie-Down

Economizer sections with a 30" or 40" return fan have a relief damper that is tied down for shipping. Remove the two brackets and two screws before operation to allow free movement of dampers. Access is from inside the economizer section.

Adjusting Scroll Dampers

Two sets of scroll dampers are provided in the housing of the twin 15" x 6" supply fan to allow control of air volume to each fan wheel. At the factory, these dampers are fully closed, unrestricting airflow. If fan paralleling occurs, correct it by loosening the adjustment screw on top of the fan housing ([Figure 59](#)) and slightly lowering the rod until air distribution between the fans is even.



Figure 59: Scroll Damper Adjustment



Adjusting Supply Fan Thrust Restraints

Thrust restraints are provided when housed double-width fans are mounted on springs. After the spring mounts are adjusted for level operation when the fan is running, check the thrust restraints. With the fan off, set the adjustment nuts so the spring is slightly compressed against the angle bolted to the fan housing frame. Refer to [Figure 60](#). When the fan is turned on, the fan moves back to a level position and the thrust restraint spring compresses.

Figure 60: Thrust Restraint Adjustment



Thrust Restraint Adjustment (with Fan OFF)

1. Loosen jam nuts A.
2. Turn nut C until spring cup and washer contact thrust restraint angle.
3. Turn nut B until spring is compressed by two turns of nut B.
4. Tighten jam nuts A.

Adjusting Seismic Restraints

Spring-mounted supply air and return air fans can be ordered with factory-installed seismic restraints. The system consists of four snubbers, one located next to each spring isolator. These snubbers allow free movement of the fan assemblies during normal operation because normal operation does not cause fan movements that exceed 0.25" (6 mm). However, if an abnormal condition occurs, they restrain the fan assembly and limit movement to 0.25" (6 mm) in any direction.


The position the fan assumes during normal operation is determined by actual job site airflow and static pressure. Therefore, for proper operation, field adjust the seismic restraints as part of the normal "Check, Test and Start" procedure. When the fan is operating in a normal manner, there should be no contact between the snubber restrainer angle and the snubber neoprene bumper. However, in a "seismic event," the snubber limits movement of the spring mounted fan assembly to 0.25" (6 mm) in any direction, thereby helping to prevent the fan from being tossed about and damaged, or causing damage.

When a seismic restraint is properly adjusted and the fan is operating normally, the neoprene center bumper is centered within the 2" (51 mm) diameter hole in the restrainer angle, and the restrainer angle is centered vertically between the flanges of the neoprene center bumper. This results in 0.25" (6 mm) clearance in all directions. When the fan is turned OFF, the restrainer angle may come to rest on the neoprene center bumper.

The seismic restraint is adjustable in all directions. Vertical slots in the restrainer angle and horizontal slots in the blower base allow the restrainer angle to be adjusted up and down and back and forth. The neoprene center bumper is mounted on a slotted hole allowing in and out adjustment.

Removing the neoprene center bumper bolt allows removal, disassembly, and replacement of the neoprene components.

Figure 61: Cross Section of Seismic Restraint



Field Power Wiring

WARNING

Hazardous voltage. Can cause severe injury or death. Disconnect electric power before servicing equipment. More than one disconnect may be required to de-energize the unit.

CAUTION

Wires are located in base rail. Move wires before drilling hole through base rail.

CAUTION

Provide proper line voltage and phase balance. Improper line voltage or excessive phase imbalance constitutes product abuse. It can cause severe damage to the unit's electrical components.

All of the unit side panels are hinged. Do not mount disconnect switches and/or motor starters on panels that provide access to internal components. Wiring conduits can penetrate the cabinet bottom, base frame, or through the hinge and latch cap without interfering with the access panels.


NOTE: Seal all holes cut into the unit to prevent water leakage.

Seal conduits connecting the unit to external panels, which will be exposed to relative humidity and air pressure differentials. Ground the motor using copper or other corrosion resistant conductor.

Wiring must comply with all applicable codes and ordinances. The warranty is voided if wiring is not in accordance with these specifications. An open fuse, tripped circuit breaker, or Manual Motor Protector (MMP) indicates a short, ground, or overload. Before replacing a fuse, circuit breaker, MMP, or restarting a fan motor, identify the trouble and correct.

According to the [National Electrical Code](#), a disconnecting means shall be located within sight of and readily accessible from the air conditioning equipment. The unit can be ordered with an optional factory mounted disconnect switch. This switch is not fused. Power leads must be over-current protected at the point of distribution. The maximum rated overcurrent protection device (MROPD) appears on the unit nameplate.

Figure 62: Field Power Wiring



All RDS and RAH Units

All units are provided with internal power wiring for single or dual point power connection. The power block or an optional disconnect switch is located within the main control panel. Field power leads are brought into the unit through 3" knockouts in the bottom of the main control panel. Refer to the unit nameplate to determine the number of power connections. See [Figure 63](#) and [Table 11](#) on [page 46](#).

If the unit has a factory mounted disconnect switch, generally the switch must be turned off to open the main control panel door. However, the door can be opened without disconnecting power by following the procedure covered on [page 111](#). If this is done, use caution since power is not removed from the unit or the controller.

The preferred entrance for power cables is through the bottom knockouts provided on the unit. If side entrance is the only option, a drilling location is provided.

Follow the drilling dimensions exactly to prevent damage to the control panel. The dimensions provided are the only possible point of side entrance for the power cables.

NOTE: To wire entry points, refer to certified drawings for dimensions.

Figure 64: Optional Side Power Wiring Entrance




Figure 63: RDS and RAH Power Wiring Connections






Figure 65: Typical Power Wire Entrance, Unit View—RDS 800C Shown (Actual Opening Shown on Submittal Documents)



Detail B



All Units

⚠ CAUTION

Provide proper line voltage and phase balance. Improper line voltage or excessive phase imbalance constitutes product abuse. It can cause severe damage to the unit's electrical components.

The minimum circuit ampacity (wire sizing amps) is shown on the unit nameplate. Refer to [Table 22 on page 106](#) for the recommended number of power wires.

Copper wire is required for all conductors. Size wires in accordance with the ampacity tables in Article 310 of the [National Electrical Code](#). If long wires are required, it may be necessary to increase the wire size to prevent excessive voltage drop. Size wires for a maximum of 3% voltage drop. Supply voltage must not vary by more than 10% of nameplate. Phase voltage imbalance must not exceed 2%. (Calculate the average voltage of the three legs. The leg with voltage deviating the farthest from the average value must not be more than 2% away.) Contact the local power company for correction of improper voltage or phase imbalance.

A ground lug is provided in the control panel for each disconnect or power block. Size grounding conductor in accordance with Table 250-122 of the National Electrical Code.

In compliance with the National Electrical Code, an electrically isolated 115V circuit is provided in the unit to supply the factory mounted service receptacle outlet and optional unit lights. This circuit is powered by a field connected 15A, 115V power supply. Leads are brought in through a 7/8" knockout in the bottom of the main control panel, near the power wire entry point.

NOTE: All wire sizes assume separate conduit for each set of parallel conductors.

All wire sizes based on NEC Table 310-16 for 75°C THW wire (copper). Canadian electrical code wire ampacities may vary.

All wire sizes assume no voltage drop for short power leads.

Table 10: Multiple Point Power Connection Options

Number of Electrical Circuits	Disconnect Designation	Load	Location (see Figure 2, page 4)
2	DS2	Supply and return fan motors plus controls	Main control panel
	DS1	Balance of unit	Main control panel
2	DS3	Electric heat	Electric heat control panel
	DS1	Balance of unit	Main control panel

Table 11: Recommended 3-phase Power Wiring To Ensure Disconnects and Power Blocks Mate with Power Wiring

Wire Gauge	Qty./Pole	Insulation Rating (°C)	No. of Conduits	Conduit (trade size, inches)	For MCA up to (amps)
10	1	75	1	1/2	35
8	1	75	1	3/4	50
6	1	75	1	1	65
4	1	75	1	1-1/4	85
3	1	75	1	1-1/4	100
2	1	75	1	1-1/4	115
1	1	75	1	1-1/4	130
1/0	1	75	1	1-1/2	150
2/0	1	75	1	2	175
3/0	1	75	1	2	200
4/0	1	75	1	2	230
250	1	75	1	2-1/2	255
300	1	75	1	2-1/2	285
350	1	75	1	3	310
400	1	75	1	3	335
500	1	75	1	3	380
3/0	2	75	2	2	400
4/0	2	75	2	2	460
250	2	75	2	2-1/2	510
300	2	75	2	2-1/2	570
350	2	75	2	3	620
400	2	75	2	3	670
500	2	75	2	3	760
250	3	75	3	2-1/2	765
300	3	75	3	2-1/2	855
350	3	75	3	3	930

Field Control Wiring

WARNING

Electrical shock hazard. Can cause severe injury or death. Connect only low voltage NEC Class II circuits to terminal block TB2.

Reinstall and secure all protective deadfront panels when the wiring installation is complete.

Units are available with several control arrangements which may require low voltage field wiring. Detailed descriptions of various field control wiring options and requirements are included in the “Field Wiring” section of [IM 919](#), “MicroTech® III Unit Controller for Applied Rooftop and Self-Contained Systems.” Refer to the unit wiring diagrams for additional installation information.

Wiring must comply with applicable codes and ordinances. The warranty is voided if wiring is not in accordance with these specifications.

All field control wiring connections are made at the class II terminal block TB2, which is located in the main control panel. Field wiring connections to the 115-volt receptacle and lights are made at terminal block TB7, which is also located in the main control panel. Refer to [Figure 66 on page 47](#) and [Control Panel on page 4](#). Two 7/8" knockouts are provided for wire entry.

Interconnecting wiring enters the air handler unit through 7/8" knockouts in the bottom of the main control panel. The interconnecting wiring is connected to TB4 in the air handler unit. Refer to [Figure 67](#). A 7/8" knockout is also available in the end of the unit base as shown in [Figure 66](#).

NOTE: If a single conduit containing 24V and 115V wiring is run above the roof line between the air handler and condensing units, install the 24V wiring as a NEC Class I wiring system.

Figure 66: Field Control Wiring Connections





Figure 67: Interconnecting Control Wiring



Sequences of Operation The following sequences of operation are for a typical "C" vintage applied rooftop unit equipped with MicroTech III, an economizer, 3 to 1 turn down burner, variable frequency drives (VFD), a return air fan and an external time clock. These sequences describe the ladder wiring diagram logic in detail; refer to [Wiring Diagrams on page 51](#) as you read them. Note that your unit's sequences of operation may vary from those described here. Refer to the wiring diagrams supplied with the unit for exact information.

For detailed description of operation information relating to the MicroTech III controller's software, refer to the appropriate operation manual ([Table 1 on page 3](#)). These manuals describe the various setpoints, parameters, operating states, and control algorithms that affect rooftop unit operation.

Power-up

When primary power is connected to the unit, 115 V (ac) power is fed through control circuit transformer T1 and control circuit fuse F1C (line 166) to compressor crankcase heaters HTR-1, HTR-2, HTR-3 and HTR-4 (lines 836 - 848).

When system switch S1 (line 203) is closed, low voltage transformers T2 (line 203), T3 (line 251) and T9 (line 802, not shown) energize, and 115 V (ac) power is supplied to the following:

- The supply fan VFD (line 135-137)
- M40A to energize the return fan VFD (line 147-149)
- Heating control panel (line 603)
- Economizer actuator (lines 256-257)

Transformer T2 supplies 24 V (ac) power to terminals 24V and COM on the main control board MCB (lines 207 and 208). Transformer T2 supplies 24 V (ac) power to the following:

- Switch S7 On-Auto-Off (line 217)
- Enthalpy sensor OAE (line 247)
- External time clock contacts (line 215)
- Airflow interlock switch PC7 (line 228)
- Dirty filter switches PC5 and PC6 (lines 242 and 247, not shown)
- Gas furnace alarm relay R24 (line 225, not shown)
- Freezestat switch FS1 (line 244, hot water or steam heat only, not shown)
- Smoke detectors SD1 and SD2 (line 237)
- The time clock, S7 switch, and emergency shutdown terminals (lines 217-222) control fan operation

When the field supplied Cool Enable switch is in the "OFF" position, field wiring terminal 105 is de-energized (line 220). Binary input MCB-BI3 will be de-energized and the cooling will be disabled. When the field supplied Heat Enable switch is in the "OFF" position, field wiring terminal 106 is deenergized (line 223). Binary input MCB-BI4 will be deenergized and the heating will be disabled.

NOTE: Unit ships with factory installed jumpers between TB2 101 and 105 and between 101 and 106.

Fan Operation

A supply fan is provided on every unit. That may be the only fan, but either a return fan or an exhaust fan, or fans, can be provided also. The start/stop signal and the speed signal for fans that are controlled by variable frequency drives are provided via an internal ModBus network. Constant volume supply and return fans are started and stopped through digital outputs.

Supply Fan

The supply fan is turned ON when the unit enters the Recirculation state. The supply fan is turned OFF when the unit transitions to the OFF state, but it stays on for a OffHtCIDelayTime (Default- 120 seconds) if the unit is turned OFF while DX cooling or staged heating is active. The OffHtCIDelayTime function is overridden when and Emergency OFF or Duct High Limit fault is active.

Return Fan

A return fan driven by a variable frequency drive is started four seconds after the supply fan is started to reduce the amp draw peak on startup. A constant volume return fan is turned ON through the same output as the supply fan. An external Fan Delay Relay is used to provide a delay between startups if required.

Supply Fan Capacity Control (VAV)

The speed of a modulating supply fan is controlled by a 0-100% signal provided to the VFD via an internal Modbus network. Supply Fan Capacity Control for a modulating fan is controlled to either maintain the duct static pressure at a desired value or maintain a fixed speed based on a signal provided via a network.

The choice of control method, SF Cap Ctrl, may be set to Duct Pressure or Speed via the keypad. After the supply fan is started, a speed signal of 33% is sent to the variable frequency drive for the DSPCtrlDelay (Default=30 seconds). Control reverts to either duct pressure or speed after the fan has been on for the duration of the DSPCtrlDelay time. The VFD speed is not controlled below the minimum SAF speed setting (default 33%) while the fan is operating.

Units supplied with Daikin MD2, MD3, and MD6 drives will have a user editable maximum supply fan hertz setpoint (default 60 Hz) located in the SAF Set Up menu. This parameter can be changed when job site conditions require the speed of the drive to be above 60 Hz.

Duct Static Pressure Control

The supply air fan speed is controlled by a VFD. The control parameter for the fan speed is the duct static pressure setpoint. If the duct static pressure is below the duct static pressure setpoint by more than ½ the deadband, the fan speed will increase. Likewise if the duct static pressure is above the duct static pressure setpoint by more than ½ the deadband the fan speed will decrease. Example - if the duct static pressure setpoint is 1.2" and the deadband is 0.1", the duct static pressure must reach 1.14 before the fan will increase in speed. The Duct Static Pressure setpoint may be set through the keypad or via a network signal. The active setpoint is changed whenever either of these values changes so it equals whichever value was changed most recently.

Speed/Network

When speed control is selected, the fan operates at the larger of its minimum speed or a value provided via a connected network or the keypad/display.

Single Zone VAV Control (1ZnVAV)

When space temperature control is selected, the supply fan VFD is controlled with a PI_Loop to maintain the Control Temperature input at the Occupied or Unoccupied Cooling Setpoint or Occupied or Unoccupied Heating Setpoint. This control choice is designed for DAC control type and will be used in applications where the unit will act as a single VAV box to control space temperature. Cooling and heating discharge air temperature control and outside air damper control will function in the normal manner as with VAV units.

Economizer Operation

Refer to [Figure 47 on page 34](#). When the outdoor air is suitable for free cooling, the switch in enthalpy sensor OAE is in position “3” (line 256, [Figure 70 on page 55](#)) energizing Analog Output A0X7. When Analog Output A0X7 energizes, the economizer is enabled. (**NOTE:** If selected from the keypad, the enthalpy decision can be made based on outdoor temperature. In that condition, if the outdoor air temperature is less than or equal to the changeover set point, the economizer is enabled.) If cooling is required, the economizer dampers (ACT3) are modulated to maintain the discharge air temperature setpoint. Analog Output A0X7 drives the outdoor air dampers toward the open and closed (line 256) position. If the outdoor air dampers are wide open and more cooling is required, the dampers hold their positions and mechanical cooling is activated.

When the outdoor air is not suitable for free cooling, the switch in enthalpy sensor OAE is in position “1,” de-energizing Analog Output A0X7. (Alternatively, the outdoor air temperature is above the changeover setpoint plus the economizer changeover differential). When the economizer is disabled, the dampers are held at their minimum position.

Heating

Gas Furnace, Super Modulating Burner (20:1 Turndown)

Refer to the Super Mod Gas Furnace Control (1000 MBh) schematic on [page 58](#) and the Standard Mod, Furnace Control (1000 MBh) schematic on [page 59](#) for a sequence of operation.

Wiring Diagram Legend

ID	Description	Standard Location
ACT3, 4	Actuator motor, economizer	Economizer section
ACT5	Actuator motor, discharge isolation damper	Discharge section
ACT6	Actuator motor, return air isolation damper	Return section
ACT7	Actuator motor, heat face/ bypass	Coil section, heat
ACT8	Actuator motor, cool face/ Bypass	Coil section, cool
ACT10, 11	Actuator motor, exhaust dampers	Return section
ACT12	Actuator motor, enthalpy wheel bypass damper	Energy recovery section
AFD10	Adjustable frequency drive, supply fan	AFD/supply fan section
AFD11	Adjustable frequency drive, evap cond. fans	Main/RCE control box
AFD20	Adjustable frequency drive, return/exhaust fan	AFD/ret. ex. fan section
AFD60	Adjust. freq. drive, energy recovery wheel(s)	Energy recovery section
AS	Airflow switch, burner blower	Gas heat box
BM	Burner blower motor	Heat section, gas
C10	Power factor capacitors, supply fan	Supply Fan section
C20	Power factor capacitors, return fan	Return section
CB10	Circuit breaker, supply fan	Main control box
CB11	Circuit breaker, evaporative condenser fan(s)	Main/cond. control box
CB20	Circuit breaker, return/ exhaust fan	Main control box
CB60	Circuit breaker, energy recovery wheel	Main control box
CCB1, 2	Compressor control boards, refriger. circuits	Main control box
CPC	Circuit board, main, micro controller	Main control box
CPR	Circuit board, expansion, micro controller	Main control box
DAT	Discharge air temperature sensor	Discharge section
DFLH	Design flow lefthand sensor	Return section
DFRH	Design flow righthand sensor	Return section
DHL	Duct hi-limit	Main control box
DS1	Disconnect, total unit or cond/ heat	Main control box
DS2	Disconnect, SAF/RAF/controls	Main control box
DS3	Disconnect, electric heat	Electric heat box
EAT	Exhaust air temperature sensor	Energy recovery section
EFT	Entering fan air temperature sensor	Supply fan section
EHB1	Staged electric heat board	Main control box
ERB1	Energy recovery board	Main control box
ERM1	Energy recovery wheel motor #1	Energy recovery section
ERM2	Energy recovery wheel motor #2	Energy recovery section
F1A, B	Fuse, control circuit transformer (T1), primary	Main control box
F1C	Fuse, control circuit transformer (T1), secondary	Main control box
F2	Fuse, control circuit transformer (T2), primary	Main control box
F3	Fuse, burner blower motor	Main control box

ID	Description	Standard Location
FB31-40	Fuseblock, electric heat (top bank)	Electric heat box
FB41-50	Fuseblock, electric heat (bottom bank)	Electric heat box
FD	Flame detector	Heat section, gas
FLC	Fan limit control	Heat section, gas
FP1, 2	Frost protection, refriger. circuits	Coil section, cool
FS1, 2	Freezestat control	Coil section, heat/cool
FSG	Flame safeguard	Gas heat box
GCB1	Generic condenser board, refriger. circ.	Main control box
GFR1, 2	Ground fault relay	Main control box
GFS1, 2	Ground fault sensor	Main control box
GRD	Ground	All control boxes
GV1	Gas valve, pilot	Heat section, gas
GV2	Gas valve, main/safety	Heat section, gas
GV3	Gas valve, redundant/safety	Heat section, gas
GV4-8	Gas valve, main, hi turn down	Heat section, gas
HL1-10	Hi-limits, pwr, elec heaters (top bank)	Heat section, electric
HL11-20	Hi-limits, pwr, elec heaters (bottom bank)	Heat section, electric
HL22	Hi-limits, gas heat (pre-filters)	Supply fan section
HL23	Hi-limits, gas heat (final filters)	Final filter section
HL31-40	Hi-limits, ctl. elec heaters (top bank)	Heat section, electric
HL41-50	Hi-limits, ctl. elec heaters (bottom bank)	Heat section, electric
HP5	Hi-pressure controls, gas	Heat section, gas
HS1	Heat switch, electric heat shutdown	Main control box
HS3	Heat switch, electric heat deadfront interlock	Electric heat box
HTR65	Heater, sump	Evap. condenser section
HTR66	Heater, vestibule	Evap. condenser vestibule
HUM1	Humidstat sensor	Energy recovery section
IT	Ignition transformer	Gas heat box
LAT	Leaving air temperature sensor	Energy recovery section
LP5	Low-pressure control, gas	Heat section, gas
LR10	Line Reactor, supply fan	Inverter bypass box
LR20	Line reactor, return/exhaust fan	Inv. bypass/main cont. box
LS1, 2	Limit switch, low fire, high fire	Gas heat box
LT10-23	Light, cabinet sections	Supply fan section
M10	Contactator, supply fan	Main control box
M20	Contactator, return fan	Main control box
M29	Contactator, burner motor	Gas heat box
M30	Contactator, reversing, inverter bypass, supply fan	Inverter bypass box
M31-39	Contactator, electric heat (top bank)	Electric heat box
M40	Contactator, reversing, Inverter Bypass, Return Fan	Inverter bypass box
M41-50	Contactator, electric heat (bottom bank)	Electric heat box
M60	Contactator, energy recovery wheel	Main control box
MCB	Microprocessor circuit board	Main control box
MJ	Mechanical Jumper	All control boxes
MMP1-8	Manual motor protector, compressors	Main/cond. control box
MMP10	Manual motor protector, supply fan	Main control box

ID	Description	Standard Location
MMP11-18	Manual motor protector, cond. fans, ckt#1	Main/cond. control box
MMP20	Manual motor protector, return fan	Main control box
MMP21-28	Manual motor protector, cond. fans, ckt#2	Main/cond. control box
MMP30	Manual motor protector, invtr. bypass, sup. fan	Inverter bypass box
MMP40	Manual motor protector, invtr. bypass, ret. fan	Inverter bypass box
MMP51, 52, 53	Manual motor protector, exhaust fan(s)	Prop exhaust box
MMP60	Manual motor protector, energy recovery wheel	Main control box
MP1-6	Motor protector, compr.#1-6	On compressors
OAE	Outside air enthalpy sensor	Economizer section
OAT	Outside air temperature sensor	Economizer section
PB1, 2	Power block, power distribution	Main control box
PB3	Power block, power distribution, electric heat	Electric heat box
PB9, 10	Power block, supply fan	Junction box, split unit
PB11, 12	Power block, power distribution	Main control box
PB19, 20	Power block, return/exhaust fan	Junction box, split unit
PC5	Pressure control, clogged filter	Pre filter section
PC6	Pressure control, clogged final filter	Final filter section
PC7	Pressure control, proof airflow	Supply fan section
PC8	Pressure control, minimum airflow	Coil section, cool
PM1	Phone modem	Main control box
PVM1, 2	Phase voltage monitor	Main control box
R20	Relay, Heat, gas/steam/hot water	Gas heat/main cont. box
R21, 22	Relay, heat, gas (hi-turn down)	Gas heat box
R23	Relay, heat, gas & electric	Gas/electric heat box
R24	Relay, heat alarm, gas	Main control box
R25	Relay, heat, gas, start supply fan inverter	Main control box
R26	Relay, isol/exh. dampers, open/close	Main control box
R28	Relay, isolation damper, safety	Main control box
R29	Relay, remote fire alarm	Main control box
R30	Relay, cool valve with face bypass	Main control box
R45	Relay, UV lights	Main control box
R46, 47	Relay, supply fan inverter, incr/decr	Main control box
R48, 49	Relay, return fan inverter, incr/decr	Main control box
R58,59	Relay, heat wheel inverter, incr/decr	Main control box
R60	Relay, energy recovery wheel, enable	Main control box
R61	Relay, smoke detector, discharge air	Main control box
R62, 63, 65	Relay, use on specials	Main control box
R66	Relay, smoke detector, return air	Main control box
R67	Relay, supply fan, enable	Main control box
R68	Relay, return fan, enable	Main control box
R69	Relay, Inv. bypass VAV box interlock	Main control box
R70-79	Relay, use on specials	Main control box
RAE	Return air enthalpy sensor	Return section
RAT	Return air temperature sensor	Return section
REC1	Receptacle, main box	Main control box

ID	Description	Standard Location
REC3	Receptacle, field power, 115V	Discharge bulkhead
REC10-23	Receptacle, cabinet sections	Cabinet sections
S1	Switch, system ON/OFF	Main control box
S3	Switch, furnace ON/OFF	Gas heat box
S4	Switch, inverter bypass, ON/OFF	Main control box
S7	Switch, local ON/AUTO/OFF to controller	Main control box
S10-23	Switches, cabinet section lights	Cabinet sections
S40-45	Switches, door interlock, UV lights	Cabinet sections
SD1	Smoke detector, supply	Discharge section
SD2	Smoke detector, return	Return section
SPS1, 2	Static pressure sensors, duct/building	Main control box
SR1-3	Sequencing relays, electric heat	Electric heat box
T1	Transformer, main control (line/115 V (ac))	Main control box
T2	Transformer, control input (115/24 V (ac))	Main control box
T3	Transformer, control output (115/24 V (ac))	Main control box
T4	Transformer, exh. damper actuator (115/12 V (dc))	Main control box
T5	Transformer, electric heat	Electric heat box
T6	Transformer, dew point controller (115/24 V (ac))	Main control box
T9	Transformer, refrig. circuit 24V	Main control box
TB1	Terminal block, internal	Main control box
TB2	Terminal block, field	Main control box
TB3	Terminal blocks, factory	Main control box
TB4	Terminal block, RFS, field	Main control box
TB7	Terminal block, 115V convenience outlet, field	Main control box
TB11	Terminal block, heat	Heat control box
TB25, 26, 27, 28	Terminal block, split unit junction box	Junction box, split unit
TD5-8	Time delay, part winding, compr #1-4	Main control box
TD10	Time delay, hi turn down burner	Gas heat box
TR1, 2	Transducer, pressure	Main control box
UV	Ultra-violet light(s)	Coil/discharge section
VM1	Valve motor #1, heating	Gas heat box/heat section
VM5	Valve motor #5, cooling	Coil section, cool
VV1	Vent valve, gas heat	Heat Section, Gas
ZNT1	Zone temp. sensor, setback	Field installed

General Notes




Figure 68: Power Package Only, Main Power




Figure 69: VAV Fan Power (with SAF and RAF VFDs and Manual Bypass)




Figure 70: VAV Control Inputs




Figure 70 continued: VAV Control Inputs





Figure 72: Super Mod Gas Furnace Control (1000 MBh)



SEQUENCE OF OPERATION



When 120V power is furnished through the system on/off switch (S1), through the burner on/off switch (S3), through the high limit control (FLC), terminal #6 on the flame safeguard (FSG) is powered on a call for heat.

Whenever power is restored to the flame safeguard, the flame safeguard will go through a 10 second initiation period before the prepurge period will begin. The burner air control valve will be at minimum position during off cycles. Upon a call for heat or any other time that a prepurge cycle occurs, the air control valve will be repositioned to the maximum position for prepurge and then returned to the minimum position for low fire start.

Upon a call for heat, the controller will close digital output (EXPB-DO1) and energize the R20A relay. Once the normally open contacts of the R20A relay close 120V power is supplied to terminal #6 on the FSG. The FSG then energizes its terminal #4, which powers the burner combustion air blower motor (BM) and starts the 90 second prepurge cycle. Blower operation is sensed by the Air Switch (AS), which makes terminal FSG-6 to FSG-7 during the prepurge cycle. The controller will reposition the burner air valve to its maximum open position via analog output EXPB-AO_X7 for prepurge. When the burner air valve reaches the full open position switch (LS2) will 'make' and provide a digital input to the controller (EXPB-DL_X3). This digital input will initiate a 20 second (adjustable) timing period in the controller. At the completion of the timing period, the controller will begin to drive the burner air valve to its minimum (low fire) position. When the valve reaches the minimum position switch LS1 will 'make' and provide a digital input to the controller (EXPB-DL_X2) indicating the controller's prepurge sequence is complete. As soon as the FSG prepurge time expires FSG terminal #8 will energize relay R22 which will turn on a digital input to the controller (EXPB-DL_X1). As soon as this digital input is 'made' the controller will close digital output (EXPB-DO2) allowing the combination gas valve(s) (GV1) to be energized.

After completion of the FSG prepurge period there will be a 10 second trial for ignition during which terminal #8 (combination gas valve - GV1) and terminal #10 (ignition transformer - IT) will be energized. If flame is being detected through the flame rod (FD) at the completion of the 10 second trial for ignition period, terminal #10 (ignition transformer - IT) will be de-energized and terminal #9 (main gas valves - GV4 and GV5 depending on burner size) will be energized and the control system will be allowed to control the firing rate once the heating stage timer (default 5 minutes) has passed. After the flame has lit and been proven and the heating stage time has passed, the controller will modulate (VM1) to the required firing rate via analog output EXPB-AO_X7. In the event the flame fails to ignite or the flame safeguard fails to detect its flame within 10 seconds, terminal #4, 8, 9, and 10 will be de-energized, thus de-energizing the burner. The FSG will then lockout and would require manual resetting. If the FSG lockout occurs, FSG terminal #3 will energize the R24 alarm input status relay which will 'make' a digital input to the controller (EXPB-DL_X4). When this digital input is 'made' the controller will drive VM1 to the closed position, de-energize digital output EXPB-DO2 and the prepurge sequence will be disabled and reset. If the FSG terminal #8 de-energizes R22 (EXPB-DL_X1) after having it turned on and the FSG is not off on safety lockout, the prepurge sequence will start over.

If an attempt is made to restart the burner by resetting the FSG or if an automatic restart is initiated after flame failure the earlier described prepurge cycle with the wide open air valve will be repeated. If the unit overheats, the high limit control (FLC) will cycle the burner, limiting furnace temperature to the limit control set point. The flame safeguard contains 'LEDS' (lower left corner) that will glow to indicate operation.



PIPING DIAGRAM





Figure 73: Standard Modulating Gas Furnace Control (1000 MBh)



SEQUENCE OF OPERATION

When 120V power is furnished through the system on/off switch (S1), through the burner on/off switch (S3), through the high limit control (FLC), terminal #6 on the flame safeguard (FSG) is powered on a call for heat.

Whenever power is restored to the flame safeguard, the flame safeguard will go through a 10 second initiation period before the prepurge period will begin. The burner air control valve will be at minimum position during off cycles. Upon a call for heat or any other time that a prepurge cycle occurs, the air control valve will be repositioned to the maximum position for prepurge and then returned to the minimum position for low fire start.

Upon a call for heat, the controller will close digital output (EXPB-D01) and energize the R20A relay. Once the normally open contacts of the R20A relay close 120V power is supplied to terminal #6 on the FSG. The FSG then energizes its terminal #4, which powers the burner combustion air blower motor (BM) and starts the FSG prepurge cycle. Blower operation is sensed by the Air Switch (AS), which makes the terminal FSG-6 to FSG-7 during the prepurge cycle.

After completion of the FSG prepurge period there will be a 10 second trial for ignition during which terminal #8 (combination gas valve - GV1) and terminal #10 (ignition transformer - IT) will be energized. If flame is being detected through the flame rod (FD) at the completion of the 10 second trial for ignition period, terminal #10 (ignition transformer - IT) will be de-energized and terminal #9 (main gas valves - GV2 and GV3) will be energized and the control system will be allowed to control the firing rate once the heating stage timer (default 5 minutes) has passed. After the flame has lit and been proven and the heating stage time has passed, the controller will modulate (VM1) to the required firing rate via analog output EXPB-AO_X7. In the event the flame fails to ignite or the flame safeguard fails to detect its flame within 10 seconds, terminal #4, 8, 9, and 10 will be de-energized, thus de-energizing the burner. The FSG will then lockout and would require manual resetting. If the FSG lockout occurs, FSG terminal #3 will energize the R24 alarm input status relay which will 'make' a digital input to the controller (EXPB-DL_X4). When this digital input is 'made' the controller will drive VM1 to the closed position. At the same time EXPB-D02 will open, the prepurge sequence will be disabled and reset. If the FSG terminal #8 de-energizes relay R22 (EXPB-DL_X1) after having it turned on and the FSG is not off on safety lockout, the controller will drive the VM1 to the closed position.

If an attempt is made to reset the FSG or if an automatic restart is initiated after flame failure, the earlier described FSG prepurge cycle will be repeated.

If the unit overheats, the high limit control (FLC) will cycle the burner, limiting furnace temperature to the limit control set point. The flame safeguard contains 'LEDS' (lower left corner) that will glow to indicate operation.

PIPING DIAGRAM




Figure 74: Electric Heat Control with SCR Control (shown)





Figure 75: Fan Control, Power Package Only



Differential Enthalpy Control (OAE/RAE)

An optional electric differential enthalpy control arrangement (OAE/RAE) is available on units with MicroTech III control. In this configuration a solid-state humidity and temperature sensing device is located in both the return (RAE) and outside intake (OAE) airstreams. This OAE device has the same A through D scale as the device described above. However, with the OAE/RAE arrangement the switch on, OAE must be set all the way past the D setting. With this done, the MicroTech III controller adjusts the return and outside air dampers to use the airstream with the lowest enthalpy.

Ground Fault Protection

The ground fault protection is designed to protect motors from destructive arcing ground faults. The system consists of a ground fault relay and a ground fault current sensor. The ground fault relay employs solid state circuits that will instantly trip and open a set of relay contacts in the 115-volt control circuit to shut the unit down whenever a ground fault condition exists. The ground fault relay is self powered. The ground fault sensor is a current transformer type of device located on the load side of the power block through which the power wires of all phases are run.

Phase Voltage Monitor

The phase voltage monitor (page 110) protects against high voltage, phase imbalance, and phase loss (single phasing) when any one of three line voltages drops to 74% or less of setting. This device also protects against phase reversal when improper phase sequence is applied to equipment, and low voltage (brownout) when all three line voltages drop to 90% or less of setting. An indicator run light is ON when all phase voltages are within specified limits. The phase voltage monitor is located on the load side of the power block with a set of contacts wired to the 115-volt control circuit to shut the unit down whenever the phase voltages are outside the specified limits.

External Time Clock

You can use an external time clock as an alternative to (or in addition to) the MicroTech III controller's internal scheduling function. The external timing mechanism is set up to open and close the circuit between field terminals 101 and 102. When the circuit is open, power is not supplied to binary input MCB-BI1. This is the normal condition where the controller follows the programmable internal schedule. When the circuit is closed, power is fed to BI1. The MicroTech III controller responds by placing the unit in the occupied mode, overriding any set internal schedule.

For more information, see the "Digital Inputs" section of [IM 919](#), "MicroTech III Applied Rooftop Unit Controller."

Smoke and Fire Protection

WARNING

Improper smoke, fire, or fume air handling can result in severe personal injury or death.

Daikin Applied optionally offers factory installed outdoor air, return air, and exhaust air dampers as well as smoke detectors in the supply and return air openings, complete with wiring and control. These components often are used in the building's smoke, fume, and fire protection systems. However, due to the wide variation in building design and ambient operating conditions into which our units are applied, we do not represent or warrant that our products will be fit and sufficient for smoke, fume, and fire control purposes. The owner and a fully qualified building designer are responsible for meeting all local and NFPA building code requirements with respect to smoke, fume, and fire control.

Smoke Detectors

Field installed smoke detectors in the return air ductwork or the supply air ductwork can be coordinated with the units operation through the unit controller's binary input, D14. This input is wired to TB2 and the supply air smoke detector can be wired between terminals 103 and 104 and the return air smoke detector can be wired between terminals 104 and 105. The T2 transformer supplies 24 V (ac) across each of these terminals and a dry set of contacts can be wired to these terminals respectively. This and additional wiring information can be seen on the input wiring schematics at line number 220.


Factory installed smoke detectors have similar wiring and the control sequence is as follows:

When smoke is detected by either sensor, the normally closed sensor contacts open. This removes power from binary input B18 on the main control board.

The Microtech III controller responds by shutting down the unit. The controller is placed in the Alarm Off state and cannot be restarted until the alarm is manually cleared. Refer to the operation manual supplied with the unit for information on clearing alarms.

The smoke detectors must be reset manually once they have been tripped. Power must be cycled to the smoke detector to reset.

Figure 78: Smoke Detector Schematic




VAV Box Output

The VAV Box Output (MCB-DO10) supplies 24 V (ac) to terminal 116 on the field terminal block (TB2) when the output is on. To use this signal, wire the coil of a field supplied and installed 24 V (ac) pilot relay across terminals 116 and 117 on TB2. When this output is on, 24 V (ac) is supplied from the T3 control transformer through the output relay to energize the field relay. Refer to the as-built wiring diagrams.

In the Heating state, the VAV Output is turned OFF to indicate that hot air instead of the normal cool air is being supplied to the VAV boxes. The VAV boxes are driven to their Heating Position when hot air is provided based on either the normally open or normally closed contacts of the VAV output. The VFD will continue to be controlled to maintain the desired duct static pressure. This output is also OFF when the unit is in the Startup or Recirculation states. If this output is in the Heat (OFF) position when the unit enters the Fan Only state or Minimum DAT Control state, the output remains OFF for an adjustable Post Heat Time (while the unit VFDs are driven to minimum speed) or until the VFD gets to its minimum speed if the Post Heat Time is set greater than 0. The Post Heat Timer can be adjusted via the keypad/display Timer Setting menu in the Extended Menus.

During unoccupied operation, the VAV Box Output is in the Cool (ON) position unless airflow is detected. When airflow is detected, it switches to the Heat (OFF) position.

Figure 80: Field Output Schematic



Entering Fan Temperature Sensor

The entering fan temperature (EFT) sensor and an associated “Lo Airflow Problem” alarm are provided on VAV units with MicroTech III control and gas or electric heat. The EFT sensor is located in the supply fan section of the unit at the supply air funnel.

Heat is disabled whenever the airflow is detected to be too low for safe heating operation. This condition is indicated when the supply air temperature exceeds the mixed air temperature by more than 60°F (16°C).

NOTE: This value is not always 60°F. It depends on whether the unit is gas or electric heat and on the burner/baffling arrangement on gas heat units.

In this case, a “Lo Airflow Problem” alarm is generated and heat is not enabled until the alarm is manually cleared. Refer to the operation manual supplied with the unit for information clearing alarms (OM 920).

Duct High Pressure Limit

The duct high pressure limit control (DHL) is provided on all VAV units. The DHL protects the duct work, the terminal boxes, and the unit from over pressurization, which could be caused by, for example, tripped fire dampers or control failure.

The DHL control is factory set to open when the discharge plenum pressure rises to 3.5" wc (872 Pa). This setting should be correct for most applications; however, it is adjustable. Removing the front cover of the device reveals a scale showing the current setting. Turning the adjustment screw (located on the bottom of the device) adjusts the setting up or down.

If the DHL switch opens, digital input MCB BI 14 on the Main Control Board de-energizes. The MicroTech III controller then shuts down the unit and enters the OFF-Alarm state. The alarm must be manually cleared before the unit can start again. Refer to the operation manual supplied with your unit for more information on clearing alarms (OM 920).

Variable Frequency Drive Operation

Refer to the vendor instructions supplied with the unit.

Convenience Receptacle/Section Lights

A Ground Fault Circuit Interrupter (GFCI) convenience receptacle is provided in the main control box on all units. One of the following is required:

1. Connect a separate field-supplied 115 V power wiring circuit to the 115V field terminal block TB7, located in the main control box.
2. Select the factory powered outlet option at time of purchase.

Optional lights are available for certain sections in the unit. Each light includes a switch and convenience receptacle and is powered by the external 115V power supply connected to TB7.


DesignFlow™ Outdoor Air Damper Option

DesignFlow airflow measurement stations are located inside the louvered outdoor air intake doors between the intake louver and outside air dampers. Essentially, they consist of a vane that is repositioned by airflow, the amount of rotation indicating the amount of airflow. They are calibrated precisely at the factory and no further calibration is required. However, a leveling adjustment is required in the field so that the DesignFlow unit is in the same orientation as when it was factory calibrated. See “DesignFlow Station Startup”.

The rotational position of the DesignFlow unit vane is translated into CFM by the microprocessor in the MicroTech III control system. The position of the vane is determined by two things—the force of the airflow impacting the vane and the gravitational effect on the vane. Gravity is the only factor at the lower CFM end of the range. On a correctly leveled unit, this gravitational effect will be the same as when the unit was calibrated in the factory.

Accurately leveling a station involves applying a precise mechanical force against the vane. This force should cause the vane to move to a specific position if the DesignFlow unit is correctly leveled.

Figure 81: DesignFlow Station



DesignFlow Station Startup

Before initial startup of the rooftop unit, carry out the following procedure on both the right-hand (control panel side) and left-hand (side opposite the control panel) DesignFlow station vanes (Figure 81).

NOTE: This procedure is much easier to carry out with two people—one making the mechanical adjustments and the other viewing and recording readings on the MicroTech III control panel.

1. Verify that power is supplied to the unit's MicroTech III control system. The DesignFlow startup procedure cannot be completed without use of the MicroTech III controls.
2. Unlock and open the louvered outdoor air intake door on the side of the unit (Figure 81).
3. The swinging vane on the measurement station is locked in place for shipment. Unlock it by removing the two shipping screws. One is located one inch from the top of the vane and the other one inch from the bottom of the vane. Both are about eight inches in from the outer edge of the vane.
4. Examine the station for shipping damage. Manually rotate the vane and verify that it does not rub against anything.
5. Manually hold the vane closed against the mechanical stop at the top of the assembly. Then, read the current vane leveling position on the MicroTech III keypad/ display.

Do this by viewing the **LH Lvl Pos=** or **RH Lvl Pos=** parameter in the DesignFlow setup menu. The **LH Lvl Pos=** parameter indicates the current position of the vane for the left-hand DesignFlow station (side opposite the control panel). The **RH Lvl Pos=** parameter indicates the current position of the vane for the right-hand DesignFlow station (control panel side).

Important: Wait several seconds until the value on the keypad stabilizes before taking the reading.

For detailed information regarding operation and navigation through the unit keypad, refer to Operation manual [OM 137](#) (discharge air control units) or [OM 138](#) (zone control units).

6. Confirm the value of the reading. Ideally, it should read close to 20.00 (19.50 to 20.50 is acceptable). If the reading is out of range, loosen the screws fixing the mechanical stop at the top of the assembly, make a small adjustment, and recheck until the reading is in the specified range.

NOTE: Generally, adjustments should not be necessary.

7. Locate the leveling component kit, which is shipped with the unit, in the unit mail control panel.
8. Duct tape the fulcrum alignment plate to the bottom corner of the vane (Figure 82) aligning it as follows:
 - a. The bottom edge of its notches should be flush with the bottom edge of the vane.
 - b. The side of one notch should be even with the bend near the outer edge of the vane.
 - c. The plate should be flat against the outer surface of the vane.
9. Locate and install the fulcrum used in the leveling procedure as follows (Figure 82):
 - a. Wipe the bottom of the louver door where the fulcrum will be located so that the duct tape will stick to it.
 - b. Pre-apply duct tape to the top surface of the bottom portion of the fulcrum, extending it about one inch beyond the edges on three sides.
 - c. With the alignment plate taped to the vane and the vane in the zero airflow position, locate the fulcrum parallel to and against the alignment plate.

NOTE: The zero airflow position is when the vane is swung away from the back wall and gently resting against its stop.
 - d. Once the fulcrum is in position, press the duct tape extensions down to hold the fulcrum in place.
 - e. Remove the alignment plate after installing the fulcrum.
10. Close and latch the louvered intake door.
11. Remove the cover from the access opening in the bottom blade of the outdoor air intake louver (Figure 85 on page 69).
12. Verify that the unit fans are off and that the outdoor air dampers are closed. If there is a wind, cover the outdoor air louvers with poly film, cardboard, or other suitable material to prevent adverse readings due to wind.
13. Rest the leveling weight assembly on the fulcrum, as shown in Figure 83, so that:
 - a. Its bottom two thumbscrews rest on the top edge of the fulcrum.
 - b. Its top thumbscrew rests against the vertical alignment mark on the vane.

NOTE: The alignment mark is located 0.50 inch in from the bend on the outer edge of the vane. It intersects with a hole located one inch up from the bottom outer edge of the vane.

14. Set up the leveling test as follows:
 - a. While holding the weight so it stays on the fulcrum, manually rotate the vane to the wide-open position, manually return it to the zero CFM position, and gently release the vane.
 - b. Locate the leveling weight assembly so its contact point is against the vertical mark on the vane.
 - c. While the weight assembly teeters on the fulcrum, gently rap the base frame to slightly vibrate the assembly and encourage the vane to seek its equilibrium point.
15. Read the current *LH Lvl Pos=* (or *RH Lvl Pos=*) parameter in the DesignFlow Setup menu on the keypad/ display. These parameters vary from 20% to 80% depending on the position of the DesignFlow vane
16. If the value indicated by the *LH Lvl Pos=* (or *RH Lvl Pos=*) parameter is not within the range of 22.56% to 23.02%, (22.79% is ideal) adjust the level of the DesignFlow unit using the procedure described in "Making Level Adjustments" below.
17. When the *LH Lvl Pos=* (or *RH Lvl Pos=*) value is in range, remove the fulcrum and leveling weight assembly and replace the access opening cover in the louvered door.

Figure 82: Tape Fulcrum Alignment Plate to Vane





Figure 83: Place Leveling Weight On Fulcrum



Making Level Adjustments

The DesignFlow unit is mounted so that it pivots at the top when three lock nuts are loosened, two at the top and one at the bottom of the assembly (Figure 84). Leveling the unit involves precisely pivoting the assembly with a known force applied to the vane until the vane opens to a specific position.

If after performing Steps 13 through 15 (DesignFlow Station Startup on page 66), the vane does not come to rest within the specified range, carry out the following steps:

1. Unlock and open the louvered outdoor air intake door on the side of the unit.
2. Loosen the two 1/4-20 NC lock nuts at the top of the DesignFlow frame (Figure 84 on page 69).
3. Close and lock the intake door.
4. Remove the cover from the access opening in the bottom blade of the outdoor air intake louver (Figure 85).
5. Loosen the 1/4-20 NC lock nut in the slotted hole at the bottom of the DesignFlow frame (Figure 86).
6. If the *LH Lvl Pos=* (or *RH Lvl Pos=*) value obtained in step 15 above is HIGHER than the specified range, move the bottom of the DesignFlow frame closer to the outdoor air dampers (away from the back end of the unit). Do this by turning the long adjuster nut to increase the L dimension in Figure 103.

If the *LH Lvl Pos=* (or *RH Lvl Pos=*) value obtained in step 15 above is LOWER than the specified range, move the bottom of the DesignFlow frame away from the outdoor air dampers (toward the back end of the unit). Do this by turning the long adjuster nut to decrease the L dimension in Figure 83.

NOTE: If the necessary adjustment cannot be made using the long adjuster nut, reposition the two 1/4-20 NC jam nuts on the threaded rod to make larger adjustments (Figure 83).

7. When finished making the adjustments, tighten the 1/4-20 NC lock nut in the slotted hole at the bottom of the DesignFlow frame (Figure 83).

NOTE: Make sure the leveling weight's top thumbscrew is still against the vertical alignment mark on the vane.

8. Gently rap the base frame to slightly vibrate the assembly to encourage the vane to seek its equilibrium point.
9. Recheck the vane position compared to the range specified in Step 16 (DesignFlow Station Startup). Readjust the level as necessary.

NOTE: If large adjustments are required to correctly level the vane assembly, before rechecking the level, relocate the fulcrum as described in Step 9 in DesignFlow Station Startup.

10. When the level is correct, unlock and open the louvered outdoor air intake door on the side of the unit and tighten the two 1/4-20 NC lock nuts at the top of the DesignFlow frame (Figure 84).
11. Close and lock the intake door.
12. Recheck the vane position and readjust the level as necessary.
13. When the vane position is correct, replace the access opening cover in the louvered door.

Figure 84: DesignFlow Frame




Figure 85: Remove Covers from Access Opening







Figure 86: Leveling Adjustment



Propeller Exhaust Fan Option

Economizer units may include propeller exhaust or centrifugal return fan options. This section covers maintenance and operating instructions for the propeller exhaust option. Centrifugal return fan construction, maintenance and operation is similar to that for supply fans and covered in other sections of this manual.

Figure 87: Two Fans with Back Return



Prestarting Checks

Check all fasteners and set screws for tightness. This is especially important for bearing set screws.


The propeller should rotate freely and not rub on the fan panel venturi. Rotation direction of the propeller should be checked by momentarily turning the unit on. Rotation should be in the same direction as the rotation decal affixed to the unit or as shown in Figure 88. For three-phase installations, fan rotation can be reversed by simply interchanging any two of the three electrical leads. For single phase installations follow the wiring diagram located on the motor.

The adjustable motor pulley is preset at the factory for the specified fan RPM. Fan speed can be increased by closing (or decreased by opening) the adjustable pulley. Two or three groove variable pitch pulleys must be adjusted an equal number of turns open. Any increase in fan speed represents a substantial increase in horsepower required from the motor. Always check motor load amperage and compare to name plate rating when changing fan speed.

Once the fan is put into operation, set up a periodic maintenance program to preserve the reliability and performance of the fan. Items to include in this program are:

- Belts
- Bearings
- Fasteners
- Setscrews
- Lubrication
- Dust/dirt removal

Figure 88: Fan Rotation



Belts

WARNING
 Rotating parts can cause severe personal injury or death. Replace all belt/fan guards that are removed temporarily for service.

Premature belt failures are frequently caused by improper belt tension (either too tight or too loose) or misaligned pulleys. The proper tension for operating a V-belt is the lowest tension at which the belts will not slip peak load conditions. For initial tensioning, the proper belt deflection half way between pulley centers is 1/64" for each inch of belt span. For example, if the belt span is 64 inches, the belt deflection should be one inch using moderate thumb pressure at midpoint of the drive (Figure 89).

Check belt tension two times during the first 24 hours of operation and periodically thereafter. To adjust belt tension, simply loosen four fasteners (two on each side of the motor plate) and slide the motor plate away from the fan shaft until proper belt tension is attained. On some fans, fasteners attaching the motor to the motor plate must be loosened to adjust the belt.

It is very important that the drive pulleys remain in proper alignment after adjustments are made (Figure 90). Misalignment of pulleys results in premature belt wear noise, vibration, and power loss.

Figure 89: Belt Adjustment





Figure 90: Drive Pulley Alignment



Bearings

Bearings are the most critical moving part of the fan and should be inspected at periodic intervals. Locking collars and set screws, in addition to fasteners attaching the bearings to the bearing plate, must be checked for tightness. In a clean environment and temperatures above 32°F/below 200°F, fan shaft bearings with grease fittings should be lubricated semiannually using a high quality lithium based grease. If unusual environmental conditions exist temperatures below 32°F/above 200°F, moisture or contaminants, more frequent lubrication is required.

With the unit running, add grease very slowly with a manual grease gun until a slight bead of grease forms at the seal. Be careful not to unseat the seal by over lubricating or using excessive pressure. Bearings without grease fittings are lubricated for life.

Fasteners and Setscrews

Any fan vibration has a tendency to loosen mechanical fasteners. A periodic inspection should include checking all fasteners and set screws for tightness. Particular attention should be paid to setscrews attaching the propeller to the shaft and the shaft to the bearings. Loose bearing set screws will lead to premature failure of the fan shaft.

Lubrication

Refer to “Bearings” above for bearing lubrication. Many fractional horsepower motors installed on the smaller fans are lubricated for life and require no further attention. Motors equipped with oil holes should be oiled in accordance with the manufacturer’s instructions printed on the motor. Use a high grade SAE 20 machine oil and use caution not to over lubricate.

Motors supplied with grease fittings should be greased according to directions printed on the motor.

Removal of Dust/Dirt

Thoroughly clean the exterior surface of the motor, fan panel, and entire propeller periodically. Dirt can clog cooling openings on motor housings, contaminate bearing lubricant, and collect on propeller blades causing severe imbalance if left unchecked. Use caution and do not allow water or solvents to enter the motor or bearings. Under no circumstances should motors or bearings be sprayed with steam or water.

Exhaust Fan ON/OFF Control

The exhaust fans are turned ON and OFF based on building static pressure, outdoor air damper position, and discharge fan capacity. Exhaust fans do not have to always run while the supply fan is on, as does a return fan. They are turned on and off through output MCB-B02 on the Main Control Board. For detailed information on Propeller Exhaust Fan Control, refer to the operation manual supplied with the unit ([OM 138](#) or [OM 137](#)).


Exhaust Fan Troubleshooting

[Table 13](#) provides guidelines for troubleshooting problems with the propeller exhaust fan options. A list of parts is provided in [Figure 91](#) on [page 73](#).

Table 13: Propeller Exhaust Fan Troubleshooting

Problem	Cause	Corrective Action
Reduced Airflow	System resistance is too high	Check backdraft dampers for proper operation. Remove obstructions in ductwork. Clean dirty filters. Check for adequate supply for air exhaust fans or exhaust air for supply fans.
	Unit running backwards	See Prestarting Checks on page 70
	Fan speed too low	Increase fan speed
	Excessive dirt on propeller	Clean propeller
Excessive Noise	Bearings	Tighten bearing collars and setscrews. Lubricate bearings. Replace defective bearings.
	V-Belt drive	Tighten pulleys on motor shaft and fan shaft. Adjust belt tension. Align pulleys. Replace worn belts or pulleys.
	Excessive vibration	Clean dirt build-up from propeller. Check all setscrews and fasteners for tightness. Check for worn bearing. Correct propeller imbalance. Check for loose dampers, guards or ductwork.
	Defective motor	Replace motor

Figure 91: Propeller Exhaust Fan Replacement Parts List



Ultraviolet Lights Option

WARNING

UVC exposure is harmful to the skin and eyes. Looking at an illuminated bulb can cause permanent blindness. Skin exposure to UVC can cause cancer. Always disconnect power to unit before servicing. Do not operate if disconnect switch has been disabled.

When this option is employed, ultraviolet C light bathes the moist surfaces on the coil and drain pan, killing most microorganisms that can grow there.

Typically, ultraviolet lights are installed on the leaving side of the cooling coils in the unit. Each light module is mounted on a rail and is removable for convenient bulb replacement.

UV Light Power Disconnect switches (two per door) are factory installed on every door that allows a direct line of sight to the UV lamps when opened. These switches are designed to prevent UV exposure when cabinet doors are opened and must not be disabled.

A viewing window near the UV lights allows viewing to determine if the lights are energized. The viewing windows use specially designed glass that blocks harmful UV light.

Ultraviolet Light Operation

Refer to [Figure 93 on page 75](#). 115 V (ac) power for the UV lights is provided by control circuit transformer T1. The lights operate whenever the unit is powered, system switch S1 is closed, and all doors with door power disconnect switches are closed. To turn the lights OFF, disconnect power to the entire unit, or open system switch S1.

The normally open disconnect switches are wired in series in a circuit that supplies 24 V (ac) to the coil of relay R45. When all doors are closed, relay R45 is energized, and its normally open contacts (in series with system switch S1) provide 115 V (ac) to the UV lights.

Figure 92: Typical Ultraviolet Light Installation





Figure 93: Typical Ultraviolet Light Wiring Schematic



⚠ WARNING

Electric shock and moving machinery hazard. Can cause severe equipment damage, personal injury, or death.

Disconnect and tag out all electrical power before servicing this equipment.

All start-up and service work must be performed only by trained, experienced technicians familiar with the hazards of working on this type of equipment.

Read and follow this manual: "MicroTech III Applied Rooftop Unit Controller" manual ([OM 920](#)) before operating or servicing.

Bond the equipment frame to the building electrical ground through grounding terminal or other approved means.

All units are completely run tested at the factory to promote proper operation in the field. Nevertheless, the following check, test, and start procedures must be performed to properly start the unit. To obtain full warranty coverage, complete and sign the check, test, and start form supplied with the unit, or complete the [Rooftop Equipment Warranty Registration on page 115](#) and return it to Daikin.

A representative of the owner or the operator of the equipment should be present during start-up to receive instructions in the operation, care, and maintenance of the unit. If the unit has a factory mounted disconnect switch, use the switch's bypass mechanism to open the main control panel door without de-energizing the control panel. See [page 43](#) for instructions.

Servicing Control Panel Components

⚠ DANGER

Hazardous voltage. May cause severe injury or death.

Disconnect electric power before servicing equipment. More than one disconnect may be required to de-energize the unit.

Disconnect all electric power to the unit when servicing control panel components. Unless power is disconnected to the unit, the components are energized. Always inspect units for multiple disconnects to ensure all power is removed from the control panel and its components before servicing.

Before Start-up

1. Verify that the unit is completely and properly installed with ductwork connected.
2. Verify that all construction debris is removed, and that the filters are clean.
3. Verify that all electrical work is complete and properly terminated.
4. Verify that all electrical connections in the unit control panel and compressor terminal box are tight, and that the proper voltage is connected.

5. Verify all nameplate electrical data is compatible with the power supply.
6. Verify the phase voltage imbalance is no greater than 3%.
7. Verify that gas piping is complete and leak tight.
8. Verify that the shutoff cock is installed ahead of the furnace, and that all air has been bled from the gas lines.
9. Manually rotate all fans and verify that they rotate freely.
10. Verify that the belts are tight and the sheaves are aligned.
11. Verify that all setscrews and fasteners on the fan assemblies are still tight. Do this by reading and following the instructions in [Setscrews on page 105](#), which is in [Maintenance on page 101](#) of this manual.
12. Verify that the evaporator condensate drain is trapped and that the drain pan is level.
13. If unit is curb mounted, verify that the curb is properly flashed to prevent water leakage.
14. Before attempting to operate the unit, review the control layout description to become familiar with the control locations.
15. Review the equipment and service literature, the sequences of operation, and the wiring diagrams to become familiar with the functions and purposes of the controls and devices.
16. Determine which optional controls are included with the unit.
17. Before closing (connecting) the power disconnect switch, open (disconnect) the following unit control circuit switches:
 - a. Main Control Panel
 - Turn system switch S1 to OFF.
 - Electric heat units: turn switch HS1 to OFF.
 - b. Furnace Control Compartment
 - Turn furnace switch S3 to OFF.
 - Main Control Panel Switch S7 to OFF.
18. If the DAC or SCC unit does not have an optional zone temperature sensor (ZNT1) connected to it, you may need to change the keypad entry under *Main Menu\Commission Unit\Unit Setup\Space Sensor = from none, Analog/Net, Digital/Net.*

NOTE: If desired, you can significantly reduce all MicroTech III internal control timers by the changing the entry under keypad menu *Main Menu\Commission Unit\Timer Settings\Service Time = (from 0 min to X min where X is the number of minutes you want the unit to operate with fast timers).*

Power Up

1. Close the unit disconnect switch. With the control system switch S1 in the OFF position, power should be available only to the control circuit transformer (T1) and the compressor crankcase heaters.
2. Turn the Switch S1 to ON. Power should now be supplied to the control panel, and the LEDs on MCB1 should follow the normal startup sequence (refer to [Power-up on page 48](#)).

Fan Start-up

1. Verify all duct isolation dampers are open. Unit mounted isolation dampers may be in the supply or return sections.
2. Place the unit into the Fan Only mode through the keypad menu *Main Menu\Quick Menu\Ctrl Mode = Fan*.
3. Turn Switch S7 to ON. The controller should enter the Startup Initial operating state. If the fan does not run:
 - a. Check fuses F1 and F3.
 - b. Check the manual motor protectors or that the circuit breakers have not tripped.
 - c. Check the optional phase monitor.
4. If the fans are equipped with optional spring isolators, check the fan spring mount adjustment. When the fans are running they should be level. Refer to [Spring Isolated Fans on page 40](#).
5. Verify the fan rotation is correct.
6. Verify the DHL safety is opening at a pressure compatible with duct working pressure limits.

NOTE: The supply and return fan drives usually are selected for operation in the drive's mid-speed range. The return fan drives are usually shipped with fixed pitch sheaves that will provide the selected fan speed; however, the supply fan drives are usually shipped with variable pitch sheaves that are adjusted to provide the minimum fan speed. Both drives should be adjusted for proper airflow during air balancing. See [Air Balancing on page 78](#).

Economizer Start-up

CAUTION

Adjust dampers properly. Improper adjustment can damage the dampers. When an economizer is ordered without an actuator, the linkage requires a 3.14" linear stroke to open it fully. Do not allow dampers to be driven beyond their normal full closed or full open position.

1. Check whether the outdoor air is suitable for free cooling by displaying the keypad menu *Main Menu View\Set Unit\ Econo Status*. See [OM 920](#) "Determining Economizer Status" section. **Low** indicates low outdoor air enthalpy; **High** indicates high outdoor air enthalpy. See [Enthalpy Control on page 62](#) to verify that the enthalpy changeover control is working properly. You may want to take temperature and humidity measurements.
2. At the keypad, set the cooling setpoint low enough so the controller calls for cooling. Adjust the value in *View\Set Unit\Cooling\Occ Clg Spt* below the temperature shown in *View\Set Unit\Temperatures\Control Temp*. In addition, on DAC units, adjust the value in *View\Set Unit\Cooling\DAT Clg Spt* below the temperature shown in *View\Set Unit\Temperatures\Discharge Temp*.
3. Place the unit into cooling mode through the keypad menu *Quick Menu\Ctrl Mode = Cool Only*.
4. Observe the outdoor air dampers:
 - a. If the outdoor enthalpy is low, the control algorithm should start to modulate the dampers open to maintain the discharge air setpoint.
 - b. If the outdoor enthalpy is high, the dampers should maintain their minimum position. Look at menu *View\Set Unit\Min OA Damper\Min OA Pos*. Change this entry to another value. Verify that the dampers move to the new minimum position setpoint.
5. If the unit is equipped with the electromechanical enthalpy changeover control (Honeywell H205) and the outdoor air condition is borderline, attempt to change its input to the MicroTech III controller by turning the switch adjustment to A or D. Check enthalpy status in keypad menu *Main Menu View\Set Unit\Econo Status*. See [OM 920](#) "Determining Economizer Status" section. If this reading is **Low**, go to Step 5a. If it is **High**, go to Step 5b.

NOTE: It may not be possible to check the economizer operation in both low and high enthalpy states on the same day. If this is the case, repeat this procedure on another day when the opposite outdoor air enthalpy conditions exist.

Heating System Startup

General

1. At the keypad, set the heating setpoints high enough so that the controller calls for heating. Adjust the value in *Main Menu View\Set Unit\Heating\Occ Htg Spt* = (above the temperature shown in) *Main Menu View\Set Unit\Temperatures\Control Temp*. In addition, on DAC units, adjust the value in *Main Menu View\Set Unit\Heating\DAT Htg Spt* above the temperature shown in *Main Menu View\Set Unit\Temperatures\Disch Temp*.
2. Place the unit into heating mode through the keypad menu *Main Menu\quick Menu\Ctrl Mode = Heat Only*.
3. Verify that the high ambient heat lockout temperature setpoint, *Main Menu\Commission Unit\Heating Setup\Htg Hi OAT Lk* is set above the current outside air temperature (shown in *Main Menu\View\Set Unit\Temperatures\OA Temp*).

Gas Furnace

Refer to the “Start-up and Operating Procedures” section of the Forced Draft Gas Fired Furnace Installation Manual, [IM 684](#) or [IM 685](#). Perform the start-up procedures given in it.

Electric Heat

Turn the electric heat switch HS1 to ON. The electric heaters should energize. If the unit has multistage electric heat, the MicroTech III Auxiliary Control board EHB1 should energize the heaters in successive stages. The rate of staging is set in keypad menu *Main Menu\Commission Unit\Heating Setup\Htg Stage Time*. The default value of “5 min” can be adjusted from 2 to 60 minutes.

Steam Heat

The steam valve actuator should open the valve. The steam valve is open when the valve stem is up. If the unit loses power, the spring in the actuator should drive the valve wide open. Check this by opening system switch S1.

Hot Water Heat

The hot water valve actuator should open the valve to the coil. The three-way hot water valve is open to the coil when the valve stem is down. If the unit loses power, the spring in the actuator should drive the valve wide open to the coil. Check this by opening system switch S1.

Air Balancing

WARNING

Moving machinery hazard. Can cause severe personal injury or death.

Do not use a mechanically driven tachometer to measure the speed of return fans on this fan arrangement. Use a strobe tachometer.

WARNING

Rotating parts can cause severe personal injury or death. Replace all belt/fan guards that are temporarily removed for service.

Air balancing should be performed by a qualified air balancing technician. Note that the supply fan motors are usually shipped with variable pitch sheaves which are typically set at the low end of the drive’s fan rpm range. See [Mounting and Adjusting Motor Sheaves on page 80](#). The return fan motors are usually shipped with fixed pitch sheaves.

The following should be performed as part of the air balancing procedure:

1. Check the operating balance with the economizer dampers positioned for both full outdoor air and minimum outdoor air.
2. Verify that the total airflow will never be less than that required for operation of the electric heaters or gas furnace.
3. For VAV units that have fan tracking control, adjust the supply/return fan balance by using the MicroTech III controller’s built-in, automatic capability. For complete information on using this feature, see [OM 920](#), MicroTech III Applied Rooftop Unit Controller.
4. When the final drive adjustments or changes are complete, check the current draw of the supply and return fan motors. The amperage must not exceed the service factor stamped on the motor nameplate.
5. Upon completion of the air balance, replace variable pitch motor sheaves (if any) with comparably sized fixed pitch sheaves. A fixed pitch sheave will reduce vibration and provide longer belt and bearing life.


Drive Belt Alignments

Sheave Alignment

Mounting:

1. Verify both driving and driven sheaves are in alignment and the shafts are parallel. The center line of the driving sheave must be in line with the center line of the driven sheave. See [Figure 94](#).
2. Verify that all setscrews are torqued to the values shown in [Table 21 on page 105](#) before starting drive. Check setscrew torque and belt tension after 24 hours of service.

Figure 94: Sheave Alignment (Adjustable Shown)



Drive Belt Adjustment


General Rules of Tensioning

1. The ideal tension is the lowest tension at which the belt will not slip under peak load conditions.
2. Check tension frequently during the first 24 – 48 hours of operation.
3. Over tensioning shortens belt and bearing life.
4. Keep belts free from foreign material which may cause slippage.
5. Inspect V-belts on a periodic basis. Adjust tension if the belt is slipping. Do not apply belt dressing. This may damage the belt and cause early failure.

Tension Measurement Procedure

1. Measure the belt span. See [Figure 95](#).
2. Place belt tension checker squarely on one belt at the center of the belt span. Apply force to the checker, perpendicular to the belt span, until the belt deflection equals belt span distance divided by 64. Determine force applied while in this position.
3. Compare this force to the values on the drive kit label found on the fan housing.

Figure 95: Drive Belt Adjustment



Mounting and Adjusting Motor Sheaves

CAUTION

Do not loosen any screws other than the two locking screws (**A**) in the outer locking ring. Before operating the drive, securely tighten these screws.

VM and VP Variable Pitch Sheaves

Mounting:

1. Mount all sheaves on the motor shaft with setscrew **A** toward the motor (Figure 96 on page 81).
2. Be sure both the driving and driven sheaves are in alignment and that the shafts are parallel.
3. Fit internal key **D** between sheave and shaft and lock setscrew **A** securely in place.

Adjusting:

1. Slack off all belt tension by moving the motor toward the driven shaft until the belts are free from the grooves. For easiest adjustment, remove the belts.
2. Loosen setscrews **B** and **C** in the moving parts of the sheave and pull out external key **E** (Figure 96). This key projects a small amount to provide a grip for removing.
3. Adjust the sheave pitch diameter for the desired fan speed by opening the moving parts by half or full turns from closed position. Do not open more than five full turns for **A** belts or six full turns for **B** belts. Adjust both halves of two-groove sheaves by the same number of turns from closed to ensure that both grooves have the same pitch diameter.
4. Replace external key **E** and securely tighten setscrews **B** over the key. Tighten setscrews **C** into the keyway in the fixed half of the sheave.
5. Put on belts and adjust the belt tension. Do not force belts over grooves. Loosen the belts by adjusting the motor base closer to the fan shaft.
6. Be sure that all keys are in place and that all setscrews are tight before starting the drive. Check the setscrews and belt tension after 24 hours of service.

LVP Variable Pitch Sheaves

Mounting:

1. For single-groove sheaves, slide the sheave onto the motor shaft so that the side of the sheave with setscrew **A** is next to the motor (Figure 97 on page 82).

For two-groove sheaves, slide the sheave onto the motor shaft so that the side of the sheave with setscrew **A** is away from the motor (Figure 97).
2. To remove the flange and locking rings:
 - a. Loosen setscrews **D**.
 - b. Loosen but do not remove capscrews **E**.
 - c. Remove key **F**. This key projects a small amount to provide a grip for removing.
 - d. Rotate the flange counterclockwise until it disengages the threads on the shaft barrel.
3. Be sure that the driving and driven sheaves are in alignment and the shafts are parallel. When aligning two-groove sheaves, allow room between the sheave and motor to get to capscrews **E**.
4. Insert key **C** between the sheave and the shaft and tighten setscrew **A** securely.

Adjusting:

1. Slack off all belt tension by moving the motor toward the driven shaft until the belts are free from the grooves. For easiest adjustment, remove the belts.
2. Loosen setscrews **D**.
3. Loosen but do not remove capscrews **E**.
4. Remove key **F**. This key projects a small amount to provide a grip for removing.
5. Adjust the pitch diameter by opening or closing the movable flange by half or full turns. Note that two-groove sheaves are supplied with both grooves set at the same pitch diameter. Both movable flanges must be moved the same number of turns to ensure the same pitch diameter for satisfactory operation. Do not open sheaves more than five turns for **A** belts or six turns for **B** belts.
6. Replace key **F**.
7. Tighten setscrews **D** and capscrews **E**.
8. Put on the belts and adjust the belt tension. Do not force belts over grooves. Loosen the belts by adjusting the motor base closer to the fan shaft.
9. Before starting the drive, make sure that all keys are in place and all setscrews and all capscrews are tight. Check and retighten all screws and re-tension the belts after approximately 24 hours of operation.

MVP Variable Pitch Sheaves

Adjusting:

1. Slack off belt tension by moving the motor toward the driven shaft until the belts are free from the grooves. For easiest adjustment, remove the belts.
2. Loosen both locking screws **A** in outer locking ring, but do not remove them from the sheave. There is a gap of approximately 1/2" (1 mm) between the inner and outer locking rings. This gap must be maintained for satisfactory locking of the sheave.

If locking screws **A** are removed by accident and the gap is lost, screw the outer locking ring down until it touches the inner locking ring. Then, back off the outer ring 1/2 to 3/4 turn until the inner and outer ring screw holes line up. Reinsert locking screws **A**, but do not tighten them until after adjustment is made.

3. Adjust the sheave to the desired pitch diameter by turning the outer locking ring with a spanner wrench. Any pitch diameter can be obtained within the sheave range. One complete turn of the outer locking ring will result in a 0.233" (6 mm) change in pitch diameter. Do not open **A-B** sheaves more than four 3/4 turns for **A** belts or 6 turns for **B** belts. Do not open **C** sheaves more than nine 1/2 turns.
4. Tighten both locking screws **A** in the outer locking ring.
5. Put on the belts and adjust the belt tension. Do not force belts over grooves. Loosen the belts by adjusting the motor base closer to the fan shaft.

Figure 96: VM and VP Variable Pitch Sheaves




Figure 97: LVP Variable Pitch Sleeves




Figure 98: MVP Variable Pitch Sheaves (Type A-B)





Figure 99: MVP Variable Pitch Sheaves (Type A-B)



⚠ CAUTION

If the unit has hot gas bypass on circuit #1 only, lead circuit must always be #1.

When all start-up procedures are completed, set the controls and program the MicroTech III controller for normal operation. Use the following list as a guide; some items may not apply to your unit. For more detail, see [IM 919](#) and [OM 920](#).

1. Turn system switch S1 to ON and S7 to AUTO.
2. Turn gas furnace switch S3 to AUTO or turn electric heat switch HS1 to ON.
3. Set the electromechanical (Honeywell H205) enthalpy control (OAE) as required (A, B, C, or D). Set the solid-state (Honeywell H705/C7400) enthalpy control (OAE/RAE) past D.
4. Set the heating and cooling parameters as required for normal unit operation.
 - a. *Main Menu\View\Set Unit\Cooling\Occ Clg Spt & DAT Clg Spt.*
 - b. *Main Menu\View\Set Unit\Heating\Occ Htg Spt & DAT Htg Spt.*
5. Set the low ambient compressor lockout setpoint as required in menu, *Main Menu\Commission Unit\Cooling Setup\Clg Lo Oat Lk* =. Do not set it below 50°F (10°C) unless the unit is equipped for low ambient operation.
6. Set the high ambient heat lockout temperature setpoint, *Main Menu\Commission Unit\Heating Setup\Htg Hi OAT Lk* as required.
7. Set the alarm limits as required in *Main Menu\Commission Unit\Alarm Configurations\Alarm Limits*.

8. Set the compressor lead/lag function as desired using keypad menu *Main Menu\Commission Unit\Cooling Setup\Lead Circuit and Main Menu\Commission Unit\Cooling Setup\Staging Type*. Refer to “Compressor Staging” in [IM 919](#) and [OM 920](#).
9. Set the duct static pressure control parameters as required in keypad menu *Airflow\Duct Pressure*.
10. Set the building static pressure control parameters as required in keypad menu
 - a. *Main Menu\View\Set Unit\RF/EF Control\Bldg SP Spt.*
 - b. If RF/EF Control = Tracking, then set the fan tracking parameters as required in keypad menu. *Main Menu\Commission Unit\RF/EF Setup\Sup Fan Max, RF @ SF Max, Sup Fan Min, RF @ SF Min.*
11. Set the economizer control parameters as required in keypad menu *Main Menu\View\Set Unit\Economizer\OAD/Econo Pos*.
12. Set the control timers as required in keypad menu *Main Menu\Commission Unit\Timer Settings*.
 - a. Set the date and time in keypad menu *Setup\Service\Time/Date*.
 - b. Set the operating schedule as required using keypad menus. *Main Menu\View\Set Unit\Date\Time\Schedules*.

NOTE: When used with a Building Automation System, these settings may need to be kept at the default of no schedule.

Maintaining Control Parameter Records

Daikin recommends that the MicroTech III controller's setpoints and parameters be recorded and saved for future reference. If the Microprocessor Control Board requires replacement, this record facilitates entering the unit's proper data. The following tables display all the setpoints, monitoring points, and program variables offered by MicroTech III plus the keypad road map used to find each parameter.

A number of menus and menu items that appear on the unit keypad/display are conditional and may not apply to a specific unit, depending on the unit software configuration. The unit software configuration is defined by a "Software Configuration Code" shown on a label located near the keypad/display. The Software Configuration Code also can be displayed via the six menu items in the Config Code menu on the unit keypad/display. Refer to [OM 920](#).

The shaded menus and menu items in [Figure 103](#) starting on [page 88](#) are conditional. A conditional menu or menu item includes a reference in [Figure 103](#) to the position in the Software Configuration Code upon which its applicability depends. For example, the Duct Pressure menu in [Figure 103](#) includes a notation [14=1 or 2]. This notation means that the Duct Pressure menu (and all its menu items) applies to the specific unit only if position 14 in its Software Configuration Code is a 1 or a 2. Otherwise, the menu or menu item is not applicable to the unit and does not affect its operation.

The items in [Figure 103](#) include the factory-set value for all adjustable items.

NOTE: Keep a record of any changes made to any of these items.

Using the Keypad/Display

The keypad/display consists of a 5-line by 22 character display, three keys and a “push and roll” navigation wheel. There is an Alarm Button, Menu (Home) Button, and a Back Button. The wheel is used to navigate between lines on a screen (page) and to increase and decrease changeable values when editing. Pushing the wheel acts as an Enter Button.

The first line on each page includes the page title and the line number to which the cursor is currently “pointing”. The line numbers are X/Y to indicate line number X of a total of Y lines for that page. The left most position of the title line includes an “up” arrow to indicate there are pages “above” the currently displayed items, a “down” arrow to indicate there are pages “below” the currently displayed items or an “up/down” arrow to indicate there are pages “above and below” the currently displayed page.


Each line on a page can contain status only information or include changeable data fields. When a line contains status only information and the cursor is on that line all but the value field of that line is highlighted meaning the text is white with a black box around it. When the line contains a changeable value and the cursor is at that line, the entire line is highlighted. Each line on a page may also be defined as a “jump” line, meaning pushing the navigation wheel will cause a “jump” to a new page. An arrow is displayed to the far right of the line to indicate it is a “jump” line and the entire line is highlighted when the cursor is on that line.

The keypad/display Information is organized into five main menus or menu groups; Alarm Lists Menu, System Summary Menu, Standard Menus, Extended Menus and Advance Menus.

NOTE: Only menus and items that are applicable to the specific unit configuration are displayed.

The Alarm Lists Menu includes active alarm and alarm log information. The System Summary Menu includes status information indicating the current operating condition of the unit. Standard Menus include basic menus and items required to setup the unit for general operation. These include such things as control mode, occupancy mode and heating and cooling setpoints. Extended Menus include more advanced items for “tuning” unit operation such as PI loop parameters and time delays. Advanced Menus include the most advanced items such as “unit configuration” parameters and service related parameters. These generally do not need changing or accessing unless there is a fundamental change to or a problem with the unit operation.

Figure 100: Keypad Controls



Passwords

When the keypad/display is first accessed, the Home Key is pressed, the Back Key is pressed multiple times, or if the keypad/display has been idle for the Password Timeout timer (default 10 minutes), the display will show a “main” page where the user can enter a password or continue without entering a password.

The three password levels available are Level 2, Level 4, and Level 6, with Level 2 having the highest level of access. Entering the Level 6 password allows access to the Alarm Lists Menu, System Summary Menu, and the Standard Menus group. Entering the Level 4 password allows similar access to Level 6 with the addition of the Extended Menus group. Entering the Level 2 password allows similar access to Level 4 with the addition of the Advanced Menu group. The Level 2 password is 6363, the Level 4 is 2526, and the Level 6 password is 5321.

Continuing without entering one of these three levels allows access only to the Alarm Lists Menu and the System Summary Menu.

NOTE: Alarms can be acknowledged without entering a password.

The password field initially has a value **** where each * represents an adjustable field. These values can be changed by entering the Edit Mode.

Entering an invalid password has the same effect as continuing without entering a password.

Once a valid password has been entered, the controller allows further changes and access without requiring the user to enter a password until either the password timer expires or a different password is entered. The default value for this password timer is 10 minutes. It is changeable from 3 to 30 minutes via the Timer Settings menu in the Extended Menus.

Figure 101: Password Main Page





Figure 102: Password Entry Page



Navigation Mode

In the Navigation Mode, when a line on a page contains no editable fields all but the value field of that line is highlighted meaning the text is white with a black box around it. When the line contains an editable value field the entire line is inverted when the cursor is pointing to that line.

When the navigation wheel is turned clockwise, the cursor moves to the next line (down) on the page. When the wheel is turned counter-clockwise the cursor moves to the previous line (up) on the page. The faster the wheel is turned the faster the cursor moves.

When the Back Button is pressed the display reverts back to the previously displayed page. If the Back button is repeated pressed the display continues to revert one page back along the current navigation path until the “main menu” is reached.

When the Menu (Home) Button is pressed the display reverts to the “main page.”

When the Alarm Button is depressed, the Alarm Lists menu is displayed.


Edit Mode

The Editing Mode is entered by pressing the navigation wheel while the cursor is pointing to a line containing an editable field. Once in the edit mode pressing the wheel again causes the editable field to be highlighted. Turning the wheel clockwise while the editable field is highlighted causes the value to be increased. Turning the wheel counter-clockwise while the editable field is highlighted causes the value to be decreased.

The faster the wheel is turned the faster the value is increased or decreased. Pressing the wheel again cause the new value to be saved and the keypad/display to leave the edit mode and return to the navigation mode.

The following is a description of the MicroTech III menu structure. These menus and items can all be displayed with the keypad/display. Menu items displayed will change based on the selected unit configuration. Refer to [OM 920](#) for more details.

Figure 103: Main Menu – Keypad/Display Menu Structure



Commission Unit	
Unit Set-Up	▶
Timer Settings	▶
SAF Set-Up	▶
RF/EF Set-Up	▶
Htg/Clg ChgOvr Set-Up	▶
Cooling Set-Up	▶
INV Cmp Set-Up	▶
Var Cmp Set-Up	▶
Econo Set-Up	▶
Min OA Set-Up	▶
Heating Set-Up	▶
OA Fan Set-Up	▶
Exp Valve Set-Up	▶
Defrost Set-Up	▶
Dehum Set-Up	▶
Energy Rec Set-Up	▶
Head Pressure Set-Up	▶
Evap Cond Set-Up	▶
D3 Set-Up	▶
Alarm Configuration	▶

For more detail go to:
page 92 — 95

Manual Control	
Manual Control= Normal	CFan Outpt 1= Off
Supply Fan= Off	CFan Outpt 2= Off
SAF Spd Cmd= 0%	CFan Outpt 3= Off
Manual Ctrl= Normal	BP/WR Valve= 0%
Supply Fan= Off	CW Valve= 0%
SAF Spd Cmd= 0%	ExhFan Out 1= Off
INV/OF Ena= Off	ExhFan Out 2= Off
INV Cmp= Off	ECond VFD= Off
INV Cmp Cmd= 0%	EC Dm Valve= Close
Comp 3= Off	Sump Pump= Off
OA Fan= Off	OA Fan Cmd= 0%
OA Fan Cmd= 0%	4 Way Valve= Off
4 Way Valve= Off	SV1= Off
RcvSol Valve=Off	SV2= Off
BP Sol Valve= Off	Gas Htg On/Off= Off
EVI Cmd= 0%	Htg Valve= 0%
EVO Cmd= 0%	SCR Out= 0%
RF/EF Fan= Off	F&BP Damper= 0%
RF/EF Spd Cmd= 0%	Htg Stg 1= Off
OAD/Econo= 0%	SCR Ena 1= Off
OAD OpCl= Close	Htg Stg 2= Off
Var Cmp= Off	SCR Ena 2= Off
Var Cmp Cmd= 0%	Htg Stg 3= Off
VCmp Emg Stop= Nrml	Htg Stg 4= Off
Comp 1= Off	Htg Stg 5= Off
Comp 2= Off	Htg Stg 6= Off
Comp 3= Off	Reheat Valve= 0%
Comp 4= Off	RH Output= Off
Comp 5= Off	LSCRH Valve= Off
Comp 6= Off	HGBP Valve= Off
Comp 7= Off	ERec Wheel= Off
Comp 8= Off	ER Whl Cmd= 0%
U1 Comp 1= Off	ERBP Dmpr Cl= Off
U1 Comp 2= Off	ERBP Dmpr Op= Off
U2 Comp 1= Off	Cond Wtr Pump= Off
U2 Comp 2= Off	Alm Output= Off
Cond Sol 1= Off	Fan Op Out= Off
Cond Sol 2= Off	


Service Menus	
Timer Settings	▶
Operating Hours	▶
Save/Restore Settings	▶
Active Alarms	▶
Alarm Log	▶
Alarm Configuration	▶
Analog Input Status	▶
Universal I/O Status	▶
Digital Input Status	▶
Digital Output Status	▶
Network Input Status	▶
Modbus Status	▶
D3 Status	▶
Sensor Offsets	▶
Reset Counter= XXXX	

For more detail go to:
page 96 — 99

Trending	
Trending Ena= No	
Apply Chgs= No	
Sample Time= 300s	
TrendOnOff= Off	
Export Data= No	
Clear Trend= Done	
Points 1-8 (Fixed)	▶
Points 9-24 (from List)	▶
Points 25-27 (with IDs)	▶
Points 28-30 (with IDs)	▶


For more detail go to:
page 100

Unit Maintenance	
Operating Hours	



This navigation map represents all possible AHU menus and menu items. Not all menus and items shown here will appear on the HMI display depending upon the specific unit configuration. Those that do not appear are not applicable to this unit.

Figure 118 continued: View/Set Unit – Keypad/Display Menu Structure







Figure 118 continued: Commission Unit – Keypad/Display Menu Structure




RF/EF Set-Up	
RF/EF Ctrl= Tracking	MinExStrtTm= 120s
Rem RAF Cap= 5%	MinExStopTm= 120s
Rem ExhF Cap= 5%	MinExOAPos= 5%
BSP DB= 0.01in	MinExSAFCap= 10%
BSP Period= 5s	ExhOnOAPos= 40%
BSP Gain= 0.2s	ExhMxOAPos= 100%
Max Spd Chg= 4%	Exh Stg 1 On= 40%
Sup Fan Max= 100%	Exh Stg 1 Off= 30%
RF @ SF Max= 95%	Exh Stg 2 On= 55%
Sup Fan Min= 30%	Exh Stg 2 Off= 40%
RF @ SF Min= 25%	Exh Stg 3 On= 70%
Lo Fan Diff= 75%	Exh Stg 3 Off= 50%
Hi Fan Diff= 75%	Max RF/EF Hz= 60Hz
RFEF Ctrl Dly= 30s	Max Vent Spd= 100%
Min Speed=	Max RFEF RPM= 2600
5% (with Exhaust Fan)	ECM Status= _____
33% (with Return Fan)	

Htg/Clg ChgOvr Set-Up
Ctrl Temp Src= RAT
AplyTstatchg= No
Use Tstat Spt= No
Occ Clg DB= 2.0°F
Clg Period= 60s
Clg Gain= 0.1
Clg PAT= 600s
Max Clg Chg= 5.0°F
Occ Htg DB= 2.0°F
Htg Period= 60s
Htg Gain= 0.1
Htg PAT= 600s
Max Htg Chg= 5.0°F
CalDRemSpt@10°C= No
CalDRemSpt@50°F= No
CalDRemSpt@30°C= No
CalDRemSpt@86°F= No
DemandShed= Ena
ClgDmdShdInc= 4°F
HtgDmdShdInc= 4°F
ClgShedRate= 2.0°F/hr
HtgShedRate= 2.0°F/hr


Cooling Set-Up
Clg Stage Time= 5min
Clg DB= 2.0°F
Clg Period= 20s
Clg Gain= 1
Clg PAT= 40s
CW Max Chg= 15%
Clg Lo OAT Lk=
55°F (RTU/SCU)
0°F (MPS)
25°F (DPS or RTU w/
VFD Cmps)
OAT Diff= 2.0°F
Min EWT= 55°F
Clg Reset= None
Min Clg Spt= 55.0°F
Min Clg Spt @= 0/NA
Max Clg Spt= 65.0°F
Max Clg Spt@= 100/NA
Lead Circuit= #1
Staging Type= Std
CFanOut1 Spt= 55°F
CFanOut2 Spt= 65°F
CFanOut3 Spt= 75°F
Cond Fan Diff= 5°F
Unocc Diff= 3°F
DT Above Spt= _____
DT Below Spt= _____



Min OA Set-Up		
AplyMinOACHg= No (Uses	CFM RESET	FAN SPEED RESET
MinOAT Type Instance Name)	OA Flow= XXXXXCFM	Min Fan Diff= 20%
Min OA Reset= None	MinOAFWSpT= 2000CFM	Max Fan Diff= 50%
BSPOAOvrd= No	Field Stn Rst= No	Min Clg Spd= 40%
RstLmtSnsr= None	Field Stn Cfg= VDC	Des Clg Spd= 100%
EXTERNAL RESET	Min CFM= 0 CFM	BSP RESET
OA @ MinV/mA= 0%	Max CFM= 10000 CFM	MinRFEFTm= 120s
OA @ MaxV/mA= 100%	V/A @Min CFM= 0.0/V	BSP OvdST= 5s
Min V/mA= 0.0/V	V/A @Max CFM= 10.0/V	BSP OvdGain= 0.2
Max V/mA= 10.0/V	OA CFM DB= 3%	BSP OvdMaxChg= 4%
CO ₂ RESET	OA CFM Period= 30s	DAMPER LIMITING
IAQ Reset= Yes	OA CFM Gain= 0.1	RstTLmt= 32.0°F
PPM@DCVlmt= 800PPM	OA CFM Max Chg= 5%	RstTSmplTm= 5s
PPM@VntLmt= 1000PPM	Design Flow= Yes	RstTGain= 0.2
IAQ PPM= XXXXPPM	Des Flo DB= 3%	RstPAT= 60s
Min PPM= 0 PPM	DF Period= 30s	RstTMaxChg= 4%
Max PPM= 2000 PPM	Des Flo Gain= 0.1	0-30% OA Max= 30%
V/A @Min PPM= 0.0/V	DF Max Chg= 5%	Min Inc Rate= 0.03
V/A @Max PPM= 10.0/V	RH Lvl Pos= _____	Max Inc Rate= 1.0
	LH Lvl Pos= _____	



This navigation map represents all possible AHU menus and menu items. Not all menus and items shown here will appear on the HMI display depending upon the specific unit configuration. Those that do not appear are not applicable to this unit.



Figure 118 continued: Commission Unit (part 2) – Keypad/Display Menu Structure





This navigation map represents all possible AHU menus and menu items. Not all menus and items shown here will appear on the HMI display depending upon the specific unit configuration. Those that do not appear are not applicable to this unit.

Figure 118 continued: Service Menu – Keypad/Display Menu Structure



This navigation map represents all possible AHU menus and menu items. Not all menus and items shown here will appear on the HMI display depending upon the specific unit configuration. Those that do not appear are not applicable to this unit.

Alarm Log	
Log Count: xx Clr Log= No	▶
+/-Alarm 1: Alarm Type	▶
+/-Alarm 2: Alarm Type	▶
•	
•	
•	
+/-Alarm 10: Alarm Type	▶
•	
•	
•	
+/-Alarm 50: Alarm Type	▶

Alarm Configuration	
ALARM LIMITS	
Hi Disch Temp=	170°F
Lo Disch Temp=	40°F
Hi Return Temp=	120°F
ALARM OUT CONFIG	
Faults=	Fast
Problems=	Slow
Warnings=	Off
ALARM DELAYS	
Frz Delay Time=	30s
LP Delay=	2s
LP Comp Delay=	5s
Air Flw Ing=	120s
Sens Alm Dly=	30s
Temp AlmDly=	30s
ALARM CONFIG	
Emerg Stop=	ManClr

3, 4 See connection on page 99

4



Analog Input Status	
MCB AI1=	XXXXXXXX
MCB AI2=	XXXXXXXX
MCB AI3=	XXXXXXXX

Universal I/O Status			
MCB X1=	XXXXXXXX	EMC X1=	XXXXXXXX
MCB X2=	XXXXXXXX	EMC X2=	XXXXXXXX
MCB X3=	XXXXXXXX	EMC X3=	XXXXXXXX
MCB X4=	XXXXXXXX	EMC X4=	XXXXXXXX
MCB X5=	XXXXXXXX	EMC X5=	XXXXXXXX
MCB X6=	XXXXXXXX	EMC X6=	XXXXXXXX
MCB X7=	XXXXXXXX	EMC X7=	XXXXXXXX
MCB X8=	XXXXXXXX	EMC X8=	XXXXXXXX
EMA X1=	XXXXXXXX	EMD X1=	XXXXXXXX
EMA X2=	XXXXXXXX	EMD X2=	XXXXXXXX
EMA X3=	XXXXXXXX	EMD X3=	XXXXXXXX
EMA X4=	XXXXXXXX	EMD X4=	XXXXXXXX
EMA X5=	XXXXXXXX	EMD X5=	XXXXXXXX
EMA X6=	XXXXXXXX	EMD X6=	XXXXXXXX
EMA X7=	XXXXXXXX	EMD X7=	XXXXXXXX
EMA X8=	XXXXXXXX	EMD X8=	XXXXXXXX
EMB X1=	XXXXXXXX	EME X1=	XXXXXXXX
EMB X2=	XXXXXXXX	EME X2=	XXXXXXXX
EMB X3=	XXXXXXXX	EME X3=	XXXXXXXX
EMB X4=	XXXXXXXX	EME X4=	XXXXXXXX
EMB X5=	XXXXXXXX	EME X5=	XXXXXXXX
EMB X6=	XXXXXXXX	EME X6=	XXXXXXXX
EMB X7=	XXXXXXXX	EME X7=	XXXXXXXX
EMB X8=	XXXXXXXX	EME X8=	XXXXXXXX

Digital Input Status	
MCB DI1=	_____
MCB DI2=	_____
MCB DI3=	_____
MCB DI4=	_____
MCB DI5=	_____
MCB DI6=	_____
EMD DLA1=	_____

Digital Output Status			
MCB DO1=	_____	EMC DO1=	_____
MCB DO2=	_____	EMC DO2=	_____
MCB DO3=	_____	EMC DO3=	_____
MCB DO4=	_____	EMC DO4=	_____
MCB DO5=	_____	EMC DO5=	_____
MCB DO6=	_____	EMC DO6=	_____
MCB DO7=	_____	EMD DO1=	_____
MCB DO8=	_____	EMD DO2=	_____
MCB DO9=	_____	EMD DO3=	_____
MCB DO10=	_____	EMD DO4=	_____
EMA DO1=	_____	EMD DO5=	_____
EMA DO2=	_____	EMD DO6=	_____
EMA DO3=	_____	EME DO1=	_____
EMA DO4=	_____	EME DO2=	_____
EMA DO5=	_____	EME DO3=	_____
EMA DO6=	_____	EME DO4=	_____
EMB DO1=	_____	EME DO5=	_____
EMB DO2=	_____	EME DO6=	_____
EMB DO3=	_____		
EMB DO4=	_____		
EMB DO5=	_____		
EMB DO6=	_____		

Figure 118 continued: Service Menu (part 2) – Keypad/Display Menu Structure



This navigation map represents all possible AHU menus and menu items. Not all menus and items shown here will appear on the HMI display depending upon the specific unit configuration. Those that do not appear are not applicable to this unit.

Figure 118 continued: BMS Communications – Keypad/Display Menu Structure





Figure 118 continued: Trending – Keypad/Display Menu Structure



Maintenance Installation and maintenance must be performed only by qualified personnel who are experienced with this type of equipment and familiar with local codes and regulations.

CAUTION

Sharp edges are inherent to sheet metal parts, screws, clips, and similar items. May cause personal injury. Exercise caution when servicing equipment.

WARNING

Moving machinery and electrical power hazards. Can cause severe personal injury or death. Disconnect and lock off all power before servicing equipment

DANGER

Hazardous voltage. Can cause severe injury or death. Disconnect electric power before servicing equipment. More than one disconnect may be required to de-energize the unit.

Servicing Control Panel Components

Disconnect all electric power to the unit when servicing control panel components. Before servicing, always inspect units for multiple disconnects to ensure all power is removed from the control panel and its components.

Planned Maintenance

Preventive maintenance is the best way to avoid unnecessary expense and inconvenience. Have this system inspected at regular intervals by a qualified service technician. The required frequency of inspections depends upon the total operating time and the indoor and outdoor environmental conditions. Routine maintenance should cover the following items:

- Tighten all belts, wire connections, and setscrews
- Clean all mechanically or with cold water, if necessary. Usually any fouling is only matted on the entering air face of the coil and can be removed by brushing
- Lubricate the motor and fan shaft bearings
- Align or replace the belts as needed
- Clean or replace the filters as needed
- Check for proper superheat
- Check for proper subcooling

NOTE: Check each circuit's refrigerant sightglass when the circuit is operating under steady-state, full load conditions at or above 70°F ambient. The sightglass should then be full and clear. If not, check for refrigerant leaks.

A partially full sightglass is not uncommon at part load conditions.

Do not use each circuit's refrigerant sightglass to indicate proper charge

The sightglass is to be used for moisture indication only.

- Check for blockage of the condensate drain. Clean the condensate pan as needed
- Check the power and control voltages
- Check the running amperage of all motors
- Check all operating temperatures and pressures
- Check and adjust all temperature and pressure controls as needed
- Check and adjust all damper linkages as needed
- Check the operation of all safety controls
- Examine the gas furnace (see [IM 684](#) or [IM 685](#))
- Lubricate the door latch mechanisms

Unit Storage

Location

The Daikin Applied Rooftop Airhandling Unit is an outdoor unit. However, the schedule may dictate storage either on the ground or in its final position at the site. If the unit is stored on the ground, additional precautions should be taken as follows:

- Make sure that the unit is well supported along the length of the base rail
- Make sure that the unit is level (no twists or uneven ground surface)
- Provide proper drainage around the unit to prevent flooding of the equipment
- Provide adequate protection from vandalism, mechanical contact, etc
- Make sure all doors are securely closed
- If isolation dampers are provided, verify that they are properly installed and fully closed to prevent the entry of animals and debris through the supply and return air openings
- Units without isolation dampers should be fitted with covers over the supply and return air openings

Preparation

Supply (and Return) fans

1. Move the motor base to check and lubricate slides and leadscrews.
2. Remove the drive belts, tag them with the fan name and unit serial number, and store them in a conditioned space out of direct sunlight.
3. Turn supply and return fan Manual Motor Protectors (MMPs) to the OFF position.
4. Once every month, rotate the fan and motor shafts. Mark the shaft positions first to make sure they stop in a different position.
5. Depending on local climatic conditions, condensate may collect on components inside the units. To prevent surface rust and discoloration, spray all bare metal parts with a rust preventive compound. Pay close attention to fan shafts, sheaves, bearings, and bearing supports,

Cabinet Sections

Once a month, open a door on each section and verify that no moisture or debris is accumulating in the unit.

Gas Furnace

If the unit is equipped with a gas furnace, close the gas shutoff valve and open furnace control switch S3.

Control Compartment

1. Daikin Applied International recommends that the electronic control equipment in the unit be stored in a 5% to 95% RH (non-condensing) environment.
2. It may be necessary to put a heat source (light bulb) in the main control panel to prevent the accumulation of atmospheric condensate within the panel.
3. The location and wattage of the heat source is dependent on local environmental conditions.
4. Check the control compartment every two weeks to provide that the heat source is functional and is adequate for current conditions.

Restart

After extended storage, perform a complete start up. Inevitable accumulations of dirt, insect nests, etc. can contribute to problems if not cleaned out thoroughly prior to start up. In addition, thermal cycling tends to loosen mechanical and electrical connections. Following the startup procedure helps discover these and other issues that may have developed during the storage interval.

Gas Furnace

For information on maintenance of the gas furnace, refer to [IM 684](#) or [IM 685](#).

Bearing Lubrication

CAUTION

Bearing overheating potential. Can damage the equipment. Do not overlubricate bearings. Use only a high grade mineral grease with a 200°F safe operating temperature. See below for specific recommended lubricants.

Motor Bearings

Supply and return fan motors should have grease added after every 2000 hours of operation. Using the following procedure, relubricate the bearings while the motor is warm, but not running. Use one of the greases shown in Table 14.

1. Remove and clean upper and lower grease plugs.
2. Insert a grease fitting into the upper hole and add clean grease (Table 14) with a low pressure gun.
3. Run the motor for five minutes before replacing the plugs.

NOTE: Specific greasing instructions are located on a tag attached to the motor. If special lubrication instructions are on the motor, they supersede all other instructions.

Table 14: Recommended Lubricants and Amounts for Fan Motor Bearings

Mfr. Grease	NEMA Size	Amount to Add (oz.)
	56 to 140	0.08
Texaco, Polystar or	140	0.15
	180	0.19
Polyrex EM (Exxon Mobile) or	210	0.30
	250	0.47
Rykon Premium #2 or	280	0.61
	320	0.76
Penzoil Pen 2 Lube	360	0.81
	400	1.25
	440	2.12

Fan Shaft Bearings

CAUTION

For safety, stop rotating equipment. Add one half of the recommended amount shown in Table 17. Start bearing, and run for a few minutes. Stop bearing and add the second half of the recommended amount. A temperature rise, sometimes 30°F (19°C), after relubrication is normal. Bearing should operate at temperature less than 200°F (94°C) and should not exceed 225°F (107°C) for intermittent operation. For a relubrication schedule, see Table 15. For any applications that are not in the ranges of the table, contact Daikin Applied.

CAUTION

Table 14, Table 15 and Table 16 state general lubrication recommendations based on our experience and are intended as suggested or starting points only. For best results, specific applications should be monitored regularly and lubrication intervals and amounts adjusted accordingly.

Any good quality lithium or lithium complex base grease, using mineral oil, conforming to NLGI grade 2 consistency, and an oil viscosity of 455-1135 SUS at 100°F (100-200 cSt at 40°C) may be used for relubrication.

Compatibility of grease is critical. Relubricatable Browning bearings are supplied with grease fittings or zerks for ease of lubrication with hand or automatic grease guns. Always wipe the fitting and grease nozzle clean.

Table 15: Relubrication Intervals

(Use NLGI #2 Lithium or Lithium Complex Grease)			
Speed	Temperature	Cleanliness	Relub. intervals
100 rpm	Up to 120°F (50°C)	Clean	6 to 12 months
500 rpm	Up to 150°F (65°C)	Clean	2 to 6 months
1000 rpm	Up to 210°F (100°C)	Clean	2 weeks to 2 months
1500 rpm	Over 210°F (100°C) to 250°F (120°C)	Clean	Weekly
Above 1500 rpm	Up to 150°F (65°C)	Dirty/wet	1 week to 1 month
Max catalog rating	Over 150°F (65°C) to 250°F (120°C)	Dirty/wet	Daily to 2 weeks
	Above 250°F (120°C)		Contact Browning

Table 16: Recommended Lubricants for Fan Shaft Ball Bearings

Name	Temperature	Base	Thickener	NLGI grade
Texaco, Premium RB	30° to 350°F (34° to 177°C)	Parafinic mineral oil	Lithium	2
Mobile, AW2	40° to 437°F (40° to 175°C)	Mineral oil	Lithium	2
Mobile, SHC 100	68° to 356°F (50° to 180°C)	Synthetic	Lithium	2
Chevron, Altplex Synthetic	60° to 450°F (51° to 232°C)	Synthetic	Lithium	2
Exxon, ronex MP	40° to 300°F (40° to 149°C)	Mineral oil	Lithium	2

NOTE: Temperature ranges over 225°F are shown for lubricants only. High temperature applications are not suitable for standard air handler components.

Table 17: Recommended Fan Relubrication Grease Charge

Shaft Size, inches (mm)	OZ. (grams)
1/2 to 3/4 (20)	0.03 (0.85)
7/8 to 1-3/16 (25–30)	0.10 (2.84)
1-1/4 to 1-1/2 (35–40)	0.15 (4.25)
1-11/16 to 1-15/16 (45–50)	0.20 (5.67)
2 to 2-7/16 (55–60)	0.30 (8.51)
2-1/2 to 2-15/16 (65–70)	0.50 (15.59)
3 to 3-7/16 (75–80)	0.85 (24.10)
3-1/2 to 4 (85–105)	1.50 (42.53)

Table 18: Shaft Size Tolerances

Shaft Size (in)	Tolerance
1-11/16 to 2-7/16	+0 to -0.0015
2-7/16 and up	+0 to -0.002

Bearing Replacement

CAUTION

The following instructions must be read in entirety before attempting installation or removal. The procedures indicated should be carefully followed. Failure to do so can result in improper installation which could cause bearing performance problems as well as serious personal injury.

Bearings in Bolt-On Housings (Units)

1. Check area - Clean and organize bearing installation area and keep well lit. Be sure mounting surfaces are clean and flat.
2. Check shaft - Shaft should be within tolerance range shown in [Table 18](#), clean, and free of nicks and burrs. Mount bearing on unused section of shafting or repair/replace shafting as required.
3. Install unit - Slide unit onto shaft. If it is difficult to mount bearing on shaft, use a piece of emery cloth to reduce any high spots on shaft. Do not hammer on any component of the bearing.
4. Fasten unit in place - Install housing mounting bolts, check and align bearing and tighten mounting bolts to recommended fastener torques. Exercising extreme caution and safety, rotate shaft slowly to center bearing.

BOA Concentric Inserts

1. Be sure that BOA Concentric collar is fitted square and snug against the shoulder on the inner ring.
2. Torque BOA Concentric collar cap screw to torque recommended in [Table 19](#).

Monitor Installed Bearing

After bearing has been run for several minutes, and again after several hours, check bearing for excessive noise or vibration. Shutdown machine and check housing temperature: typical applications operate at 100°F–105°F (38°C–66°C). Tighten all locking devices after 500 hours or 3 months, whichever comes first.

Table 19: Recommended Torque Values for Concentric Locking Bearing/Shaft Size

Fan Size (in)	Bore Size (in)	Torx Screw Size	In lbs.
27 (AF)/40 & 49 (SWSI)	2-3/16	T-30	180
30 & 33 (AF)/44 (SWSI)	2-7/16	T-45	400
36 (AF)	2-11/16	T-45	400
40 (AF)	2-15/16	T-45	400

NOTE: AF = DWDI AF, SWSI = AF Plenum Fan

Propeller Exhaust

For information, see [Propeller Exhaust Fan Option on page 70](#).

Vibration Levels

Each unit as shipped is trim balanced to operate smoothly. To provide satisfactory operation after shipping and installation, use accepted industry guidelines for field balancing fans. See [Table 20](#).

NOTE: Excessive vibration from any cause contributes to premature fan and motor bearing failure. Monitor overall vibration levels every six months of operation. An increase in levels is an indication of potential trouble.

Table 20: Vibration Levels

Fan speed (RPM)	Vibration
800 or less	5 mils maximum displacement
801 or greater	0.20 in/sec maximum velocity

Vibration Causes

1. Wheel imbalance.
 - a. Dirt or debris on wheel blades.
 - b. Loose setscrews in wheel hub or bearing-to-shaft.
 - c. Wheel distorted from overspeed.
2. Bent shaft.
3. Faulty drive.
 - a. Variable pitch sheaves—Axial and radial runout of flanges; uneven groove spacing; out of balance. Also similar faults in driven sheave.
 - b. Bad V-belts; lumpy, or mismatched; belt tension too tight or too loose.
4. Bad bearings, loose bearing hold-down bolts.
5. Motor imbalance.
6. Fan section not supported evenly on foundation.

Periodic Service and Maintenance

1. Check all moving parts for wear every six months.
2. Check bearing collar, sheave, wheel hub setscrews, sheave capscrews, and bearing hold-down bolts for tightness every six months.

Setscrews

Setscrews are used to lock bearings, sheaves, locking collars, and fan wheels to their shafts. They must be checked periodically to see that they have not loosened. If this is not done, severe equipment damage could occur.

Refer to [Table 21](#) and check the tightness of all setscrews with a torque wrench. Note that if the return fan bearings setscrews must be retightened, a special procedure is required to equally load both bearings (see “Return Fan Bearing Setscrews”).

Return Fan Bearing Setscrews


Because the return fan is mounted on a vertical shaft, the following procedure must be used to retighten any return fan bearing setscrews that have loosened. This procedure will provide that both bearings are equally loaded. If one bearing is carrying the entire weight of the fan, it could fail prematurely.

1. Loosen the fan belts.
2. Support the weight of the fan and the fan shaft with timbers or some other suitable means (see the fan shaft support in [Figure 104](#)). Important: To maintain proper drive alignment and fan-to-tunnel clearance, the fan and shaft must not drop at all when the setscrews are loosened in Step 4.
3. Verify that the upper shaft collar is securely fastened to the shaft. Check the setscrew torque.
4. Loosen the upper and lower bearing setscrews. The entire weight of the fan and shaft is now supported by the fan shaft support.
5. Retighten all bearing setscrews to the torque specification given in [Table 21](#). Remove the fan shaft support and re-tension the belts.

Table 21: Setscrew Minimum Torque Specifications

Setscrew diameter (in.)	Minimum torque (ft.lb)
1/4	5.5
5/16	10.5
3/8	19.0
7/16	29.0
1/2	42.0
5/8	92.0

Figure 104: Return Fan Assembly



Supply Fan Wheel-to-Funnel Alignment

If the unit is equipped with an airfoil or backward curved supply fan, the fan wheel-to-funnel alignment must be as shown in Figure 105, Figure 106, Figure 107, Figure 108 and Figure 109 to obtain proper air delivery and operating clearance. If necessary, adjustments are made as follows:

1. Verify that the fan shaft has not moved in its bearings.
2. Loosen the fan hub setscrews and move the wheel(s) along the shaft as necessary to obtain the correct dimension shown in Table 22, Table 23 and Table 24.
3. Retighten the setscrews to the torque specification given in Table 21 on page 105. Tighten the setscrews over the keyway first; tighten those at 90 degrees to the keyway last.
4. Verify that the radial clearance around the fan is uniform. Radial clearance can be adjusted by slightly loosening the funnel hold-down fasteners, shifting the funnel as required, and retightening the fasteners.

Figure 105: 20" DWDI Airfoil Wheel-to-Funnel




Figure 106: 24" DWDI Backward Curved Wheel-to-Funnel (036C, 040C)




Figure 107: 27 to 40" DWDI Airfoil Wheel-to-Funnel Alignment




Figure 108: 40" SWSI Airfoil Wheel-to-Funnel Alignment




Figure 109: 44" and 49" SWSI Airfoil Wheel-to-Funnel Alignment




Table 22: 27 to 40" DWDI Airfoil Wheel-to-Funnel Relationship

Wheel Diameter (inches)	"A" +0.3/ - 0.0 (in, (mm))
27	9.9 (246)
30	10.6 (269)
33	11.7 (297)
36	13.1 (333)
40	14.5 (368)

Table 23: SWSI Airfoil Wheel-to-Funnel Relationship

Wheel Diameter (inches)	"A" (in, (mm))
40	0.62 (15.7 mm)

Table 24: 44" and 49" SWSI airfoil wheel-to-funnel

Wheel Diameter (inches)	"A" (in, (mm))
44	16.21 (412)
49	17.81 (452)

Winterizing Water Coils

Coil freeze-up can be caused by such things as air stratification and failure of outdoor dampers and/or preheat coils. Routine draining of water cooling coils for winter shutdown cannot be depended upon as insurance against freeze-up. Severe coil damage may result. It is recommended that all coils be drained as thoroughly as possible and then treated in the following manner.

- Fill each coil independently with an antifreeze solution using a small circulating pump and again thoroughly drain
- Check freezing point of antifreeze before proceeding to next coil. Due to a small amount of water always remaining in each coil, there will be a diluting effect. The small amount of antifreeze solution remaining in the coil must always be concentrated enough to prevent freeze-up

NOTE: Carefully read instructions for mixing antifreeze solution used. Some products have a higher freezing point in their natural state than when mixed with water.

Manual Motor Protector (MMP)

WARNING

Warnings indicate potentially hazardous situations, which can result in property damage, severe personal injury, or death if not avoided.

The manual motor protector (MMP) provides coordinated branch circuit, short circuit protection, a disconnecting means, a motor controller, and coordinated motor overload protection. A short circuit indicator with manual reset is mounted along side of each MMP as a means to differentiate between a short circuit and overload trip conditions.

The MMP trip points are factory set. Do not change unless the motor ampacity changes or the MMP is replaced with a new device with incorrect setpoint adjustment. Any other non-authorized trip point or setpoint adjustment voids all or portions of the unit's warranty. Authorized setpoint adjustment is accomplished as follows

1. For motors with a 1.15 service factor, rotate the arrow on the dial to correspond to the motor FLA.
2. For motors with a 1.0 service factor, multiply the motor FLA by 0.9; then rotate the arrow on the dial to correspond to that value.

To reset a tripped MMP, clear the trip by rotating the knob counterclockwise to the OFF (O) position; then rotate knob clockwise to the ON (I) position. See [Figure 110](#).

Other MMP Features:

- Three-position rotary operator: OFF (O)-TRIP-ON (I) ([Figure 110](#))
- Lockout—tagoutable rotary operator: turn the rotary operator to OFF (O), slide out the extension arm, and insert a lockout pin
- Ambient compensated -20°C to +40°C
- Single-phase sensitivity: if one phase exceeds setpoint, all three phases open
- Trip test: insert a 9/64" screw driver in the test slot ([Figure 110](#)) to simulate a trip

Figure 110: Manual Motor Protector



Circuit Breaker

⚠ CAUTION

If a breaker is tripped, the handle/lever will be halfway between the OFF and ON positions. To reset a tripped circuit breaker:

⚠ WARNING

If a circuit breaker has tripped due to an overload or a fault current (short circuit), prior to resetting, the connected wiring circuits must be checked to determine the cause of the interruption.

Circuit breakers are installed upstream of all VFDs to provide short circuit protection. These breakers are not adjustable.

To reset a tripped circuit breaker: Clear the trip by rotating the lever down to the OFF position (see [Figure 111](#)). Then rotate lever up to the ON position ([Figure 111](#)).

Breakers, like MMPs, have three distinct modes of operation which are clearly indicated by the handle position. The positions are ON (usually up, OFF (usually down), and TRIPPED (midway). Some circuit breakers may have a push-to-test button.

1. Press the handle or rotate the lever to the OFF position.
2. Press the handle or rotate the lever the opposite direction to the ON position.

Figure 111: Circuit Breaker




Field Wiring Terminals

All field wiring terminals are spring clamp type, which offer several advantages over traditional screw-type terminals:

- Spring connections do not require torquing
- Spring connections resist failure due to vibration
- Easily identifiable terminal markers
- Combination spring release and square test ports Wire connections require inserting (“1” in [Figure 112](#) a stripped wire a round port and clamping the stripped wire by inserting a flat-bladed screw driver in the adjacent square port (“2” in [Figure 112](#))

Figure 112: Terminal Connectors



Phase Voltage Monitor (PVM)

The phase voltage monitor (Figure 113) is designed to protect three-phase loads from damaging power conditions. A microprocessor-based voltage and phase sensing circuit constantly monitors the three-phase voltages to detect harmful power line conditions. When a harmful condition is detected, its output relay is deactivated after a specified trip delay (Trip Delay). The output relay reactivates after power line conditions return to an acceptable level for a specified amount of time (Restart Delay). The trip and restart delays prevent nuisance tripping due to rapidly fluctuating power line conditions.

There are two LEDs on the face of the PVM (“1” in Figure 113) to indicate the following:


Table 25: LED Indication

Status	LED Indicator
Normal operation, no faults, relay energized	Green LED - steady on
Loss of input phase (relay de-energized)	Red LED - flash twice, OFF, flash twice, OFF, etc.
Voltage unbalance (relay de-energized)	Red LED - flash twice, OFF, flash twice, OFF, etc.
High or low voltage (relay de-energized)	Red LED - steady ON
Phase reversal (relay de-energized)	Red LED - pulse ON, OFF, ON, OFF, etc.
Restart delay (fault cleared, PVM pending restart, relay de-energized)	Green LED - pulse ON, OFF, ON, OFF, etc.

Other features:

- Standard 2% to 8% variable voltage unbalance (“3” in Figure 113)
- Standard 1 to 500 second variable restart delay (“2” in Figure 113)
- Standard 1 to 30 second trip delay (“4” in Figure 113) (except loss of phase, which trips at 1 second nonadjustable)

Figure 113: Phase Voltage Monitor



Disconnect

⚠ DANGER

Hazardous voltage. Will cause severe injury or death. Disconnect electric power before servicing equipment. More than one disconnect may be required to de-energize the unit.

⚠ CAUTION

Molded case switches do not provide over-current protection. This device may automatically open the circuit at levels above the ampere rating of the switch.

The optional disconnect is a “through-the-door” molded case switch with similar features of the circuit breaker. The “through-the-door” feature provides a safety interlock that disables power when an inexperienced person opens the control panel door. This is not the normal recommended method to access the control panel or to disable power to an operating unit.

Depending on the desired operating state of the unit, four different recommended methods can be utilized to access the control panel or to disable power.

1. Recommended method to access the controls through the “release” method (defeats the mechanical interlock and allows the control panel door to open without disconnecting power - switch is in the power “ON” position):
 - a. Obtain a small standard head screwdriver.
 - b. Insert the head of the screwdriver into the slotted “release” located on the right hand side of the disconnect faceplate (Figure 115). Turn the release counter-clockwise.
 - c. Pull open the door after the mechanical interlock is released.
2. Recommended normal method to turn OFF an operating unit (no emergency condition present):
 - a. Follow the “release” method described above.
 - b. Use the pump down switch to turn OFF the unit.
 - c. The controls will then shut the liquid line solenoids, pump the refrigerant into the condenser, and turn OFF the compressors.
3. Recommended method to “Lock OFF” power while the disconnect is OFF:
 - a. Rotate the handle to the “Reset Lock” position.
 - b. Manually push in the lockout mechanism into the slot on the faceplate.
 - c. Insert a padlock into the lockout hole located on the disconnect handle.
 - d. Test rotate the handle to insure that power “lockout” is provided.

4. Recommended normal method to “restore” power to a unit that is locked out:
 - a. Unlock and remove the padlock when it is safe (doors are shut, no personnel are within reach of the condensing unit or are inside the air handler).
 - b. Shut the control panel door and ensure the interlock mechanism is operable.
 - c. Rotate the handle to the “ON” position.

Figure 114: Through-the-door Handle Disconnect



Figure 115: Interlock Bypass



Pressure Sensors

The MicroTech III controller uses 0 to 5" W.C. static pressure transducers for measuring duct static pressure. As the duct static pressure varies from 0-5" W.C., the transducer output will vary from 4-20mA. The transducer output signal is 4- 20mA however the signal entering the VFD is converted to a DC signal via a 500 Ohm resistor across the output signal at the transducer.

If building static pressure control is provided, a -0.25" W.C. to 0.25" W.C. static pressure transducer is used. As the building static pressure varies from -0.25" W.C. to 0.25" W.C., the transducer output will vary from 4-20mA. The transducer output signal is 4-20mA however the signal entering the VFD is converted to a DC signal via a 500 Ohm resistor across the output signal at the transducer.

Troubleshooting Pressure Transducers

Use the following procedure to troubleshoot a suspect sensor:

- If the duct static pressure always reads 0" WC on the unit keypad/display and the VFD speed is continuously ramping to 100%, check the following:
 - If the unit has two duct static pressure sensors (SPS1 and SPS2), verify that they both function properly per the following procedure. Also check for faulty wiring connections at the VFD analog inputs
 - The controller displays and controls to the lower of the two readings. If a sensor is defective and inputs 0 volts to the VFD, the static pressure reading on the keypad/display reads 0 and the controller attempts to increase the 0 value to set point by ramping the VFD up
 - If a second sensor (SPS2) is not installed or the pressure tubing to it is not connected, make sure the 2nd DSP Sensor= parameter in the Unit Configuration menu of the keypad/ display is set to "No" so that the controller ignores the second static pressure analog input
 - If a second sensor (SPS2) is installed, make sure the 2nd DSP Sensor= parameter in the Unit Configuration menu of the keypad/display is set to "Yes"
 - Check the 24 V (dc) power supply to the sensor, verify that there is 24 V (dc) between the suspect transducer "+" and "-" terminals
- Using an accurate manometer or gauge, measure the same pressure that the suspect transducer is sensing. To do this, tap into the transducer high and low pressure tubing or locate the measurement device taps next to the transducer taps
- If the suspect sensor is measuring duct static pressure, verify that the high and low pressure taps are properly installed. An improper pressure tap installation can cause severe fluctuations in the sensed pressure. Refer to the model-specific installation manual for pressure tap installation guidelines
- Measure the DC voltage output from the transducer across the sensor "S" and "-" terminals
- If the measured voltage and pressure do not match, there may be a wiring problem, the factory 500 ohm resistor across "S" and "-" or the transducer may be defective. Check the transducer input circuit wiring and connections for defects. If the measured voltage and pressure match, the VFD parameters and/or ModBus communication between the controller and the VFD will need to be verified
- Remove powers from the controller by opening system switch S1. If available, swap a similar good transducer with the suspect transducer or try installing a new transducer. Restore power by closing S1 and verify whether the suspect transducer is defective

When writing to Daikin Applied for service or replacement parts, provide the model number, serial number, and unit part number of the unit as stamped on the serial plate attached to the unit. For questions regarding wiring diagrams, it will be necessary to provide the number on the specific diagram. If replacement parts are required, include the date of unit installation, the date of failure, an explanation of the malfunction, and a description of the replacement parts required.

Description	Daikin Applied Part Number
MT3006 Lg Controller w/ HMI 27 IOs	193407301
MT3026 Extension IO Module 26 IOs	193407401
MT3025 Extension IO Module 15 IOs	193407501
MT3024 Extension IO Module 8 IOs	193407601
MT3023 Extension IO Module 6 IOs	193407701
MT3051M Human Int Panel/Wall Mount 8×40	193408001
MT3051D Human Int Panel/Wall Mount 8×40	TBD
MT3041 Com Module BACnet IP	193408101
MT3043 Com Module LON — SCC	193408201
MT3042 Com Module BACnet MS/TP- 202 DAC	193408301
MT3044 Com Module Modbus RS485×2	193408401
MT3045 Remote Support Module	193408501
MT3 Service Cable 80 cm	193408601
MT3 Service Cable 150cm	193408701
MT3 Local HMI Cable 80 cm	193408801
MT3 Local HMI Cable 150cm	193408901
MT3 Real Time Clock Battery 200 Days	193409001
MT3 Conn Set Ctrl Spring Top Entry	193409101
MT3 Conn Set Ext 1 Spring Top Entry	193409201
MT3 Conn Set Ext 2 Spring Top Entry	193409301
MT3 Conn Set Ext 3 Spring Top Entry	193409401
MT3 Conn Set Ext 4 Spring Top Entry	193409501
MT3 Conn Ext I/O Direct Connect 10 Pk	193409601
MT3 Conn Ext I/O Direct Connect 1 Pk	193409701
MT3 Conn Ext I/O Remote Connect 10 Pk	193409701
MT3 Conn Ext I/O Remote Connect 1 Pk	193409901
MT3 SAPRO Eng Prog Tool	193410001
MT3 Test and Demo Suitcase 1	193410101
MT3 Test and Demo Suitcase 2	193410201
MT3 Conn 2 Pin Spring Top Entry	193410302
MT3 Conn 3 Pin Spring Top Entry	193410303
MT3 Conn 4 Pin Spring Top Entry	193410304
MT3 Conn 5 Pin Spring Top Entry	193410305
MT3 Conn 6 Pin Spring Top Entry	193410306
MT3 Conn 7 Pin Spring Top Entry	193410307
MT3 Conn 8 Pin Spring Top Entry	193410308

In-Warranty Return Material Procedure

Material may not be returned except by permission of authorized factory service personnel of Daikin Applied International at Minneapolis, Minnesota.

A "return goods" tag will be sent to be included with the returned material. Enter the information as called for on the tag in order to expedite handling at our factories and issuance of credits. All parts shall be returned to the factory designated on the return goods tag, transportation charges prepaid. The return of the part does not constitute an order for replacement. A purchase order for the replacement part must be entered through your nearest Daikin Applied representative. The order should include the component's part number and description and the model and serial numbers of the unit involved.

If it is determined that the failure of the returned part is due to faulty material or workmanship within the standard warranty period, credit will be issued on the customer's purchase order.

Limited Product Warranty (North America)

Limited Product Warranty (North America) Daikin Applied International ("Company") warrants to contractor, purchaser and any owner of the product (collectively "Owner") that Company, at its option, will repair or replace defective parts in the event any product manufactured by Company, including products sold under the brand names Daikin Applied Air Conditioning, AAF Air Conditioning, AAF HermanNelson and Daikin Applied Service, and used in the United States or Canada, proves defective in material or workmanship within twelve (12) months from initial startup or eighteen (18) months from the date shipped by Company, whichever occurs first. Authorized replaced parts are warranted for the duration of the original warranty. All shipments of such parts will be made FOB factory, freight prepaid and allowed. Company reserves the right to select carrier and method of shipment.

In addition, labor to repair or replace warranty parts is provided during Company normal working hours on products with rotary screw compressors, centrifugal compressors and on absorption chillers. Warranty labor is not provided for any other products.

Company's liability to Owner under this warranty shall not exceed the lesser of the cost of correcting defects in the products sold or the original purchase price of the products.

PRODUCT STARTUP ON ABSORPTION, CENTRIFUGAL AND SCREW COMPRESSOR PRODUCTS IS MANDATORY and must be performed by Daikin Applied Service or a Company authorized service representative.

It is Owner's responsibility to complete and return the Registration and Startup Forms accompanying the product to Company within ten (10) days of original startup. If this is not done, the ship date and the startup date will be deemed the same for warranty period determination, and this warranty shall expire twelve (12) months from that date.

Exceptions

1. If free warranty labor is available as set forth above, such free labor does not include diagnostic visits, inspections, travel time and related expenses, or unusual access time or costs required by product location.
2. Refrigerants, fluids, oils and expendable items such as filters are not covered by this warranty.
3. This warranty shall not apply to products or parts which (a) have been opened, disassembled, repaired, or altered by anyone other than Company or its authorized service representative; or (b) have been subjected to misuse, negligence, accidents, damage, or abnormal use or service; or (c) have been operated, installed, or startup has been provided in a manner contrary to Company's printed instructions, or (d) were manufactured or furnished by others and which are not an integral part of a product manufactured by Company; or (e) have not been fully paid for by Owner.

Assistance

To obtain assistance or information regarding this warranty, please contact your local sales representative or Daikin Applied Service office.

Sole Remedy

THIS WARRANTY CONSTITUTES THE OWNER'S SOLE REMEDY. IT IS GIVEN IN LIEU OF ALL OTHER WARRANTIES. THERE IS NO IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT AND UNDER NO CIRCUMSTANCE SHALL COMPANY BE LIABLE FOR INCIDENTAL, INDIRECT, SPECIAL, CONTINGENT OR CONSEQUENTIAL DAMAGES, WHETHER THE THEORY BE BREACH OF THIS OR ANY OTHER WARRANTY, NEGLIGENCE OR STRICT LIABILITY IN TORT.

No person (including any agent, sales representative, dealer or distributor) has the authority to expand the Company's obligation beyond the terms of this express warranty or to state that the performance of the product is other than that published by Company.

For additional consideration, Company will provide an extended warranty(ies) on certain products or components thereof. The terms of the extended warranty(ies) are shown on a separate extended warranty statement.



Air Handling Equipment Warranty Registration Form

To comply with the terms of Daikin Applied Warranty, complete and return this form within 10 days to the Warranty Department of Daikin Applied.

Check, test, and start procedure for air handling units with or without heat recovery and roof mounted air handlers.

GENERAL INFORMATION

Job Name: _____ GOI No.: _____

Installation address: _____

City: _____ State: _____

Purchasing contractor: _____

City: _____ State: _____

Name of person doing start-up: _____

Company name: _____

Address: _____

City/State/Zip: _____

UNIT INFORMATION

Unit model number: _____ Unit serial number: _____

SF VFD model number: _____ Serial number: _____

RF VFD model number: _____ Serial number: _____



AHU Equipment Warranty Registration Form (continued)

Select Yes or No. If not applicable to the type of unit, select N/A.

I. INITIAL CHECK

- A. Is any shipping damage visible? Yes No N/A
- B. Are fan drives properly aligned and belts properly adjusted? Yes No N/A
- C. Tightened all setscrews on pulleys, bearings and fans? Yes No N/A
- D. Have the hold-down bolts been backed off on spring mounted fan isolators? Yes No N/A
- E. With the power off, do fans turn freely by hand? Yes No N/A
- F. Electrical service corresponds to unit nameplate? Yes No N/A

Volts _____ Hertz _____ Phase _____

- G. Is the main disconnect adequately fused and are fuses installed? Yes No N/A
- H. Are all electrical power connections tight? (Check compressor, electrical box.) Yes No N/A
- I. Is the condensate drain trapped? Yes No N/A
- J. Fill the drain pan. Does water drain freely? Yes No N/A
- K. Is the unit mounted level? Yes No N/A

II. FAN DATA

- A. Check rotation of supply fan? Yes No N/A
- B. Voltage at supply fan motor: 1-2 _____ V 2-3 _____ V 1-3 _____ V
- C. Supply fan motor amp draw per phase: L1 _____ L2 _____ L3 _____
- D. Overload amp setting: _____
- E. What is the supply fan rpm? _____
- F. Check rotation of return fan? Yes No N/A
- G. Voltage at return fan motor: 1-2 _____ V 2-3 _____ V 1-3 _____ V
- H. Return fan motor amp draw per phase: L1 _____ L2 _____ L3 _____
- I. Overload amp setting: _____
- J. What is the return fan rpm? _____
- K. Record supply static pressure at unit in inches of H₂O: _____
- L. Record return static pressure at unit (with outside air dampers closed) in inches of H₂O: _____

III. DAMPERS

- A. Are blades and seals present? Yes No N/A
- B. Do damper open smoothly and shut tight? Yes No N/A



AHU Equipment Warranty Registration Form (continued)

Select Yes or No. If not applicable to the type of unit, select N/A.

IV. ELECTRIC HEAT

A. Electrical heat service corresponds to unit nameplate? Yes No N/A

Volts _____ Hertz _____ Phase _____

B. Are there any signs of physical damage to the electric heat coils? Yes No N/A

C. Have all electrical terminals been tightened? Yes No N/A

D. Does sequence controller stage contactors properly? Yes No N/A

E. Electric heater voltage across each phase: _____ L1 _____ L2 _____ L3

F. Amp draw across each phase at each heating stage:

	Stage 1	Stage 2	Stage 3	Stage 4	Stage 5	Stage 6
Phase L1:	_____	_____	_____	_____	_____	_____
Phase L2:	_____	_____	_____	_____	_____	_____
Phase L3:	_____	_____	_____	_____	_____	_____

G. FLA: L1 _____ L2 _____ L3 _____

H. Operate electric heat with fans off. Electric heat must cycle on high limit control Yes No N/A

V. CHILLED WATER COIL

A. Pressure test OK? Yes No N/A

B. Drain pan draining OK? Yes No N/A

VI. HOT WATER COIL

A. Pressure test OK? Yes No N/A

VII. HEAT RECOVERY

A. Heat wheel rotates freely? Yes No N/A

B. Heat wheel VFD operates properly? Yes No N/A

C. Heat wheel VFD: Model # _____ Serial # _____

D. Check for air bypass around heat wheel. Yes No N/A



AHU Equipment Warranty Registration Form (continued)

Select Yes or No. If not applicable to the type of unit, select N/A.

VIII. Design Flow calibration

- A. Verify power is supplied to the MicroTech III unit controller Yes No N/A
- B. Verify that the shipping screws have been removed from the measuring station vane Yes No N/A
- C. Examine station for damage Yes No N/A

D. Record Level Position after calibration

- LH Level Position _____
- RH Level Position _____

NOTE: This is viewed in the MicroTech III controller, in the Min OA setup menu.

IX. GAS BURNER CHECK, TEST, & START

Specifications:

For gas, see Forced Draft Gas Burner Installation and Maintenance Bulletin. (IM 684 and IM 685)

- A. Gas Furnace: Model no. _____
- B. Gas Burner: Model no. _____ Serial no. _____
- C. Gas Type firing: Single Stage _____ Modulation _____
- D. Gas Rated firing rate (MBH input): _____
- E. Gas Altitude (ft. above sea level): _____
- F. Is there a circulating tank? Yes No N/A
- G. Input (CFH): _____
- H. Gas pressure at burner (inches w.c.): _____
- I. CO₂ (%): _____
- J. CO₂ (%): _____
- K. Pilot flame only in microamps (steady at low fire): _____
- L. Pilot Tap-gas pressure (inches w.c.): _____
- M. Motor only/burner FLA running amps: _____
- N. High limit control OK? Yes No N/A
- O. Flame safeguard (microamps): _____
- P. Flame failure shutoff (seconds): _____

**AHU Equipment Warranty Registration Form (continued)**

Select Yes or No. If not applicable to the type of unit, select N/A.

Q. Airswitch OK?	Yes	No	N/A
R. High Gas Pressure Switch OK?	Yes	No	N/A
S. Low Gas Pressure Switch OK?	Yes	No	N/A
T. Main Gas Valve Close-off OK?	Yes	No	N/A

Thank you for completing this form. Please sign and date below.

Signature _____ Startup date: _____

Return completed form by mail to:

Daikin Warranty Department, 13600 Industrial Park Boulevard, Minneapolis, MN 55441
or by email to: AAH.Wty_WAR_forms@daikinapplied.com

Please fill out the Daikin Applied "Quality Assurance Survey Report" and list any additional comments that could affect the operation of this unit; e.g., shipping damage, failed components, adverse installation applications, etc. If additional comment space is needed, write the comment(s) on a separate sheet, attach it to the Survey Report and return it to the Warranty Department of Daikin Applied with the completed Equipment Warranty Registration form.



Quality Assurance Survey Report

To whom it may concern:

Please review the items below upon receiving and installing our product. Select N/A on any item that does not apply to the product.

Job Name: _____ **Daikin Applied G.O. No.** _____

Installation address: _____

City: _____ State: _____

Purchasing contractor: _____

City: _____ State: _____

Name of person doing start-up (print): _____

Company name: _____

Address: _____

City/State/Zip: _____

Unit model number: _____ **Unit serial number:** _____

1. Is there any shipping damage visible? Yes No N/A

Location on unit _____

2. How would you rate the overall appearance of the product; i.e., paint, fin damage, etc.? Excellent Good Fair Poor

3. Did all sections of the unit fit together properly? Yes No N/A

4. Did the cabinet have any air leakage? Yes No N/A

Location on unit _____

5. Were there any refrigerant leaks? Yes No N/A

From where did it occur? Shipping Workmanship Design

6. Does the refrigerant piping have excessive vibration? Yes No N/A

Location on unit _____

7. Did all of the electrical controls function at start-up? Yes No N/A

Comments _____

8. Did the labeling and schematics provide adequate information? Yes No N/A

9. How would you rate the serviceability of the product? Excellent Good Fair Poor

10. How would you rate the overall quality of the product? Excellent Good Fair Poor

11. How does the quality of Daikin Applied products rank in relation to competitive products? Excellent Good Fair Poor

Comments _____

Please list any additional comments which could affect the operation of this unit; i.e., shipping damage, failed components, adverse installation applications, etc. If additional comment space is needed, write the comment(s) on a separate sheet, attach the sheet to this completed Quality Assurance Survey Report, and return it to the Warranty Department with the completed preceding "Equipment Warranty Registration Form".



Daikin Applied Training and Development

Now that you have made an investment in modern, efficient Daikin equipment, its care should be a high priority. For training information on all Daikin HVAC products, please visit us at www.DaikinApplied.com and click on Training, or call 540-248-9646 and ask for the Training Department.

Warranty

All Daikin equipment is sold pursuant to its standard terms and conditions of sale, including Limited Product Warranty. Consult your local Daikin Applied representative for warranty details. To find your local Daikin Applied representative, go to www.DaikinApplied.com.

Aftermarket Services

To find your local parts office, visit www.DaikinApplied.com or call 800-37PARTS (800-377-2787). To find your local service office, visit www.DaikinApplied.com or call 800-432-1342.

This document contains the most current product information as of this printing. For the most up-to-date product information, please go to www.DaikinApplied.com.

Products manufactured in an ISO Certified Facility.