

SOLIDSVAC



Solidsvac Pumps SV800 Operations Manual



201 First Avenue - Bongaree - QLD 4507 - Australia

+61 456 000 665 / info@solidsvac.com / www.solidsvac.com

CONTENTS

Description	Page
1. Safety First	3
2. Prior to Operating the Carousel	3
3. Carousel Set-Up	4
4. Operation	7
5. Maintenance	7
6. Main Components	7

1. SAFETY FIRST

CAUTIONS AND GENERAL SAFETY

This manual contains important information concerning the installation, operation and maintenance of the SolidsVac Carousel, Model SV800. To prevent injury to personnel or equipment damage, this manual should be read and understood by those responsible for the installation, operation and maintenance of the equipment.

- Lift the equipment only at the lifting points provided
- The carousel should be installed in a safe level area, which provides adequate access for operating the equipment
- Ensure all hoses are in good condition, correctly rated and certified for the service in which they are to be used
- Inspect the unit regularly for damaged or worn components
- Tie down points (if fitted) must NOT be used as lifting points

2. PRIOR TO OPERATING THE CAROUSEL

- All hose connections are secure
- All nuts and bolts are tight
- Operating area is clear of personnel


3. Carousel Set-up

1. Ensure that the base of the SV800 Carousel is on solid and level ground.



2. Lift the top Rotating Arm and Support Bracket with suitably rated straps/chain attached to the Lifting Points
3. Place the supplied gasket on the top flange of the Carousel Base and position the Rotating Arm on top of the gasket. Secure with bolts, washers and nuts supplied. Swing the Support Arm into position on the Carousel Base and secure with bolt, washers and nut supplied.

N.B. Assistance will be required in lifting and positioning the Rotating Arm.



4. Lift the Drop Box with suitably rated straps/chain attached to the Lifting Points
5. Place the gasket supplied between the flange on the Rotating Arm and the Drop Box and secure with bolts, washers and nuts supplied.

N.B. Assistance will be required in lifting and positioning the drop box.

N.B. Ensure that the Carousel is secured to the floor either by bolts or welding.




4. Operation

1. Attach the discharge line to the inlet flange of the Carousel
2. Rotate the Locking Handle anti-clockwise to unlock the Rotating Arm.
3. Position the Rotating Arm over the Skip/Bin and lock into position by turning the Locking Handle clockwise.

5. Maintenance

1. Grease swivel joint regularly
2. Ensure all gaskets are in good condition
3. Check base mounting bolts are secure

6. Main Components



New design Swivel Joint includes a lubricating point and a fully enclosed double o-ring seal

Model Number

Serial Number

Date of Manufacture

Inspected by



201 First Avenue - Bongaree - QLD 4507 - Australia

+61 456 000 665 | info@solidsvac.com

www.solidsvac.com