

Replacing the Cutting Head

To replace the CSG-10 Carbide cutting head, loosen, but do not remove the Phillips screw. Remove the cutting head. Leave the spring in place. Slide the new cutting head onto the shaft. Push the cutting head down to compress the spring and tighten the Phillips screw.

CONTENTS

Unpacking & Setting Up	6
Unpacking Cutter's Mate	
Meet Your Cutter's Mate	
Setting up Cutter's Mate	
Maintaining Cutter's Mate	9
Lubricating the Cutting Wheel	
Lubricating Cutter's Mate	
Cleaning the Slide Shaft	
Adjusting Cutter's Mate	10
Grid Adapters_	
End Blocks	
Adjusting the Cutting Angle	
Hints	12
Parking & Storing Cutter's Mate	13