



# Aprisa SRi

Quick Start Guide

Aprisa SRi Radio

Version: 1.5.0

GA Release





## Copyright & Terms of Use

---

May 2025

This documentation describes features and functions provided with Aprisa SRi; Version: 1.5.0; GA Release.

### Copyright © 2025 by Aviat Networks.

All rights reserved.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, magnetic, optical, chemical, manual, or otherwise, without the prior written permission of Aviat Networks Inc.

To request permission, contact Aviat via [techpubs@aviatnet.com](mailto:techpubs@aviatnet.com)

### Warranty

Aviat Networks makes no representation or warranties with respect to the contents hereof and specifically disclaims any implied warranties or merchantability or fitness for any particular purpose.

Further, Aviat Networks reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Aviat Networks to notify any person of such revision or changes.

### Safety recommendations

The following safety recommendations must be considered to avoid injuries to persons and/or damage to the equipment:

- **Installation and Service Personnel:** Installation and service must be carried out by authorized personnel who have the technical training and experience necessary to be aware of any hazardous operations during installation and service, and of measures to avoid any danger to themselves, to any other personnel, and to the equipment.
- **Access to the Equipment:** Access to the equipment in use must be restricted to service personnel only.
- **Safety Norms:** Recommended safety norms are detailed in the Health and Safety sections of the product's Installation guide.
- **Service Personnel Skill:** Service personnel must have received adequate technical training on telecommunications, in particular the equipment and capabilities this addendum refers to.

## Trademarks

All trademarks are the property of their respective owners.

<b>WARNING</b>
Making adjustments and/or modification to this equipment that are not in accordance with the provisions of this instruction manual or other supplementary documentation may result in personal injury or damage to the equipment, and may void the equipment warranty.
<b>AVERTISSEMENT</b>
Tout réglage ou modification faits à cet équipement hors du cadre édité par ce guide d'utilisation ou par toute autre documentation supplémentaire pourraient causer des blessures ou endommager l'équipement, et peut entraîner l'annulation de la garantie.
<b>WARNUNG</b>
Die an diesen Geräten gemachte Einstellungen und/oder Änderungen, welche nicht gemäß dieser Bedienungsanleitung, oder gemäß anderen zusätzlichen Anleitungen, ausgeführt werden, können Verletzungen oder Materialschäden zur Folge haben und eventuell die Garantie ungültig machen.
<b>ATENCIÓN</b>
Llevar a cabo ajustamientos y/o modificaciones a este equipo, sin seguir las instrucciones provistas por este manual u otra documento adicional, podría resultar en lesiones a su persona o daños al equipo, y anular la garantía de este último.
<b>警告</b>
不按该说明书有关条例或其它补充文件对该设备所做的调整和 / 或 改型可能会引起人身伤害或损坏设备，并且设备保修也将失效。

## Aviat Networks Technical Support

### Service and Technical Support:

For customer service and technical support, contact one of the regional Technical Help Desks listed below.

North America & Latin America	EMEA	APAC
5250 Prue Road San Antonio, Texas 78240 USA	Motnica 9, 1236 Trzin Slovenia	Clark Freeport Zone Philippines 2023
Email: <a href="mailto:tacsupport@aviatnet.com">tacsupport@aviatnet.com</a>	Email: <a href="mailto:tacsupport@aviatnet.com">tacsupport@aviatnet.com</a>	Email: <a href="mailto:tacsupport@aviatnet.com">tacsupport@aviatnet.com</a>
<b>Phone:</b> +1 (210) 526 6345 <b>Toll Free (USA):</b> +1-800-227-8332		

### Global Support Hotline

Call the phone number for support from anywhere in the world. Aviat Networks' Global Support Hotline is available 24 hours a day, 7 days a week, providing uninterrupted support for all our customers.

When you call our Global Support Hotline:

- You will be greeted by an automated response that will ask you for your PIN#. Request a PIN# here: <https://aviatnetworks.com/how-can-aviat-help-you/pin-request-form/>
- As soon as you enter your PIN#, you will be transferred to our Global Technical Helpdesk that will assist you with your technical issue.
- If you do not have a PIN# your call will be answered by our Support Assurance Desk. Your call will be supported and prioritized accordingly.

Or you can contact your local Aviat Networks office. Contact information is available on our website at: <https://aviatnetworks.com/how-can-aviat-help-you/technical-support-tac/>

### Sales and Sales Support:

For sales information, contact one of the headquarters, or find your regional sales office at: <https://aviatnetworks.com/>

Corporate Headquarters USA	International Headquarters Singapore
200C Parker Drive, Suite 100 Austin, Texas, 78728 USA  <b>Phone:</b> +1 (512) 265-3680 <b>Fax:</b> +1 (512) 827-0350 <b>Toll Free for Sales Inquiries:</b> +1 888 478 9669	51 Changi Business Park Central 2 #04-10 The Signature Singapore 486066  <b>Phone:</b> +65 6496 0900 <b>Fax:</b> +65 6496 0999 <b>Sales Inquiries:</b> +1 321 674 4252



## Contents

Copyright & Terms of Use .....	iii
Aviat Networks Technical Support .....	v
Contents .....	vii
<b>Aprisa SRi Radio Quick Start Guide .....</b>	<b>9</b>
Introduction .....	9
Front panel connections .....	9
LED display panel .....	10
Ethernet and RS-232 RJ-45 LED indicators .....	10
Installation .....	11
Install Aprisa SRi Radio and connect protection earth .....	11
Connect the antenna and apply power to the Aprisa SRi Radio .....	14
Connect to the Aprisa SRi Radio (via SuperVisor or CLI) .....	15
Set up the Aprisa SRi Radio .....	16
Monitoring and Troubleshooting the Aprisa SRi Radio .....	17
Monitor the Aprisa SRi radio signal strength .....	17
Fault management and troubleshooting .....	18
Performance Monitoring (RF and Data Traffic) .....	19
Compliance Considerations .....	20
Canada .....	21
Mexico .....	21





# Aprisa SRi Radio Quick Start Guide


## Introduction

The Aprisa SRi is a Point-To-Multipoint (PMP) digital radio providing 915 MHz Industrial (unlicensed) License Free Spread Spectrum communications. The radios carry a combination of serial data and Ethernet data between the base station and remote radios. A single Aprisa SRi is configurable as a Point-To-Multipoint base station or remote radio.


This guide provides quick startup and basic installation instructions for the Aprisa SRi radio shown in the next figure below.

A more detailed user manual is also available. Refer to the *Aprisa SRi User Manual* for important warnings, cautions and notes and any detailed management relating to faults, configuration, maintenance, performance monitoring, and security.

## Front panel connections



All connections to the radio are made on the front panel. The functions of the connectors are (from left to right):

Designator	Description
10 - 30 VDC; 4A	+10 to +30 VDC (negative ground) DC power input using Molex 2 pin male screw fitting connector. AC/DC and DC/DC power supplies are available as accessories.
ETHERNET 1 & 2	Integrated 10Base-T/100Base-TX layer-3 Ethernet switch using RJ-45 connectors. Used for Ethernet user traffic and product management.
SERIAL 1 & 2	Two ports of RS-232 serial using RJ-45 connector. Used for RS-232 asynchronous user traffic.
	Host Port using a USB standard type A connector. Used for software upgrade and diagnostic reporting and optional: 1x RS-232 asynchronous port with USB to RS-232 converter.
ALARM	Alarm Port using an RJ-45 connector. Used for two alarm inputs and two alarm outputs.
MGMT	Management Port using a USB micro type B connector. Used to access the radio Command Line Interface (CLI).
PROTECT	Used for the Aprisa SRi Protected Station.
ANT	TNC, 50 ohm, female connector for connection of antenna feeder cable for half duplex RF operation.

## LED display panel

The Aprisa SRi has an LED Display panel which provides on-site alarms / diagnostics without the need for PC.



The LEDs indicate the following conditions.

	OK	MODE	AUX	TX	RX
<b>Flashing Red</b>		Radio has not registered			
<b>Solid Red</b>	Alarm present with severity Critical, Major and Minor			TX path fail	RX path fail
<b>Flashing Orange</b>		Diagnostics Function Active OTA software distribution	Management traffic on the USB MGMT port		
<b>Solid Orange</b>	Alarm present with Warning Severity		Device detect on the USB host port (momentary)		
<b>Flashing Green</b>	Software Upgrade Successful		Tx / Rx Data on the USB host port	RF path TX is active	RF path RX is active
<b>Solid Green</b>	Power on and functions OK and no alarms	Processor Block is OK	USB interface OK	Tx path OK	Rx path OK

LED Color	Severity
Green	No alarm – information only
Orange	Warning alarm
Red	Critical, major or minor alarm


## Ethernet and RS-232 RJ-45 LED indicators

LED	Status	Ethernet explanation	RS-232 explanation
Green	On	Ethernet signal received	RS-232 device connected
Orange	Flashing	Data traffic present on the interface	Data present on the interface

## Installation

The Aprisa SRi is shipped to you in a box containing an Aprisa SRi radio fitted with power connector.

The following figure shows a typical installation of the unit. The following sub-section describes the main requirements for installation.



### Install Aprisa SRi Radio and connect protection earth

The Aprisa SRi has four threaded holes (M4) in the base and two holes (for M5 screws) through the enclosure for mounting. Mounting options include:

#### Aprisa SRi DIN rail mounting


The Aprisa Family has an optional accessory part (APGA-MBRK-DIN) to enable the mounting on a standard DIN rail:

The Aprisa SRi is mounted into the DIN rail mounting bracket using the four M4 threaded holes in the enclosure base. Four 8 mm M4 pan pozi machine screws are supplied with the bracket.


The DIN rail mounting bracket can be mounted in three positions on a horizontal DIN rail:

- Vertical Mount (vertical enclosure perpendicular to the mount)
- Flat Vertical Mount (vertical enclosure parallel to the mount)


- Flat Horizontal Mount (horizontal enclosure parallel to the mount)



Vertical Mount




Flat Vertical Mount



Flat Horizontal Mount


### Aprisa SRi Rack Shelf mounting

The Aprisa Family has an optional accessory part (APGA-MR19-X1U) to enable the mounting on a standard 19" rack shelf:



### Aprisa SRi Wall mounting

The Aprisa SRi can be mounted on a wall using the two holes through the enclosure (5.2 mm diameter). Typically, M5 screws longer than 35 mm would be used.



The Aprisa SRi has an earth connection point on the top left and the top right of the enclosure. Use the supplied M4 screws to earth the enclosure to a protection earth.

The antenna feeder cable should use grounding kits for lightning protection as specified or supplied by the coaxial cable manufacturer to properly ground or bond the cable outer.



**Warning:** If the Aprisa SRi is operated in an environment where the ambient temperature exceeds 50°C, the Aprisa SRi must be installed within a restricted access location to prevent human contact with the enclosure heatsink.

## Connect the antenna and apply power to the Aprisa SRi Radio

Connect the antenna to the antenna port TNC female connector. If the antenna is not available, terminate the 'TX / Ant' port with a TNC male 50 ohm terminator (10 Watts min).



**Warning:** Do not directly connect the two radio antenna ports without attenuation of at least 40 dB. The receiver can be damaged if signals greater than +10 dBm are applied to the antenna port.



The Aprisa SRi is operated from a DC source of voltage between +10 VDC and +30 VDC (negative earth) and consumes up to 35 Watts. External power supplies are available from 4RF as accessories (see the *Aprisa SRi User Manual*).

The power connector (Molex 2 pin female) is supplied fitted to the radio. Wire your power source to the power connector (- / +) and plug the connector into the radio. The connector screws should be fastened to secure the connector.



**Note:** The radio fuses will blow if the connected power supply is over voltage, or the polarity is reversed. Two spare fuses are located inside the enclosure (see the **Spare Fuses** section of the *Aprisa SRi User Manual*).



**Note:** The factory default for the Terminal Operating Mode is set to Remote Station for all radios.

Turn your power source on. All the radio LEDs will flash orange for two seconds.

Then the **OK**, **AUX**, **TX** and **RX** LEDs will light green, and the **TX** and **RX** LEDs will also flash as traffic is transmitted / received. The **MODE** LED will flash red to indicate that the radio is unregistered.

When the radio has been configured and has registered with the network, the **MODE** LED will turn green (so all LEDs are now green).

The radio is now ready to operate.

If the radio has an active alarm, such as being unable to communicate with the base station, the **OK** LED will go red.



**Warning:** On link operation, RF energy is radiated from the antenna. Do not stand in front of the antenna.

## Connect to the Aprisa SRi Radio (via SuperVisor or CLI)

The Aprisa SRi has a factory default IP address of **169.254.50.10** with a subnet mask of **255.255.0.0**.

Each radio in the Aprisa SRi network must be set up with a unique IP address on the same subnet.


If the IP address of the radio is known or is the default IP address, it can be changed via the Ethernet port:

- Set up your PC for a compatible IP address, e.g., **169.254.50.1** with a subnet mask of **255.255.0.0**.
- Connect your PC network port to one of the Aprisa SRi Ethernet ports.
- Open a browser and enter **https://169.254.50.10**.



**Note:** The Aprisa SRi has a Self-Signed security certificate which may cause the browser to prompt a certificate warning. It is safe to ignore the warning and continue. The valid certificate is 'Issued By: 4RF-APRISA' which can be viewed in the browser.

- Log in to the radio with the default login **admin** and password **admin**.
- Change the IP address, Subnet mask and Gateway to network compatible IP addresses.



If the IP address of the radio is unknown, it can be changed via the Command Line Interface on the radio MGMT USB port:

- Connect your PC USB port to the Aprisa SRi MGMT USB port. USB to UART Bridge VCP Drivers are required to connect the radio USB port to your PC. You can download and install the relevant driver from [www.silabs.com/products/development-tools/software/usb-to-uart-bridge-vcp-drivers](http://www.silabs.com/products/development-tools/software/usb-to-uart-bridge-vcp-drivers).
- Set the PC serial port to 38,400 baud, 8 data bits, no parity and 1 stop bit, with no hardware flow control.
- Log in to the radio with the default login **admin** and password **admin**.
- At the command prompt >>
  - type `cd APRISASR-MIB-4RF` and **Enter**.
  - type `set termEthController1IpAddress xxx.xxx.xxx.xxx` and **Enter**.
  - type `set termEthController1SubnetMask 255.255.0.0` and **Enter**.
  - type `set termEthController1Gateway xxx.xxx.xxx.xxx` and **Enter**.



## Set up the Aprisa SRi Radio

The Aprisa SRi has a factory default **Terminal Operating Mode** of Remote Station.

One radio in the Aprisa SRi network must be set up as a **Base** Station.

The other radios in the Aprisa SRi network are set up as **Remote** Stations.

Set the **Ethernet Operating Mode**.

**OPERATING MODES**

Terminal Operating Mode: Base

Ethernet Operating Mode: Bridge ☐ Advanced

RF Operating Mode: Standard

**TERMINAL PROTECTION**

Protection Type: None

Set the unique radio **Base Station ID** to be the same in your entire network. Every base station and its attached remote radios (i.e., base station network) shall have a unique **Base station ID** in case of close proximity or close coverage between two or more base station networks.

**RF NETWORK DETAILS**

Network ID (FAN): 00A1

Base Station ID: 1

Save Cancel

Set the Aprisa SRi **TX Power** and **Channel Size** to comply with your license.

**TRANSMITTER**

TX Power (dBm): 26 (10 to 26 dBm, in 1 dB steps)

**GENERAL**

Channel Size (kHz): 50

Save Cancel

Set up the Aprisa SRi Zones / Channels. Specific channels within the selected zone hop can be disabled if there is a known transmission within the channel that may cause interference to the operation of this network. The minimum number of enabled channels is 50.

If a channel is selected in a zone that is disabled, the zone will be enabled when the channel selection is saved. The default is all zones enabled.

The zone frequencies are pre-defined in the Aprisa SRi for the zone number. The zone frequencies are spaced at 62.5 kHz.

**ZONE SETUP**

Zones	Zone 1	Zone 2	Zone 3	Zone 4	Zone 5	Zone 6	Zone 7	Zone 8
Zone	Enabled	Frequencies (MHz)	Channels Enabled					
1	<input checked="" type="checkbox"/>	902.53125 - 905.59375	50 of 50					
2	<input checked="" type="checkbox"/>	905.65625 - 908.71875	50 of 50					
3	<input checked="" type="checkbox"/>	908.78125 - 911.84375	50 of 50					
4	<input checked="" type="checkbox"/>	911.90625 - 914.96875	50 of 50					
5	<input checked="" type="checkbox"/>	915.03125 - 918.09375	50 of 50					
6	<input checked="" type="checkbox"/>	918.15625 - 921.21875	50 of 50					
7	<input checked="" type="checkbox"/>	921.28125 - 924.34375	50 of 50					
8	<input checked="" type="checkbox"/>	924.40625 - 927.46875	50 of 50					

Enable All Disable All 400 channels enabled

You can now configure the remaining terminal and network parameters and settings. Please refer to the *Aprisa SRi User Manual* for detailed instructions, such as the radio security settings and more.



## Monitoring and Troubleshooting the Aprisa SRi Radio

### Monitor the Aprisa SRi radio signal strength

When the network is installed, the radio signal strength can be monitored on remote stations by setting the radio to Test Mode.

To enter Test Mode, press and hold the **TEST** button on the radio LED panel until all the LEDs flash green (about 3 - 5 seconds).

In Test Mode, the LED Display panel presents a real time visual display of the RSSI. This can be used to adjust the antenna for optimum signal strength.



**Note:** The response time is variable and can be up to 5 seconds.

To exit Test Mode, press and hold the **TEST** button until all the LEDs flash red (about 3 – 5 seconds).

The **OK**, **MODE** and **AUX** LEDs will be solid green, and the **TX** and **RX** LEDs will be solid or flash green if the network is operating correctly.

OK LED	MODE LED	AUX LED	TX LED	RX LED	RSSI
●	●	●	●	●	>= -80 dBm
●	●	●	●	●	-84 dBm to -81 dBm
●	●	●	●	●	-88 dBm to -85 dBm
●	●	●	●	●	-92 dBm to -89 dBm
●	●	●	●	●	-96 dBm to -93 dBm
●	●	●	●	●	-100 dBm to -97 dBm
●	●	●	●	●	-104 dBm to -101 dBm
●	●	●	●	●	-108 dBm to -105 dBm
●	●	●	●	●	-112 dBm to -109 dBm
●	●	●	●	●	-116 dBm to -113 dBm
●	●	●	●	●	< RSSI threshold
●	●	●	●	●	No response received

For more information, please refer to the *Aprisa SRi User Manual*, available from Aviat Networks's Customer Resource Center.

## Fault management and troubleshooting

The Aprisa SRi supports extensive alarms for every section and building block of the device including the interfaces. SuperVisor allows user to view the main summary alarm at the top of the SuperVisor page which mimic the device LEDs and in addition all the detailed alarms of the device (see **SuperVisor > Events > Alarm Summary**). In addition, SuperVisor allows user to troubleshoot any alarm issue by using the event history log page for more information about the alarm (see **SuperVisor > Events > Event History**).

For more information, see the *Aprisa SRi User Manual*.

The screenshot displays the SuperVisor web interface for an Aprisa SRi device. The interface includes a top navigation bar with tabs for Terminal, Radio, Serial, Ethernet, IP, QoS, Security, Maintenance, Events, Software, and Monitoring. Below this is a sub-navigation bar with links for Alarm Summary, Event History, Events Setup, Traps Setup, Alarm I/O Setup, Event Action Setup, and Defaults.

The main content area is divided into two sections:

- ALARM SUMMARY:** A tree view showing the status of various components. The Base Station is expanded, showing a list of alarms with green circular icons indicating their status. The list includes:
  - Transmit Path
    - PA Current
    - PA Driver Current
    - PA Stability
    - TX AGC
    - TX Forward Power
    - TX Reverse Power
    - Temperature Threshold
    - TX Synthesizer Not Locked
    - Thermal Shutdown
  - Receive Path
  - Radio Interface Path
  - Customer Equipment Interface Path
  - Component Failure
  - Diagnostic
  - Software
  - Alarm Inputs
  - Power Supply
- EVENT HISTORY:** A table listing recent events. The table has columns for Log ID, Date/Time, Event ID, Description, State, Severity, and Additional Information. The events listed are:
 

Log ID	Date/Time	Event ID	Description	State	Severity	Additional Information
113	12/12/2018, 07:11	26	User Authentication Succeeded	inactive	information	SuperVisor, User admin, Local auth OK, IP Addr 172.10.1.1
112	12/12/2018, 07:07	30	Software Start Up	inactive	information	Power on Reset
111	12/12/2018, 05:54	72	User Session Logout	inactive	information	SuperVisor, User admin, IP Addr 172.10.1.1
110	12/12/2018, 05:39	89	User Account Activity	inactive	information	User Account: admin_factory account created
109	12/12/2018, 05:29	26	User Authentication Succeeded	inactive	information	SuperVisor, User admin, Local auth OK, IP Addr 172.10.1.1
108	12/12/2018, 05:27	30	Software Start Up	inactive	information	User Reboot (Management)
107	12/12/2018, 05:27	72	User Session Logout	inactive	information	SuperVisor, User admin, IP Addr 172.10.1.1
106	12/12/2018, 05:24	39	Software Restart Required	active	warning	Ethernet Operating Mode Changed

At the bottom right of the Event History section, there is an 'Auto Refresh' checkbox and 'Prev' and 'Next' buttons.

## Performance Monitoring (RF and Data Traffic)

The Aprisa SRI supports extensive performance monitoring statistics and diagnostic per the device and per data ports. The Aprisa SRI Terminal, Serial, Ethernet, Radio, and User Selected Monitored Parameter results have history log views for both Quarter Hourly and Daily. SuperVisor allows user to view trends of the performance monitoring parameters in graph or tabular format (see **SuperVisor > Monitoring**).

For more information, see the *Aprisa SRI User Manual*.

The screenshots show the Aviat SUPERVISOR web interface for an Aprisa SRI device. The interface includes a top navigation bar with tabs for Terminal, Radio, Serial, Ethernet, IP, QoS, Security, Maintenance, Events, Software, and Monitoring. The Monitoring tab is selected, and the left sidebar shows various monitoring categories.

**POWER SUPPLY PARAMETERS**

Parameter	Value	User
Current VDC Power Supply	12.484 V	<input type="checkbox"/>
Current 3.3V Power Supply	3.305 V	<input type="checkbox"/>
Current 5.0V Power Supply	5.246 V	<input type="checkbox"/>
Current 15.0V Power Supply	13.043 V	<input type="checkbox"/>

Buttons: QHourly, Daily, L: QHourly, L: Daily, L: Current

**RADIO PARAMETERS**

Transmitter	Receiver	Transmit Path	Receive Path
From	Node Name	Rx RSSI	Rx Freq Error
172.10.1.31	Remote Radio	-61.2 dBm	12 Hz
			Rx Mod
			64QAM Lo
			Rx Timestamp
			12/12/2018, 07:31
			User
			<input type="checkbox"/>

Buttons: QHourly, Daily, L: QHourly, L: Daily, L: Current, Prev, Next

**ETHERNET PORT PARAMETERS**

Port 1 Tx	Port 1 Rx	Port 2 Tx	Port 2 Rx
Packets	120		
Bytes	30,823		
Packets equal to 64 Bytes	60		
Packets 65 to 127 Bytes	11		
Packets 128 to 255 Bytes	9		
Packets 256 to 511 Bytes	0		
Packets 512 to 1023 Bytes	39		
Packets 1024 to 1536 Bytes	1		
Broadcast Packets	2		
Multicast Packets	6		
VLAN Frames	0		
VLAN Frames dropped	0		

Buttons: QHourly, Daily, L: QHourly, L: Daily, L: Current, Reset

**SERIAL PORT PARAMETERS**

Port 1	Port 2	USB Serial Port
Maximum Capacity	115,200 bps	
Packets Transmitted	0	
Bytes Transmitted	0	
Packets Received	0	
Bytes Received	0	
Errored Bytes Received	0	
Dropped Bytes (Congestion)	0	

Buttons: QHourly, Daily, L: QHourly, L: Daily, L: Current, Reset

## Compliance Considerations

The Aprisa SRi is a professional radio product and as such must be installed by a suitably trained and qualified installer who is aware of the local regulatory requirements existing at the time of installation and is capable of ensuring that the regulations are adhered to.

The maximum Equivalent Isotropic Radiated Power (EIRP) permitted from the Aprisa SRi is regulated and must not exceed the limits provided in the following table. To meet this regulatory requirement, knowledge of the antenna gain, and feeder cable loss must be known before setting the transmitter output power.

Regulatory requirement	Frequency range	Maximum EIRP	SRi equivalent maximum average power (RdBm)
USA, FCC Part 15.247	902 MHz to 928 MHz	+36 dBm PEP	+32 dBm
Canada, ISED RSS-247	902 MHz to 928 MHz	+36 dBm PEP	+32 dBm
Australia, ACMA AS/NZS 4268	915 MHz to 928 MHz	+30 dBm	+30 dBm
New Zealand, General User Radio License for Short Range Devices	915 MHz to 928 MHz	+30 dBm	+30 dBm
New Zealand, General User Radio License for Short Range Devices	920 MHz to 928 MHz	+36 dBm	+36 dBm
Brazil, Act No. 14.448, of December 4, 2017	902 MHz to 907.5 MHz & 915 MHz to 928 MHz	+36 dBm PEP	+30 dBm
Mexico, NOM-208-SCFI-2016	902 MHz to 928 MHz	+36 dBm PEP	+30 dBm
Peru	915 MHz to 928 MHz	+30 dBm	+30 dBm

The Aprisa SRi has a maximum mean output power of +26 dBm into a 50 ohm antenna which equates to a maximum peak power of +30 dBm PEP. To determine the maximum power to be set on the Aprisa SRi, the following installation parameters must be known:

1. Aprisa SRi equivalent average power for maximum permitted EIRP (specified in dBm)  $R_{dBm}$
2. Antenna isotropic gain (specified in dBi)  $G_{dBi}$
3. Feeder coax loss between Aprisa SRi and antenna (specified in dB/m)  $L_{dB/m}$
4. Length of feeder coax between Aprisa SRi and antenna (specified in meters)  $d_m$

From these the above information, the power setting of the Aprisa SRi ( $P_{dBm}$ ) can be calculated to ensure operation within the regulatory requirements using the formula:

$$P_{dBm} = R_{dBm} + (d_m \times L_{dB/m}) - G_{dBi}$$

Antenna gain information can be obtained from the Antenna manufacturer and is either expressed in terms of dBi, referenced to an isotropic radiator, or dBd, referenced to a dipole.

If the gain is expressed in dBd, it can be converted to dBi by adding 2.15 dB to the gain value.

The following is an example of transmitter power calculations:

Antenna type and gain	Feeder coax length and loss	Regulatory limit	Maximum SRi power setting
Yagi, 11 dBi	10 m of ½" Helix @ 0.11 dB/m gives 1.1 dB loss	+36 dBm PEP	22 dBm
Panel, 12 dBi	33 m of RG214 @ 0.22 dB/m gives 7.3 dB loss	+30 dBm	25 dBm
Dipole, 3.5 dBi	3 m of RG214 @ 0.22 dB/m gives 0.66 dB loss	+30 dBm	26 dBm
Grid, 18 dBi	15 m of ½" Helix @ 0.11 dB/m gives 1.65 dB loss	+30 dBm	13 dBm

## Canada

This radio transmitter Aprisa SRi ISED: 6772A-SI902M160 has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Cet émetteur radio Aprisa SRi ISED: 6772A-SI902M160 a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés ci-dessous avec le gain maximum autorisé indiqué. Les types d'antennes non inclus dans cette liste, ayant un gain supérieur au gain maximum indiqué pour ce type, sont strictement interdits d'utilisation avec cet appareil.

## Mexico

La operación de este equipo está sujeta a las siguientes dos condiciones:

1. es posible que este equipo o dispositivo no cause interferencia perjudicial y
2. este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

Este equipo ha sido diseñado para operar con las antenas que enseguida se enlistan y para una ganancia máxima de antena de 6 dBi.

El uso con este equipo de antenas no incluidas en esta lista o que tengan una ganancia mayor que 6 dBi quedan prohibidas. La impedancia requerida de la antena es de 50 ohms.

GA Release

[WWW.AVIATNETWORKS.COM](http://WWW.AVIATNETWORKS.COM)