

NEUTRON™ DC22

22 DC SHADE POWER DISTRIBUTION UNIT
INSTRUCTION MANUAL
#NEU-DC-22

Neutron™ is not a PoE DEVICE and is NOT POWERED BY PoE

Noutron™	Instruction	Manual
Neutron	Instruction	Manuai

All brand names, product names and trademarks are the property of their respective owners. Certain trademarks, registered trademarks, and trade names may be used to refer to either the entities claiming the marks and names or their products.

Specifications are subject to change without notice

FCC Compliance Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Thank you for your purchase of Neutron™.

This manual is designed to provide all the necessary information for installation and deployment, however if you have any additional questions or need any additional information, please reach out to our Customer Support Teams.

TOLLFREE +1 (844) 771-8725 - 24/7/365

Throughout this manual you will find QR codes that when scanned will take you to a video for that section that may contain additional information. Scan the code or click on the QR code to bring up your default browser and take you to the video.



Contents

QUICK START BASIC USE:	7
INTRODUCTION: COMPATIBLE MOTORS & CAPACITY?	8
PARTS INCLUDED IN THE BOX:	9
ADDITIONAL PARTS INCLUDED WITH BOND EDITION:	12
POPULAR OPTIONAL PARTS SOLD SEPARATELY:	12
INSTALLATION - DIMENSIONS:	13
NEUTRON MOUNTING	14
INSTALLATION – SYMMETRICAL RACK & DIN MOUNTING:	15
10 MOUNTING POINTS	16
RACK MOUNTING EXAMPLES	17
NEUTRON CONNECTIONS	18
INSTALLATION - CONNECTIONS: FRONT PANEL	19
INSTALLATION - CONNECTIONS: REAR PANEL	20
NEUTRON 485 SEGMENTS	22
THREE 485 BUS SEGMENTS	23
NEUTRON OPERATIONAL MODES	24
OPERATIONAL MODES – HIBERNATION (1 of 2)	25
OPERATIONAL MODES – USER (2 of 2)	26
NEUTRON INDICATORS (9)	27
LEDS/INDICATORS – SYSTEM STATUS	
LEDS/INDICATORS – ESM/DC POWER STATUS	29
NEUTRON USER KEYS (4)	31
KEYS UP/DOWN/RESET (3):	32
KEY ACTIONS (HIBERNATE MODE): 3 KEYS LOCKED	33
KEY ACTIONS (USER MODE): 3 KEYS LOCKED	
KEY ACTIONS (USER MODE): KEYS UNLOCKED	
TROUBLESHOOTING	
С	


QUICK START BASIC USE:

Neutron can be used as a standard shade low voltage power supply.

Simply connect the included passive DC injector to the BUS IN port on the front chassis.

This will automatically take the Neutron out of Hibernation/delivery mode.

You will see the LEDs on the BUS IN, the system status and ESM turn green, and no further action is needed to start shading.



You can now connect your low voltage motors to the front and rear ports and use the supply like any other shade power supply.

Optionally you can use the 4 devices ports as a 485 data hub for user controls and connect any IP gateway or hubs to the BUS OUT of the DATA (LAN) port on the passive DC injector.

Neutron can be used as a standard shade low voltage power supply.

INTRODUCTION: COMPATIBLE MOTORS & CAPACITY


СОММ	MOTOR MODEL NUMBER	Connector	Watts	Torque	Voltage	Neutron DC-22
E	BTX®					~ Per PDU
RF	BTX® DC RF 2Nm	2P	22	2	24V	22
RF	BTX® DC RF 4Nm	2P	40	4	24V	12
PoE	BTX® PoE 2.0	RJ45	22	2	44~57 AF	~N/A ~
PoE	BTX® PoE 4.0	RJ45	40	4	44~57 AF	~N/A ~
(CRESTRON®					
485	CSM-QMT50- DCC	CN 4P	50	6	22.1-26.1	10
485	CSM-QMTDC- 163	-1-CN 4P	42.5	0.75	22.1-26.1	11
485	CSM-QMTDC- 163	-1-EX 4P	42.5	0.75	22.1-26.1	11
485	CSM-QMTDC- 250	-4-CN 4P	42.5	4	22.1-26.1	11
485	CSM-QMTDC- 250	-4-EX 4P	42.5	4	22.1-26.1	11
485	CSM-QMTDC- 256	-2-CN 4P	36	2	22.1-26.1	13
485	CSM-QMTDC- DRF	P-3-CN 4P	42.5	1.62	22.1-26.1	11
485	CSM-QMTDC- DRF	P-3-EX 4P	42.5	1.62	22.1-26.1	11
l	LUTRON®					
485	QSSC-EDU- R20) 4P	17	0.33	21.6 - 38.5	22
485	QSSC-EDU- 5	4P	28	0.56	21.6 - 38.5	17
485	QSSC-EDU- 10	4P	52	1.12	21.6 - 38.5	9
485	QSSC-EDU- 64	4P	52	1.12	21.6 - 38.5	9
485	QSSC-EDU- R10	00 4P	37	2.82	21.6 - 39.6	13
485	QSSC-EDU- R15	50 4P	45	3.73	21.6 - 38.5	11
485	QSSC-EDU- R20	00 4P	24	6.77	21.6 - 38.5	20
485	QSSC-EDU- R22	25 4P	30	2.82	21.6 - 38.5	16
485	QSSC-EDU- 30-	SB 4P	37	2.82	21.6 - 38.5	13
485	QSSC-EDU- R30	00 4P	53	6.77	21.6 - 38.5	9
485	QSSC-EDU- R30	00-XT 4P	52	7.9	21.6 - 38.5	9
485	QSSC-EDU- 45	4P	30	5.08	21.6 - 38.5	16
485	QSSC-EDU- 60	4P	40	6.77	21.6 - 38.5	12
485	QSSC-EDU- D10)5 4P	41	11.85	21.6 - 38.5	12
485	QSSC-EDU- D14	45 4P	40	16.36	21.6 - 38.5	12
485	QSSC-EDU- D17	75 4P	45	19.74	21.6 - 38.5	11

INTRODUCTION: COMPATIBLE MOTORS & CAPACITY

СОММ	MOTOR MODEL NUMBER	nnector	Watts	Torque	Voltage	Neutron DC-22
	POWERSHADES*					~ Per PDU
RF	PS30CEQ_2.0NM_2W_202	2 2P	18	2	12V	~N/A ~
PoE	PS35PoE_2.0NM_BR17_20	22 RJ45	5	2	44~57 AF	~N/A ~
PoE	PS45PoE_6.0NM_BR20_202	23 RJ45	5	6	44~57 AF	~N/A ~
	Q-MOTION®					
485	Q-Motion® QIS Motor QIS-2	24 RJ45	32	2.5	24V	~N/A ~
	SHADE INNOVATIONS™					
PoE	Coming Soon	RJ45	15	0.7	44~57 AT	~N/A ~
PoE	Coming Soon	RJ45	15	1.1	44~57 AT	~N/A ~
PoE	Coming Soon	RJ45	15	2	44~57 AT	~N/A ~
Zigbee	Coming Soon	2P	15	0.7	12V	~N/A ~
Zigbee	Coming Soon	2P	18	1.1	12V	~N/A ~
Zigbee	Coming Soon	2P	20	2	12V	~N/A ~
	SOMFY®					
485	Sonesse® 30 #12411	144 5P	16	2	21.6-28.5	26
485	Sonesse® ULTRA 504 #11340	022 5P	36	4	21.6-28.5	13
485	30 (Obsolete) #10006	558 5P	20	2	21.6-28.5	11
PoE	Sonesse® 30 #12411	147 J45	18	1.5	48-57 AT	~N/A ~
PoE	Sonesse® 40 2 #12414	426 J45	25	2	48-57 AT	~N/A ~
PoE	Sonesse® 40 4 #12414	427 J45	51	4	48-57 BT	~N/A ~
PoE	Sonesse® 40 6 #12414	428 J45	62	6	48-57 BT	~N/A ~
Zigbee	Sonesse® 30 #12419	970 2P	18	2	21.6-28.5	24
RTS	Sonesse® 30 #12412	142 2P	15	2	21.6-28.5	26
RTS	Sonesse® 30 #12411	144 2P	16	2	21.6-28.5	19
RTS	Sonesse® ULTRA 504 #11340	023 2P	36	4	21.6-28.5	9
DCT	Sonesse® 30 #12412	146 6 P	20	2	21.6-28.5	8

INTRODUCTION: MOTOR CONNECTORS


Each of the 14 connectors are 5.08 pitch 5 positions that can support up to 12AWG wire



Connect the 24V **Positive** (+) from the shade motors to the left terminals marked with (V+)




Connect the **Negative** Ground (-) from the shade motors to the right terminals marked (V-)




Strip approx. ¼ of dielectric from each wire up to 12AWG and insert into each polarity gate and use a small flathead screwdriver to turn the top screws to close the connector gates down on the stranded wire








For best results ensure the gates are only closed onto the wire and not the dielectric



10 | Page


PARTS INCLUDED IN THE BOX: (Replacement parts also sold on website)






This manual is NOT included in the box as part of our SAVe sustainability efforts. We have 3 QR CODE locations on the enclosure for digital downloads of this manual.


POPULAR OPTINAL PARTS SOLD SEPARATELY:



INSTALLATION - DIMENSIONS:




NEUTRON MOUNTING




INSTALLATION – SYMMETRICAL RACK & DIN MOUNTING:

Using the included symmetrical rack ears and din rail brackets the unit can be mounted in a variety of ways. Including on wall or in wall box with screws through rack ears or on din rails



NEUTRON 10 MOUNTING POINTS


Neutron is Plenum rated and has 10 Rack mount and Din rail bracket mounting points




RACK MOUNTING EXAMPLES

1RU Half rack enclosures - 1 Neutron





1RU Full rack – (1 Neutron with optional Long Rack Ears* must use front & back due to weight)







1RU Full rack – (1 Neutron with optional Mid Rack Ears* must use front & back due to weight)



1RU Full rack – (2 Neutrons with optional 1RU Rack Joiner Kit)



NEUTRON CONNECTIONS





INSTALLATION - CONNECTIONS: FRONT PANEL DC MOTOR PORTS PIN OUT **BUS IN (DC HARVESTING) PIN OUT** Data A+ Data B- RS-485 (0-5Vdc) Data A+ RS-485 (0-5Vdc) Data Bn/c n/c Power + Power + Power + Power + 24-48Vdc INPUT 24Vdc **OUTPUT** n/c n/c Ground -Ground -RJ45 USOC-8 RJ45 USOC-8 Ground -Ground -TIA/EIA 568-B TIA/EIA 568-B **Ethernet FUTURE USE** (8) ±2Nm DC MOTOR PORTS (RJ45) (4) 485 DEVICE PORTS (RJ45) \circ \circ GPI/O **485 DEVICE PORTS PIN OUT** Single DC motor port (**1Nm** max per port) Data A+ RS-485 Data B- (0-5Vdc) Do not connect 485 devices to motor ports. Power + Only a single DC or AC powered motor should Power + be connected to each front motor port. n/c 24Vdc OUTPUT Ground -RJ45 USOC-8 AC motors can be connected to the front Ground -TIA/EIA 568-B motor ports however care should be taken to use the correct cable with only 3 pins **BUS OUT / RS232 PORT PIN OUT** Data A+ RS-485 (0-5Vdc) A+, B-, & G No connection on pin 4 should be Data Bmade as Neutron provides power on that RS232- TX (0-5Vdc) n/c pin to power DC motors. Failure to use the n/c proper cable may damage the AC motor. RS232- RX Ground -#3-CND-CBL-ACM compatible with 9012111 RJ45 USOC-8


Ground -

TIA/EIA 568-B


LUTRON and CRESNET CONNECTIONS:








INSTALLATION - CONNECTIONS: REAR PANEL





14 - 5.08 pitch terminal blocks are included (The cable strain relief can be removed)

(14) ±7Nm MOTOR PORTS (5.08 – FIVE POSITION TERMINAL BLOCKS, 12-24 AWG wire)




DC motor ports (**7Nm max** per port is supported)






NEUTRON 485 SEGMENTS




THREE 485 BUS SEGMENTS

Neutron has three 485 BUS segments:



NEUTRON OPERATIONAL MODES



NEUTRON OPERATIONAL MODES - HIBERNATION (1 of 2):


Neutron has 2 operational modes (HIBERNATION, USER)

MODE 1 of 2; HIBERNATION ZZZZ MODE

This is the shipping/delivery mode that the unit is set at from the factory.

In this mode no power can be provided on any Motor or Device port.

In this deep-sleep mode the priority of processing is for ESM Balancing, and ultra-low energy support systems which are running in the background. The unit has countermeasures against unintended user intervention whether biological or artificial means such as during stressful movements or packaging ingress or crushing.



You can test (or demonstrate operational readiness) with a press of the reset Key. The unit is still in Hibernation mode, but will briefly turn on the ESM, and both BUS OUT LED's for UN38.3 international inspection or other EMEA nonproliferation inspection purposes.

Neutron has two methods to switch out of Hibernation Mode.

#1 Connect a 24-48VDC power source to the BUS INPUT which will switch to USER_MODE

(The unit ships with a passive DC injector, connect the output to the BUS IN)

or

#2 Hold the RESET Key for approximately 6 seconds until the ESM LED starts flashing & has now switched to USER MODE

NEUTRON OPERATIONAL MODES - USER (2 of 2):

Neutron has 2 operational modes (HIBERNATION, USER)


MODE 2 of 2; USER MODE

This is the normal run-time mode that Neutron will be in for 99% of its operational life.

Three of the four user keys are locked by default in this mode to avoid unintentional motor movements. Check the user key section for details on how to unlock the keys for use.

Depending on the Neutron set-up this mode can help save energy by eliminating all or some of the energy used by shade motors.


NEUTRON INDICATORS (9)



NEUTRON LEDS/INDICATORS - SYSTEM STATUS:

MOTOR PORT TOTAL OUTPUT (0-22 Amps)

DC 485



LED COLOR

			2 00 20 11		
SYSTEM STATUS LED:	0		•	•	•
	NONE	GREEN	YELLOW	AMBER	RED
This LED indicates overall system	UNIT IN	UNIT IN		KEYS	
Status and Keylock status	HYBER.	USER	N/A	UNLOCKED	N/A
	MODE	MODE			
		(KEYS LOCKED)			SYSTEM
This LED also FLASHES during					ERROR*
AI BUS activity (please wait for		*			
flashing to stop before proceeding)					
This LED also winks slowly if RS232 is 6	nabled	\odot		<u>-</u>	
	1	1			

NEUTRON LEDS/INDICATORS - ECO/ESM/DC POWER STATUS:

MOTOR PORT TOTAL
OUTPUT (0-22 Amps)

POWER ACTIVITY


SYSTEM
ESM
STATUS

READY/ACT END of LINE

LED COLOR

	NONE	GREEN	YELLOW	AMBER	RED
ESM STATUS:	O Unit is	ESM	•	esm	•
This LED indicates the status of the	in Hiber.	Power	N/A	Charge	N/A
Energy Storage Module or ESM	Mode	Good		pending	
This LED also winks slowly when the ESM is harvesting power from BUS IN		\odot			
DC POWER STATUS:	0	•	•	•	LOW
This LED indicates the status of any	NO DC	DC POWER			
DC for the Reaktor to use for power	POWER	IS	N/A	N/A	
& harvesting for the ESM	DETECTED	PRESENT			
					N/A

NEUTRON LEDS/INDICATORS – 232/BUS IN/BUS/AMMETER:




	NONE	GREEN	YELLOW	AMBER	RED
RS-232 STATUS:	0	*	•	•	•
This LED indicates if a connection	RS232	Flashes On			
To the RS232 port is detected	Connection	with RS232	N/A	N/A	N/A
And flashes on with data activity	Detected	Data Activity			
485 BUS STATUS (BUS IN):	0		*	•	•
This LED Flashes on with 485 BUS	NO	On when	Flashes	N/A	N/A
Activity	DATA	Power	on with		
		present	Data Act.		
485 BUS STATUS (BUS OUT):	0		0	•	
This LED indicates upstream 485	Upstream	ON when	485 End		
Node(s) detected or 485 End of Line	Node(s)	NO RS232 is	of Line	N/A	N/A
	Detected	connected			

MOTOR PORT AMMETER:

This analog gauge indicates the total amount of current flowing through the motor ports in amps. This meter is very precise and can show quiescent current loads as low as 2mA.

The blue backlighting comes on when the ESM provides enough current to move the motor on the motor connectors.

NEUTRON USER KEYS (4)



NEUTRON KEYS UP/DOWN/RESET (3):

Neutron has 4 user keys. The UP, & DOWN KEYS are LOCKED by default to avoid unintentional presses. The RESET key is never locked. FUTURE USE






The black and white hand icon represents a KEY press & release






The solid orange hand icon represents a KEY press & hold, then release









The Status LED will illuminate with a GREEN color when the keys are locked









LOCKED





PRESS KEY; has no result







KEY LOCKED!


KEY LOCKED!

HOLD KEY; has no result



KEY LOCKED!

All LED's and BACKLIGHTING ARE OFF



KEYS ARE LOCKED: (Default)







KEY LOCKED!


PRESS KEY; has no result **KEY LOCKED! KEY LOCKED! HOLD KEY**; has no result **(EY;** has no result **KEY LOCKED!** (for 50 minutes after last Key press) GREEN STATUS LED **KEYS ARE LOCKED:** (Default) PRESS RESET KEY; Force reset, return to N KEY; has no result USER MODE **KEY LOCKED! HOLD RESET KEY;** if power is connected, WN KEY; has no result Forces reset, return to **KEY LOCKED!** USER_MODE If power is not connected switches to HIBERNATE ZZZ MODE

NEUTRON KEY ACTIONS (USER 🚣 MODE): 3 KEYS

LOCKED

NOTE: The Ammeter Blue Backlighting will turn on once any movement command is sent on or to the internal local 485 segment (Motor Ports) and turn back off after 5 minutes of inactivity on the internal local 485 segment.

MOTOR LIMIT TOOLS / 3rd PARTY CONTROL SYSTEMS:



When using motor limit setting tools, we recommend using the BUS OUT

TROUBLESHOOTING CALL US FOR HELP TOLLFREE +1 (844) 771-8725

ISSUE	POTENTIAL CAUSE:	REMEDY ACTION:
Neutron unit has no	Passive DC not	Check AC input on passive DC, check cable from output
power	connected	to BUS IN on UNIT
Shades have no power		A movement command must be sent on the bus to a
		connected motor for Neutron to provide power to the motor
Shades start to move	ESM LED IS AMBER	Check ESM LED, if the LED is not green, then the ESM
but then stop moving	or RED	needs time to harvest energy from the BUS IN, this can take a few hours
Shades start to move	ESM LED is GREEN	Ensure you are not overloading the motor port (Front
but then stop moving		motor ports 1Nm maximum per port, Rear motor ports
		7Nm maximum per port) If you have more than the port
		can provide move a motor off this port to another port
		that is not used in the same group, or you may need
4 (1)	405 BUILD O. III. :	additional Neutrons for this project
1 or more of the shades	485 BUS Collision	Check wiring of the motors not moving
in my group is not		
moving with the group The Neutron keeps	Passive PoE not	Neutron has a special feature to protect itself in the event
going back to Hibernate	providing power	of long power disruptions. Neutron will shut down if input
mode	providing power	power is lost; and after 3 hours and 45 minutes; and the
Iniouc		system (bus activity) has been idle for more than 30
		minutes
		Or the input power is lost; and the system (bus activity)
		has been idle for more than 30 minutes and ESM is very
		low.
		To remedy, re-apply power to the passive PoE and or if
		you need to move shades, hold the reset KEY for approx.
		6 seconds which will switch Neutron back to USER
		MODE

©2025 MODERN ATOMICS LLC - ALL RIGHTS RESERVED