

GAS/HEAVY-OIL DUAL BURNERS



Ecoflam
techniques for energy saving



Multiflam 500.1

Multiflam 600.1

PR/PR - MD/MD

Heavy oil / Natural gas 40÷300 mbar




LB 1472

28.09.2006


TECHNICAL DATA

| MODELS | | 500.1 | 600.1 |
|----------------------|--|-----------|-----------|
| Thermal power max. | kW | 5.000 | 5.800 |
| | kcal/h | 4.310.000 | 5.000.000 |
| Thermal power min. | kW | 1.200 | 1.500 |
| | kcal/h | 1.034.500 | 1.290.000 |
| Natural gas pressure | mbar | 40÷300 | 40÷300 |
| Voltage 50 Hz | V | 230/400 | 230/400 |
| Motor | kW | 11 | 15 |
| Rpm | N° | 2800 | 2800 |
| Fuel : | Natural Gas (L.C.V. 8.570 kcal/Nm³) Heavy oil (L.C.V. 9.800 kcal/kg max. visc 50°C at 50°C) | | |

WORKING FIELDS



DIMENSIONS D'ENCOMBREMENT



| Models | A | B | C | D | D1 | E | F | G | H | I | L | M | N | O |
|------------------------|------|-----|-----|-----|-----|------|-----|-----|-----|-----|-----|-----|-----|-----|
| Multiflam 500.1 | 1395 | 643 | 752 | 350 | 600 | 1118 | 320 | 778 | 400 | 330 | 330 | M16 | 195 | 250 |
| Multiflam 600.1 | 1395 | 643 | 752 | 350 | 600 | 1215 | 320 | 778 | 400 | 330 | 330 | M16 | 195 | 250 |

ELECTRICAL CONNECTIONS


All burners factory tested at 400 V 50 Hz three-phase for motors and 230 V 50 Hz monophase with neutral for auxiliary equipment. If mains supply is 230 V 50 Hz threephase withuot neutral, change position of connectors on burner as in fig. Protect burner supply line with safety fuses and any other devices required by safety standards obtaining in the country in question.

CONNECTION TO THE GAS PIPELINE

Once connected the burner to the gas pipeline, it is necessary to control that this last is perfectly sealed. Also verify that the chimney is not obstructed. Open the gas cock and carefully bleed the piping through the pressure gauge connector, then check the pressure value trough a suitable gauge. Power on the system and adjust the thermostats to the desired temperature. When thermostats close, the sealing control device runs a seal test of valves; at the end of the test the burner will be enabled to run the start-up sequence.

OPERATION OF BURNER WITH GAS

Before starting the burner, make sure it is mounted correctly. Then check connections are correct according to the diagram and piping is appropriate to the system. Before connecting the burner to the electricity supply, make sure voltage corresponds to burner plate data. The connection diagram and start-up cycle are shown separately. For wiring from control box to burner, see the enclosed connection diagram. Pay particular attention to neutral and phase connections : never exchange them!. Vent air and impurities of gas pipe. Check gas pressure conforms to the limits stated on the burner plate when connecting a master gauge to the test port provided on the burner. Blower motor starts and pre-purging begins. Since pre-purging has to be carried out with the max. air delivery, the burner control circuit turns the air damper to the max. delivery position by the air servocontrol in approximately 30 seconds time. When the servocontrol is fully open, a signal to the electronic control unit starts the 36 seconds pre-purge cycle. At the end of the prepurging time, the air servocontrol gets to the Low Flame position so that burner ignition is ensured at min. output. Simultaneously the ignition transformer receives voltage and after 3 seconds (pre-ignition) opens the pilot gas valve. Fuel flows to the combustion head and ignites. Two seconds after pilot gas valves have opened, the ignition transformer is excluded from the circuit. In case of no ignition the burner goes to lock-out within two seconds. After 6 sec. open the working gas valve, governed by the gas firing butterfly valve. Now the burner is operating at the min. firing rate (about 30% of the max. firing rate). The air servocontrol runs at the Low Flame position and in case the temperature control has to be set at the max. output it goes to a fully open position of air damper and butterfly valve. During the burner-off periods the air damper closes up fully.




ADJUSTING THE COMBUSTION PROCESS

IMPORTANT: to obtain the right adjustment of the combustion and thermal capacity it is important to analyze the reducts of combustion with the aid of suitable instruments. The combustion and thermal capacity adjustment is done simultaneously, together with the analysis of the products of combustion, making sure that the measured values are suitable and that they comply with current safety standards. On this matter, please refer to the table and figure below.

THESE OPERATIONS MUST BE DONE BY PROFESSIONALLY-QUALIFIED TECHNICIANS.

| | |
|-----------------|----------|
| | Metano |
| CO ₂ | 9,6% |
| CO | <100 ppm |
| | GPL |
| CO ₂ | 11,7% |
| CO | <50 ppm |



COMBUSTION ADJUSTMENT


WARNING: In order to have a correct combustion and thermal output adjustments, these must be carried out together with a combustion analysis, to be executed through suitable devices, taking care that the values are the correct ones and are in accordance with the local safety regulations. The adjustments must be carried out by qualified and skilled technicians authorised by Ecoflam S.p.A.

LANDIS & STAEFA, Model LFL1.333 OPERATING CYCLE

| Ref. | Description | Duration |
|------|---|----------|
| t1 | Duration Waiting time for confirmation of air pressure | 8" |
| t3 | Preventilation time | 36" |
| t4 | Safety time | 2" |
| t5 | Pressurizing time | 4" |
| | Time for enabling operation of the main gas valve on minimum capacity | 10" |
| t6 | Time for enabling operation of the main gas valve on maximum capacity | 10" |

The control box starts the burner fan, to carry out the prepurging of the combustion chamber, and checks the vent air pressure through the air pressure switch. At the end of prepurging, the ignition transformer cuts-in and generates a spark between the electrodes. At the same time the two gas valves

open (Vs safety valve and V1 working valve). The total safety, in case of missed ignition or casual burner's flame-out, is granted by a ionisation probe which cuts-in and sets the burner shutdown within the safety time. In case of gas lack or a major pressure drop, the minimum air pressure switch shuts down the burner.



LANDIS & STAEFA SQM 50.481A2 AIR DAMPER MOTOR

Remove cover to gain access to the adjusting cams. The cams are to be adjusted through the suitable key provided for. Description:




Manual change

- I - High flame operating opening position adjusting cam (Heavy-Oil /Gas).
- II - Limit switch for the air damper position at burner's shut down.
- III - Ignition flame opening position adjusting cam (Gas).
- IV - Ignition flame opening position adjusting cam(Heavy-Oil).
- V - Low flame operating opening position adjusting cam (Gas).
- VI - Low flame operating opening position adjusting cam (Heavy-Oil).
- VII - Not used cam.
- VIII - Not used cam.



AIR AND GAS ADJUSTMENT



ADJUSTING THE MINIMUM CAPACITY OF THE BURNER – AIR and GAS

Position the selector placed on the control panel on position 2 and proceed as follows:
Adjust the minimum gas flow rate using a suitable wrench, turn the butterfly valve until you reach the correct gas flow, as established by analyzing the combustion process.

ADJUSTING THE MAXIMUM CAPACITY OF THE GAS

Position the selector, situated on the control panel, on position 1 and proceed as follows:
Adjusting the maximum gas flow rate (see figure on solenoid valve adjustments) or adjust the gas pressure in the governor.

ADJUSTING THE MAXIMUM AIR FLOW RATE

Adjusting the maximum air flow rate (see figure, detail 2). Loosen the nut holding the air damper transmission rod;
The correct air flow as established by analyzing the combustion process.

ADJUSTING THE INTERMEDIATE BURNER CAPACITY

Using the selector, start the servomotor (closing or opening) and position on 0 to stop the stroke; the adjustment is made as outlined below. Repeat the operation for the other cam points.
Adjustment the intermediate gas flow rates (see figure, detail 3): - using a suitable Allen wrench, change the position of the cam guide blade; if you screw it down, the flow rate is reduced; if you unscrew it, the flow rate increases.

CALCULATING THE BURNER CAPACITY


To calculate the burner's capacity in kW, proceed as follows: Check the gas flow rate (in liters) on the counter and the time of the reading in seconds.

Proceed with the calculation using the following : $\frac{e}{sec} \times f = kW$

| | | |
|-----|---|----------------|
| e | = | Litres gas |
| sec | = | Time in second |
| f | [| G20 = 34,02 |
| | | G30 = 116 |
| | | G31 = 88 |

ADJUSTMENT OF GAS MINIMUM PRESSURE SWITCH

Unscrew off and remove cover M. - Set regulator N to a value equal to 60% of gas nominal feed pressure (i.e. for nat. gas nom. pressure = 20 mbar, set regulator to a value of 12 mbar; for L.P.G. nom. pressure of G30/G31- 30/37 mbar, set regulator to a value of 18 mbar).Screw up cover M



ADJUSTMENT OF THE AIR PRESSURE SWITCH


Unscrew screws A and B and remove cover C.- Set the pressure switch to the minimum by turning regulator D to position 1.
 - Start the burner and keep in low flame running, while checking that combustion is correct. Through a small cardboard, progressively obstruct the air intake until to obtain a CO₂ increase of 0,5±0,8% or else, if a pressure gauge is available, connected to pressure port E, until reaching a pressure drop of 1 mbar (10 mm of W.G.). - Slowly increase the adjustment value of the air pressure switch until to have the burner lockout. Remove the obstruction from the air intake, screw on the cover C and start the burner by pressing the control box rearm button.

Note: The pressure measured at pressure port E must be within the limits of the pressure switch working range. If not, loose the locking nut of screw F and gradually turn the same: clockwise to reduce the pressure; counterclockwise to increase. At the end tighten the locking nut.


NOZZLE CLEANING AND REPLACEMENT

Use only the suitable box wrench provided for this operation to remove the nozzle, taking care to not damage the electrodes. Fit the new nozzle with the same care.


Note: Always check the position of electrodes after having replaced the nozzle (see illustration). A wrong position could cause ignition troubles.



POSITION OF IGNITION ELECTRODES



IONIZATION CURRENT




The ionization current is checked by inserting a microammeter with an end of scale of 50 µA (d.c.) in series with the ionization probe. A faulty position of the electrode can lead to a reduction in the ionization current and cause a safety cut-out of the burner due to a flame detection failure. In this case, check the position of the electrode, its electric connection and the earthing of the burner. The ionization current is normally > 20 µA.

REMOVING THE FIRING HEAD




PUMP'S PRESSURE / OIL TEMPERATURE DIAGRAM

Pump inlet pressure: the vaporisation of light fraction of heated heavy oil causes premature pump wear, to avoid this, use the inlet pressures shown in the graph.



HEAVY OIL FEEDING

- 1 - Inlet
- 2 - Return
- 3 - Bleed and pressure gauge port
- 4 - Vacuum gauge port
- 5 - Pressure adjustment
- 6 - Nozzle outlet




WARNING: For a correct working of the pump, verify what follows:

- Pump : SUNTEC TA4C40105
- Oil temperature at the pump: Max. 140 °C
- Maximum allowable pressures: Max. 5 bar on inlet


TYPE OF INSTALLATION

The burner must be supplied with oil heating a min. temperature at the pump (50° C).

Drawing for fluid fuel oil up to 50°E at 50°C



Drawing for heavy fuel oil up to 50°E at 50°C





BEFORE PROCEEDING WITH THE FILLING OF THE OIL SYSTEM, CHECK THE FOLLOWING POINTS:

- Motor's direction of rotation (with 3phase version)
- There must be fuel in the tank
- Fuel cocks must be open
- Fuel return piping must be free from obstructions

After having checked all the above items, proceed as follows:

- Connect a fuel pressure gauge
- Set OUT1 - OUT1 - OUT3 - OUT 4 to 0°C on GEFRAN regulator
- Disconnect the resistors power cable from the motor's remote control switch, and insulate it temporarily
- Unplug the safety box
- Start the burner and manually operate the motor's remote control switch until the oil system is filled up. Note: the oil system can be considered filled when pressure gauge will show a constant reading of 16÷18 bar.



When done, shut off the burner, switch off power and restore initial conditions as follows:

- Reconnect resistors power cable
- Set OUT1 - OUT1 - OUT3 - OUT 4 on GEFRAN regulator to the initial value.
- Plug in the control box


CHECKS TO BE MADE TO ENSURE A PROPER INSTALLATION:

Before proceeding with the filling of the fuel system and subsequent burner start up, it is advisable to carry out the following checks:

- Power line must be adequate to system's adsorbed load
- Fuses must be adequate to the system's load
- Boiler's thermostats must have been properly connected
- Voltage and frequency must be within the specified limits
- Fuel type must be the one specified by the burner manufacturer
- Feed piping section must be adequate to the requested fuel flow rate
- Filters, cocks as well as fittings must have been properly installed
- Blast tube length must be the one specified by the boiler manufacturer
- Nozzle's flow rate of the burner must be adequate to boiler's output

MODULATING OPERATION

With the burner in the start position and the appliance thermostats enabled, power is delivered to the resistances (G) of the preheater and heating cartridges for the pumps and the fuel supply line to the head (O). When the preheater thermostat reaches the set value, (usually a minimum of about 90°C is necessary to guarantee a good level of circulation) the pump start-up is enabled (set point on out 1, if using the GEFTRAN 200 thermoregulating device). If the preheating system of the tank is also equipped for a fluid exchanger (hot water, steam, diathermic oil) the thermostat may enable a contact in the terminal block for any stop-start of the fluid electrovalve. This is not a standard solution as the heated fluid is normally always connected. The pump starts to send oil (the head has already been heated by its cartridge (O) and therefore has no residue of cold dense oil) which flows from the tank to the head and then to the return line of the ring. When the head thermostat reaches the set value (usually about 70-30°C the cycle starts properly and the control programmer enables start-up. The servomotor sets itself at minimum (see chapter on regulation) acting on the air and fuel via the pressure regulator on the return.



The electromagnet (A) opens the nozzle (Q) in the following condition :

- sparks from the ignition electrodes are generated by the transformer also governed by the burner control device.

If the cell fails to detect the flame the burner shuts down (with the cyclic control programmer cutting in). Once ignition has taken place and after the flame stabilisation period, the system starts operating in modulating mode.

- Before start-up make sure that the pump and delivery pipes are completely filled with hot fuel oil; the absence of fuel oil can cause pump seizure.
- If there is a block, a specific warning light on the programmer and on the burner front control board lights up and this signal is usually sent to the main control board of the equipment using the burner, setting off a buzzer and warning light.
- A few blocks are normal on first starting up (up to about 4); to release press the button on the programmer (also found on the front of the burner control board) for repeating the start cycle. Should they continue to occur seek the help of a specialised technician.

N.B. The position of the programmer at the time of the block is memorised to supply an indication of the cause of this block.

OIL DELIVERY ADJUSTMENT

The diagram illustrates the fuel feeding system of these types of burners, which incorporates a by-pass nozzle with oil flow regulation on its return pipe. The oil supply is varied by acting on the nozzle through the pressure in the return line. Max. oil supply is therefore reached when the pressure in the pump line is about 22 bar and the return line is fully closed; min. oil supply when the return line is fully open. Relevant pressure readings in the return line are as follows:

Pump pressure 22-25 bar.

Max Burner output, return oil pressure:


FLUIDICS nozzle : 16 ÷ 19 bar.

BERGONZO nozzle : 20 ÷ 24 bar.


Min Burner output, return oil pressure:

FLUIDICS nozzle : 6 ÷ 9 bar

BERGONZO nozzle : 4 ÷ 8 bar




PRE - PURGING PHASE




- LEGEND :
- A Solenoid valve (N.C.)
 - D Regulator
 - E Tank
 - F Anti - gas valve
 - G Resistance of the preheater
 - H Pipe filter
 - I Oil pump
 - N Manometr
 - O Resistance of combustion head
 - P Oil temperature sensor
 - Q Oil nozzle

Charles Bergonzo S.A. Moutier (suisse)



FLUIDICS NOZZLE



ADJUSTMENT OF FUEL TEMPERATURE



The display shows oil temperature.

The 4 leds are related to the following functions:

Out 1: contact driving working heaters

Out 2: contact driving upper heaters KMRL1

Out 3: contact driving upper heaters KMRL2

Out 4: Burner start driving contact (as the oil reaches this temp the pump is activated)

- The temperatures are already properly Factory setted :

Out 1(113°)- Out 2(115°)- Out 3(120°)- Out 4(105°).

- To modify factory temperature setting act as follows:


- press key "F"

- the led Out1 starts to flash, if You need to modify minimum oil temperature press increase or decrease button, after confirm the new value pressing again "F"

- if You need to modify an other temperature press again "F" untill You the relevant led flashes.


Please take care: if key "F" is pressed for a too long time, You enter in "configuration level" phase1, (see "CF1" on the display); these parameters are Factory setted and they have not to be modified: if You enter this function – You see CF1 flashing on the display – wait 10 seconds untill the regulator automatically goes out from "configuration level".

DESCRIPTION OF THE CONTROL PANEL OF THE BURNER




RWF 40 MICROPROCESSOR REGULATOR

Description of display and keys on the RWF 40 microprocessor regulator



PROGRAMMING LEVELS



SETTING PARAMETERS

When the burner is ignited all displays of the regulator light up. The set point display will blink for about 10 seconds. The value in the upper field of the display (red) indicates the actual value. The value in the lower field of the display (green) indicates the set point currently programmed.

CHANGING THE SET POINT

To change the set point, proceed as follows: - Press the **PGM** button to access the user level. SP1* will appear in the lower display - Change the value of set point SP1 using the t and s keys. ▼ ▲. - After a 2 second delay the value set is stored automatically - To return to normal display press **EXIT**.

* The value of SP1 depends on the value set previously in configuration level C111.

SETTING PID PARAMETERS

PID parameters are factory set to standard mean values. The operation of the regulator can be self-adapted to suit the system by activating the “tunE” function. The regulator will set the PID parameters automatically. To activate the “tunE” function proceed as follows: - With the burner in operation, press **PGM** + ▼. - the caption “tunE*” will blink in the display. - When “tunE” stops blinking, the self-adaptation routine has been completed. - Confirm the computed parameters by pressing the ▲ key for 2 seconds.

* The “tunE” function cannot be activated in Manual mode, or when the burner is off.

The PID parameters can be corrected manually from the parameters level, working on the proportional band Pb1, the derivative action time dt and the integral action time rt.

To change parameters Pb1, dt and rt, proceeds as follows: - Press the **PGM** button to access the parameters level. - To move from one parameter to the next, press **PGM** . - When Pb1 is displayed, the value can be increased or decreased using the s and t keys. - Confirm the changed parameters by pressing **PGM**. - If confirmation is not given within 2 seconds the value will be stored automatically. - Press **PGM** to access the next parameter. - When dt is displayed, repeat the procedure described above. - Press **PGM** to access the next parameter. - When rt is displayed, repeat the procedure above. - To return to normal display press **EXIT**.

DIFFERENTIAL SETTING FOR IGNITION AND SHUTOFF

The regulator allows the selection of an adjustable switching differential that establishes burner ignition and shutoff values. HYS1 indicates the lower ignition limit, below which the regulator switches the burner to maximum power. HYS3 indicates the upper shutoff limit, above which the regulator switches the burner off. To set HYS1 and HYS3 proceed as follows: - Press the **PGM** key to access the parameters level. - To move from one parameter to the next, press **PGM** . - When HYS1 is displayed (burner ignition differential-stage II), increase or decrease the value using the ▼ and ▲ keys. - Confirm the changed parameters by pressing **PGM**. - If confirmation is not given within 2 seconds the value will be stored automatically. - Press **PGM** to access the next parameter. - When HYS2 is displayed (burner shutoff differential-stage II), repeat the procedure described above. - Press **PGM** to access the next parameter. - When HYS3 is displayed (upper shutoff differential) repeat the procedure described above. - To return to normal display press **EXIT**.

MANUAL/AUTOMATIC MODE

To access “MANUAL” mode, press and hold **EXIT** for at least 5 seconds. Manual mode can only be selected when the burner is in operation. It is deactivated automatically when the burner shuts off. When the LED above the hand symbol is alight, the regulator is in manual mode and the position of the servocontrol can be changed using the ▼ and ▲ keys. The LEDs on the front of the regulator indicate whether the servocontrol OPEN or CLOSE command is currently active. Pressing the ▼ key the servocontrol OPENS. Pressing the ▲ key the servocontrol CLOSES. To select automatic mode press and hold **EXIT** for at least 5 seconds. The LED above the hand symbol goes out and the regulator reverts to automatic.


CLIMATIC COMPENSATION

The RWF 40 regulator can be set with the set point interlocked to the external probe. To select this operating mode, proceed as follows: - Connect the required probe as in the wiring diagram. - Change the regulator settings. When using an external probe the regulator must be set as follows: - Press the **PGM** key to access the configuration level. When the caption C111 (XXXX) is displayed, use the ▲ key to access the second figure (XXXX). Use the ▼ key to select the type of probe (XX3X). - Confirm the change of parameters by pressing **PGM**. If this is not done within 2 seconds, the value is stored automatically - Press **PGM** to access the configuration level. When the display reads C112 (XXXX), use the ▲ key to access the second figure (XXXX). Press the ▼ key to set the type of probe (XX3X). - Confirm the changed parameters by pressing **PGM**. - If confirmation is not given within 2 seconds the value will be stored automatically.

- To return to normal display press **EXIT**. To establish the heating curve, proceed as follows:

- Press **PGM** to access the parameters level. - Press **PGM** to move from one parameter to the next. - When the letter H is displayed (heating curve gradient), increase or decrease the value using the ▼ and ▲ keys. - Confirm the changed parameters by pressing **PGM**. - If confirmation is not given within 2 seconds the value will be stored automatically.

- To return to normal display press **EXIT**.




PROBE CONNECTION DIAGRAMS



Cod. S721

Connection for probe QAE2..(passive probe)
Water probe
Configuration code
C111 = 9XXX




Cod. S704

Connection for probe FT-TP/..(passive probe)
(Degusa probe)
Configuration code
C111 = 5XXX




Cod. S731
S731/1
S731/2
S731/3
S731/4

Connection for probe QBE620-P..(active probes)
Configuration code
C111 = GXXX
S731 - 0...4 bar / 0...400 kPa
QBE620-P4
S731/1 - 0...10 bar / 0...1 MPa
QBE620-P10
S731/2 - 0...16 bar / 0...1.6 Mpa
QBE620-P16
S731/3 - 0...25 bar / 0...2.5 MPa
QBE620-P25
S731/4 - 0...40 bar / 0...4 MPa
QBE620-P40



Cod. S720/1

Connection for probe QAC22 (passive probe)
Configuration code
C111 = XX3X
C112 = XX1X



C111 – C112 INPUT CONFIGURATION INDICATIONS

| Analog input 1 (actual value) | |
|--|---|
| Pt1000, 2-wire, Landis & Staefa IEC 751 FT-TP/... (passive probe) | 5 |
| Ni1000, 2-wire, Landis & Staefa QAE2 ... (passive probe - water probe) | 9 |
| Standard Signal DC 0...10 V QBE620P... (active probe - pressure probe) | G |



| Analog Input 3 (external temperature) | |
|---|---|
| No function (probe not active) | 0 |
| External probe Pt 1000, 2-wire, QAC22 (passive probe) | 1 |

**AUXILIARY CONTACT, TYPE OF REGULATOR, SET POINT “SP1”
BLOCK C112. Parameter configuration**



| Set point “SP1” | |
|---|---|
| Set point SP1 - data input from keys | 0 |
| Set point SP1 - interlocked to external probe (configure) | 1 |

**ERROR/FAULT INDICATION
NUMBERS BLINKING IN DISPLAY**



- **Situation** - The number *1999* blinks in the display as the actual value, with the set point value displayed normally.
- **Cause** - The real value is not being measured. This means that the upper or lower limit of the measurement range on analog input 1 (real value) has been exceeded.
- **Remedy** - Check the electrical connections and the state of the probe. If the probe is faulty, the regulator will not indicate the real value of the physical quantity monitored. This will result in automatic shutdown (failsafe), **deactivation of the self-adapt function and inhibition of manual operation**. The response of the auxiliary contact will depend on the configuration of parameter C113.




- **Situation** - The number *1999* blinks in the display as the actual value, with tA showing in the set point field.
- **Cause** - The external temperature is not being measured. This means that the upper or lower limit of the measurement range on analog input 3 (real value) has been exceeded.
- **Remedy** - Check the electrical connections and the state of the probe. If the probe is faulty, the regulator will not indicate the real value.



- **Situation** - The number *1999* blinks in the display as the actual value, with SP .E showing in the set point field.
- **Cause** - The external set point value is not being measured. This means that the upper or lower limit of the measurement range on analog input 2 (real value) has been exceeded.
- **Remedy** - Check the electrical connections and the external set point signal. If the probe is faulty, the regulator will not indicate the real value of the physical quantity monitored. This will result in automatic shutdown (failsafe), **deactivation of the self-adapt function and inhibition of manual operation**.

WHEN REPLACEMENT IS NECESSARY, PROCEED AS SHOWN IN FIGURES A-B-C BELOW



Insert the RWF 40 regulator through the relative opening in the electrical panel (A).
 Insert the fixing anchors and screws into the slots, and secure the unit to the panel (B).
 To open the regulator, squeeze the cover from the ends as shown, and lift out (C).

MAINTENANCE

ANNUAL CHECK

The burner (combustion head, electrodes, etc.) must be checked regularly by an authorized technician, once or twice a year, depending on how much it is used. Before proceeding with the maintenance check-up on the burner, it is advisable to check the general condition of the burner and take the following steps: Disconnect the burner (remove the plug).

- Close the gas shut-off cock.
- Remove the cover from the burner, clean the fan and air intake.
- Clean the combustion head and check the position of the electrodes.
- Re-install the parts.
- Check the seal on the gas connectors.
- Check the state of the flue.
- Start the burner.
- Check the combustion parameters

BEFORE TAKING ANY ACTION, CHECK:

- that there is power in the circuit and the burner is connected;
- that the gas pressure is right and the gas shut-off cock is open;
- that the control systems are properly connected. If all these conditions have been satisfied, start the burner by pressing the reset button. Check the burner cycle.

IF THE BURNER FAILS TO START:

check the switch, the thermostats, the motor and the gas pressure, fuses burnt, resistors failure, heater thermostats open.

IF THE BURNER PROCEEDS WITH PREVENTILATION BUT CUTS OUT AT THE END OF THE CYCLE:

check the air pressure and the fan. Check the air pressure switch, UV cell failure, premature ignition due to oil leakage from solenoid valve.

IF THE BURNER PROCEEDS WITH PREVENTILATION BUT DOES NOT LIGHT:

check the installation and position of the electrodes. Electrodes dirty. Nozzles clogged. Check the ignition cable. Check the ignition transformer. Check the safety device. Eccles of combustion air related to nozzles flow rate.

IF THE BURNER LIGHTS BUT CUTS OUT AFTER THE SAFETY INTERVAL:

check that the phase and neutral wires are connected correctly.
 Check the gas solenoid valve. Check the UV cell. Check the safety device. The oil pressure during prepurging is too low. Filters clogged. Nozzles are too worn. The oil temperature is too low (flame jumps). Eccles of combustion air related to nozzles flow rate

IF THE BURNER LIGHTS BUT CUTS OUT AFTER OPERATING FOR A FEW MINUTES:


check the pressure regulator and gas filter. Check the gas pressure with a pressure gauge. Check the detector value (at least 70 μ A).

PARAMETERS

| Parameter | Display | Ecoflam setting | Ecoflam setting | Ecoflam setting |
|---|---------|--------------------------|-------------------------------|-------------------------------|
| | | (passive probe) QAE22 | (passive probe) FT-TP/1000 | (active probe) QBE620-P... |
| Limit value of limit comparator | AL | 0 | 0 | 0 |
| Switching differential for limit comparator | HYS1 | 0 | 0 | 0 |
| Proportional band | Pb.1 | 8 | 8 | 1 |
| Derivative time | dt | 20 | 20 | 3 |
| Integral action time | rt | 80 | 80 | 15 |
| Dead band (neutral zone) | db | 0.5 | 0.5 | 0.5 |
| Actuator running time (sec.) | tt | 25 | 25 | 25 |
| Switch-on threshold burner / stage II | HYS1 | -2 | -2 | -0.2 |
| Switch-off level stage II | HYS2 | 0 | 0 | 0 |
| Upper switch-off threshold | HYS3 | 5 | 5 | 0.5 |
| Response threshold | q | 0 | 0 | 0 |
| Heating curve slope | H | 2 | 2 | 2 |
| Parallel displacement | P | 0 | 0 | 0 |

CONFIGURATION

| Parameter | Display | Ecoflam setting | | | | | | |
|---|---------|-----------------|------------|----------------------------|------|------|------|------|
| | | (passive probe) | | (active probe) QBE620-P... | | | | |
| | | QAE22 | FT-TP/1000 | -P4 | -P10 | -P16 | -P25 | -P40 |
| Analog input 1, 2 and 3; setpoint changeover / shift | C111 | 9030 | 5030 | G000 | G000 | G000 | G000 | G000 |
| Limit comparator; controller type; setpoint 1; locking | C112 | 0010 | 0010 | 0010 | 0010 | 0010 | 0010 | 0010 |
| Unit address; decimal place / unit, signal for out-of-range | C113 | 0110 | 0110 | 0110 | 0110 | 0110 | 0110 | 0110 |
| Measured value range start analog input 1 | SCL | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Measured value range analog input 1 | SCH | 100 | 100 | 4 | 10 | 16 | 25 | 40 |
| Measured value range analog input 2 | SCL2 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Measured value range analog input 2 | SCH2 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Lower setpoint limit | SPL | 60 | 60 | 0 | 0 | 0 | 0 | 0 |
| Upper setpoint limit | SPH | 88 | 88 | 4 | 10 | 16 | 25 | 40 |
| Actual value correction, analog input 1 | OFF1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Actual value correction, analog input 2 | OFF2 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Actual value correction, analog input 3 | OFF3 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Filter time constant for digital filter, analog input 1 | dF1 | 1 | 1 | 0 | 0 | 0 | 0 | 0 |




SMA
 COMANDO MANUALE
 INTERRUTTORE
 COMPLESSIVO ALIMENTATO
 PER IL CONTROLLO MANUALE
 DELLA VALVOLA
 PER IL CONTROLLO MANUALE
 DELLA VALVOLA

| | | | |
|---------------------------------------|-------------|---------------------------------------|-------------|
| IND. MOD. | IND. MOD. | IND. MOD. | IND. MOD. |
| SIST. SOST. | SIST. SOST. | SIST. SOST. | SIST. SOST. |
| DATA/FIRMA | DATA/FIRMA | DATA/FIRMA | DATA/FIRMA |
| DESCRIZIONE MODIFICA | | DESCRIZIONE MODIFICA | |
| DISCENSO | | DISCENSO | |
| CONTROLLATO | | CONTROLLATO | |
| 06/09/2006 | | 06/09/2006 | |
| P.A. | | P.A. | |
| /A/C/... | | /A/C/... | |
| FIRMA | | FIRMA | |
| DATA | | DATA | |
| 01 | | 01 | |
| 04 | | 04 | |
| 05 | | 05 | |
| 06 | | 06 | |
| 07 | | 07 | |
| 08 | | 08 | |
| 09 | | 09 | |
| MOTORIZZATORE | | MOTORIZZATORE | |
| LANDIS SQM 50481A2 | | LANDIS SQM 50481A2 | |
| CODICE | | CODICE | |
| BEM44025 | | BEM44025 | |
| SET/RINNOV | | SET/RINNOV | |
| UV | | UV | |
| CONTROLLO DI TERZA | | CONTROLLO DI TERZA | |
| DUNG VPS 504 | | DUNG VPS 504 | |
| DENOMINAZIONE | | DENOMINAZIONE | |
| MULTIFLAM 300.1 - 400.1 - 500.1 PR/PR | | MULTIFLAM 300.1 - 400.1 - 500.1 PR/PR | |
| APPARECCHIATURA | | APPARECCHIATURA | |
| LANDIS LFL 1.622 | | LANDIS LFL 1.622 | |
| Ufficienza - Settore Elettrico | | Ufficienza - Settore Elettrico | |
| Ecoflam S.p.A. | | Ecoflam S.p.A. | |
| Ecoflam S.p.A. | | Ecoflam S.p.A. | |

PROPRIETA' RISERVATA DELLA DITTA ECOFLAM S.P.A.
 A TERMINI DI LEGGE È VIETATO RIPRODURRE O
 COMUNICARE A TERZI IL CONTENUTO DEL PRESENTE.

| A | | B | | C | | D | | E | |
|---|--|----|---|-----|---|-----|---|------------------|--|
| Q | INTERRUTTORE GENERALE CON FUSIBILE MAIN SWITCH WITH FUSE INTERRUPTEUR GENERAL AVEC FUSIBLE INTERRUPTOR GENERAL CON FUSIBLE | 51 | FINCORDERA LIMIT SWITCH INTERRUPTEUR DE FIN DE COURSE LIMITADOR DE CARRERA | MHP | MOTORPOMPA OIL PUMP MOTOR MOTEL PUMPE MOTORBOMBA | HIF | LAMPADA DI FUNZIONAMENTO WORKING LAMP ECLAIRAGE DE FONCTIONNEMENT ESPALE DE FUNCIONAMIENTO | PAGINA LB 2/2 | |
| Z | FILTRO ANTISTURBO ANTI-KICK FILTER FILTRE ANTISTURBO | | CONVETTORIAVORE VENTILATORE REMO CONTROL SWITCH (FAN MOTOR) CONDUCTEUR A MOTEUR VENTILATEUR TELEBIP MOTOR VENTILATOR | | | | | | |
| FU | FUSIBILE FUSE FUSIBLE | | CONVETTORIAVORE VENTILATORE REMO CONTROL SWITCH (FAN MOTOR) CONDUCTEUR A MOTEUR VENTILATEUR TELEBIP MOTOR VENTILATOR | | | | | | |
| FU | FUSIBILE FUSE FUSIBLE | | INTERMITTORE DI LINEA WORKING SWITCH FUSIBLE INTERRUPTEUR DE LINEA | | | | | | |
| KA | RELE RELAY RELAIS RELÉ | | PRESSOSTATO D'ARIA AIR PRESSURE SWITCH PRESOSTATO D'ARIA PRESOSTATO D'ARIA | | | | | | |
| MV | MOTORE VENTILATORE MOTOR FAN MOTEL VENTILATEUR MOTORBOMBA | | TERMOSTATO CALDAMIA BOILER THERMOSTAT THERMOSTAT CHAUFFE TERMOSTATO CALDAMIA THERMOSTAT CALDERA | | | | | | |
| RA | RESISTENZA A SOLIDURA RESISTANCE AU LAURE RESISTENCIA A SOLDERA | | TERMOSTATO DI SICUREZZA RESISTENZE THERMOSTAT TO SECURE RESISTANCES TERMOSTATO DE SEGURIDAD RESISTENCIAS | | | | | | |
| RP | RESISTENZA POMPA PUMP RESISTOR RESISTANCE POMPE RESISTENCIA BOMBA | | TERMOSTATO DI SICUREZZA SAFETY THERMOSTAT THERMOSTAT DE SECURITE TERMOSTATO DE SEGURIDAD | | | | | | |
| TV | TRASFORMATORE TRANSFORMER TRANSFORMATEUR TRANSFORMADOR | | INTERNORE OIL GAS INTERNEUR FUEL LIQUID - GOZ INTERTRIPPER ACETE PESADO - GOZ | | | | | | |
| UV | FOTOCELLA UV CELL CELLULE UV FOTOCELULA | | ELETTRONVALVOLA GAS DI PRIMA FAMMA FIRST STAGE GAS SOLENOID VALVE ELECTRONVAVNE GAZ PETITE ALLURE ELECTRONVALVULA GAS DE 1ª LLAMA | | | | | | |
| FNP | RELE TERMICO MOTORE POMPA THERMAL RELAY MOTOR PUMP RELAIS THERMIQUE MOTEUR PUMPE RELÉ TÈRMIC MOTEUR BOMBA | | ELETTRONVALVOLA GAS DI SICUREZZA SECURITY GAS SOLENOID VALVE ELECTRONVAVNE GAZ DE SECURITE ELECTRONVALVULA GAS DE SEGURIDAD | | | | | | |
| FNV | RELE TERMICO MOTORE VENTILATORE MOTOR THERMAL RELAY FAN MOTOR RELAIS THERMIQUE MOTEUR VENTILATEUR RELÉ TÈRMIC MOTEUR VENTILADOR | | ELETTRONVALVOLA GAS DI SICUREZZA SECURITY GAS SOLENOID VALVE ELECTRONVAVNE GAZ DE SECURITE ELECTRONVALVULA GAS DE SEGURIDAD | | | | | | |
| Hgh | LAMPADA GAS GAS LAMP LAMPE DE 27' ALLURE ESPALE DE 1ª LLAMA | | ELETTRONVALVOLA GAS DI SICUREZZA SECURITY GAS SOLENOID VALVE ELECTRONVAVNE GAZ DE SECURITE ELECTRONVALVULA GAS DE SEGURIDAD | | | | | | |
| Hmb | LAMPADA MOTO 2-27FAHLE LAMP LAMPE DE 27' ALLURE ESPALE DE 2ª LLAMA | | ELETTRONVALVOLA MANTENIMENTO APERTA NORMALLY OPEN SOLENOID VALVE ELECTRONVAVNE NORMALEMENT AVERT ELECTRONVALVOLA MANTENIMIENTO ABIERTA OIL SHUT-OFF SOLENOID | | | | | | |
| Hb | LAMPADA DI BRACCIO LOCKOUT LAMP LAMPE DE BRAS ESPALE DE BRACCIO | | CONVETTORIAVORE RESISTENZE DI LAVORO WORKING RESISTOR SWITCH INTERRUPTEUR DES RESISTANCES DE TRAVAIL INTERRUPTEUR DE LAS RESISTENCIAS DE TRABAJO | | | | | | |
| Hr | LAMPADA RESISTENZE RESISTOR LAMP TÈMON RESISTENCES INDICADOR RESISTENCIAS | | PRESSOSTATO GAS DI MINIMA GAS PRESSURE SWITCH MIN PRESOSTATO GAS DI MINIMA POT PRESOSTATO GAS DE MINIMA POT | | | | | | |
| KA1 | RELE RELAY RELAIS RELÉ | | CONVETTORIAVORE RESISTENZE DI RILAMBIAMENTO LEVELLING RESISTOR SWITCH INTERRUPTEUR DES RESISTANCES DE NIVELLEMENT INTERRUPTEUR DE LAS RESISTENCIAS DE NIVELACION | | | | | | |
| KA2 | RELE RELAY RELAIS RELÉ | | CONVETTORIAVORE RESISTENZE DI LIVELLAMENTO LEVELLING RESISTOR SWITCH INTERRUPTEUR DES RESISTANCES DE NIVELLEMENT INTERRUPTEUR DE LAS RESISTENCIAS DE NIVELACION | | | | | | |
| KA3 | RELE RELAY RELAIS RELÉ | | ELETTRONVALVOLA GAS DI PILOTO PILOT GAS SOLENOID VALVE ELECTRONVALVULA GAS DE PILOTE | | | | | | |
| | | | TERMOSTATO DI ALTA-BASSA FAMMA HIGH-LOW/FANME THERMOSTAT THERMOSTAT DE HAUTE-BASSE ALLURE TERMOSTATO DE ALTA-BAJA LLAMA | | | | | | |
| <p>REGOLAZIONE CAMME PER MULTIFLAM 300.1 - 400.1</p> <p>(07) I. CAMMIA DI REGOLAZIONE ARIA MASSIMA FAMMA GAS MFTA (07) II. CAMMIA DI REGOLAZIONE CHIUSURA TOTALE (07) III. CAMMIA DI REGOLAZIONE ARIA ACCENSIONE GAS (07) IV. CAMMIA DI REGOLAZIONE ARIA ACCENSIONE MFTA (07) V. CAMMIA DI REGOLAZIONE ARIA BASSA FAMMA GAS (07) VI. CAMMIA DI REGOLAZIONE ARIA BASSA FAMMA MFTA (07) VII. CAMMIA NON UTILIZZATA (07) VIII. CAMMIA NON UTILIZZATA</p> | | | | | | | | | |
| <p>USCITE RELE DEL REGOLATORE</p> <p>OUT 1: KMRLA OUT 2: KMRL1 OUT 3: KMRL2 OUT 4: TERMOSTATO DI ACCENSIONE</p> | | | | | | | | | |
| <p>REGOLAZIONE CAMME PER MULTIFLAM 300.1 - 400.1</p> | | | | | | | | | |
| <p>PROPRIETA' RISERVATA DELLA DITTA ECOFLAM S.P.A.</p> | | | | | | | | | |
| <p>DESCRIZIONE MODIFICA</p> <p>IND.MOD. DATA-FIRMA</p> <p>SOSTA. DISSEGNO</p> <p>SOSTA. CONTROLLO</p> <p>DATA</p> <p>FIRMA</p> <p>DATA</p> <p>FIRMA</p> | | | | | | | | | |
| <p>EROGAZIONE</p> <p>MULTIFLAM 300.1-400.1-500.1 PR/PR</p> <p>LANDIS LFL 1.622</p> <p>CONTROLLO DI TENUTA</p> <p>DUNGS VPS 504</p> <p>SISTEMA AZ</p> <p>UV</p> <p>INDICAZIONE</p> <p>LANDIS SOM 50.481A2</p> <p>CODICE</p> <p>BEM44025</p> | | | | | | | | | |
| <p>Ecoflam S.p.A.</p> <p>UFF. TECNICO SETTORE ELETTRICO</p> <p>APPRECCHIATURA</p> <p>MOTORIDUTTORE</p> | | | | | | | | | |




COLLEGAMENTO BARILOTTO ECOFLAM

**Collegamento elettrico
resistenze
Parte superiore**

**Posizionamento
resistenze**

| | | | | | | | | | | | |
|----------|----|------------|----|----------------------|----|--------------------------------|----|---------------------|----|-----------------|--|
| IND.MOD. | | DATA/FIRMA | | DESCRIZIONE MODIFICA | | Ecoflam S.p.A. | | DENOMINAZIONE | | MOTOROUTTORE | |
| SOSTIT. | | DATA | | DISEGNO | | UFF. TECNICO-SETTORE ELETTRICO | | APPARECCHIATURA | | SIST. RINGIAZZ. | |
| SOST. DA | | DATA | | CONTROLLATO | | A/C - - - - - | | CONTROLLO DI TENUTA | | CODICE | |
| | | FIRMA | | | | FIRMA | | | | INDICAZIONE | |
| | | | | | | | | | | | |
| 00 | 01 | 02 | 03 | 04 | 05 | 06 | 07 | 08 | 09 | | |
| A | B | C | D | E | | | | | | | |



Multiflam 500.1 PR/MD
Multiflam 600.1 PR/MD

| N° | DESCRIPTION | MULTIFLAM 500.1 code | MULTIFLAM 600.1 code |
|----|---|-------------------------|-------------------------|
| 1 | - AIR PRESSURE SWITCH DUNGS LGW10 A2P | Q120 | Q120 |
| 2 | - PRESSURE GAUGE | BFT01105/001 | BFT01105/001 |
| 3 | - AIR INTAKE SET | GRPA100 | GRPA100 |
| 4 | - WIELAND PLUG 6 pin | E226 | |
| 5 | - GLASS | BFC02004 | BFC02004 |
| 6 | - PEED WINDOM FRAME | BFC02006 | BFC02006 |
| 7 | - MOTOR 11 k W | M176/1 | - |
| | 15 k W | - | M170/3 |
| 8 | - FAN 360x135 | BFV10305/001 | - |
| | 380x135 | - | BFV10306/001 |
| 9 | - AIR CONVEYOR | BFC08255 | BFC08255 |
| 10 | - AIR INTAKE | GRCA380 | GRCA380 |
| 11 | - AIR INTAKE PIPE | BFS02218/001 | |
| 12 | - CONTROL BOX BASE LANDIS | A401 | A401 |
| 13 | - CONTROL BOX LANDIS LFL1.333 | A124 | A124 |
| 14 | - IGNITION TRANSFORMER BRAHMA T8 | T101 | T101 |
| 15 | - REMOTE CONTROL SWITCH AEG LS15K.00 | R621/5 | R621/5 |
| 16 | - REMOTE CONTROL SWITCH (PUMP) AEG LS05.10 | R621 | R621 |
| 17 | - REMOTE CONTROL SWITCH AEG LS7K.10 | R621/3 | R621/3 |
| | AEG LS4K.10 | R621/1 | R621/1 |
| 18 | - MOTOR THERMAL RELAY AEG B18K-260 21-26A | R521/15 | - |
| | AEG B77S 25-40A | - | R521/7 |
| 19 | - MOTOR THERMAL RELAY (PUMP) AEG 3-4,7A | R521/3 | R521/3 |
| 20 | - ADJUSTMENT OF FUEL TEMPERATURE Gefran 600 | E1216 | E1216 |
| 21 | - MAIN SWITCH cod.4010011509 | R1020 | |
| 22 | - GAS/HEAVY-OIL SELECTOR | R1020/5 | R1020/5 |
| 23 | - SELECTOR | R1020/5 | R1020/5 |
| 24 | - LAMP Elettrospring EL/N-SC4 | E1510 | |
| 25 | - FUSE SUPPORT FUSIT FH-B528 | E802/2 | |
| 26 | - RELÉ BASE Finder 5532 | R905 | |
| | Finder 5534 | R906 | R906 |
| 27 | - RELÉ Finder 5532 | R711 | |
| | Finder 5534 | R712 | R712 |
| 28 | - UV CELL LANDIS QRA 2 | A205 | A205 |
| 29 | - IGNITION CABLE TC | BFE01403/2 | BFE01403/2 |
| | TL | BFE01403/3 | |
| 30 | - IGNITION ELECTRODES SET | E612 | E612 |
| 31 | - PIPE TC | | |
| | TL | | BFT14001/201 |
| 32 | - ROD TC | | |
| | TL | | |
| 33 | - GAS FIRING HEAD | BFT14004/001 | BFT14004/001 |
| 34 | - HEAVY OIL FIRING HEAD | BFT15226/001 | |
| 35 | - FRONT DISC | BFD03020 | BFD03020 |
| 36 | - NOZZLE HOLDER | BFC11019 | BFC11019 |
| 37 | - COIL EL011 | V523 | V523 |
| 38 | - CONETTORE BOBINA EL011 | V1119/07 | V1119/07 |
| 39 | - RING | BFT15224/001 | BFT15224/001 |
| 40 | - SPRING HOLDER | BFT15222/001 | BFT15222/001 |
| 41 | - PIPE | BFT15221/001 | BFT15221/001 |
| 42 | - ROD NOZZLE HOLDER TC | BFT15220/002 | |
| 43 | - INNER ASSEMBLY TC | | |
| | TL | | |
| 44 | - BLAST TUBE TC | BFB08012/017 | BFB08012/017 |
| | TL | | |
| 45 | - BLAST TUBE END | BFB07028/3 | BFB07028/3 |
| 46 | - GASKET ISOMART | BFG04051/1 | BFG04052/1 |
| 47 | - ANTIJAMMING FILTER | S132/4 | S132/4 |
| 48 | - AIR DAMPER MOTOR LANDIS SQM50.481A2 | M212/91 | M212/91 |
| 49 | - OIL PUMP SUNTEC TA4C40105 | P148/3 | P148/3 |
| 50 | - COUPLING | MP501/4 | MP501/4 |
| 51 | - HOSES TN 25X1500 C/T | S901/2 | S901/2 |

TC = SHORT HEAD TL = LONG HEAD



 **Ecoflam**

ECOFLAM S.p.A. reserves the right to make any adjustments, without prior notice, which it considers necessary or useful to its products, without affecting their main features.

Ecoflam S.p.A.

via Roma, 64 - 31023 RESANA (TV) - Italy - tel. 0423.7160 -
fax 0423.716373 <http://www.ecoflam.it> - e-mail: export@ecoflam.it

"società soggetta alla direzione e al coordinamento della Merloni Termosanitari S.p.A., via A. Merloni, 45 - 60044 Fabriano (An) CF 01026940427"