

GAS / HEAVY-OIL DUAL BURNERS

Ecoflam

CE



Multiflam 700.1

Multiflam 800.1

Multiflam 1000.1

Multiflam 1200.1

PR/PR

Natural Gas / Heavy oil

254/440V 60Hz




420010248200

420010248200


22.09.2009

| Models | Multiflam | 700.1 PR | 800.1 PR | 1000.1 PR | 1200.1 PR |
|-----------------------------|---|-----------|-----------|-----------|------------|
| Thermal power max. | kW | 7.500 | 8.500 | 10.500 | 13.000 |
| | kcal/h | 6.465.000 | 7.327.500 | 9.052.000 | 11.207.000 |
| Thermal power min. | kW | 1.500 | 2.000 | 2.500 | 2.700 |
| | kcal/h | 1.290.000 | 1.724.000 | 2.155.000 | 2.327.600 |
| Max. capacity (Natural Gas) | Nm ³ /h | 729 | 855 | 1.056 | 1.318 |
| Min. capacity (Natural Gas) | Nm ³ /h | 150 | 201 | 251 | 272 |
| Max. heavy oil flow rate | kg/h | 660 | 748 | 924 | 1.143 |
| Min. heavy oil flow rate | kg/h | 132 | 176 | 220 | 237 |
| Gas pressure | mbar | 300 | 300 | 300 | 300 |
| Voltage 60 Hz | V | 254/440 | 254/440 | 254/440 | 254/440 |
| Motor | kW | 15 | 18,5 | 22 | 37 |
| Rpm | N° | 3400 | 3400 | 3400 | 3400 |
| Fuels: | Nat. Gas L.C.V. 8.570 kcal/Nm ³ ; Heavy Oil L.C.V. 9.800 kcal/kg max. visc.50°E at 50 °C | | | | |

WORKING FIELDS



OVERALL DIMENSIONS



| MODELS | A | B | C | D | D1 | E | F | G | H | I | L | M | N | O |
|------------------|------|-----|-----|-----|----|------|-----|-----|-----|-----|-----|-----|-----|-----|
| Multiflam 700.1 | | 585 | | 470 | | 1582 | 420 | 770 | 500 | 460 | 460 | M20 | 195 | 232 |
| Multiflam 800.1 | | 655 | | 470 | | 1582 | 420 | 770 | 500 | 460 | 460 | M20 | 195 | 232 |
| Multiflam 1000.1 | | 685 | | 470 | | 1582 | 420 | 770 | 500 | 460 | 460 | M20 | 195 | 232 |
| Multiflam 1200.1 | 1690 | 800 | 890 | 470 | - | 1582 | 450 | 770 | 500 | 460 | 460 | M20 | 195 | 232 |

ELECTRICAL CONNECTIONS


All burners factory tested at 440 V 60 Hz three-phase for motors and 220 V 60 Hz monophas with neutral for auxiliary equipment. If mains supply is 254 V 60 Hz threephase withuot neutral, change position of connectors on burner as in fig. Protect burner supply line with safety fuses and any other devices required by safety standards obtaining in the country in question.

CONNECTION TO THE GAS PIPELINE

Once connected the burner to the gas pipeline, it is necessary to control that this last is perfectly sealed. Also verify that the chimney is not obstructed. Open the gas cock and carefully bleed the piping through the pressure gauge connector, then check the pressure value trough a suitable gauge. Power on the system and adjust the thermostats to the desired temperature. When thermostats close, the sealing control device runs a seal test of valves; at the end of the test the burner will be enabled to run the start-up sequence.

BURNER START-UP

Before starting the burner, make sure it is mounted correctly. Then check connections are correct according to the diagram and piping is appropriate to the system. Before connecting the burner to the electricity supply, make sure voltage corresponds to burner plate data. The connection diagram and start-up cycle are shown separately. For wiring from control box to burner, see the enclosed connection diagram. Pay particular attention to neutral and phase connections : never exchange them!. Vent air and impurities of gas pipe. Check gas pressure conforms to the limits stated on the burner plate when connecting a master gauge to the test port provided on the burner. Blower motor starts and pre-purging begins. Since pre-purging has to be carried out with the max. air delivery, the burner control circuit turns the air damper to the max. delivery position by the air servocontrol in approximately 30 seconds time. When the servocontrol is fully open, a signal to the electronic control unit starts the 66 seconds pre-purge cycle. At the end of the prepurging time, the air servocontrol gets to the Low Flame position so that burner ignition is ensured at min. output. Simultaneously the ignition transformer receives voltage and after 3 seconds (pre-ignition) opens the pilot gas valve. Fuel flows to the combustion head and ignites. Two seconds after pilot gas valves have opened, the ignition transformer is excluded from the circuit. In case of no ignition the burner goes to lock-out within two seconds. After 6 sec. open the working gas valve, governed by the gas firing butterfly valve. Now the burner is operating at the min. firing rate (about 30% of the max. firing rate). The air servocontrol runs at the Low Flame position and in case the temperature control has to be set at the max. output it goes to a fully open position of air damper and butterfly valve. During the burner-off periods the air damper closes up fully.



ADJUSTING THE COMBUSTION PROCESS

IMPORTANT: to obtain the right adjustment of the combustion and thermal capacity it is important to analyze the reducts of combustion with the aid of suitable instruments. The combustion and thermal capacity adjustment is done simultaneously, together with the analysis of the products of combustion, making sure that the measured values are suitable and that they comply with current safety standards. On this matter, please refer to the table and figure below.

THESE OPERATIONS MUST BE DONE BY PROFESSIONALLY-QUALIFIED TECHNICIANS.

NOTE:


ALL SAFETY DEVICES (AIR PRESSURE SWITCH, MINIMUM GAS PRESSURE SWITCH, GAS SOLENOID VALVES AND GAS GOVERNOR) SHALL BE DULY SEALED AFTER CALIBRATION AND BURNER START UP BY ECOFLAM'S TECHNICIANS.

LANDIS & STAEFA, Model LFL1.622-LFL1.333 OPERATING CYCLE

| Ref. | Description | Duration |
|------|---|----------|
| t1 | Duration Waiting time for confirmation of air pressure | 8" |
| t3 | Preventilation time | 66" |
| t4 | Safety time | 2" |
| t5 | Pressurizing time | 4" |
| | Time for enabling operation of the main gas valve on minimum capacity | 10" |
| t6 | Time for enabling operation of the main gas valve on maximum capacity | 10" |


The control box starts the burner fan, to carry out the prepurging of the combustion chamber, and checks the vent air pressure through the air pressure switch. At the end of prepurging, the ignition transformer cuts-in and generates a spark between the electrodes. At the same time the two gas valves

open (Vs safety valve and VI working valve). The total safety, in case of missed ignition or casual burner's flame-out, is granted by a ionisation probe which cuts-in and sets the burner shutdown within the safety time. In case of gas lack or a major pressure drop, the minimum air pressure switch shuts down the burner.




LANDIS & STAEFA SQM 50.481A2 AIR DAMPER MOTOR

Remove cover to gain access to the adjusting cams. The cams are to be adjusted through the suitable key provided for. Description:



Manual change

- I - High flame operating opening position adjusting cam (Heavy-Oil)
- II - Limit switch for the air damper position at burner's shut down
- III - Ignition flame opening position adjusting cam (Gas).
- IV - Ignition flame opening position adjusting cam (Heavy-Oil)
- V - Low flame operating opening position adjusting cam (Gas)
- VI - Low flame operating opening position adjusting cam (Heavy-Oil)
- VII - High flame operating opening position adjusting cam (Gas)
- VIII - Not used cam



CALCULATING THE BURNER CAPACITY


To calculate the burner's capacity in kW, proceed as follows: Check the gas flow rate (in liters) on the counter and the time of the reading in seconds.

Proceed with the calculation using the following formula: $\frac{e}{sec} \times f = kW$

e = Litres gas
 sec = Time in second

$$f \begin{cases} G20 = 34,02 \\ G30 = 116 \\ G31 = 88 \end{cases}$$

AIR ADJUSTMENT



ADJUSTING THE MINIMUM CAPACITY OF THE BURNER – AIR and GAS

Position the selector placed on the control panel on position 2 and proceed as follows:

Adjust the minimum gas flow rate using a suitable wrench, turn the butterfly valve until you reach the correct gas flow, as established by analyzing the combustion process.

ADJUSTING THE MAXIMUM CAPACITY OF THE GAS

Position the selector, situated on the control panel, on position 1 and proceed as follows:

Adjusting the maximum gas flow rate (see figure on solenoid valve adjustments) or adjust the gas pressure in the governor.

ADJUSTING THE MAXIMUM AIR FLOW RATE


Adjusting the maximum air flow rate (see figure, detail 2). Loosen the nut holding the air damper transmission rod; The correct air flow as established by analyzing the combustion process.

ADJUSTING THE INTERMEDIATE BURNER CAPACITY

Using the selector, start the servomotor (closing or opening) and position on 0 to stop the stroke; the adjustment is made as outlined below. Repeat the operation for the other cam points.

Adjustment the intermediate gas flow rates (see figure, detail 3): - using a suitable Allen wrench, change the position of the cam guide blade; if you screw it down, the flow rate is reduced; if you unscrew it, the flow rate increases.

SETTING THE FIRING HEAD




ADJUSTMENT OF GAS MINIMUM PRESSURE SWITCH

Unscrew off and remove cover M. - Set regulator N to a value equal to 60% of gas nominal feed pressure (i.e. for nat. gas nom. pressure = 20 mbar, set regulator to a value of 12 mbar; for L.P.G. nom. pressure of G30/G31- 30/37 mbar, set regulator to a value of 18 mbar).Screw up cover M

ADJUSTMENT OF THE AIR PRESSURE SWITCH


Unscrew screws A and B and remove cover C.- Set the pressure switch to the minimum by turning regulator D to position 1.

- Start the burner and keep in low flame running, while checking that combustion is correct. Through a small cardboard, progressively obstruct the air intake until to obtain a CO₂ increase of 0,5÷0,8% or else, if a pressure gauge is available, connected to pressure port E, until reaching a pressure drop of 1 mbar (10 mm of W.G.). - Slowly increase the adjustment value of the air pressure switch until to have the burner lockout. Remove the obstruction from the air intake, screw on the cover C and start the burner by pressing the control box rearm button.



Note: The pressure measured at pressure port E must be within the limits of the pressure switch working range. If not, loose the locking nut of screw F and gradually turn the same: clockwise to reduce the pressure; counterclockwise to increase. At the end tighten the locking nut.

DETECTOR CURRENT





The detector current is checked by inserting a microammeter (scale 1000 µA - d.c.) in series with the uv cell..

The flame detector current has to been > 70 µA.


REMOVING THE FIRING HEAD

WARNING !



PUMP'S PRESSURE / OIL TEMPERATURE DIAGRAM


Pump inlet pressure:the vaporisation of light fraction of heated heavy oil causes premature pump wear, to avoid this, use the inlet pressures shown in the graph.



TYPE OF INSTALLATION



The burner must be supplied with oil heating a min. temperature at the pump (50° C).

Drawing for fluid fuel oil up to 50°E at 50°C



- 1 - Burner
- 2 - Tank
- 3 - Heater
- 4 - Safety/operation thermostat
- 5 - Level switch
- 6 -
- 7 - Filter
- 8 - Load pumps
- 9 - Holding basin


Drawing for heavy fuel oil up to 50°E at 50°C



- 1 - Burner
- 2 - Tank
- 3 - Heater
- 4 - Safety/operation thermostat
- 5 - Level switch
- 6 - Self cleaning filter
- 7 - Heating coil
- 8 - Load pumps
- 9 - Ring pumps
- 10 - Regulator
- 11 - Heating cable

MODULATING OPERATION

With the burner in the start position and the appliance thermostats enabled, power is delivered to the resistances (G) of the preheater and heating cartridges for the pumps and the fuel supply line to the head (O). When the preheater thermostat reaches the set value, (usually a minimum of about 90°C is necessary to guarantee a good level of circulation) the pump start-up is enabled (set point on out 1, if using the GEFTRAN 200 thermoregulating device). If the preheating system of the tank is also equipped for a fluid exchanger (hot water, steam, diathermic oil) the thermostat may enable a contact in the terminal block for any stop-start of the fluid electrovalve. This is not a standard solution as the heated fluid is normally always connected. The pump starts to send oil (the head has already been heated by its cartridge (O) and therefore has no residue of cold dense oil) which flows from the tank to the head and then to the return line of the ring. When the head thermostat reaches the set value (usually about 70-30°C the cycle starts properly and the control programmer enables start-up. The servomotor sets itself at minimum (see chapter on regulation) acting on the air and fuel via the pressure regulator on the return.



The electromagnet (A) opens the nozzle (Q) in the following condition :

- sparks from the ignition electrodes are generated by the transformer also governed by the burner control device.

If the cell fails to detect the flame the burner shuts down (with the cyclic control programmer cutting in). Once ignition has taken place and after the flame stabilisation period, the system starts operating in modulating mode.

- Before start-up make sure that the pump and delivery pipes are completely filled with hot fuel oil; the absence of fuel oil can cause pump seizure.
- If there is a block, a specific warning light on the programmer and on the burner front control board lights up and this signal is usually sent to the main control board of the equipment using the burner, setting off a buzzer and warning light.
- A few blocks are normal on first starting up (up to about 4); to release press the button on the programmer (also found on the front of the burner control board) for repeating the start cycle. Should they continue to occur seek the help of a specialised technician.

N.B. The position of the programmer at the time of the block is memorised to supply an indication of the cause of this block.

OIL DELIVERY ADJUSTMENT

The diagram illustrates the fuel feeding system of these type of burners, which incorporates a by-pass nozzle with oil flow regulation on its return pipe. The oil supply is varied by acting on the nozzle through the pressure in the return line. Max. oil supply is therefore reached when the pressure in the pump line is about 30 bar and the return line is fully closed; min. oil supply when the return line is fully open (see also diagram BERGONZO). Relevant pressure readings in the return line are as follows (return oil pressure has to be measured on "M" pressure gauge):

Pump pressure 25-30 bar.

Max Burner output, return oil pressure:


FLUIDICS nozzle : 16 ÷ 19 bar.

BERGONZO nozzle : 20 ÷ 24 bar.


Min Burner output, return oil pressure:

FLUIDICS nozzle : 6 ÷ 9 bar

BERGONZO nozzle : 4 ÷ 8 bar



PRIMING AND ADJUSTMENT OF OIL PUMP







- | | |
|-----------------------------------|-------------------------|
| 1 - INLET | 4 - VACUUM GAUGE PORT |
| 2 - RETURN | 5 - REGULATING VALVE TV |
| 3 - BLEED AND PRESSURE GAUGE PORT | 6 - TO NOZZLE |

VERIFY:

- That piping system is perfectly sealed;
- That the use of hoses is avoided whenever is possible (use copper pipes preferably);
- That depression is not greater than 0,45 bar, to avoid pump's cavitation;
- That check valve is suitably designed for the duty;

The pump pressure is set at a value of 22-25 bar during the testing of burners. Before starting the burner, bleed the air in the pump through the gauge port. Fill the piping with light-oil to facilitate the pump priming. Start the burner and check the pump feeding pressure. In case the pump priming does not take place during the first prepurging, with a consequent, subsequent lock-out of the burner, rearm the burner's lock-out to restart, by pushing the button on the control box. If, after a successful pump priming, the burner locks-out after the prepurging, due to a fuel pressure drop in the pump, rearm the burner's lock-out to restart the burner. Do never allow the pump working without oil for more than three minutes. Note: before starting the burner, check that the return pipe is open. An eventual obstruction could damage the pump sealing device.

PRESSURE REGULATING VALVE ADJUSTMENT



1) Remove the cap A of the pressure regulating valve TV.

2) Loosen the fixing nut B and use an allen wrench on the screw C to adjust the delivery oil pressure. To increase the pressure turn clockwise, to decrease the pressure turn anticlockwise.

3) Tighten the nut B and pay attention not to turn also the adjusting screw.

4) Screw on the cap A, back to its previous position.



OIL PUMP TYPE TA GEAR SIZES 2-3-4-5

TA

TA - 11 - Ed 6 - May 2004

This is a general specification leaflet ; for specific applications not covered herein, contact Suntec.

The SUNTEC TA oil pump is specially designed for industrial heating applications using light or heavy oils. It is fitted with a preheater location to render cold starting easier.

APPLICATIONS

- Light and heavy oil.
- One or two-pipe system.

PUMP OPERATING PRINCIPLE

The gear set draws oil from the tank and transfers it to the valve that regulates the oil pressure to the nozzle line. All oil which does not go through the nozzle line will be dumped through the valve back to the return line in two pipe installation or, if it is a one-pipe installation, back to the gear-set.

Bleed :

The plug of the pressure gauge port must be loosened until the air is evacuated from the system.

Note :

All TA models are delivered for two-pipe system (by-pass plug fitted in vacuum gauge port).



For one-pipe system, the by-pass plug must be removed and the return port sealed by steel plug and washer.

PREHEATING FACILITY

Care should be taken to avoid starting pump with high viscosity cold oil leading to pump and coupling damage. For this reason, the TA pump body includes a drilling to accept an electric preheater. This drilling has been located to give maximum heat transfer from the heater to the oil in the pump without there being direct contact between the heater cartridge and the oil.

Heaters should be connected for a period of time prior to starting the pump. When the right temperature is reached, they can be switched off or left permanently switched on to maintain fluid oil in the pump during the periodic burner shut-downs.

The oil supply, pipes and filters must be separately heated.



TECHNICAL DATA

General

| | | | |
|---------------------|---|---|--------------|
| Mounting | Flange mounting | | |
| Connection threads | Cylindrical according to ISO 228/1 | | |
| Inlet and return | G 1/2 | | |
| Nozzle outlet | G 1/2 | | |
| Pressure gauge port | G 1/4 | | |
| Vacuum gauge port | G 1/4 | | |
| Shaft | Ø 12 mm | | |
| By-pass plug | Inserted in vacuum gauge port for 2 pipe system; to be removed with a 3/16" Allen key for 1 pipe system | | |
| Weight | 5,4 kg (TA2) | - | 5,7 kg (TA3) |
| | 6 kg (TA4) | - | 6,4 kg (TA5) |


Hydraulic data

| | | |
|---------------------------|----------------------------------|--|
| Nozzle pressure ranges | 30 : 7 - 30 bars | |
| | 40 : 7 - 40 bars | |
| Delivery pressure setting | 30 bars | |
| Operating viscosity | 4 - 450 mm ² /s (cSt) | |
| Oil temperature | 0 - 140°C in the pump | |
| Inlet pressure | light oil : | 0,45 bars max. vacuum to prevent air separation from oil |
| | heavy oil : | 5 bars max. |
| Return pressure | light oil : | 5 bars max. |
| | heavy oil : | 5 bars max. |
| Rated speed | 3600 rpm max. | |
| Torque (@ 40 rpm) | 0,3 N.m | |


Choice of heater

| | |
|-----------|-----------------------|
| Cartridge | Ø 12 mm |
| Fitting | according to EN 50262 |
| Rating | 80-100 W |

Pump capacity




Power consumption



PUMP DIMENSIONS

Example shows "C" rotation - Reverse all pump connections for "A" rotation.



We reserve the right to change specifications without prior notice.

TA - 11 - Ed 6 - May 2004



TV VALVE



TV - 11 - Ed 4 - June 99

This is a general specification leaflet ; for specific applications not covered herein, contact Suntec.


The SUNTECTV valve is a pressure regulating valve.

APPLICATIONS

- Light and heavy oil.
- Capacity up to 5000 l/h.
- May be used with the SUNTECT pump.

VALVE OPERATING PRINCIPLE

The pressure of the nozzle line is adjusted with the adjusting screw of the TV valve. The oil in excess to nozzle requirement is dumped to the return.



VALVE IDENTIFICATION

(Not all model combinations are available
Consult your Suntec representative)

TV : Pressure regulating valve

Pressure range :

- 10 : 2 - 10 bars
- 40 : 7 - 40 bars

TV 40 01 1


Regulation type :

- 01 : by screw
- 02 : by piston, for modulating purpose

Revision number

INSTALLATION

- Two pipe system : oil in excess is returned to tank.
- One pipe system : oil in excess is returned to pump suction.



TECHNICAL DATA

General

| | |
|--------------------|------------------------------------|
| Connection threads | Cylindrical according to ISO 228/1 |
| Inlet | G 3/4 |
| Nozzle outlet | G 3/4 |
| Return | G 3/4 |
| Weight | 3 kg |

Hydraulic data

| | |
|---------------------|---|
| Pressure ranges | 10 : 2 - 10 bars (delivery pressure setting : 7 bars) |
| | 40 : 7 - 40 bars (delivery pressure setting : 20 bars) |
| Operating viscosity | 4 - 450 cSt |
| Oil temperature | 0 - 140°C max. in the valve. |

MOUNTING POSITION

TV valve may be mounted in any position.


PRESSURE ADJUSTMENT

Remove cap-nut **1** and washer **2**, unscrew lock-nut **4**.


To increase pressure, turn adjusting screw **3** clockwise.

To decrease the pressure, turn screw anticlockwise.

Block lock-nut **4**, refasten washer **2** and cap-nut **1**.



DIMENSIONS





OIL PUMP TYPE T GEAR SIZES 2-3-4-5

This is a general specification leaflet ; for specific applications not covered herein, contact Suntec.

The SUNTEC T oil pump is specially designed for industrial heating applications using light or heavy oils with high capacity. It is fitted with a preheater location to render cold starting easier.

APPLICATIONS

- Light and heavy oil.
- SUNTEC recommend the use of a SUNTEC TV valve to regulate the pump pressure.

PUMP OPERATING PRINCIPLE

The gear set draws oil from the tank and transfers it to an external valve that regulates the oil pressure.

Bleed :

The plug of the pressure gauge port must be loosened until the air is evacuated from the system.

Note :

The bypass plug inserted between high pressure and shaft seal is only intended to change the pump rotation, check the presence of this plug with a 4 mm Allen key in the pressure outlet of the pump.


Caution : changing the direction of pump rotation involves changing of all pump connections.

PREHEATING FACILITY



Care should be taken to avoid starting pump with high viscosity cold oil leading to pump and coupling damage. For this reason, the T pump body includes a drilling to accept an electric preheater. This drilling has been located to give maximum heat transfer from the heater to the oil in the pump without there being direct contact between the heater cartridge and the oil.

Heaters should be connected for a period of time prior to starting the pump. When the right temperature is reached, they can be switched off or left permanently switched on to maintain fluid oil in the pump during the periodic burner shut-downs.

The oil supply, pipes and filters must be separately heated.



T - 11 - Ed 10 - May 2004



TECHNICAL DATA

General

| | | | |
|--------------------|------------------------------------|--|--|
| Mounting | Flange mounting | | |
| Connection threads | Cylindrical according to ISO 228/1 | | |



| | | | |
|--------|-------------|---|-------------|
| Shaft | Ø 20 mm | | |
| Weight | 7,8 kg (T2) | - | 8,1 kg (T3) |
| | 8,7 kg (T4) | - | 9,4 kg (T5) |

Hydraulic data

| | | | |
|-----------------------|----------------------------------|--|--|
| Nozzle pressure range | 40 bars max. (T2, T3, T4) | | |
| | 30 bars max. (T5) | | |
| Operating viscosity | 4 - 450 mm ² /s (cSt) | | |
| Oil temperature | 0 - 140°C in the pump | | |
| Inlet pressure | light oil: | 0,45 bars max. vacuum to prevent air separation from oil | |
| | heavy oil: | 5 bars max. | |
| Rated speed | 3600 rpm max. | | |
| Torque (@ 40 rpm) | 0,4 N.m | | |


Choice of heater

| | |
|-----------|-----------------------|
| Cartridge | Ø 12 mm |
| Fitting | according to EN 50262 |
| Rating | 80-100 W |




PUMP DIMENSIONS

Example shows "A" rotation - Reverse all pump connections for "C" rotation.



We reserve the right to change specifications without prior notice.

ADJUSTMENT OF FUEL TEMPERATURE



The display shows oil temperature.

The 4 leds are related to the following functions:

Out 1: contact driving working heaters

Out 2: contact driving upper heaters KMRL1

Out 3: contact driving upper heaters KMRL2

Out 4: Burner start driving contact (as the oil reaches this temp the pump is activated)

- The temperatures are already properly Factory setted :

Out 1(113°)- Out 2(115°)- Out 3(120°)- Out 4(105°).

- To modify factory temperature setting act as follows:


- press key "F"

- the led Out1 starts to flash, if You need to modify minimum oil temperature press increase or decrease button, after confirm the new value pressing again "F"


- if You need to modify an other temperature press again "F" untill You the relevant led flashes.

Please take care: if key "F" is pressed for a too long time, You enter in "configuration level" phase1, (see "CF1" on the display); these parameters are Factory setted and they have not to be modified: if You enter this function – You see CF1 flashing on the display – wait 10 seconds untill the regulator automatically goes out from "configuration level".

PRE - PURGING PHASE



PRE - PURGING PHASE





LEGEND :

- A Solenoid valve (N.C.)
- D Regulator
- E Tank
- F Anti - gas valve
- G Resistance of the preheater
- H Pipe filter
- I Oil pump
- N Manometr
- O Resistance of combustion head
- P Oil temperature sensor
- Q Oil nozzle


Charles Bergonzo S.A. Moutier (suisse)

B Gicleurs 45° Débit 700 kg/h Viscosité 2°E Pression initiale 25 atm
 Düse..... Leistung..... kgOel/h Viscosität.....E Vorlaufdruck konstant 25atü






POSITION OF IGNITION ELECTRODES



NOZZLE CLEANING AND REPLACEMENT

Use only the suitable box wrench provided for this operation to remove the nozzle, taking care to not damage the electrodes. Fit the new nozzle with the same care.

Note: Always check the position of electrodes after having replaced the nozzle (see illustration). A wrong position could cause ignition troubles.



MAINTENANCE

YEARLY CHECKS

The burner's periodical check (firing head, electrodes etc.) must be carried out by authorised personnel one or two times per year, depending on the utilisation. Before going on with the maintenance controls of the burner, it should be advisable to check its general conditions, according to the following steps:

Unplug the burner; close the fuel cock; shut down the gas supply; remove burner's cover and clean the fan and air intake; clean the firing head and check the electrode's position; reassemble all the parts; check the connection's sealing; check the chimney; start the burner and check the combustion flue ($\text{CO}_2 = 9.5 \div 9.8$; $\text{O} = \text{lower than } 75 \text{ ppm}$).

BEFORE EVERY INTERVENTION CHECK:

The electric system is duly powered and the burner is plugged in.

The gas pressure must be the suitable one and the gas cock open.

The control devices must be properly connected.

When all the above conditions are met, start the burner by pressing the lockout enable pushbutton.

Check the burner's cycle.

THE BURNER DOES NOT START:

Check the ON/OFF switch, the thermostats, the motor and the gas pressure.

The master switch is in position "0". Fuses are blown out.

The control box is faulty.

THE BURNER RUNS THE PREPURGING AND SWITCHES TO LOCKOUT AT THE END OF CYCLE:

Check the fan and the air pressure.

Check the air pressure switch.

Control box faulty. Ignition transformer faulty.

Check the ignition cable. Electrodes are dirty or in wrong position.
Nozzles are clogged or worn. Filters are clogged. Heavy-oil pressure is too low.
Combustion air's flow rate too high related to nozzle output.

THE BURNER RUNS THE PREPURGING BUT DOES NOT IGNITE:

Check the position of the electrodes; check the ignition cable;
Check the ignition transformer;
Check the control box.

THE BURNERS IGNITES BUT SWITCHES TO LOCKOUT AFTER THE SAFETY TIME:


Check phase and neutral for a correct connection.
Check gas solenoid valve.
Check the position of ionisation probe and its connection.
Check the control box.
Check nozzles (clogged or worn).
The photoresistor does not detect the flame.
The filters are clogged. Heavy-oil pressure too low.
Combustion air's flow rate too high related to nozzle output.

THE BURNERS IGNITES BUT SWITCHES TO LOCKOUT AFTER FEW MOMENTS:

Check gas governor and gas filter.
Check gas pressure through a manometer.
Check ionization value (min. 70 μ A).

THE BURNER DOES NOT SWITCHES TO HIGH FLAME:

Manual selector switch in wrong position.
Faulty control box. High flame solenoid valve's coils faulty.
Air damper's jacket faulty or wrongly adjusted.




| | | | | | | |
|-----------|------------|----------------------|-------------|------------|-------------|------|
| IND. MOD. | DWG. FIRMA | DESCRIZIONE MODIFICA | DISSEGNO | DATA | VERIF. DATA | FRMA |
| SOSTIT. | | CONTROLLO DI TENUTA | CONTROLLATO | 22-04-2009 | 26-05-2009 | FRMA |
| SOSTA | | APPARECCHIATURA | FRMA | | | |

COMPONENTI NON IDENTIFICATI
 PER INFORMAZIONI UTILIZZARE
 IL MANUALE DI RIFERIMENTO
 CON LA SIGLA IN CAPO LETTERA

PER INFORMAZIONI UTILIZZARE
 IL MANUALE DI RIFERIMENTO
 CON LA SIGLA IN CAPO LETTERA

PER INFORMAZIONI UTILIZZARE
 IL MANUALE DI RIFERIMENTO
 CON LA SIGLA IN CAPO LETTERA



COMPONENTI NON IDENTIFICATI
 PER INFORMAZIONI UTILIZZARE
 IL MANUALE DI RIFERIMENTO
 CON LA SIGLA IN CAPO LETTERA

| | |
|----------------------|---------------|
| INDICAZIONE | MOTORIDUTTORE |
| LANDIS SOM 50.48.1A2 | |
| CODICE | BEM44057 |
| SIST. FAVELAZ. | UV |

| | |
|---------------------|-----------------------|
| INDICAZIONE | MULTIFLAM 800.1 PR/PR |
| APPARECCHIATURA | LANDIS LFL 1.622 |
| CONTROLLO DI TENUTA | DUNG VPS 504 |

| | |
|-------------|--------------------------------|
| INDICAZIONE | UFF. TECNICO SETTORE ELETTRICO |
| FRMA | |

| | |
|-------------|------|
| INDICAZIONE | FRMA |
| DATA | |
| FRMA | |

PAGINA DI 1/2


09 08 07 06 05 04 03 02 01 00

09 08 07 06 05 04 03 02 01 00


PROPRIETÀ RISERVATA DELLA DITTA ECOFLAM S.p.A.
 A TERMINE DI LEGGE È VIETATO RIPRODURRE O
 COMUNICARE A TERZI IL CONTENUTO DEL PRESENTE

COLLEGAMENTO BARIOTTO ECOFLAM

Posizionamento
resistenze





Collegamento elettrico
resistenze
Parte superiore



| | | | | | | | |
|----------|------------|----------------------|------|--------------------------------|-------------------|---------------|---------------|
| IND.MOD. | DATA FIRMA | DESCRIZIONE MODIFICA | | DENOMINAZIONE | | MOTODIBUTTORE | |
| SOSTIT. | DATA | DISSEGNIATO | DATA | APPR. RECARICATA | SIST. RINDELAZ. | CODICE | IND. MODIFICA |
| SOST. DA | DATA | CONTROLATO | DATA | UFF. TECNICO SETTORE ELETTRICO | CONTROLLO TENERIA | | |
| | | | | | | | |

DESCRIPTION OF CONTROL PANEL





MULTIFLAM 800.1 PR

| N° | DESCRIPTION | MULTIFLAM 800.1 code |
|----|---|-------------------------|
| 1 | AIR PRESSURE SWITCH DG 10 U | Q112/2 |
| 2 | AIR INTAKE SET | GRPA100 |
| 3 | WIELAND PLUG 6 pin | E226 |
| 4 | GLASS | BFC02004 |
| 5 | PEED WINDOM FRAME | BFC02006 |
| 6 | MOTOR 18,5 kW | M171/4 |
| 7 | FAN RU-560 M.D.42 | BFV10410/001 |
| 8 | AIR CONVEYOR | BFC08261 |
| 9 | CONVEYOR RING | BFC08258/038 |
| 10 | AIR INTAKE | BFC04259/038 |
| 11 | CONTROL BOX BASE LANDIS | A401 |
| 12 | CONTROL BOX LANDIS LFL1.333 | A124 |
| 13 | IGNITION TRANSFORMER T8 13000/35 220/60 | T115 |
| 14 | REMOTE CONTROL SWITCH AEG LS4K.10 | R621/1 |
| | AEG LS7K.10 | R621/3 |
| 15 | REMOTE CONTROL SWITCH (PUMP) AEG LS05.10 | R621 |
| 16 | MOTOR THERMAL RELAY AEG B18K-260 | R521/15 |
| 17 | MOTOR THERMAL RELAY (PUMP) AEG 4-6.3A | R521/13 |
| 18 | MAIN SWITCH COMEPI art.ECX1252 | R1011/11 |
| 19 | RESET BUTTON KEY COMEPI a.ECX1430 | R1011/15 |
| 20 | SELECTOR GIOVENZANA A.C01600029 | R1010/3 |
| 21 | SELECTOR GAS/HEAVY OIL COMEPI ART.ECX1370 | R1011/10 |
| 22 | LAMP LYVIA 10x28 BA9S | E1512/06 |
| 23 | FUSE SUPPORT HK 520 04/1 10A | E803 |
| 24 | RELÉ BASE FINDER 95.75 | R910 |
| | FINDER 5532 | R905 |
| | FINDER 5534 | R906 |
| 25 | RELÉ FINDER MINI 40.52 | R712/1 |
| | FINDER 5532 | R711 |
| | FINDER 5534 | R712 |
| 26 | TIMER | - |
| 27 | UV CELL LANDIS QRA 2 | A205 |
| 28 | IGNITION CABLE TC | BFE01403/4 |
| 29 | IGNITION ELECTRODES SET | E612 |
| 30 | GAS PIPE SUPPORT | BFT14077/001 |
| 31 | ROD TC | BFA08059/001 |
| 32 | GAS FIRING HEAD | BFT14078/001 |
| 33 | OIL FIRING HEAD | BFT15264/001 |
| 34 | FRONT DISC | BFD03027 |
| 35 | NOZZLE HOLDER 7/8 UNEF | BFC11025 |
| 36 | COIL EL011 | V523 |
| 37 | CONNECTOR WITH RECTIFIER | V1119/07 |
| 38 | RING | BFT15224/001 |
| 39 | SPRING HOLDER | BFT15222/001 |
| 40 | PIPE | BFT15266/001 |
| 41 | ROD NOZZLE HOLDER TC | BFT15265/001 |
| 42 | DIFFUSER | BFT14027/001 |
| 43 | BLAST TUBE TC | BFB08005 |
| 44 | GASKET ISOMART | BFG04059/1 |
| 45 | ANTIJAMMING FILTER | S132/4 |
| 46 | AIR DAMPER MOTOR LANDIS SQM50.481A2 | M212/91 |
| 47 | SILENCER | BAA11001/038 |
| 48 | OIL PUMP SUNTEC TA5C30106 | P148/2 |
| 49 | OIL PUMP VALVE | - |
| 50 | COUPLING (MOTOR) | - |
| 51 | UNION | - |
| 52 | COUPLING (PUMP) | MP501/4 |
| 53 | PUMP MOTOR SIMEL 2200W | M147/182 |
| 54 | OIL FILTER 70501/03 | S107/5 |
| 55 | HOSES 25X1500 | S901/2 |
| 56 | MANOMETER CEWAL R1/4 D50-40BAR | S601/1 |
| 57 | ADJUSTMENT OF OIL PRESSURE B-GH-PRO-2 | S1108/07 |

TC = SHORT HEAD TL = LONG HEAD

| N° | DESCRIPTION | Multiflam 800.1 code |
|------|---|----------------------|
| 58 - | NOZZLE Bergonzo 700 kg/h | U701/007 |
| 59 - | ADJUSTMENT OF FUEL TEMPERATURE Gefran 600 | E1216 |
| 60 - | THERMOCOUPLE TC6MD2JBC | E1216/1 |
| 61 - | FILTER U21008/01 | S107/7 |
| 62 - | UP HEATER 30 kW 440 V 60 Hz | R127/01 |
| 63 - | DOWN HEATER | - |
| 64 - | UP OIL TANK | BFP01045/017 |
| 65 - | DOWN OIL TANK | - |
| 66 - | HEATING ELEMENT 50 W | R110 |
| 67 - | THERMOSTAT | - |
| 68 - | PILOT GAS VALVE KROMSCH.VAS 125R/LW | V1996/11 |
| 69 - | COIL KROMSCH.VAS 125R/LW | |
| 70 - | SELECTOR COMEPI ART.ECXCX1350 | R1011/18 |

TC = SHORT HEAD TL = LONG HEAD

ECOFLAM BRUCIATORI S.p.A. reserves the right to make any adjustments, without prior notice, which it considers necessary or useful to its products, without affecting their main features.

Ecoflam

Ecoflam Bruciatori S.p.A.

via Roma, 64 - 31023 RESANA (TV) - Italy - tel. 0423.719500 - fax 0423.719580
<http://www.ecoflam-burners.com> - e-mail: export@ecoflam-burners.com

"società soggetta alla direzione e al coordinamento della Ariston Thermo S.p.A., via A. Merloni, 45 - 60044 Fabriano (An) CF 01026940427"