

## Table of Contents

Scope

Requirements

Obtain SIP Credentials

Register Device

### Scope



**Intended Audience:** Partners and Tier 1 Technicians or above.

This article will go over how to manually register a Valcom SIP Intercom Controller, such as the Valcom VE8090R.

### Requirements


- Office Manager access to Manager Portal or higher.
- Access to the Controller Software of a Valcom SIP device.

## Obtain SIP Credentials

1. Log into Manager Portal

2. Navigate to **Phones**

**NOTE:** Office Managers can navigate to Users > select the user > Phones



a.

3. Select **Phone Info** for the phone you wish to register.

**NOTE:** You will only see the information if the phone model is set to Manual or Softphone.



a.

## Register Device

Transport:	Accept TCP + UDP, Originate: UDP	SIP Mode:	Station
1	2	3	4
Phone Number: 850			

Description:	Valcom PA								
Authentication Name:	850								
Secret:									
Realm:									
SIP Servers:	<table border="1"> <thead> <tr> <th></th> <th>Server</th> <th>Port</th> </tr> </thead> <tbody> <tr> <td>▶ Primary</td> <td>sbc.ucaasnetwork.com</td> <td>5060</td> </tr> </tbody> </table>				Server	Port	▶ Primary	sbc.ucaasnetwork.com	5060
	Server	Port							
▶ Primary	sbc.ucaasnetwork.com	5060							
Register:	<input checked="" type="checkbox"/>								
DNS SRV:	<input checked="" type="checkbox"/>								
Busy Message:									
Call Fwd Busy ( 302 ):									
Outbound Proxy:	sbc.ucaasnetwork.com	Outbound Port:	5060						
Keep Alive Timer (secs):	3600	Options Timer (secs):	0						
SIP Port:	5060	Idle Timeout (secs):	0						
RTP Port:	20000	Max Call Timer (secs):	0						
CID Number:	850								
CID Name:	Valcom PA								
Auto Destination:									

- **Phone Number:** Input the Extension
- **Description:** Input a Description
- **Authentication Name:** Input the Username
- **Secret:** Input the Password
- **Realm:** Input the Domain/Proxy
- **SIP Servers:** Input your SIP Server
  - x1.green.nuso.io - ATL
  - x2.green.nuso.io - STL
  - x3.green.nuso.io - LAS
  - X4.green.nuso.io - PDX
- Check the boxes for **Register** and **DNS SRV**
- **Outbound Proxy:** Input your SIP Server again.
  - Port 0
- Apply these settings to the device and it will register.

configuration

sip intercom