Sesi 6 21/6/2025-1 SU:PLC Siemen [SIR SidiQ]

- 1. Ip Configuration
- 2. Choosing a PLC and Software:
- 3. Defining Inputs and Outputs:
- 4. Writing the Program Logic:
- 5. Testing and Debugging:
- 6. Downloading and Running:
- 7. Monitoring and Adjusting:

1 Configure IP address Manual

configure the IP address, subnet mask, and potentially the gateway address on your devices

Control Panel\Network and Internet\Network Connections \Ethernet2 Properties\change setting of this connection\

The default IP address for the Siemens S7-1200 PLC is typically 192.168.0.1.








Configure IP Address Auto

Sample Batch Script

The following sample script provides a simple menu-driven approach. Save it as ip_changer.bat and run it as an administrator:



Siemens TIA Portal local project server

```
INFO: [Portal] Performance monitoring is disabled.

INFO: [Portal] net.tcp://127.8.0.1/5827/Siemens.Automation.Portal.Server/ProjectRepository

INFO: [Portal] AddbefaultUsers method. Default Users list: EXPERTBOOK/Fanez, BUILTIN\Administrators

INFO: [Portal] AddbefaultUsers method. Fetched Users list from database: 5-1-5-12-76004528-1560449861-4124384797-1001.5-1-5-32-544

INFO: [Portal] AddbefaultUsers method. Fetched Users list from database: 5-1-5-12-76004528-1560449861-4124384797-1001.5-1-5-32-544

INFO: [Portal] Net opened, listening at:

INFO: [Portal] Net opened, listening at:

INFO: [Portal] Starting new instance of access control server.

INFO: [AccessControl] No upgrade steps available for database file [AccessControl.db], current version 13 is latest version

INFO: [AccessControl] Host opened, listening at:

(only from this machine)

INFO: [AccessControl] Host opened, listening at:

(only from this machine)

INFO: [AccessControl] Access Control server started successfully.

Server started. Press Ctrl-C to ext:

NRO: [Portal] ClientAddress: 127.0.0.1/59782 : GetGroups Completed

INFO: [Portal] ClientAddress: 127.0.0.1/59782 : CreateProject Completed

INFO: [Portal] ClientAddress: 127.0.0.1/59782 : Starting project server [Project Server [Project 3] Finished paiding is starting.

INFO: [Porject: Project] Performance monitoring is enabled for project server [Project] ClientAddress: 127.0.0.1/59782 : CreateProject Server [Project] ClientAddress: 127.0.0.1/59782 : CreateProject Server [Project 3].

INFO: [Porject: Project] Performance monitoring is enabled for project server [Project] ClientAddress: 127.0.0.1/59782 : CreateProject Server [Project] Project Server [Project] Server [Project] Server [Project] Server [Proj
```

Siemens TIA Portal local project server

To manage the Siemens TIA Portal local project server from the command line, you'll use the prjsrv command (for the project server) and the pspt command (for the Power Tools). These tools, along with the musrv command for the multiuser server, allow you to start, stop, configure, and manage server projects and libraries.

Key Commands and Their Functions:

Used for managing the project server itself.

You can use it to start, stop, or configure the project server.

Used to manage server projects, libraries, and local sessions on the project server through the Power Tools.

Used for managing the multiuser server, including installation, configuration, and certificate

Example Usage:

starting the project server: prjsrv start.
Stopping the project server: prjsrv stop.
Installing the multiuser server: musrv
install -r erepository_path>-p <port_number>
-b https -h <certificate_hash> (requires administrator rights).
Managing server projects using Power Tools: pspt (followed by specific commands for actions like creating, opening, or deleting projects).

Important Considerat


Some commands, especially those related to installation and configuration of the multiuser server, require administrator privileges.

TIA Portal Installation:

The local project server is typically installed by default with TIA Portal.

The Project Server Power Tools are used for more advanced management tasks and are accessed via the pspt command.

4.2. Online connection via industrial Ethernet : assigning an IP Adress for the PG



IP address PG/PC --> PLC Subnet

In the last session, the lecturer taught 2 ways to change the PC and PLC subnet.

Conclusion:

CPU reset factory setting as Topic 4.5.1 will change subnet to default therefore changing PC/PG subnet refer to subject 4.2.1 are recomended steps compare to changing PLC subnet

4.5.1 SIMATIC S7-1200/1500:

Memory Concept for CPU Reset to Factory Setting

Requirement:

6ES7954-8LC02-0AA0 (EAN: 4047623402350) SIMATIC S7 Memory Card, 4 MB

Price Rm 219.88 US\$52 empowerlaptop.com

Price Rm 131.92 Refurbished JC-Electronic



Figuresimilar

| lemory | | | | |
|-------------------------------------------------------|--------------------------------------------------------------------------------------------|---------|----------------------|--|
| Type of memory | Flash-EPROM | | | |
| Memory size | 4 Mbyte | | | |
| Number of write/delete operations, min. | 500 000 | | | |
| Data retention (after final programming action), min. | 10 a; If the delete/write processes < 50 000 (1 a if the delete/write processes > 450 000) | | | |
| imensions | | | | |
| Width | 24 mm | 24 mm | | |
| Height | 32 mm | 32 mm | | |
| Depth | 2.1 mm | | | |
| Veights | | | | |
| Weight, approx. | 3 g | | | |
| lassifications | | | | |
| | | Version | Classification | |
| | eClass | 14 | 27-24-22-12 | |
| | eClass | 12 | 27-24-22-12 | |
| | eClass | 9.1 | 27-24-22-12 | |
| | eClass | 9 | 27-24-22-12 | |
| | eClass | 8 | 27-24-22-12 | |
| | eClass | 7.1 | 27-24-22-12 | |
| | eClass | 6 | 27-24-22-12 | |
| | ETIM | ٩ | EC000192 | |
| | ETIM | 8 | EC000192 | |
| | ETIM | 7 | EC000192 | |
| | IDEA | 4 | 6458 | |
| | UNSPSC | 15 | 43-20-14-02 | |
| pprovals / Certificates | | | | |
| General Product Approval Fo | For use in hazardous locations | | Maritime application | |

