

R.E.I.

TXG & YCT & RXT Rotary Tillers

**Operator's Manual
Parts Breakdown**



TABLE OF CONTENTS

INTRODUCTION.....	2
SAFETY	2
SAFETY SIGNAL WORDS.....	3
GENERAL SAFETY GUIDELINES.....	3
SAFETY DECAL CARE.....	4
BEFORE OPERATION	4
DURING OPERATION.....	5
HIGHWAY AND TRANSPORT OPERATIONS.....	6
OPERATION	8
FOLLOWING OPERATION.....	9
PREMORMING MAINTENANCE.....	9
MAINTENANCE.....	10
PARTS BREAKDOWN - YCT	11-14
PARTS BREAKDOWN - TXG	15-18
PARTS BREAKDOWN - RXT	19
PTO BREAKDOWN	25
LIMITED WARRANTY.....	26

INTRODUCTION

Thank you for purchasing your Richey Equipment YCT Series Tiller. Your rotary tiller is design to be used on Cat. 1 540 rpm tractors. It is important to properly maintain in keep in place all safety guards and shields that came with your spreader.

SAFETY

Read and understand this manual and all safety signs before operating and maintaining. Review the safety instructions and precautions annually.

TAKE NOTE! THIS SAFETY ALERT SYMBOL FOUND THROUGHOUT THIS MANUAL IS USED TO CALL YOUR ATTENTION TO INSTRUCTIONS INVOLVING YOUR PERSONAL SAFETY AND THE SAFETY OF OTHERS. FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN INJURY OR DEATH.



THIS SYMBOL MEANS

**ATTENTION!
BECOME ALERT!
YOUR SAFETY IS INVOLVED!**



SAFETY SIGNAL WORDS

Note the use of the signal words DANGER, WARNING and CAUTION with the safety messages. The appropriate signal word for each has been selected using the following guidelines:



DANGER: Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury. This signal word is to be limited to the most extreme situations typically for machine components which, for functional purposes, cannot be guarded.



WARNING: Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury, and includes hazards that are exposed when guards are removed. It may also be used to alert against unsafe practices.



CAUTION: Indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



GENERAL SAFETY GUIDELINES

Safety of the operator is one of the main concerns in designing and developing a new piece of equipment. Designers and manufacturers build in as many safety features as possible. However, every year many accidents occur which could have been avoided by a few seconds of thought and a more careful approach to handling equipment. You, the operator, can avoid many accidents by observing the following precautions in this section. To avoid personal injury, study the following precautions and insist those working with you, or for you, follow them.

Replace any CAUTION, WARNING, DANGER or instruction safety decal that is not readable or is missing. Location of such decals is indicated in this booklet.

Do not attempt to operate this equipment under the influence of drugs or alcohol.

Review the safety instructions with all users annually.

This equipment is dangerous to children and persons unfamiliar with its operation. The operator should be a responsible adult familiar with farm machinery and trained in this equipment's operations. **Do not allow persons to operate or assemble this unit until they have read this manual and have developed a thorough understanding of the safety precautions and of how it works.**

To prevent injury or death, use a tractor equipped with a Roll Over Protective System (ROPS). Do not paint over, remove or deface any safety signs or warning decals on your equipment. Observe all safety signs and practice the instructions on them.

Never exceed the limits of a piece of machinery. If its ability to do a job, or to do so safely, is in question - **DON'T TRY IT.**



SAFETY DECAL CARE

- Keep safety signs clean and legible at all times.
- Replace safety signs that are missing or have become illegible.
- Replaced parts that displayed a safety sign should also display the current sign.
- Safety signs are available from your Distributor or Dealer Parts Department or the factory.

How to Install Safety Signs:

- Be sure that the installation area is clean and dry.
- Decide on the exact position before you remove the backing paper.
- Remove the smallest portion of the split backing paper.
- Align the decal over the specified area and carefully press the small portion with the exposed sticky backing in place.
- Slowly peel back the remaining paper and carefully smooth the remaining portion of the decal in place.
- Small air pockets can be pierced with a pin and smoothed out using the piece of decal backing paper.



BEFORE OPERATION

- Carefully study and understand this manual.
- Do not wear loose-fitting clothing, which may catch in moving parts.
- Always wear protective clothing and substantial shoes.
- Assure that all tires are inflated evenly.
- Give the unit a visual inspection for any loose bolts, worn parts or cracked welds, and make necessary repairs. Follow the maintenance safety instructions included in this manual.
- Be sure that there are no tools lying on or in the equipment.
- Do not use the unit until you are sure that the area is clear, especially children and animals.

- Don't hurry the learning process or take the unit for granted. Ease into it and become familiar with your new equipment.
- Practice operation of your equipment and its attachments. Completely familiarize yourself and other operators with its operation before using.
- Use a tractor equipped with a Roll Over Protective System (ROPS) and fasten your seat belt prior to starting the engine.
- The manufacturer does not recommend usage of tractor with ROPS removed.
- Move tractor wheels to the widest recommended settings to increase stability.
- Securely attach to towing unit. Use a high strength, appropriately sized hitch pin with a mechanical retainer and attach safety chain.
- Do not allow anyone to stand between the tongue or hitch and the towing vehicle when backing up to the equipment.



DURING OPERATION

- Children should not be allowed on the product.
- Clear the area of small children and bystanders before moving the feeder.
- If using a towing unit, securely attach feeder by using a hardened 3/4" pin, a metal retainer, and safety chains if required. Shift towing unit to a lower gear before going down steep downgrades, thus using the engine as a retarding force. Keep towing vehicle in gear at all times. Slow down for corners and rough terrain.
- Make sure you are in compliance with all local and state regulations regarding transporting equipment on public roads and highways. Lights and slow moving signs must be clean and visible by overtaking or oncoming traffic when feeder is transported.
- Beware of bystanders, **particularly children!** Always look around to make sure that it is safe to start the engine of the towing vehicle or move the unit. This is particularly important with higher noise levels and quiet cabs, as you may not hear people shouting.
- **NO PASSENGERS ALLOWED** - Do not carry passengers anywhere on, or in, the tractor or equipment, except as required for operation.
- Keep hands and clothing clear of moving parts.
- Do not clean, lubricate or adjust your equipment while it is moving.
- When halting operation, even periodically, set the tractor or towing vehicle brakes, disengage the PTO, shut off the engine and **remove the ignition key.**
- Be especially observant of the operating area and terrain - watch for holes, rocks or other hidden hazards. Always inspect the area prior to operation.

- **DO NOT** operate near the edge of drop-offs or banks.
- **DO NOT** operate on steep slopes as overturn may result.
- Operate up and down (not across) intermediate slopes. Avoid sudden starts and stops.



HIGHWAY AND TRANSPORT OPERATIONS

- Adopt safe driving practices:
- Keep the brake pedals latched together at all times. **NEVER USE INDEPENDENT BRAKING WITH MACHINE IN TOW AS LOSS OF CONTROL AND/OR UPSET OF UNIT CAN RESULT.**
- Always drive at a safe speed relative to local conditions and ensure that your speed is low enough for an emergency stop to be safe and secure. Keep speed to a minimum.
- Reduce speed prior to turns to avoid the risk of overturning.
- Avoid sudden uphill turns on steep slopes.
- Always keep the tractor or towing vehicle in gear to provide engine braking when going downhill. Do not coast.
- Do not drink and drive!
- Comply with state and local laws governing highway safety and movement of farm machinery on public roads.
- Use approved accessory lighting flags and necessary warning devices to protect operators of other vehicles on the highway during daylight and nighttime transport. Various safety lights and devices are available from your dealer.
- The use of flashing amber lights is acceptable in most localities. However, some localities prohibit their use. Local laws should be checked for all highway lighting and marking requirements.
- When driving the tractor and equipment on the road or highway under 40 kph (20 mph) at night or during the day, use flashing amber warning lights and a slow moving vehicle (SMV) identification emblem.
- Plan your route to avoid heavy traffic.
- Be a safe and courteous driver. Always yield to oncoming traffic in all situations, including narrow bridges, intersections, etc.
- Be observant of bridge loading ratings. Do not cross bridges rated lower than the gross weight as which you are operating.

- Watch for obstructions overhead and to the side while transporting.
- Always operate equipment in a position to provide maximum visibility at all times. Make allowances for increased length and weight of the equipment when making turns, stopping the unit, etc.
- Pick the levellest possible route when transporting across fields. Avoid the edges of ditches or gullies and steep hillsides.
- Be extra careful when working on inclines.
- Maneuver the tractor or towing vehicle at safe speeds.
- Avoid overhead wires or other obstacles. Contact with overhead lines could cause serious injury or death.
- Avoid loose fill, rocks and holes; they can be dangerous for equipment operation or movement.
- Allow for unit length when making turns.
- Operate the towing vehicle from the operator's seat only.
- Never stand alongside of unit with engine running or attempt to start engine and/or operate machine while standing alongside of unit.
- Never leave running equipment attachments unattended.
- As a precaution, always recheck the hardware on equipment following every 100 hours of operation. Correct all problems. Follow the maintenance safety procedures.

Operation




Before attaching the rotary tiller to the tractor, check the unit to ensure there is oil in the top and side gearbox. See Maintenance section for lubricant specifications.

Attaching to the tractor

1. With the Rotary Tiller on a level surface, back the Cat. 1 tractor so the tractor lift arms are even with the unit's lower hitch pins. Lower or raise the tractor hitch arms until the 7/8" bushing in the arm is inside the clevis of lower hitch points. **Be sure nothing is between the tractor and the tiller before backing up.**
2. Insert the lower hitch pin through the lower hitch blocks and the tractor arm. The YCT series tillers have adjustable lower hitch blocks that can be slide to facilitate usage on larger tractors.
3. Secure the lift arm in place by using a 7/16" lynch pin or other fastener.
4. Repeat with the other arm.
5. Connect the driveline to the tractor's PTO output shaft. Secure it in place.
6. Connect the tractor top link to the upper hitch point of the rotary tiller.
7. Start the tractor and slowly raise the tiller. Check for drawbar interference. Be sure that the PTO driveline does not bottom out when lifting the machine to its maximum height. If it does appear that it could bottom out, it is necessary to shorten the PTO driveline. (See Shortening a PTO Driveline section). Ensure that in the working position there is an overlap of a minimum of 1/3 the length of each profile.

Shortening a PTO Driveline

1. With the implement attached to the tractor's three point hitch, and the PTO driveline not installed, separate the PTO driveline. Attach the implement end to the implement and the other end to the tractor PTO input shaft.
2. Raise the implement by using the tractor's hydraulic 3-point hitch to its maximum lift height.
3. Hold the half shafts next to each other and mark them so each end is approximately 1/2" from hitting the end of the telescopic profiles.
4. Shorten the inner and out guard tubes equally.
5. Shorten the inner and outer profiles by the same length as the guard tubes. Using a rattail file, round off all sharp edges and burrs. Grease the telescopic profile generously before reassembling.



Do not shorten too much, the proper overlap is a minimum of 1/3 the length of each profile.



Caution: Slip Clutches may become hot. Do Not Touch. Keep the slip clutch area clear of an material that may catch fire.

Slip clutches have adjustable torque settings. The torque setting varies with the different compression of each spring. All the springs should have an equal amount of compression.

IMPORTANT: Do not over-tighten the compression nuts as this may impair performance or cause premature wearing of the slip clutch.

Slip Clutch adjustments

Slip Clutch must be adjusted before first use or after a storage period.

1. Using a marker, scribe a line across the exposed edges of the clutch plate and friction discs.
2. Back off compression nuts to free friction discs by turning each nut *exactly* 2 revolutions.
3. Start the tractor and run the driveline at a low idle to slip the friction discs. This will remove the dirt, corrosion and surface floss from the clutch plate faces.
4. Disengage PTO, shut down tractor and wait for all components to come to a complete stop.
5. Inspect the clutch and ensure that the scribed markings on the disc and plates have changed position. If any two marks are still aligned, this is an indication that these discs have not slipped. It may be necessary to completely disassemble the clutch to free them up.
6. After ensuring all discs are free, tighten the compression nuts, uniformly, *exactly* 2 revolutions to reset the clutch original pressure.

Working Depth Adjustment

The working depth is controlled by raising or lowering the side skids. If the skids are raised, the working depth increases. By lowering the skids, the tilling depth with decrease.

Tailgate adjustment

The tailgate can be adjusted to help smooth and compact the tilled ground. Release the chain and secure to the desired height.



Start up

After making the necessary adjustments, lower the rotary tiller until the blades are a couple of inches from the ground. Engage the PTO and slowly lower the tiller to begin working.

Removal and Storage

After finishing, remove the rotary tiller from the tractor.

1. Put the PTO driveline in a safe location so it will not become damaged.
2. Clean and dry the equipment.
3. Replace any damaged or worn parts.
4. Check all bolts and nuts for tightness.
5. Lubricate and protect the machine from the elements.



FOLLOWING OPERATION

- Following operation, or when unhitching, stop the tractor or towing vehicle, set the brakes, disengage the PTO and all power drives, shut off the engine and **remove the ignition keys**.
- Store the unit in an area away from human activity.
- Do not park equipment where it will be exposed to livestock for long periods of time. Damage and livestock injury could result.
- Do not permit children to play on or around the stored unit.
- Make sure all parked machines are on a hard, level surface and engage all safety devices.
- Wheel chocks may be needed to prevent unit from rolling.



PERFORMING MAINTENANCE

- Good maintenance is your responsibility. Poor maintenance is an invitation to trouble.
- Make sure there is plenty of ventilation. Never operate the engine of the towing vehicle in a closed building. The exhaust fumes may cause asphyxiation.
- Be certain all moving parts on attachments have come to a complete stop before attempting to perform maintenance.
- Always use the proper tools or equipment for the job at hand.
- Use extreme caution when making adjustments.
- Never replace hex bolts with less than grade five bolts unless otherwise specified.
- After servicing, be sure all tools, parts and service equipment are removed.
- Where replacement parts are necessary for periodic maintenance and servicing, genuine factory replacement parts must be used to restore your equipment to original specifications. The manufacturer will not claim responsibility for use of unapproved parts and/or accessories and other damages as a result of their use.
- If equipment has been altered in any way from original design, the manufacturer does not accept any liability for injury or warranty.

MAINTENANCE


8 hours

Grease the Rotor support (*GP grease*)
Grease PTO shaft cross & bearings (*GP grease*)
Check Hardware for tightness

16 hours

Check oil level in center gearbox (*90wt*)
Check oil level in side gearbox (*140wt*)
Check Hardware for tightness


TXG-040 - TXG-050 - TXG-060



TXG-040 - TXG-050 - TXG-060

Position	Part #	Description	Qty
1	RC400000	"R" Clip 4mm	2
2	YT1066010204	Hitch Pin	2
3	TX0202	Lower Hitch Bracket	2
4	TX0203	"U" Bolt, Lower Hitch Bracket	2
5	NM120000	Hex Nut 12MM	4
6	BM101530	Bolt 10 x 30	8
7	TX0101	A Frame	1
8	TX3011	PTO Shield (complete)	1
9	BM812516	Bolt 8 x 1.25 x 16	4
10	YT1066010202	Top Hitch Pin	1
11	RC400000	"R" Clip 4mm	1
12	OS356210	Oil Seal 35.62.10	1
13	SRI62000	Snap Ring D.62 Internal	1
14	B6007000	Bearing 6007	1
15	TX0307	Input Shaft	1
16	SRE30000	Snap Ring D.30 External	1
17	TX0303	Pinion Gear Z-13	1
18	B30305	Bearing 30305	1
19	SRI60000	Snap Ring D.62 Internal	1
20	TX0309	Gearbox Cap (Dia. 62)	1
21	SRE34000	Snap Ring D.34 External	1
22	TX0402	Shim 2mm	1
23	TXC0507	Gear Drive	1
24	TX0402	Shim 2mm	1
25	B6207000	Bearing 6207	1
26	TX0304-40	Drive Shaft TXG-040	-
	TX0304-50	Drive Shaft TXG-050	-
	TX0304-60	Drive Shaft TXG-060	-
27	TX0306	Gasket - Drive shaft	1
28	TX0301-40	Drive Shaft Tube Housing TXG-040	-
	TX0301-50	Drive Shaft Tube Housing TXG-050	-
	TX0301-60	Drive Shaft Tube Housing TXG-060	-
29	BM101525	Bolt 10 x 25	4
30	B62072RS	Bearing 6207-2RS	1
31	TX0304	Ring Gear Z19	1
32	TX0402	Shim 2mm	1
33	SRE34000	Snap Ring D.34 External	1
34	TX0306	Gasket - Gearbox	1
35	TX0302	Housing - Gearbox	1
36	YT10660303000	Gearbox Oil Plug	1
37	OP1212500	Oil Plug 12 x 1.25	1
38	TX0301	Lifting Hook	1
39	BM101525	Bolt 10 x 25	4
40	BM101530	Bolt 10 x 30	4
41	DP1615000V	Drain Plug M16 x 1.5 Vented	1
42	BM101525	Bolt 10 x 25	2
43	YT1066050200	Stand Bracket	1
44	RC300000	R-Clip 3mm	1
45	YT10660501	Pin - Stand	1
46	BM101530	Bolt 10 x 30	2
47	YT1066050100	Stand Leg	1


TXG-040 - TXG-050 - TXG-060



TXG-040 - TXG-050 - TXG-060

Position	Part #	Description	Qty
48	TX0601	Skid Weldment - Left	1
49	NM24150	Lock Nut 24 X 1.5	1
50	OR253	O Ring - 25.X 3	1
51	TX0501	Side Gear Cover	1
52	OP121250	Oil Plug 12 X 1.25	1
53	TX0501	Gasket - Side Gear/Chain Case	1
54	BM812520	Bolt 8 x 1.25 x 20	13
55	TXC0512	Gasket	1
56	B3030500	Bearing 30305	1
57	SRI62000	Snap Ring 62 Internal	1
58	TXC0511	Gasket	1
59	TXC0508	Idler Gear	1
60	SRE34000	Snap Ring External D.34	1
61	TX0401	Gasket	1
62	TXC0509	Gear - Bottom	1
63	TX0302	Side Panel - Left	1
64	TX0402	Shim 2mm	1
65	B6207000	Bearing 6207	1
66	TX0406	Gasket - Rotor	1
67	BM101525	Bolt 10 x 25	4
68	TX0403	Bearing Support	1
69	BM101530	Bolt 10 x 30	4
70	OS406210	Oil Seal 40x62x10	1
71	TX0404	Blade - Left	-
	TX0405	Blade - Right	-
72	TX0401-40	Rotor - TX40	-
	TX0401-50	Rotor - TX50	-
	TX0401-60	Rotor - TX60	-
73	BM1212535	Blade Bolt - 12 x 35 Fine Thread	-
74	OS406210	Oil Seal 40x62x10	1
75	BM101530	Bolt 10 x 30	4
76	TX0403	Bearing Support	1
77	B6207000	Bearing 6207	1
78	TX0402	Shim 2mm	1
79	SRE34000	Snap Ring D. 34 External	1
80	TX0406	Gasket - Rotor	1
81	TX0201	Side Panel - Right	1
82	BM101525	Bolt 10 x 25	3
83	GN06100	Grease Nipple 6mm	1
84	TX0602	Skid Weldment - Right	1
85	BM101530	Bolt 10 x 30	2
86	BM101525	Bolt 10 x 25	4
87	TX02-40	Frame Weldment TXG-040	-
	TX02-50	Frame Weldment TXG-050	-
	TX02-60	Frame Weldment TXG-060	-
88	BM1690	Bolt 16 x 90	2
89	TX07-40	Tailgate TXG-040	-
	TX07-50	Tailgate TXG-050	-
	TX07-60	Tailgate TXG-060	-
90	TX01	Tailgate Chain assembly	1


YCT-060 - YCT-066 - YCT-074 - YCT-082



YCT-060 - YCT-066 - YCT-074 - YCT-082

Position	Part #	Description	Qty
1	BM101525	Bolt 10 x 1.5 x 25	16
2	YT1058010100	YCT-060 Main Frame	1
	YT1066010100	YCT-066 Main Frame	1
	YT1074010100	YCT-074 Main Frame	1
	YT1082010100	YCT-082 Main Frame	1
3	RC400000	"R" Clip 4mm	3
4	YT1066010204	Top Hitch Pin	1
5	YT106601020100	Lower Hitch Bracket	2
	YT108201020100	Lower Hitch Bracket - YCT-082	2
6	YT1066010201	U Bolt, Hitch	2
	LW14000	Lock Washer 14mm	
	NM14000	Nut 14mm	
	YT1082010201	Backing Plate w/bolts - YCT-082	2
7	BM1217535	Bolt 12 x 1.75 x 35	24
8	YT10660301	U Bolt, Drivtube	1
9	YT10660302	Support - Drivtube	1
10	YT0304	PTO Shield - Complete	1
11	YT106601030100	A Frame	1
12	YT1066010202	Hitch Pin	2
13	BM101525	Bolt 10 x 1.5 x 25	4
14	YT10580400	Gearbox Support Tube YCT-060	1
	YT10660400	Gearbox Support Tube YCT-066	1
	YT10740400	Gearbox Support Tube YCT-074	1
	YT10820400	Gearbox Support Tube YCT-082	1
15	OS357210	Oil Seal 35x72x10PP	1
16	SRI72000	Snap Ring Dia. 72 - Internal	-
17	B6207000	Bearing 6207	2
18	YT10660205	Bevel Pinion Gear Shaft Z=13	1
19	BM816000	Bolt 8 x 16 mm	3
20	YT1066020300	Gearbox Oil Plug	1
21	YT10660201	Gearbox Housing	1
22	B6307000	Bearing 6307	1
23	YT10660204	Spacer	1
24	YT10660203	Gasket Bearing Cover	1
25	YT10660202	Bearing Cover	1
26	DP1615000V	Drain Plug M16 x 1.5 Vented	1
27	BM812525	Bolt 8 x 1.25 x 25 mm	15
28	YT1066080100	Side Gear Cover	1
29	YT10660801	Gasket - Side Gear Cover	1
30	SRE40000	Snap Ring Dia. 40 - External	2
31	YT10660801	Shim	??
32	YT10660209	Gear Drive 17-T	1
33	YT10660802	Shim	??
34	YT10580210	Drive Shaft YCT-060	1
34	YT10660210	Drive Shaft YCT-066	1
34	YT10740210	Drive Shaft YCT-074	1
34	YT10820210	Drive Shaft YCT-082	1
35	B6308000	Bearing 6308	1
35	B63082RS	Bearing 6308 2RS	1
36	BM101530	Bolt 10 x 1.5 x 30	12
37	YT1066010400	Side Board - Left	1
38	YT10660207	Gasket Driveshaft	2
38	YT10660207	Gasket Driveshaft	2
39	YT1058020100	Driveshaft Tube Housing YCT-060	1
39	YT1066020100	Driveshaft Tube Housing YCT-066	1
39	YT1074020100	Driveshaft Tube Housing YCT-074	1
39	YT1082020100	Driveshaft Tube Housing YCT-082	1


YCT-060 - YCT-066 - YCT-074 - YCT-082



YCT-060 - YCT-066 - YCT-074 - YCT-082

Position	Part #	Description	Qty
40	YT10660211	Lifting Hook	1
41	OS65408	Oil Seal 65 x 40 x 8	1
42	YT10660206	Output Gear	1
43	YT10660208	Shim	??
44	DP1415000	Drain Plug M14 x 1.5	2
45	LNM2400	Lock Nut 24mm	1
46	OR253	O-Ring	??
47	B3030600	Bearing 30306	2
48	SRI72000	Snap Ring Dia. 72 - Internal	1
49	YT10660802	Middle Gear - Side Drive	1
50	YT10660803	Idle Gear Spacer	1
51	NM3515	Nut 35mm x 1.5	1
52	LWC35	Castle Washer - 35mm	1
53	YT10660804	Gear - Rotor	1
54	YT10660805	Gasket	??
55	SRI10000	Snap Ring Dia. 100 - Internal	1
56	YT10660808	Gasket - Drive Rotor	1
57	B6309000	Bearing 6309	1
58	OS805012	Oil Seal 80/50/12	1
59	YT10660805	Rotor Support - Side Drive	1
60	YT10660807	Rotor Shaft Support	1
61	YT10660809	Dust shielding	1
62	BM1217530	Bolt 12 x 1.75 x 30 mm	6
63	BM1212535	Bolt 12 x 1.25 x 35	84, 96, 108 120
	NM120001	Hex Nut 12mm	84, 96, 108 120
	LW12000	Lock Washer 12mm	84, 96, 108 120
64	YT1066090101	Tiller Tine - Right	21, 24, 27,30
	YT1066090102	Tiller Tine - Left	21, 24, 27,30
65	YT106009010100	Rotor Shaft - YCT-060	1
65	YT106609010100	Rotor Shaft - YCT-066	1
65	YT107409010100	Rotor Shaft - YCT-074	1
65	YT108209010100	Rotor Shaft - YCT-082	1
66	YT10660901	Cover	1
67	YT10660903	Rotor Shaft Head - Right	1
68	OS456212	Oil Seal 45 x 62 x 12	1
69	YT10660904	Bearing Housing	1
70	YT10660908	Retaining Washer	1
71	BM1217525	Bolt 12 x 1.75 x 25	1
72	YT10660902	Inner Cover - Rotor Shaft	1
73	YT10660907	End Cap	1
74	BM101535	Bolt 10 x 1.5 x 35 mm	8
75	GN101500	Grease Nipple	1
76	YT10660501	Pin - Stand	1
77	RC300000	R-Clip 3mm	1
78	YT1066050200	Stand Bracket	1
79	YT1066050100	Stand Leg	1
80	YT10660600	Skid Weldment - Left	1
80	YT10660600	Skid Weldment - Right	1
81	BM162090	Bolt 16 x 2.0 x 90	2
82	YT1060070100	Tailgate YCT-060	1
	YT1066070100	Tailgate YCT-066	1
	YT1074070100	Tailgate YCT-074	1
	YT1082070100	Tailgate YCT-082	1
83	YT1066070200	Chain - Drag Board	1
84	YT10660101	Side Plate - Right	1


RXT-080 - RXT-088 - RXT-096



RXT-080 - RXT-088 - RXT-096

POS.	Part #	Description	Qty
1	SB100755	Lower Hitch Pin - Cat. 1 & 2	2
2	RC400000	"R" Clip 4mm	4
3	SB100756	Lynch pin	2
4	RX0100	A Frame	1
5	YT1066010204	Top Hitch Pin Cat. 1	1
10	RX0310	Cap - Front Gearbox	1
11	RX0309	Input Shaft	1
13	RX0311	Gasket - Input Cap	2
14	OS406508	Oil Seal 40 x 65 x 8	1
15	B6208	Bearing - 6208	1
18	SRE40000	Snap Ring - Pinion Gear - Front	1
19	RX0305	Housing - Gearbox	1
20	YT10660303000	Gearbox Oil Plug	1
21	RX0308	Pinion Gear	1
22	B30310	Bearing 30310	1
23	RX0306	Gearbox Back Gasket	2
24	OR3555	O-Ring - 35x5.5	1
25	RX0307	Gearbox Cap	1
27	RX0315	Gasket - Drive shaft	1
28	BM101525	Bolt 10 x 1.5 x 25	6
29	RX0301-80	Drive Shaft Tube Housing RXT-080	1
29	RX0301-88	Drive Shaft Tube Housing RXT-088	
29	RX0301-96	Drive Shaft Tube Housing RXT-096	
31	OS72559	Oil Seal - 72 X 55 X 9	1
32	RX0305	Gasket - Drive shaft tube housing	3
33	B6212	Bearing 6212	1
34	RX0304	Ring Gear	1
35	SRE5200	Snap Ring Ext. 52mm	1
36	RX0314	Gasket - Center Gearbox Left Side	2
38	RX0302-80	Gearbox Support Tube - RXT-080	1
38	RX0302-88	Gearbox Support Tube - RXT-088	
38	RX0302-96	Gearbox Support Tube - RXT-096	
42	RX0206	Hanger - Tailgate	2
43	RC300000	R-Clip - Tailgate Adjustment	2
45	RX0205	Pin - Tailgate Adjustment	2
46	BM162050	Bolt - 16 x 2.0 x 50	2
47	BM162040	Bolt - 16 x 2.0 x 40	6
48	RX0601	Skid Support	2
49	RX0601	Skid Weldment - Left	1
50	RX0502	Skid shield	1


RXT-080 - RXT-088 - RXT-096



RXT-080 - RXT-088 - RXT-096

POS.	Part #	Description	Qty
51	RX0505	Skid Bracket	1
52	BM1217535	Bolt - 12 x 1.75 x 35	10
54	NM2415	Nut Lock - 24mm	1
55	RX0502	Side Drive Cover	1
56	BM812516	Bolt 8 x 1.25 x 16	27
57	DP1615000V	Breather cap - Side housing	1
58	SRE45000	Snap Ring Ext. 45mm	1
59	RX0506	Top Gear	1
60	SRI100	Snap Ring - Top Gear Bearing	1
61	BNUP309E	Bearing BNUP309E	1
62	RX0301	Gasket - Driveside Top Gear	1
63	SRE45000	Snap Ring Ext. 45mm	1
64	RX0302-80	Drive Shaft - RXT-080	1
64	RX0302-88	Drive Shaft - RXT-088	
64	RX0302-96	Drive Shaft - RXT-096	
65	RX0501	Gasket - Side Gear Case	1
66	RX0501	Side Panel - Left	1
67	RX0201-80	Frame Weldment - RXT-080	1
67	RX0201-88	Frame Weldment - RXT-088	
67	RX0201-96	Frame Weldment - RXT-096	
68	OR3555	O-Ring - 35x5.5	1
69	B30307	Bearing 30307	2
70	SRI90000	Snap Ring Int. 90mm	1
71	RX0507	Idler Gear	1
73	T810-1998	Nut 36*1.5	2
74	SRE3500	Snap Ring Ext. 35mm	2
75	FW3600	Flat Washer 36mm	1
76	RX0508	Bottom Gear	1
77	SRI100	Snap Ring Int. 100mm	1
78	B6309	Bearing - 6309	1
79	OR122355	O-Ring - - 122x 3.55	1
80	RX0402	Bearing Support - Left Side	1
82	OS76535085	Float Oil Seal-76 x 53.5 x 8.5	2
83	RX0401	Rotor Support shaft - Left side	1
84	BM1217530	Bolt - 12 x 1.75 x 30	6
85	RX0204	Protector - Right Side	1
86	RX0406	Gasket - Rotor	2
87	RX0201	Side Panel - Right	1
88	RX0602	Skid Weldment - Right	1
89	RX0403	Rotor Support shaft - Right side	1
91	RX0404	Bearing Support	1


RXT-080 - RXT-088 - RXT-096



RXT-080 - RXT-088 - RXT-096

POS.	Part #	Description	Qty
92	B6308	Bearing - 6308	1
93	FW3000	Flat Washer 30mm	1
94	SRE30000	Snap Ring Ext. 30mm	1
96	OS925355	O Ring - 92.5 x 3.55	1
97	RX0405	End Cap - Rotor Right side	1
98	BM101535	Bolt 10 x 1.5 x 35	6
99	BM1212535	Bolt - 12 x 1.25 x 35	
100	RX0407L	Blade - Left	66
100	RX0407R	Blade - Right	
101	RX0401-80	Rotor -RXT-080	1
101	RX0401-88	Rotor -RXT-088	
101	RX0401-96	Rotor -RXT-096	
102	RX0701L-80	Rod - Tailgate RXT-080 Left	1
102	RX0701L-88	Rod - Tailgate RXT-088 Left	
102	RX0701L-96	Rod - Tailgate RXT-096 Left	
103	RX0708	Rod Tube - Nylon	1
104	RX0702-80	Tailgate RXT-080	-
104	RX0702-88	Tailgate RXT-088	
104	RX0702-96	Tailgate RXT-096	
105	BM1217525	Bolt- 12 x 1.75 x 25	4
106	RX0702	Bracket - Tailgate Spring	2
107	RX0703	Rod - Tailgate Spring	2
108	RX0701	Bushing - Tailgate	2
109	BM1217570	Bolt-12 x 1.75 x 70	2
110	RX0707	Spring - Tailgate	4
111	RX0701R-80	Rod - Tailgate RXT-080 Right	-
111	RX0701R-88	Rod - Tailgate RXT-088 Right	
111	RX0701R-96	Rod - Tailgate RXT-096 Right	

PTO Shaft



Pos.	Part #	Description	Qty
1	DP1075-40	PTO Yoke - Series 40	1
	DP1075-60	PTO Yoke - Series 60	
2	DP1079-40	Female Yoke and Tube (tractor end) - Series 40	1
	DP1079-60	Female Yoke and Tube (tractor end) - Series 60	
3	DP1076-40	Cross and Bearings - Series 40	2
	DP1076-60	Cross and Bearings - Series 60	
4	DP1078-40	Male Yoke and Tube (implement end) - Series 40	1
	DP1078-60	Male Yoke and Tube (implement end) - Series 60	
5	180-510-30	Friction Disc - 4 3/4" OD	2 - 4
	180-510-40	Friction Disc - 5 1/2" OD	
6	DP1074F-40	Complete Female End PTO Shielding (tractor end) - Series 20-40	1
	DP1074F-60	Complete Female End PTO Shielding (tractor end) - Series 60	
7	DP1074M-40	Complete Male End PTO Shielding (implement end) - Series 20-40	1
	DP1074M-60	Complete Male End PTO Shielding (implement end) - Series 60	
8	DP1098-30	Slip Clutch Complete - 150mm Clutch (2 disc)	1
	DP1098-40	Slip Clutch Complete - 180 mm Clutch (2 disc)	
	DP1098-60	Slip Clutch Complete - 180 mm Clutch (4 disc)	
9	147120	Complete PTO - Series 40 - 150mm Slip Clutch	1
	147122	Complete PTO - Series 40 - 180mm Slip Clutch	
	147125	Complete PTO - Series 60 - 180mm Slip Clutch	

LIMITED WARRANTY

Richey Equipment warrants to the original purchaser of any new piece of machinery from Richey Equipment, purchased from an authorized Richey Equipment dealer, that the equipment be free from defects in material and workmanship for a period of one (1) year for non-commercial, state, and municipalities' use, ninety (90) days for commercial use from date of retail sale. Warranty for rental purposes is thirty (30) days. The obligation of Richey Equipment to the purchaser under this warranty is limited to the repair or replacement of defective parts.

A four (4) year extended **Gearbox Limited Warranty** is provided for YCT & RXT models at the end of the standard one (1) year warranty period. This warranty is not provided for commercial or rental uses. The extended warranty provides for the replacement of parts only. Not covered are oil seals, or any damages to the gearbox due to lack of lubrications.

Replacement or repair parts installed in the equipment covered by this limited warranty are warranted for ninety (90) days from the date of purchase of such part or to the expiration of the applicable new equipment warranty period, whichever occurs later. Warranted parts shall be provided at no cost to the user at an authorized Richey Equipment dealer during regular working hours. Richey Equipment reserves the right to inspect any equipment or parts which are claimed to have been defective in material or workmanship.

This limited warranty does not apply to and excludes wear items such as shear pins, tires, tubes knives, blades or other wear items. Oil or grease is not covered by this warranty.

All obligations of Richey Equipment under this limited warranty shall be terminated if:

Proper service is not preformed on the machine

The machine is modified or altered in any way.

The machine is being used or has been used for purposes other than those for which the machine was intended.

DISCLAIMER OF IMPLIED WARRANTIES & CONSEQUENTIAL DAMAGES

Richey Equipment obligation under this limited warranty, to the extent allowed by law, is in lieu of all warranties, implied or expressed, including implied warranties of merchantability and fitness for a particular purpose and any liability for incidental and consequential damages with respect to the sale or use of the items warranted. Such incidental and consequential damages shall include but not be limited to: transportation charges other than normal freight charges; cost of installation other than cost approved by Richey Equipment; duty; taxes; charges for normal service or adjustment; loss of crops or any other loss of income; rental of substitute equipment, expenses due to loss, damage, detention or delay in the delivery.



R.E.I.

**Distributed By:
Richey Equipment Inc.
P.O. Box 609
White Pine, Tn. 37890
865-674-6042
800-207-2086**