User's manual ACS320 drives (0.5 to 30 hp)





List of related manuals

Drive manuals	Code (English)
ACS320 drives (0.5 to 30 hp) user's manual	3AUA0000062599
ACS320 Short Form User's Manual	3AUA0000086933
Option manuals and guides	
MFDT-01 FlashDrop user's manual	3AFE68591074
MREL-01 output relay module user's manual	3AUA0000035974
MUL1-R1 installation instructions for ACS150, ACS310, ACS320, ACS350 and ACS355	3AFE68642868
MUL1-R3 installation instructions for ACS310, ACS320, ACS350 and ACS355	3AFE68643147
MUL1-R4 installation instructions for ACS310, ACS320, ACS350 and ACS355	3AUA0000025916
SREA-01 Ethernet adapter module quick start-up guide	3AUA0000042902
SREA-01 Ethernet adapter module user's manual	3AUA0000042896
Maintenance manuals	
Guide for capacitor reforming in ACS50, ACS55, ACS150, ACS310, ACS350, ACS355, ACS550, ACH550 and R1-R4 OINT-/SINT-boards	3AFE68735190

You can find manuals and other product documents in PDF format on the Internet. See section *Document library on the Internet* on the inside of the back cover. For manuals not available in the Document library, contact your local ABB representative.

User's manual

ACS320 drives (0.5 to 30 hp)

Table of contents	
1. Safety	
4. Mechanical installation	1
6. Electrical installation	
8. Start-up	\Diamond
Index	i

ist of related manuals	2
1. Safety	
Contents of this chapter 15 Use of warning symbols 15 Safety in installation and maintenance 16 Electrical safety 16 General safety 17 Safe start-up and operation 17 General safety 17 General safety 17	5 6 7 7
2. Introduction to the manual	
Contents of this chapter 15 Applicability 15 Farget audience 15 Purpose of the manual 15 Contents of this manual 20 Related documents 2 Categorization by frame size 2 Quick installation and commissioning flowchart 2	9 9 9 0 1
3. Operation principle and hardware description	
Contents of this chapter 25 Operation principle 25 Product overview 24 Layout 24 Power connections and control interfaces 25 Type designation label 26 Type designation key 27	3 4 4 5 6
1. Mechanical installation	
Contents of this chapter 29 Checking the installation site 29 Requirements for the installation site 29 Required tools 30 Inpacking 31 Checking the delivery 32 Installing 32 Install the drive 32 Fasten clamping plates 34	9 9 0 1 1 2
5. Planning the electrical installation	
Contents of this chapter	5

Implementing the AC power line connection	35
Selecting the supply disconnecting device (disconnecting means)	
European union	
North America	36
Other regions	36
Checking the compatibility of the motor and drive	
Selecting the power cables	
General rules	37
Alternative power cable types	38
Motor cable shield	38
Additional North American requirements	39
Selecting the control cables	40
General rules	40
Relay cable	40
Control panel cable	
Routing the cables	41
Control cable ducts	
Protecting the drive, input power cable, motor and motor cable in short circuit situations and	
against thermal overload	
Protecting the drive and input power cable in short-circuit situations	42
Protecting the motor and motor cable in short-circuit situations	42
Protecting the drive, motor cable and input power cable against thermal overload	42
Protecting the motor against thermal overload	42
Using residual current devices (RCD) with the drive	
Implementing a bypass connection	
Protecting the contacts of relay outputs	
Trotecting the contacts of relay outputs	
6. Electrical installation	
o. Liectrical installation	
Contents of this chapter	45
Checking the insulation of the assembly	45
Drive	
Input power cable	45
Motor and motor cable	46
Checking the compatibility with IT (ungrounded) and corner grounded TN systems	46
Connecting the power cables	47
Connection diagram	47
Connection procedure	48
Connecting the control cables	49
I/O terminals	49
Default I/O connection diagram	
Connection procedure	
Connecting the embedded fieldbus	
Connection diagram	
	•
7. Installation checklist	
Contents of this chapter	
Checking the installation	55

8. Start-up

Contents of this chapter	
HVAC control panel features	. 57
General display features	. 58
Start-up	
Start-up by using the Start-up assistant	
Start-up by changing the parameters individually	. 61
Modes	. 62
Standard display mode	. 62
Parameters mode	. 64
Start-up assistant mode	. 66
Changed parameters mode	. 68
Fault logger mode	. 68
Drive parameter backup mode	
Clock set mode	. 73
I/O settings mode	. 76
Application macros	. 77
Overview	
General considerations	. 77
Application / Macro listing	
Selecting an application macro	. 78
Restoring defaults	
Control wiring	
HVAC default	
Supply fan	
Return fan	
Cooling tower fan	
Condenser	
Booster pump	
PFA control macro	
Default I/O connections	
Internal timer	
Internal timer with constant speeds / PRV	
Floating point	
Dual setpoint with PID	
Dual setpoint with PID and constant speeds	
E-Clipse	
Hand control	
Hand Control	. 32
9. Program features	
9. Program realures	
Contents of this chapter	. 93
Start-up assistant	
Introduction	
List of the tasks and the relevant drive parameters	
Contents of the assistant displays	
Local control vs. external control	
Local control	
External control	
Settings	
octungs	



Diagnostics	97
Block diagram: Start, stop, direction source for EXT1	98
Block diagram: Reference source for EXT1	
Reference types and processing	
Settings	. 00
Diagnostics	. 00
Reference trimming	100
Settings	100
Programmable analog inputs	
Settings	101
Diagnostics	101
Programmable analog output	102
Settings	102
Diagnostics	102
Programmable digital inputs	103
Settings	103
Diagnostics	104
Programmable relay output	104
Settings	104
Diagnostics	104
Frequency input	105
Settings	105
Diagnostics	105
Transistor output	105
Settings	105
Diagnostics	105
Actual signals	106
Settings	106
Diagnostics	106
Power loss ride-through	107
Settings	107
DC magnetizing	107
Settings	107
Maintenance trigger	108
Settings	108
Acceleration and deceleration ramps	108
·	108
Settings	100
Critical speeds	109
Settings	
Constant speeds	109
Settings	109
Custom U/f ratio	110
Settings	110
Diagnostics	110
R compensation	111
Settings	111
Programmable protection functions	111
Al <min< td=""><td>111</td></min<>	111
Panel loss	111
External fault	111
Ctall protection	111



Motor thermal protection	
Earth fault protection	
Incorrect wiring	
Preprogrammed faults	
Overcurrent	
DC overvoltage	
DC undervoltage	
Drive temperature	
Short circuit	
Internal fault	
Supply phase loss	
Operation limits	
Settings	
Power limit	
Automatic resets	
Settings	
Diagnostics	
Supervisions	
Settings	
Diagnostics	
Parameter lock	
Settings	
PID control	
Process controller PID1	
External/Trim controller PID2	
Block diagrams	
Settings	
Diagnostics	
Sleep function for the process PID (PID1) control	
Example	
Settings	
Diagnostics	
Motor temperature measurement through the standard I/O	
Settings	
Diagnostics	
Timed functions	
Examples	
Settings	
Settings Diagnostics	
· · ·	
Energy optimizer Settings Settings	
Energy saving	
Settings	
Diagnostics	
Pump cleaning	
Settings	
Load analyzer	
Peak value logger	
Amplitude loggers	130



Settings	131
Diagnostics	131
PFA control	
(Requires use of MREL-01 option purchased separately)	131
PFA control	131
Settings	132
Diagnostics	132
10. Actual aignals and parameters	
10. Actual signals and parameters	
Contents of this chapter	133
Terms and abbreviations	134
Fieldbus equivalent	134
Actual signals in the short parameter view	134
Parameters in the short parameter view	135
Parameter listing	137
Group 99: Start-up data	137
Group 01: Operating data	139
Group 03: FB actual signals	144
Group 04: Fault history	148
Group 10: Start/Stop/Dir	149
Group 11: Reference select	151
Group 12: Constant speeds	157
Group 13: Analogue inputs	162
Group 14: Relay outputs	163
Group 15: Analogue outputs	166
Group 16: System controls	168
Group 17: Override	174
Group 18: Freq in & tran out	177
Group 20: Limits	180
Group 21: Start/Stop	181
•	183
Group 22: Accel/Decel	186
Group 25: Critical speeds	187
Group 26: Motor control	190
Group 29: Maintenance trig	
Group 30: Fault functions	191
Group 31: Automatic reset	196
Group 32: Supervision	198
Group 33: Information	200
Group 34: Panel display	201
Group 35: Motor temp meas	205
Group 36: Timed functions	206
Group 37: User load curve	212
Group 40: Process PID set 1	213
Group 41: Process PID set 2	230
Group 42: Ext / Trim PID	230
Group 44: Pump protection	233
Group 45: Energy saving	238
Group 46: Pump cleaning	
Group 52: Panel comm	
Group 53: FFR protocol	242



Group 64: Load analyzer 243 Group 81: PFA control 246 Group 98: Options 263	
Default values with different macros	
11. Fieldbus control	
Contents of this chapter	
System overview	
Control interface	
Planning	
Mechanical and electrical installation – EFB	
Communication set-up – EFB	
Serial communication selection	
Serial communication configuration	
Activate drive control functions – EFB	
Controlling the drive	
Start/Stop direction control	
Input reference select	
Miscellaneous drive control	l
Relay output control	
Analog output control	
PID control setpoint source	
Communication fault	
Pre-defined feedback 280 Mailbox Read/Write 281	
Actual value scaling	
Diagnostics – EFB	
Fault queue for drive diagnostics	
Serial communication diagnostics	
Diagnostic situations	
N2 protocol technical data	
Overview	
N2 analog input objects	
N2 binary input objects	
N2 analog output objects	
N2 binary output objects	
DDL file for NCU	
FLN protocol technical data	
Overview	
Reports	
Scaling drive feedback values	
Loop gains	
Point database	
Detailed point descriptions	
BACnet protocol technical data	
Binary input object instance summary	
Binary output object instance summary	
Binary value object instance summary	
Analog input object instance summary	



Modbus addressing	311 313 314 315 317 318 320 326 326 330 332
12. Fault tracing	
Alarm messages generated by the drive Alarms generated by the Basic control panel Fault messages generated by the drive Embedded fieldbus faults No master device Same device address Incorrect wiring	339 340 341 345 348 355 355 355
13. Maintenance and hardware diagnostics	
Contents of this chapter Maintenance intervals Cooling fan Replacing the cooling fan (frame sizes R1R4) Capacitors Reforming the capacitors Power connections Control panel Cleaning the control panel Changing the battery in the Assistant control panel LEDs 14. Technical data	357 358 358 360 360 360 360 360
Contents of this chapter	363
Ratings, types and voltages (for North American market) Definition Ratings, types and voltages (for European market)	364 364

Definitions	365
Sizing	365
Derating	366
Power cable sizes and fuses	367
Dimensions, weights and free space requirements	
Dimensions and weights	
Free space requirements	
Losses, cooling data and noise	
Losses and cooling data	
Noise	
Terminal and lead-through data for the power cables	
Terminal and lead-through data for the control cables	
Electric power network specification	371
Motor connection data	371
Control connection data	373
Clearance and creepage distance	373
Efficiency	
Degrees of protection	
Ambient conditions	
Materials	
Applicable standards	
CE marking	
Compliance with the European EMC Directive	
Compliance with EN 61800-3:2004	376
Definitions	376
Category C2	376
Category C3	377
UL marking	
UL checklist	
C-Tick marking	
•	
RoHS marking	3/8
15. Dimension drawings	
	070
Contents of this chapter	
Frame sizes R0 and R1, IP20 (cabinet installation) / UL open	
Frame sizes R0 and R1, IP20 / NEMA 1	
Frame size R2, IP20 (cabinet installation) / UL open	382
Frame size R2, NEMA 1	383
Frame size R3, IP20 (cabinet installation) / UL open	384
Frame size R3, NEMA 1	385
Frame size R4, IP20 (cabinet installation) / UL open	
Frame size R4, NEMA 1	387
Trumo dizo (14, MENIX)	001
16 Inday	
16. Index	
Further information	
Product and service inquiries	
Product training	
Providing feedback on ABB Drives manuals	. 29







Safety

Contents of this chapter

The chapter contains safety instructions which you must follow when installing, operating and servicing the drive. If ignored, physical injury or death may follow, or damage may occur to the drive, motor or driven equipment. Read the safety instructions before you work on the drive.



Use of warning symbols

Warnings caution you about conditions which can result in serious injury or death and/or damage to the equipment, and advise on how to avoid the danger. The following warning symbols are used in this manual:



WARNING! Danger; electricity warns of hazards from electricity which can cause physical injury and/or damage to the equipment.

WARNING! General danger warns about conditions, other than those caused by electricity, which can result in physical injury and/or damage to the equipment.

Safety in installation and maintenance


These warnings are intended for all who work on the drive, motor cable or motor.

Electrical safety



WARNING! If you ignore the safety instructions, injury or death can occur. If you are not a qualified electrician, do not do electrical work.

- · Only qualified electricians are allowed to install and maintain the drive!
- Never work on the drive, motor cable or motor when input power is applied. After disconnecting the input power, always wait for 5 minutes to let the intermediate circuit capacitors discharge before you start working on the drive, motor or motor cable.
- Always ensure by measuring with a multimeter (impedance at least 1 Mohm) that there is no voltage between the drive input phases U1, V1 and W1 and the ground.
- Do not work on the control cables when power is applied to the drive or to the
 external control circuits. Externally supplied control circuits may carry dangerous
 voltage even when the input power of the drive is switched off.



- Disconnect the internal EMC filter when installing the drive on an IT system (an
 ungrounded power system or a high-resistance-grounded [over 30 ohms] power
 system), otherwise the system is connected to ground potential through the EMC
 filter capacitors. This may cause danger or damage the drive. See page 46. Note:
 When the internal EMC filter is disconnected, the drive is not EMC compatible.
- Disconnect the internal EMC filter when installing the drive on a corner-grounded TN system, otherwise the drive will be damaged. See page 46. Note: When the internal EMC filter is disconnected, the drive is not EMC compatible.
- All ACS320 Drive End Grounding screws are removed at the factory. See Product overview for location details.
- All ELV (extra low voltage) circuits connected to the drive must be used within a
 zone of equipotential bonding, in other words, within a zone where all
 simultaneously accessible conductive parts are electrically connected to prevent
 hazardous voltages appearing between them. This is accomplished by a proper
 factory grounding.

Notes:

- Even when the motor is stopped, dangerous voltage is present at the power circuit terminals U1, V1, W1 and U2, V2, W2.
- For more technical information, contact the factory or your local ABB sales representative.



General safety



WARNING! If you ignore the safety instructions, injury or death can occur. If you are not a qualified electrician, do not do electrical work.

- Never attempt to repair a malfunctioning drive; contact your local ABB representative or Authorized Service Center for service support.
- Make sure that dust from drilling does not enter the drive during the installation.
 Electrically conductive dust inside the drive may cause damage or lead to malfunction.
- · Ensure sufficient cooling.

Safe start-up and operation

These warnings are intended for all who plan the operation, start up or operate the drive.

General safety



WARNING! If you ignore the safety instructions, injury or death can occur. If you are not a qualified electrician, do not do electrical work.



- Before adjusting the drive and putting it into service, make sure that the motor and all driven equipment are suitable for operation throughout the speed range provided by the drive. The drive can be adjusted to operate the motor at speeds above and below the speed provided by connecting the motor directly to the power line.
- Do not activate automatic fault reset functions if dangerous situations can occur.
 When activated, these functions will reset the drive and resume operation after a fault.
- Do not control the drive with an AC contactor or disconnecting device (disconnecting means); use the control panel start and stop keys and or external commands (I/O or fieldbus). The maximum allowed number of charging cycles of the DC capacitors (in other words, power-ups by applying power) is two per minute and the maximum total number of chargings is 15,000.

Notes:

- If an external source for start command is selected and it is ON, the drive will start immediately after an input voltage break or fault reset unless the drive is configured for 3-wire (a pulse) start/stop.
- When the control location is not set to local (LOC not shown on the display), the stop key on the control panel will not stop the drive. To stop the drive using the control panel, first press the LOC/REM key and then the stop key .





Introduction to the manual

Contents of this chapter

The chapter describes applicability, target audience and purpose of this manual. It describes the contents of this manual and refers to a list of related manuals for more information. The chapter also contains a flowchart of steps for checking the delivery, installing and commissioning the drive. The flowchart refers to chapters/sections in this manual

Applicability

The manual is applicable to the ACS320 drive firmware version 4.03c or later. See parameter 3301 FIRMWARE on page 200.

Target audience

The reader is expected to know the fundamentals of electricity, wiring, electrical components and electrical schematic symbols.

The manual is written for readers worldwide. Both SI and imperial units are shown. Special US instructions for installations in the United States are given.

Purpose of the manual

This manual provides information needed for planning the installation, installing, commissioning, using and servicing the drive.

Contents of this manual

The manual consists of the following chapters:

- Safety (page 15) gives safety instructions you must follow when installing. commissioning, operating and servicing the drive.
- Introduction to the manual (this chapter, page 19) describes applicability, target audience, purpose and contents of this manual. It also contains a guick installation and commissioning flowchart.
- Operation principle and hardware description (page 23) describes the operation principle, layout, power connections and control interfaces, type designation label and type designation information in short.
- Mechanical installation (page 29) tells how to check the installation site, unpack, check the delivery and install the drive mechanically.
- Planning the electrical installation (page 35) tells how to check the compatibility of the motor and the drive and select cables, protections and cable routing.
- Electrical installation (page 45) tells how to check the insulation of the assembly and the compatibility with IT (ungrounded) and corner grounded TN systems as well as connect power cables, control cables and embedded fieldbus.
- Installation checklist (page 55) contains a checklist for checking the mechanical and electrical installation of the drive.
- Start-up (page 57) tells how to start up the drive as well as how to start, stop, change the direction of the motor rotation and adjust the motor speed through the I/O interface. In addition, the chapter gives a brief description of each application macro together with a wiring diagram showing the default control connections. It also explains how to save a user macro and how to recall it.
- Program features (page 93) describes program features with lists of related user settings, actual signals, and fault and alarm messages.
- Actual signals and parameters (page 133) describes actual signals and parameters. It also lists the default values for the different macros.
- Fieldbus control (page 267) tells how the drive can be controlled by external devices over a communication network using embedded fieldbus
- Fault tracing (page 339) tells how to reset faults and view fault history. It lists all alarm and fault messages including the possible cause and corrective actions.
- Maintenance and hardware diagnostics (page 357) contains preventive maintenance instructions and LED indicator descriptions.
- Technical data (page 363) contains technical specifications of the drive, for example, ratings, sizes and technical requirements as well as provisions for fulfilling the requirements for CE and other marks.
- *Dimension drawings* (page 379) shows dimension drawings of the drive.

Related documents

See List of related manuals on page 2.

Categorization by frame size

The ACS320 drive is manufactured in frame sizes R0...R4. Some instructions and other information which only concern certain frame sizes are marked with the symbol of the frame size (R0...R4). To identify the frame size of your drive, see the table in section Ratings, types and voltages (for North American market) on page 364 or in section Ratings, types and voltages (for European market) on page 365.

Quick installation and commissioning flowchart

Task	See	
Identify the frame size of your drive: R0R4.	Operation principle and hardware description: Type designation key on page 27 Technical data: Ratings, types and voltages (for North American market) on page 364 or in section Ratings, types and voltages (for European market) on page 365	
<u> </u>	7	
Plan the installation: select the cables, etc.	Planning the electrical installation on page 35	
Check the ambient conditions, ratings and required cooling air flow.	Technical data on page 363	
Linearity and absolution drives	Manhanian installation. Observing the delicer.	
Unpack and check the drive.	Mechanical installation: Checking the delivery on page 31	
V	1	
If the drive will be connected to an IT (ungrounded) or corner grounded system, check that the internal EMC filter is not connected.	Operation principle and hardware description: Type designation key on page 27 Electrical installation: Checking the compatibility with IT (ungrounded) and corner grounded TN systems on page 46	
<u> </u>	_	
Install the drive on a wall or in a cabinet.	Mechanical installation on page 29	
•		
Route the cables.	Planning the electrical installation: Routing the cables on page 41	
<u> </u>	_	
Check the insulation of the input cable and the motor and the motor cable.	Electrical installation: Checking the insulation of the assembly on page 45	
<u> </u>	_	
Connect the power cables.	Electrical installation: Connecting the power cables on page 47	
. ★		
Connect the control cables.	Electrical installation: Connecting the control cables on page 49	
<u> </u>	_	
Check the installation.	Installation checklist on page 55	
Commission the drive.	Start-up on page 57	
Commission and announced	Jess. Sp S., page 9,	



Operation principle and hardware description


Contents of this chapter

The chapter briefly describes the operation principle, layout, type designation label and type designation information. It also shows a general diagram of power connections and control interfaces.

Operation principle

The ACS320 is a wall or cabinet mountable drive for controlling AC motors.


The figure below shows the simplified main circuit diagram of the drive. The rectifier converts three-phase AC voltage to DC voltage. The capacitor bank of the intermediate circuit stabilizes the DC voltage. The inverter converts the DC voltage back to AC voltage for the AC motor.



Product overview

Layout

The layout of the drive is presented below. The figure shows a frame size R2 drive. The construction of the different frame sizes R0...R4 varies to some extent.




1	Cooling outlet through top cover			
	Mounting holes			
3	Panel cover (a) / Basic control panel (b) / Assistant control panel (c)			
	Terminal cover			
5	Panel connection			
6	Option connection			
	FlashDrop connection			
8	Power OK and Fault LEDs. See section LEDs on page 361.			

9	EMC filter grounding screw (EMC). Note: The screw is on the front in frame size R4.
10	Varistor grounding screw (VAR)
11	RS-485 connection
12	Jumper J701 for connecting RS-485 termination resistor
13	I/O connections
	Switch S1 for selecting voltage or current for analog inputs
15	Input power connection (U1, V1, W1) and motor connection (U2, V2, W2). (Braking chopper connection is disabled.)
16	I/O clamping plate

17 Clamping plate18 Clamps

Power connections and control interfaces

The diagram gives an overview of connections. I/O connections are parameterable.




See Application macros on page 77 for I/O connections for the different macros and chapter *Electrical installation* on page 45 for installation in general.

Type designation label

markings)


The type designation label is attached to the left side of the drive. An example label and explanation of the label contents are shown below.



1	Type designation, see section <i>Type designation key</i> on page 27				
2	Degree of protection by enclosure (IP and UL/NEMA)				
3	Nominal ratings, see section Ratings, types and voltages (for North American market) on page 364 or Ratings, types and voltages (for European market) on page 365.				
4	Serial number of format MYYWWRXXXX, where				
	M:	Manufacturer			
	YY:	09, 10, 11, for 2009, 2010, 2011,			
	WW: 01, 02, 03, for week 1, week 2, week 3,				
	R: A, B, C, for product revision number				
	XXXX:	Integer starting every week from 0001			
5	ABB MRP code of the drive				
6	CE marking and C-Tick, C-UL US and RoHS marks (the label of your drive shows the valid				

Type designation key

The type designation contains information on the specifications and configuration of the drive. You find the type designation on the type designation label attached to the drive. The first digits from the left express the basic configuration, for example ACS320-03U-09A7-4. The optional selections are given after that, separated by + signs, for example +J404. The explanations of the type designation selections are described below.



1) The ACS320 is compatible with panels that have the following panel revisions and panel firmware versions.

Panel type	Type code	Panel revision	Panel firmware version
Basic control panel 2)	ACS-CP-C	M or later	1.13 or later
Assistant control panel	ACH-CP-B	X or later	2.04 or later

2) Available for North American market only.



Mechanical installation

Contents of this chapter

The chapter tells how to check the installation site, unpack, check the delivery and install the drive mechanically.

Checking the installation site

The drive may be installed on the wall or in a cabinet. Check the enclosure requirements for the need to use the NEMA 1 option in wall installations (see chapter Technical data on page 363.

The drive can be installed in three different ways, depending on the frame size:

- a) back mounting (all frame sizes)
- b) side mounting (frame sizes R0...R2)
- c) DIN rail mounting (all frame sizes).

The drive must be installed in an upright position.

Check the installation site according to the requirements below. Refer to chapter Dimension drawings on page 379 for frame details.

Requirements for the installation site

Operation conditions

See chapter Technical data on page 363 for the allowed operation conditions of the drive

Wall

The wall should be as close to vertical and even as possible, of non-flammable material and strong enough to carry the weight of the drive.



Floor

The floor/material below the installation should be non-flammable.

Free space around the drive

The required free space for cooling above and below the drive is 75 mm (3 in). No free space is required on the sides of the drive, so drives can be installed side by side.

Required tools

To install the drive, you need the following tools:


- screwdrivers (as appropriate for the mounting hardware used)
- wire stripper
- · tape measure
- drill (if the drive will be installed with screws/bolts)
- mounting hardware: screws or bolts (if the drive will be installed with screws/bolts). For the number of screws/bolts, see With screws on page 32.



Unpacking

The drive (1) is delivered in a package that also contains the following items (frame size R2 shown in the figure):

- plastic bag (2) including clamping plate (also used for I/O cables in frame sizes R3 and R4), I/O clamping plate (for frame sizes R0...R2), clamps and screws
- panel cover (3)
- mounting template, integrated into the package (4)
- user's manual (5)
- possible options.





Checking the delivery

Check that there are no signs of damage. Notify the shipper immediately if damaged components are found.

Before attempting installation and operation, check the information on the type designation label of the drive to verify that the drive is of the correct type. See section Type designation label on page 26.

Installing

The instructions in this manual cover drives with the IP20 degree of protection. To comply with NEMA 1, use the MUL-R1, MUL-R3 or MUL-R4 option kit, which is delivered with multilingual installation instructions (3AFE68642868, 3AFE68643147 or 3AUA0000025916, respectively).

Install the drive

Install the drive with screws or on a DIN rail as appropriate.

Note: Make sure that dust from drilling does not enter the drive during the installation.


With screws

1. Mark the hole locations using for example the mounting template cut out from the package.

The locations of the holes are also shown in the drawings in chapter *Dimension* drawings on page 379. The number and location of the holes used depend on how the drive is installed:

- a) back mounting (frame sizes R0...R4): four holes
- b) side mounting (frame sizes R0...R2): three holes; one of the bottom holes is located in the clamping plate.
- 2. Fix the screws or bolts to the marked locations.












- 3. Position the drive onto the screws on the wall.
- 4. Tighten the screws in the wall securely.






On DIN rail

- Click the drive to the rail.
- To detach the drive, press the release lever on top of the drive (1b).









Fasten clamping plates

- 1. Fasten the clamping plate to the plate at the bottom of the drive with the provided screws.
- 2. For frame sizes R0...R2, fasten the I/O clamping plate to the clamping plate with the provided screws.







Planning the electrical installation

Contents of this chapter

The chapter contains the instructions that you must follow when checking the compatibility of the motor and drive, and selecting cables, protections, cable routing and way of operation for the drive.

Note: The installation must always be designed and made according to applicable local laws and regulations. ABB does not assume any liability whatsoever for any installation which breaches the local laws and/or other regulations. Furthermore, if the recommendations given by ABB are not followed, the drive may experience problems that the warranty does not cover.

Implementing the AC power line connection

See the requirements in section *Electric power network specification* on page 371. Use a fixed connection to the AC power line.



WARNING! As the leakage current of the device typically exceeds 3.5 mA, a fixed installation is required according to IEC 61800-5-1.

Selecting the supply disconnecting device (disconnecting means)

Install a hand-operated supply disconnecting device (disconnecting means) between the AC power source and the drive. The disconnecting device must be of a type that can be locked to the open position for installation and maintenance work.

European union

To meet the European Union Directives, according to standard EN 60204-1, Safety of Machinery, the disconnecting device must be one of the following types:

- a switch-disconnector of utilization category AC-23B (EN 60947-3)
- a disconnector having an auxiliary contact that in all cases causes switching devices to break the load circuit before the opening of the main contacts of the disconnector (EN 60947-3)
- a circuit breaker suitable for isolation in accordance with FN 60947-2.

North America

The ACS320 drive does not include a disconnect device. A means to disconnect input power must be installed between the AC power source and the ACS320 drive. This branch circuit protection must:

- be sized to conform to applicable safety regulations, including but not limited to, both National and local electrical codes.
- be locked in an open position during installation and maintenance work.

The disconnect device must not be used to control the motor. Instead use the control panel, or commands to the I/O terminals for motor control.

Other regions

The disconnecting device must conform to the applicable safety regulations.

Checking the compatibility of the motor and drive

Check that the 3-phase AC induction motor and the drive are compatible according to the rating table in section Ratings, types and voltages (for North American market) on page 364 or in section Ratings, types and voltages (for European market) on page 365. The table lists the typical motor power for each drive type.

Selecting the power cables

General rules

Dimension the input power and motor cables according to local regulations.

- The input power and the motor cables must be able to carry the corresponding load currents. See section Ratings, types and voltages (for North American market) on page 364 or in section Ratings, types and voltages (for European market) on page 365 for the rated currents.
- The cable must be rated for at least 70 °C maximum permissible temperature of the conductor in continuous use. For US, see section Additional North American requirements on page 39.
- The conductivity of the PE conductor must be equal to that of the phase conductor (same cross-sectional area).
- 600 V AC cable is accepted for up to 500 V AC.
- Refer to chapter *Technical data* on page 363 for the EMC requirements.

A symmetrical shielded motor cable (see the figure below) must be used to meet the EMC requirements of the CE and C-Tick marks.

A four-conductor system is allowed for input cabling, but a shielded symmetrical cable is recommended.

Compared to a four-conductor system, the use of a symmetrical shielded cable reduces electromagnetic emission of the whole drive system as well as motor bearing currents and wear.

Alternative power cable types

Power cable types that can be used with the drive are presented below.

Motor cables

(recommended for input cables also)

Symmetrical shielded cable: three phase conductors, a concentric or otherwise symmetrically constructed PE conductor and a shield


Note: A separate PE conductor is required if the conductivity of the cable shield is not sufficient for the purpose.





Allowed as input cables


A four-conductor system: three phase conductors and a protective conductor



Motor cable shield

To function as a protective conductor, the shield must have the same cross-sectional area as the phase conductors when they are made of the same metal.

To effectively suppress radiated and conducted radio-frequency emissions, the shield conductivity must be at least 1/10 of the phase conductor conductivity. The requirements are easily met with a copper or aluminium shield. The minimum requirement of the motor cable shield of the drive is shown below. It consists of a concentric layer of copper wires. The better and tighter the shield, the lower the emission level and bearing currents.



Additional North American requirements

Type MC continuous corrugated aluminium armor cable with symmetrical grounds or shielded power cable is recommended for the motor cables if metallic conduit is not used

The power cables must be rated for 75 °C (167 °F).

Conduit

Where conduits must be coupled together, bridge the joint with a ground conductor bonded to the conduit on each side of the joint. Bond the conduits also to the drive enclosure. Use separate conduits for input power, motor and control wiring. Do not run motor wiring from more than one drive in the same conduit.

Armored cable / shielded power cable

Six-conductor (three phases and three ground) type MC continuous corrugated aluminium armor cable with symmetrical grounds is available from the following suppliers (trade names in parentheses):

- Anixter Wire & Cable (Philsheath)
- BICC General Corp (Philsheath)
- Rockbestos Co. (Gardex)
- Oaknite (CLX).

Shielded power cable is available from the following suppliers:

- Belden
- LAPPKABEL (ÖLFLEX)
- · Pirelli.


Selecting the control cables

General rules

All analog control cables and the cable used for the frequency input must be shielded.

Use a double-shielded twisted pair cable (figure a, for example JAMAK by Draka NK Cables) for analog signals. Employ one individually shielded pair for each signal. Do not use common return for different analog signals.

A double-shielded cable is the best alternative for low-voltage digital signals, but a single-shielded or unshielded twisted multipair cable (figure b) is also usable. However, for frequency input, always use a shielded cable.



Run analog and digital signals in separate cables.

Relay-controlled signals, providing their voltage does not exceed 48 V, can be run in the same cables as digital input signals. It is recommended that the relay-controlled signals are run as twisted pairs.

Never mix 24 V DC and 115/230 V AC signals in the same cable.

Relay cable

The cable type with braided metallic screen (for example OLFLEX by LAPPKABEL) has been tested and approved by ABB.

Control panel cable

In remote use, the cable connecting the control panel to the drive must not exceed 3 m (10 ft). The cable type tested and approved by ABB is used in control panel option kits.


Routing the cables

Route the motor cable away from other cable routes. Motor cables of several drives can be run in parallel installed next to each other. It is recommended that the motor cable, input power cable and control cables are installed on separate travs. Avoid long parallel runs of motor cables with other cables to decrease electromagnetic interference caused by the rapid changes in the drive output voltage.


Where control cables must cross power cables make sure that they are arranged at an angle as near to 90 degrees as possible.

The cable trays must have good electrical bonding to each other and to the grounding electrodes. Aluminium tray systems can be used to improve local equalizing of potential.

A diagram of the cable routing is shown below.



Control cable ducts



Protecting the drive, input power cable, motor and motor cable in short circuit situations and against thermal overload

Protecting the drive and input power cable in short-circuit situations

Arrange the protection according to the following guidelines.

Circuit diagram			Short-circuit protection
Distribution board	Input cable	Drive	Protect the drive and input cable with fuses or ABB
1)	 	# M 3~	manual motor starter.

Size the fuses according to instructions given in chapter Technical data on page 363. The fuses will protect the input cable in short-circuit situations, restrict drive damage and prevent damage to adjoining equipment in case of a short-circuit inside the drive.

Protecting the motor and motor cable in short-circuit situations

The drive protects the motor and motor cable in a short-circuit situation when the motor cable is dimensioned according to the nominal current of the drive. No additional protection devices are needed.

Protecting the drive, motor cable and input power cable against thermal overload

The drive protects itself and the input and motor cables against thermal overload when the cables are dimensioned according to the nominal current of the drive. No additional thermal protection devices are needed.

WARNING! If the drive is connected to multiple motors, a separate thermal overload switch or a circuit breaker must be used for protecting each cable and motor. These devices may require a separate fuse to cut off the short-circuit current.

Protecting the motor against thermal overload

According to regulations, the motor must be protected against thermal overload and the current must be switched off when overload is detected. The drive includes a motor thermal protection function that protects the motor and switches off the current when necessary. It is also possible to connect a motor temperature measurement to the drive. The user can tune both the thermal model and the temperature measurement function further by parameters.

The most common temperature sensors are:

- motor sizes IEC180...225: thermal switch (for example Klixon)
- motor sizes IEC200...250 and larger: PTC or Pt100.

For more information on the thermal model, see section *Motor thermal protection* on page 112. For more information on the temperature measurement function see section Motor temperature measurement through the standard I/O on page 121.

Using residual current devices (RCD) with the drive

ACS320-03x drives are suitable to be used with residual current devices of Type B. Other measures for protection in case of direct or indirect contact, such as separation from the environment by double or reinforced insulation or isolation from the supply system by a transformer, can also be applied.

Implementing a bypass connection

WARNING! Never connect the supply power to the drive output terminals U2, V2 and W2. Power line voltage applied to the output can result in permanent damage to the drive.


If frequent bypassing is required, employ mechanically connected switches or contactors to ensure that the motor terminals are not connected to the AC power line and drive output terminals simultaneously.

Protecting the contacts of relay outputs

Inductive loads (relays, contactors, motors) cause voltage transients when switched off.

Equip inductive loads with noise attenuating circuits (varistors, RC filters [AC] or diodes [DC]) in order to minimize the EMC emission at switch-off. If not suppressed, the disturbances may connect capacitively or inductively to other conductors in the control cable and form a risk of malfunction in other parts of the system.

Install the protective component as close to the inductive load as possible. Do not install protective components at the I/O terminal block.





Electrical installation

Contents of this chapter

The chapter tells how to check the insulation of the assembly and the compatibility with IT (ungrounded) and corner grounded TN systems as well as connect power cables, control cables and embedded fieldbus.

WARNING! Obey the safety instructions. See chapter Safety on page 15. If $\stackrel{\prime\prime}{\sim}$ you ignore the safety instructions, injury or death can occur. If you are not a qualified electrician, do not do electrical work.

Make sure that the drive is disconnected from the input power during installation. If the drive is already connected to the input power, wait for 5 minutes after disconnecting the input power.

Checking the insulation of the assembly



Do not make any voltage tolerance or insulation resistance tests (for example hi-pot or megger) on any part of the drive as testing can damage the drive. Every drive has been tested for insulation between the main circuit and the chassis at the factory. Also, there are voltage-limiting circuits inside the drive which cut down the testing voltage automatically.

Input power cable


Check the insulation of the input power cable according to local regulations before connecting to the drive.



Motor and motor cable

Check the insulation of the motor and motor cable as follows:

- 1. Check that the motor cable is connected to the motor and disconnected from the drive output terminals U2, V2 and W2.
- 2. Measure the insulation resistance between each phase conductor and the Protective Earth (PE) conductor using a measuring voltage of 500 V DC. The insulation resistance of an ABB motor must exceed 10 Mohm (reference value at 25 °C or 77 °F). For the insulation resistance of other motors, please consult the manufacturer's instructions.




Note: Moisture inside the motor casing will reduce the insulation resistance. If moisture is suspected, dry the motor and repeat the measurement.

Checking the compatibility with IT (ungrounded) and corner grounded TN systems

WARNING! If a drive whose EMC filter is not disconnected is installed on an IT system (an ungrounded power system or a high resistance-grounded [over 30 ohms] power system), the system will be connected to ground potential through the EMC filter capacitors of the drive. This may cause danger or damage the drive. If a drive whose EMC filter is not disconnected is installed on a corner grounded TN system, the drive will be damaged.

1. If you have an IT (ungrounded) or corner grounded TN system, disconnect the internal EMC filter by removing the EMC screw. For 3-phase U-type drives (with type designation ACS320-03U-), the EMC screw is already removed at the factory and replaced by a plastic one.




Note: In frame size R4 the EMC screw is located to the right of terminal W2.



Connecting the power cables

Connection diagram



- 1. Ground the other end of the PE conductor at the distribution board.
- 2. Use a separate grounding cable if the conductivity of the cable shield is insufficient (smaller than the conductivity of the phase conductor) and there is no symmetrically constructed grounding conductor in the cable. See section Selecting the power cables on page 37.
- 3. L and N are connection markings for the 1-phase power supply.


Notes:

- Do not use an asymmetrically constructed motor cable.
- If there is a symmetrically constructed grounding conductor in the motor cable in addition to the conductive shield, connect the grounding conductor to the grounding terminal at the drive and motor ends.
- Route the motor cable, input power cable and control cables separately. For more information, see section Routing the cables on page 41.

Grounding of the motor cable shield at the motor end


For minimum radio frequency interference:


- ground the cable by twisting the shield as follows: flattened width > 1/5 · length
- or ground the cable shield 360 degrees at the lead-through of the motor terminal box.






- 1. Fasten the grounding conductor (PE) of the input power cable under the grounding clamp. Connect the phase conductors to the U1, V1 and W1 terminals.
- grounding clamp. Connect the phase conductors to the U1, V1 and W1 terminals Use a tightening torque of 0.8 N·m (7 in-lb) for frame sizes R0…R2, 1.7 N·m (15 in-lb) for R3, and 2.5 N·m (22 in-lb) for R4.
- Strip the motor cable and twist the shield to form as short a pigtail as possible.
 Fasten the twisted shield under the grounding clamp. Connect the phase conductors to the U2, V2 and W2 terminals. Use a tightening torque of 0.8 N·m (7 in-lb) for frame sizes R0...R2, 1.7 N·m (15 in-lb) for R3, and 2.5 N·m (22 in-lb) for R4.
- 3. Secure the cables outside the drive mechanically.










Connecting the control cables

I/O terminals

The figure below shows the I/O terminals. Tightening torque is 0.4 N·m / 3.5 in-lb.




WARNING! All ELV (Extra Low Voltage) circuits connected to the drive must be used within a zone of equipotential bonding, in other words, within a zone where all simultaneously accessible conductive parts are electrically connected to prevent hazardous voltages appearing between them. This is accomplished by a proper factory grounding.

The terminals on the control board as well as on the optional modules attachable to the board fulfill the Protective Extra Low Voltage (PELV) requirements stated in EN 50178, provided that the external circuits connected to the terminals also fulfill the requirements and the installation site is below 2000 m (6562 ft).



Voltage and current selection for analog inputs


Switch S1 selects voltage (0 [2]...10 V / -10...10 V) or current (0 [4]...20 mA / -20...20 mA) as the signal types for analog inputs Al1 and Al2. The factory settings are unipolar voltage for AI1 (0 [2]...10 V) and unipolar current for AI2 (0 [4]...20 mA). which correspond to the default usage in the application macros. The switch is located to the left of I/O terminal 9 (see the I/O terminal figure above).



Permanently affix control cables with a minimum 1/4" spacing from power cables.


Voltage and current connection for analog inputs

Bipolar voltage (-10...10 V) and current (-20...20 mA) are also possible. If a bipolar connection is used instead of a unipolar one, see section *Programmable analog inputs* on page *101* for how to set parameters accordingly.



PNP and NPN configuration for digital inputs


You can wire the digital input terminals in either a PNP or NPN configuration.





External power supply for digital inputs

For using an external +24 V supply for the digital inputs, see the figure below.




Frequency input

If DI5 is used as a frequency input, see section *Frequency input* on page 105 for how to set parameters accordingly.

Connection example of a two-wire sensor

HVAC default, supply fan, return fan, cooling tower fan, condenser, booster pumps, PFA control, internal timer, dual setpoint with PID, E-Clipse and dual setpoint with PID and constant speeds macros (see section Application macros on page 77) use analog input 2 (Al2). The macro wiring diagrams for these macros show the connection when a separately powered sensor is used. The figure below gives an example of a connection using a two-wire sensor.



Note: The sensor is supplied through its current output. Thus the output signal must be 4...20 mA.




Default I/O connection diagram

The default connection of the control signals depends on the application macro in use, which is selected with parameter 9902 APPLIC MACRO.

The default macro is the HVAC Default. It provides a general purpose I/O configuration with three constant speeds. Parameter values are the default values given in section Parameters in the short parameter view on page 134. For information on other macros, see section *Application macros* on page 77.

The default I/O connections for the ABB standard macro are given in the figure below.



1) See parameter *Group 12: Constant speeds*:


DI3	Operation (parameter)
0	Set speed through AI1
1	Speed 1 (1202)
0	Speed 2 (1203)
1	Speed 3 (1204)


2)360 degree grounding under a clamp.


Tightening torque: 0.4 N·m (3.5 lbf·in).

Connection procedure


- 1. Remove the terminal cover by simultaneously pushing the recess and sliding the cover off the frame.
- 2. Digital signals: Strip the outer insulation of the digital signal cable 360 degrees and ground the bare shield under the clamp.
- 3. Connect the conductors of the cable to the appropriate terminals. Use a tightening torque of 0.4 N·m (3.5 in-lb).
- 4. For double-shielded cables, twist also the grounding conductors of each pair in the cable together and connect the bundle to the SCR terminal (terminal 1).









- 5. Analog signals: Strip the outer insulation of the analog signal cable 360 degrees and ground the bare shield under the clamp.
- 6. Connect the conductors to the appropriate terminals. Use a tightening torque of 0.4 N·m (3.5 in-lb).
- 7. Twist the grounding conductors of each pair in the analog signal cable together and connect the bundle to the SCR terminal (terminal 1).
- 8. Secure all cables outside the drive mechanically.
- 9. Slide the terminal cover back in place.










Embedded fieldbus can be connected to the drive with RS-485 or RS-232.


Connection diagram

RS-485

The figure below shows the fieldbus connection.




Terminate the RS-485 bus with a 120 ohm resistor at the end of the network by setting the jumper J701 shunts as in the figure below.





RS-232

Plug a communication cable into the control panel connection X2. The cable must be shorter than 3 meters.





Installation checklist

Contents of this chapter

This chapter contains the task list to be followed after the mechanical and electrical installation before proceeding to starting up the drive.

Checking the installation

Check the mechanical and electrical installation of the drive before start-up. Go through the checklist below together with another person. Read chapter Safety on page 15 of this manual before you work on the drive.

	Check				
ME	MECHANICAL INSTALLATION				
	The ambient operating conditions are allowed. (See <i>Mechanical installation: Checking the installation site</i> on page 29 as well as <i>Technical data: Losses, cooling data and noise</i> on page 369 and <i>Ambient conditions</i> on page 374.)				
	The drive is fixed properly on an even vertical non-flammable wall. (See <i>Mechanical installation</i> on page 29.)				
	The cooling air will flow freely. (See <i>Mechanical installation: Free space around the drive</i> on page 30.)				
	The motor and the driven equipment are ready for start. (See <i>Planning the electrical installation</i> : Checking the compatibility of the motor and drive on page 36 as well as <i>Technical data: Motor connection data</i> on page 371.)				
	ECTRICAL INSTALLATION (See Planning the electrical installation on page 35 and ctrical installation on page 45.)				
	For ungrounded and corner grounded systems: The internal EMC filter is disconnected (EMC screw removed).				
	The capacitors are reformed if the drive has been stored over a year.				
	The drive is grounded properly.				
	The input power voltage matches the drive nominal input voltage.				

Check
The input power connections at U1, V1 and W1 are OK and tightened with the correct torque.
Appropriate input power fuses and disconnector are installed.
The motor connections at U2, V2 and W2 are OK and tightened with the correct torque.
The motor cable, input power cable and control cables are routed separately.
Use wire ties to permanently affix control/communications wiring to the clamps provided to maintain a minimum 1/4" spacing from power wiring.
The external control (I/O) connections are OK.
The input power voltage cannot be applied to the output of the drive (with a bypass connection).
Terminal cover and, for NEMA 1, hood and connection box, are in place.



Start-up

Contents of this chapter

This chapter contains a brief description of the assistant (HVAC) control panel (operator keypad), start-up assistant and application selection.

This chapter also includes the application macros used for defining a group of parameters. Macros change a group of parameters to new, predefined values. Use macros to minimize the need for manual editing of parameters.

HVAC control panel features

The ACS320 HVAC control panel (ACS-CP-B) features:



1	Status LED (Green when normal, if flashing or
	red, see section <i>LEDs</i> on page 361.)
2	Soft key 1
3	Auto
4	Off
5	Up
6	Down
7	Soft key 2
8	Help (always available)
9	Hand



- · Language selection for the display
- Drive connection that can be made or detached at any time
- Start-up assistant to facilitate drive commissioning
- Copy function for moving parameters to other ACS320 drives
- Backup function for saving parameter sets
- Context sensitive help
- Real-time clock

General display features

Soft key functions

The soft key functions are defined by text displayed just above each key.

Display contrast


To adjust display contrast, simultaneously press and or , as appropriate.

Macros

Note: Selecting the appropriate macro should be part of the original system design, since the control wiring installed depends on the macro used.

- Review the macro descriptions in section Application macros on page 77. Use the macro that best fits system needs.
- Edit parameter 9902 APPLIC MACRO to select the appropriate macro. Use either of the following:
 - Use the Start-up assistant, which displays the macro selection immediately after motor parameter setup.
 - Refer to section Parameters mode on page 64 for parameter editing instructions.

Turning - parameters



The system can benefit from one or more of the ACS320 special features, and/or fine tuning.

- Review the parameter descriptions in section *Parameter listing* starting on page 137. Enable options and fine tune parameter values as appropriate for the system.
- 2. Edit parameters as appropriate.

Fault and alarm adjustments

The drive can detect a wide variety of potential system problems. For example, initial system operation may generate faults of alarms that indicate set-up problems.


- 1. Faults and alarms are reported on the control panel with a number. Note the number reported.
- 2. Review the description provided for the reported fault/alarm:
 - Use the fault and alarm listings shown in chapter Fault tracing on 339.
 - Press the help key (Assistant control panel only) while fault or alarm is displayed.
- 3. Adjust the system or parameters as appropriate.



Start-up

Start-up can be performed in two ways:

· Using the Start-up assistant.



See section Start-up by using the Start-up assistant.

Changing the parameters individually.
 See section Start-up by changing the parameters individually.

Start-up by using the Start-up assistant

To start the Start-up assistant, follow these steps:

1	Select MENU to enter the main menu		0.0 % SP 0.0 A 0.0 MA
2	Select ASSISTANTS with the Up/Down buttons and select ENTER.		PARAMETERS ASSISTANTS CHANGED PAR EXIT ENTER
3	Scroll to Commission drive with the Up/Down buttons.	A	OFF CASSISTANTS—2 Spin the motor Commission drive References 1 & 2 Start/Stop Control Protections EXIT SEL
4	Change the values suggested by the assistant to your preferences and then press SAVE after every change.		9901 LANGUAGE ENGLISH [0] EXIT SAVE

The Start-up assistant will guide you through the start-up.



Start-up by changing the parameters individually

To change the parameters, follow these steps:

1	Select MENU to enter the main menu.		0.0 % SP 0.0 A 0.0 MA
2	Select PARAMETERS with the UP/DOWN buttons and select ENTER to select the Parameters mode.		PARAMETERS ASSISTANTS CHANGED PAR EXIT ENTER
3	Select the appropriate parameter group with the UP/DOWN buttons and select SEL		OFF PAR GROUPS—99 99 START-UP DATA 01 OPERATING DATA 03 FB ACTUAL SIGNALS 04 FAULT HISTORY 10 START/STOP/DIR EXIT SEL
4	Select the appropriate parameter with the UP/DOWN buttons. Select EDIT to change the parameter value.		OFF PARAMETERS—9901 LANGUAGE 9902 APPLIC MACRO HVAC DEFAULT 9905 MOTOR NOM VOLT 9906 MOTOR NOM CURR EXIT
5	Press the UP/DOWN buttons to change the parameter value.	The state of the s	9902 APPLIC MACRO HVAC DEFAULT [1] CANCEL SAVE
6	Select SAVE to store the modified value or select CANCEL to leave the set mode. Any modifications not saved are canceled.		9902 APPLIC MACRO SUPPLY FAN [2] CANCEL SAVE
7	Select EXIT to return to the listing of parameter groups, and again to return to the main menu.	7	OFF PARAMETERS 9901 LANGUAGE 9902 APPLIC MACRO SUPPLY FAN 9905 MOTOR NOM VOLT 9906 MOTOR NOM CURR EXIT EDIT

To complete the control connections by manually entering the parameters, see section *Parameters mode* on page *64*.

For detailed hardware description, see the chapter Technical data.



Notes:

- The current parameter value appears below the highlighted parameter.
- To view the default parameter value, press the UP/DOWN buttons simultaneously.
- The most typical and necessary parameters to change belong to *Group 99: Start-up data*, *Group 10: Start/Stop/Dir*, *Group 11: Reference select*, *Group 20: Limits*, *Group 21: Start/Stop*, *Group 22: Accel/Decel*, *Group 30: Fault functions*, *Group 53: EFB protocol* and *Group 98: Options*.
- To restore the default factory settings, select the application macro HVAC default.

Modes

The HVAC control panel has several different modes for configuring, operating and diagnosing the drive. The modes are:

- Standard display mode Shows drive status information and operates the drive.
- Parameters mode Edits parameter values individually.
- Start-up assistant mode Guides the start-up and configuration.
- Changed parameters mode Shows changed parameters.
- Fault logger mode Shows the drive fault history.
- Drive parameter backup mode Stores or uploads the parameters.
- Clock set mode Sets the time and date for the drive.
- I/O settings mode Checks and edits the I/O settings.
- Alarm mode Reporting mode triggered by drive alarms.

Standard display mode

Use the standard display mode to read information on the drive's status and to operate the drive. To reach the standard display mode, press EXIT until the LCD display shows status information as described below.



Top. The top line of the LCD display shows the basic status information of the drive.

- HAND Indicates that the drive control is local, that is, from the control panel.
- AUTO Indicates that the drive control is remote, such as the basic I/O (X1) or fieldbus
- OFF Indicates that the drive control is local and stopped.
- Indicates the drive and motor rotation status as follows:

Control panel display	Significance
Rotating arrow (clockwise or counterclockwise)	 Drive is running and at setpoint Shaft direction is forward or reverse
Rotating dotted arrow blinking	Drive is running but not at setpoint
Stationary dotted arrow	Start command is present, but motor is not running. For example, start enable is missing.

• Upper right - shows the active reference.

Middle. Using *Group 34: Panel display*, the middle of the LCD display can be configured to display:

 One to three parameter values – The default display shows parameters 0103 OUTPUT FREQ in percentages, 0104 CURRENT in amperes and 0120 Al1 in milliamperes.

AUTO ᠒	15.0Hz
30.0	%
3.4	Ã
2.7	
8.8	
00:00	0 MENU

- Use parameters 3401, 3408, and 3415 to select the parameters (from Group 01: Operating data) to display. Entering "parameter" 0100 results in no parameter displayed. For example, if 3401 = 0100 and 3415 = 0100, then only the parameter specified by 3408 appears in the Control panel display.
- You can also scale each parameter in the display, for example, to convert the
 motor speed to a display of conveyor speed. Parameters 3402...3405 scale the
 parameter specified by 3401, parameters 3409...3412 scale the parameter
 specified by 3408, etc.
- A bar meter rather than one of the parameter values.
 - Enable bar graph displays using parameters 3404, 3411 and 3418.



Bottom. The bottom of the LCD display shows:

- Lower corners show the functions currently assigned to the two soft keys.
- Lower middle displays the current time (if configured to show the time).



Operating the drive

AUTO/HAND – The very first time the drive is powered up, it is in the auto control (AUTO) mode, and is controlled from the Control terminal block X1.

To switch to hand control (HAND) and control the drive using the control panel, press and hold the or button.

- Pressing the HAND button switches the drive to hand control while keeping the drive running.
- Pressing the OFF button switches to hand control and stops the drive.

To switch back to auto control (AUTO), press and hold the button.

Hand/Auto/Off – To start the drive press the HAND or AUTO buttons, to stop the drive press the OFF button.

Reference – To modify the reference (only possible if the display in the upper right corner is in reverse video) press the UP or DOWN buttons (the reference changes immediately).

The reference can be modified in the local control mode, and can be parameterized (using *Group 11: Reference select*) to also allow modification in the remote control mode.

Note: The Start/Stop, Shaft direction and Reference functions are only valid in local control (LOC) mode.

Parameters mode

To change the parameters, follow these steps:

,	1	Select MENU to enter the main menu.	0.0 % SP 0.0 A 0.0 MA
	2	Select PARAMETERS with the UP/DOWN buttons, and select ENTER to select the Parameters mode.	OFF CMAIN MENU——1 PARAMETERS ASSISTANTS CHANGED PAR EXIT ENTER
;	3	Select the appropriate parameter group with the UP/DOWN buttons and select SEL	OFF & PAR GROUPS——99 99 START-UP DATA 01 OPERATING DATA 03 FB ACTUAL SIGNALS 04 FAULT HISTORY 10 START/STOP/DIR EXIT SEL



4	Select the appropriate parameter in a group with the UP/DOWN buttons. Select EDIT to change the parameter.		OFF PARAMETERS—9901 LANGUAGE 9902 APPLIC MACRO HVAC DEFAULT 9905 MOTOR NOM VOLT 9906 MOTOR NOM CURR EXIT EDIT
5	Press the UP/DOWN buttons to change the parameter value.	•	9902 APPLIC MACRO HVAC DEFAULT [1] CANCEL SAVE
6	Select SAVE to store the modified value or select CANCEL to leave the set mode. Any modifications not saved are canceled. Each individual parameter setting is valid immediately after pressing SAVE.		9902 APPLIC MACRO SUPPLY FAN [2] CANCEL SAVE
7	Select EXIT to return to the listing of parameter groups, and again to return to the main menu.		9901 LANGUAGE 9902 APPLIC MACRO SUPPLY FAN 9905 MOTOR NOM VOLT 9906 MOTOR NOM CURR EXIT EDIT

To complete the control connections by manually entering the parameters, see section *Parameters mode*.

For detailed hardware description, see chapter *Dimension drawings*.

Notes:

- The current parameter value appears below the highlighted parameter.
- To view the default parameter value, press the UP/DOWN buttons simultaneously.
- The most typical and necessary parameters to change belong to Group 99: Start-up data, Group 10: Start/Stop/Dir, Group 11: Reference select, Group 20: Limits, Group 21: Start/Stop, Group 22: Accel/Decel and Group 30: Fault functions.
- To restore the default factory settings, select the application macro HVAC default.



Start-up assistant mode

To start the Start-up assistant, follow these steps:

1	Select MENU to enter the main menu	0.0 % SP 0.0 A 0.0 MA
2	Select ASSISTANTS with the Up/Down buttons and select ENTER.	PARAMETERS ASSISTANTS CHANGED PAR EXIT ENTER
3	Scroll to Commission drive with the Up/Down buttons and select SEL.	OFF CASSISTANTS—2 Spin the motor Commission drive References 1 & 2 Start/Stop Control Protections EXIT SEL
4	Change the values suggested by the assistant to your preferences and then press SAVE after every change.	OFF PAR EDIT— 9901 LANGUAGE ENGLISH [0] EXIT SAVE

The Start-up assistant will guide you through the start-up.

The Start-up assistant guides you through the basic programming of a new drive. (Familiarize yourself with basic control panel operation and follow the steps outlined above.) At the first start, the drive automatically suggests entering the first task, language select. The assistant also checks the values entered to prevent entries that are out of range.



The Start-up assistant is divided into tasks. You may activate the tasks one after the other, as the Start-up assistant suggests, or independently.

Note: If you want to set the parameters independently, use the Parameters mode.

The order of tasks presented by the Start-up assistant depends on your entries. The following task list is typical.


Task name	Description
Spin the motor	 Prompts for control panel display language selection. Prompts for motor data. Guides user through rotation check.
Commission drive	Prompts for motor data.

Task name	Description	
References 1 & 2	 Prompts for the source of speed references 1 and 2. Prompts for reference limits. Prompts for frequency (or speed) limits. 	
Start/Stop Control	 Prompts for the source for start and stop commands. Prompts for start and stop mode definition. Prompts for acceleration and deceleration times. 	
Protections	 Prompts for current and torque limits. Prompts for the use of Run enable and Start enable signals. Prompts for the use of emergency stop. Prompts for Fault function selection. Prompts for Auto reset functions selection. 	
Constant Speeds	Prompts for the use of constant speeds.Prompts for constant speed values.	
PID control	 Prompts for PID settings. Prompts for the source of process reference. Prompts for reference limits. Prompts for source, limits and units for the process actual value. Defines the use of Sleep function. 	
PID flow	 Prompts for the use of flow calculation. Prompts for units. Prompts for maximum flow. Prompts for transmitter signals. 	
Low Noise Set-up	 Prompts for switching frequency. Prompts for definition of Flux optimization. Prompts for the use of Critical speeds. 	
Panel Display	, , , ,	
Timed Functions	Prompts for the use of Timed functions.	
Outputs	 Prompts for the signals indicated through the relay outputs. Prompts for signals indicated through the analog outputs AO1 and AO2. Sets the minimum, maximum, scaling and inversion values. 	
Serial Communication	Prompts for communication settings.Prompts for control access settings.	



Changed parameters mode

To view (and edit) a listing of all parameters that have been changed from macro default values, follow these steps:



Fault logger mode

Use the Fault logger mode to see drive fault history, fault state details and help for the faults.

- 1. Select FAULT LOGGER in the MAIN MENU.
- 2. Press **ENTER** to see the latest faults (up to 10 faults, maximum).
- 3. Press **DETAIL** to see details for the selected fault.
- Details are available for the three latest faults.
- 4. Press **DIAG** to see the help description for the fault. See chapter *Fault tracing*.

Note: If a power off occurs, only the three latest faults will remain (with details only in the first fault).



Drive parameter backup mode

Use the parameter backup mode to export parameters from one drive to another. The parameters are uploaded from a drive to the control panel and downloaded from the control panel to another drive. Two options are available:

Par backup mode

The Assistant control panel can store a full set of drive parameters.

The Par backup mode has these functions:

• **UPLOAD TO PANEL** – Copies all parameters from the drive to the Control panel. This includes user sets of parameters (if defined) and internal parameters. The Control panel memory is non-volatile and does not depend on the panel's battery. To upload parameters to control panel, follow these steps:

1	Select MENU to enter the main menu.	0.0 % SP 0.0 A 0.0 MA
2	Select PAR BACKUP with the UP/DOWN buttons and select ENTER.	FAULT LOGGER CLOCK SET PAR BACKUP EXIT ENTER
3	Select UPLOAD TO PANEL and select SEL.	OFF & PAR BACKUP—— 1 UPLOAD TO PANEL BACKUP INFO DOWNLOAD FULL SET DOWNLOAD APPLICATION EXIT SEL
4	The "Copying parameters" text and a progress diagram is displayed. Select ABORT if you want to stop the process.	OFF PAR BACKUP————————————————————————————————————
5	The "Parameter upload successful" text is displayed and the control panel returns to the PAR BACKUP menu. Select EXIT to return to the main menu. Now you can disconnect the panel.	OFF & MESSAGE — Parameter upload successful OK



DOWNLOAD FULL SET – Restores the full parameter set from the Control panel to the drive. Use this option to restore a drive, or to configure identical drives. This download does not include user sets of parameters.

To describe the linear restorate the drive follows the restorate transfer.

The described the linear restorate the drive follows the restorate transfer.

The described the linear restorate the drive follows the restorate transfer.

To download all parameters to drive, follow these steps:

1	Select MENU to enter the menu.		0.0 % SP 0.0 A 0.0 MA
2	Select PAR BACKUP with the UP/DOWN buttons.		FAULT LOGGER CLOCK SET PAR BACKUP EXIT ENTER
3	Scroll to DOWNLOAD FULL SET and select SEL.		OFF PAR BACKUP—— 3 UPLOAD TO PANEL BACKUP INFO DOWNLOAD FULL SET DOWNLOAD APPLICATION EXIT SEL
4	The "Downloading parameters" text is displayed. Select ABORT if you want to stop the process.	7	OFF C PAR BACKUP————————————————————————————————————
5	After the download stops, the "Parameter download successfully completed" text is displayed and the control panel goes back to PAR BACKUP menu. Select EXIT to return to the main menu.		OFF & MESSAGE—Parameter download successfully completed OK OFF & PAR BACKUP—3 UPLOAD TO PANEL BACKUP INFO DOWNLOAD FULL SET DOWNLOAD APPLICATION EXIT SEL



Note: Download full set writes all parameters to the drive, including motor parameters. Only use this function to restore a drive, or to transfer parameters to systems that are identical to the original system.

Download application – Copies a partial parameter set from the Control panel to a drive. The partial set does not include internal motor parameters, parameters 9905...9909, 1605, 1607, 5201, nor any Group 53: EFB protocol parameters. Use this option to transfer parameters to systems that use similar configurations – the drive and motor sizes do not need to be the same.

To download application to drive, follow these steps:

_			
1	Select MENU to enter the menu.		0.0 % SP 0.0 A 0.0 MA
2	Select PAR BACKUP with the UP/DOWN buttons.	•	FAULT LOGGER CLOCK SET PAR BACKUP EXIT ENTER
3	Scroll to DOWNLOAD APPLICATION and select SEL.		OFF PAR BACKUP—4 UPLOAD TO PANEL BACKUP INFO DOWNLOAD FULL SET DOWNLOAD APPLICATION EXIT SEL
4	The "Downloading parameters" text is displayed. Select ABORT if you want to stop the process.		OFF PAR BACKUP————————————————————————————————————
5	The "Parameter download successfully completed" is displayed and the control panel returns to PAR BACKUP menu. Select EXIT to return to the main menu.		OFF &MESSAGE—Parameter download successfully completed.
			OFF TO PAR BACKUP—— 4 UPLOAD TO PANEL BACKUP INFO DOWNLOAD FULL SET DOWNLOAD APPLICATION EXIT SEL



Handling inexact downloads

In some situations, an exact copy of the download is not appropriate for the target drive. Some examples:

- A download to an old drive specifies parameters/values that are not available on the old drive.
- A download (from an old drive) to a new drive does not have definitions for the new parameters – parameters that did not originally exist.


As a default, the control panel handles these situations by:


- Discarding parameters/values not available on the target drive.
- Using parameter default values when the download provides no values or invalid values.
- Providing a Differences List A listing of the type and number of items that the target cannot accept exactly as specified.

LOC C DIFFERENCES	
VALUES UNDER MIN	3
VALUES OVER MAX	2
INVALID VALUES	1
EXTRA PARS	5
MISSING VALUES	7
READY	SEL

You can either accept the default edits by pressing READY, or view and edit each item as follows:

1. Highlight an item type in the Differences List (left screen below) and press SEL to see the details for the selected type (right screen below).







In the above-right "details" screen:

- The first item that requires editing is automatically highlighted and includes details: In general, the first item listed in the details is the value defined by the backup file. The second item listed is the "default edit."
- For tracking purposes, an asterisk initially appears by each item. As edits are made, the asterisks disappear.
- In the illustrated example, the backup specifies a switching frequency of 12 kHz, but the target drive is limited to 8 kHz.
- 3. Press EDIT to edit the parameter. The display is the target drive's standard edit screen for the selected parameter.

- 4. Highlight the desired value for the target drive.
- Press SAVE to save setting.
- 6. Press EXIT to step back to the differences view and continue for each remaining exception.
- 7. When your editing is complete, press READY in the Differences List and then select "Yes, save parameters."

Download failures

In some situations, the drive may be unable to accept a download. In those cases, the control panel display is: "Parameter download failed" plus one of the following causes:

- Set not found You are attempting to download a data set that was not defined in the backup. The remedy is to manually define the set, or upload the set from a drive that has the desired set definitions.
- Par lock The remedy is to unlock the parameter set (parameter 1602 PARAMETER LOCK).
- Incompatible drive/model The remedy is to perform backups only between drives of the same type and the same model.
- Too many differences The remedy is to manually define a new set, or upload the set from a drive that more closely resembles the target drive.

Note: If upload or download of parameters is aborted, the partial parameter set is not implemented.

Clock set mode

The clock set mode is used for setting the time and date for the internal clock of the drive. To use the timer functions of the drive, the internal clock has to be set first. Date is used to determine weekdays and is visible in Fault logs.

To set the clock, follow these steps:

1	Select MENU to enter the main menu.	0.0 % SP 0.0 A 0.0 MA
2	Scroll to CLOCK SET with the UP/DOWN buttons and select ENTER to enter the Time & date mode.	ASSISTANTS CHANGED PAR CLOCK SET EXIT ENTER



3	Select CLOCK VISIBILITY with the UP/DOWN buttons and select SEL to change the visibility of the clock.	T	OFF &TIME & DATE —— 1 CLOCK VISIBILITY TIME FORMAT DATE FORMAT SET TIME SET DATE EXIT SEL
4	Scroll to Show clock with the UP/DOWN buttons and select SEL to make the clock visible.		OFF CLOCK VISIB—1 Show clock Hide clock EXIT SEL
5	Scroll to SET TIME with the UP/DOWN buttons and select SEL.	T T	OFF & TIME & DATE — 4 CLOCK VISIBILITY TIME FORMAT DATE FORMAT SET TIME SET DATE EXIT SEL
6	Change the hours and minutes with the UP/DOWN buttons and select OK to save the values. The active value is displayed in inverted color.	T T	OFF SET TIME————————————————————————————————————
7	Scroll to TIME FORMAT with the UP/DOWN buttons and select SEL.	T T	OFF TIME & DATE—2 CLOCK VISIBILITY TIME FORMAT DATE FORMAT SET TIME SET DATE EXIT 00:00 SEL
8	The different formats are displayed. Select a format with the UP/DOWN buttons and select SEL to confirm the selection.	T T	OFF TIME FORMAT—1 24-hour 12-hour CANCEL 00:00 SEL
9	Scroll to SET DATE with the UP/DOWN buttons and select SEL.	T T	OFF TIME & DATE—5 CLOCK VISIBILITY TIME FORMAT DATE FORMAT SET TIME SET DATE EXIT 00:00 SEL



10	Change the days, months and year with the UP/DOWN buttons and select OK to save the values. The active value is displayed in inverted color.	T T	01.01.08 CANCEL 00:00 OK
11	Scroll to DATE FORMAT with the UP/DOWN buttons and select SEL.		OFF & TIME & DATE—3 CLOCK VISIBILITY TIME FORMAT DATE FORMAT SET TIME SET DATE EXIT 00:00 SEL
12	The DATE FORMATS are displayed. Select a date format with the UP/DOWN buttons and select OK to confirm the selection.	T T	OFF ©DATE FORMAT—1 dd.mm.yy mm/dd/yy dd.mm.yyyy mm/dd/yyyy CANCEL 00:00 SEL
13	Select EXIT twice to return to the main menu.		OFF TIME & DATE—3 CLOCK VISIBILITY TIME FORMAT DATE FORMAT SET TIME SET DATE EXIT 00:00 SEL



I/O settings mode

To view and edit the I/O settings, follow these steps:

1	Select MENU to enter the main menu.		0.0 % SP 0.0 A 0.0 MA
2	Scroll to I/O SETTINGS with the UP/DOWN buttons and select ENTER.		OFF CMAIN MENU 1 I/O SETTINGS PARAMETERS ASSISTANTS EXIT ENTER
3	Scroll to the I/O setting you want to view with the UP/DOWN buttons and select SEL.	T T	OFF & I/O SETTINGS—1 DIGITAL INPUTS (DI) ANALOG INPUTS (AI) RELAY OUTPUTS (ROUT) ANALOG OUTPUTS (AOUT) PANEL EXIT SEL
4	Select the setting you want to view with the UP/DOWN buttons and select EDIT.		OFF & I/O SETTINGS— -DI 1- 1001:START/STOP (EI1) 1002:START/STOP (EI1) EXIT EDIT
5	You can change the value with the UP/DOWN buttons and save it by selecting SAVE. If you do not want to change the setting, select CANCEL.		OFF & PAR EDIT————————————————————————————————————
6	Select EXIT to return to the main menu.		OFF & I/O SETTINGS— -DI 1- 1001:START/STOP (EI1) 1002:START/STOP (EI1) —— EXIT EDIT



Application macros

Overview

Macros change a group of parameters to new, predefined values designed for specific applications. Use macros to minimize the need for manual editing of parameters. Selecting a macro sets all other parameters to their default values, except:

- · Group 99: Start-up data
- 1602 PARAMETER LOCK
- 1607 PARAM. SAVE
- 3018 COMM FAULT FUNC and 3019 COMM FAULT TIME
- 9802 COMM PROT SEL
- Group 52: Panel comm and Group 53: EFB protocol
- Group 29: Maintenance trig.

After selecting a macro, additional parameter changes can be made manually using the control panel.


Application macros are enabled by setting the value for parameter 9902 APPLIC MACRO. By default, HVAC default (value 1) is the enabled macro.

General considerations

The following considerations apply for all macros:

- When using a direct speed reference in AUTO mode, connect the speed reference to analog input 1 (AI1), and provide the START command using digital input 1 (DI1). In HAND/OFF mode, the control panel provides the speed reference and START command.
- When using process PID, connect the feedback signal to analog input 2 (Al2). As
 a default, the control panel sets the Setpoint, but analog input 1 can be used as
 an alternate source. You can set up process PID using parameters (Group 40) or
 using the PID control assistant (recommended).

The S1 Jumpers are set for Al1 External Reference and PID Feedback as either 20 ma or 10 V.





Application / Macro listing

This section describes the following macros:

9902 value	Macro	9902 value	Macro
1	HVAC DEFAULT	8	INT TIMER
2	SUPPLY FAN	9	INT TIMER CS
3	RETURN FAN	10	FLOATING PNT
4	CLNG TWR FAN	11	DUAL SETPPID
5	CONDENSER	12	DUAL SP PID WITH CS
6	BOOSTER PUMP	13	E-BYPASS
7	PUMP ALTERNA	14	HAND CONTROL

Selecting an application macro

To select a macro, follow these steps:

1	Select MENU to enter the main menu.	0.0 % SP 0.0 A 0.0 MA
2	Select ASSISTANTS with the Up/Down buttons and select ENTER.	PARAMETERS ASSISTANTS CHANGED PAR EXIT
3	Scroll to Commission drive and select ENTER.	OFF CASSISTANTS—2 Spin the motor Commission drive References 1 & 2 Start/Stop Control Protections EXIT SEL
4	Select a macro with the Up/Down buttons and select SAVE.	9902 APPLIC MACRO HVAC DEFAULT [1] CANCEL SAVE



Restoring defaults


To restore the factory default settings, select application macro HVAC default.

Control wiring

Each macro has specific requirements for control wiring. Specific wiring requirements are included with each macro description.

HVAC default


This macro provides the factory default parameter settings for the drive. Factory defaults can be restored at any time by setting parameter *9902 APPLIC MACRO* to 1. The diagram below shows typical wiring using this macro. When using direct speed reference in AUTO mode or process PID, see section *General considerations* on page *77*.





Supply fan

This macro configures for supply fan applications where the supply fan brings fresh air in according to signals received from a transducer. When using direct speed reference in AUTO mode or process PID, see *General considerations* on page 77.




		Parameter	Value		Parameter	Value
	9902	applic macro	2 (SUPPLYFAN)	3207	superv 3 param	0103 (OUTPUT FREQ)
ì	1401	relay output 1	7 (STARTED)	4001	gain	0.7
	1601	run enable	2 (DI2)	4002	integration time	10.0 s
	1609	start enable 2	5 (DI5)	4101	gain	1.0
	2202	acceler time 1	15.0 s	4102	integration time	60.0 s
	2203	deceler time 1	15.0 s			

Parameters changed relative to HVAC default



Return fan

This macro configures for return fan applications where the return fan removes air according to signals received from a transducer. When using direct speed reference in AUTO mode or process PID, see *General considerations* on page 77.




	Parameters changed relative to HVAC default				
	Parameter	Value		Parameter	Value
9902	applic macro	3 (RETURNFAN)	3207	superv 3 param	0103 (OUTPUT FREQ)
1401	relay output 1	7 (STARTED)	4001	gain	0.7
1601	run enable	2 (DI2)	4002	integration time	10.0 s
1609	start enable 2	5 (DI5)	4101	gain	1.0
2202	acceler time 1	15.0 s	4102	integration time	60.0 s
2203	deceler time 1	15.0 s			



Cooling tower fan

This macro configures for cooling tower fan applications where the fan speed is controlled according to the signals received from a transducer. When using direct speed reference in AUTO mode or process PID, see *General considerations* on page 77.



Parameters changed relative to HVAC default

3207

4101

4102

Parameter

gain

superv 3 param

integration time

Value

0103 (OUTPUT FREQ)

1.0

60.0 s

Value

5 (DI5)

				Щ
\triangle	9902	applic macro	4 (CLNGTWRFAN)	
\ <u>\\</u>	1401	relay output 1	7 (STARTED)	ı
	1601	run enable	2 (DI2)	ı


Parameter

start enable 2

1609

Condenser

This macro configures for condenser and liquid cooler applications where fan speed is controlled according to signals received from a transducer. When using direct speed reference in AUTO mode or process PID, see *General considerations* on page 77.




Parameters changed relative to HVAC default					
Parameter Value				Parameter	Value
9902	applic macro	5 (CONDENSER)	2203	deceler time 1	10.0 s
1401	relay output 1	7 (STARTED)	3207	superv 3 param	0103 (OUTPUT FREQ)
1601	run enable	2 (DI2)	4005	error value inv	1 (YES)
1609	start enable 2	5 (DI5)	4101	gain	1.0
2202	acceler time 1	10.0 s	4102	integration time	60.0 s



Booster pump

This macro configures for booster pump applications where the pump speed is controlled according to a signal received from a transducer. When using direct speed reference in AUTO mode or process PID, see *General considerations* on page 77.



	Parameter	Value		Parameter	Value	ì
9902	applic macro	6 (BOOSTERPUMP)	2203	deceler time 1	5.0 s	ì
1401	relay output 1	7 (STARTED)	3207	superv 3 param	0103 (OUTPUT FREQ)	ı
1601	run enable	2 (DI2)	4001	gain	1.0	ı
1609	start enable 2	5 (DI5)	4002	integration time	60.0 s	ı
2202	acceler time 1	5.0 s				ì

Parameters changed relative to HVAC default




PFA control macro

This macro provides parameter settings for pump and fan alternation (PFA) applications. To enable the macro, set the value of parameter 9902 APPLIC MACRO to 7 (PFA CONTROL).

Note: Parameter 2108 START INHIBIT must remain in the default setting 0 (OFF).

Default I/O connections






Internal timer

This macro configures for applications where a built-in timer starts and stops the motor. When the variable speed pump reaches a maximum speed limit, auxiliary pumps start as needed. When using direct speed reference in AUTO mode or process PID, see section *General considerations* on page 77.

Momentarily activating digital input 3 (DI3) provides a boost function which operates the motor. See *Group 36: Timed functions* for more information on setting up timers.




_/	\
<i>/</i> I	'
	/
•	/

	Parameters changed relative to HVAC default					
	Parameter	Value		Parameter	Value	
9902	applic macro	8 (INT TIMER)	1609	start enable 2	5 (DI5)	
1001	ext1 commands	11 (TIMER1)	3207	superv 3 param	0103 (OUTPUT FREQ)	
1002	ext2 commands	11 (TIMER1)	3601	timers enable	1 (DI1)	
1201	const speed sel	0 (NOT SEL)	3622	boost sel	3 (DI3)	
1401	relay output 1	7 (STARTED)	3626	timer 1 src	23 (B+P3+P2+P1)	
1601	run enable	2 (DI2)				

Internal timer with constant speeds / PRV

This macro configures for applications such as a timed powered roof ventilator (PRV) which alternates between two constant speeds (constant speed 1 and 2) based on a built-in timer.

Momentarily activating digital input 3 (DI3) provides a boost function which operates the motor. See *Group 36: Timed functions* for more information on setting up timers.




	Parameters changed relative to HVAC default					
	Parameter	Value		Parameter	Value	
9902	applic macro	9 (INT TIMER CS)	3416	signal 3 min	-200.0%	
1002	ext2 commands	0 (NOT SEL)	3417	signal 3 max	200.0%	
1103	ref1 sel	0 (KEYPAD)	3419	output 3 dsp unit	4 (%)	
1106	ref3 sel	2 (AI2)	3420	output 3 min	-200.0%	
1201	const speed sel	15 (TIMER1)	3421	output 3 max	200.0%	
1301	minimum ai1	0.0%	3622	boost sel	3 (DI3)	
1401	relay output 1	7 (STARTED)	4001	gain	1.0	
1601	run enable	2 (DI2)	4002	integration time	60.0 s	
1609	start enable 2	5 (DI5)	4101	gain	1.0	
3207	superv 3 param	0103 (OUTPUT FREQ)	4102	integration time	60.0 s	
3415	signal 3 param	0105 (TORQUE)	4110	setpoint sel	1 (AI1)	



Floating point

This application macro is for applications where speed reference needs to be controlled through digital inputs (DI4 & DI5). By activating digital input 4, the speed reference increases, by activating digital input 5, the speed reference decreases. If both digital inputs are active or inactive, the reference does not change.



	Parameter	Value		Parameter	Value	
9902	applic macro	10 (FLOATINGPNT)	3416	signal 3 min	-200.0%	
1103	ref1 sel	7 (DI5U, 6D)	3417	signal 3 max	200.0%	
1401	relay output 1	7 (STARTED)	3419	output 3 dsp unit	4 (%)	
1601	run enable	2 (DI2)	3420	output 3 min	-200.0%	
3207	superv 3 param	0103 (OUTPUT FREQ)	3421	output 3 max	200.0%	

0105 (TORQUE)

Parameters changed relative to HVAC default




3415

signal 3 param

Dual setpoint with PID

This macro configures for dual setpoint PID applications, where activating digital input 3 (DI3) changes the process PID controller's setpoint to another value. When using direct speed reference in AUTO mode or process PID, see section *General considerations* on page 77. Set process PID setpoints (internal to the drive) using parameters 4011 (SET1) and 4111 (SET2).




	Parameters changed relative to HVAC default					
Parameter		Value		Parameter	Value	
9902	applic macro	11 (DUAL SETPNT)	4010	setpoint sel	19 (INTERNAL)	
1201	const speed sel	0 (NOT SEL)	4011	internal setpnt	50.0%	
1401	relay output 1	7 (STARTED)	4027	pid 1 param set	3 (DI3)	
1601	run enable	2 (DI2)	4110	setpoint sel	19 (INTERNAL)	
1609	start enable 2	5 (DI5)	4111	internal setpnt	100.0%	
3207	superv 3 param	0103 (OUTPUT FREQ)				



Dual setpoint with PID and constant speeds

This macro configures for applications with 2 constant speeds, active PID and PID alternating between two setpoints using digital inputs. Set PID setpoints (internal to the drive) using parameters 4011 (SET1) and 4111 (SET2). The digital input DI3 selects the setpoints.




	Parameters changed relative to HVAC default					
	Parameter	Value	Parameter		Value	
9902	applic macro	12 (DUAL SPNTCS)	3207	superv 3 param	0103 (OUTPUT FREQ)	
1102	ext1/ext2 sel	2 (DI2)	4001	gain	0.7	
1201	const speed sel	11 (DI5, 6)	4002	integration time	10.0 s	
1401	relay output 1	7 (STARTED)	4010	setpoint sel	19 (INTERNAL)	
1608	start enable 1	0 (NOT SEL)	4011	internal setpnt	50.0%	
2108	start inhibit	1 (ON)	4027	pid 1 param set	3 (DI3)	
2202	acceler time 1	10.0 s	4101	gain	0.7	
2203	deceler time 1	10.0 s	4102	integration time	10.0 s	
3105	ar overvoltage	0 (DISABLE)	4110	setpoint sel	19 (INTERNAL)	
3107	ar ai <min< td=""><td>0 (DISABLE)</td><td>4111</td><td>internal setpnt</td><td>100.0%</td></min<>	0 (DISABLE)	4111	internal setpnt	100.0%	



E-Clipse

This macro configures for an E-Clipse Bypass device which can bypass the drive and connect the motor direct on-line. When using direct speed reference in AUTO mode or process PID, see section *General considerations* on page 77.




	Parameters changed relative to HVAC default					
Parameter		Value		Parameter	Value	
9902	applic macro	15 (E-CLIPSE)	5303	efbbaud rate	76.8 kb/s	
9802	comm proto sel	1 (STD MODBUS)	5304	efb parity	2 (8 EVEN 1)	
1001	ext1 commands	10 (COMM)	5305	efb ctrl profile	1 (DCU PROFILE)	
1002	ext2 commands	10 (COMM)	5310	efb par 10	103	
1601	run enable	7 (COMM)	5311	efb par 11	104	
1608	start enable 1	7 (COMM)				



Hand control

This macro configures for drive control using only the control panel with no automated control. Typically, this is a temporary configuration used prior to control wiring.



	Parameters changed relative to HVAC default				
	Parameter Value		Parameter		Value
9902	applic macro	14 (HAND CONTROL)	3415	signal 3 param	100 (NOT SEL)
1001	ext1 commands	0 (NOT SEL)	3416	signal 3 min	(-)
1002	ext2 commands	0 (NOT SEL)	3417	signal 3 max	(-)
1106	ref3 sel	2 (AI2)	3418	output 3 dsp form	(-)
1201	const speed sel	0 (NOT SEL)	3419	output 3 dsp unit	(-)
1301	minimum ai1	0.0%	3420	output 3 min	(-)
1304	minimum ai2	0.0%	3421	output 3 max	(-)
1401	relay output 1	7 (STARTED)	4001	gain	1.0
1504	minimum ao1	0.0mA	4002	integration time	60.0 s
1510	minimum ao2	0.0mA	4010	setpoint sel	1 (Al1)
1601	run enable	2 (DI2)	4101	gain	1.0
1608	start enable 1	0 (NOT SEL)	4102	integration time	60.0 s
2108	start inhibit	1 (ON)	4110	setpoint sel	1 (Al1)
3207	superv 3 param	0103 (OUTPUT FREQ)	4210	setpoint sel	1 (AI1)





Program features

Contents of this chapter

The chapter describes program features. For each feature, there is a list of related user settings, actual signals, and fault and alarm messages.

Start-up assistant

Introduction

The Start-up assistant (requires the Assistant control panel) guides the user through the start-up procedure, helping to enter the requested data (parameter values) to the drive. The Start-up assistant also checks that the entered values are valid, in other words, within the allowed range.

The Start-up assistant calls other assistants, each of which guides the user through the task of specifying a related parameter set. At the first start, the drive suggests entering the first task, Language select, automatically. The user may activate the tasks either one after the other as the Start-up assistant suggests, or independently. The user may also adjust the drive parameters in the conventional way without using the assistant at all.

List of the tasks and the relevant drive parameters


Depending on the selection made in the Application task (parameter 9902 APPLIC MACRO), the Start-up assistant decides which consequent tasks it suggests.

Name	Description	Set parameters
Language select	Selecting the language	9901
Motor set-up	Setting the motor data	99059909
Application	Selecting the application macro	9902, parameters associated to the macro
Option modules	Activating the option modules	Group 35: Motor temp meas, Group 52: Panel comm, 9802
Speed control EXT1	Selecting the source for the speed (output frequency) reference	1103
	(If Al1 is used: Setting analog input Al1 limits, scale, inversion)	(13011303, 3001)
	Setting the reference limits	1104, 1105
	Setting the frequency limits	2007, 2008
	Setting the acceleration and deceleration times	2202, 2203
Speed control EXT2	Selecting the source for the speed (output frequency) reference	1106
	(If AI1 is used: Setting analog input AI1 limits, scale, inversion)	(13011303, 3001)
	Setting the reference limits	1107, 1108
PID control	Selecting the source for the process reference	1106
	(If Al1 is used: Setting analog input Al1 limits, scale, inversion)	(13011303, 3001)
	Setting the reference limits	1107, 1108
	Setting the speed (reference) limits	2007, 2008
	Setting the source and limits for the process actual value	4016, 4018, 4019
Start/Stop control	Selecting the source for start and stop signals of the two external control locations, EXT1 and EXT2	1001, 1002
	Selecting between EXT1 and EXT2	1002
	Defining the direction control	1003
	Defining the start and stop modes	21012103
	Selecting the use of Run Enable signal	1601
Protections	Setting the current limits	2003
Output signals	Selecting the signals indicated through relay output RO	Group 14: Relay outputs
	Selecting the signals indicated through analog output AO	Group 15: Analogue outputs
	Setting the minimum, maximum, scaling and inversion	

Name	Description	Set parameters
Timed functions	Setting the timed functions	Group 36: Timed functions
	Selecting the timed start/stop control for external control locations EXT1 and EXT2	1001, 1002
	Selecting timed EXT1/EXT2 control	1102
	Activation of timed constant speed 1	1201
	Selecting timed function status indicated through relay output RO	1401
	Selecting timed PID1 parameter set 1/2 control	4027


Contents of the assistant displays

There are two types of displays in the Start-up assistant: Main displays and the information displays. The main displays prompt the user to feed in information. The assistant steps through the main displays. The information displays contain help texts for the main displays. The figure below shows a typical example of both and explanations of the contents.




Local control vs. external control

The drive can receive start, stop and direction commands and reference values from the control panel or through digital and analog inputs. Embedded fieldbus enables control over an open fieldbus link. A PC equipped with DriveWindow Light PC tool can also control the drive.



Local control

The control commands are given from the control panel keypad when the drive is in local control. LOC indicates local control on the panel display.




The control panel always overrides the external control signal sources when used in local mode.

External control

When the drive is in external control, the commands are given through the standard I/O terminals (digital and analog inputs) and/or the fieldbus interface. In addition, it is also possible to set the control panel as the source for the external control.

External control is indicated with REM on the panel display.



The user can connect the control signals to two external control locations, EXT1 or EXT2. Depending on the user selection, either one is active at a time. This function operates on a 2 ms time level.


Settings

Panel key	Additional information	
LOC/REM	Selection between local and external control	
Parameter		
1102	Selection between EXT1 and EXT2	
1001/1002	Start, stop, direction source for EXT1/EXT2	
1103/1106	Reference source for EXT1/EXT2	

Actual signals	Additional information
0111/0112	EXT1/EXT2 reference


Block diagram: Start, stop, direction source for EXT1

The figure below shows the parameters that select the interface for start, stop, and direction for external control location EXT1.



Block diagram: Reference source for EXT1

The figure below shows the parameters that select the interface for the speed reference of external control location EXT1.



Reference types and processing

The drive can accept a variety of references in addition to the conventional analog input and control panel signals.

- The drive reference can be given with two digital inputs: One digital input increases the speed, the other decreases it.
- The drive can form a reference out of two analog input signals by using mathematical functions: Addition, subtraction, multiplication and division.
- The drive can form a reference out of an analog input signal and a signal received through a serial communication interface by using mathematical functions: Addition and multiplication.
- The drive reference can be given with frequency input.

It is possible to scale the external reference so that the signal minimum and maximum values correspond to a speed other than the minimum and maximum speed limits.


Settings

Parameter	Additional information
Group 11: Reference select	External reference source, type and scaling
Group 20: Limits	Operating limits
Group 22: Accel/Decel	Speed reference acceleration/deceleration ramps
Group 32: Supervision	Reference supervision

Actual signal	Additional information
0111/0112	REF1/REF2 reference
	References in different stages of the reference processing chain

Reference trimming

In reference trimming, the external reference is corrected depending on the measured value of a secondary application variable. The block diagram below illustrates the function.



Settings

Parameter	Additional information
1102	REF1/2 selection
42304232	Trimming function settings
4201 4221, 4228, 4229	PID control settings
Group 20: Limits	Drive operation limits

Programmable analog inputs

The drive has two programmable analog voltage/current inputs. The inputs can be inverted, filtered and the maximum and minimum values can be adjusted. The update cycle for the analog input is 8 ms (12 ms cycle once per second). The cycle time is shorter when information is transferred to the application program (8 ms -> 2 ms).

Settings

Parameter	Additional information
Group 11: Reference select	Al as reference source
Group 13: Analogue inputs	Analog input processing
3001, 3021, 3022, 3107	Al loss supervision
Group 35: Motor temp meas	Al in motor temperature measurement
Group 40: Process PID set 1 Group 42: Ext / Trim PID	Al as PID process control reference or actual value source
Group 44: Pump protection	Al as pump protection measurement source

Actual signal	Additional information
0120, 0121	Analog input values
1401	AI1/A2 signal loss
Alarm	
AI1 LOSS / AI2 LOSS	AI1/AI2 signal below AI1/AI2 FAULT LIMIT (3021/3022)
Fault	
Al1 LOSS Al2 LOSS	AI1/AI2 signal below limit AI1/AI2 FAULT LIMIT (3021/3022)
PAR AI SCALE	Incorrect AI signal scaling (1302 < 1301 or 1305 < 1304)

Programmable analog output

One programmable current output (0 ... 20 mA) is available. Analog output signal can be inverted, filtered and the maximum and minimum values can be adjusted. The analog output signals can be proportional to motor speed, output frequency, output current, motor torque, motor power, etc. The update cycle for the analog output is 2 ms.

It is also possible to write a value to an analog output through a serial communication link.

Settings

Parameter	Additional information
Group 15: Analogue outputs	AO value selection and processing
Group 35: Motor temp meas	AO in motor temperature measurement

Actual signal	Additional information
0124	AO value
Fault	
PAR AO SCALE	Incorrect AO signal scaling (1503 < 1502)

Programmable digital inputs

The drive has five programmable digital inputs. The update time for the digital inputs is 2 ms.

It is possible to delay the state change of digital inputs with delays defined in group Group 18: Freq in & tran out. This enables very simple program sequences by connecting several functions with the same physical wire, eg, to remove branches and leaves from a pipe by running the fan in reverse before normal operation.

One digital input (DI5) can be programmed as a frequency input. See section Frequency input on page 105.

Settings

Parameter	Additional information
Group 10: Start/Stop/Dir	DI as start, stop, direction
Group 11: Reference select	DI in reference selection, or reference source
Group 12: Constant speeds	DI in constant speed selection
Group 16: System controls	DI as external Run Enable, fault reset or user macro change signal
Group 18: Freq in & tran out	Delays in DI state changes
2109	DI as external emergency stop command source
2201	DI as acceleration and deceleration ramp selection signal
2209	DI as zero ramp force signal
3003	DI as external fault source
Group 35: Motor temp meas	DI in motor temperature measurement
3601	DI as timed function enable signal source
3622	DI as booster activation signal source
4010/4110/4210	DI as PID controller reference signal source
4022/4122	DI as sleep function activation signal in PID1
4027	DI as PID1 parameter set 1/2 selection signal source
4034/4035	DI as PID reference/output freezing source
4039/4139	DI as PID internal setpoint selection source
4228	DI as external PID2 function activation signal source
4406/4414	DI as connection signal source for pump inlet/outlet pressure switch
4421	DI as pipe fill enable source
4601	DI as pump clean trigger source
6403	DI as load analyzer logger reset source
8120	DI as PFA interlock source

Diagnostics

Actual signal	Additional information
0160	DI status
0414	DI status at the time the latest fault occurred

Programmable relay output

The drive has one programmable relay output. It is possible to add three additional relay outputs with the optional MREL-0 relay output extension module. For more information, see *MREL-01 output relay module user's manual* (3AUA0000035974 [English]).

With a parameter setting it is possible to choose what information to indicate through the relay output: Ready, running, fault, alarm, etc. The update time for the relay output is 2 ms.

A value can be written to a relay output through a serial communication link.

Settings

Parameter	Additional information
Group 14: Relay outputs	RO value selections and operation times

Actual signal	Additional information
0134	RO Control Word through fieldbus control
0162	RO 1 status
0173	RO 24 status. With option MREL-01 only.

Frequency input

Digital input DI5 can be programmed as a frequency input. Frequency input (0...16000 Hz) can be used as external reference signal source. The update time for the frequency input is 50 ms. Update time is shorter when information is transferred to the application program (50 ms -> 2 ms).

Settings

Parameter	Additional information
Group 18: Freq in & tran out	Frequency input minimum and maximum values and filtering
1103/1106	External reference REF1/2 through frequency input
4010, 4110, 4210	Frequency input as PID reference source

Diagnostics

Actual signal	Additional information
0161	Frequency input value

Transistor output

The drive has one programmable transistor output. The output can be used either as digital output or frequency output (0...16000 Hz). The update time for the transistor/frequency output is 2 ms.

Settings

Parameter	Additional information
Group 18: Freq in & tran out	Transistor output settings

Actual signal	Additional information
0163	Transistor output status
0164	Transistor output frequency

Actual signals

Several actual signals are available:

- · Drive output frequency, current, voltage and power
- · Motor speed and torque
- Intermediate circuit DC voltage
- Active control location (LOCAL, EXT1 or EXT2)
- Reference values
- Drive temperature
- · Operating time counter (h), kWh counter
- · Digital I/O and analog I/O status
- · PID controller actual values.

Three signals can be shown simultaneously on the assistant control panel display (one signal on the basic panel display). It is also possible to read the values through the serial communication link or through the analog outputs.


Settings

Parameter	Additional information
1501	Selection of an actual signal to AO
1801	Selection of an actual signal to frequency output
Group 32: Supervision	Actual signal supervision
Group 34: Panel display	Selection of an actual signals to be displayed on the control panel

Actual signal	Additional information
Group 01: Operating data Group 04: Fault history	Lists of actual signals

Power loss ride-through

If the incoming supply voltage is cut off, the drive will continue to operate by utilizing the kinetic energy of the rotating motor. The drive will be fully operational as long as the motor rotates and generates energy to the drive. The drive can continue the operation after the break if the main contactor remained closed.



 $U_{\rm DC}$ = Intermediate circuit voltage of the drive, $f_{\rm out}$ = Output frequency of the drive, $T_{\rm M}$ = Motor torque

Loss of supply voltage at nominal load ($f_{\rm out}$ = 40 Hz). The intermediate circuit DC voltage drops to the minimum limit. The controller keeps the voltage steady as long as the input power is switched off. The drive runs the motor in generator mode. The motor speed falls but the drive is operational as long as the motor has enough kinetic energy.

Settings

Parameter 2006 UNDERVOLT CTRL

DC magnetizing

When DC Magnetizing is activated, the drive automatically magnetizes the motor before starting. This feature guarantees the highest possible breakaway torque, up to 180% of the motor nominal torque. The Automatic Start feature and DC Magnetizing cannot be activated at the same time.

Settings

Parameters 2101 START FUNCTION and 2103 DC MAGN TIME

Maintenance trigger

A maintenance trigger can be activated to show a notice on the panel display when, for example, drive power consumption has exceeded the defined trigger point.

Settings


Parameter Group 29: Maintenance trig

Acceleration and deceleration ramps

Two user-selectable acceleration and deceleration ramps are available. It is possible to adjust the acceleration/deceleration times and the ramp shape. Switching between the two ramps can be controlled via a digital input or fieldbus.

The available ramp shape alternatives are Linear and S-curve.

Linear: Suitable for drives requiring steady or slow acceleration/deceleration.



S-curve: Ideal for conveyors carrying fragile loads, or other applications where a smooth transition is required when changing the speed.

Settings

Parameter Group 22: Accel/Decel

Critical speeds

A Critical Speeds function is available for applications where it is necessary to avoid certain motor speeds (drive output frequencies) or speed bands (output frequency bands) because of, for example, mechanical resonance problems. The user can define three critical frequencies or frequency bands.

Settings

Parameter Group 25: Critical speeds

Constant speeds

It is possible to define seven positive constant speeds. Constant speeds are selected with digital inputs. Constant speed activation overrides the external speed reference.

Constant speed selections are ignored if

- PID reference is being followed, or
- drive is in local control mode.

This function operates on a 2 ms time level.


Settings

Parameter Group 12: Constant speeds

Constant speed 7 (1208 CONST SPEED 7) is also used for fault functions. See parameter group Group 30: Fault functions.

Custom U/f ratio

The user can define a U/f curve (output voltage as a function of frequency). This custom ratio is used only in special applications where linear and squared U/f ratio are not sufficient (eg, when motor break-away torque needs to be boosted).



Note: The voltage and the frequency points of the U/f curve must fulfill the following requirements:



WARNING! High voltage at low frequencies may result in poor performance or motor damage (overheating).

Settings

Parameter	Additional information
2605	Custom U/f ratio activation
26102618	Custom U/f ratio settings


Fault	Additional information
PAR CUSTOM U/F	Incorrect U/f ratio

R compensation

When IR compensation is activated, the drive gives an extra voltage boost to the motor at low speeds. IR compensation is useful in applications that require high breakaway torque.

Settings

Parameter 2603 IR COMP VOLT



Programmable protection functions

Al<Min</p>

Al<Min function defines the drive operation if an analog input signal falls below the set minimum limit.

Settings

Parameters 3001 AI<MIN FUNCTION, 3021 AI1 FAULT LIMIT and 3022 AI2 FAULT LIMIT

Panel loss

The Panel loss function defines the operation of the drive if the control panel selected as control location for the drive stops communicating.

Settings

Parameter 3002 PANEL COMM ERR

External fault

External faults (1 and 2) can be supervised by defining one digital input as a source for an external fault indication signal.

Settings

Parameters 3003 EXTERNAL FAULT 1 and 3004 EXTERNAL FAULT 2

Stall protection

The drive protects the motor in a stall situation. It is possible to adjust the supervision limits (frequency, time) and choose how the drive reacts to the motor stall condition (alarm indication / fault indication & drive stop / no reaction).

Settings


Parameters 3010 STALL FUNCTION...3012 STALL TIME

Motor thermal protection

The motor can be protected against overheating by activating the Motor thermal protection function.

The drive calculates the temperature of the motor on the basis of the following assumptions:

- The motor is in the ambient temperature of 30 °C when power is applied to the drive.
- Motor temperature is calculated using either the user-adjustable or automatically calculated motor thermal time constant and motor load curve (see the figures below). The load curve should be adjusted in case the ambient temperature exceeds 30 °C.



Settings

Parameters 3005 MOT THERM PROT...3009 BREAK POINT FREQ

Note: It is also possible to use the motor temperature measurement function. See section *Motor temperature measurement through the standard I/O* on page 121.

Earth fault protection

The Earth fault protection function detects ground faults in the motor or motor cable. The protection is active only during start.

A ground fault in the input power line does not activate the protection.

Settings

Parameter 3017 EARTH FAULT

Incorrect wiring

Defines the operation when incorrect input power cable connection is detected.

Settings

Parameter 3023 WIRING FAULT

Preprogrammed faults

Overcurrent

The overcurrent trip limit for the drive is 325% of the drive nominal current.

DC overvoltage

The DC overvoltage trip limit is 420 V (for 200 V drives) and 840 V (for 400 V drives).

DC undervoltage

The DC undervoltage trip limit is adaptive. See parameter 2006 UNDERVOLT CTRL.

Drive temperature

The drive supervises the IGBT temperature. There are two supervision limits: Alarm limit and fault trip limit.

Short circuit

If a short circuit occurs, the drive will not start and a fault indication is given.

Internal fault

If the drive detects an internal fault, the drive is stopped and a fault indication is given.

Supply phase loss

If the drive detects supply phase loss (excessive DC voltage ripple), the drive is stopped and a fault indication is given.

Operation limits

The drive has adjustable limits for output frequency, current (maximum) and DC voltage.

Settings

Parameter Group 20: Limits

Power limit

Power limitation is used to protect the input bridge and the DC intermediate circuit. If the maximum allowed power is exceeded, the drive torque is automatically limited. Maximum overload and continuous power limits depend on the drive hardware. For specific values, see chapter *Technical data* on page 363.

Automatic resets

The drive can automatically reset itself after overcurrent, overvoltage, undervoltage, external and "analog input below a minimum" faults. The Automatic Resets must be activated by the user.

Settings

Parameter	Additional information
Group 31: Automatic reset	Automatic reset settings

Diagnostics

Alarm	Additional information
AUTORESET	Automatic reset alarm

Supervisions

The drive monitors whether certain user selectable variables are within the user-defined limits. The user may set limits for speed, current etc. The supervision status can be indicated through relay or digital output.

The supervision function outputs can be used for triggering some drive functionality (start/stop, sleep, pump cleaning).

The supervision functions operate on a 2 ms time level.

Settings

Parameter group Group 32: Supervision

Actual signal	Additional information
1001/1002	EXT1/EXT2 start/stop according to supervision functions
1401	Supervision status through RO 1
1402/1403/1410	Supervision status through RO 24. With option MREL-01 only.
1805	Supervision status through DO
4022/4122	Sleep start according to supervision functions
4601	Pump clean trigger according to supervision functions

Parameter lock

The user can prevent parameter adjustment by activating the parameter lock.

Settings

Parameters 1602 PARAMETER LOCK and 1603 PASS CODE

PID control

There are two built-in PID controllers in the drive:

- · Process PID (PID1) and
- External/Trim PID (PID2).

The PID controller can be used when the motor speed needs to be controlled based on process variables such as pressure, flow or temperature.

When the PID control is activated, a process reference (setpoint) is connected to the drive instead of a speed reference. An actual value (process feedback) is also brought back to the drive. The drive compares the reference and the actual values, and automatically adjusts the drive speed in order to keep the measured process quantity (actual value) at the desired level (reference).

The control operates on a 2 ms time level.

Process controller PID1

PID1 has two separate sets of parameters (Group 40: Process PID set 1, Group 41: Process PID set 2). Selection between parameter sets 1 and 2 is defined by a parameter.

In most cases when there is only one transducer signal wired to the drive, only parameter set 1 is needed. Two different parameter sets (1 and 2) are used, eq. when the load of the motor changes considerably in time.


External/Trim controller PID2

PID2 (Group 42: Ext / Trim PID) can be used in two different ways:


- External controller: Instead of using additional PID controller hardware, the user can connect PID2 output via drive analog output or fieldbus controller to control a field instrument like a damper or a valve.
- Trim controller: PID2 can be used to trim or fine tune the reference of the drive. See section Reference trimming on page 100.

Block diagrams

The figure below shows an application example: The controller adjusts the speed of a pressure boost pump according to the measured pressure and the set pressure reference.



The following figure presents the speed/scalar control block diagram for process controller PID1.



Settings


Parameter	Additional information
1101	Local control mode reference type selection
1102	EXT1/2 selection
1106	PID1 activation
1107	REF2 minimum limit
1501	PID2 output (external controller) connection to AO
9902	PID control macro selection
Group 40: Process PID set 1Group 41: Process PID set 2	PID1 settings
Group 42: Ext / Trim PID	PID2 settings

Actual signal	Additional information
0126/0127	PID 1/2 output value
0128/0129	PID 1/2 setpoint value
0130/0131	PID 1/2 feedback value
0132/0133	PID 1/2 deviation

Sleep function for the process PID (PID1) control


The sleep function operates on a 2 ms time level.

The block diagram below illustrates the sleep function enable/disable logic. The sleep function can be put into use only when the PID control is active.



Example

The time scheme below visualizes the operation of the sleep function.



Sleep function for a PID controlled pressure boost pump (when parameter 4022 SLEEP SELECTION is set to INTERNAL): The water consumption falls at night. As a consequence, the PID process controller decreases the motor speed. However, due to natural losses in the pipes and the low efficiency of the centrifugal pump at low speeds, the motor does not stop but keeps rotating. The sleep function detects the slow rotation, and stops the unnecessary pumping after the sleep delay has passed. The drive shifts into sleep mode, still monitoring the pressure. The pumping restarts when the pressure falls under the allowed minimum level and the wake-up delay has passed.

Settings

Parameter	Additional information
9902	PID control activation
40224026, 4030, 4031, 41224126, 4130, 4131	Sleep function settings


Diagnostics

Parameter	Additional information
1401	PID sleep function status through RO 1
1402/1403/1410	PID sleep function status through RO 24. With option MREL-01 only.
Alarm	Additional information
PID SLEEP	Sleep mode

Motor temperature measurement through the standard I/O

This section describes the temperature measurement of one motor when the drive I/O terminals are used as the connection interface.

Motor temperature can be measured using PT100 or PTC sensors connected to analog input and output.



WARNING! According to IEC 664, the connection of the motor temperature sensor requires double or reinforced insulation between motor live parts and the sensor. Reinforced insulation entails a clearance and creepage distance of 8 mm (400/500 V AC equipment).


If the assembly does not fulfill the requirement, the I/O board terminals must be protected against contact and they may not be connected to other equipment, or the temperature sensor must be isolated from the I/O terminals.

To fulfill the insulation requirement, connect a thermistor (and other similar components) to the drive's control terminals using any of these alternatives:

- Separate the thermistor from live parts of the motor with double reinforced insulation.
- Protect all circuits connected to the drive's digital and analog inputs. Protect
 against contact, and insulate from other low voltage circuits with basic insulation
 (rated for the same voltage level as the drive's main circuit).
- Use an external thermistor relay. The relay insulation must be rated for the same voltage level as the drive's main circuit.

The figure below shows alternate thermistor connections. At the motor end the cable shield should be grounded through a 10 nF capacitor. If this is not possible, leave the shield unconnected.

It is also possible to monitor motor temperature by connecting a PTC sensor and a thermistor relay between the +24 V DC voltage supply offered by the drive and a digital input. The figure below displays the connection.



For other faults, or for anticipating motor overheating using a model, see *Group 30:* Fault functions.

Settings

Parameter	Additional information
Group 13: Analogue inputs	Analog input settings
Group 15: Analogue outputs	Analog output settings
Group 35: Motor temp meas	Motor temperature measurement settings
Other	•
At the motor end the cable shield should be grounded through a 10 nF capacitor. If this is not possible, the shield is to be left unconnected.	


Actual value	Additional information
0145	Motor temperature
Alarm/Fault	Additional information
MOTOR TEMP/MOT OVERTEMP	Excessive motor temp

Timed functions


A variety of drive functions can be time controlled, eg start/stop and EXT1/EXT2 control. The drive offers

- four start and stop times (START TIME 1...4, STOP TIME 1...4)
- four start and stop days (START DAY 1...4, STOP DAY 1...4)
- four timed functions for collecting the selected time periods 1...4 together (TIMED FUNC 1...4)
- booster time (an additional booster time connected to timed functions).

A timed function can be connected to multiple time periods:



A parameter which is triggered by a timed function can be connected to only one timed function at a time.



Examples

Air conditioning is active on weekdays from 8:00 to 15:30 (8 a.m to 3:30 p.m) and on Sundays from 12:00 to 15:00 (12 to 3 p.m). By pressing the extension time switch, the air-conditioning is on for an extra hour.

Parameter	Setting
3601 TIMERS ENABLE	DI1
3602 START TIME 1	08:00:00
3603 STOP TIME 1	15:30:00
3604 START DAY 1	MONDAY
3605 STOP DAY 1	FRIDAY
3606 START TIME 2	12:00:00
3607 STOP TIME 2	15:00:00
3608 START DAY 2	SUNDAY
3609 STOP DAY 2	SUNDAY
3623 BOOSTER TIME	01:00:00


Parameter	Additional information
Group 36: Timed functions	Timed functions settings
1001, 1002	Timed start/stop control
1102	Timed EXT1/EXT2 selection
1201	Timed constant speed 1 activation
1209	Timed speed selection
1401	Timed function status indicated through relay output RO 1
1402/1403/1410	Timed function status indicated through relay output RO 24. With option MREL-01 only.

Parameter	Additional information
1805	Timed function status indicated through digital output DO
4027	Timed PID1 parameter set 1/2 selection
4228	Timed external PID2 activation

User load curve

The user can specify a load curve (motor torque as a function of frequency) for supervision. The curve is defined by five points. Supervision can be set for the torque dropping below the underload curve, exceeding the overload curve, or both.

A fault is generated if the torque has been out of the allowed area for longer than the user-defined time limit. An alarm is generated if the torque has been out of the allowed area for longer than the half of the user-defined time limit.



Parameter	Additional information
Group 37: User load curve	User load curve settings

Diagnostics

Actual signal	Additional information
0105	Motor torque
Alarm	
USER LOAD CURVE	Out of allowed area for longer than half of the defined time limit
Fault	
USER LOAD CURVE	Out of allowed area for longer than the defined time limit
PAR USER LOAD C	Incorrect user load curve parameter setting (3704 > 3707 or 3707 > 3710 or 3710 > 3713 or 3713 > 3716 or 3705 > 3706 or 3708 > 3709 or 3711 > 3712 or 3714 > 3715 or 3717 > 3718)

Energy optimizer

Energy optimizer optimizes the flux so that the total energy consumption and motor noise level are reduced when the drive operates below the nominal load. The total efficiency (motor and drive) can be improved by 1 ... 10% depending on the load torque and speed.

Parameter	Additional information
4501 ENERGY OPTIMIZER	Energy optimizer enabling

Energy saving

Energy saving tools calculate energy saved in kWh and MWh, energy saved in local currency as well as reduction in CO_2 emission, all compared to the situation when the pump is connected directly to the supply.

Two actual signals, 0176 SAVED AMOUNT 1 and 0177 SAVED AMOUNT 2 are used to store the energy saved in local currency. To find out the total saved energy in currency units, add the value of signal 0177 multiplied by 1000 to the value of signal 0176.

Example:

0176 SAVED AMOUNT 1 = 123.4 0177 SAVED AMOUNT 2 = 5

Total saved energy = $5 \cdot 1000 + 123.4 = 5123.4$ currency units.

Note: The values of saved energy parameters 0174 SAVED KWH, 0175 SAVED MWH, 0176 SAVED AMOUNT 1, 0177 SAVED AMOUNT 2 and 0178 SAVED CO2 are derived from subtracting the drive's energy consumed from the direct-on-line (DOL) consumption calculated on the basis of parameter 4508 PUMP POWER. As such, the accuracy of the values is dependent on the accuracy of the power estimate entered in that parameter.


Settings

Parameter	Additional information
Group 45: Energy saving	Energy saving settings

Actual signal	Additional information
0174/0175	Energy saved in kWh/Mwh
0176/0177	Energy saved in local currency
0178	Reduction in CO ₂ emission

Pump cleaning

The Pump cleaning function can be used for preventing solids from building up on pump impellers. The function consists of a programmable sequence of forward and reverse runs of the pump (see the figure below), effectively shaking off any residue on the impeller. This is especially useful with booster and wastewater pumps.



The pump cleaning cycle can be activated at start-up, with a user-defined period, with a selectable digital input or by the Supervision function (for example triggered by the motor input current).

Parameter	Additional information
Group 46: Pump cleaning	Pump cleaning settings
2205/2206	Acceleration time 2 / Deceleration time 2

Load analyzer

The load analyzer can be used for analyzing the customer's process and sizing the drive and the motor.


Peak value logger

The user can select a signal (Group 01: Operating data) to be monitored by the peak value logger (PVL). The signal is sampled at 2 ms intervals when the drive is running. The logger records the peak (maximum) value of the signal along with the time the peak occurred, as well as output current, DC voltage and output frequency at the time of the peak.

Amplitude loggers

The drive has two amplitude loggers.

For amplitude logger 2 (AL2), the user can select a signal (Group 01: Operating data) to be sampled at 200 ms intervals when the drive is running, and specify a value that corresponds to 100%. The collected samples are sorted into 10 read-only parameters according to their amplitude. Each parameter represents an amplitude range 10 percentage points wide, and displays the percentage of the collected samples that fall within that range.



Amplitude logger 1 (AL1) is fixed to monitor output current, and it cannot be reset. With amplitude logger 1, 100% corresponds to the nominal output current of the drive $(I_{2N}).$

The peak value logger and amplitude logger 2 can be reset by a user-defined method. They are also reset if either of the signals or the peak value filter time is changed.

Settings

Parameter	Additional information
Group 64: Load analyzer,	Load analyzer settings
parameters 64016405	

Diagnostics

Actual signal	Additional information
Group 64: Load analyzer,	Load analyzer results
parameters 64066433	

PFA control (Requires use of MREL-01 option purchased separately)

PFA control

The pump and fan alternation (PFA) control switches auxiliary pumps on and off as required by capacity changes. The Autochange function alternates between pumps to keep the duty times of the pumps equal. Interlocks function enables the drive to detect if any of the pumps are unavailable (for example, switched off for maintenance), in which case the next available pump is started instead.

The drive controls the motor of pump 1, varying the motor speed to control the pump capacity. This motor is the speed regulated motor.

Direct line connections power the motor of pump 2 and pump 3, etc. The drive switches pump 2 (and then pump 3, etc.) on and off as needed. These motors are auxiliary motors.

The drive PID control uses two signals: a process reference and an actual value feedback. The PID controller adjusts the speed (frequency) of the first pump such that the actual value follows the process reference.

When demand (defined by the process reference) exceeds the first motor's capacity (user defined as a frequency limit), the PFA control automatically starts an auxiliary pump. The PFA control also reduces the speed of the first pump to account for the auxiliary pump's addition to total output. Then, as before, the PID controller adjusts the speed (frequency) of the first pump such that the actual value follows the process reference. If demand continues to increase, the PFA control adds additional auxiliary pumps, using the same process.

When demand drops, such that the first pump speed falls below a minimum limit (user defined by a frequency limit), the PFA control automatically stops an auxiliary pump. The PFA control also increases the speed of the first pump to account for the auxiliary pump's missing output.

An Interlock function (when enabled) identifies off-line (out of service) motors, and the PFA control skips to the next available motor in the sequence.

An Autochange function (when enabled and with the appropriate switchgear) equalizes duty time between the pump motors. Autochange periodically increments the position of each motor in the rotation – the speed regulated motor becomes the last auxiliary motor, the first auxiliary motor becomes the speed regulated motor, etc.

When the speed regulated motor reaches the full output, it is disconnected from the drive and switched to direct on-line connection, with a slight delay in between.

Auxiliary motor 2 is connected to drive output. After a slight delay the motor speed is increased to fulfill the pumping capacity needed.

Auxiliary motors 3 and 4 are started according to the same routine.

The motor stopping routine always follows the normal PFA routine.

Settings

Parameter	Additional information
Group 14: Relay outputs	Selections of relay outputs for starting and stopping of motors
Group 44: Pump protection	Pump protection (pressure monitoring) settings
Group 81: PFA control	PFA control settings

Actual signal	Additional information
0116	Application block output signal
0162	RO 1 status
0173	RO 24 status. With option MREL-01 only.
Alarm	
AUTOCHANGE	PFA autochange function active
PFC I LOCK	PFA interlocks active
INLET LOW, INLET VERY LOW	Pressure at pump/fan inlet too low
OUTLET HIGH, OUTLET VERY HIGH	Pressure at pump/fan outlet too high
Fault	Additional information
PAR PFC REF NEG	2007 < 0
PAR PFA IO 1	Not enough relays parameterized for the PFA control. Conflict between <i>Group 14: Relay outputs</i> , parameter 8117 and parameter 8118.
PAR PFC IO 2	Parameter 8127 does not match the PFA motors in Group 14: Relay outputs and parameter 8118.
PAR PFC IO 3	Allocation of a digital input (interlock) for each PFA motor not possible
INLET LOW, INLET VERY LOW	Pressure at pump/fan inlet too low
OUTLET HIGH, OUTLET VERY HIGH	Pressure at pump/fan outlet too high



Actual signals and parameters

Contents of this chapter

The chapter describes the actual signals and parameters and gives the fieldbus equivalent values for each signal/parameter. It also contains a table of the default values for the different macros

Note: When the control panel is in the short parameter view, in other words, when parameter 1611 PARAMETER VIEW is set to 2 (SHORT VIEW), the control panel only shows a subset of all signals and parameters. The list of these signals and parameters starts on page 134.

To be able to view all actual signals and parameters, set parameter 1611 PARAMETER VIEW to 3 (LONG VIEW). The descriptions of parameters start on pages 137.

Terms and abbreviations

Term	Definition	
Actual signal	Signal measured or calculated by the drive. Can be monitored by the user. No user setting possible. <i>Group 01: Operating dataGroup 04: Fault history</i> contain actual signals.	
Def	Parameter default value	
E	Refers to types 03E- with European parametrization	
FbEq	Fieldbus equivalent: The scaling between the value and the integer used in serial communication.	
Parameter	A user-adjustable operation instruction of the drive. <i>Group 10:</i> Start/Stop/DirGroup 98: Options contain parameters.	
	Note: Parameter selections are shown on the Basic Control Panel as integer values. For example, parameter <i>1001 EXT1 COMMANDS</i> selection COMM is shown as value 10 (which is equal to the fieldbus equivalent FbEq).	
U	Refers to types 03U- with US parametrization	

Fieldbus equivalent

Example: If parameter 2008 MAXIMUM FREQ (see page 180) is set from an external control system, an integer value of 1 corresponds to 0.1 Hz. All the read and sent values are limited to 16 bits (-32768...32767).

Actual signals in the short parameter view

Actu	Actual signals in the short parameter view			
No.	Name/Value	Description	FbEq	
04 F		Fault history (read-only). See <i>Group 04: Fault history</i> in the list of all parameters.		
0401	LAST FAULT	Code of the latest fault.	1 = 1	

Parameters in the short parameter view

Parameters in the sh	ort parameter view	
No. Name/Value	Description	Default
11 REFERENCE SELECT	Panel reference type, external control location selection and external reference sources and limits. See <i>Group</i> 11: Reference select in the list of all parameters.	
1105 REF1 MAX	Defines the maximum value for external reference REF1.	E: 50.0 Hz U: 60.0 Hz
12 CONSTANT SPEEDS	Constant speed (drive output frequency) selection and values. See <i>Group 12: Constant speeds</i> in the list of all parameters.	
1202 CONST SPEED 1	Defines constant drive output frequency 1.	E: 5.0 Hz U: 6.0 Hz
1203 CONST SPEED 2	Defines constant drive output frequency 2.	E: 10.0 Hz U: 12.0 Hz
1204 CONST SPEED 3	Defines constant drive output frequency 3.	E: 15.0 Hz U: 18.0 Hz
13 ANALOG INPUTS	Analogue inputs in the list of all parameters.	
1301 MINIMUM AI1	Defines the minimum %-value that corresponds to minimum mA/(V) signal for analog input Al1.	1.0%
14 RELAY OUTPUTS	Status information indicated through relay output, and relay operating delays. See <i>Group 14: Relay outputs</i> in the list of all parameters.	
1401 RELAY OUTPUT 1	Selects a drive status indicated through relay output RO 1.	FAULT(-1)
16 SYSTEM CONTROLS	Parameter view, Run Enable, parameter lock etc. See <i>Group 16: System controls</i> in the list of all parameters.	
1611 PARAMETER VIEW	Selects the parameter view, in other words, which parameters are shown on the control panel.	SHORT VIEW
20 LIMITS	Drive operation limits. See <i>Group 20: Limits</i> in the list of all parameters.	
2008 MAXIMUM FREQ	Defines the maximum limit for the drive output frequency.	E: 50.0 Hz U: 60.0 Hz
21 START/STOP	Start and stop modes of the motor. See <i>Group 21:</i> Start/Stop in the list of all parameters.	
2102 STOP FUNCTION	Selects the motor stop function.	COAST
22 ACCEL/DECEL	Acceleration and deceleration times. See <i>Group 22:</i> Accel/Decel in the list of all parameters.	
2202 ACCELER TIME 1	Defines the acceleration time 1.	5.0 s
2203 DECELER TIME 1	Defines the deceleration time 1.	5.0 s

Para	Parameters in the short parameter view			
No.	Name/Value	Description	Default	
99 S	TART-UP DATA	Language selection. Definition of motor set-up data. See <i>Group 99: Start-up data</i> in the list of all parameters.		
9901	LANGUAGE	Selects the display language.	ENGLISH	
9902	APPLIC MACRO	Selects the application macro.	ABB STANDARD	
9905	MOTOR NOM VOLT	Defines the nominal motor voltage.	230 V (200 V units) 400 V (400 V E units) 460 V (400 V U units)	
9906	MOTOR NOM CURR	Defines the nominal motor current.	I _{2N}	
9907	MOTOR NOM FREQ	Defines the nominal motor frequency.	E: 50.0 Hz U: 60.0 Hz	
9908	MOTOR NOM SPEED	Defines the nominal motor speed.	Type dependent	
9909	MOTOR NOM POWER	Defines the nominal motor power.	P_{N}	

Parameter listing

Parameter data is specific to ACS320 firmware version 4.01C.

Group 99: Start-up data

This group defines special Start-up data required to:

- · set up the drive
- · enter motor information.

Note: Parameters checked under the heading "S" can be modified only when the drive is stopped.

	Group 99: Start-up data				
Code I	Description	Range	Resolution	Default	S
9901 I	LANGUAGE	013	1	0	
(Selects the display langu	iage.			
	4= ESPAÑOL 5= 1		EDERLANDS ÆNSKA	3= ITALIANO 7= FRANCAIS 11= RUSSKI 15= MAGYAR	
9902	APPLIC MACRO	-115	1	1	✓
á	configure the ACS320 fo application macro description to the application macro description to the application macro description to the application of the application	SUPPLY FAN 3= RET BOOSTER 7= PUM PUMP FLOATING PNT 11= DUA	See Application n URN FAN 4= IP ALTERNA 8=	nacros for CLNG TWR FAN INT TIMER	
-	31 = LOAD FD SETrontE Parameter view is s an optional device fe allows easy customi can be hidden. For i [3AFE68591074 (Er. -1 = USER S1 SAVE, -3 different user parame set contains parame results of the motor	= USER S2 SAVE - With the terms of the drive perecepter settings, including Ground and the drive perecepter settings, including Ground and the driver settings.	1 PARAMETER Ners to unpowered it, for example, se DT-01 FlashDrop these it is possible manent memory oup 99: START-U	//EW.FlashDrop I drives. FlashDrelected paramete User's Manual e to save two for later use. Ea P DATA, and the	rop ers ach

		Group 99: Start-up data			
Code	Description	Range	Resolution	Default	S
9905	MOTOR NOM VOLT	115 345 V (200 V, US)	1 V	230 V	√
	IIIO TOR ITOM TOE	230 690 V (400 V, US)	1 V	460 V	Ť
		288 862 V (600 V, US)	1 V	575 V	
	Defines the nominal motor	or voltage.	t voltage		
	Must equal the value o plate.		A		
	Sets the maximum driv	e output voltage	<i> </i>		
	supplied to the motor.		/ ;	Output	
	 Drive cannot supply the 		/ !	frequenc	су
	voltage greater than the	e mains voltage.	990)7	
9906	MOTOR NOM CURR	0.15*l _{2N} 1.5*l _{2N}	0.1 A	1.5*I _{2N}	✓
	Defines the nominal motor	or current.			
	 Must equal the value o 	n the motor rating plate.			
9907	MOTOR NOM FREQ	10.0 500 Hz	0.1 Hz	60 Hz (US)	✓
	Defines the nominal motor	or frequency.			
	• Range: 10 500 Hz (typically 50 or 60 Hz)			
	Sets the frequency at v VOLT	vhich output voltage equals	parameter 990	5 MOTOR NO	M
	Field weakening point	= Norm freq * Supply Volt / N	Not Nom Volt		
9908	MOTOR NOM SPEED	50 30000 rpm	1 rpm	Size dependent	✓
	Defines the nominal motor	or speed.			
	 Must equal the value o 	n the motor rating plate.			
9909	MOTOR NOM	0.15 1.5*P _N	0.1 Hp	0.2 HP (US)	✓
	POWER				
	Defines the nominal motor	or power.			
	 Must equal the value o 	n the motor rating plate.			
9914	PHASE INVERSION			NO	✓
	without having to exchanged drive output terminals or a NO – Phases not invertigated.		r cable phase o		
	YES – Phases inverted	l.			

Group 01: Operating data

This group contains drive operating data, including actual signals. The drive sets the values for actual signals, based on measurements or calculations. You cannot set these values.

	G	roup 01: Operating dat	ta		
Code	Description	Range	Resolution	Default	S
0101	SPEED & DIR	-3000030000	1 rpm	-	
	The calculated speed of t	he motor (rpm) & motor dir	ection.		
0102	SPEED	0 30000 rpm	1 rpm	=	
	The calculated speed of the	he motor (rpm).			
0103	OUTPUT FREQ	0.0 500.0 Hz	1Hz	=	
	The frequency (Hz) applied	ed to the motor. (Also show	n by default in C	OUTPUT disp	lay.)
0104	CURRENT	0.0 1.5*I _{2N}	0.1 A	=	
	The motor current, as me display.)	asured by the drive. (Also	shown by defaul	t in OUTPUT	•
0105	TORQUE	-200% 200 %	0.1%	-	
	Output torque. Calculated	I value of torque on motor s	haft in % of moto	or nominal to	rque.
0106	POWER	-1.5 1.5*P _N	0.1 kW	-	
	The measured motor pow	er in kW.			
0107	DC BUS VOLTAGE	0 V 2.5*V _{dN}	1 V	=	
	The DC bus voltage in VE	OC, as measured by the dri	ve.		
0109	OUTPUT VOLTAGE	0 V 2.0*V _{dN}	1 V	-	
	The voltage applied to the	e motor.			
0110	DRIVE TEMP	0°C 150°C	1°C	-	
	The temperature of the dr	rive power transistors in Ce	elsius.		
0111	EXTERNAL REF 1	0 500 Hz	0.1 Hz	-	
	External reference, REF1	or Hz.			
0112	EXTERNAL REF 2	0% 100% (torque: 0% 600%)	0.1%	-	
	External reference, REF2	, in %			
0113	CTRL LOCATION	0 2	1	-	
	Active control location. Al 0 = HAND 1 = EXT1 2 = EXT2	ternatives are:			
0114	RUN TIME (R)	0 65,535 h	1 h	0 h	
	The drive's accumulated i	running time in hours (h).			
	Can be reset by pressi parameter set mode.	ng UP and DOWN buttons	simultaneously	when in	

	Group 01: Operating data					
Code	Description	Range	Resolution	Default	S	
0115	KWH COUNTER (R)	0 65,535 kWh	1 kWh	-		
	The drive's accumulated p	ower consumption in kilo	watt hours.			
	Can be reset by pressir	ng UP and DOWN buttons	simultaneously	when in		
	parameter set mode.					
0116	APPL BLK OUTPUT	0 100%	0.1%	-		
	A multipostion blook acceptance	(torque: 0 600%)				
	Application block output siPFA control, if PFA Con	•				
	 Pra control, il Pra Con Parameter 0112 EXTER 	*				
0120	Al1	0 100%	0.1%			
0120	Relative value of analog in		0.176	-		
0121	Al2	0 100%	0.1%			
0121			0.176	-		
0124	Relative value of analog in	0 20 mA	0.1 mA			
0124	1.0.	• =•	U.I IIIA	-		
0126	The analog output 1 value PID 1 OUTPUT	-1000 1000%	0.1%			
0120	The PID Controller 1 output		0.176	-		
0127	PID 2 OUTPUT	-100 100%	0.1%			
0127	The PID Controller 2 output	100 111 100 70	0.176	-		
0128	PID 1 SETPNT					
0120	The PID 1 controller setpo	int cianal	_	_		
	 Units and scale defined 	J	/4106 & <u>4007</u> /41(17		
0129	PID 2 SETPNT	-	-	-		
0.20	The PID 2 controller setpo	int signal				
	Units and scale defined	J	& 4207			
0130	PID 1 FBK	-	-	-		
	The PID 1 controller feedb	ack signal.				
	 Units and scale defined 	•	/4106 & <i>4007</i> /410	07.		
0131	PID 2 FBK	-	=	-		
	The PID 2 controller feedb	ack signal.				
	 Units and scale defined 	by PID parameters 4206	& 4207.			
0132	PID 1 DEVIATION	-	-	-		
	The difference between th	e PID 1 controller referen	ce value and act	ual value.		
	Units and scale defined					
0133	PID 2 DEVIATION	-	-	-		
	The difference between th	e PID 2 controller referen	ce value and act	ual value.		
	Units and scale defined	by PID parameters 4206	& 4207.			
	•					

	Gr	oup 01: Operating dat	а		
Code	Description	Range	Resolution	Default	S
0134	COMM RO WORD	065535	1	0	
	Free data location that car	n be written from serial link			
	 Used for relay output co 	ntrol.			
	See parameter 1401.				
0135	COMM VALUE 1	-32768 + 32767	1	0	
	Free data location that car	n be written from serial link	-		
0136	COMM VALUE 2	-32768 +32767	1	0	
	Free data location that car	n be written from serial link			
0137	PROCESS VAR 1	-	1		
	Process variable 1				
	 Defined by parameters i 	n Group 34: Panel display	-		
0138	PROCESS VAR 2	-	1		
	Process variable 2				
	 Defined by parameters in 	n Group 34: Panel display	-		
0139	PROCESS VAR 3	-	1		
	Process variable 3				
	 Defined by parameters i 	n Group 34: Panel display	, -		
0140	RUN TIME	0 499.99 kh	0.01 kh	0 kh	
	The drive's accumulated rureset.	unning time in thousands o	of hours (kh). Ca	innot be	
0141	MWH COUNTER	0 65535 MWh	1 MWh	-	
	The drive's accumulated p	ower consumption in mega	watt hours. Car	not be reset	
0142	REVOLUTION CNTR	0 65535 Mrev	1	0	
		revolutions in millions of re /N keys simultaneously wh		,	
0143	DRIVE ON TIME HI	0 65535 days	1 day	0	
	The drive's accumulated p	ower-on-time in days. Can	not be reset.		
0144	DRIVE ON TIME LO	00.00.00 23:59:58	2 s	0	
	The drive's accumulated p seconds).	ower-on-time in 2 second	ticks (30 ticks =	60	
	Shown in format hh.mm	.SS.			
	 Cannot be reset. 				
0145	MOTOR TEMP	-10200 °C/	1	0	
		05000 Ohm / 01			
	Motor temperature in Cels	ius / PTC resistance in Oh	ms.		
	 Applies only if motor ten SENSOR TYPE. 	nperature sensor is set up.	See parameter	3501	
	DID 001111111111111111111111111111111111				
0158	PID COMM VALUE 1				

	Group 01: Operating data					
Code	Description	Range	Resolution	Default	S	
0159	PID COMM VALUE 2					
	Data received from fieldbus fo	r PID control (PID1	and PID2).			
0160	DI 1-5 STATUS					
	Status of digital inputs. Example: 10000 = DI1 is on, I	DI2DI5 are off.				
0161	PULSE INPUT FREQ		1 = 1 Hz			
	Value of frequency input in Hz	-				
0162	RO STATUS		1 = 1			
	Status of relay output 1.1 = RC	0 is energized, 0 =	RO is de-energized	=		
0163	TO STATUS		1 = 1			
	Status of transistor output whe	en transistor output	is used as a digital	output.		
0164	TO FREQUENCY		1 = 1 Hz			
	Transistor output frequency, w	hen transistor outp	ut is used as a frequ	uency output		
0173	RO 2-4 STATUS					
	Status of the relays in the Rela Relay Output Extension Modu				1	
	Example: 100 = RO 2 is on, R	RO3 and RO 4 are	off.			
0174	SAVED KWH	0.0 999.9 kWh				
	Energy saved in kWh compare directly to the supply. See the	0,	ed when the load is	connected		
	The counter value is accum over and starts again from 0		999.9 after which t	he counter ro	olls	
	Can be reset with paramete at the same time).	r 4509 ENERGY R	ESET (resets all en	ergy calculat	ors	
	See group Group 45: Energ	y saving.				
0175	SAVED MWH	0 65535 MWh				
	Energy saved in MWh compar directly to the supply. See the		sed when the load is	connected		
	The counter value is accum over and starts again from 0		65535 after which	the counter r	olls	
	Can be reset with paramete at the same time).	r 4509 ENERGY R	ESET (resets all en	ergy calculat	ors	
	See group Group 45: Energ	gy saving.				

	Group 01: Operating data					
Code	Description	Range	Resolution	Default	S	
0176	SAVED AMOUNT 1	0.0 999.9				
	Energy saved in local curre 1000). See the note on pag	• (he total saved ene	rgy is divided	d by	
	 To find out the total saved energy in currency units, add the value of parameter 0177 SAVED AMOUNT 2 multiplied by 1000 to the value of parameter 0176. 			r		
	Example: 0176 SAVED AMOUNT 1 = 0177 SAVED AMOUNT 2 = Total saved energy = 5 * 10	5	urrency units.			
	The counter value is acciover).	umulated till it reaches	999.9 (the counter	does not rol	II	
	 Can be reset with parame at the same time). 	eter 4509 ENERGY RE	ESET (resets all en	ergy calcula	tors	
	 Local energy price is set 	with parameter 4502 E	NERGY PRICE.			
	See group Group 45: End	ergy saving.				
0177	SAVED AMOUNT 2	065535				
	Energy saved in local curre means 5000 currency units	•	•	ple, value 5		
	 The counter value is accurate over). 	umulated till it reaches	65535 (the counte	r does not ro	oll	
	See parameter 0176 SAV	/ED AMOUNT 1.				
0178	SAVED CO2	0 6553.5 tn				
	Reduction on carbon dioxid	e emissions in tn. See	the note on page	238.		
	 The counter value is accurate over). 	umulated till it reaches	6553.5 (the counted	er does not ro	oll	
	 Can be reset with parame at the same time). 	eter 4509 ENERGY RE	ESET (resets all en	ergy calcula	tors	
	 CO2 conversion factor is 	set with parameter 45	07 CO2 CONV FA	CTOR.		
	See group Group 45: End	ergy saving				

■ Group 03: FB actual signals

This group monitors fieldbus communications.

		Group 03: FB actua	l signals			
Code	Descrip	tion Range	Resolution Default S			
0301	FB CM	D WORD 1 -				
	Read-or	nly copy of the Fieldbus command wo	ord 1.			
	• The fi	eldbus command is the principal mea	ns for controlling the drive from a			
		fieldbus controller. The command consists of two Command words. Bit-coded instructions in the Command words switch the drive between states.				
	EXT2	ntrol the drive, using the Command w) must be active and set to COMM. (S 002 EXT2 COMMANDS.)	ords, an external location (EXT1 or ee parameters 1001 EXT1 COMMANDS			
	The control panel displays the word in hex. For example, all zeros and a 1 in Bit 0 displays as 0001. All zeros and a 1 in Bit 15 displays as 8000.					
	Bit #	0301 FB CMD WORD 1	0302 FB CMD WORD 2			
	0	STOP	FBLOCAL_CTL			
	1	START	FBLOCAL_REF			
	2	REVERSE	START_DISABLE1			
	3	LOCAL	START_DISABLE2			
	4	RESET	Reserved			
	5	EXT2	Reserved			
	6	RUN_DISABLE	Reserved			
	7	STPMODE_R	Reserved			
	8	STPMODE_EM	Reserved			
	9	STPMODE_C	Reserved			
	10	RAMP_2	Reserved			
	11	RAMP_OUT_0	REF_CONST			
	12	RAMP_HOLD	REF_AVE			
	13	RAMP_IN_0	LINK_ON			
	14	RREQ_LOCALLOC	REQ_STARTINH			
	15	TORQLIM2	OFF_INTERLOCK			
0302	FB CM	D WORD 2 -				
		nly copy of the Fieldbus command wo	ord 2			
		parameter 0301 FB CMD WORD 1.				

	Group 03: FB actual signals						
Code	Descri	otion	Range	Resolution	Default	S	
0303	FB ST	S WORD 1	-	1	- hex		
	Read-o	nly copy of the Status word	1.				
	_	drive sends status informati Status words.	on to the fie	eldbus controller. The st	atus consist	s of	
	Bit#	0303 STS CMD WORD 1		0304 FB STS WORD 2			
	0 READY			ALARM			
	1	ENABLED		REQ_MAINT			
	2	STARTED		DIRLOCK			
	3	RUNNING		LOCALLOCK			
	4	ZERO_SPEED		CTL_MODE			
	5	ACCELERATE		Reserved			
	6	DECELERATE		Reserved			
	7	AT_SETPOINT		Reserved			
	8	LIMIT		Reserved			
	9	SUPERVISION		Reserved			
	10	REV_REF		REQ_CTL			
	11	REV_ACT		REQ_REF1			
	12	PANEL_LOCAL		REQ_REF2			
	13	FIELDBUS_LOCAL		REQ_REF2EXT			
	14	EXT2_ACT		ACK_STARTINH			
	15	FAULT		ACK_OFF_ILCK			
0304	FB ST	S WORD 2	-	1	- hex		
		nly copy of the Status word					
	• See	parameter 0303 FB STS W	ORD 1.				

ode	Descri	<u> </u>	03: FB actual signa	Resolution	Default	9
05		T WORD 1	-	1	0000 hex	•
00			ord 1	•	OOOO HEX	
		only copy of the Fault w n a fault is active, the c		s active fault is	aat in tha Fau	.14
	word	•	orresponding bit for the	active fault is	set in the Fat	uit
		n fault has a dedicated l	bit allocated within Fau	lt words		
		chapter <i>Fault tracing</i> or			ts	
		ntrol panel displays the		•		n
		s a 0001. All zeros and			10 0 1 III DIC (•
	Bit #	0305 FAULT WORD 1	0306 FAULT WORD 2	0207 EALI	LT WORD 3	
	0	OVERCURRENT	Reserved	EFB 1	LI WORD 3	
	1	DC OVERVOLT	THERM FAIL	EFB 1		
	2	DEV OVERTEMP	Reserved	EFB 2		
	3	SHORT CIRC	Reserved	INCOMPA	TIDLE CW	
	1		CURR MEAS		AD CURVE	
	4	Reserved				
	5	DC UNDERVOLT	SUPPLY PHASE		N EXTENSION	١
	6	Al1 LOSS	Reserved	INLET VE		
	7	AI2 LOSS	OVERSPEED		ERY HIGH	
	8	MOT OVERTEMP	Reserved	INLET LO		
	9	PANEL LOSS	DRIVE ID	OUTLET H		
	10	Reserved	CONFIG FILE	System en		
	11	MOTOR STALL	SERIAL 1 ERR	System er		
	12	Reserved	EFB CON FILE	System en		
	13	EXT FLT 1	FORCE TRIP	System en	ror	
	14	EXT FLT 2	MOTOR PHASE	System en	ror	
		EARTH FAULT	OUTP WIRING	Parameter		

A16-bit data word. For the possible causes and remedies and fieldbus equivalents, see chapter Fault tracing on page 339. See parameter 0305 FAULT WORD 1.

0307 **FAULT WORD 3**

A16-bit data word. For the possible causes and remedies and fieldbus equivalents, see chapter Fault tracing on page 339. See parameter 0305 FAULT WORD 1.

			Group 03:	FB actua	l signals		
Code	Descri	otion		Range	Resolution	on Default	
0308	ALAR	M WORD 1		-	1	0000 hex	
	Read-o	nly copy of th	ne ALARM WO	RD 1.			
	• When	n a fault is ac	ctive, the corres	ponding b	it for the active faul	t is set in the Fa	ault
	word	S.					
	 Each 	fault has a c	dedicated bit all	ocated wit	hin Fault words.		
	l l		ntil the whole al	arm word	is reset. (Reset by	writing zero to t	he
	word	,	diamina da a co	and the lands	F		D:4
		•			For example, all zo the total to the total total total total to the total tota		BIL
	Cone	spond to out	71. All 20103 all	uailiibi	t 13 correspond to	00000.	
	Bit#	0308 ALARN	M WORD 1		0309 ALARM WOR	RD 2	
	0	OVERCURR	ENT		OFF BUTTON		
	1	OVERVOLTA	AGE		PID SLEEP		
	2	UNDERVOL	TAGE		Reserved		
	3	DIRLOCK			OVERRIDE		
	4	I/O COMM			START ENABLE 1	MISSING	
	5	Al1 LOSS			START ENABLE 2	MISSING	
	6	AI2 LOSS			EMERGENCY STO)P	
	7	PANEL LOSS	3		Reserved		
	8	DEVICE OVE	ERTEMP		FIRST START		
	9	MOT OVERT			Reserved		
	10	UNDERLOAI	D		USER LOAD CUR\	/E	
	11	MOTOR STA			START DELAY		
	12	AUTORESE			Reserved		
	13	PFA AUTOC			INLET LOW		
	14	PFA INTERL	OCK		INLET HIGH		
	15	Reserved			PIPE FILL		
0309	AI AR	M WORD 2			1	0000 hex	
	Read-o	nly copy of th	ne ALARM WO	RD 3.			
		, ,,	308 ALARM W				
0310		M WORD 3		-	1	0000 hex	
	A 16-bit data word. For the possible cause			e causes a	and remedies and fi	eldbus equivale	ents
	see chapter <i>Fault tracing</i> on page 339.					o.a.o.a.o.aqaa	,,,,,
	An alan	m can be res	et by resetting	the whole	alarm word: Write	zero to the word	d.
		Bit #					
		0	INLET VERY LO	OW			
		1	OUTLET VERY	HIGH			
	1	215	Reserved				

Group 04: Fault history

This group stores a recent history of the faults reported by the drive.

		Group 04: Fault history	y						
Code	Description	Range	Resolution	Default	S				
0401	LAST FAULT	Fault code text	1	0					
	0 = Clear the fault histor	y (on panel = NO RECORD).						
	n = Fault code of the las	t recorded fault.							
	the fault codes and na	layed as a name. See chapt ames. The fault name shown g name in the fault listing, w play.	for this paramete	er may be sh	orter				
0402	FAULT TIME 1	Date dd.mm.yy / power-on days	1	0					
	The day on which the la	st fault occurred. Either as:							
	A date – if real time cl	lock is operating.							
	 The number of days a 	after power on – if real time	clock is not used	, or was not s	set.				
0403	FAULT TIME 2	Time hh:mm:ss	2 s	0					
	The time at which the la	st fault occurred. Either as:							
	 Real time, in format h 	Real time, in format hh:mm:ss – if real time clock is operating.							
	• The time since power on (less the whole days reported in parameter 0402 FAULT TIME 1), in format hh:mm:ss – if real time clock is not used, or was not set.								
	(minus the whole days s	atrol panel: Time elapsed afte stated by signal <i>0402 FAULT</i> equals 17 minutes and 8 se	TIME 1). 30 tick	s = 60 secor					
0404	SPEED AT FLT	-	1 rpm	0					
	The motor speed (rpm)	at the time the last fault occ	urred.						
0405	FREQ AT FLT	-	0.1 Hz	0.0					
	The frequency (Hz) at the	ne time the last fault occurre	d.						
0406	VOLTAGE AT FLT	-	0.1 V	0.0					
	The DC bus voltage (V)	at the time the last fault occ	urred.						
0407	CURRENT AT FLT	-	0.1 A	0.0					
	The motor current (A) at	the time the last fault occur	red.						
0408	TORQUE AT FLT	-	0.1%	0.0					
	The motor torque (%) at	the time the last fault occur	red.						
0409	STATUS AT FLT	-	1	0000 hex					
	The drive status (hex co	de word) at the time the las	t fault occurred.						
0412	PREVIOUS FAULT 1	Fault code text	1	0					
	Fault code of the second	d last fault. Read-only							
0413	PREVIOUS FAULT 2	Fault code text	1	0					
		ist fault. Read-only.							

	Group 04: Fault history							
Code	Description	Range	Resolution	Default	S			
0414	DI 1-5 AT FLT							
	Status of digital inputs E Example: 10000 = DI1	DI15 at the time the latest is on, DI2DI5 are off.	t fault occurred (bir	nary).				

Group 10: Start/Stop/Dir

This group:

- Defines external sources (EXT1, and EXT2) for commands that enable start, stop and direction changes.
- Locks direction or enables direction control. To select between the two external locations use the next group, parameter 1102 EXT1/EXT2 SEL.

	Gro	up 10: Start/Stop	/Dir						
Code	Description	Range	Resolution	Default	S				
1001	EXT1 COMMANDS	014	1	1	✓				
	Defines external control loca direction commands.	tion 1 (EXT1) – the	configuration of start	t, stop and					
	0 = NOT SEL – No external start, stop and direction command source. 1 = DI1 – Two-wire Start/Stop.								
	Start/Stop is through dig Stop).	• Start/Stop is through digital input DI1 (DI1 activated = Start; DI1 de-activated =							
 Parameter 1003 DIRECTION defines the direction. Selecting 1003 = 3 (r is the same as 1003 = 1 (fwd). 									
	2 = DI1, 2 – Two-wire Start/S								
	Start/Stop is through digital input DI1 (DI1 activated = Start; DI1 de-activated = Stop).								
	Direction control (requires parameter 1003 = 3 (request)) is through digital input DI2 (DI2 activated = Reverse; de-activated = Forward).								
	3 = DI1P, 2P - Three-wire St	art/Stop.							
	 Start/Stop commands a "pulse"). 	re through momenta	ry push-buttons (the	P stands fo	r				
	Start is through a normal to start the drive, the dig.	gital input 2 must be	activated prior the p	l input 1. In o ulse in 1.	order				
	Connect multiple Start p	•							
	Stop is through a normal	, ,		tal input 2.					
	 Connect multiple Stop p Parameter 1003 DIRECT 			002 - 2					
	(REQUEST) is the same			103 = 3					
	4 = DI1P, 2P, 3 - Three-wire	Start/Stop, Direction	, I.						
	 Start/Stop commands a DI1P, 2P. 	re through momenta	ry push-buttons, as	described fo	r				
	Direction control (requir input DI3 (DI3 activated)			hrough digita	al				


	Group 10: Start/	Stop/Dir	
Code	Description Range	Resolution	Default S
	 5 = DI1P, 2P, 3P - Start Forward, Start Reve Start and Direction commands are give momentary push-buttons (the P stands 	n simultaneously with t	wo separate
	Start Forward command is through a nodigital input DI1. To start the drive, the the pulse in DI1.	ormally open push-butto	on connected to e activated during
	 Start Reverse command is through a nedigital input DI2. To start the drive, the copulse in DI2. 		
	Connect multiple Start push-buttons in Stop is through a normally closed push Connect multiple Stop push-buttons in	-button connected to di	gital input DI3.
	 Requires parameter 1003 = 3 (REQUE 8 = KEYPAD – Control Panel. 		
	Start/Stop and Direction commands are active.	through the control pa	nel when EXT1 is
	Direction control requires parameter 10 = DI1F, 2R - Start/Stop/Direction comman	ds through DI1 and DI2	2 combinations.
	Start forward = DI1 activated and DI2 d Start reverse = DI1 de-activated and DI Start reverse = DI1 de-activated and DI2 activated activate	2 activated.	
	 Stop = both DI1 and DI2 activated, or b Requires parameter 1003 = 3 (REQUE 		
	10 = COMM – Assigns the fieldbus Comma and direction commands.	nd word as the source t	•
	Bits 0,1, 2 of Command word 1 (parame start/stop and direction commands.		RD 1) activates the
	 See Fieldbus user's manual for detailer 11 = TIMER 1 – Assigns Start/Stop control to Timer de-activated = STOP). See Group 	Timer 1 (Timer activa	ted = START;
	1214 = TIMER 2 4 – Assigns Start/Stop See Timer Function 1 above.		
	20 = DI5 – Start and stop through digital inpu according to parameter 1003 DIRECTI	ON (setting REQUEST	= FORWARD).
	21 = DI5, 4 – Start and stop through digital i through digital input DI4. 0 = forward, 1 1003 DIRECTION must be REQUEST.	nput DI5. 0 = stop, 1 = = reverse. To control di	start. Direction rection, parameter
	27 = SUPRV1 OVER – Start when the value supervision high limit. Stop when the value parameter <i>Group 32: Supervision</i> .		
	28 = SUPRV1 UNDER – Start when the value below the supervision low limit. Stop when parameter <i>Group 32: Supervision</i> .	ue of the supervision pa en the value goes over	arameter 1 goes the high limit. See
	29 = SUPRV2 OVER – See selection SUPR		
	30 = SUPRV2 UNDER – See selection SUF 31 = SUPRV3 OVER – See selection SUPR		
	32 = SUPRV3 UNDER – See selection SUF		
	33 = SUP10VER+DI2 – Start and stop as for digital input DI2. 0 = forward, 1 = reverse DIRECTION setting must be REQUES	se. To control direction, T.	parameter 1003
	34 = SUP1 UDR+DI2 – Start and stop as for digital input DI2. 0 = forward, 1 = revers DIRECTION setting must be REQUES	se. To control direction,	ection through parameter 1003

	Group 10: Start/Stop/Dir							
Code	Description	Range	Resolution	Default	S			
1002	EXT2 COMMANDS	014	1	1	✓			
	Defines external control location 2 (EXT2) – the configuration of start, stop and direction commands.							
	See parameter 1001 EXT:	1 COMMANDS abov	e.					
1003	DIRECTION	13	1	1	✓			
	Defines the control of motor	rotation direction.						
	1 = FORWARD – Rotation is	fixed in the forward	direction.					
	2 = REVERSE – Rotation is	fixed in the reverse of	direction.					
	3 = REQUEST – Rotation dir	ection can be chang	ged on command.					


Group 11: Reference select

This group defines:

- How the drive selects between command sources.
- Characteristics and sources for REF1 and REF2.



Code	Description	oup 11: Reference s	Resolution	Default	S		
1103	•	Range 021	Resolution	Delault	3		
1103	REF1 SELECT		1	1	•		
	Selects the signal source t	for external reference R	REF1.				
	0 = KEYPAD – Defines the						
	1 = Al1 – Defines analog i	nput 1 (Al1) as the refe	rence source.				
	2 = Al2 – Defines analog i	. , ,					
	3 = AI1/JOYST – Defines analog input 1 (AI1), configured for joystick operation, as the reference source.						
	 The minimum input si direction. Define the r 	gnal runs the drive at th ninimum using parame			erse		
	The maximum input s direction. Define the r	signal runs the drive at i	maximum reference eter 1105 REF1 MA	in the forwa $\frac{1}{x}$.	ard		
	Requires parameter 1	1103 = 3 (request).					
	EXT REF 1 MAX 春 — -						
			'				



WARNING! Because the low end of the reference range commands full reverse operation, do not use 0 V as the lower end of the reference range. Doing so means that if the control signal is lost (which is a 0 V input) the result is full reverse operation. Instead, use the following set-up so that loss of the analog input triggers a fault, stopping the drive:

- Set parameter 1301 MINIMUM AI1 (1304 MINIMUM AI2) at 20% (2 V or 4 mA).
- Set parameter 3021 AI1 FAULT LIMIT to a value 5% or higher.
- Set parameter 3001 AI<MIN FUNCTION to 1 (FAULT).

Group 11: Reference select							
Code	Description	Range	Resolution	Default	S		
	4 1 1 1 5	• "					

Analog Input Reference Correction

Parameter values 9, 10, and 14...17 use the formula in the following table.

Value setting	Calculation of the Al reference
C + B	C value + (B value - 50% of reference value)
C * B	C value * (B value / 50% of reference value)
C - B	(C value + 50% of reference value) - B value
C/B	(C value * 50% of reference value) / B value

Where:

 C = Main Reference value (= COMM for values 9. 10 and = 1 for values 14...17).

B = Correcting reference (= Al1 for values 9. 10 and = AI2 for values 14...17).

120 17 (/) 100 80 60 40 20 16 (-) O 100%

Example:


The figure shows the reference source curves for value

settings 9, 10, and 14...17, where:

- C = 25%.
- Parameter 4012 SETPOINT MIN = 0.
- Parameter 4013 SETPOINT MAX = 0.
- B varies along the horizontal axis.

REF1 SELECT

- 20 = KEYPAD(RNC) Defines the control panel as the reference source. A Stop command resets the reference to zero (R stands for reset.). Changing the control source (EXT1 to EXT2, EXT2 to EXT1) does not copy the reference.
- 21 = KEYPAD(NC) Defines the control panel as the reference source. A Stop command does not reset the reference to zero. The reference is stored. Changing the control source (EXT1 to EXT2, EXT2 to EXT1) does not copy the reference.
- 30 = DI4U,5D See selection DI3U,4D.
- 31 = DI4U,5D(NC) See selection DI3U,4D(NC).
- 32 = FREQ INPUT Frequency input.



	G	roup 11: Reference sele	ect			
Code	Description	Range	Resolution	Default	S	
1107	REF2 MIN	0.0 100.0% (torque: 0 600%)	0.1%	0.0%		
	Sets the minimum for ex	kternal reference 2.				
	The minimum analog input signal (in volts or amps) corresponds to REF2 MIN ir					
	 Parameter 1301 MINIMUM Al1 or 1304 MINIMUM Al2 sets the minimum analog input signal. 					
	 This parameter sets t 	he minimum frequency refer	ence.			
	The value is a percent	tage of the:				
	maximum frequencemaximum processnominal torque.	, ,				
1108	REF2 MAX	0.0 100.0%	0.1%	100.0%		
		(torque: 0 600%)				
	Sets the maximum for e	xternal reference 2.				
	 The maximum analog %. 	input signal (in volts or amp	os) corresponds t	o REF2 MA)	K in	
	 Parameter 1302 MAX input signal. 	CIMUM AI1 or 1305 MAXIMU	IM AI2 sets the m	naximum ana	alog	
	This parameter sets to	he maximum frequency refe	rence.			
	The value is a percent	tage of the:				
	maximum frequence	•				
	maximum process	reference				
	 nominal torque 					

Group 12: Constant speeds

This group defines a set of constant speeds. In general:

- You can program up to 7 constant speeds, ranging from 0 ... 500 Hz or 0 ... 30000 rpm.
- · Values must be positive (No negative speed values for constant speeds).
- · Constant speed selections are ignored if:
 - the torque control is active, or
 - the process PID reference is followed, or
 - the drive is in local control mode, or
 - PFA (Pump and fan alternation) is active

Note: Parameter 1208 CONST SPEED 7 acts also as a so-called fault speed which may be activated if the control signal is lost. For example, see parameters 3001 AI<MIN FUNCTION, 3002 PANEL COMM ERR and 3018 COMM FAULT FUNC.

Group 12: Constant speeds						
Code	Description	Range	Resolution	Default	S	
1201	CONST SPEED SEL	-1419	1	3	✓	

Defines the digital inputs used to select Constant speeds. See general comments in the introduction.

- 0 = NOT SEL Disables the constant speed function.
- 1 = DI1 Selects Constant speed 1 with digital input 1.
 - Digital input activated = Constant speed 1 activated.
- 2...5 = DI2...DI5 Selects Constant speed 1 with digital input DI2...DI5. See above.
- 7 = DI1,2 Selects one of three Constant speeds (1...3) using DI1 and DI2.
 - Uses two digital inputs, as defined below (0 = DI de-activated, 1 = DI activated):

DI1	DI2	Function
0	0	No constant speed
1	0	Constant speed 1 (1202)
0	1	Constant speed 2 (1203)
1	1	Constant speed 3 (1204)

- · Can be set up as a so-called fault speed, which is activated if the control signal is lost. Refer to parameter 3001 AI<MIN FUNCTION and parameter 3002 PANEL COMM ERR.
- 8 = DI2,3 Selects one of three Constant speeds (1...3) using DI2 and DI3.
 - See above (DI1,2) for code.
- 9 = DI3.4 Selects one of three Constant speeds (1...3) using DI3 and DI4.
 - · See above (DI1,2) for code.
- 10 = DI4,5 Selects one of three Constant speeds (1...3) using 4 and 5.
 - See above (DI1.2) for code.
- 12 = DI1,2,3 Selects one of seven Constant speeds (1...7) using DI1, DI2 and DI3.
 - Uses three digital inputs, as defined below (0 = DI de-activated, 1 = DI activated):

DI1	DI2	DI3	Function
0	0	0	No constant speed
1	0	0	Constant speed 1 (1202)
0	1	0	Constant speed 2 (1203)
1	1	0	Constant speed 3 (1204)
0	0	1	Constant speed 4 (1205)
1	0	1	Constant speed 5 (1206)
0	1	1	Constant speed 6 (1207)
1	1	1	Constant speed 7 (1208)

- 13 = DI3,4,5 Selects one of seven Constant speeds (1...7) using DI3, DI4 and DI5.
 - See above (DI1,2,3) for code.

			<u>. </u>			
Coc	le	Description	Range	Resolution	Default	S
		TIMER 1), timer 3 (if th	constant speed 1, constant the state of, eg, timer 1 pe parameter value is 17 = 1 meter 1209 and Group 36	(if the paramete TIMER 3) etc,	er value is 15 and the cons	i = stant

Group 12: Constant speeds

1201 =	15	16	17	18	Reference		
Timer:	1	2	3	4	1209 = 1	1209 = 2	
Timer	0				External reference	Constant speed 1	
State	1			Constant speed 1	Constant speed 2		

- 19 = TIMER 1 & 2 Selects a constant speed or the external reference depending on the state of timers 1 and 2 and the constant speed mode. See parameter 1209 and Group 36: Timed functions.
- -1 = DI1(INV) Selects Constant speed 1 with digital input DI1.
 - Inverse operation: Digital input de-activated = Constant speed 1 activated.
- -2 ... 5 = DI2(INV)...DI5(INV) Selects Constant speed 1 with digital input. See above.
- -7 = DI1,2(INV) Selects one of three Constant speeds (1...3) using DI1 and DI2.
 - Inverse operation uses two digital inputs, as defined below (0 = DI de-activated. 1 = DI activated):

DI1	DI2	Function
1	1	No constant speed
0	1	Constant speed 1 (1202)
1	0	Constant speed 2 (1203)
0	0	Constant speed 3 (1204)

- -8 = DI2,3(INV) Selects one of three Constant speeds (1...3) using DI2 and DI3.
 - · See above (DI1,2(INV)) for code.
- -9 = DI3,4(INV) Selects one of three Constant speeds (1...3) using DI3 and DI4.
 - See above (DI1,2(INV)) for code.
- -10 = DI4,5(INV) Selects one of three Constant speeds (1...3) using DI4 and DI5.
 - · See above (DI1,2(INV)) for code.

	Group 12: Constant speeds						
Code	Descripti	on		Range	Resolution	Default S	
	DI3.		on uses th	one of seven constant s	. ,	,	
	DI1	DI2	DI3	Function			
	1	1	1	No constant speed			
	0	1	1	Constant speed 1 (1202)			
	1	0	1	Constant speed 2 (1203)			
	0	0	1	Constant speed 3 (1204)			
	1	1	0	Constant speed 4 (1205)			
	0	1	0	Constant speed 5 (1206)			
	1	0	0	Constant speed 6 (1207)			
	0	0	0	Constant speed 7 (1208)			
	DI5.	, ,		one of seven constant s i) for code.	peeds (13) us	sing DI3, DI4 and	
1202	CONST	SPEED 1		0.0 500.0 Hz	0.1 Hz	6.0 (US)	
	Defines co	onstant sp	eed 1 (dri	ve output frequency).			
1203	CONST	SPEED 2		0.0 500.0 Hz	0.1 Hz	12.0	
	Defines co	onstant sp	eed 2 (dri	ve output frequency).			
1204	CONST	SPEED 3	1	0.0 500.0 Hz	0.1 Hz	18.0	
	Defines co	onstant sp	eed 3 (dri	ve output frequency).			
1205	CONST	SPEED 4		0.0 500.0 Hz	0.1 Hz	24.0	
	Defines co	onstant sp	eed 4 (dri	ve output frequency).			
1206	CONST	SPEED 5		0.0 500.0 Hz	0.1 Hz	30.0	
	Defines co	onstant sp	eed 5 (dri	ve output frequency).			
1207	CONST	SPEED 6	i	0.0 500.0 Hz	0.1 Hz	48.0	
	Defines co	onstant sp	eed 6 (dri	ve output frequency).			
1208	CONST	SPEED 7	1	0.0 500.0 Hz	0.1 Hz	60.0	
	Defines co	onstant sp	eed 7 (dri	ve output frequency).			

Group 12: Constant speeds						
Code	Description	Range	Resolution	Default	S	
1209	TIMED MODE SEL	12	1	2	✓	

Defines timer activated, constant speed mode. Timer can be used to change between external reference and a maximum of three constant speeds, or to change between a maximum of 4 selectable speeds, in other words, constant speeds 1,2,3 and 4.

1 = EXT/CS1/2/3 – Selects an external speed when no timer is active, selects Constant speed 1 when Timer 1 is active, selects Constant speed 2 when Timer 2 is active and selects Constant speed 3 when both Timers 1 and 2 are active.

TIMER1	TIMER2	Function
0	0	External reference
1	0	Constant speed 1 (1202)
0	1	Constant speed 2 (1203)
1	1	Constant speed 3 (1204)

2 = CS1/2/3/4 – Selects Constant speed 1 when no timer is active, selects Constant speed 2 when Timer 1 is active, selects Constant speed 3 when Timer 2 is active, selects Constant speed 4 when both timers are active.

TIMER1	TIMER2	Function
0	0	Constant speed 1 (1202)
1	0	Constant speed 2 (1203)
0	1	Constant speed 3 (1204)
1	1	Constant speed 4 (1205)

■ Group 13: Analogue inputs

This group defines the limits and the filtering for analog inputs.

Code 1301		Range 0.0 100.0%	Resolution 0.1%	Default S				
1301	Defines the minimum value	0.0 100.0%	0.1%					
			0.170	20.0%				
	D-6	Defines the minimum value of the analog input.						
	Define value as a percent	t of the full analog signa	al range. See exa	mple below.				
	The minimum analog input 1107 REF2 MIN.	ut signal corresponds to	o parameter 1104	REF1 MIN or				
	MINIMUM AI cannot be greater than MAXIMUM AI.							
	 These parameters (refere offset adjustment for the remaining of the remaining	•	nd max. settings) រ	provide scale and				
	See figure at parameter 1104 REF1 MIN.							
	Example: To set the minimu	um analog input value t	to 4 mA:					
	 Configure the analog input 	ut for 0 20 mA currer	nt signal.					
	• Calculate the minimum (4 (20 mA) = 4 mA / 20 mA	, .	ıll range					
1302	MAXIMUM AI1	0.0 100.0%	0.1%	20.0%				
	Defines the maximum value	of the analog input.						
	Define value as a percent of the full analog signal range.							
	 The maximum analog inp MAX. 	ut signal corresponds t	to 1105 REF1 MA.	X or 1108 REF2				
	 See figure at parameter 1 	104 REF1 MIN.						
1303	FILTER AI1	0.0 10.0 s	0.1 s	0.1 s				
	Defines the filter time constainput 1 (Al1).	ant for analog %	†	Unfiltered signal				
	 The filtered signal reache change within the time sp 		+ -					
		63	† - <i>/</i>	Filtered signal				
			/;	· morea eigna				
				t				
			Time constant					
1304	MINIMUM AI2	0.0 100.0%	0.1%	20.0%				
	Defines the minimum value	of the analog input.						
	See parameter 1301 MIN							
1305	MAXIMUM AI2	0.0 100.0%	0.1%	100.0%				
	Defines the maximum value of the analog input.							
	See parameter 1302 MAX	KIMUM AI1 above.						
1306	FILTER AI2	0.0 10.0 s	0.1 s	0.1 s				
	Defines the filter time consta • See parameter 1303 FILT	.	AI2).					

■ Group 14: Relay outputs

This group defines the condition that activates each of the relay outputs.

	Gro	up 14: Relay out	puts			
Code	Description	Range	Resolution	Default	S	
1401	RELAY OUTPUT 1	045	1	1		
	Defines the event or condition	n that activates rela	y 1 – what relay outp	out 1 means.		
	0 = NOT SEL - Relay is not	used and is de-ene	rgized.			
	1 = READY – Energize relay		-	es:		
	 Run enable signal present 	ent.				
	No faults exist.					
	Supply voltage is within	•				
	 Emergency Stop comm. 2 = RUN – Energize relay wl 		nina			
	3 = FAULT (-1) – Energize re			s when a fai	ılt	
	occurs.	siay when power is a	applied. De-ellergize	s wiich a lac	111	
	4 = FAULT – Energize relay when a fault is active.					
	5 = ALARM – Energize relay when an alarm is active.					
	 6 = REVERSED – Energize relay when motor rotates in reverse direction. 7 = STARTED – Energize relay when drive receives a start command (even if Enable signal is not present). De-energized relay when drive receives a scommand or a fault occurs. 					
	8 = SUPRV1 OVER - Energi	supervised parameter	r (<mark>3201</mark>) exce	eeds		
	the limit (3203).		- 400			
	 See Group 32: Supervis 9 = SUPRV1 UNDER – Energy 			tor (3201) dr	one	
	below the limit (3202).	rgize relay wrietring	it supervised parame	(0201) di	ops	
	See Group 32: Supervis					
	10 = SUPRV2 OVER – Ener exceeds the limit (3206)		cond supervised para	meter (3204)	
	See Group 32: Supervis	,	e 198			
	11 = SUPRV2 UNDER – Ene			rameter (320) 4)	
	drops below the limit (3.	205).	·	•	,	
	See Group 32: Supervis					
	12 = SUPRV3 OVER – Ener exceeds the limit (3209)	gize relay when thir	d supervised parame	eter (3207)		
	See Group 32: Supervis		e 198.			
	13 = SUPRV3 UNDER - End	ergize relay when th	nird supervised paran	neter (3207)		
	drops below the limit (3					
	See Group 32: Supervis					
	14 = AT SET POINT – Energy reference frequency.	gize relay when the	output frequency is e	equal to the		
	15 = FAULT (RST) – Energize relay when the drive is in a fault condition and will re					
	after the programmed auto-reset delay.					
	See parameter 3103 DE TIT/ALABA Energias		alarm agg::==			
	16 = FLT/ALARM – Energize					
	18 = REF 2 SEL – Energize	•				
	19 = CONST FREQ- Energi			ted.		

- 30 = PID SLEEP Energize relay when the PID sleep function is active.
- 31 = PFA Use relay to start/stop motor in PFA control (See *Group 81: PFA control*).

s

- · Use this option only when PFA control is used.
- Selection activated / deactivated when drive is not running.
- 32 = AUTOCHANGE Energize relay when the PFA autochange operation is performed.
 - · Use this option only when PFA control is used.
- 33 = FLUX READY Energize relay when the motor is magnetized and able to supply nominal torque (motor has reached nominal magnetizing).
- 34 = USER MACRO S2 Energize relay when User Parameter Set 2 is active.
- 35 = COMM Energize relay based on input from fieldbus communication.
 - Fieldbus writes binary code in parameter 0134 COMM RO WORD that can energizes relay 1...relay 4 according to the following:

Parameter 0134	Binary	RO4	RO3	RO2	RO1
0	000000	0	0	0	0
1	000001	0	0	0	1
2	000010	0	0	1	0
3	000011	0	0	1	1
4	000100	0	1	0	0
562					
63	111111	1	1	1	1

0 = De-energize relay, 1 = Energize relay.

		Group 14: Rela	y output	S		
Code	Description	Rang	е	Resolut	ion De	fault S
	36 = COMM(-1) – Ene • Fieldbus writes bit 4 according to the	nary code in param				
	Parameter 0134	Binary	RO4	RO3	RO2	RO1
	0	000000	1	1	1	1
	1	000001	1	1	1	0
	2	000010	1	1	0	1
	3	000011	1	1	0	0
	4	000100	1	0	1	1
	562					
	63	111111	0	0	0	0
4400	 37 = TIMER 1 - Energize relay when timer 1 is activated. See <i>Group 36: Timed functions</i>. 3840 = TIMER 24 - Energize relay when Timer 24 is active. See TIMER 1 above. 41 = MNT TRIG FAN - Energize relay when cooling fan counter is triggered. See <i>Group 29: Maintenance trig</i>. 42 = MNT TRIG REV - Energize relay when revolutions counter is triggered. See <i>Group 29: Maintenance trig</i>. 43 = MNT TRIG RUN - Energize relay when run time counter is triggered. See <i>Group 29: Maintenance trig</i>. 44 = MNT TRIG MWH - Energize relay when power consumption counter is triggered. See <i>Group 29: Maintenance trig</i>. 45 = OVERRIDE - Energize relay when override is activated. 46 = START DELAY - Energize relay when a start delay is active. 47 = USER LOAD C - Energize relay when a user load curve fault or alarm occurs. 				IMER 1 ed. See ed. See See <i>Group</i> is triggered. m occurs.	
1402	RELAY OUTPUT 2	045	-	1		2
	Defines the event or co		•			
4.400	See parameter 1401			utput 2 onl	y with MRE	
1403	RELAY OUTPUT 3	04	-			2
	Defines the event or considerable. See parameter 1401		-			
1404	RO 1 ON DELAY	0.0 360		0.1 s		.0 s
	Defines the switch-on relay 1. On / off delays are ig relay output of parar RELAY OUTPUT 1 in PFA.	Confinered when meter 1401	trol event —	1404	- -	1405

	G	roup 14: Relay outpu	ıts			
Code	Description	Range	Resolution	Default	S	
1405	RO 1 OFF DELAY	0.0 3600.0 s	0.1 s	0.0 s		
	Defines the switch-off dela	y for relay 1.				
	 On / off delays are ignor is set to PFA. 	ed when relay output of p	parameter 1401 RE	ELAY OUTPU	JT 1	
1406	RO 2 ON DELAY	0.0 3600.0 s	0.1 s	0.0 s		
	Defines the switch-on dela	y for relay 2.				
	See parameter 1404 RC	O 1 ON DELAY.				
1407	RO 2 OFF DELAY	0.0 3600.0 s	0.1 s	0.0 s		
	Defines the switch-on dela	y for relay 2.				
	See parameter 1405 RG	O 1 OFF DELAY.				
1408	RO 3 ON DELAY	0.0 3600.0 s	0.1 s	0.0 s		
	Defines the switch-on dela	y for relay 3.				
	See parameter 1404 RC	O 1 ON DELAY.				
1409	RO 3 OFF DELAY	0.0 3600.0 s	0.1 s	0.0 s		
	Switch-off delay for relay 3	3.				
	See parameter 1405 RG	O 1 OFF DELAY.				
1410	RELAY OUTPUT 4	045	1	0		
	Defines the event or condition that activates relay 4 – what relay output 4 means.					
	See parameter 1401 RE	ELAY OUTPUT 1.				
1413	RO 4 ON DELAY	0.0 3600.0 s	0.1 s	0.0 s		
	Defines the switch-on dela	y for relay 4.				
	See parameter 1404 RC	O 1 ON DELAY.				
1414	RO 4 OFF DELAY	0.0 3600.0 s	0.1 s	0.0 s		
	Defines the switch-off dela	y for relay 4.				
	See parameter 1405 RG	O 1 OFF DELAY.				

Group 15: Analogue outputs

This group defines the drive's analog (current signal) outputs. The drive's analog outputs can be:

- Any parameter of Group 01: Operating data.
- Limited to programmable minimum and maximum values of output current.
- Scaled (and/or inverted) by defining the minimum and maximum values of the source parameter (or content). Defining an maximum value (parameter 1503 AO1 CONTENT MAX) that is less than the content minimum value (parameter 1502 AO1 CONTENT MIN) results in an inverted output.
- Filtered.

	Grou	p 15: Analogue outp	outs		
Code	Description	Range	Resolution	Default S	5
1501	AO1 CONTENT SEL	xx	1	103	_
	Connects a drive signal to a	nalog output AO.			
	Parameter index in Group	01: Operating data. Fo	or example, 102 =	0102 SPEED	
1502	AO1 CONTENT MIN	Depends on selection	-	0.0 Hz	
1002	Sets the minimum content value. Content is the parameter selected by parameter 1501 AO1 CONTENT SEL. Minimum value refers to the minimum content value that will be converted to an analog output. These parameters (content and current min. and max. settings) provide scale and offset adjustment for the output. See the figure.	1504 AO (mA 1504 AO (m/ 1505 AO (m/	02 15	AO CONTEN	T ►
		1504			
				AO CONTEN	Ţ
		150	03	1502	
1503	AO1 CONTENT MAX Sets the maximum content Content is the parameter Maximum value refers to analog output.	selected by parameter			
1504	MINIMUM AO1	0.0 20.0 mA	0.1 mA	4.0 mA	_
	Sets the minimum output cu	irrent.			
1505	MAXIMUM AO1	0.0 20.0 mA	0.1 mA	2.0 mA	
	Sets the maximum output of				
1506	FILTER AO1	0 10 s	0.1 s	0.1 s	
	Defines the filter time constant of the filtered signal reached. See the figure in parameter	s 63% of a step change	within the time s	specified.	

■ Group 16: System controls

This group defines a variety of system level locks, resets and enables.

	Gr	oup 16: System contr	ols	
Code	Description	Range	Resolution	Default S
1601	RUN ENABLE	-67	1	0 🗸
	Selects the source of the	run enable signal.		
	0 = NOT SEL - Allows the			le signal.
	1 = DI1 – Defines digital in	nput DI1 as the run enable at be activated for run ena		
		and de-activates this digita		will coast to stop
	and not start until the	run enable signal resume	es.	•
	25 = DI2DI5 – DefineSee DI1 above.	s digital input DI2DI5 as	s the run enable s	signal.
	7 = COMM – Assigns the	fieldbus Command word	as the source for	the run enable
	signal.	d ad 4 (a a a a a a ta a 0004	4 ED OMB MODE	A) 45 45 -
	run disable signal.	d word 1 (parameter 0301	I FB CMD WORD	1) activates the
		nanual for detailed instruc		
	-1 = DI1(INV) – Defines a	0 1		signal.
		st be de-activated for run e tivates, the drive will coas		start until the run
	enable signal resume	es.	•	
	-25 = DI2(INV)DI5(IN enable signal.	NV) – Defines an inverted	digital input DI2	.DI5 as the run
	See DI1(INV) above.			
1602	PARAMETER LOCK	02	1	1
	Determines if the control p	oanel can change parame	eter values.	
	 This lock does not limit 		,	
	This lock does not limit			
	 This parameter value of parameter 1603 PASS 	• ,	correct pass code	e is entered. See
	0 = LOCKED - You canno			
	• The lock can be oper CODE.	ned by entering the valid p	ass code to paran	neter 1603 PASS
	1 = OPEN – You can use			
	2 = NOT SAVED – You ca	an use the control panel to a permanent memory.	change paramet	er values, but
		PARAM. SAVE to 1 (SAVI	E) to store change	ed parameter
1603	PASS CODE	065535	1	0
	Entering the correct pass	code allows you to chang	e the parameter l	ock.
	See parameter 1602 PA			
	 Code 358 allows you to LOCK once. 	change the value of the	parameter 1602 F	PARAMETER
	This entry reverts back	to 0 automatically		
	Tino citty reverso back	to o automatically.		

	Group	16: System co	ntrols		
Code	Description	Range	Resolution	Default	S
1604	FAULT RESET SEL	-68	1	0	
	Selects the source for the fault from the fault from the fault no longer than the fault no longer than the fault from the faul	•	signal resets the drive	e after a faul	t trip
	EYPAD – Defines the control panel as the only fault reset source. Fault reset is always possible with control panel.				
	1 = DI1 – Defines digital inputActivating the digital input		et source.		
	25 = DI2DI5 – Defines digital input DI2DI5 as a fault reset source. • See DI1 above.				
	7 = START/STOP - Defines t	he Stop command	as a fault reset source	e.	
	Do not use this option when fieldbus communication provides the start, stop and direction commands.				
	8 = COMM – Defines the field	lbus as a fault rese	et source.		
	 The Command word is s 	upplied through fie	Idbus communication	١.	
	The bit 4 of the Command word 1 (parameter 0301 FB CMD WORD 1) resets the drive.				
	-1 = DI1(INV) – Defines an in			irce.	
	De-activating the digital in				
	-25 = DI2(INV)DI5(INV) reset source.	 Defines an invert 	ted digital input DI2	.DI5 as a fau	ult
	 See DI1(INV) above. 				

	Group 16	: System con	trols		
Code	Description	Range	Resolution	Default	S
1605	USER PAR SET CHG	-66	1	0	
	Defines control for changing the	user parameter s	et.		
	See parameter 9902 APPLIC I	MACRO.			
	The drive must be stopped to a	hange User para	ameter sets.		
	During a change, the drive will	not start.			
	Note: Always save the User para performing a motor identification.		hanging any param	eter settings	, or
	Whenever the power is cycled, drive loads the last settings sa are lost.	•			
	Note: The value of this paramete	r (1605) is not in	cluded in the User	oarameter se	ets,
	and does not change if User para	meter sets chan	ge.		
	Note: You can use a relay output	to supervise the	selection of User p	arameter se	t 2.
	See parameter 1401.				
	0 = NOT SEL – Defines the control the only control for changing	ol panel (using pa User parameter	arameter 9902 APP sets.	LIC MACRO) as
	1 = DI1 – Defines digital input 1 a				
	 The drive loads User parame The drive loads User parame 			•	
	The User parameter set cha		0 0	•	
	25 = DI2DI5 – Defines digita parameter sets.				
	See DI1 above. 1 = DI1/(N)/() Defines an inverted.	ad digital input 1	as a control for sha	naina Haar	
	-1 = DI1(INV) – Defines an invert parameter sets.	ed digital input 1	as a control for cha	inging User	
	The drive loads User parameter		0 0	•	
	The drive loads User parameters and the second		0 0	•	
	 The User parameter set cha -25 = DI2(INV)DI5(INV) – D 	•			ntrol
	for changing User paramete • See DI1(INV) above.		u digital lilput DIZ	DIO AS A COI	itiOi
	- Gee Dir(iivv) above.				

	Gr	oup 16: System cont	rols				
Code	Description	Range	Resolution	Default	S		
1606	LOCAL LOCK	-68	1	0			
	Defines control for the us	e of the HAND mode. The	e HAND mode allo	ws drive cor	ntrol		
	from the control panel.						
	When LOCAL LOCK is	active, the control panel	cannot change to	HAND mode	€.		
	0 = NOT SEL – Disables drive.	the lock. The control pane	el can select HANI	D and contro	I the		
	Note: The OFF key always stops the drive, regardless of the parameter 1606 LOCAL LOCK value. If LOCAL LOCK is active and the drive is in the AUTO mode when the OFF key is pressed, the drive remains in the AUTO mode but coasts to stop and shows alarm 2017 OFF BUTTON on the control panel display. (This alarm is shown on the control panel only; it is not indicated by relay outputs.) Press the AUTO key to restart the drive.						
	Note: If the drive is in the OFF or HAND mode and LOCAL LOCK is activated (eg, from the control panel or through a digital input), control from the control panel is still possible until the drive is set to the AUTO mode. It is not until then that LOCAL LOCK becomes effective, disabling changing from the AUTO mode to the OFF or HAND mode by pressing the OFF or HAND key.						
	1 = DI1 – Defines digital input 1 as the control for setting the local lock.						
	-	input locks out local cont					
	25 = DI2DI5 – Define lock.	ital input enable the HANes digital input DI2DI5 a		etting the loc	al		
	See DI1 above.						
	7 = ON – Sets the lock. The drive.	he control panel cannot s	elect HAND, and c	annot contro	l the		
	8 = COMM – Defines bit 14 of the Command word 1 as the control for setting the local lock.						
	Command word is supplied through fieldbus communication.						
	 Command word is parameter 0301 FB CMD WORD 1. -1 = DI1(INV) – Defines an inverted digital input DI1 as the control for setting the local lock. 						
	De-activating the digital input locks out local control.						
	Activating the digital -25 = DI2(INV)DI5(II control for setting the	input enable the HAND s NV) – Defines an inverted e local lock.	election.	.DI5 as the			
4007	See DI1(INV) above						
1607	PARAM. SAVE	0, 1	1	0			
	Saves all altered parameters to permanent memory.						
	 Parameters altered through a fieldbus are not automatically saved to permanent memory. To save, you must use this parameter. 						
	<u>'</u>	AMETER LOCK = 2 (NO street saved. To save, you me	// 1		from		
	If parameter 1602 PAR control panel are stored	AMETER LOCK = 1 (OP d immediately to permane	// 1	ltered from t	he		
	0 = DONE – Value chang 1 = SAVE – Saves alte	es automatically when all	parameters are s	aved.			

START ENABLE 1			Croup 46.	Cyatam can	lua la		
START ENABLE 1 -67 1 4 Selects the source of the start enable 1 signal. Note: Start enable functionality differs from the run enable functionality. 0 = NOT SEL – Allows the drive to start without an external start enable signal. 1 = DI1 – Defines digital input DI1 as the start enable 1 signal. • If the voltage drops and de-activates this digital input, the drive will coast to stop and show alarm 2021 START ENABLE 1 MISSING on panel display. The drive will not start until start enable 1 signal resumes. 25 = DI2DI5 — Defines digital input DI2DI5 as the start enable 1 signal. • See DI1 above. 7 = COMM – Assigns the fieldbus Command word as the source for the start enable 1 signal. • Bit 2 of the Command word 2 (parameter 0302 FB CMD WORD 2) activates the start disable 1 signal. • See fieldbus user's manual for detailed instructions. -1 = DI1(INV) — Defines an inverted digital input DI1 as the start enable 1 signal. • See DI11(INV) — Defines an inverted digital input DI2DI5 as the start enable 1 signal. • See DI1(INV) above. Device started STARTED RELAY STATUS Group 14: Relay outputs Damper opening imme Damper opening Obamper STATUS Damper opening Obamper in fully opened. 1601 Acceleration time RUN ENABLE SIGNAL from the damper end switch when the damper is fully opened. 1601 Acceleration time MOTOR STATUS	Code	Description	Group 16:			Default	
Selects the source of the start enable 1 signal. Note: Start enable functionality differs from the run enable functionality. 0 = NOT SEL - Allows the drive to start without an external start enable signal. 1 = D11 - Defines digital input D11 as the start enable 1 signal. • This digital input must be activated for start enable 1 signal. • If the voltage drops and de-activates this digital input, the drive will coast to stop and show alarm 2021 START ENABLE 1 M/SSIN/G on panel display. The drive will not start until start enable 1 signal resumes. 25 = D12D15 - Defines digital input D12D15 as the start enable 1 signal. • See D11 above. 7 = COMM - Assigns the fieldbus Command word as the source for the start enable 1 signal. • See fieldbus user's manual for detailed instructions. 1 = D11(INV) - Defines an inverted digital input D11 as the start enable 1 signal. • See D12(INV)D15(INV) - Defines an inverted digital input D12D15 as the start enable 1 signal. • See D11(INV) above. Damper closed Relay energized Relay energized START/STOP COMMAND Group 14: Relay outputs START/STOP COMMAND Group 10: Start/Stop/Dir START/STOP COMMAND Group 10: Start/Stop/Dir STARTUS Damper closed Damper closed Damper startus Damper closed Damper startus		•					3
Note: Start enable functionality differs from the run enable functionality. 0 = NOT SEL - Allows the drive to start without an external start enable signal. 1 = DI1 - Defines digital input DI1 as the start enable 1 signal. • This digital input must be activated for start enable 1 signal. • If the voltage drops and de-activates this digital input, the drive will coast to stop and show alarm 2021 START ENABLE 1 MiSSING on panel display. The drive will not start until start enable 1 signal resumes. 25 = DI2DI5 - Defines digital input DI2DI5 as the start enable 1 signal. • See DI1 above. 7 = COMM - Assigns the fieldbus Command word as the source for the start enable 1 signal. • Bit 2 of the Command word 2 (parameter 0302 FB CMD WORD 2) activates the start disable 1 signal. • See fieldbus user's manual for detailed instructions. 1 = DI1(INV) - Defines an inverted digital input DI1 as the start enable 1 signal. • See DI2(INV)DI5(INV) - Defines an inverted digital input DI2DI5 as the start enable 1 signal. • See DI1(INV) above. Damper COMMAND Relay energized Relay energized START/STOP COMMAND Group 14: Relay outputs Damper closed Damper closed Damper closed Damper closing time Damper start/Stop/Dir Sta	1000			*****	1	4	
0 = NOT SEL – Allows the drive to start without an external start enable signal. 1 = DI1 – Defines digital input DI1 as the start enable 1 signal. • This digital input must be activated for start enable 1 signal. • If the voltage drops and de-activates this digital input, the drive will coast to stop and show alarm 2021 START ENABLE 1 MISSING on panel display. The drive will not start until start enable 1 signal resumes. 25 = DI2DI5 – Defines digital input DI2DI5 as the start enable 1 signal. • See DI1 above. 7 = COMM – Assigns the fieldbus Command word as the source for the start enable 1 signal. • See fieldbus user's manual for detailed instructions. -1 = DI1(INV) – Defines an inverted digital input DI1 as the start enable 1 signal. -25 = DI2(IVV)DI5(INV) – Defines an inverted digital input DI2DI5 as the start enable 1 signal. -25 = DI2(IVV)DI5(INV) – Defines an inverted digital input DI2DI5 as the start enable 1 signal. • See DI1(INV) above. Drive started Relay energized Relay energized START/STOP COMMAND Group 10: Start/Stop/Dir START ENABLE SIGNAL from the damper and switch when the damper is fully opened. 1601 Acceleration time RUN ENABLE SIGNAL from the damper end switch when the damper is fully opened. 1601 Acceleration time MOTOR STATUS Deceleration time				ŭ	ın anabla functions	sli t s /	
1 = DI1 — Defines digital input DI1 as the start enable 1 signal. • This digital input must be activated for start enable 1 signal. • If the voltage drops and de-activates this digital input, the drive will coast to stop and show alarm 2021 START ENABLE 1 MISSING on panel display. The drive will not start until start enable 1 signal resumes. 25 = DI2DI5 — Defines digital input DI2DI5 as the start enable 1 signal. • See DI1 above. 7 = COMM — Assigns the fieldbus Command word as the source for the start enable 1 signal. • Bit 2 of the Command word 2 (parameter 0302 FB CMD WORD 2) activates the start disable 1 signal. • See fieldbus user's manual for detailed instructions. -1 = DI1(INV) — Defines an inverted digital input DI1 as the start enable 1 signal. -25 = DI2(INV)DI5(INV) — Defines an inverted digital input DI2DI5 as the start enable 1 signal. • See DI1(INV) above. Drive started START/STOP COMMAND Group 10: Start/Stop/Dir START ENABLE SiGNAL 1608 & 1609 Relay Group 10: Start/Stop/Dir START ENABLE SIGNAL 1 from the damper end switch when the damper is fully opened. 1601 MOTOR STATUS 1601 Deceleration ime MOTOR STATUS 1601 Deceleration ime MOTOR STATUS 1601 Deceleration ime			,			•	
If the voltage drops and de-activates this digital input, the drive will coast to stop and show alarm 2021 START ENABLE 1 M/SSING on panel display. The drive will not start until start enable 1 signal resumes. 25 = DI2DI5 - Defines digital input DI2DI5 as the start enable 1 signal. • See DI1 above. 7 = COMM - Assigns the fieldbus Command word as the source for the start enable 1 signal. • Bit 2 of the Command word 2 (parameter 0302 FB CMD WORD 2) activates the start disable 1 signal. • See fieldbus user's manual for detailed instructions. -1 = DI1(INV) - Defines an inverted digital input DI1 as the start enable 1 signal. • See DI2(INV)DI5(INV) - Defines an inverted digital input DI2DI5 as the start enable 1 signal. • See DI1(INV) above. Drive started Relay energized Relay energized Relay outputs Damper closed DAMPER STATTUS Group 14: Relay outputs Damper closed DAMPER STATTUS From the damper end switch when the damper is fully opened. 1601 MOTOR STATUS						ible signal.	
and show ālarm 2021 START ENABLE 1 MīSSING on panel display. The drive will not start until start enable 1 signal resumes. 25 = DI2DI5 - Defines digital input DI2DI5 as the start enable 1 signal. • See DI1 above. 7 = COMM - Assigns the fieldbus Command word as the source for the start enable 1 signal. • Bit 2 of the Command word 2 (parameter 0302 FB CMD WORD 2) activates the start disable 1 signal. • See fieldbus user's manual for detailed instructions. -1 = DI1(INV) - Defines an inverted digital input DI1 as the start enable 1 signal. -25 = DI2(INV)DI5(INV) - Defines an inverted digital input DI2DI5 as the start enable 1 signal. • See DI1(INV) above. Drive started START/STOP COMMAND Group 10: Start/Stop/Dir START ENABLE SIGNAL 1608 & 1609 Relay de-energized Relay energized Relay outputs Damper closed DAMPER STATUS Group 14: Relay outputs Damper closed DAMPER STATUS Damper in time RUN ENABLE SIGNAL from the damper end switch when the damper is fully opened. 1607 MOTOR STATUS Deceleration time					•		
25 = DI2DI5 – Defines digital input DI2DI5 as the start enable 1 signal. • See DI1 above. 7 = COMM – Assigns the fieldbus Command word as the source for the start enable 1 signal. • Bit 2 of the Command word 2 (parameter 0302 FB CMD WORD 2) activates the start disable 1 signal. • See fieldbus user's manual for detailed instructions. -1 = DI1(INV) – Defines an inverted digital input DI1 as the start enable 1 signal. -25 = DI2(INV)DI5(INV) – Defines an inverted digital input DI2DI5 as the start enable 1 signal. • See DI1(INV) above. Drive started START/STOP COMMAND Group 10: Start/Stop/Dir START ENABLE SIGNAL 1608 & 1609 Relay Relay energized Damper open Damper closed Damper opening I time Damper dosed DAMPER STATUS Damper opening I time Damper it damper end switch when the damper is fully opened. 1601 MOTOR STATUS		and show alarm	2021 START	ENABLE 1 MIS	SSING on panel dis	will coast to splay. The dr	stop ive
7 = COMM – Assigns the fieldbus Command word as the source for the start enable 1 signal. • Bit 2 of the Command word 2 (parameter 0302 FB CMD WORD 2) activates the start disable 1 signal. • See fieldbus user's manual for detailed instructions. -1 = DI1(INV) – Defines an inverted digital input DI1 as the start enable 1 signal. -25 = DI2(INV)DI5(INV) – Defines an inverted digital input DI2DI5 as the start enable 1 signal. • See DI1(INV) above. Drive started START/STOP COMMAND Group 10: Start/Stop/Dir START ENABLE SIGNAL 1608 & 1609 Relay de-energized Relay outputs Damper open Damper closed DAMPER STATUS Damper strully opened. 1601 Acceleration time MOTOR STATUS		25 = DI2DI5 - D		•		1 signal.	
signal. Bit 2 of the Command word 2 (parameter 0302 FB CMD WORD 2) activates the start disable 1 signal. See fieldbus user's manual for detailed instructions. 1 = D11(INV) – Defines an inverted digital input D11 as the start enable 1 signal. 25 = D12(INV)D15(INV) – Defines an inverted digital input D12D15 as the start enable 1 signal. See D11(INV) above. Drive started START/STOP COMMAND Group 10: Start/Stop/Dir START ENABLE SIGNAL 1608 & 1609 Relay outputs Damper closed DAMPER STATUS Damper closed DAMPER STATUS Damper ime RUN ENABLE SIGNAL from the damper end switch when the damper is fully opened. 1601 Acceleration time MOTOR STATUS			the fieldbug (Command word	as the source for t	the start one	blo 1
start disable 1 signal. • See fieldbus user's manual for detailed instructions. -1 = DI1(INV) – Defines an inverted digital input DI1 as the start enable 1 signal. -25 = DI2(INV)DI5(INV) – Defines an inverted digital input DI2DI5 as the start enable 1 signal. • See DI1(INV) above. Drive started START/STOP COMMAND Group 10: Start/Stop/Dir START ENABLE SIGNAL 1608 & 1609 Relay de-energized Relay energized STARTED RELAY STATUS Group 14: Relay outputs Damper closed Damper closed Damper opening time Damper closed RUN ENABLE SIGNAL from the damper end switch when the damper is fully opened. 1601 MOTOR STATUS		signal.					
-1 = DI1(INV) – Defines an inverted digital input DI1 as the start enable 1 signal. -25 = DI2(INV)DI5(INV) – Defines an inverted digital input DI2DI5 as the start enable 1 signal. • See DI1(INV) above. Drive started START/STOP COMMAND Group 10: Start/Stop/Dir START ENABLE SIGNAL 1608 & 1609 Relay de-energized Relay energized Relay outputs Damper closed Damper closed Damper closing time Damper closing time RUN ENABLE SIGNAL from the damper end switch when the damper is fully opened. 1601 Acceleration time MOTOR STATUS		start disable 1 si	gnal.			2) activates	the
-25 = DI2(INV)DI5(INV) – Defines an inverted digital input DI2DI5 as the start enable 1 signal. • See DI1(INV) above. Drive started START/STOP COMMAND Group 10: Start/Stop/Dir START ENABLE SIGNAL 1608 & 1609 Relay energized Relay sTATTUS Group 14: Relay outputs Damper closed Damper closed Damper closed Damper closing time Damper closed Damper closing time RUN ENABLE SIGNAL from the damper end switch when the damper is fully opened. 1601 MOTOR STATUS Deceleration time MOTOR STATUS						hle 1 signal	
Prive started START/STOP COMMAND Group 10: Start/Stop/Dir START ENABLE SIGNAL 1608 & 1609 Relay de-energized Relay energized Relay energized Damper closed Damper closed Damper closed Damper startus Damper closed Damper closed Damper closed Damper startus Damper closed Damper closed Damper startus Damper closed Damper		` '		•		•	start
Damper open Damper closed Damper closed time Damper startus Damper startus Damper closed Damper startus Damper closed Damper closed time Relay time Damper closed Damper closed Startus Damper closed Damper closed Startus Damper closed Damp							
Relay de-energized Relay energized Relay energized Relay energized Relay energized Relay energized Relay energized STARTED RELAY STATUS Group 14: Relay outputs Damper closed Damper opening time Damper closing time RUN ENABLE SIGNAL from the damper end switch when the damper is fully opened. 1601 MOTOR STATUS Deceleration time Deceleration time		` ′					
Relay de-energized Relay energized Relay energized Relay energized Relay energized Relay energized Relay energized STARTED RELAY STATUS Group 14: Relay outputs Damper closed DAMPER STATUS Damper closing time RUN ENABLE SIGNAL from the damper end switch when the damper is fully opened. 1601 MOTOR STATUS Deceleration time		Drive	з ѕтапео		_		
Relay de-energized Relay energized Relay energized STARTED RELAY STATUS Group 14: Relay outputs Damper closed Damper opening time Damper closing Time RUN ENABLE SIGNAL from the damper end switch when the damper is fully opened. 1601 MOTOR STATUS Deceleration time							/Dir
Relay de-energized Relay energized STARTED RELAY STATUS Group 14: Relay outputs Damper closed Damper opening time Damper closing time RUN ENABLE SIGNAL from the damper end switch when the damper is fully opened. 1601 Acceleration time MOTOR STATUS Deceleration time							
Damper closed Damper open Damper opening time Damper status Damper closed Damper closed Damper closed Damper closed Damper status RUN ENABLE SIGNAL from the damper end switch when the damper is fully opened. 1601 MOTOR STATUS Deceleration time							
Damper closed Damper open Damper opening time Damper status Damper closed Damper closed Damper closed Damper closed Damper status RUN ENABLE SIGNAL from the damper end switch when the damper is fully opened. 1601 MOTOR STATUS Deceleration time		İ			i		
Damper closed Damper closed Damper opening time Damper location time Damper closed Damper status Damper closed Damper status Damper closed Damper status Damper closed Damper status Damper status Damper status Damper closed Damper status Damper s			Relay energiz	zed	I ─l start	ED	
Damper closed Damper open Damper closed Damper closed Damper closed Damper closed Damper closed Damper closed Damper closing I time RUN ENABLE SIGNAL from the damper end switch when the damper is fully opened. 1601 MOTOR STATUS Deceleration time		de-energized			RELAY	' STATUS	
Damper closed Damper opening time Damper closed Damper closed Damper status Damper closed Damper status Damper status Damper closed Damper status Damper status Damper status Damper closed Damper status		ı		Damparana	· 1	14: Relay out	buts
Damper opening time Damper opening time Closing time Closin		D		Damper ope			
Damper opening time Damper closing Itime Itime RUN ENABLE SIGNAL from the damper end switch when the damper is fully opened. 1601 MOTOR STATUS Deceleration time Deceleration time Deceleration		closed		I I	l \ closod	AMPER	
opening time Closing Time RUN ENABLE SIGNAL			Damper	>		TATUS	
RUN ENABLE SIGNAL from the damper end switch when the damper is fully opened. 1601 MOTOR STATUS Deceleration time				İ	I closing		
from the damper end switch when the damper is fully opened. 1601 Acceleration Deceleration time			unic	I			
switch when the damper is fully opened. 1601 MOTOR STATUS Acceleration time time							
Acceleration time MOTOR STATUS					switch when	the	
Acceleration Deceleration time MOTOR STATUS				1		ııy openea.	
Acceleration Deceleration time MOTOR STATUS							
time time				<u> </u>		OR STATUS	

	Grou	p 16: System cont	rols		
Code	Description	Range	Resolution	Default	S
1609	START ENABLE 2	-67	1	0	
	Selects the source of the sta	rt enable 2 signal.			
	Note: Start enable functional	lity differs from the rur	n enable functional	ity.	
	0 = NOT SEL – Allows the d			0	
	1 = DI1 – Defines digital input DI1 as the start enable 2 signal. This digital input m be activated for start enable 2 signal. If the voltage drops and de-activates th digital input, the drive will coast to stop and show alarm 2022 START ENABL MISSING on the panel display. The drive will not start until start enable 2 sign resumes.				
	25 = DI2DI5 – Defines d above.	igital input DI2DI5 a	s the start enable 2	2 signal. See	DI1
	7 = COMM – Assigns the fiel signal. Bit 3 of the Comi 2 signal. See fieldbus us	mand word 2 (parame ser's manual for detai	ter 0302) activates led instructions.	the start disa	le 2 ible
	-1 = DI1(INV) – Defines an ir -25 = DI2(INV)DI5(INV) enable 2 signal.				art
	See DI1(INV) above.				
1610	DISPLAY ALARMS	0, 1	1	1	
	Controls the visibility of the for	ollowing alarms:			
	 2001 OVERCURRENT 				
	• 2002 OVERVOLTAGE				
	 2003 UNDERVOLTAGE 				
	 2009 DEVICE OVERTEM 	P.			
	For more information, see ch	napter <i>Fault tracing</i> .			
	0 = NO – The above alarms 1 = YES – All of the above a				
1611	PARAMETER VIEW	13	1	2	
	Selects the parameter view,	in other words, which	parameters are sh	own.	
	Note: This parameter is visit device. The FlashDrop is dedrives. It allows fast customiz parameters can be hidden. F Manual [3AFE68591074 (En	signed for fast copying zation of the paramete for more information,	g of parameters to er list, for example,	unpowered selected	
	FlashDrop parameter values <i>MACRO</i> to 31 (LOAD FD SE	•	ng parameter 9902	? APPLIC	
	1 = FLASHDROP – FlashDro parameter list. Paramete visible.	op parameter list is sh ers that are hidden by	own. Does not incl the FlashDrop dev	ude short vice are not	
	2 = SHORT VIEW – Shows of 3 = LONG VIEW – Shows all	,	•	ers	

Group 17: Override

This group defines the source for the override activation signal, the override speed/ frequency and pass code and how the override is enabled and disabled.

When override DI is activated, the drive stops and then accelerates to the preset speed or frequency. When the DI is deactivated the drive stops and reboots. If the start command, run enable and start enables are active in the AUTO mode the drive starts automatically and continues normally after override mode. In the HAND mode the drive returns to OFF mode.

When override is active:

- · Drive runs at preset speed.
- · Drive ignores all keypad commands.
- · Drive ignores all commands from communication links.
- Drive ignores all digital inputs except override activation/deactivation, RUN ENABLE and START ENABLE.
- Drive displays alarm message 2020 OVERRIDE.

The following faults are ignored:

3	DEV OVERTEMP
5	OVERLOAD
6	DC UNDERVOLT
7	Al1 LOSS
8	AI2 LOSS
9	MOT OVERTEMP
10	PANEL LOSS
12	MOTOR STALL
14	EXT FAULT 1
15	EXT FAULT 2
17	UNDERLOAD
18	THERM FAIL
21	CURR MEAS
22	SUPPLY PHASE
24	OVERSPEED
28	SERIAL 1 ERR
29	EFB CON FILE
30	FORCE TRIP
31	EFB 1

32	EFB 2
33	EFB 3
34	MOTOR PHASE
1001	PAR PFA REF NEG
1002	PAR PFC IOCONF
1003	PAR AI SCALE
1004	PAR AO SCALE
1006	PAR EXT RO
1007	PAR FIELDBUS MISSING
1008	PAR PFA MODE

Commissioning the override mode

- 1. Enter the parameters in all groups as needed, except *Group 17: Override*.
- 2. Select the digital input that will activate the override mode (parameter 1701) OVERRIDE SEL).
- 3. Enter the frequency reference for the override mode with parameter 1702 OVERRIDE FREQ.
- 4. Enter the pass code (358) at parameter 1704 OVERR PASS CODE.
- 5. Enable the override mode with parameter 1705 OVERRIDE.

Changing the override parameters

- 1. If override mode is already enabled, disable it:
 - Enter the pass code (358) at parameter 1704 OVERR PASS CODE.
 - Disable the override mode with parameter 1705 OVERRIDE.
- 2. If needed, load the override parameter set with parameter 9902 APPLIC MACRO.
- 3. Change the parameters as needed, except Group 17: Override.
- 4. Select the digital input that will activate the override mode (parameter 1701 OVERRIDE SEL).
- 5. Enter the frequency reference for the override mode with parameter 1702 OVERRIDE FREQ.
- 6. Enter the pass code (358) at parameter 1704 OVERR PASS CODE.
- 7. Enable the override mode with parameter 1705 OVERRIDE. The drive replaces the override parameter set with new values of all parameters.

	C	Group 17: Override				
Code	Description	Range	Resolution	Default	S	
1701	OVERRIDE SEL	-66	1	0		
	Selects the source of the over	erride activation signal.				
	 0 = NOT SEL - Override activation signal not selected. 1 = DI1 - Defines digital input DI1 as the override activation signal. This digital input must be activated for override activation signal. 25 = DI2DI5 - Defines digital input DI2DI5 as the override activation signal. See DI1 above. -1 = DI1(INV) - Defines an inverted digital input DI1 as the override activation signal. -25 = DI2(INV)DI5(INV) - Defines an inverted digital input DI2DI5 as the override activation signal. 					
	 See DI1(INV) above. 					
1702	OVERRIDE FREQ	-500 500 Hz	0.1	0.0		
	Defines a preset frequency f	or the override.				
1704	OVERR PASS CODE	065535	1	0		
	Entering the correct override pass code unlocks parameter 1705 OVERRIDE for one change.					
	• Enter the pass code always before changing the value of the parameter 1705.					
	The pass code is 358.					
	The entry reverts back to:	zero automatically.				
1705	OVERRIDE	01	1	0		
Selects whether the override is enabled or disabled. 0 = OFF – Override disabled. 1 = ON – Override enabled. • When enabled, the drive stores the values of all parameters into all parameter set (see parameter 9902 APPLIC MACRO) and the parameter 37: Override will be write protected (except parameter 1704 CODE). To change the other parameters in Group 17: Override, on the disabled.				parameters in 04 OVERR P	n PASS	
1706	OVERRIDE DIR					
	Selects the source of the over	erride direction signal.				
	 0 = FORWARD - Assigns forward as the override direction. 1 = DI1 - Defines digital input 1 as the override direction signal. Activating the digital input selects the forward direction. De-activating the digital input selects the reverse direction. 26 = DI2DI6 - Defines digital input DI2DI6 as the override direction signal. See DI1 above. 7 = REVERSE - Assigns reverse as the override direction. 1 = DI1(INV) - Defines an inverted digital input DI1 as the override direction signal. De-activating the digital input selects the forward direction. Activating the digital input selects the reverse direction. 25 = DI2(INV)DI5(INV) - Defines an inverted digital input DI2DI5 as the override direction signal. See DI1(INV) above. 					

Group 17: Override							
Code	Description	Range	Resolution	Default	S		
1707	OVERRIDE REF						
	Selects the source of the override reference.						
	 1 = CONSTANT – Selects a preset frequency or speed for the override. The frequency value is defined by parameter 1702 OVERRIDE FREQ. 2 = PID – The reference is taken from the PID output, see group Group 40: Process PID set 1 						
	Note: The following conditions must be met when using PID in the override mode:						
	 PID1 setpoint (parameter 4010 SET POINT SEL) can be either A1, A2 OR INTERNAL PID1 parameter set 1 must be active (parameter 4027 PID 1 PARAI SET = set 1). 						
	 Override direction (p or 7 = reverse. 	parameter 1706 OVERR	IDE DIR) can be eit	ther 0 = forw	ard		

Group 18: Freq in & tran out

This group defines the frequency input and transistor output signal processing.

	Group 18: Freq in & tran out					
Code	Description	Range	Resolution	Default	S	
1801	FREQ INPUT MIN	0 16000 Hz	1 =1 Hz	0 Hz		
	Defines the minimum input Frequency input on page 1		as a frequency ir	put. See sec	tion	
1802	FREQ INPUT MAX	0 16000 Hz	1 =1 Hz	1000 Hz		
	Defines the maximum input value when DI5 is used as a frequency input. See section Frequency input on page 105.					
1803	FILTER FREQ IN	0.0 10.0 s	1 = 0.1 s	0.1 s		
	Defines the filter time constant for frequency input, ie the time within 63% of a step change is reached. See section <i>Frequency input</i> on page <i>105</i> .					
1804	TO MODE			DIGITAL		
	Selects the operation mode on page 105.	e for the transistor output	TO. See section	Transistor ou	ıtput	
	0 = DIGITAL – Transistor output is used as a digital output DO.					
	1 = FREQUENCY – Transi	stor output is used as a	frequency output	FO.		
1805	DO SIGNAL			FAULT (-1)		
	Selects a drive status indic RELAY OUTPUT 1.	ated through digital outp	ut DO. See paran	neter 1401		
1806	DO ON DELAY	0.0 3600.0 s	1 = 0.1 s	0.0 s		
	Defines the operation delay for digital output DO.					
1807	DO OFF DELAY	0.0 3600.0 s	1 = 0.1 s	0.0 s		
	Defines the release delay for digital output DO.					
1808	FO CONTENT SEL	xx		104		
	Selects a drive signal to be connected to frequency output FO. Parameter index i <i>Group 01: Operating data</i> , for example, 102 = 0102 SPEED.					

	Group 18: Freg in & tran out						
Code	Description	Range	Resolution	Default S			
1809	FO CONTENT MIN	xx	-	-			
	Defines the minimum freque parameter 1808 FO CONT FO minimum and maximur	ENT SEL.	Ū				
	FO settings as follows:	A F	:O				
	1812	1812					
	1811	1810 FO content	1809 1810 FO con	<u>-</u> > ≀tent			
	Setting range depends on	narameter 1808 FO CO	NTENT SEL settin	ng			
1810	FO CONTENT MAX	xx	-	·9·			
1010	Defines the maximum frequency output FO signal value. Signal is selected with parameter 1808 FO CONTENT SEL. See parameter 1809 FO CONTENT MIN. Setting range depends on parameter 1808 FO CONTENT SEL setting.						
1811	MINIMUM FO	10 16000 Hz	1 = 1 Hz	10 Hz			
	Defines the minimum value CONTENT MIN.	e for frequency output F	O. See parameter	1809 FO			
1812	MAXIMUM FO	10 16000 Hz	1 = 1 Hz	10 Hz			
	Defines the maximum valu CONTENT MIN.	e for frequency output F	O. See parameter	1809 FO			
1813	FILTER FO	0.0 10.0 s	1 = 0.1 s	0.1 s			
	Defines the filter time cons step change is reached.	tant for frequency outpu	t FO, ie, the time v	within 63% of a			
1814	DI 1 ON DELAY	0.0 3600.0 s	1 = 0.1 s	0.0 s			
	Defines the delay from the ON state.	signal change to the ch	ange of the digital	input DI to the			
1815	DI 1 OFF DELAY	0.0 3600.0 s	1 = 0.1 s	0.0 s			
	Defines the delay from the OFF state.	signal change to the ch	ange of the digital	input DI to the			
1816	DI 2 ON DELAY			0.0 s			
	See parameter 1814 DI 1	ON DELAY.					
1817	DI 2 OFF DELAY			0.0 s			
	See parameter 1815 DI 1	OFF DELAY.					
1818	DI 3 ON DELAY			0.0 s			
	See parameter 1814 DI 1	ON DELAY.					
1819	DI 3 OFF DELAY			0.0 s			
	See parameter 1815 DI 1	OFF DELAY.					

Group 18: Freq in & tran out					
Code	Description	Range	Resolution	Default	S
1820	DI 4 ON DELAY			0.0 s	
	See parameter 1814 DI	1 ON DELAY.			
1821	DI 4 OFF DELAY			0.0 s	
	See parameter 1815 DI	1 OFF DELAY.			
1822	DI 5 ON DELAY			0.0 s	
	See parameter 1814 DI	1 ON DELAY.			
1823	DI 5 OFF DELAY			0.0 s	
	See parameter 1815 DI	1 OFF DELAY.			

Group 20: Limits

This group defines minimum and maximum limits to follow in driving the motor – speed, frequency, current, torque, etc.

	Gro	up 20: Limit	S				
Code	Description	Range	Resolution	Default	S		
2003	MAX CURRENT 0	.0 1.1 * I _{2N}	0.1 A	1.1 * I _{2N}	✓		
	Defines the maximum output cur	rent (A) supplie	ed by the drive to the	motor.			
2006	UNDERVOLT CTRL	02	1	1			
	Sets the DC undervoltage contro	ller on or off. W	/hen on:				
	If the DC bus voltage drops due to loss of input power, the undervoltage controller decreases the motor speed in order to keep the DC bus voltage above the lower limit.						
	When the motor speed decreases, the inertia of the load causes regeneration back into the drive, keeping the DC bus charged, and preventing an undervoltage trip.						
	• The DC undervoltage controller increases power loss ride-through on systems with a high inertia, such as a centrifuge or a fan.						
	0 = DISABLE – Disables controll 1 = ENABLE (TIME) – Enables c 2 = ENABLE – Enables controlle	ontroller with 5					
2007	MINIMUM FREQ -50	0.0 500.0 H	z 0.1 Hz	0.0 Hz	✓		
	Defines the minimum limit for the drive output frequency.	Freq 2008	2007 value is < 0				
	A positive or zero minimum speed frequency defines two ranges, one positive and one negative.	0	Frequency range allo	owed	Time		
	A negative minimum speed frequency defines one speed range. See figure.	2007					
	Note: Keep MINIMUM FREQ≤ MAXIMUM FREQ.	Freq 2008	2007 va	alue is ≥ 0			
		2007	Frequency range allo	owed			
		0			Time		
		-(2007)					
		-(2008)	Frequency range allo	owed			
2008	MAXIMUM FREQ 0	.0 500.0 Hz	0.1 Hz	60.0 Hz (US)	✓		
	Defines the maximum limit for the	e drive output f	requency.				

Group 21: Start/Stop

This group defines how the motor starts and stops. The drive supports several start and stop modes.

	Gro	oup 21: Start/Sto	р			
Code	Description	Range	Resolution	Default	S	
2101	START FUNCTION	18	1	1		
	Selects the motor start metho	d.				
	1 = AUTO – The drive starts the motor instantly from zero frequency. If flyir required, use selection SCAN START.					
	2 = DC MAGN – The drive pre The pre-magnetizing time	e is defined by para	meter 2103 DC MA	GN TIME.	tart.	
	Note: Starting to a rotating ma	•				
	warning! The drive will even if the motor magnet	ization is not compl	eted. Ensure alway	s in application	ons	
	where a full break-away torqu enough to allow generation of	,		izing time is l	long	
	4 = TORQ BOOST – Torque by required.		_			
The drive pre-magnetizes the motor with DC current before the sta magnetizing time is defined by parameter 2103 DC MAGN TIME. Torque boost is applied at start. Torque boost is stopped when output exceeds 20 Hz or when it is equal to the reference value. See para TORO BOOST CURR.					ncy	
	Note: Starting to a rotating machine is not possible when TORQ BOOST is selected.					
	WARNING! The drive will start after the set pre-magnetizing time has passed although the motor magnetization is not completed. Ensure always in applications where a full break-away torque is essential, that the constant magnetizing time is long enough to allow generation of full magnetization and torque.					
			•	•		
	6 = SCAN START – Frequency scanning flying start (starting the drive connected to a rotating machine). Based on frequency scanning (interval 2008 MAXIMUM FREQ2007 MINIMUM FREQ) to identify the frequency. If frequency identification fails, DC magnetization is used (see selection DC MAGN).					
	7 = SCAN + BOOST – Combi rotating machine) and tor BOOST. If frequency idea	que boost. See sele	ections SCANSTAR	onnected to a	1)	
2102	STOP FUNCTION	1, 2	1	1		
	Selects the motor stop metho	d.				
	1 = COAST – Selects cutting coasts to stop.	•	as the stop method	I. The motor		
	2 = RAMP – Selects using a c • Deceleration ramp is defi	ned by 2203 DECE	LER TIME 1 or 220	06 DECELER		
	TIME 2 (whichever is act	ive).				

See DI1(INV) above.

	Group 21: Start/Stop						
Code	Description	Range	Resolution	Default	S		
2110	TORQ BOOST CURR	15 300%	1	100%			
	Sets the maximum supplied current during torque boost.						
	See parameter 2101 START FUNCTION.						
2113	START DELAY						
	Defines the Start delay. After the conditions for start have been fulfilled, the drive waits until the delay has elapsed and then starts the motor. Start delay can be used with all start modes.						
	• If START DELAY = zero, th	ne delay is disabled.					
	 During the Start delay, alar 	m 2028 START DELA	AY is shown.				

Group 22: Accel/Decel

This group defines ramps that control the rate of acceleration and deceleration. You define these ramps as a pair, one for acceleration and one for deceleration. You can define two pairs of ramps and use a digital input to select one or the other pair.

	(Group 22: Accel/Dece	I			
Code	Description	Range	Resolution	Default	S	
2201	ACC/DEC 1/2 SEL	-67	1	0		
	Defines control for selection	on of acceleration/deceler	ation ramps.			
	Ramps are defined in page 1.	airs, one each for acceler	ation and deceler	ation.		
ļ	 See below for the ramp 	definition parameters.				
ļ	0 = NOT SEL – Disables s					
ļ	1 = DI1 – Defines digital input 1 as the control for ramp pair selection.					
ļ	 Activating the digital input selects ramp pair 2. De-activating the digital input selects ramp pair 1. 					
	25 = DI2DI5 – Define			amp pair		
ļ	selection.	0 1				
ļ	See DI1 above. 7 - COMM - Defines as in the second control of the second control o	-1		-:		
ļ	7 = COMM – Defines seria -1 = DI1(INV) – Defines ar					
ļ	selection.	i inverted digital input i a	3 the control lor is	amp pan		
		tal input selects ramp pair	r 2			
ļ		input selects ramp pair 1.	distinct insent DIO	DIE aa tha		
	-25 = DI2(INV)DI5(IN control for ramp pair	selection.	digital input DI2	.Dis as the		
	See DI1(INV) above.					
2202	ACCELER TIME 1	0.0 1800.0 s	0.1 s	30.0 s		
	Sets the acceleration time the figure with parameter.		quency for ramp p	oair 1. See A	in	
ļ	Actual acceleration time	e also depends on parame	eter 2204 RAMP	SHAPE 1.		
ļ	See parameter 2008 M.	AXIMUM FREQ				
2202	Sets the acceleration time the figure with parameter . • Actual acceleration time	for zero to maximum frec 2204 RAMP SHAPE 1. e also depends on parame	quency for ramp p	pair 1. See		

		Group 22: Accel/Dece	1	
Code	Description	Range	Resolution	Default S
2203	DECELER TIME 1	0.0 1800.0 s	0.1 s	30.0 s
	Sets the deceleration time	e for maximum frequency t	to zero for ramp p	pair 1.
	Actual deceleration tim	e also depends on parame	eter 2204 RAMP	SHAPE 1.
	See parameter 2008 M	IAXIMUM FREQ		
2204	RAMP SHAPE 1	0 1000.0 s	0.1 s	0.0
	Selects the shape of the a ramp for ramp pair 1. See		MAX Line	ar
	becomes an s-curve. • Rule of thumb: 1/5 is a	o reach the maximum	FREQ	
	pair 1. 0.11000.0 – Specifies s	ation ramps for ramp s-curve	MAX S-cu	rve
	pair 1.	ation ramps for ramp	→ A A = 220 B = 220	
2205	ACCELER TIME 2	0.0 1800.0 s	0.1 s	60.0 s
	Sets the acceleration time parameter 2202 ACCELE	e (s) for zero to maximum (frequency for ram	np pair 2. See
2206	DECELER TIME 2	0.0 1800.0 s	0.1 s	60.0 s
	Sets the deceleration time parameter 2203 DECELE	e for maximum frequency t ER TIME 1.	to zero for ramp p	oair 2. See
2207	RAMP SHAPE 2	0 1000.0 s	0.1 s	0.0
	Selects the shape of the a parameter 2204 RAMP S	acceleration/deceleration r HAPE 1.	amp for ramp pai	r 2. See
2208	EMERG DEC TIME	0.0 1800 s	0.1 s	1.0 s
	Sets the deceleration time	e for maximum frequency	to zero for an em	ergency.
	See parameter 2109 E	MERG STOP SEL.		
	Ramp is linear.			
	•			

	G	Froup 22: Accel/Dec	el			
Code	Description	Range	Resolution	Default	S	
2209	RAMP INPUT 0	-66	1	0		
	Defines control for forcing	the ramp input to 0.				
	0 = NOT SEL - Not selecte	ed.				
	 1 = DI1 - Defines digital input 1 as the control for forcing the ramp input to 0. Activating the digital input forces ramp input to 0. Ramp output will ramp to 0 according to the currently used ramp time, after which it will stay at 0. De-activating the digital input: ramp resumes normal operation. 26 = DI2DI6 - Defines digital input DI2DI6 as the control for forcing the ramp input to 0. See DI1 above. 7 = COMM - Defines bit 13 of the Command word 1 as the control for forcing the speed to 0. Command word is supplied through fieldbus communication. 					
	Command word is part		oorminamoadon.			
	-1 = DI1(INV) – Defines an input to 0.	inverted digital input D	I1 as the control for	forcing the ra	amp	
	De-activating the digit					
	Activating the digital in -25 = DI2(INV)DI5(IN control for forcing the See DI1(INV) above.		d digital input DI2	.DI5 as the		

Group 25: Critical speeds

This group defines up to three critical speeds or ranges of speeds that are to be avoided due, for example, to mechanical resonance problems at certain speeds.

	Gro	oup 25: Critical	speeds	
Code	Description	Range	Resolution	Default S
2501	CRIT SPEED SEL	0, 1	1	0
	Sets the critical speeds fun off. The critical speed funct specific speed ranges. 0 = OFF - Disables the critical function. 1 = ON - Enables the critical function. Example: To avoid speeds fan system vibrates badly: • Determine problem speed Assume they are found to the sample of the speed fan system vibrates badly: • Set 2501 CRIT SPEED of the speed fan system vibrates badly: • Set 2502 CRIT SPEED of the speed fan system vibrates badly: • Set 2503 CRIT SPEED of the speed fan system vibrates badly: • Set 2504 CRIT SPEED of the speed fan system vibrates badly: • Set 2504 CRIT SPEED of the speed fan system vibrates badly:	ion avoids ical speeds al speeds at which a at which a at ranges. o be: Iz. SEL = 1. I LO = 18 I HI = 23 Hz. 2 LO = 46 Hz.	f1L f1H f2L 18 23 46	f2H 52
2502	• Set 2505 CRIT SPEED 2 CRIT SPEED 1 LO	2 HI = 52 HZ. 0.0 500.0 H	Hz 0.1 Hz	0.0 Hz
2302	Sets the minimum limit for			0.0 HZ
	Value must be less than	, ,	•	
	 Units are rpm. 	or equal to 2000 t	STATE OF ELD TTM.	
2503	CRIT SPEED 1 HI	0.0 500.0 l	Hz 0.1 Hz	0.0 Hz
	Sets the maximum limit for	critical speed rang	ge 1.	
	Value must be greater th	an or equal to 250) 02 CRIT SPEED 1 LO.	
	Units are rpm.			
2504	CRIT SPEED 2 LO	0.0 500.0 l	Hz 0.1 Hz	0.0 Hz
	Sets the minimum limit for	critical speed rang	je 2.	
	See parameter 2502 CR	IT SPEED 1 LO.		
2505	CRIT SPEED 2 HI	0.0 500.0 l	Hz 0.1 Hz	0.0 Hz
	Sets the maximum limit for	critical speed rang	ge 2.	
	 See parameter 2503 CR 	IT SPEED 1 HI		
2506	CRIT SPEED 3 LO	0.0 500.0 l	Hz 0.1 Hz	0.0 Hz
	Sets the minimum limit for	critical speed rang	je 3.	
	See parameter 2502 CR	IT SPEED 1 LO.		

	Group 25: Critical speeds						
Code	Description	Range	Resolution	Default	S		
2507	CRIT SPEED 3 HI	0.0 500.0 Hz	0.1 Hz	0.0 Hz			
	Sets the maximum limit for	Sets the maximum limit for critical speed range 3.					
	See parameter 2503 CR	RIT SPEED 1 HI.					

■ Group 26: Motor control

This group provides controls for fine-tuning the motor control.

		Group 26: Motor contr	ol						
Code	Description	Range	Resolution	Default	S				
2603	IR COMP VOLT	0 100 V	1 V	size dependent					
	Sets the IR compensation voltage used for 0 Hz.								
	 Keep IR compensation 	Keep IR compensation as low as possible to prevent overheating.							
	Typical IR compensation	on values are:							
	Typical IR compensation values: P_N (kW)								
	IR compensation								
	•	pensation provides an extrensation, for example, in ap	•		low				
2604	IR COMP FREQ	0 100%	1	80%					
	Sets the frequency at wh	ich IR compensation is 0 \	/ (in % of motor f	requency).					
2605	U/F RATIO	1, 2	1	2					
		J/f (voltage to frequency) ra		eakening poir	nt.				
	2 = SQUARED - Preferre	for constant torque applica ed for centrifugal pump and operating frequencies.)		s. (SQUARED	is				

Description SWITCHING FREQ Defines the switching frequence acoustic noise in the and section Switching frequence multimotor systems, do not switching frequence activates the switching frequence activates activates the switching frequence activates	motor. See also paramet uency derating, I2N and I not change the switching 0, 1	Resolution - switching freque er 2207 SWITCH LD (= all currents	FREQ CTR s) on page 30	RL 66.	
SWITCHING FREQ Defines the switching frequence acoustic noise in the and section Switching frequence multimotor systems, do a SWITCH FREQ CTRL Activates the switching frequence 600 SWITCHING FREQ is 100 Miles in the switching frequence	1, 4, 8, 12, 16 kHz uency of the drive. Higher motor. See also paramet uency derating, I2N and I not change the switching 0, 1	- switching freque er 2207 SWITCH LD (= all currents	4 kHz ency results in H FREQ CTR s) on page 30 the default va	n R <i>L</i> 66.	
Defines the switching frequence acoustic noise in the land section <i>Switching frequency</i> in multimotor systems, do a switching frequence according to the switching frequence activates the switching frequence according to the switchin	uency of the drive. Higher motor. See also paramet uency derating, I2N and I not change the switching 0, 1	er 2207 SWITCH LD (= all currents	ency results in FREQ CTR s) on page 30 the default va	RL 66.	
CTRL Activates the switching free 2606 SWITCHING FREQ i	,	-	1		
2606 SWITCHING FŘEQ i					
a specific operation point. Higher switching frequency	Activates the switching frequency control. When active, the selection of parameter 2606 SWITCHING FREQ is limited when the drive internal temperature increases. See the figure below. This function allows the highest possible switching frequency at a specific operation point. Higher switching frequency results in lower acoustic noise in the motor, but higher internal losses.				
f _{sw} limit	†				
1 = ON – Active. 2 = ON (LOAD) – Switching output current. This al	80100 °C * e depends on the drive or g frequency can adapt to llows maximum loading w	utput frequency. loading instead of the first all switching from the first and the first are the first and the first are the fi	of limiting the		
selections. The drive a loading is too high for	automatically decreases t	he actual switchi	ng frequency	/ if	
SLIP COMP RATIO	0 200%	1	0		
Defines the slip gain for the motor slip compensation control. 100% means full slip compensation, 0% means no slip compensation. Other values can be used if a static speed error is detected despite the full slip compensation. Example: 35 Hz constant speed reference is given to the drive. Despite the full slip compensation (SLIP COMP RATIO = 100%), a manual tachometer measurement from the motor axis gives a speed value of 34 Hz. The static speed error is 35 Hz - 34 Hz = 1 Hz. To compensate the error, the slip gain should be increased. 0 = No slip compensation. 1200 = Slip gain.					
S E C S F	= ON – Active. = ON (LOAD) – Switchin output current. This all selections. The drive loading is too high for SLIP COMP RATIO Defines the slip gain for the ompensation, 0% means peed error is detected de example: 35 Hz constant ompensation (SLIP COM om the motor axis gives all z = 1 Hz. To compensate	* Temperature depends on the drive of a CN – Active. = ON (LOAD) – Switching frequency can adapt to output current. This allows maximum loading we selections. The drive automatically decreases to loading is too high for the selected switching free selected switching free loading is too high for the motor slip compensation of the motor slip compensation. Other of the full slip compension of the full slip compension of the motor axis given of the motor axis given a speed value of 34 Hz. The compensation is a speed value of 34 Hz. The compensation is compensated the error, the slip gain should be compensated to the motor axis given as speed value of 34 Hz. The compensation is compensated the error, the slip gain should be compensated the compensation of the motor axis gives a speed value of 34 Hz. The compensation is compensated the error, the slip gain should be compensated the compensation of the motor axis gives a speed value of 34 Hz. The compensation is compensated the error, the slip gain should be compensated the compensation of the compensation	* Temperature depends on the drive output frequency. = ON – Active. = ON (LOAD) – Switching frequency can adapt to loading instead output current. This allows maximum loading with all switching f selections. The drive automatically decreases the actual switching loading is too high for the selected switching frequency. SLIP COMP RATIO	* Temperature depends on the drive output frequency. = ON – Active. = ON (LOAD) – Switching frequency can adapt to loading instead of limiting the output current. This allows maximum loading with all switching frequency selections. The drive automatically decreases the actual switching frequency loading is too high for the selected switching frequency. SLIP COMP RATIO 0 200% 1 0 Defines the slip gain for the motor slip compensation control. 100% means full slip compensation, 0% means no slip compensation. Other values can be used if a stepped error is detected despite the full slip compensation. Example: 35 Hz constant speed reference is given to the drive. Despite the full sompensation (SLIP COMP RATIO = 100%), a manual tachometer measurement om the motor axis gives a speed value of 34 Hz. The static speed error is 35 Hz lz = 1 Hz. To compensate the error, the slip gain should be increased.	

	G	roup 26: Motor contro	ol		
Code	Description	Range	Resolution	Default	S
2609	NOISE SMOOTHING	0, 1	1	0	
	Enables the noise smooth noise over a range of frequency has noise intensity. A rar switching frequency set by Note: This parameter has	uencies instead of a single ndom component with an a y parameter 2206 SWITC	e tonal frequency average of 0 Hz i HING FREQ.	resulting in lo	ower
	0 = DISABLE 1 = ENABLE				
2610	USER DEFINED U1	0 120% of <i>U</i> _N V	1 = 1 V	19% of <i>U</i> _N	
	Defines the first voltage poparameter 2611 USER DE			,	′
2611	USER DEFINED F1	0.0 500.0 Hz	1 = 0.1 Hz	10.0 Hz	
	Defines the first frequency	point of the custom U/f c	urve.		
2612	USER DEFINED U2	0 120% of <i>U</i> _N V	1 = 1 V	38% of <i>U</i> _N	
	Defines the second voltag parameter 2613 USER DE				d by
2613	USER DEFINED F2	0.0 500.0 Hz	1 = 0.1 Hz	20.0 Hz	
	Defines the second freque	ency point of the custom L	J/f curve.		
2614	USER DEFINED U3	0 120% of <i>U</i> _N V	1 = 1 V	47.5% of <i>U</i> _N	
	Defines the third voltage p parameter 2615 USER DE	point of the custom U/f cur EFINED F3. See section C	ve at the frequer	ncy defined bon page 110.	у
2615	USER DEFINED F3	0.0 500.0 Hz	1 = 0.1 Hz	25.0 Hz	
	Defines the third frequence	y point of the custom U/f	curve.		
2616	USER DEFINED U4	0 120% of <i>U</i> _N V	1 = 1 V	76% of <i>U</i> _N	
	Defines the fourth voltage parameter 2617 USER DE	•		•	•
2617	USER DEFINED F4	0.0 500.0 Hz	1 = 0.1 Hz	40.0 Hz	
	Defines the fourth frequen	, ·	f curve.		
2618	FW VOLTAGE	0 120% of <i>U</i> _N V	1 = 1 V	95% of <i>U</i> _N	
	Defines the voltage of the nominal frequency (9907 I	, ,	•		
2619	DC STABILISER				
	Enables or disables the D control mode to prevent properties of the properties of th	ossible voltage oscillation: / network. In case of volta abilize the DC bus voltage	s in the drive DC ge variation the o	bus caused drive tunes th	ne
	0 = DISABLE – Disables I 1 = ENABLE – Enables D				

Group 29: Maintenance trig

This group contains usage levels and trigger points. When usage reaches the set trigger point, a notice is displayed on the control panel signals that maintenance is due.

	Grou	up 29: Maintenance	trig		
Code	Description	Range	Resolution	Default S	
2901	COOLING FAN TRIG	0.0 6553.5 kh	0.1 kh	0.0	
	Defines the trigger point for to parameter 2902 COOLIN		n time counter. Va	lue is compared	
	• Time. If parameter value 0.0 = NOT SEL	is set to zero, the trigge	r is disabled.		
2902	COOLING FAN ACT	0.0 6553.5 kh	0.1 kh	0.0	
	Defines the actual value for COOLING FAN TRIG has be actual value of the counter maintenance notice is displement. Time. Parameter is reset	peen set to a non zero value definition and the value definition and the panel.	alue, the counter	starts. When the	
2903	REVOLUTION TRIG	0 65535 MRev	1 MRev	0	
	Defines the trigger point for parameter 2904 REVOLUT		unter. Value is co	mpared to	
	Millions of revolutions. If	parameter value is set to	o zero, the trigger	is disabled.	
	0.0 = NOT SEL				
2904	REVOLUTION ACT	0 65535 MRev	1 MRev	0	
	Defines the actual value for REVOLUTION TRIG has be actual value of the counter maintenance notice is displ	een set to a non zero va exceeds the value define	llue, the counter s	tarts. When the	
	Millions of revolutions. Page 1.	arameter is reset by sett	ing it to zero.		
2905	RUN TIME TRIG	0.0 6553.5 kh	0.1 kh	0.0	
	Defines the trigger point for the drive run time counter. Value is compared to the value of parameter 2906 RUN TIME ACT.				
	• Time. If parameter value 0.0 = NOT SEL	is set to zero, the trigge	r is disabled.		
2906	RUN TIME ACT	0.0 6553.5 kh	0.1 kh	0.0	
Defines the actual value for the drive run time counter. When parameter <i>TIME TRIG</i> has been set to a non zero value, the counter starts. When value of the counter exceeds the value defined by parameter 2905, a m notice is displayed on the panel. • Time. Parameter is reset by setting it to zero.				en the actual	

	Group 29: Maintenance trig						
Code	Description	Range	Resolution	Default	S		
2907	USER MWh TRIG	0.0 6553.5 MWh	0.1 MWh	0.0			
	Defines the trigger point for the drive power consumption counter. Value is compared to the value of parameter 2908 USER MWh ACT.						
	Megawatt hours. If parameter value is set to zero, the trigger is disabled.						
	0.0 = NOT SEL						
2908	USER MWh ACT	0.0 6553.5 MWh	0.1 MWh	0.0			
	Defines the actual value of the drive power consumption counter. When parameter 2907 USER MWh TRIG has been set to a non zero value, the counter starts. When the actual value of the counter exceeds the value defined by parameter 2907, a maintenance notice is displayed on the panel.						
	 Megawatt hours. Param 	eter is reset by setting it t	o zero.				

■ Group 30: Fault functions

This group defines situations that the drive should recognize as potential faults and defines how the drive should respond if the fault is detected.

	Group 30: Fault functions						
Code	Description	Range	Resolution	Default	S		
3001	AI <min function<="" td=""><td>03</td><td>1</td><td>0</td><td></td></min>	03	1	0			
	Defines the drive response if and is used:	the analog input (A	I) signal drops belov	w the fault lim	nits		
	as the active reference so	urce (<i>Group 11: Ref</i> e	erence select)				
as the Process or External PID controllers' feedback or setpoint source Process PID set 1, Group 41: Process PID set 2 or Group 42: Ext / Trin the corresponding PID controller is active.							
	3021 AI1 FAULT LIMIT and 3 0 = NOT SEL – No response		IIT set the minimum	limits.			
	1 = FAULT – Displays a fault to a stop.	(0007 AI1 LOSS or	0008 AI2 LOSS) and	d the drive co	asts		
	2 = CONST SP 7 – Displays speed using 1208 CON	a warning (2006 AI ⁻ ST SPEED 7.	1 LOSS or 2007 AI2	2 LOSS) and	sets		
	3 = LAST SPEED – Displays speed using the last ope 10 seconds.	a warning (2006 AI erating level. This val	11 LOSS or 2007 AI2 lue is the average sp	2 LOSS) and beed over the	sets last		
	WARNING! If you select operation is safe when t		,	ure that conti	nued		

	Grou	ıp 30: Fault functi	ons		
Code	Description	Range	Resolution	Default	S
3002	PANEL COMM ERR	13	1	1	
	Defines the drive response to	o a control panel com	munication error.		
	Note: When either of the two and/or direction are through t COMMANDS = 8 (KEYPAD) configuration of the external parameter 1208 CONST SPI	the control panel – 10 – the drive follows th control locations, inst	01 EXT1 COMMAN e speed reference	IDS / 1002 E according to	XT2 the
	1 = FAULT – Displays a fault 2 = CONST SP 7 – Displays : CONST SPEED 7.				1208
	3 = LAST SPEED – Displays last operating level. This WARNING! If you select	s value is the average	speed over the las	st 10 second	S.
	operation is safe when t		,	re triat coritii	iucu
3003	EXTERNAL FAULT 1	-66	1	0	
	Defines the External Fault 1	signal input and the o	Irive response to ar	n external fai	ılt
	0 = NOT SEL – External faul 1 = DI1 – Defines digital inpu • Activating the digital inp FAULT 1 and the drive of	t signal is not used. It 1 as the external fa ut indicates a fault. T	ult input.		
	25 = DI2DI5 – Defines digital input DI2DI5 as the external fault input.				
 See DI1 above. -1 = DI1(INV) – Defines an inverted digital input 1 as the exterion. De-activating the digital input indicates a fault. The drive of FAULT 1 and the drive coasts to stop. -25 = DI2(INV)DI6(INV) – Defines an inverted digital input external fault input. 				s fault <i>0014</i>	EXT
3004	See DI1(INV) above. EXTERNAL FAULT 2	-66	1	0	
	Defines the External fault 2 s		rive response to an	external fau	lt.
	See parameter 3003 EXTERNAL	0 1	•		
3005	MOT THERM PROT	0, 2	1	1	
	Defines the drive response to	o motor overheating.			
	0 = NOT SEL – No response 1 = FAULT – When the calcul alarm 2010 MOTOR TE 110 °C (230 °F) displays stop. Note: Because the mote down the drive when fat drive, the drive does no motor temperature has	lated motor temperature. When the calculates fault 0009 MOT OVENTO thermal protection and the calculate the fault. The calculates are set the fault. The calculates are set the fault. The calculates are set the fault.	ire exceeds 90 °C (ated motor tempera ERTEMP and the d has memory retenting the fauld in the fau	194 °F), disp ature exceed rive coasts to ion, do not so a shut down to as soon as	s o hut the
	2 = ALARM – When the calc displays alarm 2010 MC		iture exceeds 90 °C	€ (194 °F),	

	Gro	up 30: Fault function	ons	
Code	Description	Range	Resolution	Default S
3006	MOT THERM TIME	256 9999 s	1	1050 s
	Sets the motor thermal time constant for the motor tempe model.			
	This is the time required for motor to reach 63% of the temperature with steady longer	e final pad. Temp. rise ↓	 	t
	For thermal protection according to UL requirem for NEMA class motors, u rule of thumb: MOTOR TH TIME equals 35 times t6, t6 (in seconds) is specified the motor manufacturer as rated current.	se the HERM where d by s the time that the moto		
	 The thermal time for a Cla and for a Class 30 trip cur 		s, for a Class 20	trip curve 700 s,
3007	MOT LOAD CURVE	50 150%	1	100%
	Sets the maximum allowable load of the motor. • With the default value 100 overload protection is fund when the constant current 127% of the parameter 98 MOTOR NOM CURR value.	0%, motor ctioning 15 t exceeds		,
	The default overloadability same level as what motor manufacturer's typically a 30 °C (86 °F) ambient ten and 1000m (3300 ft) altituthe ambient temperature e °C (86 °F) or the installation is over 1000m (3300 ft), distance manufacturer's recommendation.	3008 5 Illow in the operature de. When exceeds 30 on altitude ecrease the parameter		Frequency Frequency ding to the motor
	Example: If the constant procurrent, set parameter 3007			
3008	ZERO SPEED LOAD	25 150%	1	70%
	Defines the load curve toget BREAK POINT FREQ.	her with parameters 3	007 MOT LOAD C	URVE and 3009
	25%150% = Allowed conti	inuous motor load at z	ero speed in perce	nt of the nominal

		Group 30: Fault functions	S	
Code	Description	Range	Resolution	Default S
3009	BREAK POINT FREQ	1 250 Hz	1	35 Hz
	Defines the load curve BREAK POINT FREQ.	together with parameters 3007	7 MOT LOAD C	CURVE and 3009
		tection trip times when parame VE and 3008 ZERO SPEED L		,
	3.5 I _O /I _N	A 	I _O = Output cu I _N = Nominal n	notor current
	3.0	60 s	f _{BRK} = Break p A = Trip time	equency point frequency
	2.5	90 s		
	2.0	180 s		
	1.5	300 s		
	0.5			
	0.5	f _O /f _{BRK}	: -	
	0 0.2 0.4	0.6 0.8 1.0 1.2		
3010	STALL FUNCTION	02	1	35 Hz
		eacts to a motor stall condition stall region (see the figure bel . TIME.		
		Current (A) ♣ Si	tall region	
	(0.95 · User defined limit		
		5 18 9		
		efined limit = IAX CURRENT	Par <i>301</i>	<u>.</u>
			Fai. 307	1
	0 = NOT SEL - Protect 1 = FAULT - Drive trips	ion is inactive. s on fault <i>0012 MOTOR STALL</i>	and the motor	coasts to stop.
		nerates alarm 2012 MOTOR S		
3011	STALL FREQUENC	Y 0.5 50.0 Hz	0.1 Hz	20.0 Hz
	This parameter sets the above.	e frequency value for the Stall t	function. Refer	to the figure
3012	STALL TIME	10 400 s	1 s	20 s
	This parameter sets the	e time value for the Stall function	on.	

Code Description F 3016 SUPPLY PHASE Selects how the drive reacts to a supvoltage ripple is excessive. 0 = FAULT – Drive trips on fault SUPthe DC voltage ripple exceeds 1 1 = LIMIT/ALARM – Drive output cur	oply phase loss, in PLY PHASE and t 4% of the nominal		Default when the DC	S	
Selects how the drive reacts to a supvoltage ripple is excessive. 0 = FAULT – Drive trips on fault SUP the DC voltage ripple exceeds 1 1 = LIMIT/ALARM – Drive output cur	PLY PHASE and t 4% of the nominal		hen the DC		
voltage ripple is excessive. 0 = FAULT – Drive trips on fault SUF the DC voltage ripple exceeds 1 1 = LIMIT/ALARM – Drive output cur	PLY PHASE and t 4% of the nominal		hen the DC		
0 = FAULT – Drive trips on fault SUF the DC voltage ripple exceeds 1 1 = LIMIT/ALARM – Drive output cur	4% of the nominal				
the DC voltage ripple exceeds 1 1 = LIMIT/ALARM – Drive output cur	4% of the nominal				
		DC voltage.	·		
generated when the DC voltage There is a 10 s delay between tl limitation. The current is limited limit.	ripple exceeds 14 ne activation of the	% of the nomine alarm and the	nal DC volta e output curr	ge. ent	
2 = ALARM – Drive generates alarm exceeds 14% of the nominal DC		OSS when the	DC ripple		
3017 EARTH FAULT	01	1	1		
Defines the drive response if the drive cables. The drive monitors for ground drive is not running. Also see parame 0 = DISABLE – No drive response to	d faults while the deter 3023 WIRING	rive is running			
1 = ENABLE – Ground faults display drive coasts to stop.	fault 0016 EARTH	H FAULT, and (if running) th	те	
3018 COMM FAULT FUNC	03	1	0		
Defines the drive response if the field defined by parameter 3019 COMM F		on is lost. The	time delay is	;	
0 = NOT SEL – No response.					
1 = FAULT – Displays fault 0028 SEI			•		
2 = CONST SP 7 – Displays warning 1208 CONST SPEED 7. This "a writes a new reference value.	larm speed" remai	nd sets speed ins active until	using param the fieldbus	eter	
3 = LAST SPEED – Displays warning operating level. This value is the "alarm speed" remains active ur WARNING! If you select CONS'	e average speed on til the fieldbus writh T SP7. or LAST SI	ver the last 10 tes a new refer PEED. make s	seconds. The rence value. ure that	าis	
continued operation is safe whe	n fieldbus commu	nication is lost.			
	600.0 s	0.1 s	10.0 s		
Sets the communication fault time us	ed with parameter	3018 COMM	FAULT FUN	C.	
Brief interruptions in the fieldbus or less than the COMM FAULT TIME		not treated as	faults if they	are	
3021 AI1 FAULT LIMIT 0.0.	100.0%	0.1%	0.0%		
Sets a fault level for analog input 1. S	See parameter 300	01 AI <min fui<="" td=""><td>NCTION.</td><th></th></min>	NCTION.		
Do not set this limit below the level d	Do not set this limit below the level defined by parameter 1301 MINIMUM AI1.				
Value in percent of the full signal range.	ange.				
3022 AI2 FAULT LIMIT 0.0.	100.0%	0.1%	0.0%		
Sets a fault level for analog input 2. S	See parameter 300	01 AI <min fui<="" td=""><td>NCTION.</td><th></th></min>	NCTION.		
Do not set this limit below the level d	efined by paramet	er <i>1304 MININ</i>	IUM AI2.		
Value in percent of the full signal range.	ange.				

	Group 30: Fault functions							
Code	Description	Range	Resolution	Default	S			
3023	WIRING FAULT	0, 1	1	1				
	Selects how the drive reacts when incorrect input power and motor cable connection is detected (ie, the input power cable is connected to the motor connection of the drive).							
	0 = DISABLE - No action.		D M//DINO					
	1 = ENABLE – The drive to	rips on fault 0035 00 H	P WIRING.					

Group 31: Automatic reset

This group defines conditions for automatic resets. An automatic reset occurs after a particular fault is detected. The drive holds for a set delay time, then automatically restarts. You can limit the number of resets in a specified time period, and you can set up automatic resets for a variety of faults.


	Group 31: Automatic reset							
Code	Description	Range	Resolution	Default	S			
3101	NUMBER OF	05	1	5				
	TRIALS							
	Sets the number of allowed a 3102 TRIAL TIME.	utomatic resets withir	n a trial period defir	ned by param	neter			
	If the number of automatic		Trial time					
	exceeds this limit (within the				Time			
	time), the drive prevents a	,	((-			
	stopped.		matic reset					
	Starting then requires a successful reset performed from the control panel or from a source selected by parameter 1604 FAULT RESET SEL.							
	Example: Three faults have occurred in the trial time. The last is reset only if the value for parameter 3101 NUMBER OF TRIALS is 3 or more.							
3102	TRIAL TIME	1.0 600.0 s	0.1 s	30.0 s				
	Sets the time period used for counting and limiting the number of resets.							
	See parameter 3101 NUMBER OF TRIALS.							
3103	DELAY TIME	0.0 120.0 s	0.1 s	0.5 s				
	Sets the delay time between a fault detection and attempted drive restart.							
	If DELAY TIME = zero, the	drive resets immedia	ately.					
3104	AR OVERCURRENT	0, 1	1	0				
3104	Sets the automatic reset for the overcurrent function on or off.							
3104	Sets the automatic reset for t	he overcurrent function	on on or off.					
3104	Sets the automatic reset for t 0 = DISABLE – Disables auto		on on or off.					
3104		omatic reset. matic reset.						

	Group 31: Automatic reset					
Code	Description	Range	Resolution	Default	S	
3105	AR OVERVOLTAGE	0, 1	1	1		
	Sets the automatic reset for th	e intermediate link	overvoltage functio	n on or off.		
	0 = DISABLE – Disables autor					
	1 = ENABLE – Enables automAutomatically resets fault		O/ T after the delay i	eat by param	otor	
	3103 DELAY TIME, and t			set by parain	ElEi	
3106	AR	0, 1	1	1		
	UNDERVOLTAGE					
	Sets the automatic reset for th	e intermediate link	undervoltage functi	on on or off.		
	0 = DISABLE – Disables autor 1 = ENABLE – Enables autom					
	 Automatically resets the fault 0006 DC UNDERVOLT after the delay set by parameter 3103 DELAY TIME, and the drive resumes normal operation. 					
3107	AR AI <min< td=""><td>0, 1</td><td>1</td><td>1</td><td></td></min<>	0, 1	1	1		
	Sets the automatic reset for th off.	e analog input less	than minimum valu	ie function oi	n or	
	0 = DISABLE – Disables autor					
	1 = ENABLE – Enables autom		200 4 0000 410 1	000 -6 45	_	
	 Automatically resets fault delay set by parameter 3 operation. 				е	
	WARNING! When the an	0 1 0	,	,		
	after a long stop. Make su		long delayed starts	will not caus	е	
3108	physical injury and/or damage AR EXTERNAL FLT	0, 1	1	1		
3100	Sets the automatic reset for ex	•	•			
	0 = DISABLE – Disables autor		on on or on.			
	1 = ENABLE – Enables autom					
	Automatically resets the f the delay set by paramete operation.	ault (0014 EXT FA er 3103 DELAY TII	<i>ULT 1</i> or <i>0015 EXT ME</i> , and the drive re	FAULT 2) aff sumes norm	ter al	

Group 32: Supervision

This group defines supervision for up to three signals from *Group 01: Operating data*. Supervision monitors a specified parameter and energizes a relay output if the parameter passes a defined limit. Use *Group 14: Relay outputs*, to define the relay and whether the relay activates when the signal is too low or too high.

	Gro	oup 32: Supervision	า		
Code	Description	Range	Resolution	Default	S
3201	SUPERV 1 PARAM	101199	1	103	
	Selects the first supervised p	arameter.			
	Must be a parameter number	per from Group 01: Ope	erating data.		
	 If the supervised parameter 	er passes a limit, a rela	y output is energi	zed.	
	The supervision limits are	defined in this group.			
	The relay outputs are defir which supervision limit is n	•	outputs (definitio	n also speci	fies
	LO≤HI		Value of super	vised paramet	er
	Operating data supervision using relay outputs, when LO ≤ HI.	HI (3203) LO (3202)			
	Case A = Parameter 1401 RELAY OUTPUT 1 (or 1402 RELAY OUTPUT 2, etc.) value is SUPRV1 OVER or SUPRV 2 OVER Use for monitoring when/if the supervised signal exceeds a given limit. The relay remains active until the supervised value drops below the low limit. Case B = Parameter 1401 value is SUPRV 1 UNDER supervised signal falls belo supervised value rises about 1401 value is SUPRV 1 UNDER supervised value rises about 1401 va	Case B Energized (1) RELAY OUTPUT 1 (or or SUPRV 2 UNDER. ow a given limit. The repove the high limit.	Use for monitoring lay remains active	ng when/if th	,



	Group 32: Supervision						
Code	Description	Range	Resolution	Default	S		
3208	SUPERV 3 LIM LO	Depends on selection		100.0%			
	Sets the low limit for the third supervised parameter. See parameter 3207 SUPERV 3 PARAM above. Supervision wakes up if the value is below the limit.						
3209	SUPERV 3 LIM HI	Depends on selection		100.0%			
	ŭ	third supervised parameter. ion wakes up if the value is	•	3207 SUPEI	RV 3		

Group 33: Information

This group provides access to information about the drive's current programs: versions and test date.

	Group 33: Information						
Code	Description	Range	Resolution	Default	S		
3301	FIRMWARE	10000FFFF hex	1	Firmware ver.			
	Contains the version of the	drive's firmware.					
3302	LOADING PACKAGE	0000FFFF hex	1	0			
	Contains the version of the	loading package.					
3303	TEST DATE	yy.ww	1	0			
	Contains the test date (yy.w	w).					
3304	DRIVE RATING	-	-	-			
	Indicates the drive's current	and voltage rating. The	format is XXXY	hex, where:			
	XXX =The nominal currer decimal point in the rating nominal current rating of	for the current. For exa			es a		
	 Y = The voltage rating of 	the drive, where Y = :					
	2 indicates a 2002404 indicates a 3804806 indicates a 500600	Volt rating.					
3305	PARAMETER TABLE	0000FFFF hex					
	Contains the parameter table	e version of the drive's	firmware.				

Group 34: Panel display

This group defines the content for control panel display (middle area), when the control panel is in the Output mode.

	Gr	oup 34: Panel dis	play	
Code	Description	Range	Resolution	Default S
3401	SIGNAL1 PARAM	100178	1	103
	Selects the first parameter displayed on the control parameter displayed on the control parameter of the control output mode. • Any <i>Group 01: Operating</i> parameter number can be using the following parameter of the convenient units, and/or the figure identifies selected – First parameter of the convenient units, and/or the figure identifies selected – First parameter of the convenient units, and/or the figure identifies selected – First parameter of the convenient units, and/or the figure identifies selected – First parameter of the convenient units, and/or the figure identifies selected – First parameter of the control of the	nel. lefine display panel is in the data e selected. neters, the ed, converted or displayed as a bar attions made by parar arameter not displayed	graph. neters in this group	
3402	SIGNAL1 MIN Defines the minimum experthe first display parameter. Use parameters 3402, 340, 3407, for example to converse parameter, such as 0102 Stothe speed of a conveyor motor (in ft/min). For such at the source values in the figurand max. motor speed, and values are the corresponding max. conveyor speed. Use 3405 to select the proper undisplay. Note: Selecting units does	3, 3406, and rt a Group 01 PEED (in rpm) driven by the a conversion, are are the min. the displaying min. and parameter nits for the	olay e 077 – — — — — — — — — — — — — — — — — — —	0.0 Hz
3403	_	Depends on selecti	on -	600.0 Hz
	Defines the maximum expe	cted value for the firs	t display parameter	
	Note: Parameter is not effer (DIRECT).	ctive if parameter 34	04 OUTPUT1 DSP	<i>FORM</i> = 9

Note: Parameter is not effective if parameter 3404 OUTPUT1 DSP FORM = 9

(DIRECT).

	(Group 34: Panel display	У	
Code	Description	Range	Resolution	Default S
3407	OUTPUT1 MAX	Depends on selection	1	-
	Sets the maximum value	displayed for the first displa	ay parameter.	
	Note: Parameter is not e (DIRECT).	ffective if parameter 3404 C	OUTPUT1 DSP F	FORM = 9
3408	SIGNAL2 PARAM	100178	1	104
	Selects the second parar parameter 3401 SIGNAL	neter (by number) displayed 1 <i>PARAM</i> .	d on the control p	oanel. See
3409	SIGNAL2 MIN	Depends on selection	1	-
	Defines the minimum exp parameter 3402 SIGNAL	pected value for the second 1 MIN.	display paramet	ter. See
3410	SIGNAL2 MAX	Depends on selection	1	-
	Defines the maximum ex parameter 3403 SIGNAL	pected value for the second 1 MAX.	d display parame	ter. See
3411	OUTPUT2 DSP FORM	09	1	-
	Defines the decimal point 3404 OUTPUT1 DSP FC	t location for the second dis <i>PRM</i> .	play parameter.	See parameter
3412	OUTPUT2 UNIT	0127	1	1
	Selects the units used win OUTPUT1 UNIT.	th the second display paran	neter. See paran	neter 3405
3413	OUTPUT2 MIN	Depends on selection	1	-
	Sets the minimum value 3406 OUTPUT1 MIN.	displayed for the second dis	splay parameter.	See parameter
3414	OUTPUT2 MAX	Depends on selection	1	-
	Sets the maximum value 3407 OUTPUT1 MAX.	displayed for the second di	isplay parameter	. See parameter
3415	SIGNAL3 PARAM	100178	1	120
	Selects the third parameter parameter 3401 SIGNAL	er (by number) displayed o 1 <i>PARAM</i> .	n the control par	nel. See
3416	SIGNAL3 MIN	Depends on selection	1	-
	Defines the minimum exp 3402 SIGNAL1 MIN.	pected value for the third dis	splay parameter.	See parameter
3417	SIGNAL3 MAX	Depends on selection	1	-
	Defines the maximum ex 3403 SIGNAL1 MAX.	pected value for the third di	splay parameter	. See parameter
3418	OUTPUT 3 DSP	09	1	1
	FORM			
	Defines the decimal point OUTPUT1 DSP FORM.	location for the third display	y parameter. See	e parameter 3404

	Group 34: Panel display					
Code	Description	Range	Resolution	Default	S	
3419	OUTPUT3 UNIT	-128127	1	11		
	Selects the units used with the third display parameter. See parameter 3405 OUTPUT1 UNIT.					
3420	OUTPUT3 MIN	Depends on selection	1	-		
	Sets the minimum value 3406 OUTPUT1 MIN.	e displayed for the third displa	y parameter. Se	ee parameter		
3421	OUTPUT3 MAX	Depends on selection	1	-		
	Sets the maximum value displayed for the third display parameter. See parameter 3407 OUTPUT1 MAX.					

Group 35: Motor temp meas

	Gı	roup 35: Motor tei	mp mea	as		
Code	Description	Range		Resolution	Default	S
3501	SENSOR TYPE	06		1	0	
	Activates the motor temp See also parameter <i>Gro</i>			on and selects th	ie sensor typ	e.
	0 = NONE – Function is	inactive.				
	resistance increases sensor. The tempera input AI1/2 and con	out AO feeds constant is as the motor tempe ature measurement for verts it to degrees ce	it current rature ris unction r entigrade	through the ser ses, as does the reads the voltage	nsor. The ser voltage over through and	the alog
	2 = 2 x PT100 – Function sensors. See select	n is active. The temp ion 1 x PT100 above		s measured usir	ig two Pt100	,
	3 = 3 x PT100 – Function sensors. See select	n is active. The temp	erature i	s measured usir	ng three Pt10)0
	function reads the v analog input AI1/2 a ohms. The figure or shows typical PTC s values as a function operating temperatu	ervised using one goutput AO feeds ough the sensor. It is easier temperature rises ence temperature roltage over the rature measurement roltage through and converts it into the right-hand side sensor resistance in of the motor ure.	Ohm 4000 1330 550			
	Temperature	Resistance			l I	
	Normal	0 1.5 kohm		1 1 1	1 1 1 1	т
	thermistor relay con 6 = THERM (1) – Function sensor (see selection	on PTC) connected to inected to a digital in on is active. The mote on PTC) connected to inected to a digital in	o a drive put. 0 = i or tempe o a drive put. 1 = i	through a norma motor overtempe rature is monito through a norma motor overtempe	ally closed erature. red using a f ally open erature.	PTC


	Group	35: Motor temp	meas		
Code	Description	Range	Resolution	Default	S
3502	INPUT SELECTION	17	1	1	
	Selects the source for the mo	otor temperature mea	asurement signal.		
	1 = AI1 – Analog input AI1. L temperature measureme		PTC sensor is selec	ted for the	
	2 = AI2 – Analog input AI2. L temperature measureme		PTC sensor is selec	ted for the	
	3 = DI1 – Digital input DI1. Us set to THERM(0)/THER	sed when the value o M(1).	of parameter 3501 S	ENSOR TYP	E is
	4 = DI2 – Digital input DI2. U: THERM(0)/THERM(1).	sed when parameter	3501 SENSOR TY	PE value is se	et to
	5 = DI3 – Digital input DI3. U: THERM(0)/THERM(1).	sed when parameter	3501 SENSOR TY	PE value is se	et to
	6 = DI4 – Digital input DI4. U: THERM(0)/THERM(1).	sed when parameter	3501 SENSOR TY	PE value is se	et to
	7 = DI5 – Digital input DI5. U: THERM(0)/THERM(1).	sed when parameter	3501 SENSOR TY	PE value is se	et to
3503	ALARM LIMIT	хх	1	0	
	Defines the alarm limit for mo TEMP indication is given who TYPE value is set to THERM	en the limit is exceed	ed. When paramete		SOR
3504	FAULT LIMIT	хх	1	0	
	Defines the fault trip limit for 0009 MOT OVERTEMP whe TYPE value is set to THERM	n the limit is exceede	ed. When paramete	•	
3505	AO EXCITATION			0	
	Enables current feed from ar settings in <i>Group 15: Analog</i>	• .	parameter setting	overrides the	
	With PTC the output curre	nt is 1.6 mA.			
	With Pt 100 the output cur	rent is 9.1 mA.			
	0 = DISABLE 1 = ENABLE				

Group 36: Timed functions

This group defines the timed functions. The timed functions include:

- · four daily start and stop times
- · four weekly start, stop and boost times
- · four timers for collecting selected periods together.

A timer can be connected to multiple time periods and a time period can be in multiple timers.



A parameter can be connected to only one timer.



If the parameter value is 09:00:00, then the period will be deactivated at 9 a.m.

	G	roup 36: Timed functio	ns			
Code	Description	Range	Resolution	Default	S	
3604	START DAY 1	17	1	1		
	Defines the weekly start	day.				
	1 = MONDAY7 = SUN	DAY.				
	If parameter value is (00:00:00).	s 1, then period 1 weekly is	active from Mon	day midnight		
3605	STOP DAY 1	17	1	1		
	Defines weekly stop day					
	1 = MONDAY7 = SUN	DAY.				
	 If parameter value is (23:59:58). 	s 5, then timer 1 weekly will	be deactivated o	n Friday midn	night	
3606	START TIME 2	00:00:00 23:59:58	2 s	12:00:00		
	Defines timer 2 daily sta	rt time.				
	See parameter 3602 \$	START TIME 1.				
3607	STOP TIME 2	00:00:00 23:59:58	2 s	12:00:00		
	Defines timer 2 daily stop time.					
	See parameter 3603 3	STOP TIME 1.				
3608	START DAY 2	17	1	1		
	Defines timer 2 weekly start day.					
	See parameter 3604 \$	START DAY 1.				
3609	STOP DAY 2	17	1	1		
	Defines timer 2 weekly stop day.					
	See parameter 3605 3	STOP DAY 1.				
3610	START TIME 3	00:00:00 23:59:58	2 s	12:00:00		
	Defines timer 3 daily sta	rt time.				
	See parameter 3602 3	START TIME 1.				
3611	STOP TIME 3	00:00:00 23:59:58	2 s	12:00:00		
	Defines timer 3 daily sto	p time.				
	See parameter 3603 3	STOP TIME 1.				
3612	START DAY 3	17	1	1		
	Defines timer 3 weekly start day.					
	See parameter 3604 3	START DAY 1.				
3613	STOP DAY 3	17	1	1		
	Defines timer 3 weekly s	top day.				
	See parameter 3605 3	STOP DAY 1.				
3614	START TIME 4	00:00:00 23:59:58	2 s	12:00:00		
	Defines timer 4 daily sta	rt time.				
	See parameter 3602 3	START TIME 1.				
3615	STOP TIME 4	00:00:00 23:59:58	2 s	12:00:00		
	Defines timer 4 daily sto	p time.				
	See parameter 3603 3	STOP TIME 1.				

	Group 36: Timed functions					
Code	Description	Range	Resolution	Default	S	
3616	START DAY 4	17	1	1		
	Defines timer 4 weekly sta	art day.				
	See parameter 3604 ST	TART DAY 1.				
3617	STOP DAY 4	17	1	1		
	Defines timer 4 weekly sto	op day.				
	See parameter 3605 ST	TOP DAY 1.				
3622	BOOST SEL	-66	1	0		
	Selects the source for the	booster signal.				
	0 = NOT SEL – Booster s					
	1 = DI1 – Defines DI1 as t					
		s DI2DI5 as the booster n inverted digital input DI1		ianal		
		NV) – Defines an inverted (
	booster signal.					
3623	BOOSTER TIME	00:00:00 23:59:58	2 s	12:00:00		
	Defines the booster ON	Г	ı			
	time. Time is started	Booster active	i İ			
	when booster sel signal	<u> </u>		ĺ		
	is released. If parameter range is 01:30:00, then	Activation DI		·		
	booster is active for 1		1	_		
	hour and 30 minutes		Booster tin	ne I		
	after activation DI is		1 Booster til	IIC I		
	released.					

	Gro	up 36: Timed funct	tions				
Code	Description	Range	Resolution	Default	S		
3626	TIMER 1 SRC	031	1	0			
	Defines the time periods used by the timer. 0 = NOT SEL- No timers have been selected.						
	1 = P1 – Time Period 1 selected in the timer.						
	2 = P2 – Time Period 2 selected in the timer.						
	3 = P1+P2 – Time Periods		e timer.				
	4 = P3 - Time Period 3 selection		timor				
	6 = P2+P3 - Time Periods						
	7 = P1+P2+P3 – Time Period						
	8 = P4 – Time Period 4 selected in the timer.						
	9 = P1+P4 – Time Periods 4 and 1 selected in the timer.						
	10 = P2+P4 - Time Periods						
	11 = P1+P2+P4 – Time Periods 4, 2 and 1 selected in the timer.						
	12 = P3+P4 – Time Periods 4 and 3 selected in the timer.						
	13 = P1+P3+P4 – Time Periods 4, 3 and 1 selected in the timer. 14 = P2+P3+P4 – Time Periods 4, 3 and 2 selected in the timer.						
	15 = P1+P2+P3+P4 – Time Periods 4, 3, 2 and 1 selected in the timer.						
	16 = BOOST – Booster selected in the timer.						
	17 = P1+B – Booster and T	ime Period 1 selected	in the timer.				
	18 = P2+B – Booster and T						
	19 = P1+P2 B – Booster an						
	20 = P3+B – Booster and T 21 = P1+P3+B – Booster a						
	22 = P2+P3+B – Booster and Time Periods 3 and 2 selected in the timer. 23 = P1+P2+P3+B – Booster and Time Periods 3, 2 and 1 selected in the timer.						
	24 = P4+B – Booster and Time Periods 4 selected in the timer.						
	25 = P1+P4+B – Booster and Time Period 4 and Timer 1 selected in the timer.						
	26 = P2+P4+B – Booster and Time Period 4 and 2 selected in the timer.						
	27 = P1+P2+P4+B – Booster and Time Periods 4, 2 and 1 selected in the timer.						
	28 = P3+P4+B – Booster at						
	29 = P1+P3+P4+B – Booster and Time Periods 4, 3 and 1 selected in the timer. 30 = P2+P3+P4+B – Booster and Time Periods 4, 3 and 2 selected.						
	31 = P1+2+3+4+B - Booste		•	d.			
3627	TIMER 2 SRC	031	1	0			
	See parameter 3626.						
3628	TIMER 3 SRC	031	1	0			
	See parameter 3626.						
3629	TIMER 4 SRC	031	1	0			
	See parameter 3626.						

Group 37: User load curve

This new group defines supervision of user adjustable load curves (motor torque as a function of frequency). The curve is defined by five points. - The function replaces deleted underload parameters 3013...3015

	Gre	oup 37: User load cu	rve		
Code	Description	Range	Resolution	Default	S
3701	USER LOAD C MODE	03	1	0	
	Supervision mode for the user adjustable load	Motor torque (%)			i.
	curves. This functionality replaces the former underload supervision in		Overload area	ì	
	Group 30: Fault functions.	3706 3709	3712 37 37	15 37 14 37	718 717
	0 = NOT SEL – Supervision is not active. 1 = UNDERLOAD – Supervision for the torque dropping below the underload	Allowed operating a	area 3711 Underload are	ea	
	curve. 2 = OVERLOAD – Supervision for the torque exceeding the overload curve.	3708 3704 3707	3710 371 Ou	3 37 tput frequency	716 (Hz)
	3 = BOTH – Supervision for exceeding the overload	or the torque dropping be ad curve.	low the underload	d curve or	
3702	USER LOAD C FUNC	1, 2	1	1	
	Action wanted during load	supervision.			
	2 = ALARM – An alarm is	d longer than the time set	by 3703 USER L ition defined by 3	OAD C TIME 701 USER L	E. OAD
3703	USER LOAD C TIME	10 400 s		20 s	
	Defines the time limit for generating an alarm.	enerating a fault. Half of t	this time is used a	s the limit fo	r
3704	LOAD FREQ 1	0 500 Hz		5 Hz	
	Defines the frequency valuation 3707 LOAD FREQ 2.	ue of the first curve definit	tion point. Must be	e smaller tha	n
3705	LOAD TORQ LOW 1	0 600%		10%	
	Defines the torque value o than 3706 LOAD TORQ H		e definition point.	Must be sma	aller
3706	LOAD TORQ HIGH 1	0 600%		300%	
	Defines the torque value o	f the first overload curve	definition point.		

Group 37: User load curve						
Description	Range	Resolution	Default	S		
LOAD FREQ 2	0 500 Hz		25%			
Defines the frequency value 3710 LOAD FREQ 3.	of the second curve d	efinition point. Mus	st be smaller	than		
LOAD TORQ LOW 2	0 600%		15%			
•		curve definition po	int. Must be			
LOAD TORQ HIGH 2	0 600%		300%			
Defines the torque value of t	the second overload co	urve definition poin	ıt.			
LOAD FREQ 3	0 500 Hz		43 Hz			
Defines the frequency value	of the third load curve	definition point.				
LOAD TORQ LOW 3	0 600%		25%			
		ve definition point.	Must be sma	aller		
LOAD TORQ HIGH 3	0 600%		300%			
Defines the torque value of t	the third overload curv	e definition point.				
LOAD FREQ 4	0 500 Hz		50 Hz			
Defines the frequency value	of the fourth load curv	e definition point.				
LOAD TORQ LOW 4	0 600%		30%			
•		rve definition point	. Must be sm	aller		
LOAD TORQ HIGH 4	0 600%		300%			
Defines the torque overvalue	e of the fourth load cur	ve definition point.				
LOAD FREQ 5	0 500 Hz		500 Hz			
Defines the frequency value	of fifth load curve defi	nition point.				
LOAD TORQ LOW 5	0 600%		30%			
<u>'</u>		e definition point.	Must be sma	ller		
LOAD TORQ HIGH 5	0 600%		300%			
Defines the torque value of t	he fifth overload curve	definition point.				
	Description LOAD FREQ 2 Defines the frequency value 3710 LOAD FREQ 3. LOAD TORQ LOW 2 Defines the torque value of t smaller than 3709 LOAD TO LOAD TORQ HIGH 2 Defines the torque value of t LOAD FREQ 3 Defines the frequency value LOAD TORQ LOW 3 Defines the torque value of t than 3712 LOAD TORQ HIGH 3 Defines the torque value of t than 3712 LOAD TORQ HIGH 3 Defines the frequency value LOAD TORQ LOW 4 Defines the frequency value LOAD TORQ LOW 4 Defines the torque value of t than 3715 LOAD TORQ HIGH 4 Defines the torque overvalue LOAD TORQ HIGH 4 Defines the frequency value LOAD TORQ LOW 5 Defines the frequency value LOAD TORQ LOW 5 Defines the torque value of t than 3718 LOAD TORQ HIGH 5	Description Range LOAD FREQ 2 0 500 Hz Defines the frequency value of the second curve of 3710 LOAD FREQ 3. LOAD TORQ LOW 2 0 600% Defines the torque value of the second underload smaller than 3709 LOAD TORQ HIGH 2. LOAD TORQ HIGH 2 0 600% Defines the torque value of the second overload of LOAD FREQ 3 0 500 Hz Defines the frequency value of the third load curve than 3712 LOAD TORQ HIGH 3. LOAD TORQ LOW 3 0 600% Defines the torque value of the third underload curve than 3712 LOAD TORQ HIGH 3. LOAD TORQ HIGH 3 0 600% Defines the frequency value of the fourth load curve than 3715 LOAD TORQ HIGH 4. LOAD TORQ LOW 4 0 600% Defines the torque value of the fourth underload curve than 3715 LOAD TORQ HIGH 4. LOAD TORQ HIGH 4 0 600% Defines the torque overvalue of the fourth load curve than 3715 LOAD TORQ HIGH 4. LOAD TORQ LOW 5 0 600% Defines the frequency value of the fifth underload curve defines the torque value of the fifth underload curve than 3718 LOAD TORQ HIGH 5. LOAD TORQ HIGH 5 0 600%	Description Range Resolution LOAD FREQ 2 Defines the frequency value of the second curve definition point. Mus 3710 LOAD FREQ 3. LOAD TORQ LOW 2 Defines the torque value of the second underload curve definition po smaller than 3709 LOAD TORQ HIGH 2. LOAD TORQ HIGH 2 Defines the torque value of the second overload curve definition point. LOAD FREQ 3 Defines the frequency value of the third load curve definition point. LOAD TORQ LOW 3 Defines the torque value of the third underload curve definition point. LOAD TORQ HIGH 3 LOAD TORQ HIGH 3 Defines the torque value of the third overload curve definition point. LOAD TORQ HIGH 3 Defines the torque value of the fourth load curve definition point. LOAD TORQ LOW 4 Defines the frequency value of the fourth load curve definition point. LOAD TORQ LOW 4 Defines the torque value of the fourth load curve definition point. LOAD TORQ HIGH 4 LOAD TORQ HIGH 4 Defines the torque value of the fourth load curve definition point than 3715 LOAD TORQ HIGH 4. LOAD TORQ HIGH 4 Defines the torque overvalue of the fourth load curve definition point. LOAD FREQ 5 Defines the frequency value of fifth load curve definition point. LOAD TORQ LOW 5 Defines the torque value of the fifth underload curve definition point. LOAD TORQ LOW 5 Defines the torque value of the fifth underload curve definition point.	Description Range Resolution Default LOAD FREQ 2 0 500 Hz 25% Defines the frequency value of the second curve definition point. Must be smaller 3710 LOAD FREQ 3. LOAD TORQ LOW 2 0 600% 15% Defines the torque value of the second underload curve definition point. Must be smaller than 3709 LOAD TORQ HIGH 2. LOAD TORQ HIGH 2 0 600% 300% Defines the torque value of the second overload curve definition point. LOAD FREQ 3 0 500 Hz 43 Hz Defines the frequency value of the third load curve definition point. LOAD TORQ LOW 3 0 600% 25% Defines the torque value of the third underload curve definition point. Must be sm. than 3712 LOAD TORQ HIGH 3. LOAD TORQ HIGH 3 0 600% 300% Defines the torque value of the third overload curve definition point. LOAD FREQ 4 0 500 Hz 50 Hz Defines the frequency value of the fourth load curve definition point. Must be sm. than 3715 LOAD TORQ HIGH 4. LOAD TORQ LOW 4 0 600% 30% Defines the torque value of the fourth underload curve definition point. Must be sm. than 3715 LOAD TORQ HIGH 4. LOAD TORQ HIGH 4 0 600% 30% Defines the torque overvalue of the fourth load curve definition point. Must be sm. than 3715 LOAD TORQ HIGH 4. LOAD TORQ HIGH 4 0 600% 30% Defines the frequency value of fifth load curve definition point. LOAD TORQ HIGH 4 0 600% 30% Defines the torque overvalue of the fourth load curve definition point. LOAD TORQ LOW 5 0 600% 30% Defines the torque value of the fifth underload curve definition point. Must be smathan 3718 LOAD TORQ HIGH 5. LOAD TORQ HIGH 5 0 600% 300%		

Group 40: Process PID set 1

This group defines a set of parameters used with the Process PID (PID1) controller.


Typically only parameters in this group are needed.

PID controller - basic set-up

In PID control mode, the drive compares a reference signal (setpoint) to an actual signal (feedback), and automatically adjusts the speed of the drive to match the two signals. The difference between the two signals is the error value.

Typically PID control mode is used, when the speed of a fan or pump needs to be controlled based on pressure, flow or temperature. In most cases – when there is only 1 transducer signal wired to the drive – only parameter group 40 is needed.

A schematic of setpoint/feedback signal flow using parameter group 40 is presented below



Note: To activate and use the PID controller, parameter 1106 REF2 SELECT must be set to value 19.

PID controller - advanced

ACS320 has 2 separate PID controllers:

- Process PID (PID1)
- External PID (PID2).

Process PID (PID1) has 2 separate sets of parameters:

- Process PID (PID1) SET1, defined in Group 40: Process PID set 1
- Process PID (PID1) SET2, defined in Group 41: Process PID set 2.

You can select between the 2 different sets by using parameter 4027 PID 1 PARAM SET.

Typically two different PID controller sets are used when the load of the motor changes considerably from one situation to another.


You can use External PID (PID2), defined in Group 42: Ext / Trim PID, in 2 different ways:

- · Instead of using additional PID controller hardware, you can set outputs of the ACS320 to control a field instrument like a damper or a valve. In this case, set Parameter 4230 to value 0. (0 is the default value.)
- You can use External PID (PID2) as an additional PID controller to Process PID (PID1) to trim or fine-tune the speed of the ACS320.

An example of the trimming is a return fan that follows the speed of the supply fan. As the return fan needs to run faster or slower then the supply fan in order to create under- or overpressure, correction factors to the supply fan speed are needed. Use External PID (PID2) in the return fan drive to provide these corrections.

signal.

	Group 40: Process PID set 1						
Code	Description	Range	Resolution	Default	S		
4001	GAIN	0.1 100.0	0.1	2.5			
	Defines the PID controll	er's gain.					
	At 0.1, the PID contro	ller output changes one-te	nth as much as the	e error value.			
	At 100, the PID contro value.	oller output changes one h	undred times as m	uch as the e	rror		
	Use the proportional gain and integration time values to adjust the responsiveness the system.						
	• Low value for proportional gain and a high value for integral time ensures stable operation, but provides sluggish response.						
	If the proportional gain value is too large or the integral time too short, the system become unstable.						
	Procedure:						
	Initially, set:						
	• 4001 GAIN = 0.1.						
		N TIME = 20 seconds. see if it reaches the setpoi	nt avialdu while ma	intainina atal	hla		
	operation. If not, incre	ease GAIN (4001) until the transport to sta	actual signal (or d	rive speed)			
	Reduce GAIN (4001)	until the oscillation stops.					
	 Set GAIN (4001) to 0. 	4 to 0.6 times the above v	alue.				
		RATION TIME (4002) until t may be necessary to sta	•		,		
	Increase INTEGRATION	ON TIME (4002) until the o	oscillation stops.				
	• Set INTEGRATION T	IME (4002) to 1.15 to 1.5 t	imes the above va	lue.			
	_	contains high frequency n ER AI1 or 1306 FILTER A			the		



	Grou	p 40: Process PIE) set 1		
Code	Description	Range	Resolutio	n De	fault S
4005	ERROR VALUE INV	0, 1	-		0
	Selects either a normal or ir drive speed.	nverted relationship b	etween the feed	back sigr	nal and the
	0 = NO – Normal, a decreas Fbk	· ·		•	
	1 = YES – Inverted, a decre - Ref		al decreases driv	e speed.	
4006	UNITS	031	-		4
	Selects the unit for the PID (0132).				8, <i>0130</i> , and
4007	See parameter 3405 OUT UNIT SCALE	TPUT1 UNIT for list o	of available units.		1
4007			•		1
	Defines the decimal point lo controller actual values.	ication in PID	4007 value	Entry	Display
	Enter the decimal point lo	cation counting in	0	0003	3
	from the right of the entry	' .	1	0031	3.1
	 See table for example us 	ing pi (3.14159).	2	0314	3.14
			3	3142	3.142
4008	0 % VALUE	-1000.0 1000.0%	0.1%	0	.0%
	Defines (together with the n parameter) the scaling appl PID controller's actual value parameters 0128, 0130, and	ied to the Scale			+10009
	Units and scale are define parameters 4006 UNITS UNIT SCALE.	•			
		4008			
			<u> </u>		<u> </u>
		, ,	0%	1	00%
		-1000%		Intern	al scale (%)
4009	100 % VALUE	-1000.0 1000.0%	0.1%	1	00%
	Defines (together with the p controller's actual values.	revious parameter) th	ne scaling applie	d to the F	PID
	Units and scale are define	ed by parameters 400	06 UNITS and 40	วด7 มมเา	SCALE

	Gro	up 40: Process PID	set 1							
Code	Description	Range	Resolution	Default	S					
4010	SET POINT SEL	019	1	0	✓					
	Defines the reference sign	al source for the PID co	ntroller.							
	 Parameter has no significance when the PID regulator is by-passed (see parameter 8121 REG BYPASS CTRL). 									
	0 = KEYPAD - Control par	nel provides reference.								
	1 = Al1 – Analog input 1 p	rovides reference.								
	2 = Al2 – Analog input 2 provides reference.									
	8 = COMM – Fieldbus provides reference.									
	9 = COMM+AI1 – Defines a fieldbus and analog input 1 (AI1) combination as the reference source. See Analog Input Reference Correction below.									
	10 = COMM*Al1 – Defines a fieldbus and analog input 1 (Al1) combination as the									
	reference source. See Analog Input Reference Correction below.									
	11 = DI3U, 4D(RNC) – Dig reference.				vide					
	DI3 increases the speed (the U stands for "up")									
	DI4 decreases the ref	•	,							
	 Parameter 2205 ACC R = Stop command re 	esets the reference to ze		l's rate of cha	ange.					
	NC = Reference value	-								
	12 = DI3U, 4D(NC) – Sam									
		tion rate, to the stored re	eference.		•					
		ce. See Analog Ìnput Re	eference Correction	n below.						
	15 = AI1*AI2 – Defines an the reference source.	analog input 1 (AI1) and See Analog Input Refei			on as					
	16 = Al1-Al2 – Defines an a the reference source.	analog input 1 (AI1) and See Analog Input Refei			on as					
	17 = AI1/AI2 – Defines and the reference source.	analog input 1 (AI1) and See Analog Input Refei	analog input 2 (Al2 rence Correction be	 combination combination 	on as					
	19 = INTERNAL – A const									

	Group 40: Process PID set 1									
Code	Description	Range	Resolution	Default S						
	Analog input reference	correction								
	Parameter values 9, 10), and 1417 use the formu	ula in the following	table.						
	Value Setting	Al reference is calculated as	following:							
	C + B	C value + (B value - 50% of re	ference value)							
	C * B	C value * (B value / 50% of ref	erence value)							
	C - B	(C value + 50% of reference value) - B value								
	C/B	(C value * 50% of reference va	C value * 50% of reference value) / B value							
	Where: • C = Main Reference value (= COMM for values 9, 10 and = Al1 for values 1417).									
	 B = Correcting reference 	ence (= Al1 for values 9, 10	and = Al2 for value	es 14…17).						
	Example:	120 🕇								
	The figure shows the reference source curve for value settings 9, 10 and 1417, where: • C = 25%. • Parameter 4012 SETPOINT MIN = 0. • Parameter 4013 SETPOINT MAX = 0. • B varies along the horizontal axis. 31 = DI4U, 5D(NC) - S selection DI3U,4D(NC). 32 = FREQ INPUT - F	80		9, 14 (+) 						
4011	INTERNAL SETPN		0.1%	40.0%						
	SET POINT SEL value		·							
	and 4007 UNIT SCA	nd on the unit and scale de <i>LE</i> .	illed by parameter	5 4000 UNI I S						

	Group 40: Process PID set 1							
Code	Description	Range	Resolution	Default	S			
4012	SETPOINT MIN	0.0%						
	Defines the minimum value parameter 4010 SET POIN	T SEL. Value in percen	t.					
	Example: Analog input AI1 is selected as the PID reference source (value of parameter 4010 is AI1). The reference minimum and maximum correspond to the 1301 MINIMUM AI1 and 1302 MAXIMUM AI1 settings as follows.							
	Ref 4013 (MAX)	Ref (> MIN 4012 (MIN)	MIN > MAX					
	4012 (MIN)	4013 (MAX) 1302 Al1 (%)	1301 1302 A	► I1 (%)				
4013	SETPOINT MAX	-500.0 500.0%	0.1%	100.0%				
	Defines the maximum value parameters 4010 SET POIN		•					
4014	FBK SEL	110	1	1				
	Defines the PID controller for	eedback (actual signal)).					
	You can define a combinate feedback signal.	ation of two actual valu	es (ACT1 and ACT	Γ2) as the				
	 Use parameter 4016 ACT 	T1 INPUT to define the	source for actual v	value 1 (ACT	1).			
	 Use parameter 4017 ACT 	T2 INPUT to define the	source for actual v	value 2 (ACT	2).			
	1 = ACT1 – Actual value 1 (ACT1) provides the feedback signal.							
	2 = ACT1-ACT2 - ACT1 mi 3 = ACT1+ACT2 - ACT1 pl							
	4 = ACT1*ACT – ACT1 time							
	5 = ACT1/ACT2 - ACT1 div			nal.				
	6 = MIN (ACT1, 2) – The sn							
	7 = MAX (ACT1, 2) – The g 8 = sqrt(ACT1-2) – Square feedback signal.							
	9 = sqA1 + sqA2 – Square i feedback signal.	·	•	·	ie			
	10 = sqrt(ACT1) – Square r	•	•					
	11 = COMM FBK 1 – Signal 12 = COMM FBK 2 – Signa							
	13 = AVE(ACT1,2) – The av							

	Gro	up 40: Process PID s	et 1		
Code	Description	Range	Resolution	Default	S
4015	FBK MULTIPLIER	-32.76832.767	0.001	0	
	Defines an extra multiplier	for the PID FBK value def	ined by paramete	er 4014 FBK	SEL.
	 Used mainly in applicati difference. 	ons where the flow is calc	culated from the p	oressure	
	0 = NOT SELECTED. -32.76832.767 = Multipli SEL.	er applied to the signal de	efined by parame	ter <i>4014 FBI</i>	K
	Example: FBK = Multip	$lier \times \sqrt{A1 - A2}$			
4016	ACT1 INPUT	15	1	2	✓
	Defines the source for actu	ual value 1 (ACT1).			
	1 = Al 1 – Uses analog inp				
	2 = Al 2 – Uses analog inp				
	3 = CURRENT – Uses cur • Min ACT1 = 0 current				
	Max ACT1 = 0 current Max ACT1 = 2 x nom				
	4 = TORQUE – Uses torqu				
	Min ACT1= -2 x nomi				
	 Max ACT1 = 2 x nom 	•			
	5 = POWER – Uses powe	•			
	 Min ACT1 = -2 x nom Max ACT1 = 2 x nom 				
	6 = COMM ACT 1 – Uses		COMM VAI UF 1	for ACT1	
	7 = COMM ACT 2 – Uses				
	8 = FREQ INPUT				
4017	ACT2 INPUT	15	1	2	✓
	Defines the source for actu	ual value 2 (ACT2).			
	1 = Al 1 – Uses analog inp				
	2 = AI 2 – Uses analog inp 3 = CURRENT – Uses cur				
	Min ACT2 = 0 current				
	• Max ACT2 = 2 x nom				
	4 = TORQUE – Uses torqu				
	• Min ACT2 = -2 x nomina	al torque			
	 Max ACT2 = 2 x nomina 	al torque			
	5 = POWER – Uses powe	r for ACT2, scaled so:			
	• Min ACT2 = -2 x nomina	al power			
	• Max ACT2 = 2 x nomina	al power			
	6 = COMM ACT 1 – Uses	value of signal 0158 PID	COMM VALUE 1	for ACT2.	
	7 = COMM ACT 2 – Uses	•	COMM VALUE 2	for ACT2.	
	8 = FREQ INPUT – Freque	ency input.			

		Gr	oup 40: Pi	rocess PID :	set 1		
Code	Description		F	Range	Resolu	ıtion	Default S
4018	ACT1 INF	ninimum valı e source sigr PUT ACT1 IN	ue for ACT1. nal used as tl	ne actual value arameter 401		fined by	0% y parameter <i>4016</i> I ACT 1) and 7
	Par. 4016	Source		Source min.		Source	max.
	1	Analog input	1	1301 MINIMUN	vi Al1	1302 M	IAXIMUM AI1
	2	Analog input	2	1304 MINIMUN	vi Al2	1305 M	IAXIMUM AI2
	3	Current		0		2 · nom	ninal current
	4	Torque		-2 · nominal to	rque	2 · nom	ninal torque
	5	Power		-2 · nominal po	ower	2 · nom	inal power
	4019 4018 Sc	A 1301 purce min.		4018 -	1301 Source m	B	Source 1302 signal Source max.
4019	ACT1 MAX Sets the max • See 4018	ximum value	for ACT1.	1000%	1%	Ď	100%
4020	ACT2 MIN			1000%	1%	, D	0%
	Sets the min						
	• See 4018 ACT1 MINIMUM.						
4021	ACT2 MAX			1000%	1%	, D	100%
	Sets the ma	ximum value	for ACT2.				
	1						

See 4018 ACT1 MINIMUM.

	Grou	o 40: Process PID	set 1		
Code	Description	Range	Resolution	Default	S
4022	SLEEP SELECTION	-67	-	0	
	Defines the control for the P	ID sleep function.			
	0 = NOT SEL - Disables the 1 = DI1 - Defines digital inpu • Activating the digital inpu • De-activating the digital 25 = DI2DI5 - Defines of function. • See DI1 above. 911 = SUPRV1 UNDER parameter 3201 SUPEI parameter 3203 SUPEI The internal sleep criter WAKE-UP DEV are not PID SI FEP DEI AY and	at 1 as the control for the transport of the state of the	the PID sleep funct function. Introl. as the control for the he function is activer the high limit def 4023 PID SLEEP Latr and stop delay	ated when fined by	
	7 = INTERNAL – Defines the actual value as the continuation WAKE-UP DEV and 40	e output rpm/frequenc	y, process reference unction. Refer to pa	ce, and proce arameters 40	ss 125
	-1 = DI1(INV) – Defines an in function.	nverted digital input D	I1 as the control for	r the PID slee	₽p
	 De-activating the digital 	input activates the sle	eep function.		
	Activating the digital inp-25 = DI2(INV)DI5(INV) for the PID sleep function See DI1(INV) above.	- Defines an inverted		DI5 as the co	ntrol
	-911 = SUPRV1 UNDER. parameter 3201 SUPEI parameter 3202 SUPEI The internal sleep criter WAKE-UP DEV are not 44024 PID SLEEP DEL	RV 1 PARAM stays be RV 1 LIM LO. ia set by parameters 4 effective. The sleep s	low the low limit de 4023 PID SLEEP L start and stop delay	efined by EVEL and 40 parameters	025

	Grou	p 40: Process PID s	et 1		
Code	Description	Range	Resolution	Default	S
4023	PID SLEEP LEVEL	0.0 120.0 Hz / 0 7200 rpm	0.1 Hz / 1 rpm	0.0 Hz	
	Sets the motor speed / frequency / frequency below this level, enables the PID sleep funct Requires 4022 = 7 INTEF See figure: A = PID output Reference Sleep boost step (4031) Selected process actual value Wake-up level deviation (4025) Output frequency t _{sd} = Sleep delay (4024) t < t _{sd} Sleep level (4023)	uency that enables the P for at least the time per ion (stopping the drive). RNAL.	PID sleep function iod 4024 PID SLI feedback.		peed
4024	DID OF EED DELAY	Stop Start	0.1 s	60.0 s	
4024	PID SLEEP DELAY Defines the delay for the sle When the motor speed falls speed exceeds the sleep le • See 4023 PID SLEEP LE	below the sleep level, the vel, the counter is reset.	rameter 4023 PIL	SLEEP LE	

	Grou	p 40: Process PID	set 1					
Code	Description	Range	Resolution	Default	S			
4025	WAKE-UP DEV	0.0 1000%	0.1	0.0				
	Defines the wake-up deviation at least the time period 4		, ,		alue,			
	Parameters 4006 UNITS and 4007 UNIT SCALE define the units and scale. E							
	• Parameter 4005 ERROR VALUE INV = 0, Wake-up level = Setpoint – Wake-up deviation. 4025 August 4026 Wake-up deviation.							
	Parameter 4005 ERROR VALUE INV = 1, Wake-up level = Setpoint + Wake-up deviation.							
	 Wake-up level can be about below setpoint. 	ove or		F				
	See the figure:							
	C = Wake-up level when parameter 4005 ERROR VALUE INV = 1							
	D = Wake-up level when parameter 4005 ERROR VALUE INV = 0							
	E = Feedback is above wake-up level and lasts longer than 4026 WAKE-UP DELAY PID function wakes up.							
	 F = Feedback is below wa PID function wakes up. 	•	onger than 4026 V	VAKE-UP DE	ELAY			
4026	WAKE-UP DELAY	0.00 60.00 s	0.01 s	0.50 s				
	Defines the wake-up delay	_						
	a deviation from the setpoin period re-starts the PID con	· ·	AKE-UP DEV, for a	at least this ti	ime			
	See 4023 PID SLEEP LE	VEL above.						

	Gro	up 40: Process PID s	et 1						
Code	Description	Range	Resolution	Default S					
4027	PID 1 PARAM SET	-611	1	0					
	Defines how selections are made between PID set 1 and PID set 2.								
	PID parameter set selection used.	on. When set 1 is selected	d, parameters 400	014026 are					
	When set 2 is selected, pa	When set 2 is selected, parameters 40014026 are used.							
	25 = DI2DI5 – Defines	put 1 as the control for P nput selects PID set 2. tal input selects PID set 1	ID set selection.	ID set selection.					
	See DI1 above. 7 = SET 2 - PID set 2 (part 811 = TIMER 14 - Def de-activated = PID set See parameter <i>Group 36:</i>	fines the Timer as the cor t 1; Timer activated = PII	trol for the PID se	t selection (Timer					
	-1 = DI1(INV) – Defines an inverted digital input 1 as the control for PID set selection. • Activating the digital input selects PID set 1.								
	De-activating the digit -25 = DI2(INV)DI5(IN for PID set selection. See DI1(INV) above.	tal input selects PID set 2 V) – Defines an inverted (DI5 as the control					
4028	PID OUT MIN	-500.0 500.0%	1 = 0.1%	-100.0%					
	Defines the minimum value	e of PID output.							
4029	PID OUT MAX	-500.0 500.0%	1 = 0.1%	-100.0%					
	Defines the maximum valu	ie of PID output.							
4030	SLEEP BOOST TIME	0.0 3600.0 s	1 = 0.1 s	0.0 s					
	Defines the boost time for <i>STEP</i> .	the sleep boost step. See	e parameter 4031	SLEEP BOOST					
	Referenc								
	4031 SLEEP BOOST STEP	# 4030 SLEEP BOOST TIME							
4031	SLEEP BOOST	0.0 100.0%	1 = 0.1%	0.0%					
	STEP When the drive is entering this percentage for the tim								
4032	PID REF ACC TIME	0.0 1800.0 s	1 = 0.1 s	0.0 s					
	Defines the time for the re-	ference (PID setpoint) ind	crease from 0 to 1	00%.					
	Note: Parameters 4032 Process PID set 2) is used	4036 are active even if th							

	Grou	p 40: Process PID s	set 1		
Code	Description	Range	Resolution	Default	S
4033	PID REF DEC TIME	0.0 1800.0 s	1 = 0.1 s	0.0 s	
	Defines the time for the refe	erence (PID setpoint) de	ecrease from 100 t	to 0%.	
4034	PID REF FREEZE			NOT SEL	
	Freezes the input (reference 0 = NOT SEL - Not selected 1 = DI1 - Reference is frozed 2 = DI2 - See selection DI1 3 = DI3 - See selection DI1 4 = DI4 - See selection DI1 5 = DI5 - See selection DI1 -1 = DI1(INV) - Reference idea -2 = DI2(INV) - See selection -3 = DI3(INV) - See selection -4 = DI4(INV) - See selection -5 = DI3(INV) - See selection -6 = DI4(INV) -6 = DI	d en on the rising edge of s frozen on the falling e on DI1(INV). on DI1(INV).	digital input DI1.		
	-5 = DI5(INV) – See selection	on DI1(INV).			
4035	PID OUT FREEZE Freezes the output of the pr 0 = NOT SEL - Not selected 1 = DI1 - Output is frozen of 2 = DI2 - See selection DI1 3 = DI3 - See selection DI1 4 = DI4 - See selection DI1 5 = DI5 - See selection DI1 -1 = DI1(INV) - Output is froduced by the selection of the select	d in the rising edge of digit	e of digital input DI		
4036	INTERNAL SETPNT2 Selects a constant value as active when parameter 40102 is selected with the input of percent.	<i>0 SET POINT SEL</i> valu	e is set to INTERN	NAL and setp	oint
4037	INTERNAL SETPNT3 Selects a constant value as active when parameter 40103 is selected with the input of percent.	0 SET POINT SEL valu	e is set to INTERN	NAL and setp	oint
4038	INTERNAL SETPNT4 Selects a constant value as active when parameter 40104 is selected with the input opercent.	<i>0 SET POINT SEL</i> valu	e is set to INTERN	NAL and setp	oint

			Group 40: I	Process PID			
	Descripti			Range	Resolution	Default	S
039 I S S S S S S S S S S S S S S S S S S	INT SET	PNT SE	L			NOT SEL	
					setpoint used as the DINT SEL value is		
	Example:						
	4039 INT Digital inp	SETPNT out DI2 =	SEL = INTERNA SEL = DI2 1 T MIN is used as				
					as the reference.		
1 = DI1 0 = 1 = 2 = DI2 - 3 = DI3 - 4 = DI4 - 5 = DI5 - 7 = DI1,2	1 = DI1 0 = 4 1 = 4 2 = DI2 - 3 = DI3 - 4 = DI4 - 5 = DI5 - 7 = DI1,2	3011 INTE 3036 INTE See sele See sele See sele See sele – Selects	ERNAL SETPNT ERNAL SETPNT ction DI1. ction DI1. ction DI1. ction DI1.	is used. 2 is used. ts DI1 and DI2	which internal setp	point is used	as
	DI1	DI2	Internal setpoin	t selected			
	0	0	4011 INTERNAL	SETPNT			
	1	0	4036 INTERNAL	ERNAL SETPNT2			
	0	1	4037 INTERNAL	SETPNT3			
	1	1	4038 INTERNAL	SETPNT4			
	8 = DI2,3 - See selection DI1,2. 9 = DI3,4 - See selection DI1,2. 10 = DI4,5 - See selection DI1,2. 15 = TIMED FUNC 1 0 = 4011 INTERNAL SETPNT is used. 1 = 4036 INTERNAL SETPNT2 is used. 16 = TIMED FUNC 2 - See selection TIMED FUNC 1. 17= TIMED FUNC 3 - See selection TIMED FUNC 1. 18= TIMED FUNC 4 - See selection TIMED FUNC 1. 19 = TIMED FUNC 4 - See selection TIMED FUNC 1 and TIMED FUNC 2 which internal setpoint is used as the reference. 1 = timed function active, 0 = timed function inactive.					d	
	lande	ion macu	ve.				
	TIMED F		TIMED FUNC 2	Internal setpoi	nt selected		

TIMED FUNC 1	TIMED FUNC 2	Internal setpoint selected
0	0	4011 INTERNAL SETPNT
1	0	4036 INTERNAL SETPNT2
0	1	4037 INTERNAL SETPNT3
1	1	4038 INTERNAL SETPNT4

Group 41: Process PID set 2

This group defines second set of parameters used with the Process PID (PID1) controller.

The operation of parameters 4101 ... 4139 is analogous with Process PID set 1 (PID1) parameters 4001...4039.

PID parameter set 2 can be selected by parameter 4027 PID 1 PARAM SET.

	Group 41: Process PID set 2						
Code	Description	Range	Resolution	Default	S		
4101							
 4139	See parameters 40014039.	See parameters 40014039.					

Group 42: Ext / Trim PID

This group defines the parameters used for the second PID controller (PID2) of ACS320.

The operation of parameters 4201 ... 4221 is analogous with Process PID set 1 (PID1) parameters 4001...4039.

	Group 42: Ext / Trim PID					
Code	Description	Range	Resolution	Default	S	
4201						
 4221	See parameters 40014021.					

		Group 42: Ext / Trim Pl	D			
Code	Description	Range	Resolution	Default S		
4228	ACTIVATE	-612	-	1		
	Defines the source for e	enabling the external PID fur	nction.			
	Requires parameter 4	4230 TRIM MODE = 0 NOT	SEL.			
	0 = NOT SEL - Disable					
		l input 1 as the control for er	0	PID control.		
		al input enables external PIE igital input disables external				
	_	nes digital input DI2DI5 as		nabling external		
	PID control.			ŭ		
	See DI1 above. 7 - DRIVE BLIN, Dofin	nes the start command as th	o control for onch	ling oxtornal DID		
	control.	ies the start command as th	e control for enac	ning external FID		
	Activating the start co	ommand (drive is running) er	nables external P	ID control.		
	· ·	ower-on as the control for er	•	PID control.		
		the drive enables external		ovtornal DID		
	912 = TIMER 14 – Defines the Timer as the control for enabling external PID control (Timer active enables external PID control).					
		oup 36: Timed functions.				
	-1 = DI1(INV) – Defines PID control.	an inverted digital input DI1	as the control for	enabling external		
		al input disables external PII	O control.			
	_	igital input enables external				
	-25 = DI2(INV)DI5((INV) – Defines an inverted o	digital input DI2	DI5 as the control		
	See DI1(INV) abov					
4229	OFFSET	0.0 100.0%	0.1%	0.0%		
	Defines the offset for the	e PID output.				
	When PID is activated	d, output starts from this val	ue.			
	 When PID is deactive 	ated, output resets to this val	lue.			
		ve when parameter 4230 TR	IM MODE not = 0	(trim mode is not		
	active).					
4230	TRIM MODE	02	1	0		
	Selects the type of trim, factor to the drive refere	if any. Using the trim it is poence.	ossible to combine	e a corrective		
	0 = NOT SEL – Disable					
		Adds a trim factor that is prim factor based on the cont				
4231	TRIM SCALE	-100.0 100.0%	0.1%	0.0%		
	Defines the multiplier (a	s a percent, plus or minus)	used in the trim m	node.		

■ Group 44: Pump protection

This group defines the parameters used for the set-up of pump protection.

	Grou	p 44: Pump protect	ion		
Code	Description	Range	Resolution	Default	S
4401	INLET PROT CTRL			NOT SEL	
	Enables, and selects the mo	de of, the primary supe	rvision of pump/fa	an inlet pressu	ure.
	Note: Inlet protection is activ	e only when the active	reference is PID.		
	0 = NOT SEL - Primary inlet	pressure supervision r	not used.		
	1 = ALARM – Detection of lo display.	w inlet pressure genera	ates an alarm on	the control par	nel
	2 = PROTECT – Detection of low inlet pressure	▲ Measured inlet			
	generates an alarm on	pressure			
	the control panel display. The output of		4407 ↔		
	the PI controller is	4403	<u>'</u>		-
	ramped down (according to	4405		/	-
	parameter 4417 PID			: 	► t
	OUT DEC TIME) to the forced reference	▲ PFA reference	:		
	(set by parameter	(EXT 2)	4417	1 1	
	4008 INLET FORCED REF). The drive will	4400	— ♥	· —	_
	revert to the original	4408			
	reference if the pressure		1 1	!	► t
	subsequently exceeds t	he supervision level.			
	The diagram describes				
4400	3 = FAULT – Detection of lov	v inlet pressure trips the	e drive on a fault.	NOT SEL	
4402	AI MEASURE INLET			NOT SEL	
	Selects the analog input for p		supervision.		
	0 = NOT SEL – No analog in 1 = Al1 – Pump/fan inlet pres		h analog input Al	1	
	2 = Al2 – See selection Al1.	ssure monitored through	ii alialog liiput Ai	1.	
4403	AI IN LOW LEVEL	0.00 100.00%	1 = 0.01%	0.00%	
	Sets the supervision limit for	the primary inlet pressu	ure measuremen	t. If the value o	of
	the selected input falls below				
	PROT CTRL is taken after the				
	The range corresponds to 0. input, the absolute input value.		the analog input.	with a bipola	ı
4404	VERY LOW CTRL			NOT SEL	
	Enables, and selects the mo	de of, the secondary in	let pressure supe		n.
	The function uses the analog				
	0 = NOT SEL – Secondary in	nlet pressure supervisio	on not used.		
	1 = STOP – Detection of ver	y low inlet pressure sto	ps the drive. The	drive will start	t
	again if the pressure ex 2 = FAULT – Detection of ve			fault	
	Z = 1 VOF1 - DETECTION OF A	ry low inlet pressure til	os the unive on a	iauit.	

	Gro	up 44: Pump protec	tion		
Code	Description	Range	Resolution	Default	S
4405	AI IN VERY LOW	0.00 100.00%	1 = 0.01%	0.00%	
	Supervision level for the se 4401 INLET PROT CTRL.	•	nonitoring functior	n. See param	eter
4406	DI STATUS INLET			NOT SEL	
	Selects the digital input for connection of a pressure switch at the pump/fan inlet. The "normal" state is 1 (active). If the selected input switches to 0 (inactive), the action defined by parameter 4401 INLET PROT CTRL is executed after the delay set by parameter 4407 INLET CTRL DLY expires. 0 = NOT SEL - No digital input selected. 1 = DI1 - Pump/fan inlet pressure monitored through digital input DI1. 2 = DI2 - See selection DI1. 3 = DI3 - See selection DI1. 4 = DI4 - See selection DI1. 5 = DI5 - See selection DI1.				
4407	INLET CTRL DLY	0.1 1800.0 s	1 = 0.1 s	60.0 s	
	Sets the delay after which the action defined by parameter 4401 INLET PROT CTRL is taken on detection of low inlet pressure.				
4408	INLET FORCED REF	0.0 100.0%	1 = 0.1%	0.0%	
	This reference is used after PROT CTRL.	detection of low inlet pre	essure. See param	neter 4401 IN	ILET
	WARNING! Make sure	e that it is safe to continu	ue operation using	this reference	ce.

Code Description Range Resolution Default S		Gro	up 44: Pump protec	tion		
OUTLET PROT CTRL Enables, and selects the mode of, the primary supervision of pump/fan outlet pressure Note: Outlet protection is active only when the active reference is PID. 0 = NOT SEL – Primary outlet pressure supervision not used. 1 = ALARM – Detection of high outlet pressure produces an alarm on the control panel display. 2 = PROTECT — Detection of high outlet pressure produces an alarm on the control panel display. The output of the PI controller is ramped down (according to parameter 4417 PID OUT DEC TIME) to the forced reference (set by parameter 4416 OUTLET FORCED REP.) The drive will revert to the original reference if the pressure subsequently falls below the supervision level. The following diagram describes the outlet pressure supervision function. 3 = FAULT – Detection of high outlet pressure trips the drive on a fault. 4410 AI MEAS OUTLET Selects the analog input for pump/fan outlet pressure supervision. 0 = NOT SEL – No analog input selected. 1 = Al1 – Pump/fan outlet pressure monitored through analog input Al1. 2 = Al2 – See selection Al1. 4411 AI OUT HI LEVEL 0.00 100.00% 1 = 0.01% 100.00% Sets the supervision limit for the primary outlet pressure measurement. If the value of the selected analog input exceeds this limit, the action defined by parameter 4409 OUTLET PROT CTRL is taken after a delay set with parameter 4415 OUTLET CTRL DLY expires. Supervision level VERY HIGH CTRL 1 = NOT SEL Enables, and selects the mode of, the secondary outlet pressure supervision function. The function uses the analog input selected by parameter 4410 Al MEAS OUTLET. 0 = NOT SEL — Secondary outlet pressure monitoring not used. 1 = STOP — Detection of very high outlet pressure trips the drive on a fault. 4413 AI OUT VERY HIGH OF one of very high outlet pressure trips the drive on a fault.	Code				Default	S
Note: Outlet protection is active only when the active reference is PID. 0 = NOT SEL – Primary outlet pressure supervision not used. 1 = ALARM – Detection of high outlet pressure produces an alarm on the control panel display. 2 = PROTECT – Detection of high outlet pressure produces an alarm on the control panel display. The output of the PI controller is ramped down (according to parameter 4417 PID OUT DEC TIME) to the forced reference (set by parameter 4416 OUTLET FORCED REF). The drive will revert to the original reference if the pressure subsequently falls below the supervision level. The following diagram describes the outlet pressure supervision function. 3 = FAULT – Detection of high outlet pressure rips the drive on a fault. 4410 AI MEAS OUTLET Selects the analog input for pump/fan outlet pressure supervision. 0 = NOT SEL – No analog input selected. 1 = Al1 – Pump/fan outlet pressure monitored through analog input Al1. 2 = Al2 – See selection Al1. 4411 AI OUT HI LEVEL 0.00 100.00% 1 = 0.01% Sets the supervision limit for the primary outlet pressure measurement. If the value of the selected analog input exceeds this limit, the action defined by parameter 4409 OUTLET PROT CTRL is taken after a delay set with parameter 4415 OUTLET CTRL DLY expires. Supervision level VERY HIGH CTRL Enables, and selects the mode of, the secondary outlet pressure supervision function. The function uses the analog input selected by parameter 4410 AI MEAS OUTLET. 0 = NOT SEL – Secondary outlet pressure monitoring not used. 1 = STOP – Detection of very high outlet pressure stops the drive. The drive will start again if the pressure falls below the supervision level. 2 = FAULT – Detection of very high outlet pressure stops the drive on a fault. 4413 AI OUT VERY HIGH 0.00 100.00% 1 = 0.01% 1 = 0.01% 1 = 0.01% 1 = 0.01% 1 = 0.01% 1 = 0.01% 1 = 0.01% 1 = 0.01% 1 = 0.01% 1 = 0.01% 1 = 0.01% 1 = 0.01% 1 = 0.01% 1 = 0.01% 1 = 0.01%		OUTLET PROT	90			
0 = NOT SEL – Primary outlet pressure supervision not used. 1 = ALARM – Detection of high outlet pressure produces an alarm on the control panel display. 2 = PROTECT – Detection of high outlet pressure produces an alarm on the control panel display. The output of the PI controller is ramped down (according to parameter 4417 PID OUT DEC TIME) to the forced reference (set by parameter 4416 OUTLET FORCED REF). The drive will revert to the original reference if the pressure subsequently falls below the supervision level. The following diagram describes the outlet pressure supervision function. 3 = FAULT – Detection of high outlet pressure supervision. 0 = NOT SEL – No analog input selected. 1 = Al1 – Pump/fan outlet pressure monitored through analog input Al1. 2 = Al2 – See selection Al1. 4411 Al OUT HI LEVEL 0.00 100.00% 1 = 0.01% 100.00% Sets the supervision limit for the primary outlet pressure measurement. If the value of the selected analog input exceeds this limit, the action defined by parameter 4409 OUTLET PROT CTRL is taken after a delay set with parameter 4415 OUTLET CTRL DLY expires. Supervision level 4412 VERY HIGH CTRL NOT SEL Enables, and selects the mode of, the secondary outlet pressure supervision function. The function uses the analog input selected by parameter 4410 Al MEAS OUTLET. 0 = NOT SEL – Secondary outlet pressure monitoring not used. 1 = STOP – Detection of very high outlet pressure stops the drive. The drive will start again if the pressure falls below the supervision level. 2 = FAULT – Detection of very high outlet pressure trips the drive on a fault. 4413 Al OUT VERY HIGH 0.00 100.00% 1 = 0.01% 100.00% Supervision level for secondary outlet pressure monitoring function. See parameter		Enables, and selects the m	ode of, the primary supe	ervision of pump/fa	n outlet pres	sure.
1 = ALARM – Detection of high outlet pressure produces an alarm on the control panel display. 2 = PROTECT – Detection of high outlet pressure produces an alarm on the control panel display. The output of the PI controller is ramped down (according to parameter 4417 PID OUT DEC TIME) to the forced reference (set by parameter 4417 PID OUT DEC TIME) to the original reference if the pressure subsequently falls below the supervision level. The following diagram describes the outlet pressure supervision function. 3 = FAULT – Detection of high outlet pressure supervision. 4410 AI MEAS OUTLET NOT SEL Selects the analog input for pump/fan outlet pressure supervision. 0 = NOT SEL – No analog input selected. 1 = Al1 – Pump/fan outlet pressure monitored through analog input Al1. 2 = Al2 – See selection Al1. 4411 AI OUT HI LEVEL 0.00 100.00% 1 = 0.01% 100.00% Sets the supervision limit for the primary outlet pressure measurement. If the value of the selected analog input exceeds this limit, the action defined by parameter 4409 OUTLET PROT CTRL is taken after a delay set with parameter 4415 OUTLET CTRL DLY expires. Supervision level 4412 VERY HIGH CTRL Enables, and selects the mode of, the secondary outlet pressure supervision function. The function uses the analog input selected by parameter 4410 AI MEAS OUTLET. 0 = NOT SEL – Secondary outlet pressure stops the drive. The drive will start again if the pressure falls below the supervision level. 2 = FAULT – Detection of very high outlet pressure trips the drive on a fault. 4413 AI OUT VERY HIGH 0.00 100.00% 1 = 0.01% 100.00% Supervision level for secondary outlet pressure trips the drive on a fault.		Note: Outlet protection is a	active only when the acti	ve reference is PI	D.	
on the control panel display. The output of the PI controller is ramped down (according to parameter 4417 PID OUT DEC TIME) to the forced reference (set by parameter 4416 OUTLET FORCED REF). The drive will revert to the original reference if the pressure subsequently falls below the supervision level. The following diagram describes the outlet pressure supervision function. 3 = FAULT – Detection of high outlet pressure trips the drive on a fault. 4410 AI MEAS OUTLET NOT SEL Selects the analog input for pump/fan outlet pressure supervision. 0 = NOT SEL – No analog input selected. 1 = Al1 – Pump/fan outlet pressure monitored through analog input Al1. 2 = Al2 – See selection Al1. 4411 AI OUT HI LEVEL 0.00 100.00% 1 = 0.01% 100.00% Sets the supervision limit for the primary outlet pressure measurement. If the value of the selected analog input exceeds this limit, the action defined by parameter 4409 OUTLET PROT CTRL is taken after a delay set with parameter 4415 OUTLET CTRL DLY expires. Supervision level 4412 VERY HIGH CTRL Enables, and selects the mode of, the secondary outlet pressure supervision function. The function uses the analog input selected by parameter 4410 AI MEAS OUTLET. 0 = NOT SEL – Secondary outlet pressure monitoring not used. 1 = STOP – Detection of very high outlet pressure stops the drive. The drive will start again if the pressure falls below the supervision level. 2 = FAULT – Detection of very high outlet pressure trips the drive on a fault. 4413 AI OUT VERY HIGH 0.00 100.00% 1 = 0.01% 100.00%		1 = ALARM – Detection of l display. 2 = PROTECT – Detection of high outlet pressure	high outlet pressure prod Measured outlet pressure	duces an alarm on	the control p	anel
the forced reference (set by parameter 4416 OUTLET FORCED REF). The drive will revert to the original reference if the pressure subsequently falls below the supervision level. The following diagram describes the outlet pressure supervision function. 3 = FAULT – Detection of high outlet pressure trips the drive on a fault. 4410 AI MEAS OUTLET NOT SEL Selects the analog input for pump/fan outlet pressure supervision. 0 = NOT SEL – No analog input selected. 1 = AI1 – Pump/fan outlet pressure monitored through analog input AI1. 2 = AI2 – See selection AI1. 4411 AI OUT HI LEVEL 0.00 100.00% 1 = 0.01% 100.00% Sets the supervision limit for the primary outlet pressure measurement. If the value of the selected analog input exceeds this limit, the action defined by parameter 4409 OUTLET PROT CTRL is taken after a delay set with parameter 4415 OUTLET CTRL DLY expires. Supervision level 4412 VERY HIGH CTRL Enables, and selects the mode of, the secondary outlet pressure supervision function. The function uses the analog input selected by parameter 4410 AI MEAS OUTLET. 0 = NOT SEL – Secondary outlet pressure monitoring not used. 1 = STOP – Detection of very high outlet pressure stops the drive. The drive will start again if the pressure falls below the supervision level. 2 = FAULT – Detection of very high outlet pressure trips the drive on a fault. 4413 AI OUT VERY HIGH 0.00 100.00% 1 = 0.01% 100.00% Supervision level for secondary outlet pressure monitoring function. See parameter		on the control panel display. The output of the PI controller is ramped down (according to	4413			~ t
drive will revert to the original reference if the pressure subsequently falls below the supervision level. The following diagram describes the outlet pressure supervision function. 3 = FAULT – Detection of high outlet pressure trips the drive on a fault. 4410 AI MEAS OUTLET NOT SEL Selects the analog input for pump/fan outlet pressure supervision. 0 = NOT SEL – No analog input selected. 1 = AI1 – Pump/fan outlet pressure monitored through analog input AI1. 2 = AI2 – See selection AI1. 4411 AI OUT HI LEVEL 0.00 100.00% 1 = 0.01% 100.00% Sets the supervision limit for the primary outlet pressure measurement. If the value of the selected analog input exceeds this limit, the action defined by parameter 44.09 OUTLET PROT CTRL is taken after a delay set with parameter 44.15 OUTLET CTRL DLY expires. Supervision level 4412 VERY HIGH CTRL NOT SEL Enables, and selects the mode of, the secondary outlet pressure supervision function. The function uses the analog input selected by parameter 44.10 AI MEAS OUTLET. 0 = NOT SEL – Secondary outlet pressure monitoring not used. 1 = STOP – Detection of very high outlet pressure stops the drive. The drive will start again if the pressure falls below the supervision level. 2 = FAULT – Detection of very high outlet pressure trips the drive on a fault. 4413 AI OUT VERY HIGH 0.00 100.00% 1 = 0.01% 100.00% Supervision level for secondary outlet pressure monitoring function. See parameter		OUT DEC TIME) to the forced reference (set by parameter 4416 OUTLET	(from PID1OUT)	4417		_
3 = FAULT – Detection of high outlet pressure trips the drive on a fault. 4410 AI MEAS OUTLET NOT SEL Selects the analog input for pump/fan outlet pressure supervision. 0 = NOT SEL – No analog input selected. 1 = AI1 – Pump/fan outlet pressure monitored through analog input AI1. 2 = AI2 – See selection AI1. 4411 AI OUT HI LEVEL 0.00 100.00% 1 = 0.01% 100.00% Sets the supervision limit for the primary outlet pressure measurement. If the value of the selected analog input exceeds this limit, the action defined by parameter 4409 OUTLET PROT CTRL is taken after a delay set with parameter 4415 OUTLET CTRL DLY expires. Supervision level 4412 VERY HIGH CTRL Enables, and selects the mode of, the secondary outlet pressure supervision function. The function uses the analog input selected by parameter 4410 AI MEAS OUTLET. 0 = NOT SEL – Secondary outlet pressure monitoring not used. 1 = STOP – Detection of very high outlet pressure stops the drive. The drive will start again if the pressure falls below the supervision level. 2 = FAULT – Detection of very high outlet pressure trips the drive on a fault. 4413 AI OUT VERY HIGH 0.00 100.00% 1 = 0.01% 100.00% Supervision level for secondary outlet pressure monitoring function. See parameter		the original reference if the pressure				► t
AI MEAS OUTLET Selects the analog input for pump/fan outlet pressure supervision. 0 = NOT SEL - No analog input selected. 1 = Al1 - Pump/fan outlet pressure monitored through analog input Al1. 2 = Al2 - See selection Al1. 4411 AI OUT HI LEVEL 0.00 100.00% Sets the supervision limit for the primary outlet pressure measurement. If the value of the selected analog input exceeds this limit, the action defined by parameter 4409 OUTLET PROT CTRL is taken after a delay set with parameter 4415 OUTLET CTRL DLY expires. Supervision level VERY HIGH CTRL Enables, and selects the mode of, the secondary outlet pressure supervision function. The function uses the analog input selected by parameter 4410 AI MEAS OUTLET. 0 = NOT SEL - Secondary outlet pressure monitoring not used. 1 = STOP - Detection of very high outlet pressure stops the drive. The drive will start again if the pressure falls below the supervision level. 2 = FAULT - Detection of very high outlet pressure trips the drive on a fault. 4413 AI OUT VERY HIGH 0.00 100.00% Supervision level for secondary outlet pressure monitoring function. See parameter		The following diagram	describes the outlet pre	essure supervision		
0 = NOT SEL – No analog input selected. 1 = Al1 – Pump/fan outlet pressure monitored through analog input Al1. 2 = Al2 – See selection Al1. 4411 Al OUT HI LEVEL 0.00 100.00% 1 = 0.01% 100.00% Sets the supervision limit for the primary outlet pressure measurement. If the value of the selected analog input exceeds this limit, the action defined by parameter 4409 OUTLET PROT CTRL is taken after a delay set with parameter 4415 OUTLET CTRL DLY expires. Supervision level 4412 VERY HIGH CTRL Enables, and selects the mode of, the secondary outlet pressure supervision function. The function uses the analog input selected by parameter 4410 Al MEAS OUTLET. 0 = NOT SEL – Secondary outlet pressure monitoring not used. 1 = STOP – Detection of very high outlet pressure stops the drive. The drive will start again if the pressure falls below the supervision level. 2 = FAULT – Detection of very high outlet pressure trips the drive on a fault. 4413 Al OUT VERY HIGH 0.00 100.00% 1 = 0.01% 100.00% Supervision level for secondary outlet pressure monitoring function. See parameter	4410		ng. canot process anpo			
Sets the supervision limit for the primary outlet pressure measurement. If the value of the selected analog input exceeds this limit, the action defined by parameter 4409 OUTLET PROT CTRL is taken after a delay set with parameter 4415 OUTLET CTRL DLY expires. Supervision level 4412 VERY HIGH CTRL Enables, and selects the mode of, the secondary outlet pressure supervision function. The function uses the analog input selected by parameter 4410 AI MEAS OUTLET. 0 = NOT SEL — Secondary outlet pressure monitoring not used. 1 = STOP — Detection of very high outlet pressure stops the drive. The drive will start again if the pressure falls below the supervision level. 2 = FAULT — Detection of very high outlet pressure trips the drive on a fault. 4413 AI OUT VERY HIGH 0.00 100.00% 1 = 0.01% 100.00% Supervision level for secondary outlet pressure monitoring function. See parameter		0 = NOT SEL – No analog 1 = Al1 – Pump/fan outlet p	input selected. pressure monitored thro		AI1.	
the selected analog input exceeds this limit, the action defined by parameter 4409 OUTLET PROT CTRL is taken after a delay set with parameter 4415 OUTLET CTRL DLY expires. Supervision level VERY HIGH CTRL Enables, and selects the mode of, the secondary outlet pressure supervision function. The function uses the analog input selected by parameter 4410 AI MEAS OUTLET. 0 = NOT SEL - Secondary outlet pressure monitoring not used. 1 = STOP - Detection of very high outlet pressure stops the drive. The drive will start again if the pressure falls below the supervision level. 2 = FAULT - Detection of very high outlet pressure trips the drive on a fault. 4413 AI OUT VERY HIGH 0.00 100.00% 1 = 0.01% 100.00% Supervision level for secondary outlet pressure monitoring function. See parameter	4411	AI OUT HI LEVEL	0.00 100.00%	1 = 0.01%	100.00%	
Enables, and selects the mode of, the secondary outlet pressure supervision function. The function uses the analog input selected by parameter 4410 AI MEAS OUTLET. 0 = NOT SEL – Secondary outlet pressure monitoring not used. 1 = STOP – Detection of very high outlet pressure stops the drive. The drive will start again if the pressure falls below the supervision level. 2 = FAULT – Detection of very high outlet pressure trips the drive on a fault. 4413 AI OUT VERY HIGH 0.00 100.00% 1 = 0.01% 100.00% Supervision level for secondary outlet pressure monitoring function. See parameter		the selected analog input e	exceeds this limit, the actiken after a delay set wi	tion defined by pa	rameter 4409	9
The function uses the analog input selected by parameter 4410 Al MEAS OUTLET. 0 = NOT SEL – Secondary outlet pressure monitoring not used. 1 = STOP – Detection of very high outlet pressure stops the drive. The drive will start again if the pressure falls below the supervision level. 2 = FAULT – Detection of very high outlet pressure trips the drive on a fault. 4413 Al OUT VERY HIGH 0.00 100.00% 1 = 0.01% 100.00% Supervision level for secondary outlet pressure monitoring function. See parameter	4412	VERY HIGH CTRL			NOT SEL	
1 = STOP – Detection of very high outlet pressure stops the drive. The drive will start again if the pressure falls below the supervision level. 2 = FAULT – Detection of very high outlet pressure trips the drive on a fault. 4413 AI OUT VERY HIGH 0.00 100.00% 1 = 0.01% 100.00% Supervision level for secondary outlet pressure monitoring function. See parameter						
AI OUT VERY HIGH 0.00 100.00% 1 = 0.01% 100.00% Supervision level for secondary outlet pressure monitoring function. See parameter		1 = STOP – Detection of ve again if the pressure f	ery high outlet pressure alls below the supervision	stops the drive. The level.		tart
	4413		, , ,	· ·		
		·	,	onitoring function.	See paramete	er

	Grou	p 44: Pump protec	tion		
Code	Description	Range	Resolution	Default	S
4414	DI STATUS OUTLET	-		NOT SEL	
	Selects the digital input for co "normal" state is 1 (active). If defined by parameter 4409 (parameter 4415 OUTLET CO 0 = NOT SEL – No digital input 1 = DI1 – Pump/fan outlet produced by the selection DI1. 3 = DI3 – See selection DI1. 4 = DI4 – See selection DI1. 5 = DI5 – See selection DI1.	the selected input swi DUTLET PROT CTRL TRL DLY expires. out selected.	tches to 0 (inactiv is taken after a de	re), the actior elay set by	
4415	OUTLET CTRL DLY	0.1 1800.0 s	1 = 0.1 s	60.0 s	
	Sets the delay after which the is taken on detection of high		ameter 4409 OUT	LET PROT C	TRL
4416	OUTLET FORCED REF	0.00 100.00%	1 = 0.01%	0.0%	
	This reference is used after of OUTLET PROT CTRL.	detection of high outlet	pressure. See pa	rameter 440	9
	WARNING! Make sure			this reference	ce.
4417	PID OUT DEC TIME	0.0 3800.0 s	1 = 0.1 s	60.0 s	
	PI controller ramp-down time PROT CTRL and 4409 OUT		ECT for paramete	ers 4401 INLE	ΞT
4418	APPL PROFILE CTL			NOT SEL	
	Parameters 4418 APPL PRO Application profile protection status signal. If the selected for a longer time than the set internal status signal "PROFI output (see parameter <i>Group</i> 0 = NOT SEL – Not selected	feature, based on long signal exceeds (and re delay (parameter 442 LE HIGH" is set to 1. To 14: Relay outputs).	g-term monitoring emains above) the 10 PROF LIMIT O	of an internal supervision N DLY), the	l limit
	1 = CONTROL DEV1 – Sign parameter 4419 PROFIL reference and the actua pump, piping and valves 2 = CONTROL DEV2 – Sign parameter 4419 PROFIL reference and the actua	al 0126 PID 1 OUTPU LE OUTP LIM. Monitor I value gives an indica s. al 0127 PID 2 OUTPU LE OUTP LIM. Monitor I value gives an indica	ring the deviation tion of the genera T is monitored and the deviation	between the local condition of dompared to between the	the to
	pump, piping and valves 3 = APPL OUTPUT – Signal parameter 4419 PROFI may indicate a leak in the	0116 APPL BLK OUT LE OUTP LIM. The sig	PUT is monitored inal constantly ren	and compare maining at 10	ed to 0%
4419	PROFILE OUTP LIM	-500.0 500.0%	1 = 0.1%	100.0%	
	Supervision limit for the Appl				
4420	PROF LIMIT ON DLY	0.00 100.00 h	1 = 0.01 h	0.00 h	
	Delay time for the Application	n profile protection.			

	Grou	ıp 44: Pump protect	ion	
Code	Description	Range	Resolution	Default S
4421	PIPEFILL ENABLE			NOT SEL
	Enables the Precharge func	tion, which calculates re	eference steps.	
	0 = NOT SEL - Not enabled			
	1 = DI1 – When DI1 is active started. If DI1 becomes normal PID control is el 2 = DI2 – See selection DI1.	s inactive (0) before the nabled.	ction is active wh Precharge function	en the drive is on is finished,
	3 = DI3 – See selection DI1.			
	4 = DI4 – See selection DI1.			
	5 = DI5 – See selection DI1.			
	finished, normal PID co	s inactive (0), the Precha secomes active (1) befor ontrol is enabled.	arge function is a	ctive when the function is
	-2 = DI2(INV) – See selection -3 = DI3(INV) – See selection	` ,		
	-4 = DI4(INV) – See selection	, ,		
	-5 = DI5(INV) – See selection	` '		
4422	PIPEFILL STEP	0.0 100.0%	1 = 0.1%	0.0%
	Defines the speed step used is specified by parameter 40	•		rence ramp time
	The speed step is added to ACT CHANGE DELAY has a 4423 REQ ACT CHANGE h	elapsed and the change	, ,	
	 Speed step in percent of t 	the maximum speed out	put	
4423	REQ ACT CHANGE	0.0 100.0%	1 = 0.1%	0.0%
	Defines the requested change parameter 4424 ACT CHAN	0 1	during the time th	nat is set by
	If the requested change in the to the speed reference.	ne feedback is not reach	ed, <i>4422 PIPEFIL</i>	L STEP is added
	 Value in percent of the ma 	aximum speed.		
4424	ACT CHANGE DELAY	0.1 6000.0 s	1 = 0.1 s	0.0 s
	Defines the time that is waite feedback value.	ed after the feedback va	alue is compared	with the old
	If parameter 4423 REQ ACT reference stays as it is. If RE value of parameter 4422 PII	EQ ACT CHANGE is no	t seen in the feed	lback value, the
4425	PID ENABLE DEV	0.0 100.0%	1 = 0.1%	0.1%
	Defines the level when the F the level is reached, PID is a ramp times are set, they are	enabled. PID is execute		
	Value in percent of the ma	aximum feedback.		

	Group 44: Pump protection							
Code	Description	Range	Resolution	Default	S			
4426	PIPEFILL TIMEOUT	1 60000 s	1 = 1 s	NOT SEL				
	Defines the maximum time t elapses, PID is preset and P reference ramps. 0 = NOT SEL - 160000 s:	PID is allowed to run as i	it is parameterized					

Group 45: Energy saving

This group defines the set-up for calculation and optimization of energy savings.

Note: The values of saved energy parameters 0174 SAVED KWH, 0175 SAVED MWH, 0176 SAVED AMOUNT 1, 0177 SAVED AMOUNT 2 and 0178 SAVED CO2 are derived from subtracting the drive's energy consumed from the direct-on-line (DOL) consumption calculated on the basis of parameter 4508 PUMP POWER. As such, the accuracy of the values is dependent on the accuracy of the power estimate entered in that parameter.

		Group 45: Energy savin	ng .		
Code	Description	Range	Resolution	Default	S
4501	ENERGY OPTIMIZER	rungo	Resolution	OFF	
	energy consumption and	energy optimizer, which opti d motor noise level are reduc stal efficiency (motor and driv ue and speed.	ed when the dri	ve operates b	elow
4502	ENERGY PRICE	0.00 655.35	1 = 0.1 (Currency)	0.00 (Currency)	
	parameters 0174 SAVE	D. Used for reference when e D. KWH, 0175 SAVED MWH I 0178 SAVED CO2 (reduction	, 0176 SAVED A	AMOUNT 1, C	177
4507	CO2 CONV FACTOR	0.0 655.35 tn/MWh	1 = 0.1 tn/MWh	0.5 tn/MWh	
Conversion factor for converting energy into CO2 emissions (kg/kWh or tn/MWh Used for multiplying the saved energy in MWh to calculate the value of paramet 0178 SAVED CO2 (reduction in carbon dioxide emissions in tn).					
4508	PUMP POWER	0.0 1000.0%	1 = 0.1%	100.0%	
	energy savings are calc	nected directly to supply (DO ulated. See parameters 0174 OUNT 1, 0177 SAVED AMO	4 SAVED KWH,	0175 SAVED	
	· ·	parameter as the reference nce power can also be some y on-line.	•		

	Group 45: Energy saving						
Code	Description	Range	Resolution	Default	S		
4509	ENERGY RESET			DONE			
	Resets energy calculators 0174 SAVED KWH, 0175 SAVED MWH, 0176 SAVED AMOUNT 1, 0177 SAVED AMOUNT 2 and 0178 SAVED CO2.						
	0 = DONE - Reset not re 1 = RESET - Reset ener			y to DONE.			

Group 46: Pump cleaning

This group defines the set-up for pump cleaning.

	Gro	up 46: Pump clean	ning		
Code	Description	Range	Resolution	Default	S
4601	PUMP CLEAN TRIG			NOT SEL	
	Defines how the Pump clear consists of forward and reve	0	ed. The pump clea	ining sequend	се
	Forward	4602	503	t -	
	▼ Reverse				
	4607 460	5 4604 4606 4604	4 4605 4604		
	ı	4608		→	
	WARNING! Before perform the Pump	enabling the Pump co	leaning function er	nsure it is safe	e to
	Notes:	0 1			
	The Pump cleaning function	on overrides paramete	er 1003 DIRECTIO	N.	
	 The Pump cleaning function frequencies (parameters 2 				
	The Pump cleaning function ACCELER TIME 2) and description	,	"		RL).
	The drive must be started Pump cleaning function set		gnal must be prese	ent before the	;
	0 = NOT SEL - No triggering 1 = DI1 - Trigger on the risin 2 = DI2 - See selection DI1. 3 = DI3 - See selection DI1. 4 = DI4 - See selection DI1.	ng edge of digital input	t DI1.		
	1 = DI1 - Trigger on the risin 2 = DI2 - See selection DI1. 3 = DI3 - See selection DI1.	ng edge of digital input	t DI1.		

	Gr	oup 46: Pump cleani	ng	
Code	Description	Range	Resolution	Default S
Code	7 = DI1/SUP1OVR - Enabover (parameter 14 Supervision). 8 = DI2/SUP1OVR - See 19 = DI3/SUP1OVR - See 11 = DI5/SUP1OVR - See 11 = DI5/SUP1OVR - See 12 = SUPRV1 OVER - Tri 1). See parameter Gr 13 = DRIVE START - Trig 14 = TIMER TRIG - Pump defined by parameter -1 = DI1(INV) - Trigger on -2 = DI2(INV) - See select -3 = DI3(INV) - See select -4 = DI4(INV) - See select -5 = DI5(INV) - See select -7 = DI1(INV)S10 - Enablo OVER (parameter 14	selection DI1/SUP1OVR. selection DI1/SUP1OVR. selection DI1/SUP1OVR. selection DI1/SUP1OVR. selection DI1/SUP1OVR selection DI1/SUP1OVR gger on SUPRV1 OVER soup 32: Supervision. ger when the drive receive cleaning sequence is stated 4607 TRIG TIME. the falling edge of digital tion DI1(INV). tion DI1(INV).	igital input DI1, trigee parameter Grant R. R. (parameter 1401 personal research start comma arted periodically a input DI1.	gger on SUPRV1 oup 32: RELAY OUTPUT and. at intervals
	Supervision8 = DI2(INV)S1O - See s -9 = DI3(INV)S1O - See s -10 = DI4(INV)S1O - See -11 = DI5(INV)S1O - See	election DI1(INV)S1O. selection DI1(INV)S1O.		
4602	FWD STEP	0.0 100.0%	1 = 0.1%	0.0%
	Defines the forward step from nominal motor frequency (in percent of the
4603	REV STEP	0.0 100.0%	1 = 0.1%	0.0%
	Defines the reverse step finominal motor frequency (in percent of the
4604	OFF TIME	0.0 1000.0 s	1 = 0.1 s	0.0 s
	Defines the length of the in cleaning sequence in second		and reverse steps	in the pump
4605	FWD TIME	0.0 1000.0 s	1 = 0.1 s	0.0 s
	Defines the duration of each	ch forward step in the pur	mp cleaning seque	ence in seconds.
4606	REV TIME	0.0 1000.0 s	1 = 0.1 s	0.0 s
	Defines the duration of each	ch reverse step in the pur	mp cleaning seque	ence in seconds.
4607	TRIG TIME	0.0 200.0 h	1 = 0.1 h	0.0 h
	Defines the time for setting	TIMER TRIG of parame	eter 4601 PUMP C	CLEAN TRIG.
4608	COUNT	0100	1 = 1	0
	Number of steps to be per	formed in the pump clear	ning sequence.	
	· · · · · · · · · · · · · · · · · · ·			

Group 52: Panel comm

This group defines the communication settings for the control panel port on the drive. Normally, when using the supplied control panel, there is no need to change settings in this group.

In this group, parameter modifications take effect on the next power-up.

	G	roup 52: Panel com	m		
Code	Description	Range	Resolution	Default	S
5201	STATION ID	1247	1	1	
	Defines the address of the line.	drive. Two units with the	e same address a	re not allowed	d on-
	• Range: 1247				
5202	BAUD RATE	9.6 115.2 kbits/s	-	9.6 kbits/s	
	Defines the transfer rate of	f the link.			
	9.6				
	19.2				
	38.4				
	57.6				
	115.2				
5203	PARITY	03	1	0	
	Defines the use of parity a stations.	nd stop bit(s). The same	setting must be u	ised in all on-	line
	0 = 8N1 - 8 data bits, no p				
	1 = 8N2 - 8 data bits, no p 2 = 8E1 - 8 data bits, ever	•	a atan hit		
	3 = 801 - 8 data bits, ever		•		
5204	OK MESSAGES	065535	1	-	
	Number of valid messages increases constantly.	received by the drive. D	uring normal oper	ation, this nur	mber
5205	PARITY ERRORS	065535	1	-	
	Number of characters with is high, check that the pari same.				
	Note: High electromagneti	c noise levels generate	errors.		
5206	FRAME ERRORS	065535	1	-	
	Number of characters with is high, check that the combus are the same.				
	Note: High electromagneti	c noise levels generate	errors.		
5207	BUFFER OVERRUNS	065535	1	-	
	Number of characters which which exceed the maximum	·	·	ber of charac	cters

Group 52: Panel comm							
Code	Description	Range	Resolution	Default	S		
5208	CRC ERRORS	065535	1	-			
	Number of messages with a CRC (cyclic redundancy check) error received by the drive. If the number is high, check CRC calculation for possible errors.						
	Note: High electromagneti	c noise levels generate	errors.				

■ Group 53: EFB protocol

This group defines set-up variables used for an embedded fieldbus (EFB) communication protocol. Refer to communication protocol documentation for more information on these parameters.

	G	roup 53: EFB protoco	ol		
Code	Description	Range	Resolution	Default	S
5301	EFB PROTOCOL ID	0000 FFFF hex	1	0000 hex	
	Contains the identification	and program revision of tl	ne protocol.		
	Note: You can reset this pa	arameter only with parame	eter 9802 COM	A PROT SEL.	
	 Format XXYY hex, wher protocol. 	re XX = protocol ID and Y	Y = program rev	ision of the	
5302	EFB STATION ID	065535	1	1	✓
	Defines the address of the on-line.	device. Two units with the	e same address	are not allowe	ed
5303	EFB BAUD RATE	1.2 76.8 kbits/s	-	9.6 kbits/s	
	Defines the transfer rate of	the link.			
	1.2 kbits/s				
	2.4 kbits/s				
	4.8 kbits/s				
	9.6 kbits/s				
	19.2 kbits/s				
	38.4 kbits/s				
	57.6 kbits/s				
	76.8 kbits/s				
5304	EFB PARITY	03		0	
	Defines the use of parity ar used in all on-line stations.	. ,,	length. The sam	ne setting mus	t be
	0 = 8 NONE 1 – 8 data bits				
	1 = 8 NONE 2 – 8 data bits 2 = 8 EVEN 1 – 8 data bits	, , ,, , ,			
	3 = 8 ODD 1 - 8 data bits,		-		
L		1 - 3/1			

	Gro	oup 53: EFB proto	col			
Code	Description	Range	Resolution	Default	S	
5305	EFB CTRL PROFILE	02	1	0		
	Selects the communication p	orofile. See section Co	ommunication profil	es on page 3	319.	
	0 = ABB DRV LIM - Operation	on of Control/Status w	ords conforms to A	BB Drives Pr	rofile.	
	1 = DCU PROFILE – Operation Profile.	tion of Control/Status	words conforms to	32-bit DCU		
	2 = ABB DRV FULL – Opera Profile.	ation of Control/Status	words conforms to	ABB Drives	'	
5306	EFB OK MESSAGES	065535	1	0		
	Number of valid messages reincreases constantly.	eceived by the drive. D	ouring normal opera	ition, this nur	mber	
5307	EFB CRC ERRORS	065535	1	0		
	Number of messages with a drive. If the number is high,	check CRC calculation	n for possible errors	,	÷	
	Note: High electromagnetic	noise levels generate	errors.			
5308	EFB UART ERRORS	065535	1	0		
	Number of messages with a		red by the drive.			
5309	EFB STATUS	07	1	0		
	Status of the EFB protocol.					
	0 = IDLE – EFB protocol is configured, but not receiving any messages.					
		1 = EXECUT INIT – EFB protocol is initializing. 2 = TIME OUT – A time-out has occurred in the communication between the network				
	master and the EFB pro		mmunication betw	een the netw	/OIK	
	3 = CONFIG ERROR – EFB					
	4 = OFF-LINE – EFB protoc drive.	ol is receiving messag	es that are NOT ac	ddressed to t	this	
	5 = ON-LINE – EFB protoco			ed to this driv	ve.	
	6 = RESET- EFB protocol is 7 = LISTEN ONLY - EFB pro					
5310	EFB PAR 10EFB	065535	1 1	Protocol		
5320	PAR 20	000000	'	dep.		
	1 All 20					

Group 64: Load analyzer

This group defines the settings for the load analyzing function for peak value and amplitude. See section Load analyzer on page 130.

	Group 64: Load analyzer						
Code	Description	Range	Resolution	Default	S		
6401	PVL SIGNAL	xx		103			
	Defines the signal logged Group 01: Operating data	•					
6402	PVL FILTER TIME	0.0 120.0 s	1 = 0.1 s	0.1 s			
	Defines the filter time for p	oeak value logging. Filter	time				

	G	roup 64: Load analyze	er		
Code	Description	Range	Resolution	Default	S
6403	LOGGERS RESET	<u> </u>		NOT SEL	
	Defines the source for the	reset of loggers.			
	0 = NOT SEL - No reset s	selected.			
	1 = DI1 – Reset loggers o	3 3			
	2 = DI2 – See selection D				
	3 = DI3 – See selection D				
	4 = DI4 – See selection D 5 = DI5 – See selection D				
		rs. Parameter is set to NO	T SEL.		
		gers on the falling edge of			
	-2 = DI2(INV) – See selec	tion DI1(INV).			
	-3 = DI3(INV) – See selec	, ,			
	-4 = DI4(INV) – See selec	tion DI1(INV).			
	-5 = DI5(INV) – See selec	tion DI1(INV).			
6404	AL2 SIGNAL	xx		103	
		for amplitude logger 2. Pa	rameter index in	Group 01:	
	Operating data. For exam	ple, 102 = <i>0102 SPEED</i> .			
6405	AL2 SIGNAL BASE	-		-	
		om which the percentage d			
	Representation and defau	It value depends on the sig	gnal selected wit	h parameter 6	404
6406	PEAK VALUE				
0.00		e signal selected with para	meter 6401 PVI	SIGNAL	
6407	PEAK TIME 1	0 65535 d	1 = 1 d	0 d	
		tection. Day on which the	neak value was	detected	
	'	ne clock is operating. / The			the
		clock is not used, or was no	,	ciapoca aitoi	uic
6408	PEAK TIME 2	00:00:00 23:59:58		00:00:00	
	Time of the peak value de	tection.			
6409	CURRENT AT PEAK	0.0 6553.5 A	1 = 0.1 A	0.0 A	
	Current at the moment of	the peak value			
6410	UDC AT PEAK	0 65535 V	1 = 1 V	0 V	
	DC voltage at the momen	t of the peak value			
6411	FREQ AT PEAK	0.0 6553.5 Hz	1 = 0.1 Hz	0.0 Hz	
	Output frequency at the m	noment of the peak value			
6412	TIME OF RESET 1	0 65535 d	1 = 1 d	0 d	
	Last reset date of the pea	k logger and amplitude log	ger 2. Day of the	e last reset.	
	Format: Date if the real tin	ne clock is operating. / Nur	mber of days ela	psed after the	;
	power-on if the real time of	lock is not used, or was no	,	·	9
6413		, ,	,	psed after the	

Code Description Range Resolution Default S 6414 AL1RANGEOTO10 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 1020% distribution 6416 AL1RANGE20TO30 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 2030% distribution 6417 AL1RANGE30TO40 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 3040% distribution 6418 AL1RANGE30TO60 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution 6419 AL1RANGE60TO70 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution 6421 AL1RANGE60TO70 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution 64		Gro	up 64: Load analy	zer		
AL1RANGEOTO10 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 010% distribution AL1RANGE10TO20 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 1020% distribution AL1RANGE20TO30 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 2030% distribution AL1RANGE30TO40 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 2030% distribution AL1RANGE30TO40 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 3040% distribution AL1RANGE40TO50 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE50TO60 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE60TO70 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE60TO70 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE70TO80 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE90TO 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL2RANGE90TO 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 010% distribution AL2RANGE90TO 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 010% distribution AL2RANGE30TO30 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 010% distribution AL2RANGE30TO40 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 010% distribution AL2RANGE30TO50 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution AL2RANGE30TO60 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 50	Code	-	Range	Resolution	Default	S
AL1RANGE10TO20 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 10 20% distribution 0.41 (AL1RANGE20TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 20 30% distribution 0.417 AL1RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 30 40% distribution 0.418 AL1RANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 40 50% distribution 0.419 AL1RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 40 50% distribution 0.419 AL1RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 40 50% distribution 0.420 AL1RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 40 50% distribution 0.421 AL1RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 40 50% distribution 0.422 AL1RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 40 50% distribution 0.423 AL1RANGE90TO 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 40 50% distribution 0.424 AL2RANGE90TO 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 0 10% distribution 0.425 AL2RANGE0TO10 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 0 10% distribution 0.426 AL2RANGE20TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 0 10% distribution 0.427 AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 30 40% distribution 0.428 AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 50 60% distribution 0.429 AL2RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 50 60% distribut	6414	AL1RANGE0TO10			0.0%	
Amplitude logger 1 (current in percent of nominal current) 1020% distribution AL1RANGE20TO30 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 2030% distribution AL1RANGE30TO40 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 3040% distribution AL1RANGE40TO50 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE50TO60 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE60TO70 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE70TO80 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE80TO90 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE80TO90 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE90TO 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL2ANGE90TO 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 010% distribution AL2RANGE0TO10 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 010% distribution AL2RANGE20TO30 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 020% distribution AL2RANGE30TO40 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution AL2RANGE30TO40 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution AL2RANGE50TO60 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution AL2RANGE60TO70 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution AL2RANGE60TO70 0.0100.0% 1		Amplitude logger 1 (current i	n percent of nominal of	current) 010% di	stribution	
ALTRANGE20TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 2030% distribution 6417 ALTRANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 30 40% distribution 6418 ALTRANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 40 50% distribution 6419 ALTRANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 40 50% distribution 6420 ALTRANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 40 50% distribution 6421 ALTRANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 40 50% distribution 6422 ALTRANGE80TO90 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 40 50% distribution 6423 ALTRANGE90TO 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 40 50% distribution 6424 ALZRANGE90TO 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 0 50% distribution 6425 ALZRANGE40TO20 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 10 20% distribution 6426 ALZRANGE20TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 20 30% distribution 6428 ALZRANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 30 40% distribution 6428 ALZRANGE50TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 50 60% distribution 6428 ALZRANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 50 60% distribution 6430 ALZRANGE50TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter	6415	AL1RANGE10TO20	0.0 100.0%	1 = 0.1%	0.0%	
Amplitude logger 1 (current in percent of nominal current) 2030% distribution AL1RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 3040% distribution AL1RANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL2RANGE90TO 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with perameter 6404) 010% distribution AL2RANGE10TO20 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 1020% distribution AL2RANGE10TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 2030% distribution AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 2030% distribution AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution		Amplitude logger 1 (current i	n percent of nominal of	current) 1020% o	distribution	
AL1RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 3040% distribution 0.418 AL1RANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution 0.0	6416	AL1RANGE20TO30	0.0 100.0%	1 = 0.1%	0.0%	
Amplitude logger 1 (current in percent of nominal current) 3040% distribution AL1RANGE40TO50 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE50TO60 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE60TO70 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE70TO80 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE80TO90 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE90TO 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL2RANGE90TO 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 010% distribution AL2RANGE0TO10 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 1020% distribution AL2RANGE10TO20 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 2030% distribution AL2RANGE20TO30 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 2030% distribution AL2RANGE30TO40 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution AL2RANGE30TO50 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution AL2RANGE50TO60 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution AL2RANGE60TO70 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution AL2RANGE60TO70 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution		Amplitude logger 1 (current i	n percent of nominal of	current) 2030% o	distribution	
ALTRANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution ALTRANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution ALTRANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution ALTRANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution ALTRANGE80TO90 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution ALTRANGE90TO 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution ALZRANGE0TO10 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 010% distribution ALZRANGE10TO20 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 1020% distribution ALZRANGE20TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 2030% distribution ALZRANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution ALZRANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 4050% distribution ALZRANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution ALZRANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution ALZRANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution ALZRANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution	6417	AL1RANGE30TO40	0.0 100.0%	1 = 0.1%	0.0%	
Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE50TO60 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE60TO70 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE70TO80 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE80TO90 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE90TO 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL2RANGE90TO 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL2RANGE10TO0 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 010% distribution AL2RANGE10TO20 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 1020% distribution AL2RANGE20TO30 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 2030% distribution AL2RANGE30TO40 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution AL2RANGE40TO50 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution AL2RANGE50TO60 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution AL2RANGE60TO70 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution AL2RANGE60TO70 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution		Amplitude logger 1 (current i	n percent of nominal of	current) 3040% o	distribution	
ALTRANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution ALTRANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution ALTRANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution ALTRANGE80TO90 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution ALTRANGE80TO90 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution ALTRANGE90TO 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 010% distribution ALZRANGE10TO20 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 1020% distribution ALZRANGE20TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 1020% distribution ALZRANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 2030% distribution ALZRANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution ALZRANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution ALZRANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution ALZRANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution ALZRANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution ALZRANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution	6418	AL1RANGE40TO50	0.0 100.0%	1 = 0.1%	0.0%	
Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE60TO70 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE70TO80 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE80TO90 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE90TO 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL22 AL2RANGE90TO 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 010% distribution AL2RANGE10TO20 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 1020% distribution AL2RANGE20TO30 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 2030% distribution AL2RANGE30TO40 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution AL2RANGE40TO50 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 4050% distribution AL2RANGE50TO60 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution AL2RANGE60TO70 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution AL2RANGE60TO70 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution AL2RANGE70TO80 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution AL2RANGE70TO80 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution		Amplitude logger 1 (current i	n percent of nominal of	current) 4050% o	distribution	
AL1RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE90TO 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL2RANGE90TO 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 010% distribution AL2RANGE10TO20 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 1020% distribution AL2RANGE20TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 2030% distribution AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution AL2RANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 4050% distribution AL2RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution	6419	AL1RANGE50TO60	0.0 100.0%	1 = 0.1%	0.0%	
Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE90TO 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL2RANGE90TO 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 0 10% distribution AL2RANGE10TO20 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 10 20% distribution AL2RANGE20TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 20 30% distribution AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 30 40% distribution AL2RANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 40 50% distribution AL2RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 50 60% distribution AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 50 60% distribution AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 60 70% distribution AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 60 70% distribution AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 60 70% distribution		Amplitude logger 1 (current i	n percent of nominal of	current) 4050% o	distribution	
AL1RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE90TO 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL2RANGE0TO10 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 010% distribution AL2RANGE10TO20 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 1020% distribution AL2RANGE20TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 2030% distribution AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution AL2RANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 4050% distribution AL2RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution	6420	AL1RANGE60TO70	0.0 100.0%	1 = 0.1%	0.0%	
Amplitude logger 1 (current in percent of nominal current) 4050% distribution 6422 AL1RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution 6423 AL1RANGE90TO 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution 6424 AL2RANGE0TO10 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 010% distribution 6425 AL2RANGE10TO20 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 1020% distribution 6426 AL2RANGE20TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 2030% distribution 6427 AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution 6428 AL2RANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 4050% distribution 6429 AL2RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution 6430 AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution 6431 AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution 6432 AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0%		Amplitude logger 1 (current i	n percent of nominal of	current) 4050% o	distribution	
AL1RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL1RANGE90TO 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution AL2RANGE0TO10 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 010% distribution AL2RANGE10TO20 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 1020% distribution AL2RANGE20TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 2030% distribution AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution AL2RANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 4050% distribution AL2RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution	6421	AL1RANGE70TO80	0.0 100.0%	1 = 0.1%	0.0%	
Amplitude logger 1 (current in percent of nominal current) 4050% distribution 6423 AL1RANGE90TO 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution 6424 AL2RANGE0TO10 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 010% distribution 6425 AL2RANGE10TO20 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 1020% distribution 6426 AL2RANGE20TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 2030% distribution 6427 AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution 6428 AL2RANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 4050% distribution 6429 AL2RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution 6430 AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution 6431 AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution 6432 AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0%		Amplitude logger 1 (current i	n percent of nominal of	current) 4050% o	distribution	
AL2RANGE30TO 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 1 (current in percent of nominal current) 4050% distribution 6424 AL2RANGE0TO10 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 010% distribution 6425 AL2RANGE10TO20 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 1020% distribution 6426 AL2RANGE20TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 2030% distribution 6427 AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution 6428 AL2RANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 4050% distribution 6429 AL2RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution 6430 AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution 6431 AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution 6432 AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution	6422	AL1RANGE80TO90	0.0 100.0%	1 = 0.1%	0.0%	
Amplitude logger 1 (current in percent of nominal current) 4050% distribution 6424 AL2RANGE0TO10 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 010% distribution 6425 AL2RANGE10TO20 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 1020% distribution 6426 AL2RANGE20TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 2030% distribution 6427 AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution 6428 AL2RANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 4050% distribution 6429 AL2RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution 6430 AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution 6431 AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution 6432 AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution		Amplitude logger 1 (current i	n percent of nominal of	current) 4050% o	distribution	
AL2RANGE10TO10 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 0 10% distribution AL2RANGE10TO20 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 10 20% distribution AL2RANGE20TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 20 30% distribution AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 30 40% distribution AL2RANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 40 50% distribution AL2RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 50 60% distribution AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 60 70% distribution AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 70 80% distribution AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 70 80% distribution	6423	AL1RANGE90TO	0.0 100.0%	1 = 0.1%	0.0%	
Amplitude logger 2 (selection with parameter 6404) 010% distribution 6425 AL2RANGE10TO20 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 1020% distribution 6426 AL2RANGE20TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 2030% distribution 6427 AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution 6428 AL2RANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 4050% distribution 6429 AL2RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution 6430 AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution 6431 AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution 6432 AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0%		Amplitude logger 1 (current i	n percent of nominal of	current) 4050% o	distribution	
AL2RANGE10TO20 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 10 20% distribution 6426 AL2RANGE20TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 20 30% distribution 6427 AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 30 40% distribution 6428 AL2RANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 40 50% distribution 6429 AL2RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 50 60% distribution 6430 AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 60 70% distribution 6431 AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 70 80% distribution 6432 AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0%	6424	AL2RANGE0TO10	0.0 100.0%	1 = 0.1%	0.0%	
Amplitude logger 2 (selection with parameter 6404) 1020% distribution 6426 AL2RANGE20TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 2030% distribution 6427 AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution 6428 AL2RANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 4050% distribution 6429 AL2RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution 6430 AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution 6431 AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution 6432 AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0%		Amplitude logger 2 (selection	n with parameter 6404) 010% distribut	ion	
6426 AL2RANGE20TO30 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 2030% distribution 6427 AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution 0.0% 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 4050% distribution 0.0% 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution 0.0% 0.0% 0.0% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution 0.0% 0.0% 0.0% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution 0.0% <t< td=""><td>6425</td><td>AL2RANGE10TO20</td><td>0.0 100.0%</td><td>1 = 0.1%</td><td>0.0%</td><td></td></t<>	6425	AL2RANGE10TO20	0.0 100.0%	1 = 0.1%	0.0%	
Amplitude logger 2 (selection with parameter 6404) 2030% distribution 6427 AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution 6428 AL2RANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 4050% distribution 6429 AL2RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution 6430 AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution 6431 AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution 6432 AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0%		Amplitude logger 2 (selection	n with parameter 6404) 1020% distribu	ıtion	
6427 AL2RANGE30TO40 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 3040% distribution 6428 AL2RANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 4050% distribution 0.0% 0.0% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution 0.0% 0.0% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution 0.0% 0.0% 0.0% AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution 0.0% AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0%	6426	AL2RANGE20TO30	0.0 100.0%	1 = 0.1%	0.0%	
Amplitude logger 2 (selection with parameter 6404) 3040% distribution 6428 AL2RANGE40TO50 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 4050% distribution 6429 AL2RANGE50TO60 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution 6430 AL2RANGE60TO70 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution 6431 AL2RANGE70TO80 0.0100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution 6432 AL2RANGE80TO90 0.0100.0% 1 = 0.1% 0.0%		Amplitude logger 2 (selection	n with parameter 6404) 2030% distribu	ıtion	
6428 AL2RANGE40TO50 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 4050% distribution 6429 AL2RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution 6430 AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution 6431 AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution 6432 AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0%	6427	AL2RANGE30TO40	0.0 100.0%	1 = 0.1%	0.0%	
Amplitude logger 2 (selection with parameter 6404) 4050% distribution 6429 AL2RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution 6430 AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution 6431 AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution 6432 AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0%		Amplitude logger 2 (selection	n with parameter 6404) 3040% distribu	ıtion	
6429 AL2RANGE50TO60 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 5060% distribution 6430 AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution 6431 AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution 6432 AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0%	6428	AL2RANGE40TO50	0.0 100.0%	1 = 0.1%	0.0%	
Amplitude logger 2 (selection with parameter 6404) 5060% distribution 6430 AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution 6431 AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution 6432 AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0%		Amplitude logger 2 (selection	n with parameter 6404) 4050% distribu	ıtion	
6430 AL2RANGE60TO70 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 6070% distribution 6431 AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution 6432 AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0%	6429	AL2RANGE50TO60	0.0 100.0%	1 = 0.1%	0.0%	
Amplitude logger 2 (selection with parameter 6404) 6070% distribution 6431 AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution 6432 AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0%		Amplitude logger 2 (selection	n with parameter 6404) 5060% distribu	ıtion	
6431 AL2RANGE70TO80 0.0 100.0% 1 = 0.1% 0.0% Amplitude logger 2 (selection with parameter 6404) 7080% distribution 6432 AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0%	6430	AL2RANGE60TO70	0.0 100.0%	1 = 0.1%	0.0%	
Amplitude logger 2 (selection with parameter 6404) 7080% distribution 6432 AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0%		Amplitude logger 2 (selection	n with parameter 6404) 6070% distribu	ıtion	
6432 AL2RANGE80TO90 0.0 100.0% 1 = 0.1% 0.0%	6431	AL2RANGE70TO80	0.0 100.0%	1 = 0.1%	0.0%	
		Amplitude logger 2 (selection	n with parameter 6404) 7080% distribu	ıtion	
Amplitude legger 2 (collection with persenter \$404) 20, 000/ distribution	6432	AL2RANGE80TO90	0.0 100.0%	1 = 0.1%	0.0%	
Amplitude logger 2 (selection with parameter 6404) 8090% distribution		Amplitude logger 2 (selection	n with parameter 6404) 8090% distribu	ıtion	

	Group 64: Load analyzer						
Code	Description	Range	Resolution	Default	S		
6433	AL2RANGE90TO	0.0 100.0%	1 = 0.1%	0.0%			
	Amplitude logger 2 (selection with parameter 6404) 90100% distribution						

Group 81: PFA control

This group defines a Pump and Fan Alternation (PFA) mode of operation. The major features of PFA are:

- The ACS320 controls the motor of pump no. 1, varying the motor speed to control
 the pump capacity. This motor is the speed regulated motor.
- Direct line connections power the motor of pump no. 2 and pump no. 3, etc. The ACS320 switches pump no. 2 (and then pump no. 3, etc.) on and off as needed. These motors are auxiliary motors. Use of the MREL-01 relay output module is required for control of pump no. 2 and no. 3.
- The ACS320 PID control uses two signals: a process reference and an actual value feedback. The PID controller adjusts the speed (frequency) of the first pump such that the actual value follows the process reference.
- When demand (defined by the process reference) exceeds the first motor's capacity (user defined as a frequency limit), the PFA automatically starts an auxiliary pump. The PFA also reduces the speed of the first pump to account for the auxiliary pump's addition to total output. Then, as before, the PID controller adjusts the speed (frequency) of the first pump such that the actual value follows the process reference. If demand continues to increase, PFA adds additional auxiliary pumps, using the same process.
- When demand drops, such that the first pump speed falls below a minimum limit (user defined by a frequency limit), the PFA automatically stops an auxiliary pump. The PFA also increases the speed of the first pump to account for the auxiliary pump's missing output.
- An Interlock function (when enabled) identifies off-line (out of service) motors, and the PFA skips to the next available motor in the sequence.

An Autochange function (when enabled and with the appropriate switchgear) equalizes duty time between the pump motors. Autochange periodically increments the position of each motor in the rotation – the speed regulated motor becomes the last auxiliary motor, the first auxiliary motor becomes the speed regulated motor, etc.

	G	roup 81: PFA contro	ol		
Code	Description	Range	Resolution	Default	S
8103	REFERENCE STEP	0.0 100.0%	0.1%	0.0%	
	1				
	Sets a percentage value the	at is added to the proce	ss reference.		
	Applies only when <u>at least</u>	<u>st one</u> auxiliary (constar	nt speed) motor is	running.	
	 Default value is 0%. 				
	Example: An ACS320 open pipe.	rates three parallel pum	os that maintain wa	ater pressure	e in a
	Parameter 4011 INTERN trols the pressure in the		stant pressure ref	erence that o	con-
	 The speed regulated pur 	mp operates alone at lov	v water consumpti	on levels.	
	 As water consumption in second. 	creases, first one consta	ant speed pump or	perates, ther	, the
	 As flow increases, the pressure at the output end of the pipe drops relative to the pressure measured at the input end. As auxiliary motors step in to increase the flow, the adjustments below correct the reference to more closely match the output pressure. 				
	 When the first auxiliary pump operates, increase the reference with parameter 8103 REFERENCE STEP 1. 				
	When both auxiliary pumps operate, increase the reference with parameter 8103 REFERENCE STEP 1 + parameter 8104 REFERENCE STEP 2.				
	When three auxiliary pur REFERENCE STEP 1 + REFERENCE STEP 3.				
8104	REFERENCE STEP	0.0 100.0%	0.1%	0.0%	
	2				
	Sets a percentage value the	at is added to the proce	ss reference.		
	Applies only when at least	<u>st two</u> auxiliary (constar	it speed) motors a	re running.	
	See parameter 8103 RE	FERENCE STEP 1.			
8105	REFERENCE STEP	0.0 100.0%	0.1%	0.0%	
	3				
	Sets a percentage value the	at is added to the proce	ss reference.		
	Applies only when at least	• •	ant speed) motors	are running.	
	See parameter 8103 RE	FERENCE STEP 1			

ACS320 output frequency exceeds the limit: 8110 START FREQ 2 + 1.

least the time: 8115 AUX MOT START D.

Output frequency stays above the relaxed limit (8110 START FREQ 2 - 1 Hz) for at

		Group 81: PFA contro	ol .		
Code	Description	Range	Resolution	Default	S
8111	START FREQ 3	0.0 500.0 Hz	0.1 Hz	60.0	
	Sets the frequency limit	used to start the third auxili	ary motor.		
	• See parameter 8109 S	START FREQ 1 1for a com	plete description	of the opera	tion.
	The third auxiliary motor	starts if:			
	Two auxiliary motors a	are running.			
	ACS320 output frequence	ency exceeds the limit: 811	1 START FREQ 3	+ 1 Hz.	
	Output frequency stay least the time: 8115 A	s above the relaxed limit (8 UX MOT START D.	3111 START FRE	Q 3 - 1 Hz) f	or at
8112	LOW FREQ 1	0.0 500.0 Hz	0.1 Hz	25.0	
	stops if: • First auxiliary motor is alone. • ACS320 output freque drops below the limit: 8112 LOW FREQ 1	ency f _{MAX} 8109 -	ary motor. The firs	t auxiliary m	ıotor
	Output frequency stay the relaxed limit (8112 LOW FREQ 1 + for at least the time: 8 AUX MOT STOP D.	8112 (8112)- 1 ≠ − 1 Hz)		<u> </u>	Ā V
	After the first auxiliary mestops:	otor	8116	-	
	Output frequency increby the value = (8109 START FREQ 1) (8112 LOW FREQ 1).	1			t
	In effect, the output of loss of the auxiliary me	the speed regulated motor otor.	increases to com	pensate for	the
	See the figure, where:				
	• A = (8109 START FRE	EQ 1) - (8112 LOW FREQ	1)		
	B = Output frequency	decrease during the stop d	lelay.		
		auxiliary motor's run status	-	creases (1 =	= On)
	same. For details on the	rsteresis – if time is reverse the path for starting, see the			
	Note: Low Frequency 1	value must be between:			

(2007 MINIMUM FREQ).8109 START FREQ 1

	(Group 81: PFA contro	I								
Code	Description	Range	Resolution	Default	S						
8113	LOW FREQ 2	0.0 500.0 Hz	0.1 Hz	25.0							
	Sets the frequency limit us	Sets the frequency limit used to stop the second auxiliary motor.									
	See 8112 LOW FREQ 1 for a complete description of the operation.										
	The second auxiliary moto	r stops if:									
	 Two auxiliary motors are 	e running.									
	Drive output frequency of	drops below the limit: 811:	3 LOW FREQ 2 -	1.							
	Output frequency stays least the time: 8116 AUX	below the relaxed limit (8 X MOT STOP D.	113 LOW FREQ 2	2 + 1 Hz) for	at						
8114	LOW FREQ 3	0.0 500.0 Hz	0.1 Hz	25.0							
	Sets the frequency limit us	ed to stop the third auxilia	ary motor.								
	 See 8112 LOW FREQ 1 	for a complete description	n of the operation	٦.							
	The third auxiliary motor s										
	Three auxiliary motors are running.										
	 ACS320 output frequen 	cy drops below the limit: 8	3114 LOW FREQ	3 - 1.							
	 Output frequency stays below the relaxed limit (8114 LOW FREQ 3 + 1 Hz) for at least the time: 8116 AUX MOT STOP D. 										
8115	AUX MOT START D	0.0 3600.0 s	0.1 s; 1 s	5.0 s							
	Sets the Start delay for the	auxiliary motors.									
	• The output frequency must remain above the start frequency limit (parameter 8109, 8110, or 8111) for this time period before the auxiliary motor starts.										
	See 8109 START FREQ 1 for a complete description of the operation.										
8116	6 AUX MOT STOP D 0.0 3600.0 s 0.1 s; 1 s 3.0 s										
	• The output frequency must remain below the low frequency limit (parameter 8112,										
	,	me period before the auxi									
	See 8112 LOW FREQ 1 for a complete description of the operation.										

PFC with Autochange mode

		Group 81: PFA contro								
Code	Description	Range	Resolution	Default	S					
3117	NR OF AUX MOT	04 (5 with TO)	1 = 1	1	✓					
	which the drive uses to		•	, ,						
	The Autochange function ulated motor.	n, if used, requires an addit	tional relay output	for the spee	d reg-					
	The following describes the set-up of the required relay outputs.									
	Relay outputs									
	- I	As noted above, each auxiliary motor requires a relay output, which the drive uses to send start/stop signals. The following describes how the drive keeps track of motors and relays.								
	The drive provides one relay output RO1. An external relay output module can be added to provide relay outputs RO2RO4.									
	Note: If five auxiliary motors are used (Autochange disabled), use transistor output TO in addition to relay outputs RO1RO4. Note that max. voltage at TO is 30 V DC.									
	Parameters 14011403 and 1410 define, respectively, how relays RO1RO4 are used – the parameter value 31 (PFA) defines the relay as used for PFA.									
	The drive assigns auxiliary motors to relays in ascending order. If the Autochange function is disabled, the first auxiliary motor is the one connected to the first relay with a parameter setting = 31 (PFA), and so on.									
	If the Autochange function lated motor is the one country the first auxiliary motor is ting = 31 (PFA), and so one of the first auxiliary motor is ting = 31 (PFA).	on is used, the assignment onnected to the first relay we set the one connected to the on. The fourth auxiliary mo frequency values as the thi	vith a parameter se second relay with tor uses the same	etting = 31 (F a paramete reference s	PFA), er set- etep,					
	ACS320	ACS320	Relay logic							

Standard PFC mode

		Group 81: PFA control				
Code	Description	Range	Resolution	Default	S	

The table below shows the PFA motor assignments for some typical settings in the relay output parameters (1401...1403 and 1410), where the settings are either = 31 (), or =X (anything but 31), and where the Autochange function is disabled (8118 AUTOCHNG INTERV = 0).

	Para	ameter set	tting	Relay assignment				
1401	1402	1403	1410	8117	Autochange disabled			
					RO1	RO2	RO3	RO4
31	Х	Х	Х	1	Aux.	Х	Х	Х
31	31	Х	Х	2	Aux.	Aux.	Х	Х
31	31	31	Х	3	Aux.	Aux.	Aux.	Х
Х	31	31	Х	2	Х	Aux.	Aux.	Х
31	31	Х	Х	1*	Aux.	Aux.	Х	Х

^{* =} One additional relay output for the PFC that is in use. One motor is in "sleep" when the other is rotating.

The table below shows the PFA motor assignments for some typical settings in the relay output parameters (1401...1403 and 1410), where the settings are either = 31 (), or =X (anything but 31), and where the Autochange function is enabled (8118 AUTOCHNG INTERV > 0).

	Para	ameter se	tting	Relay assignment				
1401	1402	1403	1410	8117	Autochange enabled			
					RO1	RO2	RO3	RO4
31	31	Х	Х	1	PFA	PFA	Х	Х
31	31	31	Х	2	PFA	PFA	PFA	Х
Х	31	31	Х	1	Х	PFA	PFA	Х
31	31	Х	Х	0**	PFA	PFA	Х	Х

^{** =} No auxiliary motors, but the Autochange function is in use. Working as a standard PID-control.

	Gr	oup 81: PFA contro	ol		
Code	Description	Range	Resolution	Default	S
8118	AUTOCHNG INTERV	0.1 336.0 h	1 = 0.1 h	NOT SEL	
	Controls operation of the Au	tochange function and	sets the interval b	etween cha	nges.
	The Autochange time intervals running.	al only applies to the tim	ne when the spee	d regulated n	notor
	See parameter 8119 AUTO	CHNG LEVEL for an ov	erview of the Auto	ochange fund	ction.
	The drive always coasts to s Autochange enabled selection	•	•		!
	WARNING! When enabled, the Autochange function requires the interlocks (8120 INTERLOCKS > 0) enabled. During the Autochange function the power output is interrupted and the drive coasts to stop, preventing damage to the contacts.				
	ACS	Relay logic PFC with Auto	change mode		
	-0.1 = TEST MODE – Force 0.0 = NOT SEL – Disables t The operating time interval (he Autochange function	٦.	veen automa	ntic

motor changes.

ning motors are not interrupted.

\sim	_	٠.
/	.ກ	4

	Gr	oup 81: PFA contr	ol					
Code	Description	Range	Resolution	Default	S			
119	AUTOCHNG LEVEL	0.0 100.0%	0.1%	50.0%				
	Sets an upper limit, as a percoutput from the PID/PFA conprevented. For example, use Pump-Fan system is operation	trol block exceeds this this parameter to den	s limit, the Autocha y the Autochange t	ange functior	ı is			
	Autochange overview							
	The purpose of the autochar motors used in a system. At	each autochange ope	ration:	·				
	 A different motor takes a to lated motor. 	urn connected to the A	ACS320 output – tł	ne speed reg	gu-			
	The starting order of the or	ther motors rotates.						
	The Autochange function rec	quires:						
	External switchgear for ch	External switchgear for changing the drive's output power connections.						
	Parameter 8120 INTERLO	OCKS = value > 0.						
	The Autochange function is p	performed when:						
	The running time since the 8118 AUTOCHNG INTER		e operation reache	s the time se	et b			
	The PFA input is below the	e level set by this para	meter, 8119 AUT	OCHNG LEV	ΈL			
	Note: The ACS320 always of	oasts to stop when au	itochange operatio	n is perform	ed.			
	In an autochange operation, figure below):	·	• .	•				
	Initiates a change when the running time, since the last autochange operation, reaches 8118 AUTOCHNO INTERV, and PFA input is below limit 8119 AUTOCHNG LEVEL.	t 100% — —	4PFA		2PF 3PF			
	 Stops the speed regulated motor. 	<u></u>			t			
	Switches off the contactor of the speed regulated motor.	1PFA	118	— 8122 — 8118 —	<u>`</u>			
	Increments the starting order counter, to change the starting order for the motors.	operation not B = Autochange op			ge			
	Identifies the next motor in line to be the speed regular	='						
	illie to be the speed regula	ilcu motor.						

• Switches on the contactor of the new speed regulated motor. The autochange switchgear connects this motor to the ACS320 power output.

• Delays motor start for the time 8122 PFA START DELAY.

	Group 81	l: PFA contro		
Code	Description	Range	Resolution	Default S
	 Starts the speed regulated motor. Identifies the next constant speed Switches the above motor on, but running (as a constant speed mot running before and after autochar Continues with a normal PFA ope 	only if the new or) – This step I nge operation.	speed regulated	
	Starting order counter	Output		
	The operation of the starting-order counter: • The relay output parameter definitions (14011403 and 1410) establish the initial motor sequence. (The lowest parameter number with a value 31 (PFA) identifies the relay connected to 1PFA, the first motor, and so on.) • Initially, 1PFA = speed regulated motor, 2PFA = 1st auxiliary	frequency No	Area autochange is allowed	motors
	 motor, etc. The first autochange operation shifts the sequence to: 2PFA = sp , 1PFA = last auxiliary motor. 	eed regulated n	notor, 3PFA = 1s	st auxiliary motor,
	The next autochange operation sl	hifts the sequen	ce again, and so	on.
	If the autochange operation cannot are interlocked, the drive displays			all inactive motors
	When the ACS320 power supply autochange rotation positions in p autochange rotation starts at the p	ermanent mem	ory. When powe	
	If the PFA relay configuration is chrotation is reset. (See the first bull	• (PFA enable valu	e is changed), the

Defines operation of the Interlock function. When the Interlock function is enabled:

- · An interlock is active when its command signal is absent.
- · An interlock is inactive when its command signal is present.

The drive will not start if a start command occurs when the speed regulated motor's interlock is active – the control panel displays alarm 2015 PFC I LOCK.

Wire each Interlock circuit as follows:

- Wire a contact of the motor's On/Off switch to the Interlock circuit the drive's PFA logic can then recognize that the motor is switched off, and start the next available motor.
- Wire a contact of the motor thermal relay (or other protective device in the motor circuit) to the Interlock input the drive's PFA logic can then recognize that a motor fault is activated and stop the motor.
- 0 = NOT SEL Disables the Interlock function. All digital inputs are available for other purposes.
 - Requires parameter 8118 AUTOCHNG INTERV = 0 (The Autochange function must be disabled if the Interlock function is disabled.)
- 1 = DI1 Enables the Interlock function, and assigns a digital input (starting with DI1) to the interlock signal for each PFA relay. These assignments are defined in the following table and depend on:

The number of PFA relays (number of parameters 1401...1403 and 1410) with value = 31 (PFA)

The Autochange function status (disabled if 8118 AUTOCHNG INTERV = 0, and otherwise enabled).

No. PFA relays	Autochange disabled (8118)	Autochange enabled (8118)
0	DI1: Speed Reg Motor DI2DI5: Free	Not allowed
1	DI1: Speed Reg Motor DI2: First PFA Relay DI3DI5: Free	DI1: First PFA Relay DI2DI5: Free
2	DI1: Speed Reg Motor DI2: First PFA Relay DI3: Second PFA Relay DI4DI5: Free	DI1: First PFA Relay DI2: Second PFA Relay DI3DI5: Free
3	DI1: Speed Reg Motor DI2: First PFA Relay DI3: Second PFA Relay DI4: Third PFA Relay DI5DI5: Free	DI1: First PFA Relay DI2: Second PFA Relay DI3: Third PFA Relay DI4DI5: Free
4	DI1: Speed Reg Motor DI2: First PFA Relay DI3: Second PFA Relay DI4: Third PFA Relay DI5: Fourth PFA Relay	DI1: First PFA Relay DI2: Second PFA Relay DI3: Third PFA Relay DI4: Fourth PFA Relay DI5DI5: Free

Note: MREL-01 required for PFA relays 2, 3 and 4.

DI1: Free

DI2: First PFA Relay

DI4: Third PFA Relay

DI2: First PFA Relay DI3: Second PFA Relay

DI4: Third PFA Relay

DI5: Fourth PFA Relay

DI5...DI5: Free DI1: Free

DI3: Second PFA Relay

	Group 81: PFA control						
Code	Description	Range	Resolution	Default	S		
	 2 = DI2 - Enables the Interlock function, and assigns a digital input (starting with DI2 to the interlock signal for each PFA relay. These assignments are defined in the following table and depend on: The number of PFA relays (number of parameters 14011403 and 1410) with value = 31 (PFA). The Autochange function status (disabled if 8118 AUTOCHNG INTERV = 0, and otherwise enabled). 						
	No. PFA relays	Autochange disabled (8118)	Autochange enak	oled (8118)			
	0	DI1: Free DI2: Speed Reg Motor DI3DI5: Free	Not allowed				
	1	DI1: Free DI2: Speed Reg Motor DI3: First PFA Relay DI4DI5: Free	DI1: Free DI2: First PFA Rela DI3DI5: Free	ay			
	2	DI1: Free DI2: Speed Reg Motor DI3: First PFA Relay DI4: Second PFA Relay	DI1: Free DI2: First PFA Rela DI3: Second PFA I DI4DI5: Free				

Note: MREL-01 required for PFA relays 2, 3 and 4.

DI5...DI5: Free

DI2: Speed Reg Motor

DI4: Second PFA Relay

DI3: First PFA Relay

DI5: Third PFA Relay

DI2: Speed Reg Motor

DI3: First PFA Relay DI4: Second PFA Relay

DI5: Third PFA Relay

DI1: Free

DI1: Free

3

4

- 3 = DI3 Enables the Interlocks function, and assigns a digital input (starting with DI3) to the interlock signal for each PFA relay. These assignments are defined in the following table and depend on:
 - The number of PFA relays (number of parameters 1401...1403 and 1410) with value = 31 (PFA).
 - The Autochange function status (disabled if 8118 AUTOCHNG INTERV = 0, and otherwise enabled).


	Group 81: PFA control						
Code	Description	Range	Resolution Default S				
	No. PFA relays	Autochange disabled (8118)	Autochange enabled (8118)				
	0	DI1DI2: Free DI3: Speed Reg Motor DI4DI5: Free	Not allowed				
	1	DI1DI2: Free DI3: Speed Reg Motor DI4: First PFA Relay DI5DI5: Free	DI1DI2: Free DI3: First PFA Relay DI4DI5: Free				
	2	DI1DI2: Free DI3: Speed Reg Motor DI4: First PFA Relay DI5: Second PFA Relay	DI1DI2: Free DI3: First PFA Relay DI4: Second PFA Relay DI5DI5: Free				
	3	DI1DI2: Free DI3: Speed Reg Motor DI4: First PFA Relay DI5: Second PFA Relay	DI1DI2: Free DI3: First PFA Relay DI4: Second PFA Relay DI5: Third PFA Relay				
	4	Not allowed	DI1DI2: Free DI3: First PFA Relay DI4: Second PFA Relay DI5: Third PFA Relay				

Note: MREL-01 required for PFA relays 2, 3 and 4.

- 4 = DI4 Enables the Interlock function, and assigns a digital input (starting with DI4) to the interlock signal for each PFA relay. These assignments are defined in the following table and depend on:
 - The number of PFA relays (number of parameters 1401...1403 and 1410) with value = 31 (PFA).
 - The Autochange function status (disabled if 8118 AUTOCHNG INTERV = 0)

No. PFA relays	Autochange disabled (8118)	Autochange enabled (8118)
0	DI1DI3: Free DI4: Speed Reg Motor DI5DI5: Free	Not allowed
1	DI1DI3: Free DI4: Speed Reg Motor DI5: First PFA Relay	DI1DI3: Free DI4: First PFA Relay DI5DI5: Free
2	DI1DI3: Free DI4: Speed Reg Motor DI5: First PFA Relay	DI1DI3: Free DI4: First PFA Relay DI5: Second PFA Relay
3	Not allowed	DI1DI3: Free DI4: First PFA Relay DI5: Second PFA Relay
4	Not allowed	Not allowed

		Group 81: PFA cont	trol
Code	Description	Range	Resolution Default S
	to the interlor following table. • The number of = 31 (PFA).	ock signal for each PFA relay. The le and depend on: PFA relays (number of paramet ge function status (disabled if 81)	signs a digital input (starting with DI5) nese assignments are defined in the lers 14011403 and 1410) with value 118 AUTOCHNG INTERV = 0, and
	No. PFA relays	Autochange disabled (8118)	Autochange enabled (8118)
	0	DI1DI4: Free DI5: Speed Reg Motor	Not allowed
	1	DI1DI4: Free DI5: Speed Reg Motor	DI1DI4: Free DI5: First PFA Relay
	2	Not allowed	DI1DI4: Free DI5: First PFA Relay
	35	Not allowed	Not allowed
	used as the The drive us PFA frequer The figure s	en fullator f _{MAX} rovides mecha- D regu- ator by- nly in fitions. st the fittions. st the fittions fittions. st the fittions fittions. st the fittions fittions. st the fittions fittions. st the fittions fittions. st the fittions fittions fittions. st the fittions fittions fittions. st the fittions fittions fittions. st the fittions fittions fittions fittions. st the fittions fittions fittions fittions. st the fittions fittions fittions fittions. st the fittions fittions fittions fittions fittions. st the fittions	y motors running ary motors running ary motors running by 4014 FBK SEL (or 4114) for the control signal 4014 FBK SEL (or 4114)



		Group 81: PFA contr	ol		
Code	Description	Range	Resolution	Default	S
8123	PFA ENABLE	01	-	0	✓
	Sets the start delay for spedrive works as follows:	eed regulated motors in	the system. Using	the delay, th	ie
	Switches on the contact the drive power output.	tor of the speed regulate	d motor – connecti	ng the moto	r to
	Delays motor start for the time 8122 PFA START DELAY.				
	Starts the speed regulated motor.				
	Starts auxiliary motors.	See parameter 8115 AU	X MOT START D f	or delay.	
	•After the drive relay	quipped with star-delta soutput switches a motor ection and then back to the	On, the star-delta	starter must	
	 So, the PFA start delay 	must be longer than the	time setting of the	star-delta st	tarter.
	1 = ACTIVE – PFA contro 2 = SPFC ACTIVE – SPF alternation application auxiliary motor is star	C control enabled. The s			

Accel/Decel applies.

0 = NOT SEL

the output of the auxiliary motor. Then the deceleration ramp defined in *Group 22*:

0.1...1800 = Activates this function using the value entered as the acceleration time.

		Group 81: PFA contro	l		
Code	Description	Range	Resolution	Default	S
8126	TIMED	04	1	0	
	AUTOCHANGE				
	Sets the Autochange fu controlled with the time	nction with timer. When enal r functions.	bles, the Autocha	nge functior	n is
	0 = NOT SEL.				
		the Autochange function what ables the Autochange function			5 1
8127	MOTORS	07	1	0	✓
	Sets the actual number of PFA controlled motors (maximum 6 motors, 1 speed regulated, 3 connected direct-on-line and 3 spare motors).				
	 This value includes a 	lso the speed regulated motor	or.		
	This value must be conchange function is used.	ompatible with number of relead.	ays allocated to F	PFA if the Au	uto-
	If Autochange function is not used, the speed regulated motor does not need to have a relay output allocated to PFA but it needs to be included in this value.				0
8128	AUX START ORDER	₹			
	Sets the start order of the	ne auxiliary motors.			
	auxiliary motors. T whose cumulative cumulative run time motor to be stoppe	Time sharing is active. Evens he start order depends on th run time is shortest is started e is the second shortest etc. d is the one whose cumulati he start order is fixed to be t	e run times: The d first, then the m When the demar ve run time is lon	auxiliary mo otor whose nd drops, the gest.	otor

Group 98: Options

This group configures for options, in particular, enabling serial communication with the drive.

		Group 98: Options	;		
Code	Description	Range	Resolution	Default	S
9802	COMM PROT SEL	05	1	0	
	Selects the communication	protocol.			
	0 = NOT SEL – No communication protocol selected.				
	1 = STD MODBUS – The drive communicates with Modbus via the RS485 channel (X1-communications, terminal).				
	See also Group 53: EF	B protocol.			
	2 = N2 – Enables fieldbus of the RS485 serial link ()			s N2 protoco	ol via
	3 = FLN – Enables fieldbus RS485 serial link (X1-c			protocol via t	the
	5 = BACNET – Enables field via the RS485 serial lin			BACnet proto	ocol
	10 = MODBUS RS232				

Default values with different macros

When application macro is changed (9902 APPLIC MACRO), the software updates the parameter values to their default values. The table below shows the parameter default values for different macros. For other parameters, the default values are the same for all macros. See the parameter list starting on page 137.

Index	Name/ Selection	HVAC DEFAULT	SUPPLY FAN	RETURN FAN	CLNG TWR FAN	CONDENSER	BOOSTER PUMP	PUMP ALTERNA
9902	APPLIC MACRO	1 = HVAC DEFAULT	2 = SUPPLY FAN	3 = RETURN FAN	4 = CLNG TWR FAN	5 = CONDENSER	6 = BOOSTER PUMP	7 = PUMP ALTERNA
1001	EXT1 COMMANDS	1 = DI1	1 = DI1	1 = DI1	1 = DI1	1 = DI1	1 = DI1	1 = DI1
1002	EXT2 COMMANDS	1 = DI1	1 = DI1	1 = DI1	1 = DI1	1 = DI1	1 = DI1	1 = DI1
1003	DIRECTION	1 = FORWARD	1 = FORWARD	1 = FORWARD	1 = FORWARD	1 = FORWARD	1 = FORWARD	1=FORWARD
1102	EXT1/EXT2 SEL	0 = EXT1	0 = EXT1	0 = EXT1	0 = EXT1	0 = EXT1	0 = EXT1	0 = EXT1
1103	REF1 SELECT	1 = AI1	1 = AI1	1 = AI1	1 = AI1	1 = AI1	1 = AI1	1 = AI1
1106	REF2 SELECT	19 = PID1OUT	19 = PID1OUT	19 = PID1OUT	19 = PID1OUT	19 = PID1OUT	19 = PID1OUT	19 = PID1OUT
1201	CONST SPEED SEL	3 = DI3	3 = DI3	3 = DI3	3 = DI3	3 = DI3	3 = DI3	0 = NOT SEL
1304	MINIMUM AI2	20.0%	20.0%	20.0%	20.0%	20.0%	20.0%	20.0%
1401	RELAY OUTPUT 1	1 = READY	7 = STARTED	7 = STARTED	1 = READY	1 = READY	1 = READY	31 = PFA
1601	RUN ENABLE	0 = NOT SEL	2 = DI2	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL
1805	DO SIGNAL	2 = RUN	2 = RUN	2 = RUN	2 = RUN	2 = RUN	2 = RUN	2 = RUN
2008	MAXIMUM FREQ	50.0 Hz	50.0 Hz	50.0 Hz	50.0 Hz	50.0 Hz	50.0 Hz	50.0 Hz
2201	ACC/DEC 1/2 SEL	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL
2202	ACCELER TIME 1	30.0 s	30.0 s	30.0 s	30.0 s	30.0 s	10.0 s	10.0 s
2203	DECELER TIME 1	30.0 s	30.0 s	30.0 s	30.0 s	30.0 s	10.0 s	10.0 s
3019	COMM FAULT TIME	10.0 s	10.0 s	10.0 s	10.0 s	10.0 s	10.0 s	10.0 s
4001	GAIN	2.5	2.5	2.5	2.5	2.5	2.5	2.5
4002	INTEGRATION TIME	3.0 s	3.0 s	3.0 s	3.0 s	3.0 s	3.0 s	3.0 s
4101	GAIN	2.5	2.5	2.5	2.5	2.5	2.5	2.5
4102	INTEGRATION TIME	3.0 s	3.0 s	3.0 s	3.0 s	60.0 s	3.0 s	3.0 s
8116	AUX MOT STOP D	3.0 s	3.0 s	3.0 s	3.0 s	3.0 s	3.0 s	3.0 s
8118	AUTOCHNG INTERV	0.0 = NOT SEL	0.0 = NOT SEL	0.0 = NOT SEL	0.0 = NOT SEL	0.0 = NOT SEL	0.0 = NOT SEL	0.0 = NOT SEL
8123	PFA ENABLE	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL	1 = ACTIVE

Index	Name/ Selection	INT TIMER	INTTIMERCS	FLOATING PNT	DUAL SETPPID	DL SP PID CS	E-BYPASS	HAND CONTROL
9902	APPLIC MACRO	8 = INT TIMER	9 = INT TIMER CS	10 = FLOATING PNT	11 = DUAL SETPPID	12 = DL SP PID CS	13 = BYPASS	14 = HAND CONTROL
1001	EXT1 COMMANDS	11 = TIMER 1	1 = DI1	1 = DI1	1 = DI1	1 = DI1	1 = DI1	0 = NOT SEL
1002	EXT2 COMMANDS		0 = NOT SEL		1 = DI1	1 = DI1	1 = DI1	0 = NOT SEL
1003	DIRECTION	1 = FORWARD	1 = FORWARD	1 = FORWARD	1 = FORWARD	1 = FORWARD	1 = FORWARD	1 = FORWARD
1102	EXT1/EXT2 SEL	0 = EXT1	0 = EXT1	0 = EXT1	0 = EXT1	2 = DI2	0 = EXT1	0 = EXT1
1103	REF1 SELECT	1 = Al1	0 = KEYPAD	30 = DI4U,5D	1 = AI1	1 = AI1	1 = AI1	1 = AI1
1106	REF2 SELECT	19 = PID1OUT	2 = AI2	19 = PID1OUT	19 = PID1OUT	19 = PID1OUT	19 = PID1OUT	2 = AI2
1201	CONST SPEED SEL	0 = NOT SEL	1	3 = DI3	0 = NOT SEL	10 = DI4,5	0 = NOT SEL	0 = NOT SEL
1304	MINIMUM AI2	20.0%	20%	20%	20.0%	20.0%	20.0%	20.0%
1401	RELAY OUTPUT 1	7 = STARTED	7 = STARTED	7 = STARTED	7 = STARTED	1 = READY	7 = STARTED	1 = READY
1601	RUN ENABLE	2 = DI2	2 = DI2	2 = DI2	2 = DI2	0 = NOT SEL	2 = DI2	0 = NOT SEL
1805	DO SIGNAL	2 = RUN	2 = RUN	2 = RUN	2 = RUN	2 = RUN	2 = RUN	2 = RUN
2008	MAXIMUM FREQ	50.0 Hz	50.0 Hz	50.0 Hz	50.0 Hz	50.0 Hz	50.0 Hz	50.0 Hz
2201	ACC/DEC 1/2 SEL	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL
2202	ACCELER TIME 1	30.0 s	30.0 s	30.0 s	30.0 s	30.0 s	30.0 s	30.0 s
2203	DECELER TIME 1	30.0 s	30.0 s	30.0 s	30.0 s	30.0 s	30.0 s	30.0 s
3019	COMM FAULT TIME	10.0 s	10.0 s	10.0 s	10.0 s	10.0 s	10.0 s	10.0 s
4001	GAIN	2.5	1.0	2.5	2.5	2.5	2.5	1.0
4002	INTEGRATION TIME	3.0 s	60.0 s	3.0 s	3.0 s	3.0 s	3.0 s	60.0 s
4101	GAIN	2.5	2.5	2.5	2.5	2.5	2.5	2.5
4102	INTEGRATION TIME	3.0 s	3.0 s	3.0 s	3.0 s	3.0 s	3.0 s	3.0 s
8116	AUX MOT STOP D	3.0 s	3.0 s	3.0 s	3.0 s	3.0 s	3.0 s	3.0 s
8118	AUTOCHNG INTERV	0.0 = NOT SEL	0.0 = NOT SEL	0.0 = NOT SEL	0.0 = NOT SEL	0.0 = NOT SEL	0.0 = NOT SEL	0.0 = NOT SEL
8123	PFA ENABLE	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL	0 = NOT SEL





Fieldbus control

Contents of this chapter


The chapter describes how the drive can be controlled by external devices over a communication network using embedded fieldbus.

System overview

The drive can be connected to an external control system via embedded fieldbus. The embedded fieldbus supports Modbus RTU, BACnet®, Metasys® N2 and APOGEE® FLN protocols.

Embedded fieldbus connection is either RS-232 (control panel connector X2) or RS-485 (I/O terminals 23...26). The maximum length of the communication cable with RS-232 is restricted to 3 meters.

RS-232 is designed for a point-to-point application (a single master controlling one slave). RS-485 is designed for a multipoint application (a single master controlling one or more slaves).



The drive can be set to receive all of its control information through the fieldbus interface, or the control can be distributed between the fieldbus interface and other available sources, for example, digital and analog inputs.

Control interface

In general, the basic control interface between the fieldbus system and the drive consists of:

Protocol	Control Interface	Reference for more information
Modbus	Output Words Control word Reference1 Reference2 Input Words Status word Actual value 1 Actual value 2 Actual value 3 Actual value 4 Actual value 5 Actual value 6 Actual value 7 Actual value 8	The content of these words is defined by profiles. For details on the profiles used, see ABB control profiles technical data
N2	Binary output objectsAnalog output objectsBinary input objectsAnalog input objects	N2 protocol technical data
FLN	Binary output pointsAnalog output pointsBinary input pointsAnalog input points	FLN protocol technical data
BACnet	 Device management Binary output objects Analog output objects Binary input objects Analog input objects 	BACnet protocol technical data

Note: The words "output" and "input" are used as seen from the fieldbus controller point of view. For example an output describes data flow from the fieldbus controller to the drive and appears as an input from the drive point of view.

Planning

Network planning should address the following questions:

- · What types and quantities of devices must be connected to the network?
- · What control information must be sent down to the drives?
- · What feedback information must be sent from the drives to the controlling system?

Mechanical and electrical installation - EFB




WARNING! Connections should be made only while the drive is disconnected from the power source.


Drive terminals 23...26 are for RS485 communications.

- Use Belden 9842 or equivalent. Belden 9842 is a dual twisted, shielded pair cable with a wave impedance of 120 Ω .
- Use one of these twisted shielded pairs for the RS485 link. Use this pair to connect all A (-) terminals together and all B (+) terminals together.
- Use one of the wires in the other pair for the logical ground (terminal 26), leaving one wire unused.
- Do not directly ground the RS485 network at any point. Ground all devices on the network using their corresponding grounding terminals.
- As always, the grounding wires should not form any closed loops, and all the devices should be grounded to a common ground.
- Connect the RS485 link in a daisy-chained bus, without dropout lines.
- To reduce noise on the network, terminate the RS485 network using 120 Ω resistors at both ends of the network. Use the DIP switch to connect or disconnect the termination resistors. See following wiring diagram.
- · For configuration information see the following:
 - below.
 - Activate drive control functions EFB on page 275.
 - The appropriate EFB protocol specific technical data. For example, Modbus protocol technical data on page 318.

Preferred Wiring Diagram



Alternate Wiring Diagram



Communication set-up - EFB

Serial communication selection

To activate the serial communication, set parameter 9802 COMM PROT SEL =

- 1 (STD MODBUS)
- 2 (N2)
- 3 (FLN)
- 5 (BACNET).

Note: If you cannot see the desired selection on the panel, your drive does not have that protocol software in the application memory.

Serial communication configuration

Setting parameter 9802 COMM PROT SEL automatically sets the appropriate default values in parameters that define the communication process. These parameters and descriptions are defined below. In particular, note that the station Id may require adjustment.

Code	Description		EFB F	Protocol F	Reference
Code	Description	Modbus	N2	FLN	BACnet
5301	EFB PROTOCOL ID Contains the identification and program revision of the protocol.	COMM PRO	<i>T SEL</i> , set	entered for parameter 9802 meter automatically. The ocol ID, and YY = program	
5302	EFB STATION ID Defines the node address of the RS485 link.	Set each driv with a unique parameter. When this protect the default va parameter is: Note: For a n affect, the dri cycled OR 53 to 0 before s address. Lea places the Ri reset, disablii	otocol is sealue for this 1 lew address ve power released and the sealure for this 2 lecting a reving 5302 S485 chan	elected, so so to take must be rest be set new = 0 nel in	Sets MS/TP MAC ID. A temporary value of 0 places the protocol channel in reset.

Cada	Description		EFB F	Protocol F	Reference
Code	Description	Modbus	N2	FLN	BACnet
5303	EFB BAUD RATE Defines the communication speed of	When this pro the default va parameter is	otocol is sealue for this	elected,	When this protocol is selected, the default value for this parameter is:
	the RS485 link in kbits per second (kbits/s). 1.2 kbits/s	9.6	9.6	4.8	38400.
	2.4 kbits/s 4.8 kbits/s 9.6 kbits/s				
	19.2 kbits/s 38.4 kbits/s 57.6 kbits/s				
	76.8 kbits/s				
5304	EFB PARITY Defines the data length,	When this protocol is		s protocol this param	is selected, the default neter is: 0
	parity and stop bits to be used with the RS485 link communication.	selected, the default value for			Sets MS/TP character format.
	The same settings must be used in all on-line stations.	this parameter is: 1			
	0 = 8N1 – 8 data bits, No parity, one stop bit. 1 = 8N2 – 8 data bits, No				
	parity, two stop bits. 2 = 8E1 - 8 data bits, Even parity, one stop				
	bit. 3 = 8O1 – 8 data bits, Odd				
5305	parity, one stop bit. EFB CTRL PROFILE Selects the communication profile used by the EFB protocol. 0 = ABB DRV LIM — Operation of Control/Status Words conform to ABB Drives Profile, as used in ACH400. 1 = DCU PROFILE — Operation of Control/Status Words conform to 32-bit DCU Profile. 2 = ABB DRV FULL — Operation of Control/Status Words conform to ABB Drives Profile, as used in ACH600/800.	When this protocol is selected, the default value for this parameter is: 0	value for the Changing	this param the value	ocol is selected, the default neter is: 0. for this parameter has no col's behavior.

Code	Description		EFB F	Protocol F	Reference	
Code	Description	Modbus	N2	FLN	BACnet	
5310	EFB PAR10	Not used for Comm setup.	millisecor the defau	nds. When It value is:	e turnaround time in this protocol is selected,	
			3 msec.	0 msec.	5 msec.	
5311	EFB PAR11		This parameter, too with parameter 531 BACnet Device Ob Instance IDs: • For the range 1 to 65,535: This parameter (5317 must be 0 example, the foll values set the ID 49134: 5311 = 4to and 5317 = 0. • For IDs > 65,335 ID equals 5311's plus 10,000 time 5317's value. For example, the foll values set the ID 71234: 5311 = 11 and 5317 = 7.			
5312	EFB PAR12	Not used for	Comm set	up.	This parameter sets the BACnet Device Object Max Info Frames Property.	
5313	EFB PAR13	Not used for	Comm set	up.	This parameter sets the BACnet Device Object Max Master Property.	
5314	EFB PAR14	Not used for	Comm set	up.		
5315	EFB PAR15	Not used for	Comm set	up.		
5316	EFB PAR 16	Not used for	Comm set	up.	This parameter indicates the count of MS/TP tokens passed to this drive.	
5317	EFB PAR17				This parameter works with parameter 5311 to set BACnet Device Object Instance IDs. See parameter 5311.	

Note: After any changes to the communication settings, protocol must be reactivated by either cycling the drive power, or by clearing and then restoring the station Id (5302) or use Reinitialize Device Service.

Activate drive control functions - EFB

Controlling the drive

Fieldbus control of various drive functions requires configuration to:

- Tell the drive to accept fieldbus control of the function.
- Define as a fieldbus input, any drive data required for control.
- Define as a fieldbus output, any control data required by the drive.

The following sections describe, at a general level, the configuration required for each control function. For the protocol-specific details, see the document supplied with the FBA module.

Start/Stop direction control

Using the fieldbus for start/stop/direction control of the drive requires:

- Drive parameter values set as defined below.
- Fieldbus controller supplied command(s) in the appropriate location. (The location is defined by the Protocol Reference, which is protocol dependent.)

				Protocol Reference					
Drive	e Parameter	Value	Description	Modbus ¹					
2or arameter		30.00	2000.11	abb drv	dcu profile	N2	FLN	BACnet	
1001	EXT1 COMMAND S	10 (COMM)	Start/Stop by fieldbus with Ext1 selected.	40001 bits 03	40031 bits 0, 1	BO1	24	BV10	
1002	EXT2 COMMAND S	10 (COMM)	Start/Stop by fieldbus with Ext2 selected.	40001 bits 03	40031 bits 0, 1	BO1	24	BV10	
1003	DIRECTION	3 (REQUEST)	Direction by fieldbus.	4002/ 4003 ²	40031 bit 3	BO2	22	BV11	

^{1.}For Modbus, the protocol reference can depend on the profile used, hence two columns in these tables. One column refers to the ABB Drives profile, selected when parameter 5305 = 0 (ABB DRV LIM) or 5305 = 2 (ABB DRV FULL). The other column refers to the DCU profile selected when parameter 5305 = 1 (DCU PROFILE). See section ABB control profiles technical data.

^{2.}The reference provides direction control – a negative reference provides reverse rotation.

Input reference select

Using the fieldbus to provide input references to the drive requires:

- Drive parameter values set as defined below.
- Fieldbus controller supplied reference word(s) in the appropriate location. (The location is defined by the Protocol Reference, which is protocol dependent.)

				Protocol Reference						
Drive	Parameter	Value	Setting	Mod		FLN				
		10.00		abb drv	dcu profile		N2	BACnet		
1102	EXT1/ EXT2 SEL	8 (COMM)	Reference set selection by fieldbus.	40001 bit 11	40031 bit 5	BO5	26	BV13		
1103	REF1 SEL	8 (COMM)	Input reference 1 by fieldbus.	40002		AO1	60	AV16		
1106	REF2 SEL	8 (COMM)	Input reference 2 by fieldbus.	40003		AO2	61	AV17		

Reference scaling

Where required, REFERENCES can be scaled. See the following, as appropriate:

- Modbus Register 40002 in the Modbus protocol technical data section.
- Reference scaling in the ABB control profiles technical data section.
- N2 analog output objects in the N2 protocol technical data section.
- The slope of points 60 and 61 in the FLN protocol technical data section.

Miscellaneous drive control

Note: The user should change only the parameters for the functions you wish to control vial fieldbus. All other parameters should typically remain at factory default. For simple start/stop and speed reference fieldbus control, only parameters 1001 EXT1 COMMANDS and 1103 REF1 SELECT need to be changed to COMM.

Using the fieldbus for miscellaneous drive control requires:

- Drive parameter values set as defined below.
- Fieldbus controller supplied reference word(s) in the appropriate location. (The location is defined by the Protocol Reference, which is protocol dependent.)

				Protocol Reference					
Drive	Parameter	Value	Setting	Modbus					
				abb drv	dcu profile	N2	FLN	BACnet	
1601	RUN ENABLE	7 (COMM)	Run enable by fieldbus. (Not recommended ¹)	40001 bit 3	40031 bit 6 (inverted)	BO4	35	BV12	

					Protocol	Refere	nce	
Drive	Parameter	Value	Setting	Mod	lbus			
				abb drv	dcu profile	N2	FLN	BACnet
1604	FAULT RESET SEL	8 (COMM)	Fault reset by fieldbus.	40001 bit 7	40031 bit 4	BO6	94	BV14
1606	LOCAL LOCK	8 (COMM)	Source for local lock selection is the fieldbus.	Does not apply	40031 bit 14			
1607	PARAM SAVE	1 (SAVE)	Saves altered parameters to memory (then value returns to 0).	41607	40032 bit 2	BO18	N/A ¹	
1608	START ENABLE 1	7 (COMM)	Source for start enable 1 is the fieldbus Command word. (Not recommended) ¹	Does not apply.	40032 bit 2			BV20
1609	START ENABLE 2	7 (COMM)	Source for start enable 2 is the fieldbus Command word. (Not recommended) ¹		40032 bit 3			BV21
2013	MIN TORQUE SEL	7 (COMM)	Source for minimum torque selection is the fieldbus.		40031 bit 15			
2014	MAX TORQUE SEL	7 (COMM)	Source for maximum torque selection is the fieldbus.					
2201	ACC/DEC 1/2 SEL	7 (COMM)	Source for ramp pair selection is the fieldbus.		40031 bit 10			

^{1.}ABB recommends hard wiring run permissive and safeties.

Relay output control

Using the fieldbus for relay output control requires:

- Drive parameter values set as defined below.
- Fieldbus controller supplied reference word(s) in the appropriate location. (The location is defined by the Protocol Reference, which is protocol dependent.)

				Protocol Reference					
Drive	Parameter	Value	Setting	Modbus					
				abb drv	dcu profile	N2	FLN	BACnet	
1401	RELAY OUTPUT 1		Relay Output 1 controlled by fieldbus.	40134 bit 00033	0 or	BO7	40	BO0	

Drive Parameter					Protoco	l Reference		
Drive	Drive Parameter		Setting	Modbus				
21170 T di dilliotoi				abb drv	dcu profile	N2	FLN	BACnet
1402 ¹	RELAY OUTPUT 2	35 (COMM)	Relay Output 2 controlled by fieldbus.	40134 bit 00034	1 or	BO8	41	BO1
1403 ¹	RELAY OUTPUT 3	35 (COMM)	Relay Output 3 controlled by fieldbus.	40134 bit 00035	2 or	BO9	42	BO2
1410 ¹	RELAY OUTPUT 4	35 (COMM)	Relay Output 4 controlled by fieldbus.	40134 bit 00036	3 or	BO10	43	BO3

^{1.} More than 1 relay requires the addition of a relay extension module.

For example: To control relays 1 and 2 using serial communication: Set parameters 1401 RELAY OUTPUT 1 and 1402 RELAY OUTPUT 2 = 35 (COMM).

Then, for example using N2:

- To turn Relay 1 On: Force object B07 to On.
- To turn Relay 2 On: Force object B08 to On.
- To turn both Relay 1 and 2 On: Force objects B07 and B08 On.

Note: Relay status feedback occurs without configuration as defined below.

Drive Parameter				Protocol Reference					
		Value	Setting	Modbus		N2	FLN	BACnet	
				abb drv dcu profile		INZ	FLIN	BACHEL	
0122	RO 1-3 STATUS	Relay 13 status.	40122	0122		BI4 BI6	76 78	BI0 BI2	
0123	RO 4 STATUS	Relay 4 status.	40123	0123		BI7	79	BI3	

Analog output control

Using the fieldbus for analog output control requires:

- · Drive parameter values set as defined below.
- Fieldbus controller supplied reference word(s) in the appropriate location. (The location is defined by the Protocol Reference, which is protocol dependent.)

				Protocol Reference				
Dri	ve Parameter	Value	Setting	Modbus			FLN	BACnet
211101 a.a		5		abb drv	dcu profile	N2		
	AO1 CONTENT SEL	135 (COMM VALUE 1)	writing to	-		-	-	-
0135	COMM VALUE 1	_	parameter 0135.	40135		AO14	46	AO0

PID control setpoint source

Use the following settings to select the fieldbus as the setpoint source for PID loops:

					Protoc	ol Re	ferenc	e
Drive	Parameter	Value	Setting	Modbus				
2				abb drv	dcu profile	N2	FLN	BACnet
4010	SET POINT SEL (Set 1)	8 (COMM VALUE 1) 9 (COMM +	Setpoint is either: Input Reference 2 (+/-/* AI1). Control	40003	3	AO2	61	AV17
4110	SET POINT	Al1) 10 (COMM*Al1)	requires parameter 1106 value = comm. Process PID setpoint.					
4210	SET POINT SEL (Ext/Trim)		Control requires parameter 1106 value = pid1 out and parameter 4010 value = comm.					

Communication fault

When using fieldbus control, specify the drive's action if serial communication is lost.

Drive Parameter		Value	Description	
3018	COMM FAULT FUNC	0 (NOT SEL)) 1 (FAULT) 2 (CONST SP7) 3 (LAST SPEED)	Set for appropriate drive response.	
3019	COMM FAULT TIME	Set time delay before acting on a communication loss.		

Feedback from the drive - EFB

Pre-defined feedback

Inputs to the controller (drive outputs) have pre-defined meanings established by the protocol. This feedback does not require drive configuration. The following table lists a sample of feedback data. For a complete listing, see input word/point/object listings in the technical data for the appropriate protocol starting on 284.

	Drive Parameter		Protocol R	eference	
Drive Farameter		Modbus	N2	FLN	BACnet
0102	SPEED	40102	Al3	5	AV0
0103	FREQ OUTPUT	40103	Al1	2	AV1
0104	CURRENT	40104	Al4	6	AV4
0105	TORQUE	40105	AI5	7	AV5
0106	POWER	40106	Al6	8	AV6
0107	DC BUS VOLT	40107	Al11	13	AV2
0109	OUTPUT VOLTAGE	40109	Al12	14	AV3
0115	KWH COUNTER	40115	Al8	10	AV8
0118	DI1-3 STATUS – bit 1 (DI3)	40118	BI10, BI11, BI12,	70, 71, 72	BI6, BI7, BI8
0122	RO1-3 STATUS	40122	BI4, BI5, BI6	76, 77, 78	BI0, BI1, BI2
0301	FB STATUS WORD – bit 0 (STOP)	40301 bit 0	BI1	23	BV0
0301	FB STATUS WORD – bit 2 (REV)	40301 bit 2	BI2	21	BV1

Note: With Modbus, any parameter can be accessed using the format: 4 followed by the parameter number.

Mailbox Read/Write

The ACS320 provides a "Mailbox" function to access parameters that have not been pre-defined by the protocol. Using mailbox, any drive parameter can be identified and read. Mailbox can also be used to adjust parameter settings by writing a value to any parameter identified. The following table describes the use of this function.

Name	Description		Protocol	Referenc	е
Name	Description	Modbus ¹	N2	FLN	BACnet
Mailbox Parameter	Enter the number of the drive parameter to access.	Does not apply.	AO19	95	AV25
Mailbox Data	Contains the parameter value after a read, or enter the desired parameter value for a write.		AO20	96	AV26
Mailbox Read	A binary value triggers a read – the value of the "Mailbox Parameter" appears in "Mailbox data".		BO19	97	BV15
Mailbox Write	A binary value triggers a write – the drive value for the "Mailbox Parameter" changes to the value in "Mailbox data".		BO20	98	BV16

^{1.}As noted above, Modbus provides direct access to all parameters using the format: 4 followed by the parameter number.

Actual value scaling

The scaling of actual values can be protocol dependent. In general, for Actual values, scale the feedback integer using the parameter's resolution. (See section Parameter *listing* for parameter resolutions.) For example:

Feedback Integer	Parameter Resolution	(Feedback Integer) * (Parameter Resolution) = Scaled Value
1	0.1 mA	1 * 0.1 mA = 0.1 mA
10	0.1%	10 * 0.1% = 1%

Where parameters are in percent, section *Parameter listing* specifies what parameter corresponds to 100%. In such cases, to convert from percent to engineering units, multiply by the value of the parameter that defines 100% and divide by 100%. For example:

Feedback Integer	Parameter Resolution	Value of the Parameter that defines 100%	(Feedback Integer) * (Parameter Resolution) * (Value of 100% Ref.) / 100% = Scaled Value
10	0.1%	1800 rpm ¹	10 * 0.1% * 1800 RPM / 100% = 18 rpm
100	0.1%	600 Hz ²	100 * 0.1% * 600 Hz / 100% = 60 Hz

^{1.} Assuming, for the sake of this example, that the Actual value uses parameter 9908 MOTOR NOM SPEED as the 100% reference, and that 9908 = 1800 rpm.

^{2.} Assuming, for the sake of this example, that the Actual value uses parameter 9907 MOTOR NOM FREQ as the 100% reference, and that 9907 = 6.00 Hz.

Although Actual value scaling could differ from the above for the N2 and FLN protocols, it currently does not. To confirm, see the following sections, as appropriate:

- N2 analog input objects in the N2 protocol technical data section.
- Scaling drive feedback values in the FLN protocol technical data section.

Scaling does not apply for the BACnet protocol.

Diagnostics – EFB

Fault queue for drive diagnostics

For general ACS320 diagnostics information, see section LEDs. The three most recent ACS320 faults are reported to the fieldbus as defined below.

	Drive Parameter	Protocol Reference				
Drive Farameter		Modbus	N2	FLN	BACnet	
0401	Last Fault	40401	17	90	AV18	
0412	Previous Fault 1	40402	18	91	AV19	
0413	Previous Fault 2	40403	19	92	AV20	

Serial communication diagnostics

Network problems can be caused by multiple sources. Some of these sources are:

- Loose connections
- Incorrect wiring (including swapped wires)
- Bad grounding
- **Duplicate station numbers**
- Incorrect setup of drives or other devices on the network

The major diagnostic features for fault tracing on an EFB network include Group 53: EFB protocol parameters 5306...5309. Section Parameter listing describes these parameters in detail.

Diagnostic situations

The sub-sections below describe various diagnostic situations – the problem symptoms and corrective actions.

Normal operation

During normal network operation, 5306...5309 parameter values act as follows at each drive:

- 5306 EFB OK MESSAGES advances (advances for each application message properly received and addressed to this drive).
- 5307 EFB CRC ERRORS does not advance at all (advances when an invalid message CRC is received).

- 5308 EFB UART ERRORS does not advance at all (advances when character format errors are detected, such as parity or framing errors).
- 5309 EFB STATUS value varies depending on network traffic.
- BACnet protocol: 5316 EFB PAR 16 (MS/TP token counter) advances for each token passed to this drive. (Does not apply for other protocols.)

Loss of communication

The AC320 behavior, if communication is lost, was configured in *Communication* fault. The parameters are 3018 COMM FAULT FUNC and 3019 COMM FAULT TIME. Section *Parameter listing* describes these parameter.

No master station on line

If no master station is on line: Neither the EFB OK MESSAGES nor the errors (5307) EFB CRC ERRORS and 5308 EFB UART ERRORS) increase on any of the stations.

To correct:

- Check that a network master is connected and properly programmed on the network
- · Verify that the cable is connected, and is not cut or short circuited.

Duplicate stations

If two or more stations have duplicate numbers:

- Two or more drives cannot be addressed.
- Every time there is a read or write to one particular station, the value for 5307 EFB CRC ERRORS or 5308 EFB UART ERRORS advances.

To correct: Check all station numbers and edit conflicting values.

Swapped wires

If the communication wires are swapped (terminal A on one drive is connected to terminal B on another):

- The value of 5306 EFB OK MESSAGES does not advance.
- The values of 5307 EFB CRC ERRORS and 5308 EFB UART ERRORS are advancing.

To correct: Check that the EIA-485 lines are not swapped.

Fault 28 - Serial 1 Err

If the drive's control panel shows fault 0028 SERIAL 1 ERR, check for either of the following:

- The master system is down. To correct, resolve problem with master system.
- The communication connection is bad. To correct, check communication connection at the drive.

The time-out selection for the drive is too short for the given installation. The
master is not polling the drive within the specified time-out delay. To correct,
increase the time set by parameter 3019 COMM FAULT TIME.

Fault 31 - EFB1

For BACnet: If the drive's control panel shows fault *0031 EFB 1*, the drive has an invalid Device Object Instance ID. To correct, use parameters 5311 and 5317 and establish a unique drive ID that is in the range 1 to 4.194,303.

Faults 31 ... 33 - EFB1 ... EFB3

Except as noted above, these three EFB fault codes (0031 EFB 1...0033 EFB 3) are not used.

Intermittent off-line occurrences

The problems described above are the most common problems encountered with ACS320 serial communication. Intermittent problems might also be caused by:

- · Marginally loose connections,
- Wear on wires caused by equipment vibrations.
- Insufficient grounding and shielding on both the devices and on the communication cables

N2 protocol technical data

Overview


The N2 fieldbus connection to the ACS320 drives is based on an industry standard RS-485 physical interface. The N2 fieldbus protocol is a master-slave type, serial communication protocol, used by the Johnson Controls Metasys® system. In the Metasys architecture the N2 fieldbus connects object interfaces and remote controllers to Network Control Units (NCUs).

The N2 fieldbus can also be used to connect ACS320 drives to the Metasys Companion product line.

This section describes the use of the N2 fieldbus with the ACS320 drives' connection and does not describe the protocol in detail.

Supported features

In the N2 fieldbus protocol the ACS320 drive appears as a "virtual object".



A virtual object is made up of:

- Analog Inputs
- Binary Inputs
- Analog Outputs
- **Binary Outputs**
- Internal values for Floating point, Integer, and Byte values.

The ACS320 drive does not support N2 fieldbus communication "internal values".

All of the Analog and Binary I/O objects are listed below, starting with N2 analog input objects below.

Analog input – The analog input objects support the following features:

- Analog Input actual value in engineering units
- Low Alarm limit
- Low Warning limit
- High Warning limit
- High Alarm limit
- Differential value for the hysteresis of the Alarms and Warnings
- Change of State (COS) enabled
- Alarm Enabled
- Warning Enabled
- Override value is received, but there is no action taken.

Binary input – The binary input objects support the following features:

- Binary Input actual value
- Normal / Alarm state specification
- Alarm Enabled

- · Change of State (COS) enabled
- Override value is received, but there is no action taken.

Analog output – The analog output objects support the following features:


- · Analog Output value in engineering units
- Override value is used to change the Analog Output value. It is not possible to return to the previous value by removing the override. The override feature is used only to change the value.

Binary output – The binary output objects support the following features:


- Binary Output value
- Override value is used to change the Binary Output value. It is not possible to return to the previous value by removing the override. The override feature is used only to change the value.

Metasys integration

The following diagram shows the drives' integration to the Johnson Controls Metasys system.



The following diagram shows the drives' integration to the Johnson Controls Metasys Companion system.



On the N2 fieldbus each ACS320 drive can be accessed by the full complement of Metasys FMS features, including Change-of-State (COS) monitoring, alarm notification, scheduling, trend, and totalization.

On one N2 fieldbus segment there can be up to 32 nodes while integrating ACS320 drives with Johnson Controls Metasys.

Drive device type

For the Metasys and Metasys Companion products, the device type for the ACS320 drive is VND.

N2 analog input objects

The following table lists the N2 analog Input objects defined for the ACS320 drive.

	N2 Analog Inputs:								
Number	Object	Drive Parameter	Scale Factor	Units	Range				
Al1	OUTPUT FREQUENCY	0103	10	Hz	0250				
Al2	RATED SPEED	Note 1	10	%	0100				
AI3	SPEED	0102	1	rpm	09999				
Al4	CURRENT	0104	10	Α	09999				
AI5	TORQUE	0105	10	%	-200200				
Al6	POWER	0106	10	kW	09999				

	N2 Analog Inputs:							
Number	Object	Drive Parameter	Scale Factor	Units	Range			
AI7	DRIVE TEMPERATURE	0110	10	°C	0125			
Al8	KILOWATT HOURS	0115	1	kWh	065535			
AI9	MEGAWATT HOURS	0141	1	MWh	065535			
AI10	RUN TIME	0114	1	Н	065535			
AI11	DC BUS VOLTAGE	0107	1	V	0999			
Al12	OUTPUT VOLTAGE	0109	1	V	0999			
Al13	PRC PID FEEDBACK	0130	10	%	0100			
Al14	PRC PID DEVIATION	0132	10	%	0100			
Al15	EXT PID FEEDBACK	0131	10	%	0100			
Al16	EXT PID DEVIATION	0133	10	%	0100			
Al17	LAST FAULT	0401	1		fault code			
Al18	PREV FAULT	0402	1		fault code			
Al19	OLDEST FAULT	0403	1		fault code			
Al20	AI 1 ACTUAL	0120	10	%	0100			
Al21	AI 2 ACTUAL	0121	10	%	0100			
Al22	AO 1 ACTUAL	0124	10	mA	020			
Al24	MOTOR TEMP	0145	1	°C	0200			
Al25	REVOLUTION CNT	0142	1	MREV	032767			

^{1.}RATED SPEED is a percent of maximum frequency (parameter 2008) if the drive is in scalar mode, and is a percent of maximum speed (parameter 2002) in speed mode.

N2 binary input objects

The following table lists the N2 binary input objects defined for the ACS320 drive.

	N2 Binary Inputs:							
Number	Object	Drive Parameter	Range					
BI1	STOP/RUN	Status Word	0 = Stop, 1 = Drive Running					
BI2	FORWARD/REVERSE	Status Word	0 = Forward, 1 = Reverse					
BI3	FAULT STATUS	Status Word	0 = OK, 1 = Drive Fault					
BI4	RELAY 1 STATUS	0122 (bit mask 04)	0 = Off, 1 = On					
BI5	RELAY 2 STATUS	0122 (bit mask 02)	$0 = Off, 1 = On^{1}$					
BI6	RELAY 3 STATUS	0122 (bit mask 01)	$0 = Off, 1 = On^{1}$					
BI7	RELAY 4 STATUS	0123 (bit mask 04)	$0 = Off, 1 = On^{1}$					
BI10	INPUT 1 STATUS	0118 (bit mask 04)	0 = Off, 1 = On					
BI11	INPUT 2 STATUS	0118 (bit mask 02)	0 = Off, 1 = On					
BI12	INPUT 3 STATUS	0118 (bit mask 01)	0 = Off, 1 = On					
BI13	INPUT 4 STATUS	0119 (bit mask 04)	0 = Off, 1 = On					
BI14	INPUT 5 STATUS	0119 (bit mask 02)	0 = Off, 1 = On					
BI16	EXTERNAL 2 SELECT	Status Word	0 = EXT1 = EXT2					
BI17	HAND/AUTO	Status Word	0 = AUTO, 1 = HAND					

	N2 Binary Inputs:					
Number	Object	Drive Parameter	Range			
BI18	ALARM	Status Word	0 = OK, 1 = ALARM			
BI19	MAINTENANCE REQ	Status Word	0 = OK, 1 = MAINT REQ			
BI20	DRIVE READY	Status Word	0 = Not Ready, 1 = Ready			
BI21	AT SETPOINT	Status Word	0 = No, 1 = At Setpoint			
BI22	RUN ENABLED	Status Word	0 = Not Enabled, 1 = Enabled			
BI23	N2 LOCAL MODE	Status Word	0 = Auto, 1 = N2 Local			
BI24	N2 CONTROL SRC	Status Word	0 = No, 1 = Yes			
BI25	N2 REF1 SRC	Status Word	0 = No, 1 = Yes			
BI26	N2 REF2 SRC	Status Word	0 = No, 1 = Yes			

^{1.}Require optional MREL relay output card.

N2 analog output objects

The following table lists the N2 analog output objects defined for the ACS320 drive.

N2 Analog Outputs:							
Number	Object	Drive Parameter	Scale Factor	Units	Range		
AO1	REFERENCE 1	Reference 1	10	%	0100		
AO2	REFERENCE 2	Reference 2	10	%	0100		
AO3	ACCEL TIME 1	2202	10	S	0.11800		
AO4	DECEL TIME 1	2203	10	S	0.11800		
AO5	CURRENT LIMIT	2003	10	А	01.3*I _{2N}		
AO6	PID1-CONT GAIN	4001	10	%	0.1100		
AO7	PID1-CONT I-TIME	4002	10	S	0.1600		
AO8	PID1-CONT D-TIME	4003	10	S	010		
AO9	PID1-CONT D FILTER	4004	10	S	010		
AO10	PID2-CONT GAIN	4101	10	%	0.1100		
AO11	PID2-CONT I-TIME	4102	10	S	0.1600		
AO12	PID2-CONT D-TIME	4103	10	S	010		
AO13	PID2-CONT D FILTER	4104	10	S	010		
AO14	COMMAND AO 1	135	10	%	0100		
AO16	EXT PID SETPOINT	4211	10	%	0100		
AO17	SPD OUT MIN	2001/2007	10	%	0200		
AO18	SPD OUT MAX	2002/2008	10	%	0200		
A019	MAILBOX PARAMETER		1		065535		
A020	MAILBOX DATA		1		065535		

N2 binary output objects

The following table lists the N2 binary output objects defined for the ACS320 drive.

	N2 Binary Outputs:						
Number	Object	Drive Parameter	Range				
BO1	STOP/START	Command word	0 = Stop, 1 = Start to Speed				
BO2	FORWARD/REVERSE	Command word	0 = Forward, 1 = Reverse				
ВО3	PANEL LOCK	Command word	0 = Open, 1 = Locked				
BO4	RUN ENABLE	Command word	0 = Enable, 1 = Disable				
BO5	REF1/REF2 SELECT	Command word	0 = Ref1, 1 = Ref2				
BO6	FAULT RESET	Command word	Change 0 -> 1 Resets				
BO7	COMMAND RO 1	134 (bit mask 01)	0 = Off, 1 = On				
BO8	COMMAND RO 2	134 (bit mask 02)	$0 = Off, 1 = On^{1}$				
ВО9	COMMAND RO 3	134 (bit mask 04)	$0 = Off, 1 = On^{1}$				
BO10	COMMAND RO 4	134 (bit mask 08)	$0 = Off, 1 = On^{1}$				
BO13	RESET RUN TIME	114 (indirectly)	0 = N/A, 1 = On (Reset Run Time)				
BO14	RESET KWH COUNT	115 (indirectly)	0 = N/A, 1 = On (Reset kWh Count)				
BO15	PRC PID SELECT	4027 (indirectly)	0 = SET2, 1 = SET2				
BO16	N2 LOCAL CTL ²	Command word	0 = Auto, 1 = N2				
BO17	N2 LOCAL REF ²	Command word	0 = Auto, 1 = N2				
BO18	SAVE PARAMETERS	1607 (indirectly)	0 = N/A, 1 = On (Save Parameters)				
B019	READ MAILBOX		0 = No, 1 = Yes				
B020	WRITE MAILBOX		0 = No, 1 = Yes				

^{1.}Requires optional MREL relay output card.

2.N2 LOCAL CTL and N2 LOCAL REF have priority over drive input terminals. Use these binary outputs for temporary N2 control of the drive when COMM is not the selected control source.

DDL file for NCU

The listing below is the Data Definition Language (DDL) file for ACS320 drives used with the Network Control Units.

This listing is useful when defining drive I/O objects to the Network Controller Units.

Below is the ACS320.DDL file listing.

```
CSAI "AI3", N, N, "SPEED", "RPM"
CSAI "AI4", N, N, "CURRENT", "A"
CSAI "AI5", N, N, "TOROUE", "%"
CSAI "AI6", N, N, "POWER", "kW"
CSAI "AI7", N, N, "DRV TEMP", "°C"
CSAI "AI8", N, N, "ENERGY k", "kWh"
CSAI "AI9", N, N, "ENERGY M", "MWh"
CSAI "AI10", N, N, "RUN TIME", "H"
CSAI "AI11", N, N, "DC VOLT", "V"
CSAI "AI12",N,N,"VOLT ACT","V"
CSAI "AI13",N,N,"PID1 ACT"."%"
CSAI "AI14", N, N, "PID2 DEV", "%"
CSAI "AI15", N, N, "PID2 ACT", "%"
CSAI "AI16", N, N, "PID2 DEV", "%"
CSAI "AI17", N, N, "LAST FLT", "Code"
CSAI "AI18", N, N, "PREV FLT", "Code"
CSAI "AI19", N, N, "1ST FLT", "Code"
CSAI "AI20", N, N, "AI 1 ACT", "%"
CSAI "AI21", N, N, "AI 2 ACT", "%"
CSAI "AI22", N, N, "AO 1 ACT", "mA"
CSAI "AI24", N, N, "MTR TEMP", "°C"
CSAI "AI25", N, N, "REVL CNT", ""
CSBI "BI1", N, N, "STOP/RUN", "STOP", "RUN"
CSBI "BI2", N, N, "FWD/REV", "FWD", "REV"
CSBI "BI3", N, N, "FAULT", "OK", "FLT"
CSBI "BI4", N, N, "RELAY 1", "OFF", "ON"
CSBI "BI5", N, N, "RELAY 2", "OFF", "ON"
CSBI "BI6", N, N, "RELAY 3", "OFF", "ON"
CSBI "BI7", N, N, "RELAY 4", "OFF", "ON"
CSBI "BI10", N, N, "INPUT 1", "OFF", "ON"
CSBI "BI11", N, N, "INPUT 2", "OFF", "ON"
CSBI "BI12", N, N, "INPUT 3", "OFF", "ON"
CSBI "BI13", N, N, "INPUT 4", "OFF", "ON"
CSBI "BI14", N, N, "INPUT 5", "OFF", "ON"
CSBI "BI16", N, N, "EXT1/2", "EXT1", "EXT2"
CSBI "BI17", N, N, "HND/AUTO", "HAND", "AUTO"
CSBI "BI18", N, N, "ALARM", "OFF", "ON"
CSBI "BI19", N, N, "MNTNCE R", "OFF", "ON"
CSBI "BI20",N,N,"DRV REDY","NO","YES"
CSBI "BI21", N, N, "AT SETPT", "NO", "YES"
CSBI "BI22", N, N, "RUN ENAB", "NO", "YES"
CSBI "BI23", N, N, "N2 LOC M", "AUTO", "N2 L"
CSBI "BI24", N, N, "N2 CTRL", "NO", "YES"
CSBI "BI25", N, N, "N2 R1SRC", "NO", "YES"
CSBI "BI26", N, N, "N2 R2SRC", "NO", "YES"
CSAO "AO1", Y, Y, "REF 1", "%"
CSAO "AO2", Y, Y, "REF 2", "%"
CSAO "AO3", Y, Y, "ACCEL 1", "s"
CSAO "AO4", Y, Y, "DECEL 1", "s"
CSAO "AO5", Y, Y, "CURR LIM", "A"
```

```
CSAO "AO6", Y, Y, "PID1 GN", "%"
CSAO "AO7", Y, Y, "PID1 I", "s"
CSAO "AO8", Y, Y, "PID1 D", "s"
CSAO "AO9", Y, Y, "PID1 FLT", "s"
CSAO "AO10", Y, Y, PID2 GN", "%"
CSAO "A011", Y, Y, "PID2 I", "s"
CSAO "A012", Y, Y, "PID2 D", "s"
CSAO "A013", Y, Y, "PID2 FLT". "s"
CSAO "A014", Y, Y, "CMD A0 1", "%"
CSAO "AO16", Y, Y, "PI2 STPT", "%"
CSAO "AO17", Y, Y, "MIN SPD", "%"
CSAO "AO18", Y, Y, "MAX SPD", "%"
CSAO "A019", Y, Y, "MB PARAM", ""
CSAO "AO20", Y, Y, "MB DATA", ""
CSBO "BO1", Y, Y, "START", "STOP", "START"
CSBO "BO2", Y, Y, "REVERSE", "FWD", "REV"
CSBO "BO3", Y, Y, "PAN LOCK", "OPEN", "LOCKED"
CSBO "BO4", Y, Y, "RUN ENAB", "DISABLE", "ENABLE"
CSBO "BO5", Y, Y, "R1/2 SEL", "EXT 1", "EXT 2"
CSBO "BO6", Y, Y, "FLT RSET", "-", "RESET"
CSBO "BO7", Y, Y, "CMD RO 1", "OFF", "ON"
CSBO "BO8", Y, Y, "CMD RO 2", "OFF", "ON"
CSBO "BO9", Y, Y, "CMD RO 3", "OFF", "ON"
CSBO "B010", Y, Y, "CMD RO 4", "OFF", "ON"
CSBO "BO13", Y, Y, "RST RTIM", "OFF", "RESET"
CSBO "BO14", Y, Y, "RST KWH", "OFF", "RESET"
CSBO "B015", Y, Y, "PID SEL", "SET1", "SET2"
CSBO "B016", Y, Y, "N2 LOC C", "AUTO", "N2"
CSBO "BO17", Y, Y, "N2 LOC R", "EUTO", "N2"
CSBO "BO18", Y, Y, "SAV PRMS", "OFF", "SAVE"
CSBO "B019", Y, Y, "READ MB", "NO", "READ"
CSBO "BO20", Y, Y, "WRITE MB", "NO", "WRITE"
```

FLN protocol technical data

Overview

The FLN fieldbus connection to the ACS320 drives is based on an industry standard RS-485 physical interface. The FLN (Floor Level Network) fieldbus protocol is a serial communication protocol, used by the Siemens APOGEE® system. The ACS320 interface is specified in Siemens application xxxx.

Supported features

The ACS320 supports all required FLN features.

Reports

The ACS320 provides seven pre-defined reports. Using a report request generated from the FLN fieldbus controller, select one of the following sets of points. By providing views of selected points, these reports are often easier to work with than views of the full point database.

ABB ACS320

	FLN ABB drive report						
Po	oint	Subpoint name	Data				
#	Type	Subpoint name	Dala				
01	LAO	CTLR ADDRESS	Each host FLN application (for example, CIS or				
02	LAO	APPLICATION	Insight) controls both the particular data reported for each point, and the report format.				
20	LAO	OVRD TIME					
29	LDO	DAY.NIGHT					

Startup

	FLN start-up report						
P	Point Submaint name		Data				
#	Type	Subpoint name	Data				
21	LDI	FWD.REV	Each host FLN application (for example, CIS or				
22	LDO	CMD FWD.REV	Insight) controls both the particular data reported for each point, and the report format.				
23	LDI	STOP.RUN					
24	LDO	CMD STP.STRT					
25	LDI	EXT1.2 ACT					
26	LDO	EXT1.2 CMD					
34	LDI	ENA.DIS ACT					
35	LDO	ENA.DIS CMD					
36	LDI	FLN LOC ACT					
60	LAO	INPUT REF1					
61	LAO	INPUT REF2					
68	LDO	FLN LOC CTL					
69	LDO	FLN LOC REF					
94	LDO	RESET FAULT					

Overview

	FLN overview report						
Po	Point Subpoint name		Data				
#	Type	Subpoint name	Data				
03	LAI	FREQ OUTPUT	Each host FLN application (for example, CIS or				
04	LAI	PCT OUTPUT	Insight) controls both the particular data reported for each point, and the report format.				
05	LAI	SPEED					
06	LAI	CURRENT					
07	LAI	TORQUE					
80	LAI	POWER					
09	LAI	DRIVE TEMP					
10	LAI	DRIVE KWH					
11	LAI	DRIVE MWH					
12	LAI	RUN TIME					
13	LAI	DC BUS VOLT					
14	LAI	OUTPUT VOLT					
17	LAI	MOTOR TEMP					
18	LAI	MREV COUNTER					
21	LDI	FWD.REV					
23	LDI	STOP.RUN					
25	LDI	EXT1.2 ACT					
27	LDI	DRIVE READY					
28	LDI	AT SETPOINT					
33	LDI	HANDAUTO ACT					
34	LDI	ENA.DIS ACT					
36	LDI	FLN LOC ACT					

Drive I/O

	FLN drive I/O report						
Po	Point Subpoint name		Data				
#	Type	Subpoint name	Data				
40	LDO	RO 1 COMMAND	Each host FLN application (for example, CIS or				
41	LDO	RO 2 COMMAND	Insight) controls both the particular data reported for each point, and the report format.				
42	LDO	RO 3 COMMAND	out point, and the report formati				
43	LDO	RO 4 COMMAND					
46	LAO	AO 1 COMMAND					
70	LDI	DI 1 ACTUAL					
71	LDI	DI 2 ACTUAL					
72	LDI	DI 3 ACTUAL					
73	LDI	DI 4 ACTUAL					
74	LDI	DI 5 ACTUAL					
76	LDI	RO 1 ACTUAL					
77	LDI	RO 2 ACTUAL					
78	LDI	RO 3 ACTUAL					
79	LDI	RO 4 ACTUAL					

Drive Config

	FLN drive config. report					
P	oint	Subpoint name	Data			
#	Type	Suppoint name	Data			
30	LAO	CURRENT LIM	Each host FLN application (for example, CIS or			
31	LAO ACCEL TIME 1		Insight) controls both the particular data reported for each point, and the report format.			
32	LAO	DECEL TIME 1	out point, and the report formati			
48	LDO	RST RUN TIME				
49	LDO	RESET KWH				
59	LDO	LOCK PANEL				
66	LDO	SPD OUT MIN]			
67	LDO	SPD OUT MAX				
95	LAO	MBOX PARAM				
96	LAO	MBOX DATA				
97	LDO	MBOX READ				
98	LDO	MBOX WRITE				

Process PID

	FLN process PID report						
Po	Point		Data				
#	Type	Subpoint name	Data				
15	LAI	PRC PID FBCK	Each host FLN application (for example, CIS or				
16	LAI	PRC PID DEV	Insight) controls both the particular data reported for each point, and the report format.				
50	LAO	PRC PID GAIN					
51	LAO	PRC PID ITIM					
52	LAO	PRC PID DTIM					
53	LAO	PRC PID DFIL					
54	LDO	PRC PID SEL					
60	LAO	INPUT REF1					
61	LAO	INPUT REF2					
82	LAI	AI 1 ACTUAL					
83	LAI	AI 2 ACTUAL					
84	LAI	AO 1 ACTUAL					

External PID

	FLN external PID report					
Po	oint	Subpoint name	Data			
#	Type	Suppoint name	Data			
55	LAO	EXT PID GAIN	Each host FLN application (for example, CIS or			
56	LAO	EXT PID ITIM	Insight) controls both the particular data reported for each point, and the report format.			
57	LAO	EXT PID DTIM				
58	LAO	EXT PID DFIL				
62	LAO	EXT PID STPT				
63	LAI	EXT PID FBCK				
64	LAI	EXT PID DEV				
82	LAI	AI 1 ACTUAL				
83	LAI	AI 2 ACTUAL				
84	LAI	AO 1 ACTUAL				

Scaling drive feedback values

Feedback values are provided with units of percent, where 0% and 100% correspond to the range of the sensor being used to measure the control variable. These points have default units in Hz. If other units are required:

- Unbundle these points with appropriate slopes and intercepts.
- The new intercept equals the lowest value of the desired range.

· Calculate the new slope as follows:

Example – You are controlling water temperature from a cooling tower using the ACS320 to control a fan. The temperature sensor has a range of 30 to 250 degrees Fahrenheit.

To unbundle the setpoint (INPUT REF 2), for commanding in degrees Fahrenheit, where 0...60 Hz is equal to 30...250° F:

New Intercept = 30 (the temperature that corresponds to 0%)

New Slope =
$$\frac{\text{(Desired Range) x (Slope of Existing Point)}}{\text{Range of Existing Point}}$$
$$= \frac{(250^{\circ} \text{ F} - 30^{\circ} \text{ F}) \text{ x (0.1)}}{100\% - 0\%} = 0.22$$

To unbundle the feedback (PRC PID FBCK) for monitoring in degrees Fahrenheit:

New Slope =
$$\frac{\text{(Desired Range)} \times \text{(Slope of Existing Point)}}{\text{Range of Existing Point}}$$
$$= \frac{(250^{\circ} \text{ F} - 30^{\circ} \text{ F}) \times (0.01)}{100^{\circ} \times 0^{\circ}} = 0.022$$

Loop gains

PRC PID GAIN (Point 50) and PRC PID ITIM (Point 51) are PID parameters similar to the P and I gains in the APOGEE TECs. Because the ABB PI loop and the Siemens loop are structured differently, there is no a one-to-one correspondence between the gains. The following formulas allow translation from ABB gains to Siemens gains and vice versa:

To convert from ABB PI gains to Siemens P and I gains:

P GAIN_{Siemens} = PI GAIN_{ABB} x 0.0015

I GAIN_{Siemens} =
$$\frac{\text{PI GAIN}_{ABB}}{\text{PI GAIN}_{ABB}}$$
 x 0.0015

• To convert from Siemens P and I gains to ABB PI gains:

P GAIN_{ABB} = PI GAIN_{Siemens} x 667

I GAIN_{ABB} =
$$\frac{PI \text{ GAIN}_{\text{Siemens}}}{PI \text{ GAIN}_{\text{Siemens}}} \times 667$$

Point database

The following table lists the point database for FLN / ACS320 (Application 2762).

	FLN Point Database							
Po	oint	Subpoint Name	Factory Default	Engr. Units	Slope	Intercept	On Text	Off Text
#	Type			(SI L	Jnits)			
01	LAO	CTLR ADDRESS	99	-	1	0	-	-
02	LAO	APPLICATION	2734	-	1		-	-
{03}	LAI	FREQ OUTPUT	0	Hz	0.1	0	-	-
{04}	LAI	PCT OUTPUT	0	PCT	0.1	0	-	-
{05}	LAI	SPEED	0	RPM	1	0	-	-
{06}	LAI	CURRENT	0	Α	0.1		-	-
{07}	LAI	TORQUE	0	PCT	0.1	-200	-	-
{80}	LAI	POWER	0 (0)	HP (KW)	0.134 0.1	0	-	-
{09}	LAI	DRIVE TEMP	77 (25)	°F (°C)	0.18 (0.1)	32 0	-	-
{10}	LAI	DRIVE KWH	0	KWH	1		-	-
{11}	LAI	DRIVE MWH	0	MWH	1		-	-
{12}	LAI	RUN TIME	0	HRS	1		-	-
{13}	LAI	DC BUS VOLT	0	V	1		-	-
{14}	LAI	OUTPUT VOLT	0	V	1		-	-
{15}	LAI	PRC PID FBCK	0	PCT	0.1		-	-
{16}	LAI	PRC PID DEV	0	PCT	0.1		-	-
{17}	LAI	MOTOR TEMP	77(25)	° F (° C)	1.8 (1)	32 0	-	-
{18}	LAI	MREV COUNTER	0	MREV	1	0	-	-
20	LAO	OVRD TIME	1	hrs	1	0	-	-
{21}	LDI	FWD.REV	FWD	-	1	0	REV	FWD
{22}	LDO	CMD FWD.REV	FWD	-	1	0	REV	FWD
{23}	LDI	STOP.RUN	STOP	-	1	0	RUN	STOP
{24}	LDO	CMD STP.STRT	STOP	-	1	0	RUN	STOP
{25}	LDI	EXT1.2 ACT	EXT1	-	1	0	EXT2	EXT1
{26}	LDO	EXT1.2 CMD	EXT1	-	1	0	EXT2	EXT1
{27}	LDI	DRIVE READY	NOTRDY	-	1	0	READY	NOTRDY

Point Subpoint Name Factory Default Slope Intercept On Text # Type (SI Units) (28) LDI AT SETPOINT NO - 1 0 YES {29} LDO DAY.NIGHT DAY - 1 0 NIGHT 30 LAO CURRENT LIM 0 A 0.1 0 - 31 LAO ACCEL TIME 1 300 sec 0.1 0 - 32 LAO DECEL TIME 1 300 sec 0.1 0 - 33} LDI HANDAUTO AUTO - 1 0 HAND {34} LDI ENA.DIS ACT DISABL - 1 0 ENABLE {35} LDO ENA.DIS CMD DISABL - 1 0 FLN	Off Text NO DAY AUTO
{28} LDI AT SETPOINT NO - 1 0 YES {29} LDO DAY.NIGHT DAY - 1 0 NIGHT 30 LAO CURRENT LIM 0 A 0.1 0 - 31 LAO ACCEL TIME 1 300 sec 0.1 0 - 32 LAO DECEL TIME 1 300 sec 0.1 0 - {33} LDI HANDAUTO AUTO AUTO AUTO AUTO AUTO AUTO AUTO	DAY
{29} LDO DAY.NIGHT DAY - 1 0 NIGHT 30 LAO CURRENT LIM 0 A 0.1 0 - 31 LAO ACCEL TIME 1 300 sec 0.1 0 - 32 LAO DECEL TIME 1 300 sec 0.1 0 - {33} LDI HANDAUTO AUTO AUTO AUTO AUTO AUTO ACT - 1 0 HANDAUTO ACT {34} LDI ENA.DIS ACT DISABL - 1 0 ENABLE {35} LDO ENA.DIS CMD DISABL - 1 0 ENABLE {36} LDI FLN LOC ACT AUTO - 1 0 FLN	DAY
30	-
31 LAO ACCEL TIME 1 300 sec 0.1 0 - 32 LAO DECEL TIME 1 300 sec 0.1 0 - {33} LDI HANDAUTO AUTO AUTO ACT - 1 0 HAND {34} LDI ENA.DIS ACT DISABL - 1 0 ENABLE {35} LDO ENA.DIS CMD DISABL - 1 0 ENABLE {36} LDI FLN LOC ACT AUTO - 1 0 FLN	-
32 LAO DECEL TIME 1 300 sec 0.1 0 - {33} LDI HANDAUTO ACT AUTO - 1 0 HAND {34} LDI ENA.DIS ACT DISABL - 1 0 ENABLE {35} LDO ENA.DIS CMD DISABL - 1 0 ENABLE {36} LDI FLN LOC ACT AUTO - 1 0 FLN	- - AUTO
{33} LDI HANDAUTO AUTO - 1 0 HAND ACT {34} LDI ENA.DIS ACT DISABL - 1 0 ENABLE {35} LDO ENA.DIS CMD DISABL - 1 0 ENABLE {36} LDI FLN LOC ACT AUTO - 1 0 FLN	- AUTO
ACT	AUTO
{35} LDO ENA.DIS CMD DISABL - 1 0 ENABLE {36} LDI FLN LOC ACT AUTO - 1 0 FLN	
(36) LDI FLN LOC ACT AUTO - 1 0 FLN	DISABL
	DISABL
(07) I DI OTI ODO NO	AUTO
[37] LDI CTL SRC NO - 1 0 YES	NO
[38] LDI FLN REF1 SRC NO - 1 0 YES	NO
[39] LDI FLN REF2 SRC NO - 1 0 YES	NO
[40] LDO RO 1 OFF - 1 0 ON	OFF
{41} LDO RO 2 OFF - 1 0 ON	OFF
[42] LDO RO 3 OFF - 1 0 ON	OFF
43} LDO RO 4 OFF - 1 0 ON	OFF
[46] LAO AO 1	-
48 LDO RST RUN TIME NO - 1 0 RESET	NO
49 LDO RESET KWH NO - 1 0 RESET	NO
50 LAO PRC PID GAIN 10 PCT 0.1 0 -	-
51 LAO PRC PID ITIM 600 SEC 0.1 0 -	-
52 LAO PRC PID DTIM 0 SEC 0.1 0 -	-
53 LAO PRC PID DFIL 10 SEC 0.1 0 -	-
54 LDO PRC PID SEL SET1 - 1 0 SET2	SET1
55 LAO EXT PID GAIN 10 PCT 0.1 0 -	-
56 LAO EXT PID ITIM 600 SEC 0.1 0 -	-
57 LAO EXT PID DTIM 0 SEC 0.1 0 -	-
58 LAO EXT PID DFIL 10 SEC 0.1 0 -	-
59 LDO LOCK PANEL UNLOCK - 1 0 LOCK	UNLOCK
(60) LAO INPUT REF1 0 PCT 0.1 0 -	1-
{61} LAO INPUT REF2 0 PCT 0.1 0 -	-
[62] LAO EXT PID STPT 0 PCT 0.1 0 -	1-
(63) LAI EXT PID FBCK 0 PCT 0.1 0 -	1-
{64} LAI EXT PID DEV 0 PCT 0.1 0 -	1-

	FLN Point Database							
Po	oint	Subpoint Name	Factory Default	Engr. Units	Slope	Intercept	On Text	Off Text
#	Type			(SI U	Jnits)			
66	LDO	SPD OUT MIN	0	PCT	0.1	0	-	-
67	LDO	SPD OUT MAX	1000	PCT	0.1	0	-	-
{68}	LDO	FLN LOC CTL	AUTO	-	1	0	FLN	AUTO
{69}	LDO	FLN LOC REF	AUTO	-	1	0	FLN	AUTO
{70}	LDI	DI 1 ACTUAL	OFF	-	1	0	ON	OFF
{71}	LDI	DI 2 ACTUAL	OFF	-	1	0	ON	OFF
{72}	LDI	DI 3 ACTUAL	OFF	-	1	0	ON	OFF
{73}	LDI	DI 4 ACTUAL	OFF	-	1	0	ON	OFF
{74}	LDI	DI 5 ACTUAL	OFF	-	1	0	ON	OFF
{76}	LDI	RO 1 ACTUAL	OFF	-	1	0	ON	OFF
{77}	LDI	RO 2 ACTUAL	OFF	-	1	0	ON	OFF
{78}	LDI	RO 3 ACTUAL	OFF	-	1	0	ON	OFF
{79}	LDI	RO 4 ACTUAL	OFF	-	1	0	ON	OFF
{82}	LAI	AI 1 ACTUAL	0	PCT	0.1	0	-	-
{83}	LAI	AI 2 ACTUAL	0	PCT	0.1	0	_	-
{84}	LAI	AO 1 ACTUAL	0	MA	0.1	0	_	-
{86}	LDI	OK.ALARM	OK	-	1	0	ALARM	OK
{87}	LDI	OK.MAINT	OK	-	1	0	MAINT	OK
{88}	LAI	ALARM WORD 1	-	-	1	0	-	-
{89}	LAI	ALARM WORD 2	-	-	1	0	-	-
{90}	LAI	LAST FAULT	-	-	1	0	-	-
{91}	LAI	PREV FAULT 1	-	-	1	0	-	-
{92}	LAI	PREV FAULT 2	-	-	1	0	-	-
{93}	LDI	OK.FAULT	OK	-	1	0	FAULT	OK
{94}	LDO	RESET FAULT	NO	-	1	0	RESET	NO
{95}	LAO	MBOX PARAM	-	-	1	0	-	-
{96}	LAO	MBOX DATA	-	-	1	0	-	-
{97}	LDO	MBOX READ	DONE	-	1	0	READ	DONE
{98}	LDO	MBOX WRITE	DONE	-	1	0	WRITE	DONE
{99}	LAO	ERROR STATUS	-	-	1	0	-	-

a.Points not listed are not used in this application.

b.A single value in a column means that the value is the same in English units and in SI units.

c.Point numbers that appear in brackets { } may be unbundled at the field panel.

Detailed point descriptions

		FLN Detailed Point Descriptions	
	Point	Description	Drive Parameter
1	CTRL ADDRESS	The FLN address of the drive. It can be set by FLN and by the panel.	5302
2	APPLICATION	The Application ID for FLN on the ACS320. This ID is assigned by Siemens for each unique application. It correlates directly to a particular point list approved at the time of release. Therefore, this point list shall remain fixed once approval is granted. Any changes to the point list shall require a new Application ID and re-approval by Siemens. The Application ID assigned to ACS320 is 2934.	
3	FREQ OUTPUT	The output frequency applied to the motor, in Hertz.	0103
4	PCT OUTPUT	The ratio of output frequency or speed to the corresponding maximum rating, depending on control mode. For scalar mode, it is the ratio of Output Frequency (parameter 0103) to Maximum Frequency (parameter 2008). For speed mode, it is the ratio Speed (parameter 0102) to Maximum Speed (2002).	None. This ratio is calculated by the FLN application.
5	SPEED	The calculated speed of the motor, in RPM.	0102
6	CURRENT	The measured output current.	0104
7	TORQUE	The calculated output torque of the motor as a percentage of nominal torque.	0105
8	POWER	The measured output power in KW. The FLN point definition also supports horsepower by selecting English units.	0106
	DRIVE TEMP	The measured heatsink temperature, in ° C. The FLN point definition also supports ° F by selecting English units.	0110
10	DRIVE KWH	The drive's cumulative power consumption in kilowatt-hours. This value may be reset by commanding FLN point 49, RESET KWH.	0115
11	DRIVE MWH	The drive's cumulative power consumption in megawatt hours. This value cannot be reset.	0141
12	RUN TIME	The drive's cumulative run time in hours. This value may be reset by commanding FLN point 48, RESET RUN TIME.	0114
13	DC BUS VOLT	The DC bus voltage level of the drive.	0107
14	OUTPUT VOLT	The AC output voltage applied to the motor.	0109
15	PRC PID FBCK	The Process PID feedback signal.	0130
16	PRC PID DEV	The deviation of the Process PID output signal from its setpoint.	0132
17	MOTOR TEMP	The measured motor temperature as set up in Group 35.	0145
18	ROTATION CNT	The motor's cumulative revolution count, in megarevolutions.	0142
19	N/A		

	FLN Detailed Point Descriptions				
	Point	Description	Drive Parameter		
20	OVRD TIME	1 of the 5 mandatory FLN points required for compatibility with Siemens control systems. It has no functionality in the drive application.	None		
21	FWD.REV ACT	Indicates the rotational direction of the motor, regardless of control source (1 = REV, 0 = FWD).			
22	FWD.REV CMD	Commanded by FLN to change the rotational direction of the drive. Parameter 1001 must be set to COMM for FLN to control the direction of the motor by EXT1. Parameter 1002 must be set to COMM for FLN to control the direction of the motor by EXT2.			
23	RUN.STOP ACT	Indicates the drive's run status, regardless of control source (1 = RUN, 0 = STOP).			
24	RUN.STOP CMD	Commanded by FLN to start the drive. Parameter 1001 must be set to COMM for FLN to control the run state of the drive by EXT1. Parameter 1002 must be set to COMM for FLN to have this control.			
25	EXT1.2 ACT	Indicates whether External 1 or External 2 is the active control source (1 = EXT2, 0 = EXT1).			
26	EXT1.2 CMD	Commanded by FLN to select External 1 or External 2 as the active control source (1 = EXT2, 0 = EXT1). Parameter 1102 must be set to COMM for FLN to have this control.			
27	DRIVE READY	Indicates the drive is ready to accept a run command (1 = READY, 0 = NOTRDY).			
28	AT SETPOINT	Indicates the drive has reached its commanded setpoint (1 = YES, 0 = NO)			
29	DAY.NIGHT	1 of the 5 mandatory FLN points required for compatibility with Siemens control systems. It has no functionality in the drive application.	None		
30	CURRENT LIM	Sets the output current limit of the drive.	2003		
31	ACCEL TIME 1	Sets the acceleration time for Ramp 1.	2202		
32	DECEL TIME 1	Sets the deceleration time for Ramp 1.	2203		
33	HANDAUTO ACT	Indicates whether the drive is in Hand or Auto control (1 = HAND, 0 = AUTO).			
34	ENA.DIS ACT	Indicates the status of the Run Enable command, regardless of its source (1 = ENABLE, 0 = DISABL).			
35	ENA.DIS CMD	Commanded by FLN to assert the Run Enable command (1 = ENABLE, 0 = DISABL). Parameter 1601 must be set to COMM for FLN to have this control.			
36	FLN LOC ACT	Indicates if the drive has been placed in "FLN LOCAL" mode by commanding either point 68 (FLN LOC CTL) or point 69 (FLN LOC REF). Commanding either of these points to FLN (1) "steals" control from its normal source and places in under FLN control. Note that the HAND mode of the panel has priority over FLN local control.			

	FLN Detailed Point Descriptions				
	Point	Description	Drive Parameter		
37	FLN CTL SRC	Indicates if FLN is a source for control inputs (1 = YES, 0 = NO). Note that this status point is true if any of the following control inputs are from FLN: Run/Stop, Ext1/2 Select or Run Enable.			
38	FLN REF1 SRC	Indicates if FLN is the source for speed reference 1 (1 = YES, 0 = NO).			
39	FLN REF2 SRC	Indicates if FLN is the source for speed reference 2 (1 = YES, 0 = NO).			
40	RO1 COMMAND	Controls the output state of Relay 1. Parameter 1401 must be set to COMM for FLN to have this control (1 = ON, 0 = OFF).	0134, bit 0		
41	RO2 COMMAND	Controls the output state of Relay 2. Access to relay 2 requires ACS320 option MREL. Parameter 1402 must be set to COMM for FLN to have this control (1 = ON, 0 = OFF).	0134, bit 1		
42	RO3 COMMAND	Controls the output state of Relay 3. Access to relay 3 requires ACS320 option MREL. Parameter 1403 must be set to COMM for FLN to have this control (1 = ON, 0 = OFF).	0134, bit 2		
43	RO4 COMMAND	Controls the output state of Relay 4. Access to relay 4 require ACS320 option MREL. Parameter 1410 must be set to COMM for FLN to have this control (1 = ON, 0 = OFF).	0134, bit 3		
46	AO1 COMMAND	Controls Analog Output 1. Parameter 1501 must be set to this value for FLN to have this control.	0135 (COMM VALUE 1)		
48	RESET RUN TIME	Commanded by FLN to reset the cumulative run timer (1 = RESET, 0 = NO). The control input is rising-edge sensitive, so, once the command is issued, this point automatically returns to its inactive state. This "momentary" operation avoids any need for an explicit command to clear the point before a subsequent reset can be issued.			
49	RESET KWH	Commanded by FLN to reset the cumulative kilowatt-hour counter (1 = RESET, 0 = NO). The control input is rising-edge sensitive, so, once the command is issued, this point automatically returns to its inactive state. This "momentary" operation avoids any need for an explicit command to clear the point before a subsequent reset can be issued.			
50	PRC PID GAIN	Sets the proportional gain of the active Process PID set, as selected by Point 54, PRC PID SEL (1 = SET2, 0 = SET1).	4001 (SET1) 4101 (SET2)		
51	PRC PID ITIM	Sets the integration time of the active Process PID set, as selected by Point 54, PRC PID SEL (1 = SET2, 0 = SET1).	4002 (SET1) 4102 (SET2)		
52	PRC PID DTIM	Sets the derivation time of the active Process PID set, as selected by Point 54, PRC PID SEL (1 = SET2, 0 = SET1).	4001 (SET1) 4101 (SET2)		

	FLN Detailed Point Descriptions				
	Point	Description	Drive Parameter		
53	PRC PID DFIL	Sets the time constant for the error-derivative of the active Process PID set, as selected by Point 54, PRC PID SEL (1 = SET2, 0 = SET1).	4004 (SET1) 4104 (SET2)		
54	PRC PID SEL	Selects the active Process PID set (1 = SET2, 0 = SET1).	4027		
55	EXT PID GAIN	Sets the proportional gain of the External PID controller.	4201		
56	EXT PID ITIM	Sets the integration time of the External PID controller.	4202		
57	EXT PID DTIM	Sets the derivation time of the External PID controller.	4203		
58	EXT PID DFIL	Sets the time constant for the error-derivative of the External PID controller.	4204		
59	LOCK PANEL	Command by FLN to lock the panel and prevent parameter changes (1 = LOCK, 0 = UNLOCK).	1602		
60	INPUT REF 1	Sets Input Reference 1. Parameter 1102 must be set to COMM for FLN to control this value.			
61	INPUT REF 2	Sets Input Reference 2. Parameter 1106 must be set to COMM for FLN to control this value.			
62	EXT PID STPT	The setpoint for the External PID controller. The function of this point requires parameter 4210, PID Setpoint Select, to be set to 19 (Internal).	4211		
63	EXT PID FBCK	The External PID feedback signal.	0131		
64	EXT PID DEV	The deviation of the External PID output signal from its setpoint.	0133		
65	N/A				
66	SPD OUT MIN	Sets the minimum output speed of the drive as a percentage of the motor nominal rating.	2007 (SCALAR) 2001 (SPEED)		
67	SPD OUT MAX	Sets the maximum output speed of the drive as a percentage of the motor nominal rating.	2008 (SCALAR) 2002 (SPEED)		
68	FLN LOC CTL	Commanded by FLN to temporarily "steal" start/stop control of the drive from its normal source and place it under FLN control. This functionality is analogous to placing the drive in HAND mode at the panel, with the control being taken by FLN instead. HAND mode at the panel has priority over this point. Thus, this point is only effective in temporarily taking control from the digital inputs or some other internal control functionality.			
69 70	FLN LOC REF	Commanded by FLN to temporarily "steal" input reference control of the drive from its normal source and place it under FLN control. This functionality is analogous to placing the drive in HAND mode at the panel, with the reference control being taken by FLN instead. HAND mode at the panel has priority over this point. Thus, this point is only effective in temporarily taking control from the analog inputs or some other internal control functionality. Indicates the status of Digital Input 1 (1 = ON, 0 = OFF).	0118, bit 2		
70	DITACIDAL	Indicates the status of Digital Hiput 1 (1 - ON, 0 = OFF).	0 1 10, DIL Z		

	FLN Detailed Point Descriptions					
	Point	Description	Drive Parameter			
71	DI 2 ACTUAL	Indicates the status of Digital Input 2 (1 = ON, 0 = OFF).	0118, bit 1			
72	DI 3 ACTUAL	Indicates the status of Digital Input 3 (1 = ON, 0 = OFF).	0118, bit 0			
73	DI 4 ACTUAL	Indicates the status of Digital Input 4 (1 = ON, 0 = OFF).	0119, bit 2			
74	DI 5 ACTUAL	Indicates the status of Digital Input 5 (1 = ON, 0 = OFF).	0119, bit 1			
76	RO 1 ACTUAL	Indicates the status of Relay Output 1 (1 = ON, 0 = OFF).	0122, bit 2			
77	RO 2 ACTUAL	Indicates the status of Relay Output 2 (1 = ON, 0 = OFF).	0122, bit 1			
78	RO 3 ACTUAL	Indicates the status of Relay Output 3 (1 = ON , 0 = OFF).	0122, bit 0			
79	RO 4 ACTUAL	Indicates the status of Relay Output 4 (1 = ON, 0 = OFF).	0123, bit 2			
82	AI 1 ACTUAL	Indicates the input level of Analog Input 1.	0120			
83	AI 2 ACTUAL	Indicates the input level of Analog Input 2.	0121			
84	AO 1 ACTUAL	Indicates the output level of Analog Output 1.	0124			
86	OK.ALARM	Indicates the current alarm state of the drive (1 = ALARM, 0 = OK).				
87	OK.MAINT	Indicates the current maintenance state of the drive (1 = MAINT, 0 = OK).				
		Maintenance triggers are configured in drive parameter Group 29.				
88	ALARM WORD1	This point is a bit-field indicating active alarms in the drive.	0308			
89	ALARM WORD2	This point is a bit-field indicating active alarms in the drive.	0309			
90	LAST FAULT	This point is first in the drive's fault log and indicates the most recent fault declared.	0401			
91	PREV FAULT 1	This point is second in the drive's fault log and indicates the previous fault declared.	0412			
92	PREV FAULT 2	This point is last in the drive's fault log and indicates the oldest fault in the log.	0413			
93	OK.FAULT	Indicates the current fault state of the drive (1 = FAULT, 0 = OK).				
94	RESET FAULT	Command by FLN to reset a faulted drive (1 = RESET, 0 = NO).				
		Parameter 1604 must be set to COMM for FLN to control this state.				
		The control input is rising-edge sensitive, so, once the command is issued, this point automatically returns to its inactive state. This "momentary" operation avoids any need for an explicit command to clear the point before a subsequent reset can be issued.				
95	MBOX PARAM	Sets the parameter to be used by the mailbox function.				
96	MBOX DATA	Sets or indicates the data value of the mailbox function.				
97	MBOX READ	Command by FLN to read the parameter value specified by Point 95, MBOX PARAM. The parameter value is returned in Point 96, MBOX DATA.				
		The control input is rising-edge sensitive, so, once the command is issued, this point automatically returns to its inactive state. This "momentary" operation avoids any need for an explicit command to clear the point before a subsequent reset can be issued.				

	FLN Detailed Point Descriptions				
	Point	Description	Drive Parameter		
98	MBOX WRITE	Command by FLN to write the data value specified by Point 96, MBOX DATA, to the parameter value specified by Point 95, MBOX PARAM.			
		The control input is rising-edge sensitive, so, once the command is issued, this point automatically returns to its inactive state. This "momentary" operation avoids any need for an explicit command to clear the point before a subsequent reset can be issued.			
99	ERROR STATUS	1 of the 5 mandatory FLN points required for compatibility with Siemens control systems. It has no functionality in the drive application.	None		

BACnet protocol technical data

Binary input object instance summary

The following table summarizes the Binary input objects supported:

Instance ID	Object Name	Description	Active/Inactiv e Text	Present Value Access Type
BI0	RO 1 ACT	This object indicates the status of Relay Output 1.	ON/OFF	R
BI1	RO 2 ACT	This object indicates the status of Relay Output 2 (requires MREL-01 option).	ON/OFF	R
BI2	RO 3 ACT	This object indicates the status of Relay Output 3 (requires MREL-01 option).	ON/OFF	R
BI3	RO 4 ACT	This object indicates the status of Relay Output 4 (requires MREL-01 option).	ON/OFF	R
BI6	DI 1 ACT	This object indicates the status of Digital Input 1.	ON/OFF	R
BI7	DI 2 ACT	This object indicates the status of Digital Input 2.	ON/OFF	R
BI8	DI 3 ACT	This object indicates the status of Digital Input 3.	ON/OFF	R
BI9	DI 4 ACT	This object indicates the status of Digital Input 4.	ON/OFF	R
BI10	DI 5 ACT	This object indicates the status of Digital Input 5.	ON/OFF	R

Note: For Present Value Access Types, R = Read-only, W = Writeable, C = Commandable. Commandable values support priority arrays & relinquish defaults.

Binary output object instance summary

The following table summarizes the Binary output objects supported:

Instance ID	Object Name	Description	Active/Inactive Text	Present Value Access Type
BO0	RO1 COMMAND	This object controls the output state of Relay 1. This control requires that parameter 1401 value = COMM.	ON/OFF	С
BO1	RO2 COMMAND	This object controls the output state of Relay 2. This control requires that parameter 1402 value = COMM (also requires MREL-01 option).	ON/OFF	С
BO2	RO3 COMMAND	This object controls the output state of Relay 3. This control requires that parameter 1403 value = COMM (also requires MREL-01 option).	ON/OFF	С
BO3	RO4 COMMAND	This object controls the output state of Relay 4. This control requires that parameter 1410 value = COMM (also requires MREL-01 option).	ON/OFF	С

Note: For Present Value Access Types, R = Read-only, W = Writeable, C = Commandable. Commandable values support priority arrays & relinquish defaults.

Binary value object instance summary

The following table summarizes the Binary value objects supported:

Instance ID	Object Name	Description	Active/Inactive Text	Present Value Access Type
BV0	RUN/STOP ACT	This object indicates the drive Run Status, regardless of the control source.	RUN/STOP	R
BV1	FWD/REV ACT	This object indicates the motor's rotation direction, regardless of the control source.	REV/FWD	R
BV2	FAULT ACT	this object indicates the drive's fault status.	FAULT/OK	R
BV3	EXT 1/2 ACT	This object indicates which control source is active: External 1 or External 2.	EXT2/EXT1	R
BV4	HAND/AUTO ACT	This object indicates whether the drive is under Hand or Auto control.	HAND/AUTO	R
BV5	ALARM ACT	This object indicates the drive's alarm status.	ALARM/OK	R
BV6	MAINT REQ	This object indicates the drive's maintenance status. Refer to <i>Group 29:</i> Maintenance trig.	MAINT/OK	R

Instance ID	Object Name	Description	Active/Inactive Text	Present Value Access Type
BV7	DRIVE READY	This object indicates whether the drive is ready to accept a run command.	READY/NOT READY	R
BV8	AT SETPOINT	This object indicates whether the drive is at the commanded setpoint.	YES/NO	R
BV9	RUN ENA ACT	This object indicates the Run Enable command status, regardless of the control source.	ENABLE/DISABLE	R
BV10	RUN/STOP CMD	This object commands a drive start. Control requires either: Parameter 1001 value = COMM for control by EXT1 or Parameter 1002 value = COMM for control by EXT2.	RUN/STOP	С
BV11	FWD/REV CMD	This object commands a motor rotation direction change. Control requires 1003 = REQUEST and either: Parameter 1001 value = COMM for control by EXT1 or Parameter 1002 value = COMM for control by EXT2.	REV/FWD	С
BV12	RUN ENA CMD	This object commands Run Enable. Control requires parameter 1601 value = COMM.	ENABLE/DISABLE	С
BV13	EXT 1/2 CMD	This object selects ext1 or ext2 as the active control source. Control requires parameter 1102 value = COMM.	EXT2/EXT1	С
BV14	FAULT RESET	This object resets a faulted drive. The command is rising-edge triggered. Control requires parameter 1604 value = COMM.	RESET/NO	С
BV15	MBOX READ	This object reads a parameter (defined by AV25 MBOX PARAM) and returns it in AV26 MBOX DATA.	READ/RESET	W
BV16	MBOX WRITE	This object writes the data value specified by AV26, MBOX DATA, to a parameter (defined by AV25, MBOX PARAM).	WRITE/RESET	W

Instance ID	Object Name	Description	Active/Inactive Text	Present Value Access Type
BV17	LOCK PANEL	This object locks the panel and prevents parameter changes. The corresponding drive parameter is 1602.	LOCK/UNLOCK	W
BV18	CTL OVERRIDE CMD	This object commands the drive into BACnet Control Override. In this mode, BACnet takes drive control from the normal source. However, the control panel's HAND mode has priority over BACnet Control Override.	ON/OFF	С
BV19	CTL OVERRIDE ACT	This object indicates whether the drive is in BACnet Control Override. (See BV18.)	ON/OFF	R
BV20	START ENABLE 1	This object commands start enable1. Control requires par. <i>1608</i> value = COMM.	ENABLE/DISABLE	С
BV21	START ENABLE 2	This object commands start enable1. Control requires par. 1609 value = COMM.	ENABLE/DISABLE	С

Note: For Present Value Access Types, R = Read-only, W = Writeable, C = Commandable. Commandable values support priority arrays & relinquish defaults.

Analog input object instance summary

The following table summarizes the Analog input objects supported:

Instance ID	Object Name	Description	Units	Present Value Access Type
AI0	ANALOG INPUT 1	This object indicates the value of Analog Input 1. The corresponding drive parameter is <i>0120</i> .	Percent	R
Al1	ANALOG INPUT 2	This object indicates the value of Analog Input 2. The corresponding drive parameter is <i>0121</i> .	Percent	R

Note: For Present Value Access Types, R = Read-only, W = Writeable, C = Commandable. Commandable values support priority arrays & relinquish defaults.

Analog output object instance summary

The following table summarizes the Analog output objects supported:

Instance ID	Object Name	Description	Units	Present Value Access Type
AO0		This object controls Analog Output 1. The corresponding drive parameter is 0135 COMM VALUE 1. Control requires parameter 1501 value = 135.	Percent	С

Note: For Present Value Access Types, R = Read-only, W = Writeable, C = Commandable. Commandable values support priority arrays & relinquish defaults.

Analog value object instance summary

The following table summarizes the Analog value objects supported:

Instance ID	Object Name	Description	Units	Present Value Access Type
AV0	OUTPUT SPEED	This object indicates the calculated motor speed in RPM. The corresponding drive parameter is <i>0102</i> .	RPM	R
AV1	OUTPUT FREQ	This object indicates the output frequency applied to the motor in Hz. The corresponding drive parameter is 0103.	Hertz	R
AV2	DC BUS VOLT	This object indicates the drive's DC bus voltage level. The corresponding drive parameter is <i>0107</i> .	Volts	R
AV3	OUTPUT VOLT	This object indicates the AC output voltage applied to the motor. The corresponding drive parameter is <i>0109</i> .	Volts	R
AV4	CURRENT	This object indicates the measured output current. The corresponding drive parameter is <i>0104</i> .	Amps	R
AV5	TORQUE	This object indicates the calculated motor output torque as a percentage of nominal torque. The corresponding drive parameter is <i>0105</i> .	Percent	R
AV6	POWER	This object indicates the measured output power in kW. The corresponding drive parameter is <i>0106</i> .	Kilowatts	R
AV7	DRIVE TEMP	This object indicates the measured heatsink temperature in °C. The corresponding drive parameter is <i>0110</i> .	°C	R
AV8	KWH (R)	This object indicates, in kW hours, the drive's accumulated energy usage since the last reset. The value can be reset to zero. The corresponding drive parameter is <i>0115</i> .	kWh	W
AV9	KWH (NR)	This object indicates the drive's accumulated energy usage in kW hours. The value cannot be reset.	kWh	R

Instance ID	Object Name	Description	Units	Present Value Access Type
AV10	PRC PID FBCK	This object is the Process PID feedback signal. The corresponding drive parameter is <i>0130</i> .	Percent	R
AV11	PRC PID DEV	This object is the Process PID output signal's deviation from its setpoint. The corresponding drive parameter is <i>0132</i> .		R
AV12	EXT PID FBCK	This object is the External PID feedback signal. The corresponding drive parameter is <i>0131</i> .	Percent	R
AV13	EXT PID DEV	This object is the External PID output signal's deviation from its setpoint. The corresponding drive parameter is <i>0133</i> .	Percent	R
AV14	RUN TIME (R)	This object indicates, in hours, the drive's accumulated run time since the last reset. The value can be reset to zero. The corresponding drive parameter is 0114.	Hours	W
AV15	MOTOR TEMP	This object indicates the drive's motor temperature, as set up in <i>Group 35: Motor temp meas.</i> The corresponding drive parameter is <i>0145</i> .	°C	R
AV16	INPUT REF 1	This object sets Input Reference 1. Control requires parameter 1103 value = COMM.		С
AV17	INPUT REF 2	This object sets either: Input Reference 2. Control requires parameter 1106 value = COMM. Process PID setpoint. Control requires parameter 1106 value = PID1 OUT and parameter 4010 value = COMM.	Percent	С
AV18	LAST FLT	This object indicates the most recent fault entered in the drive's fault log. The corresponding drive parameter is 0401.	None	R
AV19	PREV FLT 1	This object indicates the second most recent fault entered in the drive's fault log. The corresponding drive parameter is 0412.		R
AV20	PREV FLT 2	This object indicates the third most recent fault entered in the drive's fault log. The corresponding drive parameter is <i>0413</i> .		R
AV21	AO 1 ACT	This object indicates Analog Output 1's level. The corresponding drive parameter is <i>0124</i> .		R
AV23	ACCEL1 TIME	·		W
AV24	DECEL1 TIME	This object sets the Ramp1 deceleration time. The corresponding drive parameter is 2203.		W
AV25	MBOX PARAM	This object defines the parameter to be read or written to by the mailbox function. See BV15 and BV16.	None	W

Instance ID	Object Name	Description	Units	Present Value Access Type
AV26	MBOX DATA	This object holds the mailbox function's parameter value – a value that was read, or is to be written. See BV15 and BV16.	None	W
AV27	EXT PID STPT	This object sets the External PID controller setpoint. The corresponding drive parameter is 4211. Control requires parameter 4210,value = 19 (.	Percent	С

Note: For Present Value Access Types, R = Read-only, W = Writeable, C = Commandable. Commandable values support priority arrays & relinquish defaults.

BACnet guick-start seguence

The following steps summarize the process for enabling and configuring BACnet on the ACS320:

1. Enable BACnet protocol: Set drive parameter 9802 COMM PROT SEL = BACNET (5).

Note: If you cannot see the desired selection on the panel, your drive does not have that protocol software in the application memory.

- To confirm this selection, read drive parameter 5301 EFB PROTOCOL ID. It should read x5xx (where "x" is any value).
- 2. Place the BACnet channel in "reset": Set drive parameter 5302 EFB STATION ID = 0
 - This setting holds the BACnet communication channel in reset while remaining settings are completed.
- 3. Define the MS/TP baud rate.
 - Set drive parameter 5303 EFB BAUD RATE = appropriate value.
- 4. Define the Device Object Instance ID.
 - To define a specific device object instance value, use drive parameters 5311 and 5317 (object instance values must be unique and in the range 1 to 4.194.303).
 - To use the drive's MS/TP MAC ID as the device object instance value, set drive parameter 5311 and 5317 = 0.
- 5. Define a unique MS/TP MAC ID. Set drive parameter 5302 EFB STATION ID = appropriate value.
 - Once this parameter is set to a non-zero value, current BACnet settings are "latched" and used for communication until the channel is reset.
 - In order to participate in MS/TP token passing, the MAC ID used must be within the limits defined by other masters' "Max Master" property.

- 6. Confirm proper BACnet communication.
 - When BACnet communication is operating properly, drive parameter 5316 EFB PAR 16 (the MS/TP token counter), should be continually increasing.
 - Drive parameter 5306 EFB UART ERRORS, should be stable.

Protocol implementation conformance statement (PICS)

PICS summary

BACnet Standard Device Profile. This version of ACS320 BACnet fully conforms to the 'Application-Specific Controller' standard device profile (B-ASC).

Services Supported. The following services are supported by the ACS320:

- I-Am (Response to Who-Is, also broadcast on power-up & other reset)
- I-Have (Response to Who-Has)
- ReadProperty
- WriteProperty
- DeviceCommunicationControl
- ReinitializeDevice.

Data Link Layer. The ACS320 implements MS/TP (Master) Data Link Layer. All standard MS/TP baud rates are supported (9600, 19200, 38400 & 76800).

MAC ID / Device Object Instance. The ACS320 supports separate MAC ID and Device Object Instance parameters:

- Set the MAC ID using drive parameter 5302 EFB STATION ID. Default: 5302 = 1.
- Set the Device Object Instance ID using drive parameters 5311 and 5317.
 Default: Both 5311 and 5317 = 0, which causes the MAC ID to "double" as the Device Object Instance. For Device Object Instance values not linked to the MAC ID, set ID values using 5311 and 5317:
 - For IDs in the range 1 to 65,535: Parameter 5311sets the ID directly (5317 must be 0). For example, the following values set the ID to 49,134: 5311 = 49134 and 5317 = 0.
 - For IDs > 65,335: The ID equals 5311's value plus 10,000 times 5317's value.
 For example, the following values set the ID to 71,234:
 5311 = 1234 and 5317 = 7.

Max Info Frames Property. Configure the Device Object Max Info Frames property using drive parameter 5312. Default: 5312 = 1.

Max Master Property. Configure the Device Object Max Master property using drive parameter 5313. Default: 5313 = 127.

MS/TP Token Counter

Parameter 5316 stores the count of MS/TP tokens passed to the associated node.

Statement

This statement is part of this Standard and is required for its use.

BACnet Protocol Implementation Conformance Statement					
Date:	February 2013				
Vendor Name:	ABB, Inc				
Product Name:	Low Voltage AC Motor Drive				
Product Model Number:	ACS320				
Applications Software Version:	403C				
Firmware Revision:	0526				
BACnet Protocol Revision:	7				
Product Description:	The ACS320 is a high-performance adjustable frequency drive specifically designed for commercial automation applications. This product supports native BACnet, connecting directly to the MS/TP LAN. All standard MS/TP baud rates are supported, as well as master mode functionality. Over BACnet, the drive can be fully controlled as a standard adjustable frequency drive. In addition, up to 16 configurable I/O ports are available over BACnet for user applications.				
BACnet Standardized Device Profile (Annex L):	□ BACnet Operator Workstation (B-OWS) □ BACnet Building Controller (B-BC) □ BACnet Advanced Application Controller (B-AAC) ☑ BACnet Application Specific Controller (B-ASC) □ BACnet Smart Sensor (B-SS) □ BACnet Smart Actuator (B-SA)				
List all BACnet Interoperability Building Blocks Supported (Annex K):	DS-RP-B, DS-WP-B, DM-DDB-B, DM-DOB-B, DM-DCC-B, DM-RD-B.				
Segmentation Capability:	☐ Segmented requests supported. Window Size ☐ Segmented responses supported. Window Size				

BACnet Protocol In	BACnet Protocol Implementation Conformance Statement					
Standard Object Types Supported: An object type is supported if it may be present in the device. For each standard Object Type supported provide the following data: 1. Whether objects of this type are dynamically creatable using the CreateObject service 2. Whether objects of this type are dynamically detectable using the DeleteObject service 3. List of the optional properties supported 4. List of all properties that are writable where not otherwise required by this standard 5. List of proprietary properties and for each its property identifier, datatype, and meaning 6. List of any property range restrictions	See table at Object/Property support matrix on page 317.					
Data Link Layer Options:	□ BACnet IP, (Annex J) □ BACnet IP, (Annex J), Foreign Device □ ISO 8802-3, Ethernet (Clause 7) □ ANSI/ATA 878.1, 2.5 Mb. ARCNET (Clause 8) □ ANSI/ATA 878.1, EIA-485 ARCNET (Clause 8), baud rate(s) ⊠ MS/TP master (Clause 9), baud rate(s): 9600, 19200, 38400, 76800 □ MS/TP slave (Clause 9), baud rate(s): □ Point-To-Point, EIA 232 (Clause 10), baud rate(s): □ Point-To-Point, modem, (Clause 10), baud rate(s): □ LonTalk, (Clause 11), medium: □ Other:					
Device Address Binding: Is static device binding supported? (This is currently necessary for two-way communication with MS/TP slaves and certain other devices.)	☐ Yes ☑ No					
Networking Options:	□ Router, Clause 6 - List all routing configurations, eg, ARCNET-Ethernet, Ethernet-MS/TP, etc. □ Annex H, BACnet Tunneling Router over IP □ BACnet/IP Broadcast Management Device (BBMD)					
Does the BBMD support registrations by Foreign Devices?	☐ Yes ☐ No					

BACnet Protocol Implementation Conformance Statement					
Character Sets Supported: Indicating support for multiple character sets does not imply that they can all be supported simultaneously.	□ ANSI X3.4 □ IBM™/Microsoft™ DBCS □ ISO 8859-1 □ ISO 10646 (UCS-2) □ ISO 10646 (UCS-4) □ JIS C 6226				
If this product is a communication gateway, describe the types of non-BACnet equipment/network(s) that the gateway supports:					

BACnet object definitions

Object/Property support matrix

The following table summarizes the object types/properties supported:

	Object Type						
Property	Device	Binary Input	Binary Output	Binary Value	Analog Input	Analog Output	Analog Value
Object Identifier	✓	✓	✓	✓	✓	✓	✓
Object Name	✓	✓	✓	✓	✓	✓	✓
Object Type	✓	✓	✓	✓	✓	✓	✓
System Status	✓						
Vendor Name	✓						
Vendor Identifier	✓						
Model Name	✓						
Firmware Revision	✓						
Appl Software Revision	✓						
Protocol Version	✓						
Protocol Revision	✓						
Services Supported	✓						
Object Types Supported	✓						
Object List	✓						
Max APDU Length	✓						
Segmentation Support	✓						
APDU Timeout	✓						
Number APDU Retries	✓						
Max Master	✓						
Max Info Frames	✓						
Device Address Binding	✓						
Database Revision	✓						
Present Value		✓	✓	✓	✓	✓	✓

	Object Type							
Property	Device	Binary Input	Binary Output	Binary Value	Analog Input	Analog Output	Analog Value	
Status Flags		✓	✓	✓	✓	✓	✓	
Event State		✓	✓	✓	✓	✓	✓	
Out-of-Service		✓	✓	✓	✓	✓	✓	
Units					✓	✓	✓	
Priority Array			✓	√ *		✓	√ *	
Relinquish Default			✓	√ *		✓	√ *	
Polarity		✓	✓					
Active Text		✓	✓	✓				
Inactive Text		✓	✓	✓				

^{*} For commandable values only.

Modbus protocol technical data

Overview

The Modbus® protocol was introduced by Modicon, Inc. for use in control environments featuring Modicon programmable controllers. Due to its ease of use and implementation, this common PLC language was quickly adopted as a de-facto standard for integration of a wide variety of master controllers and slave devices.

Modbus is a serial, asynchronous protocol. Transactions are half-duplex, featuring a single Master controlling one or more Slaves. While RS232 can be used for point-topoint communication between a single Master and a single Slave, a more common implementation features a multi-drop RS485 network with a single Master controlling multiple Slaves. The ACS320 features RS485 for its Modbus physical interface.

RTU

The Modbus specification defines two distinct transmission modes: ASCII and RTU. The ACS320 supports RTU only.

Feature summary

The following Modbus function codes are supported by the ACS320.

Function	Code (Hex)	Description
Read Coil Status	0x01	Read discrete output status. For the ACS320, the individual bits of the control word are mapped to Coils 116. Relay outputs are mapped sequentially beginning with Coil 33 (eg, RO1=Coil 33).
Read Discrete Input Status	0x02	Read discrete inputs status. For the ACS320, the individual bits of the status word are mapped to Inputs 116 or 132, depending on the active profile. Terminal inputs are mapped sequentially beginning with Input 33 (eg, DI1=Input 33).

Function	Code (Hex)	Description
Read Multiple Holding Registers	0x03	Read multiple holding registers. For the ACS320, the entire parameter set is mapped as holding registers, as well as command, status and reference values.
Read Multiple Input Registers	0x04	Read multiple input registers. For the ACS320, the 2 analog input channels are mapped as input registers 1 & 2.
Force Single Coil	0x05	Write a single discrete output. For the ACS320, the individual bits of the control word are mapped to Coils 116. Relay outputs are mapped sequentially beginning with Coil 33 (eg, RO1=Coil 33).
Write Single Holding Register	0x06	Write single holding register. For the ACS320, the entire parameter set is mapped as holding registers, as well as command, status and reference values.
Diagnostics	0x08	Perform Modbus diagnostics. Subcodes for Query (0x00), Restart (0x01) & Listen Only (0x04) are supported.
Force Multiple Coils	0x0F	Write multiple discrete outputs. For the ACS320, the individual bits of the control word are mapped to Coils 116. Relay outputs are mapped sequentially beginning with Coil 33 (eg, RO1=Coil 33).
Write Multiple Holding Registers	0x10	Write multiple holding registers. For the ACS320, the entire parameter set is mapped as holding registers, as well as command, status and reference values.
Read/Write Multiple Holding Registers	0x17	This function combines functions 0x03 and 0x10 into a single command.

Mapping summary

The following table summarizes the mapping between the ACS320 (parameters and I/O) and Modbus reference space. For details, see section Modbus addressing below.

ACS320	Modbus Reference	Supported Function Codes
 Control Bits 	Coils(0xxxx)	01 – Read Coil Status
 Relay Outputs 		05 – Force Single Coil
		15 – Force Multiple Coils
Status Bits	Discrete Inputs(1xxxx)	02 – Read Input Status
 Discrete Inputs 		
 Analog Inputs 	Input Registers(3xxxxx)	04 – Read Input Registers
 Parameters 	Holding Registers(4xxxx)	03 – Read 4X Registers
 Control/Status 		06 – Preset Single 4X Register
Words		16 – Preset Multiple 4X Registers
References		23 – Read/Write 4X Registers

Communication profiles

When communicating by Modbus, the ACS320 supports multiple profiles for control and status information. Parameter 5305 EFB CTRL PROFILE selects the profile used.

ABB DRV LIM - This profile is based on the PROFIBUS interface, and is discussed in detail in the following sections.

- DCU PROFILE Another profile is called the DCU PROFILE profile. It extends the
 control and status interface to 32 bits, and is the internal interface between the
 main drive application and the embedded fieldbus environment.
- ABB DRV FULL This profile is also based on the PROFIBUS interface, and supports two control word bits not supported by the ABB DRV LIM profile.

Modbus addressing

With Modbus, each function code implies access to a specific Modbus reference set. Thus, the leading digit is not included in the address field of a Modbus message.

Note: The drive supports the zero-based addressing of the Modbus specification. Holding register 40002 is addressed as 0001 in a Modbus message. Similarly, coil 33 is addressed as 0032 in a Modbus message.

Refer again to section *Mapping summary* above. The following sections describe, in detail, the mapping to each Modbus reference set.

0xxxx Mapping – Modbus Coils. The drive maps the following information to the 0xxxx Modbus set called Modbus Coils:

- Bit-wise map of the CONTROL WORD (selected using parameter 5305 EFB CTRL PROFILE). The first 32 coils are reserved for this purpose.
- Relay output states, numbered sequentially beginning with coil 00033.

The following table summarizes the 0xxxx reference set:

Modbus Ref.	Internal Location (All Profiles)	(5305 = 0)	(5305 = 1)	(5305 = 2)
0 0001	– Bit 0	OFF1*	STOP	OFF1*
0 0002	– Bit 1	OFF2*	START	OFF2*
0 0003	– Bit 2	OFF3*	REVERSE	OFF3*
0 0004	– Bit 3	START	LOCAL	START
0 0005	– Bit 4	N/A	RESET	RAMP_OUT_ZERO*
0 0006	– Bit 5	RAMP_HOLD*	EXT2	RAMP_HOLD*
0 0007	– Bit 6	RAMP_IN_ZERO*	RUN_DISABLE	RAMP_IN_ZERO*
0 0008	– Bit 7	RESET	STPMODE_R	RESET
0 0009	– Bit 8	N/A	STPMODE_EM	N/A
0 0010	– Bit 9	N/A	STPMODE_C	N/A
0 0011	– Bit 10	N/A	RAMP_2	REMOTE_CMD*
0 0012	– Bit 11	EXT2	RAMP_OUT_0	EXT2
0 0013	– Bit 12	N/A	RAMP_HOLD	N/A
0 0014	– Bit 13	N/A	RAMP_IN_0	N/A
0 0015	– Bit 14	N/A	REQ_LOCALLOCK	N/A
0 0016	– Bit 15	N/A	TORQLIM2	N/A

Modbus Ref.	Internal Location (All Profiles)	(5305 = 0)	(5305 = 1)	(5305 = 2)
0 0017	– Bit 16	Does not apply	FBLOCAL_CTL	Does not apply
0 0018	– Bit 17		FBLOCAL_REF	
0 0019	– Bit 18		START_DISABLE1	
0 0020	– Bit 19		START_DISABLE2	
0 0021 0 0032	Reserved	Reserved	Reserved	Reserved
0 0033	relay output 1	Relay Output 1	Relay Output 1	Relay Output 1
0 0034	relay output 2	Relay Output 2	Relay Output 2	Relay Output 2
0 0035	relay output 3	Relay Output 3	Relay Output 3	Relay Output 3
0 0036	relay output 4	Relay Output 4	Relay Output 4	Relay Output 4

^{* =} Active low

For the 0xxxx registers:

- · Status is always readable.
- Forcing is allowed by user configuration of the drive for fieldbus control.
- · Additional relay outputs are added sequentially.

The drive supports the following Modbus function codes for coils:

Function Code	Description
01	Read coil status
05	Force single coil
15 (0x0F Hex)	Force multiple coils

1xxxx Mapping - Modbus Discrete Inputs. The drive maps the following information to the 1xxxx Modbus set called Modbus Discrete Inputs:

- Bit-wise map of the STATUS WORD (selected using parameter 5305 EFB CTRL PROFILE). The first 32 inputs are reserved for this purpose.
- Discrete hardware inputs, numbered sequentially beginning with input 33.

The following table summarizes the 1xxxx reference set:

Modbus Ref.	Internal Location (All Profiles)	(5305 = 0 or 2)	(5305 = 1)
1 0001	– Bit 0	RDY_ON	READY
10002	– Bit 1	RDY_RUN	ENABLED
10003	– Bit 2	RDY_REF	STARTED
10004	– Bit 3	TRIPPED	RUNNING
10005	– Bit 4	OFF_2_STA*	ZERO_SPEED
10006	– Bit 5	OFF_3_STA*	ACCELERATE
10007	– Bit 6	SWC_ON_INHIB	DECELERATE
10008	– Bit 7	ALARM	AT_SETPOINT
10009	– Bit 8	AT_SETPOINT	LIMIT

Modbus Ref.	Internal Location (All Profiles)	(5305 = 0 or 2)	(5305 = 1)
1 0010	- Bit 9	REMOTE	SUPERVISION
1 0011	– Bit 10	ABOVE_LIMIT	REV_REF
1 0012	– Bit 11	EXT2	REV_ACT
1 0013	– Bit 12	RUN_ENABLE	PANEL_LOCAL
1 0014	– Bit 13	N/A	FIELDBUS_LOCAL
1 0015	– Bit 14	N/A	EXT2_ACT
1 0016	– Bit 15	N/A	FAULT
1 0017	– Bit 16	Reserved	ALARM
1 0018	– Bit 17	Reserved	REQ_MAINT
1 0019	– Bit 18	Reserved	DIRLOCK
10020	– Bit 19	Reserved	LOCALLOCK
1 0021	– Bit 20	Reserved	CTL_MODE
10022	– Bit 21	Reserved	Reserved
10023	– Bit 22	Reserved	Reserved
10024	– Bit 23	Reserved	Reserved
10025	– Bit 24	Reserved	Reserved
10026	– Bit 25	Reserved	Reserved
10027	– Bit 26	Reserved	REQ_CTL
10028	– Bit 27	Reserved	REQ_REF1
10029	– Bit 28	Reserved	REQ_REF2
10030	– Bit 29	Reserved	REQ_REF2EXT
1 0031	– Bit 30	Reserved	ACK_STARTINH
10032	– Bit 31	Reserved	ACK_OFF_ILCK
10033		DI1	DI1
10034		DI2	DI2
10035		DI3	DI3
10036		DI4	DI4
10037		DI5	DI5

^{* =} Active low

For the 1xxxx registers:

· Additional discrete inputs are added sequentially.

The drive supports the following Modbus function codes for discrete inputs:

Function Code	Description
02	Read input status

3xxxx Mapping – Modbus Inputs. The drive maps the following information to the 3xxxx Modbus addresses called Modbus input registers:

· Any user defined analog inputs.

The following table summarizes the input registers:

Modbus Reference	Internal Location (All Profiles)	Remarks	
3 0001	ai1	This register shall report the level of Analog Input 1 (0100%).	
3 0002	ai2	This register shall report the level of Analog Input 2 (0100%).	

The drive supports the following Modbus function codes for 3xxxx registers:

Function Code	Description
04	Read 3xxxx input status

4xxxx Register Mapping. The drive maps its parameters and other data to the 4xxxx holding registers as follows:

- 40001...40099 map to drive control and actual values. These registers are described in the table below.
- 40101...49999 map to drive parameters 0101...9999. Register addresses that do not correspond to drive parameters are invalid. If there is an attempt to read or write outside the parameter addresses, the Modbus interface returns an exception code to the controller.

The following table summarizes the 4xxxx drive control registers 40001...40099 (for 4xxxx registers above 40099, see the drive parameter list, for example, 40102 is parameter 0102):

Mo	odbus Register	Access	Remarks
4 0001		R/W	Maps directly to the profile cSupported only if 5305 = 0 or 2 (ABB Drives profile). Parameter 5319 holds a copy in hex format.
4 0002	Reference 1	R/W	Range = 0+20000 (scaled to 01105 REF1 MAX, or -200000 (scaled to 1105 REF1 MAX0).
40003	Reference 2	R/W	Range = 0+10000 (scaled to 01108 REF2 MAX, or -100000 (scaled to 1108 REF2 MAX0).
4 0004		R	Maps directly to the profile sSupported only if 5305 = 0 or 2 (ABB Drives profile). Parameter 5320 holds a copy in hex format.
40005	Actual 1 (select using 5310)	R	By default, stores a copy of 0103 OUTPUT FREQ. Use parameter 5310 to select a different actual value for this register.
40006	Actual 2 (select using 5311)	R	By default, stores a copy of 0104 CURRENT. Use parameter 5311 to select a different actual value for this register.
4 0007	Actual 3 (select using 5312)	R	By default, stores nothing. Use parameter 5312 to select an actual value for this register.
4 0008	Actual 4 (select by 5313)	R	By default, stores nothing. Use parameter 5313 to select an actual value for this register.
4 0009	Actual 5 (select using 5314)	R	By default, stores nothing. Use parameter 5314 to select an actual value for this register.

3	2	4
J	_	4

M	odbus Register	Access	Remarks
4 0010	Actual 6 (select using 5315)	R	By default, stores nothing. Use parameter 5315 to select an actual value for this register.
4 0011	Actual 7 (select using 5316)	R	By default, stores nothing. Use parameter 5316 to select an actual value for this register.
4 0012	Actual 8 (select using 5317)	R	By default, stores nothing. Use parameter 5317 to select an actual value for this register.
4 0031	LSW	R/W	Maps directly to the Least Significant Word of the DCU profile's CONTROL WORD. Supported only if 5305 = 1. See parameter 0301.
4 0032	MSW	R	Maps directly to the Most Significant Word of the DCU profile's CONTROL WORD. Supported only if 5305 = 1. See parameter 0302.
4 0033	LSW	R	Maps directly to the Least Significant Word of the DCU profile's CONTROL WORD. Supported only if 5305 = 1. See parameter 0303.
4 0034	MSW	R	Maps directly to the Most Significant Word of the DCU profile's CONTROL WORD. Supported only if 5305 = 1. See parameter 0304.

For the Modbus protocol, drive parameters in group 53 report the parameter mapping to 4xxxx Registers.

Code	Description
5310	EFB PAR 10
	Specifies the parameter mapped to Modbus register 40005.
5311	EFB PAR 11
	Specifies the parameter mapped to Modbus register 40006.
5312	EFB PAR 12
	Specifies the parameter mapped to Modbus register 40007.
5313	EFB PAR 13
	Specifies the parameter mapped to Modbus register 40008.
5314	EFB PAR 14
	Specifies the parameter mapped to Modbus register 40009.
5315	EFB PAR 15
	Specifies the parameter mapped to Modbus register 40010.
5316	EFB PAR 16
	Specifies the parameter mapped to Modbus register 40011.
5317	EFB PAR 17
	Specifies the parameter mapped to Modbus register 40012.
5318	Reserved.
5319	EFB PAR 19
	Holds a copy (in hex) of the CONTROL WORD, Modbus register 40001.
5320	EFB PAR 20
	Holds a copy (in hex) of the STATUS WORD, Modbus register 40004.

Except where restricted by the drive, all parameters are available for both reading and writing. The parameter writes are verified for the correct value, and for a valid register addresses.

Note: Parameter writes through standard Modbus are always volatile, in other words, modified values are not automatically stored to permanent memory. Use parameter 1607 PARAM, SAVE to save all altered values.

The drive supports the following Modbus function codes for 4xxxx registers:

Function Code	Description		
03	Read holding 4xxxx registers		
06	Preset single 4xxxx register		
16 (0x10 Hex)	Preset multiple 4xxxx registers		
23 (0x17 Hex)	Read/write 4xxxx registers		

Actual values

The contents of the register addresses 40005...40012 are actual values and are:

- Specified using parameters 5310...5317.
- · Read-only values containing information on the operation of the drive.
- 16-bit words containing a sign bit and a 15-bit integer.
- · When negative values, written as the two's complement of the corresponding positive value.
- Scaled as described earlier in Actual value scaling.

Exception codes

Exception codes are serial communication responses from the drive. The drive supports the standard Modbus exception codes defined below.

Exception Code	Name	Meaning
01		Unsupported command
02		The data address received in the query is not allowable. It is not a defined parameter/group.
03		A value contained in the query data field is not an allowable value for the drive, because it is one of the following: Outside min. or max. limits. Parameter is read-only. Message is too long. Parameter write not allowed when start is active. Parameter write not allowed when factory macro is selected.

ABB control profiles technical data

Overview

ABB Drives profile

The ABB Drives profile provides a standard profile that can be used on multiple protocols, including Modbus and the protocols available on the FBA module. Two implementations of the ABB Drives profile are available:

- ABB DRV FULL This implementation standardizes the control interface with ACS600 and ACS800 drives
- ABB DRV LIM This implementation standardizes the control interface with ACH400 drives. This implementation does not support two control word bits supported by ABB DRV FULL.

Except as noted, the following "ABB Drives profile" descriptions apply to both implementations.

DCU profile

The DCU profile extends the control and status interface to 32 bits, and is the internal interface between the main drive application and the embedded fieldbus environment.

Control word

The CONTROL WORD is the principal means for controlling the drive from a fieldbus system. The fieldbus master station sends the CONTROL WORD to the drive. The drive switches between states according to the bit-coded instructions in the CONTROL WORD. Using the CONTROL WORD (ABB Drives profile version) requires that:

- The drive is in remote (REM) control.
- The serial communication channel is defined as the source for controlling commands (set using parameters 1001 EXT1 COMMANDS, 1002 EXT2 COMMANDS and 1102 EXT1/EXT2 SEL).
- The serial communication channel used is configured to use an ABB control
 profile. For example, to use the control profile ABB DRV FULL, requires both
 parameter 9802 COMM PROT SEL = 1 (STD MODBUS), and parameter 5305 EFB
 CTRL PROFILE = 2 (ABB DRV FULL).

ABB Drives profile

The following table and the state diagram later in this sub-section describe the CONTROL WORD content for the ABB Drives profile.

	ABB Drives Profile (EFB) CONTROL WORD						
Bit	Name	Value	Commanded State	Comments			
0	OFF1 CONTROL	1	READY TO OPERATE	Enter READY TO OPERATE.			
		0	EMERGENCY OFF	Drive ramps to stop according to currently active deceleration ramp (2203 or 2205) Normal command sequence: • Enter OFF1 ACTIVE. • Proceed to READY TO SWITCH ON, unless other interlocks (OFF2, OFF3) are active.			
1	OFF2	1	OPERATING	Continue operation (OFF2 inactive)			
	CONTROL	0	EMERGENCY OFF	Drive coasts to stop. Normal command sequence: • Enter OFF2 ACTIVE. • Proceed to SWITCHON INHIBITED.			
2	OFF3 CONTROL	1	OPERATING	Continue operation (OFF3 inactive)			
	ooiiiiioz	0	EMERGENCY STOP	Drive stops within in time specified by parameter 2208. Normal command sequence: • Enter OFF3 active. • Proceed to switch on inhibited. **WARNING!** Be sure motor and driven equipment can be stopped using this mode.			
3	INHIBIT OPERATION	1	OPERATION ENABLED	Enter OPERATION ENABLED (Note the Run enable signal must be active. See parameter 1601. If parameter 1601 is set to COMM, this bit also actives the Run Enable signal.)			
		0	OPERATION INHIBITED	Inhibit operation. Enter OPERATION INHIBITED.			
4	Unused (ABB DI		1				
	RAMP_OUT_ ZERO (ABB DRV	1	NORMAL OPERATION	Enter RAMP FUNCTION GENERATOR: ACCELERATION ENABLED.			
	FULL)	0	RFG OUT ZERO	Force ramp function generator output to Zero. Drive ramps to stop (current and DC voltage limits in force).			
5	RAMP_HOLD		RFG OUT ENABLED	Enable ramp function. Enter RAMP FUNCTION GENERATOR: ACCELERATION ENABLED.			
		0	RFG OUT HOLD	Halt ramping (Ramp Function Generator output held)			

	ABB Drives Profile (EFB) CONTROL WORD						
Bit	Name	Value	Commanded State	Comments			
6	RAMP_IN_ ZERO	1	RFG INPUT ENABLED	Normal operation. Enter OPERATING.			
		0	RFG INPUT ZERO	Force Ramp Function Generator input to zero.			
7	RESET	0=>1	RESET	Fault reset if an active fault exists (Enter SWITCH-ON INHIBITED). Effective if 1604 = COMM.			
		0	OPERATING	Continue normal operation			
89	Unused						
10	Unused (ABB DF	RV LIM)					
	REMOTE_CMD	1		Fieldbus control enabled.			
	(ABB DRV FULL)	0		 CW ≠ 0 or Ref ≠ 0: Retain last CW and Ref. CW = 0 and Ref = 0: Fieldbus control enabled. Ref and deceleration/acceleration ramp are locked. 			
11	1 EXT CTRL LOC		EXT2 SELECT	Select external control location 2 (EXT2). Effective if 1102 = COMM.			
		0	EXT1 SELECT	Select external control location 1 (EXT1). Effective if 1102 = COMM.			
1215	Unused						

DCU profile

The following tables describe the CONTROL WORD content for the DCU profile.

	DCU Profile CONTROL WORD (See Parameter 0301)						
Bit	Name	Value	Command/Req.	Comments			
0	STOP	1	Stop	Stops according to either the stop			
		0	(no op)	mode parameter or the stop mode requests (bits 7 and 8).			
1	START	1	Start	Simultaneous STOP and START			
		0	(no op)	commands result in a stop command.			
2	REVERSE	1	Reverse direction	This bit XOR'd with the sign of the			
		0	Forward direction	reference defines direction.			
3	3 LOCAL		Local mode	When the fieldbus sets this bit, it			
			External mode	steals control and the drive moves to fieldbus local control mode.			
4	RESET	-> 1	Reset	Edge sensitive.			
		other	(no op)				
5	EXT2	1	Switch to				
		0	Switch to				
6	RUN_DISABLE	1	Run disable	Inverted run enable.			
		0	Run enable on				

	DCU Profile CONTROL WORD (See Parameter 0301)					
Bit	Name	Value	Command/Req.	Comments		
7	STPMODE_R	1	Normal ramp stop mode			
		0	(no op)			
8	STPMODE_EM	1	Emergency ramp stop mode			
		0	(no op)			
9	STPMODE_C	1	Coast stop mode			
		0	(no op)			
10	RAMP_2	1	Ramp pair 2			
		0	Ramp pair 1			
11	RAMP_OUT_0	1	Ramp output to 0			
			(no op)			
12	RAMP_HOLD	1	Ramp freeze			
		0	(no op)			
13	RAMP_IN_0	1	Ramp input to 0			
		0	(no op)			
14		1	Local mode lock	In lock, the drive will not switch to		
C	C	0	(no op)	local mode.		
15	TORQLIM2	1	Torque limit pair 2			
		0	Torque limit pair 1			

	DCU Profile CONTROL WORD (See Parameter 0302)					
Bit	Name	Value	Function	Comments		
1626			Reserved			
27	REF_CONST	1	Constant speed ref.	These bits are only for supervision purposes.		
		0	(no op)			
28	REF_AVE	1	Average speed ref.			
		0	(no op)			
29	LINK_ON		Master is detected in link			
		0	Link is down			
30	REQ_STARTINH	1 Start inhibit request is pending				
		0	Start inhibit request is OFF			
31	OFF_INTERLOCK	1	Panel OFF button pressed	For the control panel (or PC tool) this is the OFF button interlock.		
		0	(no op)			

Status word

The contents of the STATUS WORD is status information, sent by the drive to the master station.

ABB Drives profile

The following table and the state diagram later in this sub-section describe the status word content for the ABB Drives profile.

	ABB Drives Profile (EFB) STATUS WORD				
Bit	Name	Value	Description (Correspond to states/boxes in the state diagram)		
0	RDY_ON	1	READY TO SWITCH ON		
		0	NOT READY TO SWITCH ON		
1	RDY_RUN	1	READY TO OPERATE		
		0	OFF1 ACTIVE		
2	RDY_REF	1	OPERATION ENABLED		
		0	OPERATION INHIBITED		
3	TRIPPED	01	FAULT		
		0	No fault		
4	OFF_2_STA	1	OFF2 INACTIVE		
		0	OFF2 ACTIVE		
5	OFF_3_STA	1	OFF3 INACTIVE		
		0	OFF3 ACTIVE		
6	SWC_ON_INHIB	1	SWITCH-ON INHIBIT ACTIVE		
		0	SWITCH-ON INHIBIT NOT ACTIVE		
7	ALARM	1	Warning/alarm (See chapter <i>Fault tracing</i> section for details on alarms.)		
		0	No warning/alarm		
8	AT_SETPOINT	1	OPERATING. Actual value equals (within tolerance limits) the reference value.		
			Actual value is outside tolerance limits (not equal to reference value).		
9	REMOTE	1	Drive control location: REMOTE (EXT1 or EXT2)		
		0	Drive control location: LOCAL		
10	ABOVE_LIMIT	1	Supervised parameter's value ≥ supervision high limit.		
			Bit remains "1" until supervised parameter's value < supervision low limit.		
			See Group 32: Supervision.		
		0	Supervised parameter's value < supervision low limit.		
			Bit remains "0" until supervised parameter's value > supervision high limit.		
			See Group 32: Supervision.		

	ABB Drives Profile (EFB) STATUS WORD				
Bit	Name	Value	Description (Correspond to states/boxes in the state diagram)		
11	EXT CTRL LOC	1	External control location 2 (EXT2) selected		
		0	External control location 1 (EXT1) selected		
12	EXT RUN ENABLE	1 External Run Enable signal received			
		0	No External Run Enable signal received		
13 15	Unused				

DCU profile

The following tables describe the STATUS WORD content for the DCU profile.

	DCU Profile STATUS WORD (See Parameter 0303)					
Bit	Name	Value	Status			
0	READY	1	Drive is ready to receive start command.			
		0	Drive is not ready.			
1	ENABLED	1	External run enable signal received.			
		0	No external run enable signal received.			
2	STARTED	1	Drive has received start command.			
		0	Drive has not received start command.			
3	RUNNING	1	Drive is modulating.			
		0	Drive is not modulating.			
4	ZERO_SPEED	1	Drive is at zero speed.			
		0	Drive has not reached zero speed.			
5	ACCELERATE	1	Drive is accelerating.			
		0	Drive is not accelerating.			
6	DECELERATE	1	Drive is decelerating.			
		0	Drive is not decelerating.			
7	AT_SETPOINT	1	Drive is at setpoint.			
		0	Drive has not reached setpoint.			
8	LIMIT	1	Operation is limited by Group 20 settings.			
		0	Operation is within Group 20 settings.			
9	SUPERVISION	1	A supervised parameter (Group 32) is outside its limits.			
		0	All supervised parameters are within limits.			
10	REV_REF	1	Drive reference is in reverse direction.			
		0	Drive reference is in forward direction.			
11	REV_ACT	1	Drive is running in reverse direction.			
		0	Drive is running in forward direction.			
12	PANEL_LOCAL	1	Control is in control panel (or PC tool) local mode.			
		0	Control is not in control panel local mode.			
13	FIELDBUS_LOCA L	1	Control is in fieldbus local mode (steals control panel local).			
		0	Control is not in fieldbus local mode.			

2	•	
. 5	. 5	/
_	•	-

	DCU Profile STATUS WORD (See Parameter 0303)					
Bit	Bit Name Value Status					
14	EXT2_ACT	1	Control is in the EXT2 mode.			
		0	Control is in the EXT1 mode.			
15	FAULT	1	Drive is in a fault state.			
		0	Drive is not in a fault state.			

	DCU I	Profile s	TATUS WORD (See Parameter 0304)
Bit	Name	Value	Status
16	ALARM	1	An alarm is on.
		0	No alarms are on.
17	REQ_MAINT	1	A maintenance request is pending.
		0	No maintenance request is pending.
18	DIRLOCK	1	Direction lock is ON. (Direction change is locked out.)
		0	Direction lock is OFF.
19	LOCALLOCK	1	Local mode lock is ON. (Local mode is locked out.)
		0	Local mode lock is OFF.
20	CTL_MODE	1	Drive is in vector control mode.
		0	Drive is in scalar control mode.
2125	Reserved		
26	REQ_CTL	1	Copy the control word
		0	(no op)
27	REQ_REF1	1	Reference 1 requested in this channel.
		0	Reference 1 is not requested in this channel.
28	REQ_REF2	1	Reference 2 requested in this channel.
		0	Reference 2 is not requested in this channel.
29	REQ_REF2EXT	1	External PID reference 2 requested in this channel.
		0	External PID reference 2 is not requested in this channel.
30	ACK_STARTINH	1	A start inhibit from this channel is granted.
		0	A start inhibit from this channel is not granted.
31	ACK_OFF_ILCK	1	Start inhibit due to OFF button
		0	Normal operation

State diagram

ABB Drives profile


To illustrate the operation of the state diagram, the following example (ABB DRV LIM implementation of the ABB Drives profile) uses the control word to start the drive:

- First, the requirements for using the CONTROL WORD must be met. See above.
- When the power is first connected, the state of the drive is not ready to switch on. See dotted lined path (===) in the state diagram below.

• Use the CONTROL WORD to step through the state machine states until the OPERATING state is reached, meaning that the drive is running and follows the given reference. See table below.

Step	CONTROL WORD Value	Description
1	CW = 0000 0000 0000 0110	This CW value changes the drive state to READY TO
	l l bit 15 bit (SWITCH ON.
	DIL 15 DIL	J
2		Wait at least 100 ms before proceeding.
3	CW = 0000 0000 0000 0111	This CW value changes the drive state to READY TO OPERATE.
4	CW = 0000 0000 0000 1111	This CW value changes the drive state to OPERATION ENABLED. The drive starts, but will not accelerate.
5	CW = 0000 0000 0010 1111	This CW value releases the ramp function generator (RFG) output, and changes the drive state to RFG: ACCELERATOR ENABLED.
6	CW = 0000 0000 0110 1111	This CW value releases the ramp function generator (RFG) output, and changes the drive state to OPERATING. The drive accelerates to the given reference and follows the reference.

The state diagram below describes the start-stop function of CONTROL WORD (CW) and STATUS WORD (SW) bits for the ABB Drives profile.



^{*}This state transition also occurs if the fault is reset from any other source (eg, digital input).

Reference scaling


ABB Drives and DCU profiles


The following table describes REFERENCE scaling for the ABB Drives profile.

	ABB Drives and DCU Profiles			
Reference	Range	Reference Type	Scaling	Remarks
REF1	-32767 +32767	Speed or frequency	-20000 = -(par. 1105) 0 = 0 +20000 = (par. 1105) (20000 corresponds to 100%)	Final reference limited by 1104/1105. Actual motor speed limited by 2001/2002 (speed) or 2007/2008 (frequency).
REF2	-32767 +32767	Speed or frequency	-10000 = -(par. 1108) 0 = 0 +10000 = (par. 1108) (10000 corresponds to 100%)	Final reference limited by 1107/1108. Actual motor speed limited by 2001/2002 (speed) or 2007/2008 (frequency).
		Torque	-10000 = -(par. 1108) 0 = 0 +10000 = (par. 1108) (10000 corresponds to 100%)	Final reference limited by 2015/2017 (torque1) or 2016/2018 (torque2).
		PID Reference	-10000 = -(par. 1108) 0 = 0 +10000 = (par. 1108) (10000 corresponds to 100%)	Final reference limited by 4012/4013 (PID set1) or 4112/4113 (PID set2).

Note: The setting of parameter 1104 REF1 MIN and 1107 REF2 MIN has no effect on the scaling of references.

When parameter 1103 REF1 SELECT or 1106 REF2 SELECT is set to COMM+AI1 or COMM*AI1. the reference is scaled as follows:





Reference handling

Use *Group 10: Start/Stop/Dir* parameters to configure for control of rotation direction for each control location (EXT1 and EXT2). The following diagrams illustrate how Group 10: Start/Stop/Dir parameters and the sign of the fieldbus reference interact to produce REFERENCE values (REF1 and REF2). Note, fieldbus references are bipolar, that is they can be positive or negative.

	ABB Drives Profile			
Parameter	Value Setting	Al Reference Scaling		
1003	1 ()	Resultant Ref.		
		Max. Ref		

ABB Drives Profile			
Parameter	Value Setting	Al Reference S	caling
1003	2 ()	Max. Ref	Resultant Ref.
		Fieldbus -163% -100% Reference	100% 163%
1003	3 (request)	Max. Ref	Resultant Ref.



Fault tracing

Contents of this chapter

The chapter tells how to reset faults and view fault history. It also lists all alarm and fault messages including the possible cause and corrective actions.

Safety



WARNING! Only qualified electricians are allowed to maintain the drive. Read the safety instructions in chapter Safety on page 15 before you work on the

Alarm and fault indications

Fault is indicated with a red LED. See section *LEDs* on page 361.

An alarm or fault message on the panel display indicates abnormal drive status. Using the information given in this chapter most alarm and fault causes can be identified and corrected. If not, contact an ABB representative.

The four digit code number in parenthesis after the fault is for the fieldbus communication. (See chapter Fieldbus control on page 267.)

How to reset

The drive can be reset either by pressing the keypad key (Basic Control Panel) or (Assistant Control Panel), through digital input or fieldbus, or by switching the supply voltage off for a while. The source for the fault reset signal is selected by parameter 1604 FAULT RESET SEL. When the fault has been removed, the motor can be restarted.

Fault history

When a fault is detected, it is stored in the Fault history. The latest faults are stored together with the time stamp.

Parameters 0401 LAST FAULT, 0412 PREVIOUS FAULT 1 and 0413 PREVIOUS FAULT 2 store the most recent faults. Parameters 0404...0409 show drive operation data at the time the latest fault occurred. The Assistant control panel provides additional information about the fault history. See section Fault logger mode on page 68 for more information.

Alarm messages generated by the drive

CODE	ALARM	CAUSE	WHAT TO DO
2001	OVERCURRENT 0308 bit 0 (programmable fault function 1610)	Output current limit controller is active.	Check motor load. Check acceleration time (2202 and 2205). Check motor and motor cable (including phasing).
			Check ambient conditions. Load capacity decreases if installation site ambient temperature exceeds 40 °C. See section <i>Derating</i> on page <i>366</i> .
2002	OVERVOLTAGE 0308 bit 1 (programmable fault function 1610)	DC overvoltage controller is active.	Check deceleration time (2203 and 2206). Check input power line for static or transient overvoltage.
2003	UNDERVOLTAGE 0308 bit 2 (programmable fault function 1610)	DC undervoltage controller is active.	Check input power supply.
2004	DIR LOCK 0308 bit 3	Change of direction is not allowed.	Check the settings of parameter 1003 DIRECTION.
2005	IO COMM 0308 bit 4 (programmable fault	Fieldbus communication break	Check status of fieldbus communication. See chapter <i>Fieldbus control</i> on page 267. Check fault function parameter
	function 3018, 3019)		settings. Check connections. Check if master can communicate.
2006	Al1 LOSS 0308 bit 5 (programmable fault function 3001, 3021)	Analog input Al1 signal has fallen below limit defined by parameter 3021 Al1 FAULT LIMIT.	Check fault function parameter settings. Check for proper analog control signal levels. Check connections.
2007	Al2 LOSS 0308 bit 6 (programmable fault function 3001, 3021)	Analog input Al2 signal has fallen below limit defined by parameter 3022 Al2 FAULT LIMIT.	Check fault function parameter settings. Check for proper analog control signal levels. Check connections.
2008	PANEL LOSS 0308 bit 7 (programmable fault function 3002)	Control panel selected as active control location for drive has ceased communicating.	Check panel connection. Check fault function parameters. Check control panel connector. Refit control panel in mounting platform. If drive is in external control mode (REM) and is set to accept start/stop, direction commands or references via control panel: Check Group 10: Start/Stop/Dir and Group 11: Reference select settings.

CODE	ALARM	CAUSE	WHAT TO DO
2009	DEVICE OVERTEMP 0308 bit 8	Drive IGBT temperature is excessive. Alarm limit is 120 °C.	Check ambient conditions. See also section <i>Derating</i> on page 366. Check air flow and fan operation. Check motor power against unit power.
2010	MOTOR TEMP 0305 bit 9 (programmable fault function 30053009 / 3503)	Motor temperature is too high (or appears to be too high) due to excessive load, insufficient motor power, inadequate cooling or incorrect start-up data.	Check motor ratings, load and cooling. Check start-up data. Check fault function parameters.
		Measured motor temperature has exceeded alarm limit set by parameter 3503 ALARM LIMIT.	Check value of alarm limit. Check that actual number of sensors corresponds to value set by parameter (2501 SENSOR TYPE). Let motor cool down. Ensure proper motor cooling: Check cooling fan, clean cooling surfaces, etc.
2012	MOTOR STALL 0308 bit 11 (programmable fault function 30103012)	Motor is operating in stall region due to, eg, excessive load or insufficient motor power.	Check motor load and drive ratings. Check fault function parameters.
2013	AUTORESET 0308 bit 12	Automatic reset alarm	Check parameter <i>Group 31: Automatic reset</i> settings.
2014	AUTOCHANGE 0308 bit 13	PFA autochange function is active.	See parameter <i>Group 81: PFA control</i> , section on page 92.
2015	PFC I LOCK 0308 bit 14	PFA interlocks are active.	Drive cannot start any motor (when Autochange is used) the speed regulated motor (when Autochange is not used). See parameter group Group 81: PFA control.
2018	PID SLEEP 3009 bit 1	Sleep function has entered sleeping mode.	See parameter Group 40: Process PID set 1Group 41: Process PID set 2.
2020	OVERRIDE	Override mode is activated. See <i>Group</i> 17: Override.	See sections Commissioning the override mode and Changing the override parameters.
2021	START ENABLE 1 MISSING 3009 bit 4	No Start Enable 1 signal received	Check parameter 1608 START ENABLE 1settings. Check digital input connections. Check fieldbus communication settings.

CODE	ALARM	CAUSE	WHAT TO DO
2022	START ENABLE 2 MISSING 3009 bit 5	No Start Enable 2 signal received	Check parameter 1609 START ENABLE 2 settings. Check digital input connections. Check fieldbus communication settings.
2023	EMERGENCY STOP 3009 bit 6	Drive has received emergency stop command and ramps to stop according to ramp time defined by parameter 2208 EMERG DEC TIME.	Check that it is safe to continue operation. Return emergency stop push button to normal position.
2025	FIRST START 3009 bit 8	Motor identification magnetization is on. This alarm belongs to normal start-up procedure.	Wait until drive indicates that motor identification is completed.
2026	INPUT PHASE LOSS 3009 bit 9 (programmable fault function 3016)	Intermediate circuit DC voltage is oscillating due to missing input power line phase or blown fuse. Alarm is generated when DC voltage ripple exceeds 14% of nominal DC voltage.	Check input power line fuses. Check for input power supply imbalance. Check fault function parameters.
2027	USER LOAD CURVE 3009 bit 10	Condition defined by 3701 USER LOAD C MODE has been valid longer than half of the time set by 3703 USER LOAD C TIME.	See parameter <i>Group 37: User load curve</i> .
2028	START DELAY 3009 bit 11	Start delay in progress	See parameter 2113 START DELAY.
2030	INLET LOW 3009 bit 13	Pressure at pump/fan inlet too low	Check for a closed valve on the inlet side of the pump/fan. Check piping for leaks. See parameter <i>Group 44: Pump protection</i> .
2031	OUTLET HIGH 3009 bit 14	Pressure at pump/fan outlet too high	Check piping for blocks. See parameter <i>Group 44: Pump protection</i> .
2032	PIPE FILL 3009 bit 15	Pipe fill in progress	See parameters 44214426.
2033	INLET VERY LOW 0310 bit 0	Pressure at pump/fan inlet too low	Check for a closed valve on the inlet side of the pump/fan. Check piping for leaks. See parameter Group 44: Pump protection.

CODE	ALARM	CAUSE	WHAT TO DO
	OUTLET VERY HIGH 0310 bit 1	outlet too high	Check piping for blocks. See parameter <i>Group 44: Pump protection</i> .

¹⁾ Even when the relay output is configured to indicate alarm conditions (eg, parameter 1401 RELAY OUTPUT 1 = 5 (ALARM) or 16 (FLT/ALARM)), this alarm is not indicated by a relay output.

Alarms generated by the Basic control panel

The Basic control panel indicates control panel alarms with a code, A5xxx.

ALARM CODE	CAUSE	WHAT TO DO
5001	Drive is not responding.	Check panel connection.
5002	Incompatible communication profile	Contact your local ABB representative.
5010	Corrupted panel parameter backup file	Retry parameter upload. Retry parameter download.
5011	Drive is controlled from another source.	Change drive control to local control mode.
5012	Direction of rotation is locked.	Enable change of direction. See parameter 1003 DIRECTION.
5013	Panel control is disabled because start inhibit is active.	Start from the panel is not possible. Reset the emergency stop command or remove the 3-wire stop command before starting from the panel. See parameters 1001 EXT1 COMMANDS, 1002 EXT2 COMMANDS and 2109 EMERG STOP SEL.
5014	Panel control is disabled because of drive fault.	Reset drive fault and retry.
5015	Panel control is disabled because local control mode lock is active.	Deactivate local control mode lock and retry. See parameter 1606 LOCAL LOCK.
5018	Parameter default value is not found.	Contact your local ABB representative.
5019	Writing non-zero parameter value is prohibited.	Only parameter reset is allowed.
5020	Parameter or parameter group does not exist or parameter value is inconsistent.	Contact your local ABB representative.
5021	Parameter or parameter group is hidden.	Contact your local ABB representative.
5022	Parameter is write protected.	Parameter value is read-only and cannot be changed.
5023	Parameter change is not allowed, when drive is running.	Stop drive and change parameter value.
5024	Drive is executing task.	Wait until task is completed.
5025	Software is being uploaded or downloaded.	Wait until upload/download is complete.
5026	Value is at or below minimum limit.	Contact your local ABB representative.
5027	Value is at or above maximum limit.	Contact your local ABB representative.
5028	Invalid value	Contact your local ABB representative.
5029	Memory is not ready.	Retry.

ALARM CODE	CAUSE	WHAT TO DO
5030	Invalid request	Contact your local ABB representative.
5031	Drive is not ready for operation, eg due to low DC voltage.	Check input power supply.
5032	Parameter error	Contact your local ABB representative.
5040	Parameter download error. Selected parameter set is not in current parameter backup file.	Perform upload function before download.
5041	Parameter backup file does not fit into memory.	Contact your local ABB representative.
5042	Parameter download error. Selected parameter set is not in current parameter backup file.	Perform upload function before download.
5043	No start inhibit	
5044	Parameter backup file restoring error	Check that file is compatible with drive.
5050	Parameter upload aborted	Retry parameter upload.
5051	File error	Contact your local ABB representative.
5052	Parameter upload has failed.	Retry parameter upload.
5060	Parameter download aborted	Retry parameter download.
5062	Parameter download has failed.	Retry parameter download.
5070	Panel backup memory write error	Contact your local ABB representative.
5071	Panel backup memory read error	Contact your local ABB representative.
5080	Operation is not allowed because drive is not in local control mode.	Switch to local control mode.
5081	Operation is not allowed because of active fault.	Check cause of fault and reset fault.
5083	Operation is not allowed because parameter lock is on.	Check parameter 1602 PARAMETER LOCK setting.
5084	Operation is not allowed because drive is performing task.	Wait until task is completed and retry.
5085	Parameter download from source to destination drive has failed.	Check that source and destination drive types are same, ie, ACS320. See the type designation label of the drive.
5086	Parameter download from source to destination drive has failed.	Check that source and destination drive type designations are the same. See type designation labels of the drives.

ALARM CODE	CAUSE	WHAT TO DO
5087	Parameter download from source to destination drive has failed because parameter sets are incompatible.	Check that source and destination drive information are same. See parameters in <i>Group 33: Information</i> .
5088	Operation has failed because of drive memory error.	Contact your local ABB representative.
5089	Download has failed because of CRC error.	Contact your local ABB representative.
5090	Download has failed because of data processing error.	Contact your local ABB representative.
5091	Operation has failed because of parameter error.	Contact your local ABB representative.
5092	Parameter download from source to destination drive has failed because parameter sets are incompatible.	Check that source and destination drive information are same. See parameters in <i>Group 33: Information</i> .

Fault messages generated by the drive

CODE	FAULT	CAUSE	WHAT TO DO
0001	OVERCURRENT (2310) 0305 bit 0	Output current has exceeded trip level.	Check motor load. Check acceleration time (2202 and 2505). Check motor and motor cable (including phasing). Check ambient conditions. Load capacity decreases if installation site ambient temperature exceeds 40 °C. See section <i>Derating</i> on page 366.
0002	DC OVERVOLT (3210) 0305 bit 1	Excessive intermediate circuit DC voltage. DC overvoltage trip limit is 420 V for 200 V drives and 840 V for 400 V drives.	Check that overvoltage controller is on. Check input power line for static or transient overvoltage. Check deceleration time (2203, 2206).
0003	DEV OVERTEMP (4210) 0305 bit 2	Drive IGBT temperature is excessive. Fault trip limit is 135 °C.	Check ambient conditions. See also section <i>Derating</i> on page 366. Check air flow and fan operation. Check motor power against unit power.
0004	SHORT CIRC (2340) 0305 bit 3	Short circuit in motor cable(s) or motor	Check motor and motor cable.
0006	DC UNDERVOLT (3220) 0305 bit 5	Intermediate circuit DC voltage is not sufficient due to missing input power line phase, blown fuse, rectifier bridge internal fault or too low input power.	Check that undervoltage controller is on (parameter 2006 UNDERVOLT CTRL). Check input power supply and fuses.
0007	Al1 LOSS (8110) 0305 bit 6 (programmable fault function 3001, 3021)	Analog input Al1 signal has fallen below limit defined by parameter 3021 Al1 FAULT LIMIT.	Check fault function parameter settings. Check for proper analog control signal levels. Check connections.
0008	Al2 LOSS (8110) 0305 bit 7 (programmable fault function 3001, 3022)	Analog input AI2 signal has fallen below limit defined by parameter 3022 AI2 FAULT LIMIT.	Check fault function parameter settings. Check for proper analog control signal levels. Check connections.

CODE	FAULT	CAUSE	WHAT TO DO
0009	MOT OVERTEMP (4310) 0305 bit 8 (programmable fault function 03053009 / 3504)	Motor temperature is too high (or appears to be too high) due to excessive load, insufficient motor power, inadequate cooling or incorrect start-up data.	Check motor ratings, load and cooling. Check start-up data. Check fault function parameters.
		Measured motor temperature has exceeded fault limit set by parameter 3504 FAULT LIMIT.	Check value of fault limit. Check that actual number of sensors corresponds to value set by parameter 3501 SENSOR TYPE. Let motor cool down. Ensure proper motor cooling: Check cooling fan, clean cooling surfaces, etc.
0010	PANEL LOSS (5300) 0305 bit 9 (programmable fault function 3002)	Control panel selected as active control location for drive has ceased communicating.	Check panel connection. Check fault function parameters. Check control panel connector. Refit control panel in mounting platform. If drive is in external control mode (REM) and is set to accept start/stop, direction commands or references via control panel: Check Group 10: Start/Stop/Dir and Group 11: Reference select settings.
0012	MOTOR STALL (7121) 0305 bit 11 (programmable fault function 30103012)	Motor is operating in stall region due to eg excessive load or insufficient motor power.	Check motor load and drive ratings. Check fault function parameters.
0014	EXT FAULT 1 (9000) 0305 bit 13 (programmable fault function 3003)	External fault 1	Check external devices for faults. Check parameter 3003 EXTERNAL FAULT 1 setting.
0015	EXT FAULT 2 (9001) 0305 bit 14 (programmable fault function 3004)	External fault 2	Check external devices for faults. Check parameter 3004 EXTERNAL FAULT 2 setting.
0016	EARTH FAULT (2330) 0305 bit 15 (programmable fault function 3017)	Drive has detected a ground fault in motor or motor cable.	Check motor. Check fault function parameters. Check motor cable. Motor cable length must not exceed maximum specifications. See section <i>Motor connection data</i> on page 371.

CODE	FAULT	CAUSE	WHAT TO DO
0018	THERM FAIL (5210) 0306 bit 1	Drive internal fault. Thermistor used for drive internal temperature measurement is open or short-circuited.	Contact your local ABB representative.
0021	CURR MEAS (2211) 0306 bit 4	Drive internal fault. Current measurement is out of range.	Contact your local ABB representative.
0022	SUPPLY PHASE (3130) 0306 bit 5	Intermediate circuit DC voltage is oscillating due to missing input power line phase or blown fuse. Trip occurs when DC voltage ripple exceeds 14% of nominal DC voltage.	Check input power line fuses. Check for input power supply imbalance. Check fault function parameters.
0024	OVERSPEED (7310) 0306 bit 7	Motor is turning faster than highest allowed speed due to incorrectly set minimum/maximum speed. Operating range limits are set by parameters 2007 MINIMUM FO and 2008 MAXIMUM FO.	Check minimum/maximum frequency settings. Check adequacy of motor braking torque.
0026	DRIVE ID (5400) 0306 bit 9	Internal drive ID fault	Contact your local ABB representative.
0027	CONFIG FILE (630F) 0306 bit 10	Internal configuration file error	Contact your local ABB representative.
0028	SERIAL 1 ERR (7510) 0306 bit 11 (programmable fault function 3018, 3019)	Fieldbus communication break	Check status of fieldbus communication. See chapter <i>Fieldbus control</i> on page 267. Check fault function parameter settings. Check connections. Check if master can communicate.
0029	EFB CON FILE (6306) 0306 bit 12	Configuration file reading error	Contact your local ABB representative.
0030	FORCE TRIP (FF90) 0306 bit 13	Trip command received from fieldbus	See appropriate communication module manual.

CODE	FAULT	CAUSE	WHAT TO DO
0031	EFB 1 (FF92) 0307 bit 0	Error from the embedded fieldbus (EFB) protocol application. The meaning is protocol dependent.	See chapter <i>Fieldbus control</i> on page 267.
0032	EFB 2 (FF93) 0307 bit 1		
0033	EFB 3 (FF94) 0307 bit 2		
0034	MOTOR PHASE (FF56) 0306 bit 14	Motor circuit fault due to missing motor phase or motor thermistor relay (used in motor temperature measurement) fault.	Check motor and motor cable. Check motor thermistor relay (if used).
0035	OUTP WIRING (FF95) 0306 bit 15 (programmable fault function 3023)	Incorrect input power and motor cable connection (ie input power cable is connected to drive motor connection). The fault can be erroneously declared if the input power is a delta grounded system and the motor cable capacitance is large. This fault can be disabled using parameter 3023 WIRING FAULT.	Check input power connections. Check fault function parameters.
0036	INCOMPATIBLE SW (630F) 0307 bit 3	Loaded software is not compatible.	Contact your local ABB representative.
0038	USER LOAD CURVE (FF6B) 0307 bit 4	Condition defined by 3701 USER LOAD C MODE has been valid longer than the time set by 3703 USER LOAD C TIME.	See parameter <i>Group 37: User load curve</i> .
0039	UNKNOWN EXTENSION (7086) 0307 bit 5	Option module not supported by the drive firmware is connected to the drive.	Check connections.
0040	INLET VERY LOW (8A81) 0307 bit 6	Pressure at pump/fan inlet too low	Check for a closed valve on the inlet side of the pump/fan. Check piping for leaks. See parameter <i>Group 44: Pump protection</i> .

CODE	FAULT	CAUSE	WHAT TO DO
0041	OUTLET VERY HIGH (8A83) 0307 bit 7	Pressure at pump/fan outlet too high	Check piping for blocks. See parameter <i>Group 44: Pump protection</i> .
0042	INLET LOW (8A80) 0307 bit 8	Pressure at pump/fan inlet too low	Check for a closed valve on the inlet side of the pump/fan. Check piping for leaks. See parameter Group 44: Pump protection.
0043	OUTLET HIGH (8A82) 0307 bit 9	Pressure at pump/fan outlet too high	Check piping for blocks. See parameter <i>Group 44: Pump protection</i> .
0101	SERF CORRUPT (FF55) 0307 bit 14		
0103	SERF MACRO (FF55) 0307 bit 14		
0201	DSP T1 OVERLOAD (6100) 0307 bit 13		
0202	DSP T2 OVERLOAD (6100) 0307 bit 13	Drive internal error	Write down fault code and contact your local ABB representative.
0203	DSP T3 OVERLOAD (6100) 0307 bit 13		
0204	DSP STACK ERROR (6100) 0307 bit 12		
0206	CB ID ERROR (5000) 0307 bit 11		
1000	PAR HZRPM (6320) <i>0307</i> bit 15	Incorrect frequency limit parameter setting	Check parameter settings. Check that following applies: • 2007 MINIMUM FO < 2008 MAXIMUM FO • 2007 MINIMUM FO / 9907 MOTOR NOM FREQ and 2008 MAXIMUM FO / 9907 MOTOR NOM FREQ are within range.

CODE	FAULT	CAUSE	WHAT TO DO
1001	PAR PFC REF NEG (6320) 0307 bit 15	Incorrect PFA parameters	Check parameter <i>Group 81: PFA</i> control settings. Check that following applies: • 2007 MINIMUM FO > 0 when 8123 is ACTIVE or SPFC ACTIVE.
1003	PAR AI SCALE (6320) 0307 bit 15	Incorrect analog input Al signal scaling	Check parameter <i>Group 13: Analogue inputs</i> settings. Check that following applies: • 1301 MINIMUM AI1 < 1302 MAXIMUM AI1 • 1304 MINIMUM AI2 < 1305 MAXIMUM AI2.
1004	PAR AO SCALE (6320) 0307 bit 15	Incorrect analog output AO signal scaling	Check parameter <i>Group 15: Analogue outputs</i> settings. Check that following applies: • 1504 MINIMUM AO1 < 1505 MAXIMUM AO1.
1005	PAR PCU 2 (6320) 0307 bit 15	Incorrect motor nominal power setting	Check parameter 9909 setting. Following must apply: • 1.1 < (9906 MOTOR NOM CURR * 9905 MOTOR NOM VOLT * 1.73 / P _N) < 3.0 where P _N = 1000 * 9909 MOTOR NOM POWER (if units are in kW) or P _N = 746 * 9909 MOTOR NOM POWER (if units are in hp).
1006	PAR EXT RO (6320) 0307 bit 15	Incorrect extension relay output parameters.	Check parameter settings. Check that following applies: Relay Output Extension Module MREL-0 is connected to the drive. 14021403 RELAY OUTPUT 2RELAY OUTPUT 4 have non-zero values. See MREL-01 Relay Output Extension Module User's Manual (3AUA0000035974 [English]).
1007	PAR FBUSMISS (6320) 0307 bit 15	Fieldbus control has not been activated.	Check fieldbus parameter settings.
1009	PAR PCU 1 (6320) 0307 bit 15	Incorrect motor nominal speed/frequency setting	Check parameter settings. Following must apply: • 1 < (60 * 9907 MOTOR NOM FREQ! 9908 MOTOR NOM SPEED) < 16 • 0.8 < 9908 MOTOR NOM SPEED! (120 *9907 MOTOR NOM FREQ! Motor poles) < 0.992

CODE	FAULT	CAUSE	WHAT TO DO
1012	PAR PFA IO 1 (6320) 0307 bit 15	I/O configuration for PFA not complete	Check parameter settings. Following must apply: There are enough relays parameterized for PFA. No conflict exists between parameter Group 14: Relay outputs, parameter 8117 NR OF AUX MOT and parameter 8118 AUTOCHNG INTERV.
1013	PAR PFC IO 2 (6320) 0307 bit 15	I/O configuration for PFA not complete	Check parameter settings. Following must apply: • The actual number of PFA motors (parameter 8127 MOTORS) matches the PFA motors in parameter Group 14: Relay outputs and parameter 8118 AUTOCHNG INTERV.
1014	PAR PFC IO 3 (6320) 0307 bit 15	I/O configuration for PFA not complete. The drive is unable to allocate a digital input (interlock) for each PFA motor.	See parameters 8120 INTERLOCKS and 8127 MOTORS.
1015	PAR CUSTOM U/F (6320) 0307 bit 15	Incorrect voltage to frequency (U/f) ratio voltage setting.	Check parameter 2610 USER DEFINED U12617 USER DEFINED F4 settings.
1017	PAR SETUP 1 (6320) 0307 bit 15	It is not allowed to use frequency input signal and frequency output signal simultaneously.	Disable frequency output or frequency input: • change transistor output to digital mode (value of parameter 1804 TO MODE = DIGITAL), or • change frequency input selection to other value in parameters Group 11: Reference select, Group 40: Process PID set 1, Group 41: Process PID set 2 and Group 42: Ext / Trim PID.
1026	PAR USER LOAD C (6320) 0307 bit 15	Incorrect user load curve parameter setting	Check parameter settings. Following must apply: • 3704 LOAD FREQ 1 ≤ 3707 LOAD FREQ 2 ≤ 3710 LOAD FREQ 3 ≤ 3713 LOAD FREQ 4 ≤ 3716 LOAD FREQ 5 • 3705 LOAD TORQ LOW 1 < 3706 LOAD TORQ HIGH 1 • 3708 LOAD TORQ LOW 2 < 3709 LOAD TORQ HIGH 2 • 3711 LOAD TORQ LOW 3 < 3711 LOAD TORQ HIGH 3 • 3714 LOAD TORQ LOW 4 < 3715 LOAD TORQ HIGH 4 • 3717 LOAD TORQ LOW 5 < 3718 LOAD TORQ LOW 5 < 3718 LOAD TORQ HIGH 5.

Embedded fieldbus faults

Embedded fieldbus faults can be traced by monitoring group Group 53; EFB protocol parameters. See also fault/alarm SERIAL 1 ERR.

No master device

If there is no master device on line, parameter 5306 EFB OK MESSAGES and 5307 EFB CRC ERRORS values remain unchanged.

What to do:

- Check that the network master is connected and properly configured.
- · Check the cable connection.

Same device address

If two or more devices have the same address, parameter 5307 EFB CRC ERRORS value increases with every read/write command.

What to do:

· Check the device addresses. No two devices on line may have the same address.

Incorrect wiring

If the communication wires are swapped (terminal A on one device is connected to terminal B on another device), parameter 5306 EFB OK MESSAGES value remains unchanged and parameter 5307 EFB CRC ERRORS increases.

What to do:

Check the RS-232/485 interface connection.



Maintenance and hardware diagnostics

Contents of this chapter

The chapter contains preventive maintenance instructions and LED indicator descriptions.

Maintenance intervals

If installed in an appropriate environment, the drive requires very little maintenance. The table lists the routine maintenance intervals recommended by ABB Drives.

Maintenance	Interval	Instruction
Reforming of capacitors	Every year when stored	See Capacitors on page 360.
Check of dustiness, corrosion and temperature	Every year	
Replacement of the cooling fan (frame sizes R1R4)	Every three years	See Cooling fan on page 358.
Check and tightening of the power terminals	Every six years	See <i>Power connections</i> on page 360.
Replacement of the battery in the Assistant Control Panel	Every ten years	See Changing the battery in the Assistant control panel on page 360.

Consult your local ABB Service representative for more details on the maintenance. On the Internet, go to http://www.abb.com/drives and select Drive Services -Maintenance and Field Services.

Cooling fan

The life span of the drive's cooling fan depends on the drive usage and ambient temperature.

When the Assistant control panel is in use, the Notice Handler Assistant informs when the definable value of the operating hour counter is reached (see parameter 2901 COOLING FAN TRIG). This information can also be passed to the relay output (see parameter 1401 RELAY OUTPUT 1) regardless of the used panel type.


Fan failure can be predicted by the increasing noise from the fan bearings. If the drive is operated in a critical part of a process, fan replacement is recommended once these symptoms start appearing. Replacement fans are available from ABB Drives. Do not use other than ABB specified spare parts.


Replacing the cooling fan (frame sizes R1...R4)

Only frame sizes R1...R4 include a fan; frame size R0 has natural cooling.


WARNING! Obey the safety instructions. See chapter *Safety* on page 15. If you ignore the safety instructions, injury or death can occur. If you are not a qualified electrician, do not do electrical work.


- 1. Stop the drive and disconnect it from the power line. Wait for five minutes to let the drive DC capacitors discharge. Make sure that there is no voltage present. Measure by a multimeter (impedance at least 1 Mohm) the voltage between the input terminals and ground and the output terminals and ground.
- Remove the hood if the drive has the NEMA 1 option.
- 3. Lever the fan holder off the drive frame with, for example, a screwdriver.
- 4. Free the fan cable from the clip in the drive frame.
- 5. Lift the holder from the hinges.






6. Disconnect the fan cable. The figure below on the right shows the location of the fan cable connector in frame size R2. The inside views in different frame sizes are not identical, but the fan cable connector is always on the control board that is against the front of the drive.





- 7. Free the fan cable from the clip in the fan holder.
- 8. Remove the fan from the holder.



- 9. Install the new fan in reverse order.
- 10. Restore power.

Capacitors

Reforming the capacitors

The capacitors must be reformed if the drive has been stored for a year. See section Type designation label on page 26 for how to find out the manufacturing time from the serial number. For information on reforming the capacitors, refer to Guide for Capacitor Reforming in ACS50, ACS55, ACS150, ACS310, ACS320, ACS350, ACS550 and ACH550 (3AFE68735190 [English]), available on the Internet (go to http://www.abb.com and enter the code in the Search field).

Power connections

WARNING! Obey the safety instructions. See chapter Safety on page 15. If , you ignore the safety instructions, injury or death can occur. If you are not a qualified electrician, do not do electrical work.

- 1. Stop the drive and disconnect it from the power line. Wait for five minutes to let the drive DC capacitors discharge. Make sure that there is no voltage present. Measure by a multimeter (impedance at least 1 Mohm) the voltage between the input terminals and ground and the output terminals and ground.
- 2. Check the tightness of the power cable connections. Use the tightening torques given in section Terminal and lead-through data for the power cables on page 371.
- 3. Restore power.

Control panel

Cleaning the control panel

Use a soft damp cloth to clean the control panel. Avoid harsh cleaners which could scratch the display window.

Changing the battery in the Assistant control panel

A battery is only used in Assistant control panels that have the clock function available and enabled. The battery keeps the clock operating in memory during power interruptions.

The expected life for the battery is greater than ten years. To remove the battery, use a coin to rotate the battery holder on the back of the control panel. Replace the battery with type CR2032.

Note: The battery is NOT required for any control panel or drive functions, except the clock.

LEDs

There is a green and a red LED on the front of the drive. They are visible through the panel cover but invisible if a control panel is attached to the drive. The Assistant control panel has one LED. The table below describes the LED indications.

Where	LED off	LED lit	and steady	LED bli	nking
On the front of the drive.	No power	Green	Power supply on the board OK	Green	Drive in an alarm state
If a control panel is attached to the drive, switch to remote control (otherwise a fault will be generated), and then remove the panel to be able to see the LEDs.		Red	Drive in a fault state. To reset the fault, press RESET from the control panel or switch off the drive power.	Red	Drive in a fault state. To reset the fault, switch off the drive power.
At the top left corner of the	Panel has no power or no	Green	Drive in a normal state	Green	Drive in an alarm state
Assistant Control Panel	drive connection.	Red	Drive in a fault state. To reset the fault, press RESET from the control panel or switch off the drive power.	Red	-



Technical data

Contents of this chapter

The chapter contains the technical specifications of the drive, for example, ratings, sizes and technical requirements as well as provisions for fulfilling the requirements for CE and other marks.

Ratings, types and voltages (for North American market)

			Ratings	6		
	Inj	out		Output		
Type Code	Nominal without Reactor A	Nominal with 5% Reactor A	Continuous @ 50C, 10% Overload ¹⁾ A	Continuous @ 40C, 0% Overload A	Instantaneous Peak ²⁾ A	Frame Size
1-phase supply voltage	e 200 - 240 V	units (Conf	irm output rati	ngs meet moto	r requirements)	
ACS320-01U-02A4-2	6.1	N/A	2.3	2.4	4.0	R0
ACS320-01U-04A7-2	11.4	N/A	4.5	4.7	7.9	R1
ACS320-01U-06A7-2	16.1	N/A	6.5	6.7	11.4	R1
ACS320-01U-07A5-2	16.8	N/A	7.2	7.5	12.6	R2
ACS320-01U-09A8-2	21.0	N/A	9.4	9.8	16.5	R2
3-phase supply voltage	e 200 - 240 V	units				
ACS320-03U-02A6-2	4.7	2.6	2.4	2.6	4.2	R0
ACS320-03U-03A9-2	6.7	3.9	3.5	3.9	6.1	R0
ACS320-03U-05A2-2	8.4	5.2	4.7	5.2	8.2	R1
ACS320-03U-07A4-2	13.0	7.4	6.7	7.4	11.7	R1
ACS320-03U-08A3-2	13.2	8.3	7.5	8.3	13.1	R1
ACS320-03U-10A8-2	15.7	10.8	9.8	10.8	17.2	R2
ACS320-03U-14A6-2	23.9	14.6	13.3	14.6	23.3	R2
ACS320-03U-19A4-2	27.3	19.4	17.6	19.4	30.8	R2
ACS320-03U-26A8-2	45	26.8	24.4	26.8	42.7	R3
ACS320-03U-34A1-2	55	34.1	31.0	34.1	54.3	R4
ACS320-03U-50A8-2	76	50.8	46.2	50.8	80.9	R4
3-phase supply voltage	e 380 - 480 V	units				
ACS320-03U-01A2-4	2.2	1.2	1.1	1.2	2.1	R0
ACS320-03U-01A9-4	3.6	1.9	1.7	1.9	3.3	R0
ACS320-03U-02A4-4	4.1	2.4	2.2	2.4	4.2	R1
ACS320-03U-03A3-4	6.0	3.3	3.0	3.3	5.8	R1
ACS320-03U-04A1-4	6.9	4.1	3.7	4.1	7.2	R1
ACS320-03U-05A6-4	9.6	5.6	5.1	5.6	9.8	R1
ACS320-03U-07A3-4	11.6	7.3	6.6	7.3	12.8	R1
ACS320-03U-08A8-4	13.6	8.8	8.0	8.8	15.4	R1
ACS320-03U-12A5-4	18.8	12.5	11.4	12.5	21.9	R3
ACS320-03U-15A6-4	22.1	15.6	14.2	15.6	27.3	R3
ACS320-03U-23A1-4	30.9	23.1	21.0	23.1	40.4	R3
ACS320-03U-31A0-4	52.0	31.0	28.2	31	54.3	R4
ACS320-03U-38A0-4	61.0	38.0	34.5	38	66.5	R4
ACS320-03U-44A0-4	67.0	44.0	40.0	44	77.0	R4

Definition

R0...R4 ACS320 is manufactured in frame sizes R0...R4. Some instructions and other information that only concern certain frame sizes are marked with the symbol of the frame size (R0...R4)

Overloadability for one minute every ten minutes.
 Instantaneous peak current for two seconds every ten minutes.

Ratings, types and voltages (for European market)

Type	Input ²⁾	Input ²⁾ with 5% choke			Output			Frame size
ACS320-	I _{1N}	I _{1N}	I _{LD}	I _{2N}	I _{2max}	F	'n	
03E ¹⁾	Α	Α	Α	Α	Α	kW	hp	
3-phase U _N =	380480	V (380, 40	00, 415, 44	10, 460, 48	0 V) ³⁾			
03E-01A2-4	2.2	1.1	1.1	1.2	2.1	0.37	0.5	R0
03E-01A9-4	3.6	1.8	1.7	1.9	3.3	0.55	0.75	R0
03E-02A4-4	4.1	2.3	2.2	2.4	4.2	0.75	1	R1
03E-03A3-4	6.0	3.1	3.0	3.3	5.8	1.1	1.5	R1
03E-04A1-4	6.9	3.5	3.7	4.1	7.2	1.5	2	R1
03E-05A6-4	10	4.8	5.1	5.6	9.8	2.2	3	R1
03E-07A3-4	12	6.1	6.6	7.3	12.8	3	3	R1
03E-08A8-4	14	7.7	8.0	8.8	15.4	4	5	R1

00578903 xls J

Definitions

continuous rms input current (for dimensioning cables and fuses) at ambient I_{1N} temperature of +40 °C (104 °F).

continuous output current at max ambient temperature of +50 °C (122 °F). I_{LD} 10% overloadability for one minute every ten minutes.

maximum continuous output current at ambient temperature of +40 °C (104 °F). I_{2N} No overloadability, derating 1% for every additional 1 °C up to 50 °C (122 °F).

maximum instantaneous output current. Available for two seconds every ten lomay. minutes at start-up, or as long as allowed by the drive temperature.

 P_{N} typical motor power. The kilowatt ratings apply to most IEC 4-pole motors. The horsepower ratings apply to most NEMA 4-pole motors.

R0...R4 ACS320 is manufactured in frame sizes R0...R4. Some instructions and other information that only concern certain frame sizes are marked with the symbol of the frame size (R0...R4).

Sizing

The current ratings are the same regardless of the supply voltage within one voltage range. To achieve typical motor power, the rated current of the drive must be higher than or equal to the rated motor current.

Note 1: The maximum allowed motor shaft power is limited to 1.5 $\cdot P_N$ (where $P_N =$ typical motor power). If the limit is exceeded, motor torque and current are automatically restricted. The function protects the input bridge of the drive against overload.

Note 2: The ratings apply at ambient temperature of 40 °C (104 °F) for I_{2N} and 50 °C (122 °F) for I_{1D} .

In multimotor systems, the drive output current rating I_{1D} must be equal to or greater than the calculated sum of the input currents of all motors.

¹⁾ E = EMC filter connected (metal EMC filter screw installed)

²⁾ Input current depends on the supply network, line inductance and load motor. With 5% choke values can be met by ABB CHK-xx or typical 5% chokes.

Derating

The load capacity decreases if the installation site ambient temperature exceeds 40 °C (104 °F) or if the altitude exceeds 1000 meters (3300 ft).

Temperature derating

In the temperature range +40 °C...+50 °C (+104 °F...+122 °F), the rated output current is decreased by 1% for every additional 1 °C (1.8 °F). The output current is calculated by multiplying the current given in the rating table by the derating factor.

Example: If the ambient temperature is 50 °C (+122 °F), the derating factor is $100\% - 1 \frac{\%}{^{\circ}\text{C}} \cdot 10 ^{\circ}\text{C} = 90\%$ or 0.90. The output current is then $0.90 \cdot I_{2N}$ (where I_{2N} = continuous output at 40 °C, 0% overload)

Altitude derating

In altitudes 1000...2000 m (3300...6600 ft) above sea level, the derating is 1% for every 100 m (330 ft).

Switching frequency derating

Derate according to the switching frequency used (see parameter 2606 SWITCHING FREQ) as follows:

Switching		Drive voltage rating
frequency	<i>U</i> _N = 200240 V	U _N = 380480 V
4 kHz	No derating	No derating
8 kHz	Derate I _{2N} to 90%.	Derate I _{2N} to 75% for R0 or to 80% for R1R4.
12 kHz	Derate I _{2N} to 80%.	Derate $I_{\rm 2N}$ to 50% for R0 or to 65% for R1R4 and derate maximum ambient temperature to 30 °C (86 °F).
16 kHz	Derate I _{2N} to 75%.	Derate $I_{\rm 2N}$ to 50% and derate maximum ambient temperature to 30 °C (86 °F).

 I_{2N} = continuous output at 40 °C, 0% overload.

Power cable sizes and fuses

Cable dimensioning for rated input currents is shown in the table below together with the corresponding fuse types for short-circuit protection of the input power cable. The rated fuse currents given in the table are the maximal for the mentioned fuse types. If smaller fuse ratings are used, check that the fuse rms current rating is larger than the rated input current given in section Ratings, types and voltages (for North American market) on page 364 or in section Ratings, types and voltages (for European market) on page 365. If 150% output power is needed, multiply input current by 1.5. See also section Selecting the power cables on page 37.

Check that the operating time of the fuse is below 0.5 seconds. The operating time depends on the fuse type, the supply network impedance as well as the crosssectional area, material and length of the supply cable. In case the 0.5 seconds operating time is exceeded with the gG or T fuses, ultra rapid (aR) fuses will in most cases reduce the operating time to an acceptable level.

Notes:

- · Do not use larger fuses.
- · Choose the correct fuse size according to the actual input current which depends on the input line voltage and the input choke selection.
- Other fuse types can be used if they meet the ratings and the melting curve of the fuse does not exceed the melting curve of the fuse mentioned in this table.

	F	uses	Si	ze of copp	er cond	luctor in	cablin	gs
Type Code	gG	UL Class T or CC (600 V)	Supply (U1, V1, W2)			otor /2, W3)	PE	
	А	А	mm ²	AWG	mm ²	AWG	mm ²	AWG
1-phase supply voltage	e 200 - 240	V units						
ACS320-01U-02A4-2	10	10	2.5	14	0.75	18	2.5	14
ACS320-01U-04A7-2	16	20	2.5	14	0.75	18	2.5	14
ACS320-01U-06A7-2	16/20* ⁾	25	2.5	10	1.5	14	2.5	10
ACS320-01U-07A5-2	20/25*)	30	2.5	10	1.5	14	2.5	10
ACS320-01U-09A8-2	25/35* ⁾	35	6	10	2.5	12	6	10
3-phase supply voltage	e 200 - 240	V units						
ACS320-03U-02A6-2	10	10	2.5	14	1.5	14	2.5	14
ACS320-03U-03A9-2	10	10	2.5	14	1.5	14	2.5	14
ACS320-03U-05A2-2	10	15	2.5	14	1.5	14	2.5	14
ACS320-03U-07A4-2	16	15	2.5	12	1.5	14	2.5	12
ACS320-03U-08A3-2	16	15	2.5	12	1.5	14	2.5	12
ACS320-03U-10A8-2	16	20	2.5	12	2.5	12	2.5	12
ACS320-03U-14A6-2	25	30	6	10	6	10	6	10
ACS320-03U-19A4-2	25	35	6	10	6	10	6	10
ACS320-03U-26A8-2	63	60	10	8	10	8	10	8
ACS320-03U-34A1-2	80	80	16	6	16	6	16	6
ACS320-03U-50A8-2	100	100	25	2	25	2	16	4
3-phase supply voltage	e 380 - 480	V units						
ACS320-03U-01A2-4	10	10	2.5	14	1.5	14	2.5	14
ACS320-03U-01A9-4	10	10	2.5	14	1.5	14	2.5	14

	F	uses	Size of copper conductor in cablings						
Type Code	gG UL Class T or CC (600 V)		Supply (U1, V1, W2)			otor /2, W3)	PE		
	Α	Α	mm ²	AWG	mm ²	AWG	mm ²	AWG	
ACS320-03U-02A4-4	10	10	2.5	14	1.5	14	2.5	14	
ACS320-03U-03A3-4	10	10	2.5	12	1.5	14	2.5	12	
ACS320-03U-04A1-4	16	15	2.5	12	1.5	14	2.5	12	
ACS320-03U-05A6-4	16	15	2.5	12	1.5	14	2.5	12	
ACS320-03U-07A3-4	16	20	2.5	12	1.5	14	2.5	12	
ACS320-03U-08A8-4	20	25	2.5	12	2.5	12	2.5	12	
ACS320-03U-12A5-4	25	30	6	10	6	10	6	10	
ACS320-03U-15A6-4	35	35	6	8	6	8	6	8	
ACS320-03U-23A1-4	50	50	10	8	10	8	10	8	
ACS320-03U-31A0-4	80	80	16	6	16	6	16	6	
ACS320-03U-38A0-4	100	100	25	4	16	4	16	4	
ACS320-03U-44A0-4	100	100	25	4	25	4	16	4	

^{*)} If 150% output is needed use the larger fuse alternative.

Dimensions, weights and free space requirements

Dimensions and weights

Frame size		Dimensions and weights IP20 (cabinet) / UL open										
	Н	H1 H2 H3 W D Weight								ight		
	mm	in	mm	in	mm	in	mm	in	mm	in	kg	lb
R0	169	6.65	202	7.95	239	9.41	70	2.76	161	6.34	1.2	2.6
R1	169	6.65	202	7.95	239	9.41	70	2.76	161	6.34	1.4	3.1
R2	169	6.65	202	7.95	239	9.41	105	4.13	165	6.50	1.8	4.0
R3	169	6.65	202	7.95	236	9.29	169	6.65	169	6.65	2.9	6.4
R4	181	7.13	202	7.95	244	9.61	260	10.24	169	6.65	5.1	11.2

00578903.xls G

Frame size		Dimensions and weights IP20 / NEMA 1								
	H	14	H5		W		D		Weight	
	mm	in	mm	in	mm	in	mm	in	kg	lb
R0	257	10.12	280	11.02	70	2.76	169	6.65	1.6	3.5
R1	257	10.12	280	11.02	70	2.76	169	6.65	1.8	4.0
R2	257	10.12	282	11.10	105	4.13	169	6.65	2.2	4.9
R3	260	10.24	299	11.77	169	6.65	177	6.97	3.5	7.7
R4	270	10.63	320	12.60	260	10.24	177	6.97	5.7	12.6

00578903.xls G

Symbols

IP20 (cabinet) / UL open

height without fastenings and clamping plate

H2 height with fastenings, without clamping plate

Н3 height with fastenings and clamping plate

IP20 / NEMA 1

H4 height with fastenings and connection box

Н5 height with fastenings, connection box and hood

Free space requirements

Frame	Free space required									
size	Ab	ove	Ве	low	On the sides					
	mm	in	mm	in	mm	in				
R0R4	75	3	75	3	0	0				

Losses, cooling data and noise

Losses and cooling data

Frame size R0 has natural convection cooling. Frame sizes R1...R4 are provided with an internal fan. The air flow direction is from bottom to top.

The table below specifies the heat dissipation in the main circuit at nominal load and in the control circuit with minimum load (I/O and panel not in use) and maximum load (all digital inputs in the on state and the panel, fieldbus and fan in use). The total heat dissipation is the sum of the heat dissipation in the main and control circuits.

			Heat d	issipation					
Time Code	Main	circuit		Contro	Air	flow			
Type Code	Rated current		Min		Max				
	W	BTU/Hr	W	BTU/Hr	W	BTU/Hr	m ³ /h	ft ³ /min	
1-phase supply voltag	1-phase supply voltage 200 - 240 V units								
ACS320-01U-02A4-2	19	65	6.1	21	22.7	78	-	ı	
ACS320-01U-04A7-2	38	130	9.5	32	26.4	90	24	14	
ACS320-01U-06A7-2	60	205	9.5	32	26.4	90	24	14	
ACS320-01U-07A5-2	62	212	10.5	36	27.5	94	21	12	
ACS320-01U-09A8-2	83	283	10.5	36	27.5	94	21	12	
3-phase supply voltag	je 200 -	240 V uni	ts						
ACS320-03U-02A6-2	19	65	6.1	21	22.7	78	-	-	
ACS320-03U-03A9-2	31	106	6.1	21	22.7	78	-	-	
ACS320-03U-05A2-2	38	130	9.5	32	26.4	90	24	14	
ACS320-03U-07A4-2	60	205	9.5	32	26.4	90	24	14	
ACS320-03U-08A3-2	62	212	9.5	32	26.4	90	21	12	
ACS320-03U-10A8-2	83	283	10.5	36	27.5	94	21	12	
ACS320-03U-14A6-2	112	383	10.5	36	27.5	94	52	31	
ACS320-03U-19A4-2	152	519	10.5	36	27.5	94	52	31	
ACS320-03U-26A8-2	250	854	16.6	57	35.4	121	71	42	
ACS320-03U-34A1-2	270	922	33.4	114	57.8	197	96	57	

			Heat di	ssipation						
Type Code	Main	circuit		Contro	Air	flow				
Type Code	Rated current		Min		I	Max				
	W	BTU/Hr	W	BTU/Hr	W	BTU/Hr	m ³ /h	ft ³ /min		
ACS320-03U-50A8-2	430	1469	33.4	114	57.8	197	96	57		
3-phase supply voltag	3-phase supply voltage 380 - 480 V units									
ACS320-03U-01A2-4	11	38	6.6	23	24.4	83	-	-		
ACS320-03U-01A9-4	16	55	6.6	23	24.4	83	-	-		
ACS320-03U-02A4-4	21	72	9.8	33	28.7	98	13	8		
ACS320-03U-03A3-4	31	106	9.8	33	28.7	98	13	8		
ACS320-03U-04A1-4	40	137	9.8	33	28.7	98	13	8		
ACS320-03U-05A6-4	61	208	9.8	33	28.7	98	19	11		
ACS320-03U-07A3-4	74	253	14.1	48	32.7	112	24	14		
ACS320-03U-08A8-4	94	321	14.1	48	32.7	112	24	14		
ACS320-03U-12A5-4	130	444	12.0	41	31.2	107	52	31		
ACS320-03U-15A6-4	173	591	12.0	41	31.2	107	52	31		
ACS320-03U-23A1-4	266	908	16.6	57	35.4	121	71	42		
ACS320-03U-31A0-4	350	1195	33.4	114	57.8	197	96	57		
ACS320-03U-38A0-4	440	1503	33.4	114	57.8	197	96	57		
ACS320-03U-44A0-4	530	1810	33.4	114	57.8	197	96	57		

Noise

Frame	Noise level
size	dBA
R0	<30
R1	5062
R2	5062
R3	5062
R4	<62

Terminal and lead-through data for the power cables

Frame size	diame	cable ter for //A 1	U1, V1, W1, U2, V2, W2			PE				
	U1, V1, W1, U2, V2, W2		Max. terminal size flexible/rigid		Tightening torque		Max. clamp size solid or stranded		Tightening torque	
	mm	in	mm ²	AWG	N·m	lbf∙in	mm ²	AWG	N·m	lbf∙in
R0	16	0.63	4.0/6.0	10	0.8	7	25	3	1.2	11
R1	16	0.63	4.0/6.0	10	0.8	7	25	3	1.2	11
R2	16	0.63	4.0/6.0	10	0.8	7	25	3	1.2	11
R3	29	1.14	10.0/16.0	6	1.7	15	25	3	1.2	11
R4	35	1.38	25.0/35.0	2	2.5	22	25	3	1.2	11

Terminal and lead-through data for the control cables

Conductor size							Tightening	
Solid or	stranded		with ferrule astic sleeve	Stranded, v	torque			
Min/Max	Min/Max	Min/Max	Min/Max	Min/Max	Min/Max			
mm ²	AWG	mm ²	AWG	mm ²	AWG	N·m	lbf∙in	
0.14/1.5	26/16	0.25/1.5	23/16	0.25/1.5	23/16	0.4	3.5	

Electric power network specification

Voltage (U₁) 200/208/220/230/240 V AC 1-phase for 200 V AC drives 200/208/220/230/240 V AC 3-phase for 200 V AC drives 380/400/415/440/460/480 V AC 3-phase for 400 V AC drives

±10% variation from converter nominal voltage is allowed as default.

Short-circuit capacity Maximum allowed prospective short-circuit current at the input power connection as defined in IEC 60439-1 is 100 kA. The drive is suitable

for use in a circuit capable of delivering not more than 100 kA rms symmetrical amperes at the drive maximum rated voltage.

Frequency 50/60 Hz ± 5%, maximum rate of change 17%/s **Imbalance** Max. ±3% of nominal phase to phase input voltage

Motor connection data

Voltage (U2) 0 to U_1 , 3-phase symmetrical, U_{max} at the field weakening point

Short-circuit protection The motor output is short-circuit proof by IEC 61800-5-1 and UL 508C. (IEC 61800-5-1,

ÚL 508C)

Frequency 0...500 Hz Frequency resolution 0.01 Hz

Current See section Ratings, types and voltages (for North American market)

on page 364 or Ratings, types and voltages (for European market)

on page 365.

Power limit $1.5 \cdot P_{\rm N}$ Field weakening point

ig point 10...500 Hz

Switching frequency

4, 8, 12 or 16 kHz

Maximum recommended motor cable length

R0: 30 m (100 ft), R1...R4: 50 m (165 ft)

With output chokes the motor cable length may be extended to 60 m (195 ft) for R0 and 100 m (330 ft) for R1...R4.

To comply with the European EMC Directive, use the cable lengths specified in the table below for 4 kHz switching frequency. The lengths are given for using the drive with the internal EMC filter or an optional external EMC filter.

4 kHz switching frequency	Internal EMC filter	Optional external EMC filter		
Second environment (category C3 ¹⁾)	30 m (100 ft)	30 m (100 ft) minimum		
First environment (category C2 ¹⁾)	-	30 m (100 ft)		

¹⁾ See the new terms in section *Definitions* on page 376.

Control connection data

Analog inputs X1A: 2

and 5

Voltage signal, unipolar

bipolar Current signal. unipolar 0 (2)...10 V, R_{in} > 312 kohm -10...10 V, R_{in} > 312 kohm 0 (4)...20 mA, R_{in} = 100 ohm -20...20 mA, R_{in} = 100 ohm

bipolar Potentiometer reference

value (X1A: 4) Resolution

10 V ± 1%, max, 10 mA, R < 10 kohm

0.1% ±1%

vlagus

Analog output X1A: 7 Auxiliary voltage X1A: 9

Digital inputs X1A: 12...16

Voltage

(frequency input X1A:

Relay output X1B:

16)

17...19

Type

Accuracy

Frequency input

Input impedance

Tvpe Max. switching voltage

Max. switching current Max. continuous current

Digital output X1B: Tvpe Max. switching voltage Max. switching current

20...21

Accuracy RS-485 interface X1C:

23...26

Cable

Termination Isolation

Frequency Resolution

Transfer rate Communication type Protocol

0 (4)...20 mA. load < 500 ohm 24 V DC ± 10%, max, 200 mA 12...24 V DC with internal or external

PNP and NPN Pulse train 0...16 kHz (X1A: 16 only) 24 kohm

NO + NC 250 V AC / 30 V DC

0.5 A / 30 V DC; 5 A / 230 V AC 2 A rms

Transistor output PNP 30 V DC 100 mA / 30 V DC, short-circuit

protected . 10 Hz ...16 kHz

Shielded twisted pair, impedance

100...150 ohm Daisy chained bus without drop out

lines Bus interface isolated from the drive 1.2...76.8 kbit/s

Serial, asynchronous, half duplex

Modbus

1 Hz 0.2%

Clearance and creepage distance

The clearance and creepage distance between I/O connections and mains circuit is 5.5 mm, which guarantees safety insulation of overvoltage category 3 (IEC 60664-1).

Efficiency

Approximately 95 to 98% at nominal power level, depending on the drive size and options

Degrees of protection

IP20 (cabinet installation) / UL open: Standard enclosure. The drive must be installed in a cabinet to fulfil the requirements for shielding from contact.

IP20 / NEMA 1: Achieved with an option kit including a hood and a connection box.

Ambient conditions

Environmental limits for the drive are given below. The drive is to be used in a heated indoor controlled environment.

	used in a neated indoor controlled environment.					
	Operation installed for stationary use	Storage in the protective package	Transportation in the protective package			
Installation site altitude	0 to 2000 m (6600 ft) above sea level (above 1000 m [3300 ft], see section Derating on page 366)	-	-			
Air temperature	-10 to +50 °C (14 to 122 °F). No frost allowed. See section <i>Derating</i> on page 366.	-40 to +70 °C (-40 to +158 °F)	-40 to +70 °C (-40 to +158 °F)			
Relative humidity	0 to 95% Max. 95%		Max. 95%			
	No condensation allowed. Maximum allowed relative humidity is 60% in the presence of corrosive gases.					
Contamination levels	No conductive dust alle	owed.				
(IEC 60721-3-3, IEC 60721-3-2, IEC 60721-3-1)	According to IEC 60721-3-3, chemical gases: Class 3C2 solid particles: Class 3S2. The drive must be installed in clean air according to enclosure classification. Cooling air must be clean, free from corrosive materials and electrically conductive dust.	According to IEC 60721-3-1, chemical gases: Class 1C2 solid particles: Class 1S2	According to IEC 60721-3-2, chemical gases: Class 2C2 solid particles: Class 2S2			
Sinusoidal vibration (IEC 60721-3-3)	Tested according to IEC 60721-3-3, mechanical conditions: Class 3M4 29 Hz, 3.0 mm (0.12 in) 9200 Hz, 10 m/s² (33 ft/s²)	-	-			
Shock (IEC 60068-2-27, ISTA 1A)	Not allowed during operation.	According to ISTA 1A. Max. 100 m/s ² (330 ft/s ²), 11 ms.	According to ISTA 1A. Max. 100 m/s ² (330 ft/s ²), 11 ms.			
Free fall	Not allowed	76 cm (30 in)	76 cm (30 in)			
	l .	` '	` ′			

Materials

Drive enclosure

- PC/ABS 2 mm, PC+10%GF 2.5...3 mm and PA66+25%GF 1.5 mm, all in color NCS 1502-Y (RAL 9002 / PMS 420 C)
- hot-dip zinc coated steel sheet 1.5 mm, thickness of coating 20 micrometers
- extruded aluminium AlSi.

Package Disposal

Corrugated cardboard.

The drive contains raw materials that should be recycled to preserve energy and natural resources. The package materials are environmentally compatible and recyclable. All metal parts can be recycled. The plastic parts can either be recycled or burned under controlled circumstances, according to local regulations. Most recyclable parts are marked with recycling marks.

If recycling is not feasible, all parts excluding electrolytic capacitors and printed circuit boards can be landfilled. The DC capacitors contain electrolyte, which is classified as hazardous waste within the EU. They must be removed and handled according to local regulations.

For further information on environmental aspects and more detailed recycling instructions, please contact your local ABB distributor.

Applicable standards

The drive complies with the following standards:

IEC/EN 61800-5-1: 2003

Electrical, thermal and functional safety requirements for adjustable

frequency a.c. power drives

IEC/EN 60204-1:

2006

Safety of machinery. Electrical equipment of machines. Part 1: General requirements. Provision's for compliance: The final assembler of the machine is responsible for installing

- an emergency-stop device - a supply disconnecting device.

IEC/EN 61800-3: 2004

Adjustable speed electrical power drive systems. Part 3: EMC requirements and specific test methods

UL 508C UL Standard for Safety, Power Conversion Equipment, third edition

CE marking

The CE mark is attached to the drive to verify that the drive follows the provisions of the European Low Voltage and EMC Directives (Directive 73/23/EEC, as amended by 93/68/EEC, and Directive 2004/108/EC).

Compliance with the European EMC Directive

The EMC Directive defines the requirements for immunity and emissions of electrical equipment used within the European Union. The EMC product standard (EN 61800-3:2004) covers requirements stated for drives. See section *Compliance with EN 61800-3:2004* on page 376.

Compliance with EN 61800-3:2004

Definitions

EMC stands for **Electrom**agnetic **C**ompatibility. It is the ability of electrical/electronic equipment to operate without problems within an electromagnetic environment. Likewise, the equipment must not disturb or interfere with any other product or system within its locality.

First environment includes establishments connected to a low-voltage network which supplies buildings used for domestic purposes.

Second environment includes establishments connected to a network not directly supplying domestic premises.

Drive of category C2: drive of rated voltage less than 1000 V and intended to be installed and commissioned only by a professional when used in the first environment.

Note: A professional is a person or organization having necessary skills in installing and/or commissioning power drive systems, including their EMC aspects.

Category C2 has the same EMC emission limits as the earlier class first environment restricted distribution. EMC standard IEC/EN 61800-3 does not any more restrict the distribution of the drive, but the using, installation and commissioning are defined.

Drive of category C3: drive of rated voltage less than 1000 V, intended for use in the second environment and not intended for use in the first environment.

Category C3 has the same EMC emission limits as the earlier class second environment unrestricted distribution.

Category C2

The emission limits are complied with the following provisions:

 The optional EMC filter is selected according to the ABB documentation and installed as specified in the EMC filter manual.

- 2. The motor and control cables are selected as specified in this manual.
- 3. The drive is installed according to the instructions given in this manual.
- 4. Motor cable length maximum 30 m (100 ft) with 4 kHz switching frequency.

Note: In a domestic environment, this product may cause radio inference, in which case supplementary mitigation measures may be required.

Category C3

The immunity performance of the drive complies with the demands of IEC/EN 61800-3. second environment (see page 376 for IEC/EN 61800-3 definitions).

The emission limits are complied with the following provisions:

- 1. The internal EMC filter is connected (the metal screw at EMC is in place) or the optional EMC filter is installed.
- 2. The motor and control cables are selected as specified in this manual.
- 3. The drive is installed according to the instructions given in this manual.
- 4. With the internal EMC filter: motor cable length 30 m (100 ft) with 4 kHz switching frequency.

Notes:

- A drive of category C3 is not intended to be used on a low-voltage public network which supplies domestic premises. Radio frequency interference is expected if the drive is used on such a network.
- It is not allowed to install a drive with the internal EMC filter connected on IT. (ungrounded) systems. The supply network becomes connected to ground potential through the EMC filter capacitors which may cause danger or damage the drive.
- It is not allowed to install a drive with the internal EMC filter connected on a corner grounded TN system as this would damage the drive.

UL marking

See the type designation label for the valid markings of your drive.

The UL mark is attached to the drive to verify that it meets UL requirements.

UL checklist

Input power connection - See section Electric power network specification on page 371.

Disconnecting device (disconnecting means) - See Selecting the supply disconnecting device (disconnecting means) on page 36.

Ambient conditions – The drives are to be used in a heated indoor controlled environment. See section Ambient conditions on page 374 for specific limits.

Input cable fuses – For installation in the United States, branch circuit protection must be provided in accordance with the National Electrical Code (NEC) and any applicable local codes. To fulfill this requirement, use the UL classified fuses given in section Power cable sizes and fuses on page 367.

For installation in Canada, branch circuit protection must be provided in accordance with Canadian Electrical Code and any applicable provincial codes. To fulfill this requirement, use the UL classified fuses given in section Power cable sizes and fuses on page 367.

Power cable selection – See section Selecting the power cables on page 37.

Power cable connections - For the connection diagram and tightening torques, see section Connecting the power cables on page 47.

Overload protection – The drive provides overload protection in accordance with the National Electrical Code (US).



C-Tick marking

See the type designation label for the valid markings of your drive.

C-Tick marking is required in Australia and New Zealand. A C-Tick mark is attached to the drive to verify compliance with the relevant standard (IEC 61800-3:2004 -Adjustable speed electrical power drive systems – Part 3: EMC product standard including specific test methods), mandated by the Trans-Tasman Electromagnetic Compatibility Scheme.

The Trans-Tasman Electromagnetic Compatibility Scheme (EMCS) was introduced by the Australian Communication Authority (ACA) and the Radio Spectrum Management Group (RSM) of the New Zealand Ministry of Economic Development (NZMED) in November 2001. The aim of the scheme is to protect the radio frequency spectrum by introducing technical limits for emission from electrical/electronic products.

For fulfilling the requirements of the standard, see section Compliance with EN 61800-3:2004 on page 376.

RoHS marking

The RoHS mark is attached to the drive to verify that drive follows the provisions of the European RoHS Directive. RoHS = the restriction of the use of certain hazardous substances in electrical and electronic equipment.


Dimension drawings

Contents of this chapter

This chapter contains the dimension drawings of the ACS320. The dimensions are given in millimeters and [inches].

Frame sizes R0 and R1, IP20 (cabinet installation) / UL open

R1 and R0 are identical except for the fan at the top of R1.




Frame sizes R0 and R1, IP20 / NEMA 1


3AUA0000051086-A

Frame sizes R0 and R1, IP20 / NEMA 1

R1 and R0 are identical except for the fan at the top of R1.




Frame size R2, IP20 (cabinet installation) / UL open




Frame size R2, IP20 / NEMA 1

3AUA0000051097-A

Frame size R2, NEMA 1





Frame size R3, IP20 (cabinet installation) / UL open




Frame size R3, IP20 / NEMA 1


Frame size R3, NEMA 1








Frame size R4, IP20 (cabinet installation) / UL open



Frame size R4, IP20 / NEMA 1

Frame size R4, NEMA 1



Index

Numerics 0xxxx register EFB function codes 321 EFB mapping 320 1xxxx register EFB function codes 322 EFB mapping 321 3xxxx register EFB function codes 323 EFB mapping 322 4xxxx register EFB function codes 325 EFB mapping 323 Δ acceleration /deceleration, parameter group 183 at aux. stop (PFA), parameter 262 ramp select, parameter 183 ramp shape, parameter 184 ramp time (PFA), parameter 262 ramp zero select, parameter 185 time, parameter 183 activate (external PID), parameter 231 actual input (PID), parameters 222 actual max. (PID), parameters 223 actual min. (PID), parameters 223 actual signals, parameter group 144 actual values scaling, EFB comm 281

```
scaling, FLN fieldbus 297
air flow 358
alarm
   codes 345
   enable display, parameter 173
   listing 345
altitude
   environment limit 374
   shipping limit 374
altitude derating 366
analog cable
   requirements 40
analog I/O
   connections 49
   specifications 49
analog input
   BACnet object listing 310
   data parameter 140
   fault limit, parameters 195
   filter, parameters 162
   less than min. auto. reset, parameter 197
   less than min., fault parameter 191
   maximum, parameters 162
   minimum, parameters 162
   N2 object listing 287
   parameter group 162
   ref. correction formula 155
analog output
   BACnet object listing 311
   content max., parameters 167
   content min., parameters 167
   current max., parameters 167
   current min., parameters 167
   data content, parameters 167
   data parameter 140
```

```
filter, parameters 167
   N2 object listing 289
   parameter group 124, 166
application block output, data parameter 140
application macro, parameter 137, 139, 144, 148, 151, 152
applications
   see macros
autochange
   interval, parameter 253
   level, parameter 254
   overview 254
   starting order counter 255
automatic reset
   see reset, automatic
auxiliary motor
   see motor, auxiliary
В
backing up parameters (Assistant panel) 68
backup
   drive parameters 68
BACnet
   data link layer 314
   mac id 314
   max info frame property 314
   MS/TP token counter 314
   object, analog inputs 310
   object, analog outputs 311
   object, analog values 311
   object, binary inputs 307
   object, binary outputs 308
   object, binary values 308
   object, definitions 317
   pics, statement 315
   pics, summary 314
```

```
services supported 314
   support, matrix 317
battery, assistant control panel 360
   maintenance procedure 360
baud rate (RS232), parameter 241
binary input
   BACnet object listing 307
   N2 object listing 288
binary output
   BACnet object listing 308
   N2 object listing 290
branch circuit protection 36, 378
break point frequency, fault parameter 194
buffer overruns (count), parameter 241
C
cable requirements
   grounding 40, 49, 53
   input power 37
   motor 38
capacitor
   maintenance interval 357
   reforming 360
CE marking 376
CISPR11 class A
   radiation limits 376
CISPR11 class B
   radiation limits 377
clock 73
comm
   fault function, parameter 195
   fault time, parameter 195
   protocol select, parameter 263
   relay output word, data parameter 141
   values, data parameter 141
```

```
comm (EFB)
   actual value scaling 281
   actual values 280
   also see RS232 241
   analog output control, activate 278
   baud rate, parameter 242
   comm fault response 195, 279
   config file, fault code 350
   configuration 272
   configure for loss of communication 283
   control interface 25, 269
   control profile, parameter 243
   control word 326
   CRC errors (count), parameter 243
   diagnostics 282
   drive control of functions, activate 275
   exception codes 325
   fault code 28 283
   fault code 31 284
   fault code 32 284
   fault code 33 284
   fault codes 351
   fault tracing parameters 282
   fault, duplicate device address 355
   fault, duplicate stations 283
   fault, intermittent off-line 284
   fault, no master station on line 283, 355
   fault, swapped wires 283, 355
   feedback from drive 280
   feedback from drive, mailbox 281
   input ref. sel., activate 276
   installation 54, 270
   mailbox, param. read/write 281
   modbus actual values 325
   normal operation 282
```

```
ok messages (count), parameter 243
   overview 267
   parameter group 241
   parameters 243
   parity, parameter 242
   PID control setpoint source, activate 279
   planning 269
   profiles 319
   protocol id, parameter 242
   protocol, parameter group 242, 243
   reference scaling, ABB drives profile 335
   relay output control, activate 277
   set-up 272
   start/stop control, activate 275
   state diagram 334
   station id, parameter 242
   status word 330
   status, parameter 243
   termination 270
   UART errors (count), parameter 243
comm (FBA)
   comm fault response 195
confia file
   fault code 350
connections
   EFB comm 54, 270
constant speed
   see speed, constant
construction code 27
contamination levels
   environment limit 374
   shipping limit 374
contrast, control panel 58
control
   connection specifications 373
```

```
location, data parameter 139
control cable
   requirements 40
control panel
   backup, drive parameters 68
   cable requirements 40
   changed parameters mode 68
   clock set 73
   comm error, fault parameter 192
   contrast 58
   display contrast 58
   display decimal point (form), parameters 202
   display max., parameters 203
   display min., parameters 202
   display process variables, parameter group 201
   display selection, parameters 201
   display units, parameters 202
   features 57
   i/o settings mode 76
   maintenance interval, battery 357
   maintenance procedure 360
   modes 62
   operating the drive 64
   parameter editing 61
   parameter lock, parameter 168
   parameters mode 64
   pass code, parameter 168
   reference control, parameter 152
   signal max., parameters 201
   signal min., parameters 201, 206
   soft keys 58
   start-up assistant 60
   start-up assistant mode 66
   status information 63
control panel (Assistant)
```

```
fault logger mode 68
   parameter backup mode 68
control word
   comm (EFB), description 326
cooling 358
   fan maintenance triggers 190
cooling fan 358
correction source (PID), parameter 232
cover
   remove 53
CRC errors (count), parameter 242
critical speeds (avoiding)
   high, parameters 186
   low, parameters 186
   parameter group 186
   select, parameter 186
C-Tick marking 378
current
   at fault, history parameter 148
   data parameter 139
   max. limit, parameter 180
   measurement, fault code 350
   rating code 27
DC brake time, parameter 182
DC bus voltage, data parameter 139
DC current ref., parameter 182
DC magnetizing time, parameter 182
DC overvoltage, fault code 341, 348
DC stabilator, parameter 189
```

DC undervoltage, fault code 341, 348

DDL file (N2) 290 deceleration

battery maintenance procedure 360

```
at aux. start (PFA), parameter 262
   emergency time, parameter 184
   parameter group 183
   ramp select, parameter 183
   ramp shape, parameter 184
   ramp time (PFA), parameter 262
   ramp zero select, parameter 185
   time, parameter 184
default macro 79
derating
   altitude 366
   switching frequency 366
   temperature 366
derivation time (PID), parameter 217
device overtemperature, fault code 348
device type (N2) 287
diagnostics
   EFB comm 282
differences list, downloads 72
digital cable
   requirements 40
digital input
   at fault, history parameters 149
   connections 49
digital output
   connections 49
   specifications 373
direction
   control, parameter 151
display format (PID), parameter 218, 233
download
   failure 73
   handling inexact transfers 72
   parameter sets 70
drive
```

```
control terminal 49
   device type (N2) 287
   EFB comm installation 54, 270
   fan replacement 358
   id. fault code 350
   identification 27
   rating, parameter 200
   temperature, data parameter 139
   weight 368
drive input protection 42
drive on time, data parameters 141
Ε
earth fault
   fault code 349
   parameter 195
earthing
   see ground
efficiency 373
embedded field bus
   see comm (EFB)
EMC
   CE marking 376
   C-Tick marking 378
   motor cable requirements 37
emergency
   deceleration time, parameter 184
   stop select, parameter 182
EN 61800-3 first environment
   restricted distribution radiation limits 376
   unrestricted distribution radiation limits 377
enclosure protection class code 27
energy savings group 238
environment
   first, definition 376
```

```
second, definition 376
error value inversion (PID), parameter 218
exception codes, EFB modbus 325
external commands selection, parameter 149
external control selection, parameter 152
external fault
   automatic reset, parameter 197
   parameters 192
external reference, data parameter 139
F
fan, drive module
   maintenance interval 357
   replacement procedure 358
fault
   codes 348
   comm (FBA) 195
   comm failure (EFB) 195, 279
   current at, history parameter 148
   digital input status at, history parameter 149
   frequency at, history parameter 148
   functions, parameter group 191
   history 340
   history, parameter group 148
   last, history parameter 148
   listing 348
   previous, history parameter 148
   reset 54, 339
   reset select, parameter 169
   speed at, history parameter 148
   status at, history parameter 148
   time of, history parameters 148
   torque at, history parameter 148
   voltage at, history parameter 148
   words, data parameters 146
```

```
fault code
   28 serial 1 err 283
fault history 340
fault logging (Assistant panel) 68
features
   N2 fieldbus 285
feedback multiplier (PID), parameter 222
feedback select (PID), parameter 221
fieldbus
   command words, data parameters 144
   status words, data parameters 145
firmware test date, parameter 200
firmware version, parameter 200
first environment, definition 376
FlashDrop
   parameter view, parameter 173
FLN fieldbus
   also see comm (EFB)
   description 293
   loop gains 298
   point database 299
   point descriptions 302
   reports 293
   supported features 293
force trip, fault code 350
frame errors (count), parameter 241, 243
frame size 369
free fall
   stress testing 374
free space
   for cooling 358
freq in & tran out 177
frequency
   at fault, history parameter 148
   max. limit, parameter 180
```

```
min. limit, parameter 180
   motor, resolution 371
   motor, specification 371
   switching, parameter 188
fuses 367
G
gain (PID), parameter 216
generic profile
   actual value scaling 281
   reference scaling 335
ground
   cable/wire requirements 40, 49, 53
Н
heat loss 358
incomp swtype, fault code 351
information
   parameter group 200
input power
   branch circuit protection 36, 378
   cable/wire requirements 37
   fuses 367
   specifications 371
input power connection 47
   terminal size 371
   torque 371
installation
   compatibility 36
   environment 374
   flow chart 22
   location 29
   tools 30
insulation
```

```
check 46
integration time (PID), parameter 217, 231
interlocks
   parameter 256
internal setpoint (PID), parameter 220
IR compensation
   frequency, parameter 187
   parameters 187
   voltage, parameter 187
K
keypad reference select, parameter 152
kWh counter, data parameter 140
L
language, parameter 137
limits, parameter group 180
load analyzer group 243
load frequency, see user load curve
load package version, parameter 200
load torque, see user load curve
local mode
   lock, parameter 171
low frequency (PFA), parameters 249
М
macros
   booster pump 84
   condenser 83
   cooling tower fan 82
   dual setpoint w/ PID 89
   dual setpoint w/ PID & const. speeds 90
   floating point 88
   hand control 92
   HVAC default 79
   internal timer 86
```

```
internal timer w/constant speeds 87
   listing 78
   return fan 81
   supply fan 80
   to select 78
mailbox. EFB comm 281
mains
   see input power
maintenance
   capacitors 360
   control panel 360
   drive module fan 358
   fan 358
   intervals 357
   triggers, parameter group 190
mapping
   EFB modbus 319
materials 375
maximum
   frequency, parameter 180
metasys
   connection diagram (companion) 287
   connection diagram (system) 286
   integration 286
minimum
   frequency, parameter 180
modbus
   EFB addressing, convention 320
   EFB coils 320
   EFB discrete inputs 321
   EFB holding registers 323
   EFB input registers 322
   EFB mapping details 320
   EFB mapping summary 319
   EFB supported features 318
```

```
motor
   aux. start delay (PFA), parameter 250
   aux. stop delay (PFA), parameter 250
   checking insulation 46
   compatibility 36
   connection specifications 371
   load curve break point frequency 194
   load curve max., fault parameter 193
   load curve zero speed load 193
   maintenance triggers 190
   nominal current, parameter 138
   nominal frequency, parameter 138
   nominal power, parameter 138
   nominal speed, parameter 138
   nominal voltage, parameter 138
   number of aux., parameter 250, 251
   phase, fault code 351
   stall, fault code 349
   temperature alarm limit, parameter 206
   temperature fault limit, parameter 206
   temperature measure, parameter group 205
   temperature sensor selection, parameter 206
   temperature sensor type, parameter 205
   temperature, data parameter 141
   thermal protection, fault parameter 192
   thermal time, fault parameter 193
motor cable
   checking insulation 46
   max. length 372
   requirements 38
   requirements, EMC 37
motor connection
   terminal size 371
   torque 371
motor control
```

```
IR compensation, parameters 187
   parameter group 187
motor temperature
   measure, parameter group 124
   overtemperature, fault code 349
motor, auxiliary
   actual signals and parameters 246
   aux start order, parameter 263
MWh counter, data parameter 141
Ν
N2 fieldbus
   also see comm (EFB)
   description 284
   node limit 287
   supported features 285
NCU
   see network control unit
NEMA 1
   see UL type 1
NEMA 12
   see UL type 12
network control unit
   description 284
   N2 DDL file 290
noise
   random sw. freq. parameter 189
NPN 50
O
object
   virtual, description 285
offset (PID), parameter 231
ok messages (count), parameter 241
operating data, parameter group 139
```

```
options, parameter group 263
output frequency, data parameter 139
output voltage, data parameter 139
output wiring
   fault code 351
overcurrent
   automatic reset, parameter 196
   fault code 348
overspeed, fault code 350
P
panel display variables, parameter group 201
panel loss, fault code 349
parameter
   analog input scale, fault code 353
   analog output scale, fault code 353
   change lock 168
   external relay output, fault code 353
   fieldbus, fault code 353
   hz rpm, fault code 352
   PCU 1 (power control unit), fault code 354
   PCU 2 (power control unit), fault code 353
   PFC mode, fault code 175
   PFC ref. neg., fault code 353
   restore (Assistant panel) 68
   save changes, parameter 171
parameter view, parameter 173
parameters
   editing 61
   view changes 68
parity (RS232), parameter 241
parity errors (count), parameter 241
PE earth
   earth fault, parameter 195
PE earth connection
```

```
terminal size 371
   torque 371
PFA
   acceleration time, parameter 262
   aux start order, parameter 263
   aux. motor start delay, parameter 250
   aux. motor stop delay, parameter 250
   control, parameter group 246
   deceleration time, parameter 262
   enable, parameter 261
   low frequency, parameters 249
   number of aux. motors, parameter 250, 251
   reference step, parameters 247
   start delay, parameter 260
   start frequency, parameters 248
PFC (pump fan control)
   see PFA (pump fan alternation)
PID
   0% (actual signal), parameter 218
   100% (actual signal), parameter 218
   actual input select, parameters 222
   actual value max., parameters 223
   actual value min., parameters 223
   adjustment procedure 216
   comm value 1, data parameter 141
   comm value 2, data parameter 142
   correction source, parameter 232
   decimal point (actual signal), parameter 218, 233
   derivation filter, parameter 217
   derivation time, parameter 217
   error feedback inversion, parameter 218
   external / trimming, parameter group 230, 233, 238
   external source activate, parameter 231
   feedback multiplier, parameter 222
   feedback select, parameter 221
```

```
feedback, data parameter 140
   gain, parameter 216
   integration time, parameter 217, 231
   internal setpoint, parameter 220
   offset, parameter 231
   output, data parameter 140
   parameter set select, parameter 227
   process sets, parameter groups 118, 213
   scaling (0%...100%), parameters 218
   setpoint maximum, parameter 221
   setpoint minimum, parameter 221
   setpoint select, parameter 219
   setpoint source, EFB comm activate 279
   setpoint, data parameter 140
   sleep delay, parameter 225, 226
   sleep level, parameter 225
   sleep selection, parameter 224
   trim mode, parameter 231
   trim scale, parameter 231
   units (actual signal), parameter 218
   wake-up delay, parameter 226
   wake-up deviation, parameter 226
PID controller
   advanced set-up 214
   basic set-up 118, 213
planning
   EFB comm 269
PNP 50
power
   data parameter 139
   first applied 60
previous faults, history parameters 148
process PID sets, parameter groups 118, 213
process variables, data parameter 141
profiles
```

```
abb drives, overview 326
   comm (EFB) 319
   dcu, overview 326
protection
   branch circuit 36, 378
   enclosure standard 374
   environmental 373
protocol
   BACnet, technical data 307
protocol implementation conformance statement
    see BACnet, pics
PT100 temperature sensor 205
PTC temperature sensor 205
pump cleaning group 239
pump protection group 233
R
radiation limits, conducted
   EN 61800-3 376
ramp pair (accel/decel), parameter 183
ratings 364
reference
   analog input corrections 155
   corrections for parameter values 155
   keypad control, parameter 152
   maximum, parameters 156
   minimum, parameters 156
   select source, parameter 153
   select, parameter group 151
reference scaling
   EFB, ABB drives profile 335
reference step (PFA), parameters 247
regulator by-pass control, parameter 259
relative humidity
   environment limit 374
```

```
shipping limit 374
relay output
   activation condition parameters 163
   off-delay, parameters 166
   on-delay, parameters 165
   parameter group 163
relays, specifications 373
remove cover 53
reports, FLN fieldbus 293
reset, automatic
   analog input less than min., parameter 197
   delay time, parameter 196
   external fault, parameter 197
   number of trials, parameter 196
   overcurrent, parameter 196
   parameter group
   trial time, parameter 196
   undervoltage, parameter 197
resonance (avoiding)
   select, parameter 186
revolution counter, data parameter 141
RoHS marking 378
RS232
   baud rate, parameter 241
   panel, parameter group 241
   parity, parameter 241
   station id, parameter 241
RS232 counts
   buffer overruns, parameter 241
   CRC errors, parameter 242
   frame errors, parameter 241, 243
   ok messages, parameter 241
   parity errors, parameter 241
RS485 comm 270
run enable
```

```
source select, parameter 168
run time, data parameter 139
safety 15
scaling
   actual values. EFB comm 281
   FLN actual values 297
   reference (EFB, ABB drives profile) 335
s-curve ramp, parameter 184
sensor type, parameter 205
serial 1 error (fault code 28) 283
serial 1 error, fault code 350
setpoint maximum (PID), parameter 221
setpoint minimum (PID), parameter 221
setpoint select (PID), parameter 219
shock
   stress testing 374
short circuit, fault code 348
sleep selection (PID), parameter 224
slip compensation ratio, parameter 188
soft keys, control panel 58
specifications
   control connections 373
   cooling 358
   input power 371
   mains 371
   motor connections 371
speed
   at fault, history parameter 148
   data parameter 139
speed, constant
   digital input selection parameter 158
   parameter 160
   parameter group 124, 157
```

```
stall
   frequency, fault parameter 194
   function, fault parameter 194
   region 194
   time, fault parameter 194, 195
standards
   CE marking 376
   C-Tick marking 378
   EN 61800-3 376
   ICE/EN 60204-1 375
   IEC/EN 61800-3 375
   IEC/EN 61800-5-1 375
   UL 508C 375
   UL marking 377
start
   aux. motor (PFA), parameters 248
   aux. motor delay 250
   control, EFB comm 275
   DC magnetizing time, parameter 182
   delay (PFA), parameter 260
   frequency (PFA), parameters 248
   function, parameter 181
   inhibit, parameter 182
   parameter group 181
   torque boost current, parameter 183
start delay, parameter 183
start mode
   automatic 181
   automatic torque boost 181
   DC magnetizing 181
   flying start 181
start/stop, parameter group 181
start/stop/dir, parameter group 149
starting order counter 255
start-up
```

```
macros 58
   tuning 58
start-up assistant 60
start-up data, parameter group 137
state diagram
   ABB drives 334
   comm (EFB) 334
station id (RS232), parameter 241
status at fault, history parameter 148
status word
   comm (EFB), definition 330
stop
   aux. motor (PFA), parameters 249
   aux. motor delay 250
   DC brake time, parameter 182
   DC current ref., parameter 182
   emergency select, parameter 182
   function, parameter 181
   parameter group 181
stop function 135
   emergency 182
   motor 181
supervision
   parameter group 198
   parameter low limit, parameters 199
   parameter selection, parameters 198
supply phase, fault code 350
switching frequency control, parameter 188
switching frequency derating 366
switching frequency, parameter 188
system controls, parameter group 168
```

temperature derating 366

termination 270

```
test date, parameter 200
thermal fail, fault code 350
timer functions
   parameter group 124
timers
   boost 210
   enable 208
   parameter group 206
   source 211
   start/stop time 208, 212, 241, 242, 247
tools 30
torque
   at fault, history parameter 148
   boost current, parameter 183
   data parameter 139
trim mode (PID), parameter 231
trim scale (PID), parameter 231
U
U/f ratio, parameter 187
UL type 1
   code 27
   description 373
UL type 12
   code 27
   description 373
undervoltage
   automatic reset, parameter 197
   control enable, parameter 180
units (PID), parameter 218
user load curve
   frequency, parameters 212, 213
   function, parameter 212
   mode, parameter 212
   time, parameter 212
```

```
torque, parameters 212, 213
user parameter set
   change control, parameter 170
V
vibration
   stress testing 374
virtual object, N2 285
VND 287
voltage
   at fault, history parameter 148
   rating code 27
voltage/frequency ratio, parameter 187
W
wake-up delay (PID), parameter 226
wake-up deviation (PID), parameter 226
warning
   automatic start up 17
   dangerous voltages 16
   high temperatures 42
   listing 15
   qualified installer 16
weight 368
wiring
   fault, parameter 196
   installation 41
   requirements 35
Ζ
```

zero speed load, fault parameter 193

Further information

Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to www.abb.com/searchchannels.

Product training

For information on ABB product training, navigate to www.abb.com/drives and select Training courses.

Providing feedback on ABB Drives manuals

Your comments on our manuals are welcome. Go to <u>www.abb.com/drives</u> and select *Document Library – Manuals feedback form (LV AC drives*).

Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet. Go to www.abb.com/drives and select *Document Library*. You can browse the library or enter selection criteria, for example a document code, in the search field.

Contact us

www.abb.com/drives www.abb.com/drivespartners

3AUA0000062599 Rev D (EN) EFFECTIVE: 2014-06-30



3AUA0000062599D