

 **HONDA**

1982

Owner's Manual



ATC110

**HONDA ATC110
OWNER'S MANUAL**

1982



All information in this publication is based on the latest product information available at the time of approval for printing. HONDA MOTOR CO., LTD. reserves the right to make changes at any time without notice and without incurring any obligation.

No part of this publication may be reproduced without written permission.

////////////////////////////////////// PREFACE //

This booklet is your guide to the basic operation and proper maintenance of your new Honda ATC110. Please take the time to read it carefully. Details necessary for riding the Honda ATC are given to acquaint the new owner with special riding techniques to be learned. When service is required, remember that your Honda dealer knows your vehicle best. If you have the required mechanical "know-how" and tools, your dealer can supply you with an official Honda Shop Manual to help you perform many maintenance and repair tasks.

Thank you for selecting a Honda. We wish you continued riding pleasure in the miles ahead.

CONTENTS

	Page		Page
ATC SAFETY	1	Clutch	41
DESCRIPTION	2	Brakes	42
Parts Location	2	Throttle Cable	43
Serial Numbers	4	Drive Chain	44
Parts Function	5	Cam Chain	45
Fuel	10	Spark Arrester	46
Engine Oil	12	STORAGE	47
Tires	14	TRANSPORTING	48
OPERATION	16	OPTIONAL PARTS	51
Pre-ride Inspection	16	SPECIFICATIONS	52
Starting the Engine	17	WIRING DIAGRAM	53
Break-in	19		
Riding :	20		
Parking	28		
MAINTENANCE	29		
Maintenance Schedule	29		
Tool Kit	31		
Engine Oil	32		
Fuel Strainer	33		
Carburetor	34		
High Altitude	35		
Spark Plug	37		
Air Cleaner	38		
Valves	39		

WARNING

- * *ATC riding requires special efforts on your part to ensure your safety. Know these requirements before you ride.*

SAFE RIDING RULES

- * Always make a pre-ride inspection (page 16) before you start the engine. You may prevent an accident or equipment damage.
- * Always obey local off-road riding laws and regulations.
- * Obtain permission to ride on private property. Avoid posted areas and obey “no trespassing” signs.
- * Know the terrain on which you are riding. If you are not familiar with the terrain, ride cautiously. Hidden rocks, holes or ravines could spell disaster.
- * Your ability to operate safely is largely dependent upon your proper judgement in operating the machine.
- * Do not use the flag pole bracket as a trailer hitch.

PROTECTIVE APPAREL

- * Most cycle accident fatalities are due to head injuries; ALWAYS wear a helmet. You should also wear a face shield or goggles, boots, gloves and protective clothing.
- * The exhaust system becomes very hot during operation and it remains hot after operation. Never touch any part of the hot exhaust system. Wear clothing that fully covers your legs.


MODIFICATIONS

- * Modification of the ATC, or removal of original equipment may render the vehicle unsafe or illegal.
- * Spark arresters and mufflers are required in most areas. Don't modify your exhaust system. Remember that excessive noise bothers everyone and creates a bad image for motorcycling.


DESCRIPTION

PARTS LOCATION

- (1) Fuel tank cap
- (2) Throttle lever
- (3) Headlight switch
- (4) Ignition switch
- (5) Oil filler cap
- (6) Foot peg
- (7) Brake pedal



- (8) Fuel valve
- (9) Choke lever
- (10) Recoil starter
- (11) Neutral indicator
- (12) Gear change pedal
- (13) Posi-torque speed range selector



SERIAL NUMBERS

The frame and engine serial numbers are required by your dealer when ordering replacement parts. Record the numbers here for your reference.


FRAME NO. _____

ENGINE NO. _____

The frame serial number (1) is stamped on the left of the steering head. The engine serial number (2) is stamped on the crankcase just above the left foot peg.



(1) Frame serial number




(2) Engine serial number

PARTS FUNCTION

Ignition Switch

The three position ignition switch (1) is on the left handlebar grip. At RUN, the engine will operate. In either OFF position the engine will not operate.




(1) Ignition switch

Headlight Switch

The headlight switch (2) is under the ignition switch. Its operating positions are as follows:


Position	Function
OFF	Headlight is off.
LO	Headlight is on low beam.
HI	Headlight is on high beam.



(2) Headlight switch

Throttle Lever

The throttle lever (1) is next to the right handlebar grip and is operated by the rider's thumb. Pressing the lever forward opens the throttle. When the lever is released, spring tension closes the throttle automatically.



(1) Throttle lever


Brake Lever/Parking Brake

The brake lever (1) and the brake pedal both operate the rear wheel brake. Either one can be used to stop the ATC. There is no brake at the front wheel. The brake lever has the added feature of a lock (2) which allows the lever to be used as a parking brake.

Pull the brake lever back and lock it with the lock. Always apply the parking brake when parking on a hill or when leaving the engine running.

NOTE:

- * Use of the parking brake in freezing weather may cause the brakes to freeze in the locked position.




(1) Brake lever/Parking brake (2) Lock


Gear Change Pedal

The gear change pedal (1) is near the left foot peg. One full stroke of the gear change pedal will shift the transmission. The pedal automatically returns to the horizontal position when released. Each stroke of the pedal engages the next gear in sequence.

Depress the pedal to shift to a higher gear and raise the pedal to downshift.



(1) Gear change pedal



(1) Shifting sequence

Posi-Torque Speed Range Selector

The ATC110 is equipped with the Honda Posi-Torque transmission which augments the four forward gears with two final drive ratios so that there are eight different forward speeds available.


The speed range selector lever (1) for the sub-transmission is located on the left-crankcase cover to the rear of the recoil starter housing.

Moving the lever to L engages the low range, and moving the lever to H engages the high range. Select the low range for low speed riding conditions where greater power is needed, as when climbing hills or traveling over difficult terrain. Select the high range for higher speed riding conditions where greater pulling power is not required.

The speed range selector lever may be moved while the engine is idling, though it is recommended that the engine be stopped first. If necessary, roll the ATC110 forward to engage the sub-transmission gears.

CAUTION:

- * *Do not move the selector lever while riding, or damage to the sub-transmission may result.*




(1) Speed range selector lever

Neutral Indicator

The neutral indicator (1) is on the left crankcase cover, just behind the recoil starter. This feature enables the rider to verify that the transmission is in neutral before starting the engine.

The indicator rotates as the gears are changed. When the indicator aligns with the N mark on the crankcase, the transmission is in neutral.




(1) Neutral indicator

Choke Lever

The choke lever (1) is on the left side of the carburetor.

Raising the choke lever will close the choke valve. When the lever is raised, the carburetor will deliver a rich fuel mixture for starting the engine when cold. Lower the lever to open the choke valve as the engine attains normal operating temperature.



(1) Choke lever

FUEL

Fuel Valve

The three way fuel valve (1) is on the left side of the carburetor.

OFF

At OFF , fuel cannot flow from the tank to the carburetor. Turn the valve off whenever the ATC is not in use.

ON


At ON , fuel will flow from the main fuel supply to the carburetor.

RES

At RES , fuel will flow from the reserve fuel supply to the carburetor. Use the reserve fuel only when the main supply is gone. Refill the tank as soon as possible after switching to RES . The reserve fuel supply is 0.54ℓ (0.14 US gal).

NOTE:

- * Do not operate the machine with the fuel valve in the “RES” position after refueling. You may run out of fuel, with no reserve.



(1) Fuel valve

Fuel Tank

Fuel tank capacity is 7.2ℓ (1.9 US gal) including 0.54ℓ (0.14 US gal) in the reserve supply. Remove the fuel tank cap (1) by twisting counterclockwise.

Any automotive gasoline with a pump octane number ($\frac{R+M}{2}$) of 86 or higher, or research octane number of 91 or higher may be used.

If knocking or pinging occurs, try a different brand of gasoline or a higher octane grade.


The fuel tank cap (1) has a lever (2) with ON and OFF positions to open or close the tank vent. The lever should be turned to ON to allow fuel to flow when running the engine.

Turning the lever to OFF will prevent fuel from flowing out the vent hole when transporting the ATC.

WARNING

- * Gasoline is extremely flammable and is explosive under certain conditions. Refuel in a well ventilated area with the engine stopped. Do not smoke or allow open flames or sparks in the area where the vehicle is refueled or where gasoline is stored.*

- * Do not overfill the tank (there should be no fuel in the filler neck). After refueling, make sure the filler cap is closed securely.*
- * Avoid repeated or prolonged contact with skin or breathing of vapor. KEEP OUT OF REACH OF CHILDREN.*



(1) Fuel filler cap

(2) Cap lever

ENGINE OIL

Engine Oil Level Check

Check engine oil level each day before operating the ATC.

The oil filler cap (1) is on the right crankcase cover and contains a dipstick for measuring the oil level. The oil level must be maintained between the upper (2) and lower (3) level marks on the dipstick.

1. Unlatch and raise the seat for better access to the oil filler cap.



- (1) Oil filler cap/dipstick (3) Lower level mark
(2) Upper level mark

2. With the machine on level ground, remove the oil filler cap/dipstick and wipe it clean.
3. Reinsert the dipstick without screwing it in and check the oil level.
4. Add the specified oil up to the upper level mark, if required.
5. Replace the filler cap/dipstick.

CAUTION:

* *Running the engine with insufficient oil can cause serious engine damage.*



- (4) Seat latch

Engine Oil Recommendation

USE HONDA 4-STROKE OIL OR AN EQUIVALENT.

Use only high detergent, premium quality motor oil certified to meet or exceed US automobile manufacturer's requirements for Service Classification SE or SF.


Motor oils intended for Service SE or SF will show this designation on the container. The use of special oil additives is unnecessary and will only increase operating expenses.

CAUTION:

* *Engine oil is a major factor affecting the performance and service life of the engine. Non-detergent, vegetable, or castor based racing oils, are not recommended.*

Recommended oil viscosity:
SAE 10W-40

Other viscosities shown in the chart below may be used when the average temperature in your riding area is within the indicated range.



TIRES

The ATC110 is equipped with 22x11-8 low pressure tubeless tires to promote comfortable riding. Although the tires are designed specifically for vigorous off-road use, they are not immune to punctures. Always select your riding area with care.

CAUTION:

* *Driving on paved surfaces will cause excessive tire wear.*

For normal use, the tires should be inflated to a recommended pressure of 2.2 psi (15 kPa, 0.15 kg/cm²). A manually operated tire pump should be used rather than the high pressure systems found in service stations. This will minimize the possibility of tire damage from overinflation.

NOTE:

* Tire pressure should be checked when the tires are "cold", before you ride.

If no air pressure gauge is available to accurately measure 2.2 psi (15 kPa, 0.15 kg/cm²), this value can be estimated by measuring the circumference of the tires with a measuring tape. When inflated to 2.2 psi (15 kPa, 0.15 kg/cm²), the maximum tire circumference measured over the tread ribs will be approximately 1,742 mm (68.6 in.). The relationship

between tire pressure and actual circumference varies slightly with factors of wear and stretching that occur through use.

Recommended Pressure: 2.2 psi (15 kPa, 0.15 kg/cm²)

Standard Tire Circumference: 1,742 mm (68.6 in.)

Max. Pressure: 2.8 psi (20 kPa, 0.2 kg/cm²)

Min. Pressure: 1.7 psi (12 kPa, 0.12 kg/cm²)



 **WARNING**

- * *Be sure to inflate both rear tires equally. If the ATC110 is operated with unequal tire pressures, the resultant difference in tire circumference will cause the ATC110 to run toward one side and will adversely affect handling.*

CAUTION:

- * *Maintain proper tire pressure. Underinflated tires may adversely affect maneuverability and cause wheel damage when riding over bumpy terrain. Overinflated tires may rub on the fenders and hamper movement of the ATC.*

If you have a flat tire, use the plug method to make temporary repairs. The plug method is the same as that for conventional tubeless tires. A plug type repair kit, which is available at most auto part stores or service stations, provides a plug, an installation tool, tire cement, and an instruction sheet. Follow the instructions provided in the repair kit to make a temporary repair until the tire can be permanently repaired by the cold patch method. Any tire which cannot be repaired by the plug method should be replaced. Whenever the ATC is to be operated far from service facilities or available transportation, we recommend that the rider carry a tire pump and a suitable repair kit with him.

PRE-RIDE INSPECTION

WARNING

** If the Pre-ride Inspection is not performed, serious damage or an accident may result.*

Inspect your ATC110 every day before you start the engine. The items listed here will only take a few minutes, and in the long run they can save time, expense, and possibly your life.

1. Engine oil level – add engine oil if required (page 12). Check for leaks.
2. Fuel level – fill fuel tank when necessary (page 11). Check for leaks.
3. Brake – check operation. Adjust free play if necessary (page 42).
4. Tires – check condition and pressure (page 14).
5. Drive chain – check condition and slack (page 44). Adjust and lubricate if necessary.
6. Throttle – check for smooth opening and closing in all steering positions (page 6).
7. Headlight switch – check for proper function (page 5).

8. Ignition switch – check for proper function (page 5).
9. Nuts, Bolts, Fasteners – check wheels to see that axle nuts are tightened and secured by cotter pins. Check security of all other nuts, bolts and fasteners.

Correct any discrepancy before you ride. Contact your authorized Honda dealer for assistance if you cannot correct the problem.


STARTING THE ENGINE

WARNING

- * *Never run the engine in a closed area. The exhaust contains poisonous carbon monoxide gas.*
- * *Do not try to start the engine with the transmission in gear. You may injure yourself or damage the vehicle.*

Starting Procedure


1. Select a level surface and set the parking brake before starting the engine.
2. Turn the fuel cap lever (1) and fuel valve (2) ON.
3. Move the ignition switch (3) to RUN.



(1) Cap lever

(2) Fuel valve

4. Select the Posi-Torque range. If necessary, roll the ATC forward to engage the sub-transmission gears.
5. Make sure that the transmission is in neutral by lifting the shift lever and checking that the neutral indicator (4) is at N.
6. Raise the choke lever (5) completely and open the throttle (6) slightly.
7. Pull the recoil starter (7) slightly until compression is felt. With the engine against compression, pull the starter rope briskly.



(3) Ignition switch

(4) Neutral indicator

NOTE:

- * In cold weather, leave the choke lever up for several minutes after the engine starts and then gradually push the choke down as the engine warms up.
- * The Posi-Torque selector lever may be moved while the engine is idling, but it is recommended that the engine be stopped.


CAUTION:

- * *Extended use of the choke may impair piston and cylinder wall lubrication.*

- * *Do not race the engine during the warm up period. Racing a cold engine wastes fuel and increases engine wear.*



(5) Choke lever



(6) Throttle lever



(7) Recoil starter rope

Flooded Engine

If the engine does not start after several attempts, it may have become flooded with excess fuel. To clear the engine, turn the ignition switch off, push the choke lever down completely, hold the throttle fully open, and pull the recoil starter rope several times.

When the engine is cleared, turn the ignition switch on and repeat the normal starting procedure, but do not use the choke.

BREAK-IN

During the first few days of riding, operate your new ATC110 so that the engine neither pulls laboriously nor approaches maximum rpm in any gear. Avoid full throttle operation, and select your gears to spare the engine undue stress. Careful break-in procedure during initial operation will measurably extend the service life of the engine.

RIDING

WARNING

- * Review ATC Safety (page 1) before you ride.
- * Avoid "wheelies" and jumping as they cause loss of control.
- * Ride with your feet on the foot pegs at all times. If your feet are removed from the pegs to touch the ground while the ATC is moving, they may come in contact with the rear wheels.

Under normal riding conditions it is not necessary or desirable to touch the ground for balance.

For your initial riding practice, select a safe area free of obstacles and with an even surface. Avoid paved surfaces as they make learning to maneuver more difficult, and will also significantly shorten tire life.

1. After the engine has been warmed up, release the parking brake. The machine is ready for riding.
2. While the engine is idling, depress the gear change pedal to shift into low (1st) gear.
3. Increase engine speed by opening the throttle.
4. When the speed increases, close the throttle and shift to 2nd gear by depressing the gear change pedal.


CAUTION:

- * Do not shift gears without closing the throttle. The engine and drive train could be damaged by overspeed and shock.

5. This sequence is repeated to progressively shift to 3rd and top (4th) gear.

CAUTION:

- * Do not move the Posi-Torque selector lever while riding or damage to the sub-transmission may result.
- * Do not tow the vehicle or coast for long distances while the engine is off. The transmission will not be properly lubricated and damage may result.



Shifting sequence

Turning Maneuvers

For better traction in off-road use, the ATC has been fitted with a rear axle which drives both rear wheels equally at all times.


When negotiating a turn, the wheel on the outside of the turn must travel a wider radius, and thus a greater distance, than the inside wheel. As the rear axle does not permit a differing rate of wheel rotation, it is not enough to merely steer the ATC into a turn. The new rider must learn to shift his weight and control the throttle to allow the rear tires to negotiate the turn. This is the primary technique to be mastered in riding the Honda ATC.

Practice turning the ATC at slow, constant speeds. Defer higher speeds until you are confident of your proficiency.

Steer in the direction of the turn, and lean your body to the inside of the turn, while supporting your weight on the outer foot peg. Use the throttle to maintain power throughout the turn.

This technique allows the ATC to lean slightly toward the outside, altering the balance of traction between the rear wheels sufficiently to allow them to negotiate the turn.

Once this technique is learned, turning maneuvers can be performed within a relatively small area.




Incorrect turning techniques may cause the front wheel to slide straight ahead when steered without affecting the ATC's direction of travel. If this should occur, close the throttle and come to a stop. Then continue practicing the technique outlined on the preceding page.

If the front wheel tends to skid in mud or snow, you may be able to improve control under these conditions by leaning forward, transferring additional weight to the front wheel.


If the rear wheels inadvertently skid sideways, correct your slide by steering in the direction of the skid if you have room to perform this maneuver safely. Avoid braking or accelerating until you have directional control.

To avoid skids while traveling on slippery terrain, the rider must exercise a high degree of caution. Controlled skids and spins, when performed safely, add to the sport the rider can enjoy. However, as skidding maneuvers are inherently more hazardous than those performed under full traction, we must caution the rider to first master the basic techniques of handling before practicing any skidding maneuver.

Surface composition is, of course, a major factor affecting skidding capability. It is obviously easier to slide on packed snow than in deep sand. Surfaces with extremely low or extremely high coefficients of friction must not be used for skidding maneuvers. It is dangerous to skid on ice, because you may lose all directional control, and it is dangerous to skid on pavement, because you may regain traction suddenly and unexpectedly, which can cause you to lose your balance and overturn.



Climbing Hills



Practice climbing on evenly surfaced slopes of less than 20°. The ATC's capability in climbing hills or traversing any specific terrain is dependent upon rider skill. As you gain experience in handling the ATC, and learn the hazards to be encountered and your own limitations, you may then proceed to ride more challenging terrain. However, you must first be able to discern and avoid any hill or hazard that would cause the ATC to overturn.

The riding technique for hill climbing involves transferring your weight toward the front wheel to keep it in contact with the ground. This may be done by leaning forward, or for greater weight transference, by standing on the foot pegs and leaning forward.

Take a running start, in the appropriate gear and speed for the ascent, and climb at a steady rate of speed.

WARNING

- * *Do not apply power suddenly by opening the throttle or changing gears while ascending a hill or the front wheel may rise from the ground. If the front wheel lifts, rider control will be lessened and the ATC may overturn backward.*

If you should find that you have incorrectly estimated climbing capability and lack the power or traction to continue the ascent, then if space permits, turn the ATC around while you still have the forward speed to do so and descend. Avoid stalling part way up a hill, as maneuvering will then become more difficult.

WARNING


** Before attempting a turn on a hillside, the rider should first master turning technique on level ground.*

If you do lose all forward speed, and can neither continue uphill nor maneuver the ATC under its own power, dismount and physically turn the machine around. If it cannot be turned and must be backed down, first shift the transmission into neutral. However, we strongly recommend that the rider turn the ATC around rather than back it downhill.

WARNING

** To avoid overturning, the rider must exercise a high degree of caution when dismounting or moving the ATC on a hillside.*

** Applying the brakes or engaging the transmission, while rolling backward downhill can easily cause the ATC to overturn and fall on the rider.*




Descending Hills

It is usually advisable to descend hills with the ATC pointed directly downhill, avoiding angles that would cause the vehicle to lean sharply to one side. As you approach the point of descent, stop and survey the terrain below. Never ride headlong past your limit of visibility. When you have picked a safe path of descent, shift the transmission into low gear and descend slowly with the throttle closed. Sit back on the seat, with arms extended and braced on the handlebars.

When descending sand dunes, we recommend that the rider apply the brake intermittently to further retard forward speed.

Braking effectiveness is, of course, reduced while descending any incline with a loose surface.




Traversing Slopes

When riding across a slope, at right angles to the incline of the hill, lean your body in the uphill direction to maintain balance and stability. On a loose surface such as sand, it may become necessary to steer slightly uphill in order to maintain your course of travel.

WARNING

- * *Balance is more precarious while the ATC is tilted to one side. Avoid traversing slopes where there is slippery or difficult terrain.*



Riding Through Water

WARNING

- * *Do not ford any stream with fast flowing water. The tires may float, making it difficult to maintain control.*
- * *Do not ride the vehicle through water for prolonged periods.*

The Honda ATC can ford water to a depth of approximately 10 inches, although the rider must be careful to avoid getting the spark plug or air cleaner wet.

When crossing streams, choose a course where both banks have gradual inclines. Proceed at a slow, steady speed, and take care to avoid submerged obstacles and slippery rocks.

After riding through water, the brakes may be less effective than normal. Test the brakes after traveling through any water, and if necessary, apply the brakes repeatedly until the heat of friction has dried them, and the brakes regain their normal effectiveness.



High Altitude Riding

When operating this vehicle at high altitudes the air-fuel mixture becomes overly rich. Above 6,500 feet (2,000 m) driveability and performance may be reduced and fuel consumption increased. The carburetor can be modified to compensate for this high altitude richness. However, the carburetor must be returned to standard factory specifications when lower altitude riding is desired. (See pages 35–36).

CAUTION:

- * *Sustained operation at altitudes below 5,000 feet (1,500 m) with high altitude carburetor modifications may cause engine overheating and damage.*

PARKING

1. Stop the vehicle, shift the transmission into neutral, turn the fuel valve, fuel cap lever, and ignition switch OFF.
2. Pull the parking brake lever and lock it. (See page 6.)

MAINTENANCE

MAINTENANCE SCHEDULE

The maintenance intervals shown in the following schedule are based upon average riding conditions. Machines subjected to severe use, or ridden in unusually dusty areas, require more frequent servicing. Items marked * should be serviced by an authorized Honda dealer, unless the owner has the proper tools and is mechanically proficient. Other maintenance items are simple to perform and may be serviced by the owner.

Perform the Pre-ride Inspection (Page 16) at each scheduled maintenance period.

I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean R: Replace A: Adjust		INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
ENGINE OIL	NOTE (1), (2)	R	R	32
AIR CLEANER ELEMENT	NOTE (2)		I	38
SPARK PLUG			I	37
* VALVE CLEARANCE		I	I	39
* CAM CHAIN TENSIONER		A	A	45
* CARBURETOR		I	I	34
FUEL LINE		I: (EVERY YEAR)		—

- NOTE:** (1) Replace every 30 operating days or every 3 months, whichever comes first.
 (2) Service more frequently when riding in dusty areas.

I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean R: Replace A: Adjust	INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
FUEL STRAINER	C: (EVERY YEAR)		33
THROTTLE OPERATION	I	I	43
DRIVE CHAIN	I	I	44
* BRAKE SHOES	I: (EVERY YEAR)		—
BRAKE SYSTEM	I	I	42
* CLUTCH	A	A	41
* SPARK ARRESTER		C	46
ALL NUTS, BOLTS, FASTENERS	I	I	—
LIGHTING EQUIPMENT	I	I	—
TIRES	I	I	14
* STEERING HEAD BEARING	A: (EVERY YEAR)		—

WARNING


- * Always turn the engine off before performing any maintenance operations unless otherwise stated.*
- * To maintain the safety and reliability of your HONDA ATC do not modify it and use only new genuine HONDA parts or their equivalent when servicing or repairing.*
The use of replacement parts which are not of equivalent quality may impair the operation of your ATC.

TOOL KIT

The tool kit is stored in the compartment (1) shown below. The tools provided are sufficient to perform routine maintenance and simple repairs. Any extensive work requiring additional tools should be performed by an authorized Honda motorcycle dealer.

Listed below are the items included in the tool kit:

- 8x12mm open end wrench
- 10x14mm open end wrench
- Spark plug wrench
- Pliers ● Screwdriver blade ● Screwdriver handle
- 17mm socket wrench ● Socket wrench handle
- Tool bag



(1) Tool kit compartment


ENGINE OIL

Engine oil should be changed in accordance with the maintenance schedule. Use motor oils of the grade and viscosity recommended on page 13.

When changing oil, drain the used oil from the crankcase while the engine is still warm. This will ensure complete and rapid draining.

1. Remove the oil filler cap from the right crankcase cover.
2. Place a drip pan under the engine to catch the oil, and then remove the drain plug (1) with a 17mm socket wrench.
3. After the oil stops draining pull the recoil starter several times to drain any oil which may be left in the engine.
(Make sure the ignition switch is at OFF.)
4. When the oil has been completely drained, check that the drain plug sealing washer is in good condition and install the drain plug.

5. Fill the crankcase with approximately 1.1ℓ (1.2 US qt) of the recommended grade of motor oil.
6. Make sure that the oil level is between the upper and lower marks on the dipstick. Add more oil if necessary.



(1) Drain plug


FUEL STRAINER

The fuel strainer is on the left side of the carburetor. The fine mesh screen of the strainer prevents dirt from entering the carburetor passages. Dirt which accumulates at the filter must be removed periodically, or the fuel flow will eventually be restricted.

WARNING

- * *Gasoline is extremely flammable and is explosive under certain conditions. Refuel in a well ventilated area with the engine stopped. Do not smoke or allow flames or sparks in the area.*
- * *Gasoline is harmful or fatal if swallowed. Avoid repeated or prolonged contact with skin or breathing of vapor. Keep out of reach of children. If gasoline is swallowed, do not induce vomiting. Call a physician immediately.*

1. Turn the fuel valve OFF .
2. Remove the two screws which retain the fuel valve, and remove the valve.
3. Remove the neoprene O - ring (2) and the filter screen (1).
4. Wash the screen in non-flammable or high flash point solvent.
5. Reassemble by reversing the disassembly sequence.
6. Turn the fuel valve ON , and check for leaks. Correct if necessary.



(1) Filter screen


(2) O - ring

CARBURETOR

NOTE:

- * Do not attempt to compensate for faults in other systems by carburetor adjustment. See your authorized Honda dealer for regularly scheduled carburetor adjustments.
- * The engine must be warm for accurate idle adjustment. Ten minutes of stop-and-go riding is sufficient.

1. Warm up the engine.
2. Adjust idle speed with the throttle stop screw (1).
IDLE SPEED: 1,700 \pm 100 rpm
3. Turn the pilot screw (2) clockwise until you hear the engine miss or decrease in speed, then counter-clockwise until the engine again misses or decreases in speed. Center the pilot screw exactly between these two extreme positions.
Usually the correct setting (between extremes of rich and lean) will be found to be 1-1/8 turns open from a fully closed position.
If idle speed changes after adjusting fuel mixture, readjust the throttle stop screw.



(1) Throttle stop screw

(2) Pilot screw

HIGH ALTITUDE

When operating this vehicle at high altitude the air-fuel mixture becomes overly rich.

Above 6,500 feet (2,000 m) driveability and performance may be reduced and fuel consumption increased.

A high altitude jet is available for carburetor modification to compensate for this high altitude richness. Although installation and adjustment procedures are offered here, unless you are mechanically proficient and have the necessary tools we strongly urge that this carburetor modification be performed by your authorized Honda dealer.

CAUTION:

* *Sustained operation at altitudes below 5,000 feet (1,500 m) with the high altitude jet installed may cause engine overheating and damage.*

Altitude	Main jet	Pilot screw
Below 6,500 feet	No. 85	Factory Preset
Above 5,000 feet	No. 78	1/2 turn clockwise

Installation: Above 5,000 ft (1,500 m)

1. Turn the fuel valve OFF .
2. Place the carburetor drain tube in a suitable container. Turn the carburetor drain screw counterclockwise and drain the carburetor.
3. Remove the carburetor.

WARNING

- * *Gasoline is extremely flammable and is explosive under certain conditions. Perform this operation in a well ventilated area. Do not smoke or allow flames or sparks in the area.*
4. Remove the float chamber.
 5. Remove the standard main jet (No. 85) and



(1) Main jet

install the high altitude main jet (No. 78). Reinstall the float chamber.

6. Install the carburetor. Assure that the drain screw is turned fully clockwise. Turn the fuel valve ON.
7. Start the engine. Adjust the idle speed (3) and pilot screw (2) (page 34).

NOTE:

- * Adjust the idle speed and pilot screw at high altitude to ensure proper high altitude operation.

Removal: Below 6,500 ft (2,000 m)

1. Follow installation steps 1-4.
2. Reinstall the original No. 85 main jet.
3. Reinstall the carburetor. Adjust the idle speed and pilot screw (page 34).

NOTE:

- * Adjust the idle speed and pilot screw at low altitude to ensure proper low altitude operation.



(2) Pilot screw

(3) Throttle stop screw

SPARK PLUG

Standard spark plug

NGK: DR8HS

CAUTION:


* *The use of spark plugs of incorrect size or heat range can cause serious engine damage.*

1. Disconnect the spark plug cap.
2. Clean any dirt from around the spark plug base.
3. Remove the spark plug.
4. Visually inspect the spark plug electrodes for wear. The center electrode should have square edges and the side electrode should have a constant thickness. If the electrodes and insulator tip appear unusually fouled or burned, we suggest that you contact an authorized Honda dealer. Discard the spark plug if there is apparent wear or if the insulator is cracked or chipped.
5. Make sure that the spark plug gap is 0.6–0.7 mm (0.024–0.028 in) using a feeler gauge. If adjustment is necessary, bend the side electrode (1) carefully.

6. When installing the spark plug, screw it in finger tight and then tighten with the plug wrench another 1/2 turn to compress the washer.

CAUTION:

* *The spark plug must be securely tightened. An improperly tightened plug can become very hot and possibly damage the engine.*




(1) Side electrode

AIR CLEANER

The air cleaner element accumulates dust and must be cleaned periodically. If the ATC110 is ridden in unusually dusty areas, the element must be cleaned at more frequent intervals than specified in the MAINTENANCE SCHEDULE.

1. Remove the mounting bolts (1) and the air cleaner tube clamp (2).
2. Loosen the air cleaner setting nut (3), and withdraw the filter from the housing.
3. Remove the filter element, wash it in non-flammable or high flash point solvent. Allow it to dry thoroughly.
4. Soak the filter element in clean gear oil (SAE 80–SAE 90) until saturated, then squeeze out the excess oil.
5. Reassemble by reversing the disassembly sequence.



(1) Mounting bolts
(2) Tube clamp


(3) Element setting nut

CAUTION:

- * Do not pinch the air intake tube between the air cleaner case and frame when installing the air cleaner case.

WARNING

- * Never use gasoline or low flash point solvents for cleaning the air cleaner element. A fire or explosion could result.



(4) Air intake tube

(5) Air cleaner case

VALVES


Valve clearance should be maintained at 0.07 mm (0.003 in.). Excessive clearance will cause noise. Insufficient clearance will cause loss of power and could cause valve damage.

NOTE:

* Check and adjust valve clearance while the engine is cold. The clearance may increase as the temperature rises.

1. Remove the recoil starter and valve adjusting caps.
2. Rotate the generator rotor counterclockwise until the T mark (1) on the generator rotor lines up with the timing index mark (2) on the stator. In this position, the piston may either be on the compression or the exhaust stroke. The adjustment must be made when the piston is on top of the compression stroke when both the intake and exhaust valves are closed. This can be determined by moving the rocker arms by hand. If they are free, it is an indication that the valves are closed and that the piston is on the compression stroke. If they are tight and the valves are open, rotate the generator rotor 360° (one complete revolution) and realign the T mark to the timing index mark.


3. Check the clearance of both valves by inserting a 0.07 mm (0.003 in.) gauge between the adjusting screw and valve stem.



(1) T mark

(2) Index mark

4. If adjustment is necessary, loosen the adjusting screw lock nut (3) and turn the screw (4) so that there is a slight resistance when the gauge is inserted.
5. After adjustment, tighten the lock nut while holding the adjusting screw to prevent it from turning.
6. Recheck the clearance to make sure that it has not changed.




(3) Lock nut

(5) Feeler gauge

(4) Adjusting screw

CLUTCH

1. Make sure the ignition switch is OFF.
2. Loosen the lock nut (2), and turn the clutch adjuster (1) counterclockwise until you feel resistance. Then turn 1/8–1/4 turn clockwise, and tighten the lock nut to hold the adjuster in this position.
3. After adjustment, start the engine and test ride the ATC110 to be certain that the clutch is operating properly.



(1) Clutch adjuster

(2) Lock nut

BRAKES

Brake Pedal:


Free play, measured at the end of the pedal (1), should be 15–20 mm (5/8–3/4 in.).

Adjust by turning the adjusting nut (2) located on the brake operating rod at the rear of the frame.

Other Checks:

Check the brake cable for kinks or signs of wear that could cause sticking or failure.

Lubricate the brake cable with a commercially available cable lubricant to prevent premature wear or corrosion.



(1) Brake pedal


(2) Pedal adjusting nut

Make sure the brake arm, spring, rod and fasteners are in good condition.

Brake Lever/Parking Brake:

Free play, measured at the tip of the brake lever (3), should be within 15–20 mm (5/8–3/4 in.).

Adjusting nuts (4) are located at the brake cable mount on the right side of the frame just behind the engine.




(3) Brake lever

(4) Lever adjusting nuts


THROTTLE CABLE

Inspect throttle cable condition and operation. The cable must not bind or impair smooth operation of the throttle lever in any steering position. Reroute the cable if it is improperly installed. Replace the cable if it has become worn or kinked. Lubricate the cable with a commercially available cable lubricant to prevent premature wear or corrosion. Free play, measured at the tip of the throttle lever (1), should be maintained at 5–10 mm (3/16–3/8 in).



(1) Throttle lever

The cable adjuster (3) is located near the throttle lever. Loosen the lock nut (2) and turn the adjuster to obtain the correct free play.




(2) Lock nut

(3) Cable adjuster

DRIVE CHAIN

The drive chain (1) will wear with use and requires periodic adjustment in accordance with the maintenance schedule.

Shut the engine off. Remove the inspection cap (2). Chain tension should be checked by measuring the amount of chain slack through the inspection hole. The amount of slack should be 10–20 mm (3/8–3/4 in.). To adjust tension, loosen the locking nut (3), and move the chain tensioner plate (4) to adjust tension. Retighten the locking nut and re-install the cap.



(1) Drive chain

(2) Inspection cap

Lubrication:

The drive chain can be lubricated through the inspection hole. This hole is capped to prevent dirt from entering the chain case. Be sure to reinstall the cap after lubrication.

NOTE:

- * The O-rings in this chain can be damaged by steam cleaning, high pressure washers. Lubricate the chain only with SAE 80 or 90 gear oil. Commercial chain lubricants may contain certain solvents which could damage the rubber O-rings.




(3) Locking nut

(4) Chain tensioner plate

CAM CHAIN

An improperly adjusted cam chain will adversely affect engine performance. Adjust tension while the engine is idling.

1. To adjust, loosen the lock nut (1) and tensioner adjusting bolt (2) approximately 1-1/2 turn.
2. If the chain is still noisy, remove the 14 mm sealing bolt located on the left bottom side of the crankcase, and screw in the tensioner bolt (3) gradually until the cam chain becomes quiet. After adjustment, tighten the tensioner adjust bolt, lock nut, and 14 mm sealing bolt securely.



(1) Lock nut (2) Tensioner adjusting bolt



(3) Tensioner bolt


SPARK ARRESTER

The exhaust system must be periodically purged of accumulated carbon.

WARNING

- * *The exhaust system becomes VERY HOT even after short periods of engine operation.*
- * *To avoid fire hazards, DO NOT perform this maintenance in the vicinity of flammable materials.*

1. Remove the spark arrester bolt (1) and slide the arrester (2) out.
2. Clean the arrester of accumulated carbon.
3. Start the engine, and purge accumulated carbon from the system by momentarily revving up the engine several times.
4. Stop the engine and allow the exhaust pipe to cool.
5. Reinstall the spark arrester with the bolt.



(1) Spark arrester bolt (2) Spark arrester

STORAGE

Preparing the machine for storage:

1. Completely clean all parts of the machine. If the machine has been exposed to sea air or salt water, wash it down with fresh water and wipe dry.
2. Drain the fuel tank and the carburetor.

WARNING

* *Gasoline is flammable and is explosive under certain conditions. Do not smoke or allow flames or sparks near the equipment while draining fuel.*

- A. Place the carburetor drain tube (1) in a suitable container.
- B. Open the fuel drain by turning the drain screw (2) counterclockwise.
- C. Turn the fuel valve to RES and the fuel tank cap lever to ON.




(1) Carburetor drain tube

3. Change the engine oil. (See page 32.)
4. Position the piston at the top of the compression stroke by pulling the starter rope until compression is felt.
5. Inflate the tires to the normal pressure and place the ATC on blocks to raise the tires off the ground.
6. Cover the machine and store in a place which is free of humidity and dust.

NOTE:

- * Be sure to close the fuel drain before refueling when the ATC is taken out of storage.



(2) Carburetor drain screw

TRANSPORTING

1. Place the carburetor drain tube in a suitable container.
2. Turn the fuel cap lever and fuel valve OFF .
3. Turn the drain screw counterclockwise to drain the gasoline from the carburetor.

* If wheel removal is required when transporting, follow the procedures on following pages.

WARNING

- * *Never incline the machine with the front wheel up, or rest it on its side without draining the fuel. Fuel vapor or spilled fuel may ignite.*
 - * *Gasoline is flammable and is explosive under certain conditions. Do not smoke or allow flames or sparks near the equipment while draining fuel.*
4. After draining turn the drain screw clockwise.

NOTE:

- * Be sure the fuel drain is closed (screw turned clockwise) before refueling the ATC.
- * It is unnecessary to drain the engine oil from the crankcase, as no appreciable oil leakage will occur when the ATC is rested on its side.


REAR WHEEL REMOVAL

1. Place a support block under the vehicle and raise the rear wheel off the ground.
2. Loosen the wheel nuts (1) with the 12 mm socket wrench.
3. Remove the wheel.

Installation Notes:

- Reinstall the rear wheels by reversing the disassembly sequence.
Torque the wheel nuts in a cross-pattern.

Torque: 18–25N·m (1.8–2.5 kg–m, 13–18ft-1b)



(1) Wheel nuts




FRONT WHEEL REMOVAL

1. Place a support block under the engine to raise the front wheel off the ground.
2. Remove the cotter pins (1) securing both front axle nuts.
3. Loosen the nuts (2) with the 17 mm socket wrench in the tool kit. Remove the nuts, and axle collars (3).
4. Remove the front wheel and axle.
5. Remove the axle (5) and wheel spacer (4) from the front wheel.

NOTE:

- * Cover the wheel hub (6) as soon as the axle has been removed to prevent entry of dirt.



(1) Cotter pin

(2) Axle nut

(3) Axle collar

(4) Wheel spacer

Installation Note:


- Reinstall the front wheel by reversing the disassembly sequence.

CAUTION:

- * *When the front axle is reinstalled, be careful that the grease seal is not cut or damaged.*
- * *Always replace used cotter pins with new ones. To reduce the hazard of snagging the ends of the cotter pins, while the ATC is operated, we recommend that the projecting ends of the front axle cotter pins be cut close to the axle nuts.*

WARNING

- * *Be certain that the axle nuts are tightened and secured by cotter pins. If they are not, the wheels may come loose during operation.*



(5) Front axle

(6) Wheel hub

OPTIONAL PARTS


Front Carrier

Max. Load 10 kg (22 lbs)



Rear Carrier

Max. Load 25 kg (55 lbs)



Chevron pattern tire

For soft, sandy or swampy terrain

CAUTION:

- * *Load cargo on the rear carrier as far forward as possible. Do not allow cargo to extend beyond the end of the rear carrier.*

WARNING

- * *To prevent an accident, use extreme care when adding or riding with accessories and cargo. Addition of accessories and cargo can reduce the ATC's stability, performance and safe operating speed. Accessories are designed for work applications and should be removed for recreational riding.*



Air pressure gauge

SPECIFICATIONS

DIMENSIONS

Overall length	1,630 mm (64.2 in)
Overall width	950 mm (37.4 in)
Overall height	940 mm (37.0 in)
Wheel base	1,040 mm (40.9 in)

WEIGHT

Dry weight	108 kg (238 lbs)
------------------	------------------

CAPACITIES

Engine oil	1.1 liter (1.17 US qt)
Fuel tank	7.2 liter (1.9 US gal)
Fuel reserve capacity	0.54 liter (0.14 US gal)
Passenger capacity	Operator only

ENGINE

Bore and stroke	52x49.5 mm (2.05x1.95 in)
Compression ratio	8.2 : 1
Displacement	105 cc (6.4 cu-in)
Spark plug gap	0.6–0.7 mm (0.024–0.028 in)
Valve clearance	0.05 mm (0.002 in)

CHASSIS AND SUSPENSION

Caster angle	68.5°
Trail length	26 mm (1.0 in)
Tire size, front and rear	22x11–8


POWER TRANSMISSION

Primary reduction	3.722
Final reduction	3.267
Gear ratio, 1st	2.538
2nd	1.611
3rd	1.190
4th	0.958

Posi-torque gear ratio

Low range	1.867
High range	1.000

WIRING DIAGRAM



3194303
PRINTED IN USA