



Squaremax NP261XHD OEM Shifter Kit

'73- '86 GM K Series & '87- '91 GM V Series

Revision 01 (10/16/20)

Package Contents

- *(1) NP261XHD Floor Shift Lever*
- *(1) Upper Reinforcement Bracket*
- *(1) Lower Reinforcement Bracket*
- *(4) M8x1.0x25mm Flange Hex Head Bolt*
- *(1) NP261XHD Floor Shift Bezel*
- *(3) #8 Torx Pan Head Sheetmetal Screw*
- *(1) Shift Knob*
- *(1) Floor Shift Adjustable Linkage*

Tools Required

- 1. Tape Measure or Scale*
- 2. Masking Tape*
- 3. Double Stick Tape*
- 4. Black and/or Silver Sharpie*
- 5. Corded or Cordless Drill*
- 6. Drill Bit Assortment*
- 7. Sheetmetal Step Drill Bit*
- 8. 1/4" Die Grinder*

9. *Corded or Cordless Reciprocating Saw*
10. *¼" Ratchet*
11. *10mm 6 or 12-Point Socket*
12. *#10 Torx Driver*

Transmission Tunnel Modification

1. *Remove any all flooring (I.E. Carpet, Rubber Mat and insulation) from transmission tunnel. This is a good time to vacuum and wash down the floor.*
2. *Adjust the Adjustable Floor Shift Linkage to the center of the adjustment and snug bolt. Final adjustment will be made after installation is completed.*
3. *Shift transfer case to 2WD position.*
4. *Temporarily install the Adjustable Linkage to the shift lever on the transfer case.*
5. *Swing Adjustable Floor Shift Linkage parallel to frame rail and vehicle centerline.*
6. *Using the Sharpie, mark the centerline of the socket position on the Adjustable Floor Shift Linkage on the underside of the transmission tunnel.*
7. *Measure 1.500" forward from the centerline mark you made on the underside of the transmission tunnel and mark with Sharpie.*
8. *Loosely assemble the Upper and Lower Reinforcement Brackets together using (2) two of the M8x1.0x25mm Flanged Hex Bolts.*
9. *Place the assembled Reinforcement Bracket on the underside of the transmission tunnel. Make sure the Reinforcement Bracket is touching the D/S of the tunnel and the top of the tunnel.*
10. *Align the forward inner front edge of the Reinforcement Bracket with the mark you made using the 1.500" measurement.*
11. *Using the Sharpie, mark the upper and lower hole centers of the Reinforcement Bracket and set aside.*
12. *Drill a 1/8" pilot hole on the hole center marks you just made.*
13. *Using the Sheetmetal Step Bit, open the 1/8" diameter holes to ¼".*
14. *Fasten the assembled Reinforcement Bracket to the transmission tunnel. You will only be using the (2) two ¼" holes you just drilled using (2) two of the M8x1.0x25mm Flanged Head Bolts.*
15. *Using the Sharpie, mark the inside profile of the Reinforcement Bracket.*
16. *Remove the assembled Reinforcement Bracket from the transmission tunnel and set aside.*
17. *Using the ¼" Die Grinder, cut the straight sections of the inside profile you previously marked on the underside of the transmission tunnel.*
18. *Once completed, you may use the Reciprocating Saw to cut the profiles and radius corners.*
19. *Deburr all sharp edges to prevent injury.*
20. *Disassemble the Reinforcement Bracket.*

21. Loosely bolt the upper half of the Reinforcement Bracket to the underside of the transmission tunnel using (1) one of the M8x1.0x25mm Flanged Headed Bolts in the upper ¼" hole.
22. Overlay the lower half of the Reinforcement Bracket over the upper half of the Reinforcement Bracket and loosely install (1) one of the M8x1.0x25mm Flanged Headed Bolts in the lower ¼" hole.
23. Once the Reinforcement Bracket is in place and aligned properly hand tighten.
24. Using the Sharpie, mark the two remaining hole centers in the Reinforcement Bracket.
25. Drill a 1/8" pilot hole on the hole center marks you just made.
26. Using the Sheetmetal Step Bit, open the 1/8" diameter holes to ¼".
27. Paint or treat all bare metal surfaces to prevent rust.
28. Reinstall any and all flooring (I.E. insulation, rubber mat or carpet).
29. Using the Sharpie, mark the floor shifter cutout on the back side of the insulation, rubber mat or carpet.
30. Remove any and all flooring and cut shifter cutout profile.
31. Reinstall any and all flooring.
32. Place Insulated Double Stick Tape to the upper and lower halves of the Reinforcement Bracket.
33. Carefully align and stick upper half to underside of transmission tunnel. Apply pressure to ensure adhesion.
34. Overlay lower half of Reinforcement Bracket over upper half and apply pressure to ensure adhesion.
35. Place Floor Shift Lever through cutout and fasten using the (4) four M8x1.0x25mm Flanged Hex Head Bolts.
36. Torque hardware using proper torque specifications from the Torque Tension Chart.
37. Install Floor Shift Bezel using the (3) #8 Torx Pan Head Sheetmetal Screws. Please note the holes in the Floor Shift Lever are not pre-tapped. Make sure the screws are perpendicular to the mounting tab surface before turning. Keep constant pressure and double check the screw is perpendicular to the mounting tab surfaces.
38. Install Shift Knob.
39. Place Floor Shift Lever in the 2WD position.
40. Confirm the transfer case is in the 2WD position.
41. Loosen the Floor Shift Adjustable Linkage bolt.
42. Adjust the Floor Shift Adjustable Linkage to fit.
43. Snap the socket on the Floor Shift Adjustable Linkage onto the ball on the Floor Shift Lever.
44. Torque hardware using proper torque specifications from the Torque Tension Chart.
45. Shift transfer case shift lever through all positions.
46. Make any adjustment if necessary.
47. Enjoy the presentation of your new Squaremax NP261XHD OEM Shifter Kit!