

Medium-Voltage Variable Frequency Drive SINAMICS Perfect Harmony GH180

NXG ToolSuite Software

Function Manual · A5E03086439

SINAMICS Perfect Harmony GH180

AC

11/2013

NXG ToolSuite Software User

Function Manual

Safety Precautions and Warnings	1
NXG / NXGII ToolSuite Overview	2
NXG / NXGII Drive Tool	3
NXG Debug Tool	4
NXG SOP Utilities	5
NXG Configuration Update Utility Overview	6
Drive Server Setup/Status Utility	7
High Availability Drive Tool	8
Glossary	A
Abbreviations	B
Operators and Precedence	C
Ethernet Connections	D

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 DANGER
indicates that death or severe personal injury will result if proper precautions are not taken.
 WARNING
indicates that death or severe personal injury may result if proper precautions are not taken.
 CAUTION
with a safety alert symbol, indicates that minor personal injury can result if proper precautions are not taken.
CAUTION
without a safety alert symbol, indicates that property damage can result if proper precautions are not taken.
NOTICE
indicates that an unintended result or situation can occur if the corresponding information is not taken into account.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The device/system may only be set up and used in conjunction with this documentation. Commissioning and operation of a device/system may only be performed by **qualified personnel**. Within the context of the safety notes in this documentation qualified persons are defined as persons who are authorized to commission, ground and label devices, systems and circuits in accordance with established safety practices and standards.

Proper use of Siemens products

Note the following:

 WARNING
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be adhered to. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of the Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Table of Contents

1	Safety Precautions and Warnings	5
2	NXG / NXGII ToolSuite Overview.....	9
2.1	Overview.....	9
2.2	Installation Procedure	10
2.3	Starting ToolSuite	15
3	NXG / NXGII Drive Tool.....	17
3.1	Drive Configuration Features.....	18
3.2	Drive Variable Graphing Features	19
3.3	Drive Status Features	25
3.4	Drive Control Features	25
3.4.1	Drive Tool Pull Down Menu Features	26
3.5	Start and Configure the Drive Tool	31
3.6	Set Up Ethernet (TCP/IP) Communications	32
3.7	Operating the Drive Tool	35
3.7.1	Fault or Alarm Displays	35
3.7.2	Graphing Display	40
3.7.3	Time Scale Adjustment.....	46
3.7.4	Freezing Graph on Fault.....	47
3.7.5	Freezing Graph on Trigger	48
3.7.6	Post Processing of Data	49
4	NXG Debug Tool.....	51
4.1	System Requirements	51
4.2	Start and Configure the Debug Tool.....	51
4.3	Operating the Debug Tool	56
5	NXG SOP Utilities.....	61
5.1	Introduction.....	61
5.2	SOP Utility Tool Overview	61
5.3	Starting the SOP Utility Tool.....	63
5.4	SOP Development Process.....	65
5.5	Overview of the Compile Process	66
5.6	Input Source File	68
5.6.1	System Type Identification	71
5.6.2	SOP Source File.....	73
5.6.3	Input Flags.....	76
5.6.4	Output Flags.....	76
5.6.5	Redefining Flag Names	78
5.7	Compiler Operation	79

5.8	Output Hex File.....	80
5.9	Downloading a System Program (Hex File).....	80
5.9.1	Siemens LD A SOP Upload/Download Utility Method.....	81
5.9.2	Terminal Emulation Method.....	82
5.9.3	Termination.....	83
5.10	Uploading a System Program (Hex File).....	87
5.11	Reverse Compiler.....	87
5.12	Header.....	93
5.13	Combined Source /Hex File.....	96
6	NXG Configuration Update Utility Overview.....	105
6.1	System Requirements.....	105
6.2	Start and Configure the Configuration Update Utility.....	106
6.3	Features Overview.....	107
6.3.1	Copy Setup Files to Another Directory.....	107
6.3.2	Update Flash Disk Files.....	111
6.3.3	Bootable Default Disk Procedure.....	114
6.3.4	Copy Flash Disk to PC.....	119
6.3.5	Make Bootable Copied Disk Procedure.....	123
6.3.6	Update ToolSuite Host Files on PC.....	128
7	Drive Server Setup/Status Utility.....	131
7.1	Start and Configure the Configuration Update Utility.....	131
7.1.1	Create a New Server Connection.....	132
7.2	Setup/Status Application Operation.....	136
7.2.1	Status Screen.....	136
7.2.2	Menu Functions - Setup Menu.....	137
7.2.2.1	Select New Server Connection.....	137
7.2.2.2	Server Connection Maintenance.....	137
7.2.2.3	Create New Server Connection.....	138
7.2.2.4	Edit Server Connection Data.....	138
7.2.2.5	Rename Server Connection.....	139
7.2.2.6	Delete Server Connection.....	139
7.2.3	Menu Functions - Server Maintenance.....	139
7.2.3.1	List Server Names.....	139
7.2.3.2	Create New Server.....	139
7.2.3.3	Rename Server.....	140
7.2.3.4	Delete Server.....	140
7.2.4	Menu Functions - Config Menu.....	141
7.2.4.1	Select Server Controlled Data.....	141
7.2.4.2	Set Server as Configured.....	141
7.2.4.3	Set Operating Conditions.....	141
7.2.4.4	Configure Initial Parameters.....	142
7.2.4.5	Change Drive Names/P Addresses.....	143
7.2.5	Menu Functions - Security Menu.....	143
7.2.5.1	Enter Security Code.....	143
7.2.5.2	Security Clear.....	143
7.2.5.3	Run Menu.....	144
7.2.5.4	Start Menu.....	144
7.2.5.5	Restart Menu.....	144

8	High Availability Drive Tool.....	145
8.1	Connection to Drive Tool.....	145
8.2	Selecting Desired Control System.....	148
A	Glossary	151
B	Abbreviations.....	165
C	Operators and Precedence.....	171
C.1	Operators and Precedence.....	171
C.2	Ladder Logic Translation.....	175
D	Ethernet Connections.....	177
D.1	Direct Connection.....	177
D.1.1	Required Items for a Single Ethernet Direct Connection.....	177
D.1.2	Required Items for a Single PC Multiple Drive Ethernet Connection Support.....	178
D.1.3	Configuring a PC to Work with a Direct Connection.....	179
D.1.3.1	Windows® XP /2000.....	179
D.1.3.2	Windows® Vista.....	184

Safety Precautions and Warnings

Perfect Harmony drives are designed with considerable thought to personal safety. However, as with any piece of high power equipment, there are numerous internal connections that present potentially lethal voltages. In addition, some internal components are thermally hot to the touch. Follow the warnings below when working in or near the Perfect Harmony system.

 DANGER

Electrical Hazards!

- **Always** follow the proper lock-out/tag-out procedures before beginning any maintenance or troubleshooting work on the drive.
- **Always** follow standard safety precautions and local codes during installation of external wiring. Protective separation must be kept between extra low voltage (ELV) wiring and any other wiring as specified in IEC61800-5-1.
- **Always** work with one hand, wear insulated or rubber safety shoes, and wear safety glasses. Also, always work with another person present.
- **Always** use extreme caution when handling or measuring components that are inside the enclosure. Be careful to prevent meter leads from shorting together or from touching other terminals.
- **Use** only instrumentation (e.g., meters, oscilloscopes, etc.) intended for high voltage measurements (that is, isolation is provided inside the instrument, not provided by isolating the chassis ground of the instrument).
- **Never** assume that switching off the input disconnect will remove all voltage from internal components. Voltage is still present on the terminals of the input disconnect. Also, there may be voltages present that are applied from other external sources.
- **Never** touch anything within the Perfect Harmony cabinets until verifying that it is neither thermally hot nor electrically alive.
- **Never** remove safety shields (marked with a **HIGH VOLTAGE** sign) or attempt to measure points beneath the shields.
- **Never** run the drive with cabinet doors open. The only exception is the control cabinet which contains extra low voltages (ELV).
- **Never** connect any grounded (i.e., non-isolated) meters or oscilloscopes to the Perfect Harmony system.
- **Never** connect or disconnect any meters, wiring, or printed circuit boards while the drive is energized.
- **Never** defeat the instrument's grounding.
- **Only** qualified individuals should install, operate, troubleshoot, and maintain this drive. A qualified individual is "one familiar with the construction and operation of the equipment and the hazards involved."
- **Hazardous voltages** may still exist within the Perfect Harmony cabinets even when the disconnect switch is open (off) and the supply power is shut off.

⚠ WARNING

- **Always** comply with local codes and requirements if disposal of failed components is necessary (for example, CPU battery, capacitors, etc.).
- **Always** ensure the use of an even and flat truck bed to transport the Perfect Harmony drive system. Before unloading, be sure that the concrete pad is level for storage and permanent positioning.
- **Always** confirm proper tonnage ratings of cranes, cables, and hooks when lifting the drive system. Dropping the cabinet or lowering it too quickly could damage the unit.
- **Never** disconnect control power while medium voltage is energized. This could cause severe system overheating and/or damage.
- **Never** store flammable material in, on, or near the drive enclosure. This includes equipment drawings and manuals.
- **Never** use fork trucks to lift cabinets that are not equipped with lifting tubes. Be sure that the fork truck tines fit the lifting tubes properly and are the appropriate length.
- During operation, the nominal weighted sound pressure level can possibly exceed 70 dB at a distance of 1 meter from the drive.

CAUTION

ESD Sensitive Equipment!

- **Always** be aware of electrostatic discharge (ESD) when working near or touching components inside the Perfect Harmony cabinet. The printed circuit boards contain components that are sensitive to static electricity. Handling and servicing of components that are sensitive to ESD should be done only by qualified personnel and only after reading and understanding proper ESD techniques. The following ESD guidelines should be followed. Following these rules can greatly reduce the possibility of ESD damage to PC board components.
- **Always** transport static sensitive equipment in antistatic bags.
- **Always** use a soldering iron that has a grounded tip. Also, use either a metallic vacuum-style plunger or copper braid when desoldering.
- Make certain that anyone handling the Perfect Harmony printed circuit boards is wearing a properly grounded static strap. The wrist strap should be connected to ground through a 1 megohm resistor. Grounding kits are available commercially through most electronic wholesalers.
- Static charge buildup can be removed from a conductive object by touching the object to a properly grounded piece of metal.
- When handling a PC board, always hold the card by its edges.
- Do not slide printed circuit boards across any surface (e.g., a table or work bench). If possible, perform PCB maintenance at a workstation that has a conductive covering that is grounded through a 1 megohm resistor. If a conductive tabletop cover is unavailable, a clean steel or aluminum tabletop is an excellent substitute.
- Avoid plastic, StyrofoamTM, vinyl and other non-conductive materials. They are excellent static generators and do not give up their charge easily.
- When returning components to Siemens LD A, always use static-safe packing. This limits any further component damage due to ESD.

Additional safety precautions and warnings appear throughout this manual. These important messages should be followed to reduce the risk of personal injury or equipment damage.


NXG / NXGII ToolSuite Overview

2.1 Overview

The NXG / NXGII ToolSuite is a PC-based high-level Graphical User Interface (GUI) application that integrates various software tools used for NXG / NXGII based drives. ToolSuite, equipped with the Microsoft® Windows Operating System, allows navigation through a drive's features by using a PC and a mouse or by using a touch screen (instead of a keypad) – allowing you to monitor and control that drive's functions quickly and easily. The NXG Control and the PC running the NXG ToolSuite software, interface with one another using Ethernet and TCP/IP protocol.

ToolSuite contains the following tools:

- Drive Tool (for non - High Availability VFDs)
- Debug Tool
- SOP Utilities
- Configuration Update Utility
- Drive Server Setup / Status Utility (for High Availability VFDs)
- High Availability Drive Tool



IMPORTANT!




Ensure that Version 2.0 of Microsoft's® .NET Framework is installed **prior** to installing ToolSuite. Non-Siemens personnel can obtain .NET Framework by visiting the Microsoft® website and downloading it from there. Siemens personnel can download this application from a designated Siemen's server.

2.2 Installation Procedure

Perform the following steps to install ToolSuite.


1. Insert the Siemens NXG ToolSuite CD into your PC's CD drive. Open Windows Explorer and select the CD drive.
2. Double Click on the file ToolSuite Setup vx.x.exe (vx.x will vary based on the latest software version).




3. The "ToolSuite Installation Wizard" dialog boxes should appear as shown above. Follow the instructions and select the "Next>" button.




4. This dialog box shows the version information for all of the ToolSuite software components. Select the "Next>" button.




5. Select the "Next>" button to begin the installation.




6. After clicking "Next", the Updating System window appears.



7. If the installation was successful, the following dialog box appears. Click “Finish” to exit the installation.



8. After clicking “Finish” a Installer Information pop-up displays on the PC’s monitor prompting you to re-start your computer. Choose “Yes” to complete configuration changes or “No” if you wish to manually restart your PC at a later time.




9. If the installation was interrupted or stopped by the user before the ToolSuite software fully installs, the following dialog box appears.



10. Click “OK” to proceed.

2.2 Installation Procedure

11. To re-run the installation, follow the steps as described in the previous pages. Upon selecting the ToolSuite Setup v5.1.0.exe file, the Application Maintenance window displays as indicated below.




12. Make the desired selection and proceed as prompted by the software.

2.3 Starting ToolSuite


The ToolSuite installation program places an icon on your PC's desktop.



1. Double click the icon to start the ToolSuite.
2. The ToolSuite Splash Screen appears.



3. Once the ToolSuite is started, a window displays showing the Drive Tools, Debug Tool, and Utilities Tabs. At this point invoke one of the Tools listed below:
 - Drive Tool - Refer to Chapter *NXG / NXGII Drive Tool*
 - Debug Tool – Refer to Chapter *NXG Debug Tool*
 - Utilities – Refer to Chapters *NXG SOP Utilities*, *NXG Configuration Update Utility Overview*, *Drive Server Setup/Status Utility*
 - HA Drive Tool - Refer to Chapter *High Availability Drive Tool*




NXG / NXGII Drive Tool

The NXG / NXGII Drive Tool is the main graphical interface to the non-HA Drive. Its purpose is to manage all of the drive features and provide the user with a user-friendly view of the drive. To read about the HA Drive Tool, refer to *High Availability Drive Tool* Chapter of this manual.

The Drive Tool's main features are shown in the figure below:


1. Drive Configuration
2. Drive Variable Graphing
3. Drive Status
4. Drive Control



The sections that follow provide additional information about each of these features.

3.1 Drive Configuration Features


- Folders for each drive configuration category (matches the drive's keypad Quick Keys)
- Icon colors:
 - If multiple configuration files option is NOT enabled then:
 - GREEN** = default
 - RED** = changed from default
 - If multiple configuration files option IS enabled then:
 - GREEN** = master config file parameter and default
 - RED** = master config file parameter changed from default
 - LIGHT BLUE** = secondary config file parameter and default
 - DARK BLUE** = secondary config file parameter changed from default
- On screen help and ID identifier (matches the keypad IDs for Speed Menus)
- All parameters editing assisted by min, max limits, and defaults




3.2 Drive Variable Graphing Features

These drive variable graphing features are accessible via the Main Toolbar options and their respective submenus. See the pictures below.

- Adjustable Time Scale




- Pick List Selectable Variables




3.2 Drive Variable Graphing Features


- Graphing Capability Of Up To 10 Variables




- Individual Variable Offsets and Variable Scaling




- Customizable Graphics



- Fonts, Color, Styles



- Freeze Graphics, Freeze Graph On Fault




- Freeze On Settable Trigger



- Zoom Graph




- Printable Graphics




3.2 Drive Variable Graphing Features

- Exportable Graphics
 - Export: EMF, WMF, BMP, JPG, PNG, Text / Data
 - Export Destination: Clipboard, File, Printer
 - Export Size: Pixels, or Millimeters, Inches, Points (Width / Pixels, DPI)



3.3 Drive Status Features



- Seven programmable display variables
- Pick list selectable variables
- First four variables are synchronized to the keypad
- Fault and alarm indicators (traffic lights red = fault, yellow = alarm, display flashes)



3.4 Drive Control Features


- Manual Start Button
- Auto Start Button

- Stop Button
- Fault Reset Button
- Show Active Fault / Alarm Log Button

3.4.1 Drive Tool Pull Down Menu Features

File:

- Load Configuration Files
- Reset To Factory Defaults
- Create Config File
- Save Data
- Save Data As
- Display Active Config File
- Drive Parameter Data



- Print Data
- Write Data To Text File
- Search by ID
- Search by Text


- Set Factory Defaults
- Options
- Enter manual speed: Ctrl+D¹
- System Program
 - Download New System Program
 - Display System Program Name

1. When manually entering the drive speed, be aware that although the drive may be using speed limits set by Speed Limits set 1, Speed Limits set 2, or Speed Limits set 3, the Drive Tool limits the manually entered speed value to those values established by Speed Limit set 1 exclusively. Therefore, the maximum and minimum allowable values of entered speed will be limited to those values established by Speed Limits set 1.

- Upload System Program
- Network
 - Make Network 2 same as Network 1
 - View Network Module Types


View:

- Configuration Window
- Graphics Window
- Status Window



Security:


- Enter Security Code from Toolbar Menu or by:Ctrl+S



- Security Edit
- Change Security Code
- Security Level Clear


Status:

- Elapsed Time
 - Preset
 - Reset
 - Display
- Input kW Hours Consumed
 - Preset
 - Reset
 - Display
- Output kW HoursConsumed
 - Preset
 - Reset
 - Display
- Cells
 - Display Cell Status
 - Display Bypass Status
 - Reset Bypassed Cells
- Set Clock Time
- Over Temperature Timers
 - Cell
 - Preset
 - Reset
 - Display
 - Transformer
 - Preset
 - Reset
 - Display



Logs:

- Fault Log
 - English
 - Display Log
 - Store Log in File
 - Print Log
 - Drive Language
 - Display Log*
 - Store Log in File*
 - Print Log*
 - Clear Log



- Historic Log
 - English
 - Display Log
 - Store Log in File
 - Print Log
 - Drive Language
 - Display Log*
 - Store Log in File*
 - Print Log*
 - Clear Log
- Event Log
 - English
 - Display Log
 - Store Log in File
 - Print Log
 - Drive Language
 - Display Log*
 - Store Log in File*

- Print Log*

Clear Log

NOTICE


Items designated with an asterisk * are only available when ToolSuite is connected to a drive running NXG Version 5.0 or later software and the selected drive language is other than English.

Diagnostics

- Speed Test
 - Start Speed Test
 - Stop Speed Test


Calibration

- Auto-Tune




3.5 Start and Configure the Drive Tool

If no configured Drives exist, it will be necessary to configure a new one. To do this, click the “New” button in the “Drive Configurator” area of the ToolSuite dialog box shown below.



In the new dialog box shown below, select the “Use Default Values” Operation Type. Select “Harmony” from the Type Selection drop-down list and enter a drive name in the field provided directly under “Drive Name”. Click the “OK” button.



The ToolSuite dialog box will reappear, now showing the newly configured drive. Refer to Appendix B Ethernet Connections, which contains the information for a PC-to-drive communications setup.

3.6 Set Up Ethernet (TCP/IP) Communications



IMPORTANT!

To use the Drive Tool to control drives through an existing network, assign a unique IP address to each drive.

NOTICE

IP Address Duplication

Duplicating IP addresses will cause unintended communication issues that will lead to incorrect drive operation.


To avoid duplication of IP addresses, ensure that the IP addresses of the drive and the PC are NOT the same before connecting an external PC to the Ethernet connection of the drive.

Go to each drive and use that drive's keypad to set the menu items of the "TCP/IP setup" menu (ID = 9300). The menu items below **must** be updated based on the settings unique to your network:

Table 3-1: Network Settings

Menu Item	Menu ID	Default Setting	Custom Setting (Write yours here)
IP Address	9310	172.17.20.16	
Subnet Mask	9320	255.255.0.0	
Gateway Mask	9330	172.17.1.1	


Next, set the TCP/IP address in the Drive Tool to the same value as the drive, so that it will communicate with the drive. The following figure shows the drive's TCP/IP address highlighted. Change this value to match that of the drive to which you wish to communicate. Double-click the "TCP/IP server name" text or its adjacent icon to edit its value.



If the PC on which the Drive Tool runs already has the correct network settings for the LAN, the Drive Tool will start communicating with the drive within a few seconds of the time that you make this change. If the settings are not correct, then enter new network settings by simply right clicking the TCP/IP server name to display the “String Entry” pop-up window and enter the necessary information.

Afterwards, the Configuration window will display a tree of several folders, and the Graphics and Status windows will start displaying data similar to that shown in the following graphic.

3.6 Set Up Ethernet (TCP/IP) Communications



3.7 Operating the Drive Tool

Now that your Drive Tool is installed and operational, please take some time to become familiar with its features, and how to use them.

3.7.1 Fault or Alarm Displays

When a fault or an alarm condition exists, the Drive Tool window flashes to annunciate the existence of a Fault/Alarm.

NOTICE


The Drive Tool flashing window feature can be disabled via the “Configuration → Options” pull down menu.

The Drive Tool also displays traffic lights in the lower right-corner of the display window. In addition, the word “Fault” will appear under Mode within the Status window.


NOTICE

Red lights indicate Faults and yellow lights represent Alarms.

To display the most recent Fault Alarms, go to the Menu Bar and Select “Fault Log → Display Log...”





The ToolSuite software displays a pop-up window that informs the user that the Fault Log is currently being uploaded. Once the information is uploaded, a dialog box that lists the Fault Alarms in the order of their occurrence appears.



Name	Pos	Set Time	Reset Time
A1 Link	001	7/27/07 14:55:04	0/0/00 00:00:00
A1 Link	002	7/27/07 14:49:16	7/27/07 14:49:20
Wago Configuration	003	7/3/07 08:58:05	0/0/00 00:00:00
Wago Configuration	004	7/3/07 08:56:42	0/0/00 00:00:00
Wago Configuration	005	7/3/07 08:55:16	0/0/00 00:00:00
B1 OverTemp Warning	006	6/26/07 15:43:58	6/26/07 15:44:08
B1 OverTemp Warning	007	6/26/07 15:43:57	6/26/07 15:43:57
B1 Link	008	6/26/07 15:43:54	0/0/00 00:00:00
A1 OverTemp Warning	009	6/26/07 15:42:53	6/26/07 15:44:08
C4 OverTemp Warning	010	6/26/07 15:42:43	6/26/07 15:44:08
B4 OverTemp Warning	011	6/26/07 15:42:43	6/26/07 15:44:08
A4 OverTemp Warning	012	6/26/07 15:42:43	6/26/07 15:44:08
C3 OverTemp Warning	013	6/26/07 15:42:43	6/26/07 15:44:08
B3 OverTemp Warning	014	6/26/07 15:42:43	6/26/07 15:44:08
A3 OverTemp Warning	015	6/26/07 15:42:43	6/26/07 15:44:08
C2 OverTemp Warning	016	6/26/07 15:42:43	6/26/07 15:44:08
B2 OverTemp Warning	017	6/26/07 15:42:43	6/26/07 15:44:08
A2 OverTemp Warning	018	6/26/07 15:42:43	6/26/07 15:44:08
C1 OverTemp Warning	019	6/26/07 15:42:43	6/26/07 15:44:08
B1 OverTemp Warning	020	6/26/07 15:42:43	6/26/07 15:43:54
A1 Link	021	6/26/07 15:42:43	0/0/00 00:00:00
A1 Link	022	6/26/07 15:41:59	6/26/07 15:42:04
A1 Link	023	6/26/07 15:41:57	6/26/07 15:41:59
A1 OverTemp Warning	024	6/26/07 15:41:41	6/26/07 15:41:41
C4 OverTemp Warning	025	6/26/07 15:41:22	6/26/07 15:41:49
B4 OverTemp Warning	026	6/26/07 15:41:22	6/26/07 15:41:49
A4 OverTemp Warning	027	6/26/07 15:41:22	6/26/07 15:41:49
C3 OverTemp Warning	028	6/26/07 15:41:22	6/26/07 15:41:49
B3 OverTemp Warning	029	6/26/07 15:41:22	6/26/07 15:41:49
A3 OverTemp Warning	030	6/26/07 15:41:22	6/26/07 15:41:49
C2 OverTemp Warning	031	6/26/07 15:41:22	6/26/07 15:41:49
B2 OverTemp Warning	032	6/26/07 15:41:22	6/26/07 15:41:49
A2 OverTemp Warning	033	6/26/07 15:41:22	6/26/07 15:41:49
C1 OverTemp Warning	034	6/26/07 15:41:22	6/26/07 15:41:49
B1 OverTemp Warning	035	6/26/07 15:41:22	6/26/07 15:41:49
A1 Link	036	6/26/07 15:41:22	6/26/07 15:41:57
A2 OverTemp Warning	037	6/26/07 15:40:09	6/26/07 15:40:46
C1 Output Fuse Blown	038	6/26/07 15:40:09	6/26/07 15:40:52
B1 DC Bus Over Volt	039	6/26/07 15:40:09	6/26/07 15:40:52
A1 IGBT OOS 3	040	6/26/07 15:40:09	6/26/07 15:40:52
Cell Bypass Fault	041	6/26/07 15:39:43	6/26/07 15:39:49
A2 OverTemp Warning	042	6/26/07 15:34:22	6/26/07 15:34:34
A2 OverTemp Warning	043	6/26/07 15:34:22	6/26/07 15:34:34

If an alarm has reset itself, the reset time will be noted. If a fault condition no longer persists, you can reset the fault by clicking the “Reset” button in the Drive Tool window.




If all faults have been reset, the Drive Tool window will appear as shown above, without flashing.

NOTICE



The yellow traffic light indicates that an alarm condition still persists.

To change a drive parameter, select the desired parameter from within the configuration window and double click on it. This will cause a dialog box similar to the one below to appear. You can then type in the desired value (some parameters will be changed from a pick list). The limits, default value, and current value are displayed, along with a more complete parameter description than those shown in the configuration window. You can enter a comment as a

record of the change if desired. The “Set to Default” button will restore the default value. The “Help” button is not currently supported.



Desired values may also be edited by selecting a directory (folder) or a specific variable parameter by right clicking the icon and selecting the appropriate submenu item as shown below. The submenu provides not only the means to change values, but to search for specific IDs as well. Parameters that are changed from the default value will appear as reddish icons and parameters set to their default values are displayed as greenish icons.



NOTICE

To permanently change a drive parameter, select “Configuration” → “Save Data” from the pull down menu bar of the Drive Tool window.

3.7.2 Graphing Display

A list of the variables that you can display in the ToolSuite is given in Table 3-2. A total of ten variables can be displayed at the same time. Select variables with the Graphing submenu (ID# 10). Each variable has a scale factor and an offset. The Y-axis display range is -1.0 to $+1.0$. All variables are required to be scaled within this range to be visible on the screen. The value shown on the screen is the actual value divided by the chosen scale factor. Unless otherwise indicated, the variables are in per unit; hence the default Scale Factor of 1.0 is satisfactory for most variables.

The offset parameter shifts the zero point of the variable up or down on the plot window. For most variables, the default offset of 0.0 is sufficient.




Table 3-2: List of Variables Available for Display

Variable Name	Description
Ids	Measured motor magnetizing current
Iqs	Measured motor torque current
Ids reference	Motor magnetizing current command
Iqs reference	Motor torque current command
Iqs reference filtered	Filtered torque current command
Flux DS	Estimated motor flux
Flux QS	Flux input to PLL for motor speed and flux angle estimation (typically 0.0)
Vds reference	D-axis voltage command (or output of magnetizing current regulator)
Vqs reference	Q-axis voltage command (or output of torque current regulator)
Output frequency	Drive output frequency in rad/sec
Slip frequency	Estimated motor slip frequency in rad/sec
Motor speed (frequency-slip)	Estimated motor speed in rad/sec
Motor speed filtered	Filtered motor speed in rad/sec
Rloss for braking	Equivalent motor resistance during dual frequency braking
Xloss for braking	Equivalent motor inductance during dual frequency braking
Field weakening limit	Field weakening torque current limit
Dual Frequency Braking Limit	Current limit during dual frequency braking
Maximum Current Limit	Maximum torque limit (at output of speed regulator)
Minimum Current Limit	Minimum torque limit (at output of speed regulator)
Iq gain	Speed regulator enable signal
Ua reference	Phase A output voltage command
Ub reference	Phase B output voltage command
Uc reference	Phase C output voltage command
Flux D loss filtered	D-axis flux component at the loss inducing frequency
Flux Q loss filtered	Q-axis flux component at the loss inducing frequency
Id loss filtered	D-component of current at loss frequency
Iq loss filtered	Q-component of current at loss frequency
W loss	Loss inducing frequency in rad/sec
Ws filtered	Filtered drive output frequency
Theta loss	Flux angle of the loss inducing frequency in radians
Flux DS Filtered	Filtered motor flux

3.7 Operating the Drive Tool

Variable Name	Description
Ids Filtered	Filtered motor magnetizing current
Iqs Filtered	Filtered motor torque current
Vd Loss	Magnitude of loss inducing voltage
Ids No Load	No-load motor current
Stator Resistance	Stator resistance
Wp Reference	Pulsation frequency in rad/sec
Output Vector Angle	Motor flux angle in radians
Volt Second Phase A Measurements	Measured phase A motor volt-seconds
Volt Second Phase B Measurements	Measured phase B motor volt-seconds
Volt Second Phase C Measurements	Measured phase C motor volt-seconds
Ia Current Measurements	Measured phase A motor current
Ib Current Measurements	Measured phase B motor current
Ic Current Measurements	Measured phase C motor current
Ids Measured Current After Synch Filter (V/Hz)	Not used
Iqs Measured Current After Synch Filter (V/Hz)	Not used
Raw Speed Demand	*Raw speed demand in rad/sec
Auxiliary Demand Before Ramp	*Auxiliary demand before speed ramp in rad/sec
Auxiliary Demand After Ramp	*Auxiliary demand after speed ramp in rad/sec
Speed Demand	*Ran Speed demand & Aux demand before ramp
Speed Profile Output	*Output of speed profile routine in rad/sec
Critical Speed Avoidance Output	*Critical speed avoidance output in rad/sec
Polarity Change Output	*Output of polarity change function in rad/sec
Minimum Demand Output	*Output of minimum limit routine in rad/sec
Ramp Output	*Output of speed ramp function in rad/sec
Speed Demand At Limit Input	*Input signal to speed (maximum) limit function in rad/sec
Speed Reference	*Motor speed reference in rad/sec
Raw Flux Demand	Flux demand from menu
Flux Ramp Output	Output of flux ramp controller
Energy Saver Output	Output of energy saver controller

Variable Name	Description
Field Weakening Output	Output of field weakening controller
Flux Reference	Flux reference
Id Input Current	Real component of input current
Iq Input Current	Reactive component of input current
Phase A Input Current	Phase A input current
Phase B Input Current	Phase B input current
Phase C Input Current	Phase C input current
Phase A Input Voltage	Phase A input voltage
Phase B input voltage	Phase B input voltage
Phase C Input Voltage	Phase C input voltage
Zero Sequence Average	RMS value of zero sequence component in input voltage
Negative Sequence D Voltage	D-component of negative sequence in input voltage
Negative Sequence Q Voltage	Q-component of negative sequence in input voltage
D Voltage	Amplitude of voltage of line voltage (taking transformer tap setting into account)
Q Voltage	Q-axis component voltage used to drive input PLL for frequency estimation.
Input Frequency	Input (line frequency) in rad/sec
Input Power Average (kilowatts)	Input power
Input Power Factor	Input side power factor
Ah Harmonic Coefficient	Amplitude of A-component of harmonic chosen using menu setting
Bh Harmonic Coefficient	Amplitude of B-component of harmonic chosen using menu setting
Transformer Thermal Level	Output torque limit set by transformer thermal limit regulator
One Cycle Reactive Current Level	Input one cycle reactive current trip level
Single Phasing Current Level	Output torque limit set by input single-phasing regulator
Under Voltage level	Output torque limit set by input undervoltage regulator
Input Side Flux	Input voltage converter to flux for Up Transfer
Line Flux Vector Angle	Angle of input voltage in radians
Output Neutral Voltage	Input side neutral voltage
Sync Motor Field Current	Field current command (for synchronous motor)
Encoder Speed	Encoder speed output
Motor Voltage	Motor voltage (or drive output voltage)
Output Power Average (kilowatts)	Output Power

3.7 Operating the Drive Tool


Variable Name	Description
Phase A Filter Current	Filter current in A phase
Phase B Filter Current	Filter current in B phase
Phase C Filter Current	Clamped Filter current in C phase
Measured Phase A Volts	Actual Drive voltage A phase (Does not work)
Measured Phase B Volts	Actual Drive voltage B phase (Does not work)
Measured Phase C Volts	Actual Drive voltage C phase (Does not work)
Measured Output Neutral Voltage	Drive neutral voltage
Max Available Output Volts	Max available output voltage
Input Reactive Power (kVAR)	Input kVAR
Drive Efficiency	Efficiency
Drive State	Drive state
Up Transfer State	Up transfer state variable
Down Transfer State	Down transfer state variable
Drive Internal Losses	Difference between output and input power
Excess Input Reactive Current	Input to one-cycle algorithm, indicating the input reactive current allowance before a trip condition exists
Speed Droop	Amount of droop subtracted from the speed demand (rad/sec)
Precharge State Variable	State machine value for precharge transitions
Precharge Voltage	Input voltage during precharge
Input Real Current	Filtered real component of input current
Input Reactive Current	Filtered reactive component of input current
AFE Reactive Current Reference	Desired input reactive current in AFE system
AFE Input Voltage Feed-forward	Feed forward voltage term of AFE control
AFE Real Current Feed-forward	Feed forward current term of AFE control
Input Id Unfiltered	Real current before filtering
Input Iq Unfiltered	Reactive current before filtering
AFE kVAR	Input reactive power on AFE
AFE kW	Input real power on AFE
Maximum Demand Output	Clamped speed demand (at the maximum limit) at the ramp input
SMDC Mode State Variable	SMDC startup state machine variable Disabled = 0 Transition = 1 Enabled = 2

Variable Name	Description
Drive Loss Fault Limit	Threshold limit used by the Excessive Drive Loss Fault for tripping
Iqs Ref Ramp	Torque ramp output
HS dlay ang	High Speed delay angle
In V Fund Mag	Input Voltage Fundamental Magnitude
Rlbk Disable	Disable Rollback active
Total Current	Total Output Current filtered
Ph A out V	Phase A Output volts (rms)
Ph B out V	Phase B Output volts (rms)
Ph C out V	Phase C Output volts (rms)
Ph A out I	Phase A Output current (rms)
Ph B out I	Phase B Output current (rms)
Ph C out I	Phase C Output current (rms)
Max Tot I Limit	Maximum current limit
ExLoss Lev	Trip level used in excessive drive loss algorithm
HST State	High starting torque mode state
OT Lim	Drive over temperature roll back limit

* Refer to the Command Generator Diagram, DWG A1A459713, to see where these variables are used in the control code.

3.7.3 Time Scale Adjustment

The total time span of the screen can be adjusted using the Time Scale parameter (ID # 10000). The update rate of the screen depends on the traffic on the network. A small time scale of 20 seconds or less may result in broken traces. A time span of 30 seconds results in a uniform display with no gaps in the traces.




3.7.4 Freezing Graph on Fault

The screen can be set to automatically “freeze” whenever a fault occurs. This feature is enabled/disabled by clicking the right mouse button while the cursor is on the graphing window and selecting “Freeze On Fault.”

NOTICE

The “Freeze on Trigger” function **must** be disabled to enable the “Freeze On Fault” menu selection.

When this feature is enabled, the “Freeze On Fault” menu selection will display a check mark and the Graphics window title will show “Graphics – Freeze On Fault”. When this feature is enabled and all faults are cleared and a subsequent fault occurs, the graph will freeze five samples after the occurrence of the fault.



There are 100 samples across the entire graphing time scale.

3.7.5 Freezing Graph on Trigger


The screen can be set to automatically ‘freeze’ whenever the value of a variable being graphed reaches a set trigger point condition. This feature is enabled/disabled by clicking the right mouse button while the cursor is on the graphing window and selecting “Freeze on Trigger.”

NOTICE

The “Freeze on Fault” function must be disabled and the trigger **must** be properly set-up to enable the “Freeze on Trigger” menu selection.

The trigger is set-up by clicking the right mouse button while the cursor is on the graphing window and “Set up trigger...” is selected. Select the variable on which the trigger will be based in addition to the type of trigger and the trigger point. The trigger point is based on the non-scaled non-offset variable value. Also, enter the number of samples which will be displayed after the trigger point is reached. There are 100 samples across the entire graphing time scale.


When this feature is enabled, the “Freeze on Trigger” menu selection will display a check mark, and the graphics window title will show “Graphics – Trigger enabled.”




When this feature is enabled and the trigger conditions are satisfied, the graph will freeze after the number samples entered in the trigger set-up are subsequently graphed. The Graphics window title will then show “Graphics – Graph triggered.”

3.7.6 Post Processing of Data

The screen can be manually “frozen” by placing the mouse over the plot window, clicking on the right mouse button and choosing the “Freeze/Unfreeze” command (or using CONTROL P on the keyboard), or by using either of the two automatic methods described in the preceding subsections of this chapter.



While the screen is frozen, the “Export” command (available using the right mouse button) can be used to save the plot as a Windows MetaFile, BitMap File, or in a tabular form in a Text File (that can be read by Excel or any Text Editor). Alternatively, the plot can be sent directly to a printer.



NXG Debug Tool



The NXG Debug Tool is PC-based application software that provides a remote graphical user interface for Siemens medium voltage Perfect Harmony NXG Series Drives. With the Debug Tool, you can examine drive variables using a PC and a mouse, allowing you to monitor that drive's functions quickly and easily. The NXG Debug Tool is a high level GUI that runs on a PC equipped with the Microsoft® Windows Operating System. The NXG Drive Control and the PC running the NXG Debug Tool interface with each other using Ethernet and TCP/IP protocols.

4.1 System Requirements


The NXG Debug Tool is a Microsoft® Windows application requiring the .NET 2.x Framework. It requires Windows® 98/NT4.0/2000/XP/Vista, at least 128 MB of RAM, and a minimum of 15 MB of disk space.

4.2 Start and Configure the Debug Tool


If no configured drives exist, it will be necessary to configure a new one. To do this, click the "New" button in the "Drive configurator" area of the ToolSuite dialog box to display the New Debug Tool window as shown below.




In the new dialog box shown below, enter a drive name and the IP address of the drive in the space provided. Click the “OK” button.



The ToolSuite dialog box reappears, now showing the newly configured drive “New Drive.”



Double click the icon “New Drive” to start the Debug Tool. If the IP address is correct, the display should appear as shown below:



The following figures show examples of screens in the NXG Debug Tool:




Figure 4-1: Example of NXG Debug Tool Screen: SOP, Drive Misc Status Flags 2




Figure 4-2: Example of NXG Debug Tool Screen: Status, Synch Motor Misc




Figure 4-3: Example of NXG Debug Tool Screen: Status, Modulator

4.3 Operating the Debug Tool

The Debug Tool was designed to replace the local debug monitor and keyboard interface hardware previously used to provide internal debug information about the NXG Control. The tool uses pull down menus and contains the same screens as the previous debug monitor interface. To gain access to a feature of interest, simply click on the pull down menu to select that feature. Below is a list of available features:

Operation

NOTICE
Available features are dependent upon the version of drive software to which the Debug Tool is connected. The full feature set is available on NXG software version 5.3 or higher.

- Change IP Address
- Exit

Status

- General
- Advanced
- Synch Motor Misc
- Modulator
- Power Cell Status 1
- Power Cell Status 2
- AP Cell Status
 - DSP State
 - DSP Status
 - Misc Status
 - Cell Feedback
 - Feedback by Rank
 - Rank 1
 - Rank 2
 - Rank 3
 - Rank 4
 - Rank 5
 - Rank 6
 - Rank 7
 - Com Via TCP
- Wago
- Internal I/O 1
- Internal I/O 2
- Parallel Data 1
- Parallel Data 2

- Software/Firmware Versions

SOP

- Command Generator Flags
- Comparators
- Counters
- Drive Misc Status Flags 1
- Drive Misc Status Flags 2
- Drive Misc Status Flags 3
- Loss of Signal Flags
- Serial Flags
- Static Flags
- Synch Transfer Flags
- Temp Flags
 - Temp Flags 1 to 64
 - Temp Flags 65 to 128
 - Temp Flags 129 to 192
 - Temp Flags 193 to 256
 - Temp Flags 257 to 316
- User Interface
- Active Variables/Counters/Timers
- Timers
 - Menu Based
 - SOP Based
- Wago
 - Digital Inputs
 - Inputs 1-8
 - Inputs 9-12
 - Digital Outputs

Faults/Alarms

- Drive
 - Word 1 bits 0-31
 - Word 1 bits 32-63
 - Word 2 bits 0-31
 - Word 2 bits 32-63
 - Word 4 bits 0-31

- Word 4 bits 32-63
- User
 - User Faults 1–32
 - User Faults 33-64

Networks

- Status
- Network 1
 - Input Flags
 - Output Flags
 - Fixed Registers
 - Register Data
 - Global Data
- Network 2
 - Input Flags
 - Output Flags
 - Fixed Registers
 - Register Data
 - Global Data
- Internal Net
- TCP/IP Net
- Hex

Files

- List
 - Config Files
 - SOP Source Files
 - SOP Hex Files
- Upload
 - Config Files
 - Drctry File
 - SOP Source Files
 - SOP Hex Files
 - System Files

All system files

Diskmon.bin

Eagle.exe

Silcograph file

Language File

Language File
MinMax File
Modulator Look-up Table File
Version History File

Logs

- Fault
- Historical
- Event Log File
- Old Event Log File

About

- Current NXG Debug Tool version and connected NXG Drive Software version

NXG SOP Utilities

5.1 Introduction

Siemens ID Series of digital drives contain customized programmable logic functions that define many features and capabilities of the drives. These logic functions are combined into a *System Program* that can be edited either at the factory or in the field. Examples of logic functions include start/stop control logic, input and output control logic (e.g., annunciators, interlocks, etc.), drive-to-machinery coordination, and more. The *System Program* is stored on the system non-volatile memory, and runs in the drive under an interpreter, causing the intended logic statements to perform their functionality.

The *System Program* is the logic that maps the external I/O into the functionality of the drive. In its simplest form, it just maps internal states to external points. In more complex forms, additional complex logic, in the form of Boolean logic, as well as timers, counters, and comparators, express the system functionality to the drive.

Generally, this type of logic takes the form of ladder logic diagrams. Sum-Of-Products notation is a shorthand method for expressing the ladder logic in textual form. In fact, there is a direct correlation between the two, which is covered in the section on ladder logic and Boolean theory.

The SOP Utilities is a group of utilities under the ToolSuite umbrella program. It is launched much the same as the other tools. It performs most of the functionality on the PC running the ToolSuite, but has serial communications capability for uploading and downloading the *System Program* directly to the drive via an RS232 interface between the drive and the PC.

The purpose of the SOP Utilities Tool is to convert logic statements in the form of Sum-Of-Products (SOP) notation into a form of machine-recognizable code that is run under the built-in drive SOP interpreter. The mechanics of this operation are described in the drive manual and are not discussed in this context.

5.2 SOP Utility Tool Overview

To understand the use of this utility, we must look at the individual functions and describe the purpose of each. These functions are summarized in Table 5-1.

Table 5-1: SOP Utility Terminology

Name	Function
Source File	The source file is an ASCII text file containing simple Boolean statements and operators. This file is edited on a PC using any standard ASCII text editor. This file is used as the input to the compiler program and is unreadable by the drive. The source file uses the .SOP file extension.
Hex File	The hex file is a compiled version of the source file, and is in the format of an Intel ASCII Hex downloadable file. The hex file is a result or output of the compile process. This is the file that is sent from the PC to the drive over the communications cable, using the serial communications function of the Tool and software functions chosen from the drive menus. The hex file is viewable by a text editor, but is unreadable by the user. It must be reverse compiled to be viewed by the user. Optionally, during the compile process, the entire source file, with comments, may be appended to the hex file.
ASCII Text Editor	The ASCII text editor is a software program used to edit the source file of the system program. The default is Windows Notepad, but any text editor can be used, as long as no hidden, unprintable characters are used.
Compiler Function	The compiler function is built into and invoked from the SOP Tool. It is used to translate the ASCII text source file (.SOP) into hex. This program reads the input source file (.SOP), validates the statements for proper syntax and symbolic content, generates primitive logic functions that implement the higher level logic statements, and stores this information into an output file using Intel hex file format. The resulting .HEX file can be downloaded to the drive. With Version 2.4 NXG Drive software, the source file can be appended to the hex file for retrieval by the reverse compiler function.
Reverse Compiler Function	The reverse compiler program does the opposite of the compiler program. It uses the compiled hex file (with a .HEX extension) as the input, and produces an ASCII text output file (with a .DIS [for disassembly] extension) that can be read by the user via any standard text editor software. This program is useful if the original source file is lost, damaged, or unavailable. Note that any comments in the original source file will not be reverse compiled, since they are ignored by the compiler program when the hex file is created with Version 2.4 NXG Drive software. If the source file is appended to the hex file, a reverse compile will retrieve the source, complete with comments, rather than go through the reverse compile process.
Communications Function	The communications function is used to send the compiled version of the <i>System Program</i> from the PC to the drive or retrieve the file from the drive. The communication options must be configured for proper communications (i.e., baud rate, number of data bits, number of stop bits, and parity settings).
Communications Cable	This is a serial communications cable over which data (e.g., the <i>System Program</i>) is transmitted between the drive and the PC. The exact specifications of this cable vary, based on the drive being used and the type of connector available on the serial communications port of the PC.
Product Type	The supported product type is generally a Siemens ID-Series motor drive, Perfect Harmony, or other compatible drive. It uses the <i>System Program</i> that is stored in a nonvolatile portion of memory on the drive to evaluate logic statements in order to perform their functionality with the drive operation or I/O. Within its menu structure, the drive contains software functions used to enable uploading and downloading between the drive and the PC via RS232 serial communications. The settings of communications parameters in the drive must match the settings in the communication options in the Tool for proper communications during <i>System Program</i> transfers.

NOTICE

Intel hex format is an ASCII representation of binary data. The hex file mentioned in the previous table uses various record types to set the download location and to detect errors. The source file, if included, is simply appended to the end of the Intel Hex file, and does not affect the operation of the SOP file. It is not loaded into memory, but simply stored for future reference or retrieval.

5.3 Starting the SOP Utility Tool

Start the SOP Utility Tool by selecting the Utilities Tab as shown in Figure 5-1.




Figure 5-1: SOP Utilities Start Window

Once the SOP Utility Tool starts, the opening screen, as shown in Figure 5-2, will display.




Figure 5-2: SOP Utilities Opening Screen

Selecting the target source file also selects the target Directory (DRCTRY) file for mapping the valid Product flags and I/O, and automatically selects the Product type (see Figure 5-3). The source file can then be further edited by selecting the edit button. This will invoke the text editor – the default being the Windows Notepad. The default editor can be changed by selecting the “Change Default Editor” and then browsing to the desired text editor. A word processor can be used, but only if the output file is set for pure ASCII text, with no formatting characters embedded in the saved file.




Figure 5-3: SOP Utilities Window

5.4 SOP Development Process

The SOP general process consists of:

- Creating a text document explaining, in prose, the operation of the system, including all fault handling processes.
- Creating a ladder logic diagram of the control logic that is to be implemented in the SOP, including a detail of the I/O interface as matches the system drawings.
- Converting the ladder logic into sum-of-products statements utilizing Boolean logic and DeMorgan's Theorems.
- Creating a text document, the source file, with the appropriate statements and detailed comments as to the system use of the logic. This text file is given the extension of .sop, for sum-of-products notation source file.

The textual description is created in the SOP text templates. The templates are a series of spreadsheets that textually define the standardized TB2 designation, the WAGO assignment, the sequence of operation, etc. Templates are available for both air-cooled and water-cooled systems.

The standard logic diagrams and accompanying SOP function blocks are defined in Engineering Reports and are useful for creating the standardized functions of the SOP – both in ladder logic and in sum-of-products notation. The Engineering Report provides a standard

means to produce customer SOPs. The function blocks can be used as presented, or can serve as a template for customer requests not specifically addressed by the blocks.

The SOP input source file is composed in an ASCII text editor and compiled by a Siemens LD A compiler. SOP testing is performed at the Siemens LD A facility.

The remainder of this chapter details the process of creating and compiling the SOP.

5.5 Overview of the Compile Process


Once the source file is completed, the next stage is compilation. This is necessary to transform a human-readable document into a machine-readable program.

Compilation requires a directory file, which is determined by the type of target drive to be used. This is determined in one of two ways. Either the drive type is embedded as the first line of the source file, or if this statement is missing, the drive type must be explicitly determined by selecting from a picklist.

The directory file contains data critical to the compile process. It is an ASCII text file, which contains the variable names along with designators that the compiler uses. Comments are included to help understand the meaning and use of the variables. It is useful to view the directory file as the *System Program* is being developed, to obtain the correct spelling of the system flags and variables. It is for this reason that the file is readable text. However, it is critical to **not** edit the directory file without first-hand intimate knowledge of the data structures used within the file.


The compilation process reads each logic statement from left to right, creating data tables for the variables used, logic statements, operators, and output assignments. The result is readable by a special interpreter that resides within the product core code. The actual names are not used, but are substituted by the compile process, substituting and assigning special internal memory locations for each. This reinforces the need for proper spelling of variables as they appear in the directory file.

Selecting the Compile button begins the compile process, which then prompts the user to select whether to attach the source file to the generated hex file:




On successful completion of compilation, a dialog box will pop up stating this along with additional pertinent information on the size of the file, checksum of the SOP hex file, and number


of counters and timers used, along with other information that is useful for debugging purposes by factory personnel:




Should an error occur during compilation, an error dialog will appear:



Acknowledging the error reveals the source of the error by logic statement number, and by text file line number:



An output file is not generated until a successful compilation occurs. Should the name of the source file not conform to the 8.3 DOS naming convention, and the Product type be a Next-Gen drive, an additional message will appear:



NOTICE

This is not a limitation of the SOP compiler, but of the NXG operating system file system, so it only applies to this Product type.

For a list of other compile errors, see Table 5-6 in this chapter.

5.6 Input Source File

The input source file is the ASCII text version of the *System Program* that is edited by the user. Editing can be performed using any standard ASCII text editor on a PC. The file can contain both logic statements and explanatory comments to aid in documenting the content and intent of the logic statements. With the exception of simple true and false logic assignments, the order of the statements in the source file is the order in which the statements will be executed by the drive's run time software. True and false statements are placed first in the hex file at the time of compilation, and are executed only once after *System Program* initialization. All other statements are executed in order from top to bottom in a continuous manner. Results of the evaluation of a logic statement are immediately available as inputs to statements that follow.

The format for a *System Program* source statement is as follows:

output_symbol = {unary_operator} input_symbol { [binary_operator {unary_operator} input_symbol] ... };

where:

output_symbol represents an output symbol defined in the symbol directory file
= the assignment operator (only one per source statement)
input_symbol represents an input symbol defined in the symbol directory file
unary_operator Boolean NOT operator (/ character)
binary_operator Boolean operators OR and AND (+ and *, respectively)
{ } represents optional syntax
[] represents required syntax
... the previous operation may be repeated
; statement terminator

The statement can span multiple lines and can contain spaces as needed for readability. The output_symbol is a required field and can be any symbol that would be valid as an output variable. The output_symbol is followed by one or more optional spaces and then the required assignment operator "=". A source statement can contain only a single assignment operator.

NOTICE

Program statements may span multiple lines by breaking the line at a convenient operator. The single line length of 132 characters should not be exceeded.

The input side of the equation must equate a simple Boolean form (either true or false) after evaluation. It is formed from either a simple input symbol (possibly negated with a NOT unary operator) or a combination of input symbols on which binary operators operate. Input symbols and binary operators are evaluated left to right by the run time software. The precedence of operations is summarized in the next section.

NOTICE

- | |
|---|
| <ul style="list-style-type: none"> • Each statement must be terminated with a semicolon. • Symbol names are not case-sensitive to the compiler. The symbols symbol_1, Symbol_1, and SYMBOL_1 are all treated identically. |
|---|

NOTICE

In the case of logic assignments, where the source state is a simple “true” or “false,” the assignment is made only once at runtime software initiation.
--

The execution flow of the run time software is as follows:

1. Comparator evaluations are performed and the resulting system flags are updated.
2. Input flags are scanned and their present state(s) are recorded.
3. Logic equations are executed based on the recorded input states.
4. The results of the logic statement(s) are output.

A sample input source file is illustrated at the end of this chapter. Although this sample source file may appear to be very complex, it contains only four basic types of statements:

- Logic statements that can continue to additional lines
- Comment lines for explanation of code operation and purpose, or to document I/O assignments
- Text labels for user-designated faults
- Assignments that substitute a user-defined label for an internal variable for easier understanding

Semi-colons serve a dual purpose in the source file. Every logic statement must be terminated by a semi-colon. Also, comments are any text that follows the semi-colon at any placement location on a line. All lines that begin with text instead of a semi-colon are interpreted by the compiler program as logic statement lines. Program source lines may continue to other lines and are finally terminated with a semi-colon. This technique can be used to make the logic more readable. Based on this, comments may not be added within the scope of a single, multi-line program statement, as the semi-colon will be interpreted as the end of the logic statement, and the next line without a semi-colon, as the next logic statement.

Logic operators separate variables used within logic statements. Every variable must have some logic operator following it in the logic statement. The logic operators supported in the SOP are the AND (*), OR (+), ASSIGNMENT (=), statement termination (;), and NOT (/).

Comment lines provide additional information to the reader, but provide no additional information for the compiler. It is strictly a tool for better understanding of the intended logic of the logic statements. As such, comments should not be added simply to be there, but must be structured to provide an overview of what the logic is trying to accomplish in the system. This

information is vital to the maintenance of the SOP for future reference as to the intent of the logic, not only for the originator, but also for anyone who must maintain or change the code in the future. It is a tool for conveying information that is not intuitively apparent in the logic statements themselves.

Substitution names also serve to clarify the intent of the logic statements. When a generic system flag, such as a timer, counter, I/O assignment, or temp flag, is used for a specific purpose, consider using the substitution operator to define a label that better suits its functionality. For example, if an output is used to switch on a pump or fan, then consider renaming the output "Pump_on", or "Fan_on" instead of the generic "ExternalDigitalOutputxxx_O".

NOTICE

- All source code comment lines are ignored by the *System Program* compiler. Only the program statements (with any optional comment suffixes omitted) are compiled into the binary (hex formatted) *System Program* that is downloaded to the drive. For this reason, the process of reverse compiling the *System Program* yields source code without comments. For more information on the process of reverse compilation, refer to Table 5-1 and Table 5-7.
- Comment text cannot be added within the context of a multi-line logic statement, but must follow the semi-colon terminating the logic statement. Logic statements can extend to multiple lines for readability, but must be terminated by a semi-colon at the end of the statement.
- Logic statements must not exceed 132 characters in length. The compiler truncates any single line beyond that length and ignores anything further in the line. This length limitation is for a single line, and the count is reset when a new line is started. Therefore, continuing long logic statements to multiple lines is essential for proper compilation as well as better readability.
- Typically, logic statements are broken at the OR operator (+) in the sum-of-products notation.
- All statements must be in the form of sum-of-products notation.

5.6.1 System Type Identification

Because the compiler and reverse compiler support a number of different end products, the compiler needs to know what the target system is, so that it can generate the proper code for that target system.

To identify the system type, include the system type identifier command as the first line in the *System Program* SOP file. The syntax of this command is shown below:

```
#system_type
```

The statement must be on the first line, a pound sign (#) character must appear in column 1, and the program line must end with a semicolon. For Perfect Harmony Drives, the proper format of this command is shown below:

```
#NEXTGEN;
```

NOTICE

A comment can follow the semicolon with the system type identification command.

The compiler also recognizes other system types.

Table 5-2 shows the interface for the pull-down product type selector. Alternatively, if you have an SOP file that does not include the `#system_type;` identifier, then the Product Type selector pull-down is activated and a selection must be made before a directory file can be selected or before compilation is enabled (note that the Compile button is grayed out until after the selection is made).

Table 5-2: Product Types Recognized by the System Compiler

Target Product Type	Identification Command
Perfect Harmony	#HARMONY;
454 GT	#ID_454GT;
ID-CSI	#ID_CSI;
DC Harmony	#HARMONY_DC;
ID-2010	#ID_2010;
NXG Control	#NEXTGEN
Silcovert H	#SILCOVERT_H
High Availability	#HIGH_AVAIL




Figure 5-4: SOP Utilities Compiler Showing Product Type Pull-Down

Table 5-3: Directory Filename Associations

Target System Type	Directory File Name
Perfect Harmony	DRCTRY.PWM
454 G T	DRCTRY.IGB
ID-CSI	DRCTRY.CSI
DC Harmony (e.g., torch supply)	DRCTRY.HDC
ID-2010	DRCTRY.DC
NXG Control	DRCTRY.NXG
Silcovert H	DRCTRY.SIH
High Availability	DRCTRY.HA

5.6.2 SOP Source File

The SOP file, as mentioned previously, is written with a text editor or a word processor set for pure ASCII text (having a .TXT file extension) with no control or formatting codes, with the exception of horizontal tabs (ASCII code 09h) and carriage returns (0Dh). Only printable characters and spaces (20h) can be used. The file consists of the format shown in Table 5-4.

Table 5-4: SOP Text File Format

Item	Description
Drive type specifier	This must reside on the first line of the file prefixed with the pound sign (#) and followed with the name of the drive (in the case of Perfect Harmony this would be #NEXTGEN;).
Header	A comment field containing the following information: Title - Siemens LD A Perfect Harmony drive Program part number Customer name Sales order number and Siemens drive part number Drive description Original SOP date File name Engineer name (Originator) Revision history (date and change description). Example: <pre> ; Siemens Perfect Harmony Step Pwm Ac Motor Drive ; System Operating Program - Standard Performance ; NXG Control ; ; ; Program Number: 18xxxxxx.SOP ; Customer: xxxxxxxxxxxxxxxxxxxxxxxx ; Siemens Sales Order: xxxxxxxx ; Siemens Part Number: xxxxxx.xx ; Description: xxxxx HP, xx.x kVac in - x.x kVac out, Size xx ; ; Original mm-dd-yy <initials>: Original version. ; ; REVISIONS: ; Changed mm-dd-yy - <initials>: ECR number - Description of changes </pre>
Operators	Comment field containing operators and symbols Example: <pre> ; = equals * logical AND + logical OR / logical NOT ; ; comment line </pre>

Item	Description
I/O specifier	Comment field describing the system input and output flags as they relate to the external system. This would include any user faults and notes on menu settings, such as Comparator setups and XCL settings, as they apply to the <i>System Program</i>. These can (and should) be grouped logically to allow easy access to information and to make the SOP more understandable. Example: <pre> ;----- ; Wago Digital Inputs (dedicated) ;----- ; RemoteStart_I EDi01-a - Remote start - Momentary close to start ; RemoteStop_I EDi01-b - Remote stop - Momentary open to stop ; RemoteFaultReset_I EDi01-c - Remote fault reset - Momentary close to reset drive faults ;----- ; Comparator Flags ;----- ; Values of "Fixed Percentage" is what is entered in the comparator menu. ; The percentage is entered as the desired percentage of signal full scale. ; Comparator1_I Coolant conductivity > 3 uS Process Alarm ; 1A - Analog input 3 ; 1B - Fixed percentage = 30 % ; 1C - Magnitude comparison </pre>
User fault messages	Assigns the text to be displayed when this particular user fault is activated. Example: <pre> ; UserText1 = "UPS On Inverter"; ; UserText2 = "UPS Alarm"; </pre>
Replacement variable assignment	Allows the user to redefine the label on common variables to make the SOP code easier to read. The compiler only uses this during compile. If any information is to be stored, it is recommended that the source file be attached. Example: <pre> \$ManualControlOn = Counter01; \$ManualControlOff = CounterReset01; </pre>
Main logic section	All the equations and assignments for the configuration, annunciation, and operation of the drive. These should be logically arranged with careful consideration given to the order of evaluation of the equations.

5.6.3 Input Flags

Input flags are identified by `variable_I`. Input flags are symbols that are encountered on the right-hand side of a source statement (to the right of the equals sign) that express the state of an input to the system. They may reflect the state of a digital input (e.g., *ExternalDigitalInput01a_I*, *ExternalDigitalInput01b_I*) or switch (e.g., *KeypadManualStart_I*), the state of a system process (e.g., *Cells_I*, *OverloadFault_I*, *OutputPhaseOpen_I*), internal variable, Comparator flag (e.g., *Comparator_1*), or a simple literal (TRUE, FALSE). These input flags are combined using the unary and binary operators to form logic expressions.

Digital input flags generally represent the state of a discrete digital input signal into the system. These may be a 24-volt logic input, a key switch or push-button in the system, or some form of a binary input. They also can be internal flags that indicate a state or condition of the drive, e.g., faults, warnings, limits, etc. The inputs are scanned at the beginning of each execution cycle, but may reflect older information in some cases.

System constants TRUE and FALSE are predefined and can be used as input terms to an expression.

There exists the capability to compare the value of certain system variables against preset thresholds in real time, and then use the results of the comparisons (TRUE or FALSE) in the *System Program* to control actions on the drive. The variable(s) to be compared and the thresholds are entered into the system using the keypad. The output of the comparisons (*Comparator1_I* ... *Comparator16_I*) are available for use in the *System Program* as input symbols.

5.6.4 Output Flags

The output flags all have “_O”, tagged to the end of the variable name (`variable_O`). The output flags (the symbol placed on the left-hand side of the assignment “=” operator) direct the result of the input expression towards an output purpose. Output flags represent items such as digital outputs and system control switches.

Table 5-5: Types of Output Flags

Types	Examples
digital outputs	<i>ExternalDigitalOutput01a_O</i>
system control switches	<i>AutoDisplayMode_O</i> , <i>RampStop_O</i> , , <i>RunRequest_O</i>

NOTICE

Digital output flags generally represent some form of discrete digital output bit(s) from the system. These may be a relay coil driving contacts (NO or NC), direct digital outputs, or lamp controls. The digital output signals are updated at the completion of each *System Program* execution loop.

NOTICE

The Perfect Harmony series of drives (as well as all other ID series drives) have a set of pre-defined symbols that describe control outputs or “switches” that can be controlled by the *System Program*. These switches can control functions such as the source of the speed reference, a selection for the system acceleration rate, and a multitude of others. In most cases, to cause the system to perform in the intended manner, the proper control switches must be set (and others cleared) by the *System Program*. The default state for all control switches is FALSE. Unless the *System Program* sets the switch to TRUE, it will be inactive (FALSE).

NOTICE

No variable_I, Input variable can appear on the left side of the “=” sign. Both variable_I and variable_O can appear on the right side of the “=” sign

NOTICE

Only one switch should be set at any one time from any functional grouping of switches (e.g., command generator input grouping).

There is a set of Boolean temporary flags available to hold temporary or common expressions in the *System Program*. By using these temporary flags to hold common expressions, *System Program* execution times can be improved. The *System Program* compiler does not perform any optimization, it generates code closely matching the equations as written. If there are expressions that are repeatedly evaluated, set a temporary flag to the intermediate results, and then use the flag instead of the longer expression.

For example:

```
ExternalDigitalOutput01a_O = ExternalDigitalInput01_a +
ExternalDigitalInput01b + RunRequest_O;

SetPoint1_O = ExternalDigitalInput01a_1 +
ExternalDigitalInput01b + RunRequest_O;

SetPoint2_O = ExternalDigitalInput01a_1 +
ExternalDigitalInput01b + RunRequest_O ;
```

could be replaced with:

```
TempFlag01 = ExternalDigitalInput01a_1 +
ExternalDigitalInput01b _1 +
RunRequest_O;

ExternalDigitalOutput01a_O = TempFlag01;

SetPoint1_O = TempFlag01; SetPoint2_O = TempFlag01;
```

A time-out function may be implemented with *System Program* timers. These timers are enabled using logic statements and the output (based on the timer expiring) is available as an input to logic statements. The time period is set in seconds with the resolution. The unit specified in the logic statement is seconds (with a decimal fraction rounded to the nearest internal

resolution). Time intervals are up to 16,383.5 seconds for the Next Gen version of Perfect Harmony.

The statement:

```
Timer01(20.0) = symbol_a;
```

enables timer 1 if *symbol_a* is true. The statement:

```
output_1 = Timer01;
```

sets the symbol *output_1* true if the timer has expired (timed out). In the example above, if *symbol_a* is false, *output_1* will be false. If *symbol_a* is set true, then 20 seconds later, *output_1* will be set true (assuming *symbol_a* remains true).

Once the enabling logic goes FALSE, the entire time-out period must pass before the timer will time-out. Should it go FALSE before the time-out period, the timer count is reset to zero, and the timer must go the entire period before timing out.

Counters in a *System Program* can be used to count the number of FALSE to TRUE transitions of the counter input. A corresponding counter reset input is used to reset the counter value to zero. For example:

```
Counter01(13) = input_a;
CounterReset01 = input_b;
output_a = Counter01;
```

If *input_b* is set TRUE, Counter01 is set and held to zero. If *input_b* is FALSE, after 13 FALSE to TRUE transitions of *input_a*, the symbol Counter01 (and *output_a*) will be set TRUE. After 13 transitions, Counter01 will remain TRUE until Counter01 is cleared by CounterReset01. The maximum count value is 32767. The count value must be an integer.

5.6.5 Redefining Flag Names

To make flag names more intuitive, you can redefine flag names so that your names may be substituted for the generic flag names thereafter. The definitions are made near the start of the program to ensure that they are defined when needed. The format for the definitions is:

```
$NewFlagName=nameInDirectoryFile
```

where NewFlagName is your new definition, and nameInDirectoryFile is the flag name found in the drty.ngn file.

For example, a typical SOP program might define flags as follows:

```
Counter01(30) = /ExternalDigitalInput01f_I*
ExternalDigitalInput01e_I*Timer00;
CounterReset01 = ExternalDigitalInput01e_I;
```

If you include the following at the start of the program:

```
$FireAlarmCircuitTimer = Counter01;
$FireAlarm_I = ExternalDigitalInput01f_I;
$FireAlarmPumpHasOverheated = ExternalDigitalInput01e_I;
$FireAlarmWarningTimer = Timer00;
$ResestFireAlarmCircuitTimer01 = CounterReset01;
```

then the lines in the program become:

```
FireAlarmCircuitTimer (30) = /FireAlarm_I*/
FireAlarmPumpHasOverheated_I *FireAlarmWarningTimer;
ResetFireAlarmCircuitTimer01 = FireAlarmPumpHasOverheated_I;
```

5.7 Compiler Operation

As discussed earlier in this chapter, three files are accessed during the compilation process: the source (or SOP) file, the DRCTRY.NGN (directory) file, and the output hex file. When the compiler is invoked, it first opens the SOP file to determine if it contains a *system_id* definition line as the first line in the file. This line defines the target system type to the compiler. If the necessary files are not found in the default directory, you may search elsewhere using the standard Browse button.




Figure 5-5: Selecting the .SOP File Using the Browse Button

The System type information is used to search for a proper directory file to use during compilation. The type information is placed into the hex file so that the *System Program* cannot be used in the wrong type of system (e.g., loading a *Harmony System Program* into a 454 *GT* drive).

NOTICE

If you use the Siemens LD A SOP Utilities program to compile an SOP file that does not include the *#system_type;* identifier, then the Product Type drop-down list is enabled, and you must select the appropriate product type. This selection will then be compiled into the resulting hex file.

NOTICE

The DRCTRY.NGN file must adhere to certain syntax and format rules. Refer to Appendix *Operators and Precedence*.

The compiler searches for the directory file in the current directory first. If it is not found there, the compiler provides a browse function for finding an appropriate file. In all cases, the operator can verify that the intended file was used.

5.8 Output Hex File

Any inconsistencies that occur during the compilation process are flagged and error messages are displayed in a pop-up window. These error messages indicate the problem and lead the user towards problem resolution. Error messages are listed in Table 5-6.5-6

After successful processing, the third and final file is created. This is the hex file and it is named the same as the source file with the extension changed to ".HEX." The entire recompiled *System Program* and is summed up in a modulo 256 result that is inverted (2's complement) and placed in the header of the compiled *System Program*. This is the *System Program* checksum. The output is formatted in Intel 8086/8088 record format with a starting load offset of 0000. Each record consists of 16 bytes of data. Zeroes are appended to the final record for padding.

When interpreted as an Intel hex file by the drive during the download process, a binary image of the logic functions results. These logic functions are stored and later executed by the drive. Each line of the hex file contains its own checksum. In addition, the compiler generates an overall *System Program* checksum. All of these checksums are validated during *System Program* downloading and restart to ensure correctness prior to storing the statements inside the drive.

When downloaded into the drive, the *System Program* is structured into sections. The first section is called the *header* and contains *System Program* location pointers, as well as the version number and the *System Program* checksum.

The other sections concern the functionality of the *System Program* and are not covered here.

5.9 Downloading a System Program (Hex File)

When the text for a *System Program* has been created, and the text file has been compiled into a hex file using the *System Program* compiler, the resulting hex file must be downloaded into the drive to become functional. Software embedded in the drive can be invoked to accept the properly formatted hex file into the drive using the RS232 serial port as the transfer medium. The program can be downloaded in one of two methods:

1. Using the Upload/Download component of the Siemens LD A SOP Utilities software. This method can be used by PCs that have at least Windows 2000 or later installed.
2. Using a terminal emulation program on the PC set up in ASCII file mode. This method can be used by PCs that do not run Windows or have a Windows version before Windows 95 (using a DOS™ window). A native Windows terminal emulator can also be used.

5.9.1 Siemens LD A SOP Upload/Download Utility Method

The .HEX file must be downloaded using the Upload/Download component of the Siemens LD A SOP Utilities program.




Figure 5-6: Siemens LD A SOP Utilities - Upload/Download Component

1. Invoke the Siemens LD A SOP Utilities program.
2. Select the Upload/Download tab.
3. Enter the HEX file to be downloaded.
4. Select the Download radio button.
5. Set the baud rate from the drop down box to 9600 baud.
6. Connect the appropriate serial port of the host PC to the DB9 port of the drive using an appropriate serial cable (9-pin with appropriate connectors).
7. Select the "System Program Download" function menu (9120) of the drive. The drive will display download status information on the front panel (e.g., "Downloading from RS232"). The drive will indicate when it starts to receive data.

At the end of each hex line received, the drive will cause a bar in the last column of the keypad display to rotate to indicate that data is being received. Each data record that follows is then checked against its own checksum and loaded at the appropriate address in RAM. Errors in a data record result in a displayed error message and termination of the download process.

NOTICE

Check the downloaded *System Program* file for the proper version number. If the user tries to download a *System Program* that was compiled with the wrong DRCTRY.NGN file (for example, an obsolete DRCTRY.DAT file), an error message will be displayed and the downloaded *System Program* will not be transferred to FLASH. Further, the system will not run a motor if, on power-up, the software detects a *System Program* checksum error or an out-of-range *System Program* version stored in the FLASH. To use an older *System Program* in a drive with newer software, the *System Program* must be recompiled with the newer DRCTRY.NGN file before it is downloaded.

5.9.2 Terminal Emulation Method

The .HEX file must be downloaded with a terminal emulation program on the PC set up in ASCII file mode.

1. Set the baud rate (the same as drive's baud rate parameter), parity (none), data bits (8) and stop bits (1) of the communications software on the host PC, notebook, or laptop computer.
2. Connect the appropriate serial port of the host PC to the DB9 port of the drive using an appropriate serial cable (9-pin with appropriate connectors).
3. "Enable" the communications software (i.e., prepare the software to either send information to the drive or receive information from the drive). This basically puts the PC and communications software into a ready state. Typical communications software packages include Microsoft® Windows Terminal and Procomm-Plus (only Windows 95™-compatible, if running this operating system).
4. Use the "System Program Upload" or "System Program Download" function from the Serial Functions Menu (9110) of the drive to perform the desired function. The drive will display download status information on the front panel (e.g., "Downloading from RS232").

The drive will indicate when it starts to receive data. At the end of each hex line received, the drive will cause a bar in the last column of the keypad display to rotate to indicate that data is being received. Each data record that follows is then checked against its own checksum and loaded at the appropriate address in RAM. Errors in a data record result in a displayed error message and termination of the download process.

NOTICE

Check the downloaded *System Program* file for the proper version number. If the user tries to download a *System Program* that was compiled with the wrong DRCTRY.NGN file (for example, an obsolete DRCTRY.DAT file), an error message will be displayed and the downloaded *System Program* will not be transferred to FLASH. Further, the system will not run a motor if, on power-up, the software detects a *System Program* checksum error or an out-of-range *System Program* version stored in the FLASH. To use an older *System Program* in a drive with newer software, the *System Program* must be recompiled with the newer DRCTRY.NGN file before it is downloaded.

5.9.3 Termination

Termination occurs when a valid “End Record” is received. If any error in transmission occurs, or if the user manually “CANCELS” the transmission, the original *System Program* will be copied back down from FLASH. If the new program is accepted and reaches normal termination, it is then transferred from temporary RAM into non-volatile FLASH storage, overwriting the original. The *System Program* is then re-initialized with the new information, and the *System Program* is restarted, executing the new statements.

NOTICE

To cancel the download process during the *System Program* download, a [SHIFT]+[CANCEL] key sequence can be entered from the drive's keypad to terminate the download process and restore the system to its original state.

Since the *System Program* execution must be stopped while downloading a new *System Program*, the drive cannot be running during the download process.

Table 5-6: Compiler Error Messages

Error Message	Description
DRCTRY Error ERROR in line <i>nnnn</i> - << <i>flag name</i> >> is longer than 43 characters. The error occurred in the Directory file.	While loading, the <i>System Program</i> flag found that the directory file is too long. The offending flag and its line number in the directory file are listed. The directory file is probably corrupted. Get the latest version and try again.
DRCTRY Error ERROR in line <i>nnnn</i> - << <i>flag name</i> >> can't find system address.	While loading the directory file, the compiler can't determine the system address. The flag name and error line number points to the source of the error. The directory is probably corrupted. Get the latest and try again.
DRCTRY Error ERROR in line <i>nnnn!!</i> << <i>flag name</i> >> can't find bit address.	While loading the directory file, the bit address cannot be determined. The file is probably corrupt. The flag name and line number should show where the corruption occurs. Replace the directory file and try again.
DRCTRY Error ERROR in line <i>nnnn!!</i> << <i>flag name</i> >> can't find type code.	While loading the directory file, the flag type cannot be determined. The file is probably corrupted. The flag name and line number should show where the corruption occurs. Replace the directory file and try again.
SOP Error ERROR!! User Text <i>text flag</i> defined multiple times.	The user text assignment flag displayed has been used multiple times in the System Program. Find the occurrences and correct them, then recompile.
SOP Error ERROR!! Expecting \"' found >> CR or LF <<	The compiler was expecting an end quotation mark and found an end of line instead. The error location will show in another popup window at the end. Edit the source program and try again.
SOP Error ERROR!! User Text <i>flag ID</i> is longer than 24 characters.	User Text must not exceed 24 characters - the limit on the keypad directory. Edit the source file and try again.

5.9 Downloading a System Program (Hex File)

Error Message	Description
SOP Error ERROR!! Expecting <code>'\'</code> found <code>>> character <<.</code>	The compiler was expecting an end quotation mark but found another character instead. Locate the error by the line number shown in an error popup window, edit the file, and try again.
SOP Error ERROR!! Expecting <code>'='</code> found <code>>> flag name <<.</code>	The compiler is looking for the assignment operator and found another flag. This is usually caused by improper use of the statement terminator, the semi-colon, or the comment indicator--also a semi-colon.
SOP Error ERROR!! opcode <code>>> token name <<</code> not supported.	The compiler has parsed the source code and found a "token" it interprets as an opcode, but is not an acceptable operator (<code>"=</code> ", <code>"+"</code> , <code>"*"</code> , <code>"/"</code> , or <code>";"</code>). Check the file and try again.
SOP Error ERROR! Timer enable <i>flag name</i> cannot be set false.	The timer flag shown was set to false. This will never do anything and is therefore displayed as an error.
SOP Error ERROR! Counter reset <i>flag name</i> cannot be set true or false.	Setting the counter reset flag that is named prevents proper operation of the counter. The name of the reset flag is displayed to help find the error.
SOP Error ERROR! Counter enable <i>flag name</i> cannot be set true or false.	Counters count transitions from low to high. Setting the counter to true or false renders the counter useless and is thus displayed as an error. The offending flag name is displayed.
SOP Error ERROR!! input <code>>> flag name <<</code> is not an input type.	The flag named is not defined as an input only flag and cannot be used as an input (on the right side of the equals sign).
SOP Error ERROR!! Expecting <code>','</code> found <code>>> flag name <<.</code>	This error is usually displayed when the preceding logic statement is not properly terminated by a semi-colon.
SOP Error ERROR!! input <code>>> flag name <<</code> not in directory.	The input flag named is not found in the directory file. Check the spelling and try again.
SOP Error ERROR!! Expecting <code>'='</code> found <code>>>flag name <<.</code>	The compiler is expecting the assignment operator as it is parsing what it thinks is a new logic statement. Check the syntax in the preceding statement, edit the file, and try again.
SOP Error ERROR!! attempt to redefine output <code>>> flag name <<.</code>	An output flag has a logic statement assigned to it (it is used on the left side of the assignment operator) more than once. Find and change the offending line and recompile.
SOP Error ERROR!! output <code>>> flag name <<</code> is not an output type.	The flag named is not defined as an output only flag, and cannot be used as an output (on the left side of the equals sign).
SOP Error ERROR!! output name <code>>> flag name <<</code> not in directory.	The output flag on the left of the equals sign is not found. Check the spelling of the flag name shown and try again.

Error Message	Description
SOP Error ERROR!! Too Many Timers and Counters (Max 128 combined).	There is a fixed number of timers and counters that can be used in any <i>System Program</i> . The limit is 128 for the total of both timers and counters. Try to reduce the number of either timers or counters and compile again.
SOP Error ERROR!! Drty name <<flag name >> used in alias not found in drty file	The flag named as an alias is not found in the directory file. This is an advanced feature of the new compiler being released with the version 2.5 drive software, but will work with version 2.4 software. Define statements that can be used for more user-friendly names of functions, and substituted for fixed names.
SOP Error ERROR!! <<flag name>> is longer than 43 characters.	<i>System Program</i> flag names are limited to 43 characters, and are truncated to that number. A flag longer than this is probably caused by a typo. Find and fix the error and recompile.
SOP Error ERROR! A timer or counter (<i>flag name</i>) must be defined as an output before being used as an input!	Timers and Counters are unique system flags. They require storage space for intermediate values for time or count, and additional space for storing their preset, enable logic state, reset, and output status flag. Therefore, the Timer or Counter must logically be assigned (on the left of the equals sign) before the status flag (the timer or counter name without the value) can be used as an input flag (to the left of the equals sign).
SOP Error ERROR!! input scan table is full	The storage space for the number of inputs is limited to the assignment of unique inputs. The limit for NXG is 800 entries. A flag is assigned only once even if used multiple times (as an input).
SOP Error ERROR!! Counter reset (<flag name>) used without a defined counter. A counter must be defined as an output first!	A reset flag is a unique flag used for resetting counters, but due to the storage situation as described above, a reset flag cannot appear in a <i>System Program</i> before the counter is defined as an output (to the left of the equals sign). If the logic for the reset must appear before the definition, the use of a temporary flag to define the logic state can appear before the Counter, with the reset flag assigned to the temporary flag. Rewrite the logic and recompile.
SOP Error ERROR!! output scan table is full	The output scan table can contain a maximum of 800 unique entries. Timers and counters are created in the output scan table even if they are used as an input. These are the entries that map an I/O table location to the real world source (memory location, hardware output, etc.) And only one is required for each flag used. Bit flags take up 8 spaces even if only one is used.
SOP Error ERROR!! input scan table is full	The input scan table can contain a maximum of 800 unique entries. These are the entries that map an input flag from the real world source to the I/O table. Only one entry is required for each flag used. Bit flags take up 8 spaces even if only one is used.

5.9 Downloading a System Program (Hex File)

Error Message	Description
SOP Error ERROR!! logic table is full.	The logic table can contain a maximum of 5000 total entries. The entries are created by logic statements as strings of inputs and outputs in sequential order separated by their operators. Each input, output, and operator used counts as an entry.
SOP Error ERROR!! The maximum time for a single timer is 16383.5 secs! (4.55 hours)	The amount of time assigned to a timer exceeded the max value allowed. This value applies for NXG software only.
SOP Error ERROR!! expecting) got>> name <<	Timers and counters, when they are defined, must have the flag name followed by a value enclosed in parentheses. The trailing parenthesis is missing
SOP Error ERROR!! The maximum count for a counter is 32767!	The number of low to high transitions required to activate the output of a counter has been exceeded. Reduce the number in the parentheses and recompile.
SOP Error ERROR!! expecting (got>> name <<	Timers and counters, when they are defined, must have the flag name followed by a value enclosed in parentheses. The compiler expected a left parenthesis as the next character.
SOP Error ERROR!! System Program size (nnnn bytes) is greater than allowed (8192 bytes)	The total storage size of the <i>System Program</i> , listed in bytes, exceeds the max allowed space. This is the actual bytes used and not the size of the Intel Hex file, which is an ASCII representation of the data within a header, load information, and checksum error checking.
SOP Error WARNING...Unable to load complete directory! Too many flags in directory (nnnn)	The size of the directory file has exceeded the allocated memory for storing that file. Check the version of the compiler to ensure you are using the latest. Also check the directory file.
SOP Error WARNING!! flag name has been redefined as an output on statement: nnnn line:nnnn.	An output flag has a logic statement assigned to it (it is used on the left side of the assignment operator) more than once. Find and change the offending line and recompile. The second usage of the flag is located by the statement or line number.
No output file created. There is a warning message in the file. It need to be commented out or removed before recompiling. Edit <source file name> and try again. The error occurred in logic statement: n n n , line: n n n n	If a corrupted hex file is reverse compiled, or if the wrong directory file was used in that process, there are usually "UNDEFINED" flags in the source file. If this is the case, the program will have to be rewritten. It is ALWAYS advisable to use source files instead of reverse compiled files so that changes can be documented, and the logic is described via the comments in the original file. The location of the compiler error is shown as both the statement and line number.
This file was created by the reverse compiler from a corrupt HEX file or utilizing the wrong DRCTRY file. No output file created. Edit <i>source file name</i> and try again The error occurred in logic statement: n n n n , line: n n n n	This is a special error that only occurs after a reverse compiled file is recompiled. The reverse compilation process inserted a warning message. This message needs to be reviewed before proceeding. Based on the message, it may be simply a matter of deleting the warning, or it could require rewriting portions of the <i>System Program</i> .

5.10 Uploading a System Program (Hex File)

In a manner similar to downloading a System Program, the System Program can be uploaded from the drive to a receiving computer (binary format in the drive, hex format from the drive or compiler). This can permit archival of a functioning System Program. Also, the text statements in a System Program can be re-created so that the program can be examined or modified as needed.

Using a similar method as described in the download section, invoke the serial communications upload function on the drive. If using the DOS-based upload utility, invoke the data capture process of the communications software prior to starting the data upload function in the drive.

From the drive keypad, enter the "System Program Upload" function menu (9130). Once this function has been invoked, the keypad will indicate that the drive is uploading data. Most serial communications packages will display the ASCII hex data while it is being uploaded so that the upload process can be monitored. Once complete, the drive will indicate that it has finished and will return to the System Program upload menu (9130). At this point, the data capture process in the PC is stopped and the resulting file is saved.

NOTICE

As with the download, the upload process can be terminated from the drive side by entering a [SHIFT]+[CANCEL] key sequence.

5.11 Reverse Compiler

Because the System Program embedded in the drive is in a non-readable form, a program to reverse compile the hex records of a System Program back into readable statements was created. A reverse compiled program can be examined for logic functions and even edited, recompiled, and re-downloaded into the drive to alter the System Program functionality as needed. Since the embedded hex file does not contain any symbolic information, a directory file within range is needed during the reverse compile process to convert from the binary address information back into symbolic readable form.

The Siemens SOP Utilities program contains an integrated Reverse Compiler program. This component is similar to the compile component. A HEX file and DRCTRY file must be specified. If they do not exist in the default directory, locate the necessary files. When the appropriate files are specified, press the reverse compilation. See Figure 5-7. Reverse Compiler errors are listed in Table 5-7.






Figure 5-7: Reverse Compiler Options Window

Select hex file (contains valid source code):




Information on file (Information button):




Directory version button:




Results of Rev Compile button when source code is embedded:




Loaded hex file with no source code (in this case with same Directory versions for compile and reverse compile):




Pushing Rev Compile to generate the reverse compiled (*.dis) file rather than simply extracting the source.



Loaded hex file with no source code (in this case with differences in Directory versions also).





Loaded hex file – information button (Hex File)




Version button (DRCTRY File)



Push Rev Compile button (hex file has no embedded source and contains errors):



Go back to Compiler option and load created reverse compiled program to look for errors.



Load file in editor – look at header and errors.

5.12 Header

```
#NEXTGEN;
```

```
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!! Warning !!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
The version of DRCTRY.NGN used is DIFFERENT from the original DRCTRY
Probable errors will occur, check the output files
(You must comment these lines out before recompiling)
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
```

```
; Siemens LD A
; ID Series System Program Reverse Compiler Windows Ver. 6.6.2 12/12/05
;
; REVCMP Directory File Name : C:\PROJECTS\NXG4.0\FLASH\DRCTRY.NGN
; REVCMP used DRCTRY.NGN ver : 4.28
; Hex File Name : Sop.hex
; System Program Name : NOWAGO.SOP
; System Program Date/Time : May 25 15:26:52 2000
; System Type : NEXTGEN
; Hex file used DRCTRY version : 1.00
```

Errors in statements:

```
TempFlag01_O      = TempFlag01_O * /UNDEFINED * /UNDEFINED * TempFlag02_O
+
                  UNDEFINED * TempFlag02_O + UNDEFINED * TempFlag02_O;
TempFlag02_O      = TempFlag03_O * UNDEFINED;
```

Table 5-7: Reverse Compiler Error Messages

Error Message	Description
Hex File Error Too many input table entries (> 800)	Then number of distinct inputs in the scan table exceeds the maximum allowable 800 entries. The hex file is possibly corrupted or is of the wrong drive type.
Hex File Error Too many output table entries (> 800)	Then number of distinct outputs in the scan table exceeds the maximum allowable 800 entries. The hex file is possibly corrupted or is of the wrong drive type.
Hex File Error Too many logic table entries (> 5000)	The number of entries in the logic table exceeds the maximum allowable 5000 entries. The hex file is possibly corrupted or is of the wrong drive type.
Hex File Error Too many counter/timer entries (> 128)	The hex file contains too many timers and counters (total sum of both) which cannot exceed 128 for NXG. The hex file is possibly corrupted or is of the wrong drive type.
DRCTRY Error ERROR in line <i>nnnn</i> - << <i>flag name</i> >> is longer than 43 characters. The error occurred in <i>directory file name</i> .	The flag name shown is longer than the max allowable 43 characters. Check the flag indicated and check for a corrupted hex file.
!!!!!!!!!!!!!!!!!!!!Warning!!!!!!!!!!!!!!!!!!!! This file is corrupted (bad System Program checksum). Carefully check all logic equations for invalid or undefined flags, erroneous timer or counter values, wrong use of flags, erroneous logic, etc. Edit these lines (and comment these warning lines), compile and use at your own risk. !!	This error message is added to the top of a reverse compiled program when the stored System Program checksum does not compare with the calculated one. The file must be check for integrity, any errors corrected, and this comment removed before re-compiling. Since the checksum is invalid, the file may or may not work properly.
DRCTRY Version Error The version of <i>directory file name</i> used is DIFFERENT from the original DRCTRY. Probable errors will occur, check the output files. (You must comment the warning lines out in the '.DIS' file before recompiling).	This message will display if the version with which the System Program is reverse compiled is different from the version used to create the original hex file. A warning will be added to the file along with the statistics of the compiler version and directory version, along with other information on the file.

Error Message	Description
!!!!!!!!!!!!!!!!!!!!Warning !!!!!!!!!!!!!!!!!!!!! The version of <i>directory file name</i> used is DIFFERENT from the original DRCTRY Probable errors will occur, check the output files (You must comment these lines out before recompiling) !!! ; Siemens LD A Group ; ID Series System Program Reverse Compiler <i>version Number</i> ; REVCMP Directory File Name : <i>directory file name</i> ; REVCMP used <i>directory file name</i> ver: <i>n.nn</i> ; Hex File Name : <i>hex file name</i> ; System Program Name : <i>System Program name</i> ; System Program Date/Time: <i>time/date</i> ; System Type : <i>drive type</i> ; Hex file used DRCTRY version : <i>n.nn</i>	This header is added to the top of the reverse compiler output file when the directory version error displays. The comments must be removed before the file can be recompiled successfully.
The file was reverse compiled successfully. Original DRCTRY file version: <i>n . n n .</i> Current DRCTRY file version: <i>n . n n .</i> Number of counters and timers: <i>n n n .</i> Number of in items: <i>n n n .</i> Number of out items: <i>n n n .</i> Number of logic items: <i>n n n n .</i> Checksum: <i>0xN N N N .</i>	Header continuation.
Hex File Error The hex file is corrupted. <i>n n</i> UNDEFINED label(s) found. Output file created anyway. Check file for error(s).	The hex file used as the input to the reverse compiler was corrupted in some manner, creating UNDEFINED labels - labels that could not be found in the directory file. It may simply be that the directory file used to reverse compile did not contain the flags found. This error occurs anytime there is one or more "UNDEFINED" labels found.
Source Corrupt This file is a dual source/hex file, but the source is corrupt. Do you want to try to reverse compile using the older method?	This message occurs only with embedded source file information in the hex file. If the source file exists, the reverse compiler simply extracts the source text directly. If the end of file is not found within the source text, it is assumed corrupted and prompts the user to do an actual reverse compiler of the compiled code. All comments are lost.
No Errors The SOP source has been successfully extracted from the hex file.	This message displays if the source text exists within the hex file and is successfully extracted.

The output file will contain a source statement for each original statement in the System Program. The statements will be ordered with the invariant statements first, followed by the dependent statements. All of the statements in a section will be in the same order as the original file, with the exception of any true/false type statements which are moved to the front of the file.

NOTICE

Comments from the original source file are not included in a compiled hex file and therefore cannot be reverse compiled. (See Section 5.13 on combined source and Hex files.)

A copy of the symbol directory file (e.g., DRCTRY.NGN) must exist within the working directory of the compiler and reverse compiler, or in the directory of the invoked executable program.

5.13 Combined Source / Hex File

Beginning with NXG Software Version 2.4, the system is capable of accepting a combined source/hex file format. The older style compiled sop files. However, when reverse compiling, this new file format undergoes a pseudo reverse compiling process rather than the traditional reverse compiling process. In this pseudo reverse compiling process, all the original source comments and formatting is presented to the user as the reverse compiled output. This combined file type must be created or reverse compiled with SOP Utilities version 5.0 or later. In all other respects, this type of compiled sop is the same as the older file version.

For example:

Original SOP File

```
#NEXTGEN; ;
```

```
-----
;      Siemens LD R NEXT GEN HARMONY AC MOTOR DRIVE
;      SYSTEM OPERATING PROGRAM (TEST VERSION)
;      Program Number: NoWago.sop Customer: Siemens
Siemens Sales Order: xxxx
Siemens Part Numbers: xxxx
;      Description: none
;      Engineer: JAB
;
; Original Version Date: 10/31/00
-----
```

```
;      ;SYMBOL DEFINITION
;-----
```

```
;      = equals * logical AND+ logical OR / logical NOT
;      ; comment line
;-----
```

```
;      ;INITIALIZED FLAGS
;-----
```

```
; Keypad Speed reference
RawDemandKeypad_O= TRUE;
; Speed profile
```

```
SpeedProfile_O= FALSE;
RunRequest_O = TempFlag01_O * TempFlag02_O;
Ram pStop_O = TempFlag02_O;
;
; Fault Reset
;
DriveFaultReset_O = KeypadFaultReset_I + ToolFaultReset_I;
=====
;
===== END OF FILE =====
;
=====
```

Old Style .hex File Data

```
:020000020000FC
:1 000000046005F00800065008A0001 04AC009B464A :10001 0004E4F5741
474F2E534F50000000000000F5 :100020000000000000000000204465632031 3920FA :1
000300030393A34333A31 30203230303200000037
:10004000A20006009E0024020300012502040001 14 :1000500041
0007000F450008000F000000000000ED :100060000008010009030004040006020001040066
:100070000605000107000208000606000100000056 :100080001 3000000012E000100014000020001
5495 :10009000000500014900060001 0000000000000000A
:0C00A0009E00000000000000000009E001 8
:0000000 1FF
Old Style Reverse Compiled Output
#NEXTGEN;
; Siemens LD R Group
; ID Series System Program Reverse Compiler Windows Ver. 5.0.0 12/3/02
;
REVCMP Directory File Name : C:\PROGRAM FILES\Siemens\FLASH FILES\DRCTRY.NGN
REVCMP used DRCTRY.NGN ver: 0401
; Hex File Name : nowago.hex
System Program Name : NOWAGO.SOP
System Program Date/Time : Dec 19 09:43:10 2002
; System Type : NEXTGEN
; Hex file used DRCTRY version : 0401
RawDemandKeypad_O = TRUE;
SpeedProfile_O= FALSE;
RunRequest_O= TempFlag01_O * TempFlag02_O;
RampStop_O= TempFlag02_O;
DriveFaultReset_O = KeypadFaultReset_I + ToolFaultReset_I;
```

New Style .hex File

```

:020000020000FC
:1 000000046005F00800065008A0001 04AC009B464A :10001 0004E4F5741
474F2E534F50000000000000F5 :100020000000000000000000204465632031 3920FA :1
000300030393A34333A31 30203230303200000037
:10004000A20006009E0024020300012502040001 14 :1000500041
0007000F450008000F000000000000ED :100060000008010009030004040006020001040066
:100070000605000107000208000606000100000056 :100080001 3000000012E000100014000020001
5495 :10009000000500014900060001 0000000000000000A
:0C00A0009E00000000000000000009E001 8

:00000001 FF

<1><2 1 6>Start-of-source
<2><1 29>#NEXTGEN;
<3><1 61>;-----
<4><23>;SIEMENS NEXT GEN HARMONY AC MOTOR DRIVE
<5><1 30>;SYSTEM OPERATING PROGRAM (TEST VERSION) <6><74>
<7><235>;Program Number: NoWago.sop
<8><157>;Customer: Siemens
<9><255>; Siemens Sales Order: xxxx
<10><94>; Siemens Part Numbers: xxxx
<11><115>;Description: none
<12><121>;Engineer: JAB
<13><69>;
<14><59>; Original Version Date: 10/31/00
<15><206>;-----
<16><36>;SYMBOL DEFINITION
<17><206>;-----
<18><69>;
<19><71>;= equals* logical AND+ logical OR / logical NOT
<20><251>; ; comment line
<21><69>;
<22><14>;-----
<23><8>;INITIALIZED FLAGS
<24><206>;-----
<25><101>;
<26><163>; Keypad Speed reference
<27><65>RawDemandKeypad_O= TRUE;
<28><1 0>

```

```

<29><103>; Speed profile
<30><157>SpeedProfile_O= FALSE;
<31><10>
<32><87>RunRequest_O = TempFlag01_O * TempFlag02_O;
<33><1 98>RampStop_O = TempFlag02_O;
<34><69>;
<35><132>; Fault Reset
<36><69>;
<37><30>DriveFaultReset_O = KeypadFaultReset_I + ToolFaultReset_I;
<38><1 0>
<39><219>;=====
=====
<40><206>;===== END OF FILE
=====
<41><21
9>;=====
=====
<42><1 0>
<43><240>End-of-file

```

New Style Reverse Compiled Output

```

#NEXTGEN;
;-----
;      SIEMENS NEXT GEN HARMONY AC MOTOR DRIVE
;      SYSTEM OPERATING PROGRAM (TEST VERSION)
;      Program umberNNoWago.sop
;      Customer: Siemens
Siemens Sales Order: xxxx
Siemens Part Numbers: xxxx
;      Description: none
;      Engineer: JAB
;
; Original Version Date: 10/31/00
;-----
;SYMBOL DEFINITION
;-----
= equals * logical AND+ logical OR / logical NOT
;      ; comment line
;

```

```

;-----
;INITIALIZED FLAGS
;-----
;
; Keypad Speed reference RawDemandKeypad_O= TRUE;
; Speed profile
SpeedProfile_O= FALSE;
RunRequest_O = TempFlag01_O * TempFlag02_O;
RampStop_O = TempFlag02_O;
;
; Fault Reset
;
DriveFaultReset_O = KeypadFaultReset_I + ToolFaultReset_I;
;=====
=====;===== END OF FILE
=====
;=====
=====

```

Original SOP File

```

#NEXTGEN;
;-----
;      Siemens LD R NEXT GEN HARMONY AC MOTOR DRIVE
;      SYSTEM OPERATING PROGRAM (TEST VERSION)
;      Program Number: NoWago.sop Customer: Siemens
Siemens Sales Order: xxxx
Siemens Part Numbers: xxxx
;      Description: none
;      Engineer: JAB
;
; Original Version Date: 10/31/00
;-----
;SYMBOL DEFINITION
;-----
;
;      = equals * logical AND+ logical OR / logical NOT

```



```

;      ; comment line
;
;-----
INITIALIZED FLAGS
;-----
;
; Keypad Speed reference
RawDemandKeypad_O= TRUE;
; Speed profile
SpeedProfile_O= FALSE;
RunRequest_O = TempFlag01_O * TempFlag02_O;
RampStop_O = TempFlag02_O;
;
; Fault Reset
;
DriveFaultReset_O = KeypadFaultReset_I + ToolFaultReset_I;
;=====
;===== END OF FILE=====
;=====

```

Old Style .hex File Data

```

:0200000020000FC
:1 000000046005F00800065008A0001 04AC009B464A :10001 0004E4F5741
474F2E534F50000000000000F5 :100020000000000000000000204465632031 3920FA :1
000300030393A34333A31 30203230303200000037
:10004000A20006009E0024020300012502040001 14 :1000500041
0007000F450008000F000000000000ED :100060000008010009030004040006020001040066
:100070000605000107000208000606000100000056 :100080001 3000000012E000100014000020001
5495 :10009000000500014900060001 0000000000000000A
:0C00A0009E00000000000000000009E001 8
:0000000 1FF

```

Old Style Reverse Compiled Output

```

#NEXTGEN;
; Siemens LD A Group
; ID Series System Program Reverse Compiler Windows Ver. 5.0.0 12/3/02
;
REVCMP Directory File Name : C:\PROGRAM FILES\Siemens\FLASH FILES\DRCTRY.NGN
REVCMP used DRCTRY.NGN ver: 0401
;      Hex File Name : nowago.hex

```

```

System Program Name : NOWAGO.SOP
System Program Date/Time : Dec 19 09:43:10 2002
;      System Type : NEXTGEN
; Hex file used DRCTRY version : 0401
RawDemandKeypad_O = TRUE;
SpeedProfile_O= FALSE;
RunRequest_O= TempFlag01_O * TempFlag02_O;
RampStop_O= TempFlag02_O;
DriveFaultReset_O = KeypadFaultReset_I + ToolFaultReset_I;

```

New Style .hex file

```

:0200000020000FC
:1 000000046005F00800065008A0001 04AC009B464A :10001 0004E4F5741
474F2E534F50000000000000F5 :100020000000000000000000204465632031 3920FA :1
000300030393A34333A31 30203230303200000037
:10004000A20006009E0024020300012502040001 14 :1000500041
0007000F450008000F000000000000ED :1000600000008010009030004040006020001040066
:100070000605000107000208000606000100000056 :100080001 3000000012E000100014000020001
5495 :10009000000500014900060001 0000000000000000A
:0C00A0009E00000000000000000009E001 8
:00000001 FF
<1><2 1 6>Start-of-source
<2><1 29>#NEXTGEN;
<3><1 61>;-----
<4><23>;SIEMENS NEXT GEN HARMONY AC MOTOR DRIVE
<5><1 30>;SYSTEM OPERATING PROGRAM (TEST VERSION)
<6><74>
<7><235>;Program Number: NoWago.sop
<8><157>;Customer: Siemens
<9><255>; Siemens Sales Order: xxxx
<10><94>; Siemens Part Numbers: xxxx
<11><115>;Description: none
<12><121>;Engineer: JAB
<13><69>;
<14><59>; Original Version Date: 10/31/00
<15><206>;-----
<16><36>;SYMBOL DEFINITION
<17><206>;-----
<18><69>;

```

```

<19><71>;= equals* logical AND+ logical OR / logical NOT
<20><251>; ; comment line
<21><69>;
<22><14>;-----
<23><8>;INITIALIZED FLAGS
<24><206>;-----
<25><101>;
<26><163>; Keypad Speed reference
<27><65>RawDemandKeypad_O= TRUE;
<28><1 0>
<29><103>; Speed profile
<30><157>SpeedProfile_O= FALSE;
<31><10>
<32><87>RunRequest_O = TempFlag01_O * TempFlag02_O;
<33><1 98>RampStop_O = TempFlag02_O;
<34><69>;
<35><132>; Fault Reset
<36><69>;
<37><30>DriveFaultReset_O = KeypadFaultReset_I + ToolFaultReset_I;
<38><1 0>
<39><219>;=====
=====
<40><206>;===== END OF FILE
=====
<41>
><219>;=====
===== <42><1 0>
<43><240>End-of-file

```

New Style reverse Compiled Output

```

#NEXTGEN;
;-----
;      SIEMENS NEXT GEN HARMONY AC MOTOR DRIVE
;      SYSTEM OPERATING PROGRAM (TEST VERSION)
;      Program umber\NoWago.sop
;      Customer: Siemens
Siemens Sales Order: xxxx
Siemens Part Numbers: xxxx
;      Description: none
;      Engineer: JAB

```

```

;
; Original Version Date: 10/31/00
;-----
;SYMBOL DEFINITION
;-----
= equals * logical AND+ logical OR / logical NOT
;      ; comment line
;
;-----
;INITIALIZED FLAGS
;-----
;
; Keypad Speed reference RawDemandKeypad_O= TRUE;
; Speed profile
SpeedProfile_O= FALSE;
RunRequest_O = TempFlag01_O * TempFlag02_O;
RampStop_O = TempFlag02_O;
;
; Fault Reset
;
DriveFaultReset_O = KeypadFaultReset_I + ToolFaultReset_I;
;=====
;===== END OF FILE =====
;=====

```

NXG Configuration Update Utility Overview

The Configuration Update Utility allows updating and configuration of software for the NXG CompactFlash card and the NXG ToolSuite.

NOTICE
This utility is intended for use by trained Siemens personnel only.


The Configuration Update Utility is a Microsoft® Windows based application for creating or updating CompactFlash and ToolSuite software for the NXG Control. When purchased, a CompactFlash memory card needs to be configured and made “bootable” for the real-time operating system that the NXG Control uses.

6.1 System Requirements


The NXG Configuration Update Utility is a Microsoft® Windows application requiring the .NET 2.x Framework. It requires Windows 2000/XP/Vista, at least 128 MB of RAM, and a minimum of 15 MB of disk space.

6.2 Start and Configure the Configuration Update Utility

Select → Utilities tab of the ToolSuite application and click → Configuration Update button (as shown in figure below):



The Configuration Update Utility screen should appear as shown below:



6.3 Features Overview

The Configuration Update Utility screen features currently available are:

- Copy setup files to another directory
- Update flash disk files
- Make bootable default disk
- Copy files from flash disk to PC
- Make bootable copied disk
- Update ToolSuite Host files on PC


6.3.1 Copy Setup Files to Another Directory

This feature copies and overwrites the files from the source folder to the destination folder. The source folder can be a source, remote or local, to the PC being used. The typical output folder location is your local hard drive. This feature is mainly used by laptop users who want to load the latest software and files onto their laptops.


NOTICE
This feature will overwrite the existing destination files (i.e., on your local hard drive). Never use this feature with the CompactFlash disk as the destination drive or folder.

Perform the steps as indicated below to copy setup files to another directory:


1. Verify which drive type is active by checking the Drive Type text box located on the Configuration Update Utility screen. If the system indicated is not the drive type desired, click → Options menu located at the top of the Configuration Update Utility screen (see figure). To change drive type, click → Select Drive Type..., in the pull-down menu. Options available are "NXG Harmony", "HA Harmony", or "Silcovert H".




2. The Select Drive Type screen will appear (see figure below). Choose the desired drive type and then click → OK. The newly selected drive system will appear in the Drive Type text box located on the Configuration Update Utility screen (see figure above).



- After selecting drive type, go to → Configuration Update Utility screen → Operation Type, click → Copy setup files to another directory (see figure below).




- Next click → Select Source Folder button (see figure above). The Select Source Folder screen will appear (see figure below).




- Click → Browse button to locate the file name desired or manually type name of file into text box.
- After choosing the Source Folder, click → Ok.
- Return to the Configuration Update Utility Screen and press → Select Destination Folder button.

NOTICE

Never use this feature with the CompactFlash disk as the destination drive or folder.



8. The Select Destination Folder screen will appear (see figure below).




9. Typically, 'Select Output Directory' should default to *C:\Program Files\Robicon\Flash Copy*. Click → Flash Copy Folder button to manually select this location.

10. After selecting desired Output Directory, click → OK.

11. Next click → Start button on the Configuration Update Utility screen.

12. A dialog window will appear confirming that you are about to overwrite existing files (not shown). Click → 'Yes' button.

13. Successful completion of process is confirmed by a pop-up message "Operation completed successfully". Press → OK to finish.



6.3.2 Update Flash Disk Files


This feature allows the user to update files from a source folder location (which contains newer versions of NXG software) to the CompactFlash. The source folder can be a remote or local source to the PC being used. The output folder location is the CompactFlash card used in the NXG Control. This feature updates the NXG software and configuration files, while maintaining the existing drive settings and system programs.

NOTICE


This feature can only be used on an existing CompactFlash or directory that already contains files that may be older than the current release. Be certain to back these files up before proceeding with this operation.

Perform the steps as indicated below to update flash disk files:


1. Verify which drive type is active by checking the Drive Type text box located on the Configuration Update Utility screen. If the system indicated is not the drive type desired, click → Options menu located at the top of the Configuration Update Utility screen (see figure below). To change drive type, click → Select Drive Type..., in the pull-down menu. Options available are “NXG Harmony”, “HA Harmony”, or “Silcovert H”.




- The Select Drive Type screen will appear (see figure below). Choose the desired drive type, then click → OK. The newly selected drive system will appear in the Drive Type text box on the Configuration Update Utility screen (see figure above).



- After selecting drive type, go to the Configuration Update Utility screen → Operation Type, click → Update flash disk files (see figure below).



- Next click → Select Source Folder button (see figure above). The Select Source Folder screen will appear (see figure below)




- Click → Browse button to locate a newer or older version of the file name than the one currently on the CompactFlash.

6. Click → Local Hard Drive Copy button, to identify the location of the drive type selection.


NOTICE

For NXG Drives, the file name is *C:\Program Files\Robicon\Flash Files*.

7. After choosing the Source Folder, click → OK.
8. Return to the Configuration Update Utility screen and press → Select Destination Drive (see figure below).




9. Typically, 'Select Output Drive' will be the CompactFlash card.
10. The Select Destination Drive screen will appear (see figure below).



11. After selecting desired Output Drive, click → OK.
12. Next click → Start button on the Configuration Update Utility screen.
13. A dialog window will appear confirming that you are about to overwrite existing files (not shown). Click → 'Yes' button.

14. Successful completion of process is confirmed by a pop-up message “Operation completed successfully”. Press → OK to finish.



15. User can now insert the CompactFlash card into the CPU board.


6.3.3 Bootable Default Disk Procedure

This feature allows the user to make a “Bootable” CompactFlash disk that contains all of the software and configuration files necessary to run the drive (except for the system program). The source folder can be a source that is remote or local to the PC being used. The typical output drive is the CompactFlash card used in the NXG Control. This feature is necessary when a new CompactFlash disk is used for the first time.


NOTICE
This feature will completely reformat the entire CompactFlash and write all of the necessary files for NXG Control. If the CompactFlash contains files that are to be kept, then care should be taken to back these files up before proceeding with this operation.

Perform the steps as indicated below to create a bootable default disk:


1. Verify which drive type is active by checking the Drive Type text box located on the Configuration Update Utility screen. If the system indicated is not the drive type desired, click → Options menu located at the top of the Configuration Update Utility screen (see figure below). To change drive type, click → Select Drive Type..., in the pull-down menu. Options available are “NXG Harmony”, “HA Harmony”, or “Silcovert H”.




2. The Select Drive Type dialog window will appear (see figure below). Choose the desired drive type and press → OK. The newly selected drive system will appear in the Drive Type text box on the Configuration Update Utility screen (see figure above).



- After selecting drive type, go to → Configuration Update Utility screen → Operation Type, click → Make bootable default disk (see figure below).



- Next click → Select Source Folder button (see figure above). The Select Source Folder screen will appear (see figure below)




- Click → Browse button to locate a newer or older version of the file name than the one currently on the CompactFlash. Click → Local Hard Drive Copy button, to identify the location of the drive type selection.

NOTICE


For NXG / NXGII Drives, the file name is *C:\Program Files\Robicon\Fish Files*.

- After choosing the Source Folder, click → OK.


7. Return to the Configuration Update Utility screen and press → Select Destination Drive.



If there are no eligible drives found the following message will be displayed:



If one or more eligible drives are found the following selection box will be displayed:



8. Select the drive letter of the CompactFlash card, then click → OK.

9. Next click → Start button on the Configuration Update Utility screen.


If an error occurs with the CompactFlash card the following screen will be displayed:




If no errors occur, a warning is issued indicating the CompactFlash card will be overwritten. Click → Yes.




10. Return to the Configuration Update Utility screen and press → OK. A screen will be displayed indicating system is processing.



11. Upon successful completion of process the following screen will appear asking if user wishes to eject the Flash Disk. Click → Yes.



12. Successful completion of process is confirmed by a pop-up message "Operation completed successfully". Press → OK to finish.




13. User can now insert the CompactFlash card into the CPU board.

6.3.4 Copy Flash Disk to PC


This feature is for extracting a version of software from pre-programmed CompactFlash disks to use as a source for updating or making other CompactFlash disks. It copies all of the files from the CompactFlash disk and places them into the Destination Folder, typically on a PC.

Perform the steps as indicated below to copy files from a flash disk to a PC:


1. Verify which drive type is active by checking the Drive Type text box located on the Configuration Update Utility screen. If the system indicated is not the drive type desired, click → Options menu located at the top of the Configuration Update Utility screen (see figure below). To change drive type, click → Select Drive Type..., in the pull-down menu. Options available are "NXG Harmony", "HA Harmony", or "Silcovert H".




2. The Select Drive Type dialog window will appear (see figure below). Choose the desired drive type, then click → OK. The newly selected drive system will appear in the DriveType text box on the Configuration Update Utility screen (see figure above).



- After selecting drive type, go to → Configuration Update Utility screen → Operation Type, click → Copy files from flash disk to PC (see figure below).




- Next click → Select Source Drive button (see figure above). The Select Source Drive screen will appear (see figure below).




- Select the drive letter of the CompactFlash card.
- After choosing the Source Folder, press → Ok.

7. Return to the Configuration Update Utility screen and press → Select Destination Folder.



8. The Select Destination Folder screen should appear (see figure below).




IMPORTANT!

Ensure that the Destination Folder does not contain any files or sub-directories. Any content in the selected Destination Folder is overwritten upon clicking “Yes” as described in Step12 below.

9. Select the location where Flash files are to be copied. Click → Flash Copy Folder button to manually transfer files to *C:\Program Files\Robicon\Flash Copy*.
10. After choosing the Destination Folder, click → Ok.
11. Next click → Start button on the Configuration Update Utility screen.
12. A dialog window will appear confirming that you are about to overwrite existing files (not shown). Click → Yes.

13. Successful completion of process is confirmed by a pop-up message "Operation completed successfully". Press → OK to finish.




6.3.5 Make Bootable Copied Disk Procedure

This feature allows the user to duplicate Flash Disks. This feature formats and makes a "Bootable" CompactFlash disk that contains all of the software and configuration files necessary to run the drive (including the system programs). The source folder can be a source that is remote or local to the PC being used. The standard source will be the Flash Copy folder. The default output drive is the CompactFlash card used in the NXG Control.


NOTICE
This feature will completely reformat the entire CompactFlash and write all of the necessary files for NXG Control. If the CompactFlash contains files that are to be kept, then care should be taken to back these files up before proceeding with this operation.

Perform the steps as indicated below to make a bootable copied disk:


1. Verify which drive type is active by checking the Drive Type text box located on the Configuration Update Utility screen. If the system indicated is not the drive type desired, click → Options menu located at the top of the Configuration Update Utility screen (see figure). To change drive type, click → Select Drive Type..., in the pull-down menu. Options available are "NXG Harmony", "HA Harmony", or "Silcovert H".




2. The Select Drive Type screen will appear (see figure below). Choose the desired drive type and then click → OK. The newly selected drive system will appear in the Drive Type text box on the Configuration Update Utility screen (see figure above).



3. After selecting drive type, go to → Configuration Update Utility screen → Operation Type, click → Make bootable copied disk (see figure below).



4. Next click → Select Source Folder button (see figure above). The Select Source Folder screen will appear (see figure below)




5. Click → Browse button to locate a newer or older version of the file name than the one currently on the CompactFlash.
6. Click → Local Hard Drive Copy button, to identify the location of the drive type selection.


NOTICE

For NXG Drives, the file name is *C:\Program Files\Robicon\Flash Files*.

7. After choosing the Source Folder, click → OK.
8. Return to the Configuration Update Utility screen and press → Select Destination Drive.




9. The Select Source Drive screen will appear (see figure below). Select the CompactFlash card drive.




10. After selecting the Destination Drive, click → Ok.
11. Next click → Start button on the Configuration Update Utility screen.
12. A dialog window will appear confirming that you are about to overwrite existing files (not shown). Click → 'Yes' button.

NOTICE

The files will be copied to the CompactFlash disk. A screen will be displayed indicating System is processing (see figure below).



13. Upon successful completion of process a screen will appear (not shown) asking if user wishes to eject the Flash Disk. Click → Yes.
14. A dialog window will appear confirming that you are about to overwrite existing files (not shown). Click → 'Yes' button.
15. Successful completion of process is confirmed by a pop-up message "Operation completed successfully". Press → OK to finish.




16. User can now insert the CompactFlash disk into the CPU board.

6.3.6 Update ToolSuite Host Files on PC


This feature updates the configuration files for all ToolSuite configured drives. The ToolSuite installation program updates configuration files automatically. As an option this section is provided for Siemens personnel, who wish to manually update ToolSuite configuration files.

Perform the steps as indicated below to update ToolSuite Host Files on PC:


1. Verify which drive type is active by checking the Drive Type text box located on the Configuration Update Utility screen. If the system indicated is not the drive type desired, click → Options menu located at the top of the Configuration Update Utility screen (see figure below). To change drive type, click → Select Drive Type..., in the pull-down menu. Options available are "NXG Harmony", "HA Harmony", or "Silcovert H".




2. The Select Drive Type screen will appear (see figure below). Choose the desired drive type and then click → OK. The newly selected drive system will appear in the Drive Type text box on the Configuration Update Utility screen (see figure above).



- After selecting drive type, go to → Configuration Update Utility screen → Operation Type, click → Update ToolSuite host files on PC (see figure below).



- Next click → Select Source Folder button (see figure above). The Select Source Folder screen will appear (see figure below).




- Click → Browse button to locate source folder. Ensure that the source files are match selected Drive Type.

NOTICE

For NXG drives, the file name is *C:\Program Files\Robicon\Fish Files*.

6.3 Features Overview

6. Next click → Start button on the Configuration Update Utility screen.
7. A dialog window will appear confirming that you are about to overwrite existing files (not shown). Click→ 'Yes' button.
8. Successful completion of process is confirmed by a pop-up message "Operation completed successfully". Press → OK to finish.



Drive Server Setup/Status Utility

The Drive Server Setup/Status utility defines the setup requirements for computer-to-computer communication, where one of the computers is hosting a Drive Server. Refer to the Drive Server Manual for information related to configuration of a system hosting a Drive Server.

NOTICE


This utility is intended for use by trained Siemens personnel only.

NOTICE


This utility is used both on computers that host a Drive Server and also with computers that communicate to another computer hosting a Drive Server.

7.1 Start and Configure the Configuration Update Utility

Select → Utilities tab of the ToolSuite application and click → Drive Server Setup/Status button (as shown in figure below):



If no existing drive server is configured, the first time the Drive Server is started the Drive Server Setup/Status screen will appear as shown below:




To begin using the Driver Server Utility, a new server connection must be established. Refer to the following Section *Create a New Server Connection*.

7.1.1 Create a New Server Connection


This feature allows the user to create a new server connection. If an error message displays on the Drive Server Setup/Status Utility screen, a new server connection must be created.

Perform the steps as indicated below to create a new server connection:

1. On the Drive Server Setup/Status Utility screen click → Security menu, select → Enter Security code (see figure below).




2. The Security Code screen will appear (see figure below). Enter → drsv in the text box, then click → Ok.




3. The Valid Code screen will appear confirming correct security code was entered. Click → Ok, then proceed to next step.



4. Return to the Drive Server Setup/Status Utility screen and click → Setup menu → click Server Connection Maintenance, next select → Create New Server Connection (see figure).



5. When Connect screen appears the text box fields will be empty. Enter data as shown in figure below.



The screenshot shows a 'Connect' dialog box with three text input fields and two buttons at the bottom. The first field, labeled 'Connection Name', contains the text 'Remote Drive Server'. The second field, labeled 'Actual Server Name', contains the text 'ThisServer'. The third field, labeled 'Machine's Name or IP Address', is empty. Arrows point from the annotations to each of these three fields. The 'Ok' and 'Cancel' buttons are at the bottom.

Connect

Connection Name
Remote Drive Server ← Gives Connection IDENTITY

Actual Server Name
ThisServer ← Default Entry (System Dependant)

Machine's Name or IP Address
← Remote PC name should be entered in text box (System Dependant)

Ok Cancel

The data entered into the Connection Name text box is per the user's choice. It is used to identify the connection by name. The data entered into the Actual Server Name text box is system dependent. The text shown in the example figure above is the Default Entry. If the Actual Server Name has been changed from the Default Entry, that new name must be entered in this field.

NOTICE

Use the Drive Server Setup/Status Utility to determine the actual name of the configured Drive Server.


The data entered in the Machine's Name or IP Address text box is also system dependent. The Machine Name on which the server resides should be used to achieve maximum functionality.

The Machine Name and domain of the Remote PC can be determine by performing the following:

- Open desktop on Remote PC, move cursor to → 'My Computer' GUI, click → right mouse button, click → 'Properties' (using left mouse button), click → 'My Computer' tab (using left mouse button). A dialog window should appear (see figure).

NOTICE

If the server is running on the same machine as the Drive Server Setup/Status Utility, enter → 'LocalHost' in the text box.



The Machine Name has two benefits. First, it provides additional functionality through the Drive Server Setup/Status application. Secondly, the Machine Name does not require the PC that the Drive Server is executing from to have a static IP address.

NOTICE


The best setup is achieved when both PCs are located in the same domain.

Sometimes site specific network policies prohibit the PC which hosts the Drive Server and the remote PC from being on the same domain. In this case the IP address of the PC which hosts the Drive Server should be entered into the Machine Name or IP Address of the Connect screen.

NOTICE

A static IP Address must be entered so that the IP Address of the machine will remain constant.

After all of the previous steps have been completed, the Drive Server Setup/Status Utility screen should now display the following data:



7.2 Setup / Status Application Operation

Features Overview

The Drive Server Setup/Status Utility screen features currently found are:

- Status Screen
- Menu Functions

7.2.1 Status Screen

The Status screen indicates the following system data:

- **Server Name:** Refers to the name of the Drive Server connected to the PC. Listed below are the variables found in this operation:
 - **Is server ok to operate:** Indicates if Drive Server has/has not been successfully configured. If indication is 'False', refer to Drive Server's event log to diagnose and fix error
 - **Is server connected to drives:** This statement is 'TRUE' when: Drive Server is ready to operate, when Drive Server is connected to the minimum number of drives required for operation, and is connected to the Master Unit (HA Drive Systems)
 - **Is server configured:** Confirms Drive Server has/ has not been properly configured and is/is not operational. (see Section *Set Server as Configured*).
 - **Is System duplicate type:** 'Yes' indicates duplicate type systems (HA Drive Systems). No is indicated with Parallel Drive Systems. (see Section *Set Operating Conditions*).
 - **The controlling unit is:** Indicates the current controlling unit (HA Drive Systems - Only)

- **The number of units in cluster:** This line item identifies the total number of Drives in system (see Section *Set Operating Conditions*).
- **The number of units connected:** The collective number of Drives communicating together
- **Number of units to operate:** This number represents the minimum number of Drives required to be connected in order for the system to run a motor (see Section *Set Operating Conditions*).
- **Unit connect status:** This line item provides the connection status of each Drive defined in the system

7.2.2 Menu Functions - Setup Menu

7.2.2.1 Select New Server Connection

This section allows the user to switch between Drive Server connections.

NOTICE
If there are < 2 server connections defined, one of the following informational messages will be displayed on the Drive Server Setup/ Status Utility screen: • There are no choices • No alternative choices are available

7.2.2.2 Server Connection Maintenance

This item is not enabled within the menus, unless a security password has been entered to grant 'Restricted Access'. Without Restricted Access permissive, NO sub-menu items will be available.

7.2.2.3 Create New Server Connection

This menu item allows user to create a new Drive Server connection. To perform this operation, three variables must be entered into the text boxes on the Connect screen. First, the data entered into the Connection Name text box is per the user's choice. It is used to identify the connection by name. Second, the data entered into the Actual Server Name text box is system dependent. The text must be the actual name used in the server definition..

NOTICE

If the Actual Server Name has been changed from the Default Entry, that new name must be entered in this field.

Third, the data entered in the Machine's Name or IP Address text box is also system dependent. The Machine Name on which the server resides should be used to achieve maximum functionality.

The Machine Name and domain of the Remote PC can be determine by performing the following:

- Open desktop on Remote PC, move cursor to → 'My Computer' GUI, click → right mouse button, click → 'Properties' (using left mouse button), click → 'My Computer' tab (using left mouse button). A dialog window should appear.

NOTICE

If the server is running on the same machine as the Drive Server Setup/Status Utility, enter → 'LocalHost' in the text box.

NOTICE

If the Drive Server is executing from a different domain, the Machine Name cannot be used. For this application the IP Address of the machine on which the server is executing should be entered. That machine should be setup with a static IP address.
--

7.2.2.4 Edit Server Connection Data

This selection allows the user to edit the server information for a connection. This selection is valid only if there is a minimum of one connection defined. If two or more connections are defined, the user will be asked which connection will be desired for editing.

NOTICE

Refer to Section <i>Create New Server Connection</i> to identify what data to enter in the Connect screen, Actual Server Name, and Machine Name/IP Address text boxes.
--

NOTICE

If data for the current connection being used has been edited, the Drive Server Setup/Status Utility will reconnect using the new information.
--

7.2.2.5 Rename Server Connection

This menu item allows the user to rename the server connection. This selection is valid only if there is a minimum of one connection defined. If two or more connections are defined, the user will be asked which connection will be desired for renaming.

NOTICE

After completing this process, the connection name for any drive using the old connection name must be updated with the new name.

7.2.2.6 Delete Server Connection

This selection allows the user to delete a server connection. This selection is only valid if there are a minimum of (2) connections defined.

NOTICE

The server connection being used cannot be deleted.

7.2.3 Menu Functions - Server Maintenance

7.2.3.1 List Server Names

Clicking on this menu item provides the user with a list of the currently defined server names on the user's PC.

7.2.3.2 Create New Server

Selecting this item allows the user to create a new server. Drive Servers can only be created on the machine on which the Drive Server Setup/Status Utility is currently running. To create a new server, first enter the new server's name.

NOTICE

If the name chosen already exists for another server, the user must select a different name.
--

After entering name for new server, the user must now define the new server's operating parameters.

NOTICE

See Section <i>Set Operating Conditions</i> .

Next enter the IP Addresses for each of the attached drives.

NOTICE

The server will be stopped and then restarted during this process.
--



IMPORTANT!

The new server is not enabled within the menus if restricted access has not been established by entering the security password or there is no server installed on the user's PC.

7.2.3.3 Rename Server

Selecting this item will allow the user to rename a server. Drive Servers can only be renamed on the machine on which the Drive Server Setup/Status utility is currently running. If there is more than one server defined the user will be asked to select the server to be renamed.

After completing this step all connections using the old server name must be updated with the new server name.

NOTICE

The server will be stopped and then restarted during this process.



IMPORTANT!

The new server is not enabled within the menus if restricted access has not been established by entering the security password or there is no server installed on the user's PC.

7.2.3.4 Delete Server

Choosing this feature allows the user to delete a server. Drive Servers can only be deleted on the machine on which the Drive Server Setup/ Status Utility is currently running. There must be a minimum of one server defined on a PC running the server software.

NOTICE

If only one server is defined on the PC, the user will not be allowed to delete it.

NOTICE

The server will be stopped and then restarted during this process.



IMPORTANT!

The new server is not enabled within the menus if restricted access has not been established by entering the security password or there is no server installed on the user's PC.

7.2.4 Menu Functions - Config Menu

7.2.4.1 Select Server Controlled Data

This menu item allows the user to set the parameters that will be controlled by the server. The user must be connected to a Drive Server for this menu item to function. The controlled data set must be enabled for the server that is connected.

When this item is selected, a list of parameter IDs will be displayed with checkboxes. The user will identify the parameters to be controlled by the server, by clicking the associated checkboxes beside each of parameter. Only those parameters checked will be controlled by the server.

NOTICE

There are menu items provided to alternately check or uncheck all of the checkboxes.
--

Once a parameter is configured to be controlled by a server, the same value will be maintained in all attached drives.



IMPORTANT!

The item is not enabled within the menus if restricted access has not been established by entering the security password or there is no server installed on the user's PC.
--

NOTICE

See Section <i>Set Server as Configured</i> .

7.2.4.2 Set Server as Configured

A Drive Server that is operating has been configured. Therefore a server that is being setup for operation is unconfigured. An unconfigured server communicates with server, but parameter control has not been enabled and drive tool communication with the drives through the server is not permitted. A Drive Server must be set as unconfigured to use the select server controlled data, set operating conditions, configure initial parameters or change drive Names/IP Address menu items. The user must be connected to a server to perform this operation.



IMPORTANT!

The item is not enabled within the menus if restricted access has not been established by entering the security password or there is not connected to server.

7.2.4.3 Set Operating Conditions

This menu item is for future functionality and is currently not available.

7.2.4.4 Configure Initial Parameters

This option applies only to Non-High Availability type systems. The menu item gives the user the ability to configure the initial parameters for the server. This procedure is used for first-time set up of server parameters or to restore parameter settings that may have been altered due to an interruption with server. The user must be connected to a server to perform these commands.

**IMPORTANT!**

The server chosen must have initial parameters configured.

This section of this chapter addresses loading server with proper parameter values prior to being set as Configured.

NOTICE

Once the server is set as 'Configured' any parameter value in a drive that does not agree with the server's value, will be over written to match the value of the server.

When a parameter value mismatch occurs a dialog window will be displayed. In the first column of the display the user will see a list of the Parameter IDs (Only Parameter IDs which are set as server controlled in the respective server controlled data procedure will be displayed). In the second column of the display the user will see a list of values currently in the server. The next column will display lists of data for each of the drives connected to the server.

NOTICE

Rows will be highlighted in Yellow for any drive having a parameter value that is different than the server's value.

If a parameter value conflict is identified, the user must resolve the error before proceeding. If one of the drives has the correct value the user must check the box next to the displayed value in that drive's respective column (Only one column per row may contain a check mark). By double clicking on a column header, the user will be able to check all of the checkboxes in that column. Click → Apply button to move the data from the checked items into the server, then view results. Press → Refresh button to refresh the data from the drives. Some of the drives data may be listed as "Unknown". This occurs when the server contains controllable parameters which are not used in the attached drive.

**IMPORTANT!**

The item is not enabled within the menus if restricted access has not been established by entering the security password, the system is a High Availability type system, if there is no server connected or connected server is set As Configured (see Section *Set Server as Configured*).

7.2.4.5 Change Drive Names/IP Addresses

This menu item allows the user to set the IP addresses for each of the drives that are linked to the server. The user must be connected to a server to perform this operation (the server used for this operation will have its IP Address changed).

There should be (1) IP Address entry box for each drive identified in the set operating conditions 'Number of Drives' field. The number of drives SHOULD be set prior to entering data.

NOTICE

For High Availability systems the first address must be reserved for the "A" control unit (this unit does not control the fiber optic switch).



IMPORTANT!

This item is not enabled within the menus if restricted access has not been established by entering the security password or the connected server is set As Configured (see Section *Set Server as Configured*).

7.2.5 Menu Functions - Security Menu

7.2.5.1 Enter Security Code

Selecting this menu item displays a dialog window containing a text box to enter a password. The password allows the user to access restricted features within the program.



IMPORTANT!

This item is not enabled within the menus if restricted access HAS BEEN GRANTED by entering the security password.

7.2.5.2 Security Clear



CAUTION!

When enabling this menu option the user's access to the restricted features within a program WILL BE REMOVED.



IMPORTANT!

This item is not enabled within the menus if restricted access HAS NOT been granted by entering the security password.

7.2.5.3 Run Menu

NOTICE

This menu item is not available if an IP Address is entered in the server connection data in place of a machine name (See Section <i>Create New Server Connection</i>).
--

7.2.5.4 Start Menu

Clicking this menu command will start server.



IMPORTANT!

This menu item is not enabled if restricted access HAS NOT been granted by entering the security password, no server is connected to, or the server is currently running.

Clicking this menu command will stop server.



IMPORTANT!

This menu item is not enabled if restricted access HAS NOT been granted by entering the security password, no server is connected to, or the server is currently NOT running.

7.2.5.5 Restart Menu

Clicking this menu command will stop, then restart the server. This feature allows user to re-initialize server if server's drive information has been modified.



IMPORTANT!

This menu item is not enabled if restricted access HAS NOT been granted by entering the security password, no server is connected to, or the server is currently NOT running.

High Availability Drive Tool

This section defines the features added to the Drive Tool, exclusive to High Availability systems only.

8.1 Connection to Drive Tool


After defining the Drive Server connection on a PC (as outlined in the *Drive Server Setup/Status Utility* Chapter, Section *Start and Configure the Configuration Update Utility*), that connection can be used for communication by the Drive Tool.

NOTICE
It is important to remember the server connection name being used on a PC, as this name must also be used to connect the drive with the Drive Tool from that PC.


In order for a drive to connect through its Drive Server, the Drive Server must first be set “As Configured” and must have “Ok to operate” and “Connected to drives” as its status. If these conditions are not met, the Drive Tool will not connect.

8.1 Connection to Drive Tool

1. Create a new Drive Tool configuration (as outlined in the ToolSuite Manual). After creating new Drive Tool, start the new instance. A window similar to the one in the figure below will appear.




2. Double click the "TCP/IP server name" parameter in the menu tree. A dialog window will appear. In the 'New Value' text box, enter the name of the Drive Server connection ("Remote Drive Server" is used in the figure below).



If the Name entered is not recognized by the Drive Server, the following dialog will appear:




If the Name entered is accepted by the Drive Server, the following dialog will appear:




8.2 Selecting Desired Control System

To change the selected Control System perform the following steps:

1. Click on → View menu, then click → Drive in the pull-down menu (as shown in figure below).



2. Type 'Control' in the text box of the dialog window (see figure below).



NOTICE

'Control' is the default setting and represents the Control System currently controlling the motor.

When the 'Control' feature is selected on the Drive Tool menu tree, only the parameters which are server controlled will be active. The controlling unit, either 'A' or 'B' will be identified in the list. When a selection is made for a specific Control System, the parameters in the tree will be those parameters on that control which are not server controlled. The Control System that is active will be displayed in the top line of the menu tree.

Glossary

This appendix contains definitions of terms and abbreviations used throughout the Perfect Harmony series manuals.

AND

AND is a logical Boolean function whose output is true if all of the inputs are true in SOP notation, AND is represented as "*" (e.g., $C=A*B$), although sometimes it may be omitted between operands with the AND operation being implied (e.g., $C=AB$).

ASCII

ASCII is an acronym for American Standard Code for Information Interchange, a set of 8-bit computer codes used for the representation of text.

Automatic bypass operation

Automatic bypass operation is the same as bypass operation, but occurs automatically if a drive fault occurs and a pre-defined time has elapsed after the fault.

Automatic mode

Automatic mode is a control scheme in which the operator selects an input to be used as the desired velocity input. Speed profiling is used in automatic mode to allow the operator to scale the output based on a programmable input range.

Baud rate

Baud rate is a measure of the switching speed of a line, representing the number of changes of state of the line per second. The baud rate of the serial port of the Perfect Harmony is selected through the Baud Rate parameter in the Communications Menu [9].

Bit

Bit is an acronym for Binary digit. Typically, bits are used to indicate either a true (1) or false (0) state within the drive's programming.

Boolean algebra

Developed by mathematician George Boole, Boolean algebra is a form of mathematical rules used in the design of digital and logic systems.

Bypass option

The Bypass option can be selected to provide optional line operation of the motor.

Carrier frequency

Carrier frequency is the set switching frequency of the power devices (IGBTs) in the power section of each cell. The carrier frequency is measured in cycles per second (Hz).

“Catch a spinning load” feature

“Catch a spinning load” is a feature that can be used with high-inertia loads (e.g., fans), in which the drive may attempt to turn on while the motor is already turning. This feature can be enabled via the NXG menu system.

CLVC

An acronym for Closed Loop Vector Control - which is one of six control modes in the NXG drive. This is flux vector control for an induction machine (IM), utilizing an encoder for speed feedback.

CMP

Refer to the glossary term **SOP**.

Comparator

A comparator is a device that compares two quantities and determines their equality. The comparator submenus allow the programmer to specify two variables to be compared. The results of the custom comparison operations can be used in the system program.

Compiler

A computer program (or set of programs) that translates high-level programming computer language (the source code) into a lower-level programmable language (assemble or machine language).

Configuration Update

see ToolSuite definition.

Converter

The converter is the component of the drive that changes AC voltage to DC voltage.

Critical speed avoidance

Critical speed avoidance is a feature that allows the operator to program up to 3 mechanical system frequencies that the drive will “skip over” during its operation.

CSMC

An acronym for Closed Loop Synchronous Machine (SM) Control. One of six control modes of the NXG drive. This is a flux vector control for a synchronous machine, utilizing an encoder for speed feedback and providing a field excitation command for use by an external field exciter.

DC link

The DC link is a large capacitor bank between the converter and inverter section of the drive. The DC link, along with the converter, establishes the voltage source for the inverter.

Debug Tool

see ToolSuite definition.

De Morgan's Theorem

The duality principal of Boolean algebra used to convert system logic equations into sum-of-products notation.

Downloading

Downloading is a process by which information is transmitted from a remote device (such as a PC) to the drive. The term “downloading” implies the transmission of an entire file of information (e.g., the system program) rather than continued interactive communications between the two devices. The use of a PC for downloading requires special serial communications software to be available on the PC, which may link to the drive via RS232 or through the Host Simulator via an ethernet connection.

DRCTRY

Directory file for system tokens and flags used in the compilation of system programs. It provides a direct lookup table of ASCII names to internal ID numbers. It also identifies whether the flag is a word or bit-field, and also whether it can be used as an input or output only, or can be used for both.

Drive

The term “drive” refers to the power conversion equipment that converts utility power into power for a motor in a controlled manner.

ELV

ELV is an acronym for extra low voltage, and represents any voltage not exceeding a limit that is generally accepted to be 50 VAC and 120 VDC (ripple free).

EMC

EMC is an acronym for electromagnetic compatibility—the ability of equipment to function satisfactorily in its electromagnetic environment without introducing intolerable electromagnetic disturbances to anything in that environment.

ESD

ESD is an acronym for electrostatic discharge. ESD is an undesirable electrical side effect that occurs when static charges build up on a surface and are discharged to another. When printed circuit boards are involved, impaired operation and component damage are possible side effects due to the static-sensitive nature of the PC board components. These side effects may manifest themselves as intermittent problems or total component failures. It is important to recognize that these effects are cumulative and may not be obvious.

Fault log

Fault messages are saved to memory so that the operator may view them at a later time. This memory location is called the fault log. The fault log lists both fault and alarm messages, the date and time that they occurred, and the time and date that they are reset.

Faults

Faults are error conditions that have occurred in the Perfect Harmony system. The severity of faults vary. Likewise, the *treatment* or corrective action for a fault may vary from changing a parameter value to replacing a hardware component such as a fuse.

Flash Card

Non-volatile memory storage device for the NXG control. It stores the drive program, system program, logs, parameters, and other related drive files.

FPGA

Field Programmable Gate Array. An FPGA is an integrated circuit that contains thousands of logic gates.

Function

A function is one of four components found in the Perfect Harmony menu system. Functions are built-in programs that perform specific tasks. Examples of functions include System Program Upload/Download and Display System Program Name.

Harmonics

Harmonics are undesirable AC currents or voltages at integer multiples of the fundamental frequency. The fundamental frequency is the lowest frequency in the wave form (generally the repetition frequency). Harmonics are present in any non-sinusoidal wave form and cannot transfer power on average.

Harmonics arise from non-linear loads in which current is not strictly proportional to voltage. Linear loads like resistors, capacitors, and inductors do not produce harmonics. However, non-linear devices such as diodes and silicon controlled rectifiers (SCRs) do generate harmonic currents. Harmonics are also found in uninterruptable power supplies (UPSs), rectifiers, transformers, ballasts, welders, arc furnaces, and personal computers.

Hexadecimal digits

Hexadecimal (or “hex”) digits are the “numerals” used to represent numbers in the base 16 (hex) number system. Unlike the more familiar decimal system, which uses the numerals 0 through 9 to make numbers in powers of 10, the base 16 number system uses the numerals 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, A, B, C, D, E, and F to make numbers in powers of 16.

Historic log

The historic log is a troubleshooting/diagnostic tool of the Perfect Harmony NXG control. The historic log continuously logs drive status, including the drive state, internal fault words, and multiple user-selectable variables. This information is sampled every slow loop cycle of the NXG control (typically 450 to 900 times per second). If a fault occurs, the log is frozen a pre-defined number of samples after the fault event, and data samples prior to and after the fault condition are recorded to allow post-fault analysis. The number of samples recorded are user-selectable via the NXG control, as well as the option to record the historic log within the VFD event log.

Host Simulator

see ToolSuite definition.

I/O

I/O is an acronym for input/output. I/O refers to any and all inputs and outputs connected to a computer system. Both inputs and outputs can be classified as analog (e.g., input power, drive output, meter outputs, etc.) or digital (e.g., contact closures or switch inputs, relay outputs, etc.).

IGBT

IGBT is an acronym for Insulated Gate Bipolar Transistors. IGBTs are semiconductors that are used in the Perfect Harmony drives to provide reliable, high-speed switching, high-power capabilities, improved control accuracy, and reduced motor noise.

Induction motor

An induction motor is an AC motor that produces torque by the reaction between a varying magnetic field (generated in the stator) and the current induced in the coils of the rotor.

Intel hex

Intel hex refers to a file format in which records consist of ASCII format hexadecimal (base 16) numbers with load address information and error checking embedded.

Inverter

The inverter is a portion of the drive that changes DC voltage into AC voltage. The term “inverter” is sometimes used mistakenly to refer to the entire drive (the converter, DC link, and inverter sections).

Jerk rate

Jerk rate is the time it takes for the drive to go from one acceleration rate to another. The jerk rate is a programmable parameter used to limit the rate of change of the acceleration. Jerk rate has no effect if acceleration is constant. Jerk rate helps to prevent small overshoots and provides the “S-curve” (speed / timeplot) characteristic as the speed setpoint is reached.

Jog mode

Jog mode is an operational mode that uses a pre-programmed jog speed when a digital input (programmed as the jog mode input) is closed.

Jumpers

Jumper blocks are groups of pins that can control functions of the system, based on the state of the jumpers. Jumpers (small, removable connectors) are either installed (on) or not installed (off) to provide a hardware switch.

Ladder logic

(Also Ladder Diagram) A graphical representation of logic in which two vertical lines, representing power, flow from the source on the left and the sink on the right, with logic branches running between, resembling rungs of a ladder. Each branch consists of various labeled contacts placed in series and connected to a single relay coil (or function block) on the right.

LED

LED is an acronym for light emitting diode. The Perfect Harmony uses three LEDs as diagnostic indicators on the keypad/display assembly.

Loss of signal feature

The loss of signal feature is a control scheme that gives the operator the ability to select one of three possible actions in the event that the signal from an external sensor, configured to specify the speed demand, is lost. Under this condition, the operator may program the drive (through the system program) to (1) revert to a fixed, pre-programmed speed, (2) maintain the current speed, or (3) perform a controlled (ramped) stop of the drive. By default, current speed is maintained.

LVD

LVD is an acronym for Low Voltage Directive, a safety directive in the EU.

Lvl RH

This term refers the two security fields associated with each parameter of the system. These fields allow the operator to individually customize specific security features for each menu option (submenu, parameter, pick list, and function). These fields are shown in parameter dumps and have the following meanings. Lvl is the term for the security level. Setting R=1 blocks parameter change, and setting H=1 hides the menu option from view until the appropriate access level has been activated.

Manual mode

Manual mode is a control scheme of the Perfect Harmony in which the desired velocity of the drive is set manually by the operator. In local manual mode, the desired velocity is set using the up and down arrow keys on the front keypad of the drive. In remote manual mode, the desired velocity is set using a potentiometer input (located remotely from the drive) that is wired to the drive.

Memory

Memory is the working storage area for the Perfect Harmony drive that is a collection of RAM chips.

Microprocessor

A microprocessor is a central processing unit (CPU) that exists on a single silicon chip. The microprocessor board is the printed circuit board on which the microprocessor is mounted. The NXG drive employs a single-board computer with a Pentium® microprocessor.

NEMA 1 and NEMA 12

NEMA 1 is an enclosure rating in which no openings allow penetration of a 0.25-inch diameter rod. NEMA 1 enclosures are intended for indoor use only. NEMA 12 is a more stringent NEMA rating in which the cabinet is said to be “dust tight” (although it is still not advisable to use NEMA 12 in conductive dust atmospheres). The approximate equivalent IEC rating is IP52.

Normally closed (NC)

Normally closed refers to the contact of a relay that is closed when the coil is de-energized.

Normally open (NO)

Normally open refers to the contact of a relay that is open when the coil is de-energized.

OLTM

An acronym for Open Loop Test Mode - One of six control modes of the NXG drive.

OLVC

An acronym for Open Loop Vector Control, also known as Encoderless Vector Control. OLVC is a flux vector control that is one of six control modes of the NXG drive. The drive computes the rotational speed of the rotor and uses it for speed feedback.

OOS

OOS is an abbreviation for out of saturation - a type of fault condition in which a voltage drop is detected across one of the IGBTs during conduction. This can indicate that the motor is drawing current too rapidly or in excess.

OR

OR is a logical Boolean function whose output is true if any of the inputs is true. In SOP notation, OR is represented as “+”.

Parameter

A parameter is one of four items found in the Perfect Harmony menu system. Parameters are system attributes that have corresponding values that can be monitored or, in some cases, changed by the user.

PED

PED is an acronym for pressure equipment directive, a directive of the EU relating to pressure vessels.

Pick list

A pick list is one of four items found in the Perfect Harmony menu system. Pick lists are parameters that have a finite list of pre-defined “values” from which to choose, rather than a value range used by parameters.

PID

PID is an acronym for proportional + integral + derivative, a control scheme used to control modulating equipment in such a way that the control output is based on (1) a proportional amount of the error between the desired setpoint and the actual feedback value, (2) the summation of this error over time, and (3) the change in error over time. Output contributions from each of these three components are combined to create a single output response. The amount of contribution from each component is programmable through gain parameters. By optimizing these gain parameters, the operator can “tune” the PID control loop for maximum efficiency, minimal overshoot, quick response time, and minimal cycling.

Qualified user

A qualified user is a properly trained individual who is familiar with the construction and operation of the equipment and the hazards involved.

Quick menu

Quick menu is a feature of the menu system that allows the operator to directly access any of the menus or parameters, rather than scrolling through menus to the appropriate item. This feature uses the [Shift] button in conjunction with the right arrow. The user is prompted to enter the four digit ID number associated with the desired menu or parameter.

RAM

RAM is an acronym for Random Access Memory, a temporary storage area for drive information. The information in RAM is lost when power is no longer supplied to it. Therefore, it is referred to as volatile memory.

Regeneration

Regeneration is the characteristic of an AC motor to act as a generator when the rotor’s mechanical frequency is greater than the applied electrical frequency.

Relay

A relay is an electrically controlled device that causes electrical contacts to change their status. Open contacts will close and closed contacts will open when rated voltage is applied to the coil of a relay.

Resonance avoidance

Resonance avoidance is a feature that allows the operator to program up to 3 mechanical system frequencies that the drive will “skip over” during its operations.

RS232C

RS232C is a serial communications standard of the Electronics Industries Association (EIA).

Setpoint

Setpoint is the desired or optimal speed of the VFD to maintain process levels (speed command).

Slip

Slip is the difference between the stator electrical frequency of the motor and the rotor mechanical frequency of the motor, normalized to the stator frequency as shown in the following equation.:

$$\text{Slip} = \frac{\omega_s - \omega_R}{\omega_s}$$

Slip is the force that produces torque in an induction motor. Slip can also be defined as the shaft power of the motor divided by the stator input power.

Slip compensation

Slip compensation is a method of increasing the speed reference to the speed regulator circuit (based on the motor torque) to maintain motor speed as the load on the motor changes. The slip compensation circuit increases the frequency at which the inverter section is controlled to compensate for decreased speed due to load droop. For example, a motor with a full load speed of 1760 rpm has a slip of 40 rpm. The no load rpm would be 1800 rpm. If the motor nameplate current is 100 A, the drive is sending a 60 Hz wave form to the motor (fully loaded); then the slip compensation circuit would cause the inverter to run 1.33 Hz faster to allow the motor to operate at 1800 rpm, which is the synchronous speed of the motor.

SMC

Is an acronym for Synchronous Motor Control - which is one of six control modes in the NXG drive. This mode computes the rotational speed similarly to open-loop vector control, and controls the field reference or the synchronous motor as in closed-loop synchronous motor control.

SOP

(1) SOP is an acronym for Sum Of Products. The term “sum-of-products” comes from the application of Boolean algebraic rules to produce a set of terms or conditions that are grouped in a fashion that represents parallel paths (ORing) of required conditions that all must be met (ANDing). This would be equivalent to branches of connected contacts on a relay logic ladder that connect to a common relay coil. In fact, the notation can be used as a shortcut to describe the ladder logic. **(2)** SOP, when used as a filename extension, refers to System Operating Program.

SOP Utilities

The program within the Siemens LD A ToolSuite used for converting between text and machine loadable code. It can also be used for uploading and downloading files over the RS232 connection. See also ToolSuite definition.

Stop mode

Stop mode is used to shut down the drive in a controlled manner, regardless of its current state.

Submenus

A submenu is one of four components found in the Perfect Harmony menu system. Submenus are nested menus (i.e., menus within other menus). Submenus are used to logically group menu items based on similar functionality or use.

Synchronous speed

Synchronous speed refers to the speed of an AC induction motor's rotating magnetic field. It is determined by the frequency applied to the stator and the number of magnetic poles present in each phase of the stator windings. Synchronous Speed equals 120 times the applied Frequency (in Hz) divided by the number of poles per phase.

System Operating Program

The functions of the programmable inputs and outputs are determined by the default *system program*. These functions can be changed by modifying the appropriate setup menus from the front keypad and display. I/O assignments can also be changed by editing the system program (an ASCII text file with the extension .SOP), compiling it using the compiler program, and then downloading it to the controller through its serial port, all by utilizing the SOP Utility Program with the Siemens LD A ToolSuite.

ToolSuite

Is the suite of programs developed by Siemens that allows easier access to the NXG drive for programming and monitoring. It is comprised of the following components:

ToolSuite Launcher

also referred to as ToolSuite; used for coordinating other tools.

SOP Utilities

used to launch an editor that compiles or reverse compiles a System Program. It also allows for serial connection to the drive for uploading and downloading System Programs.

Configuration Update

allows for backing-up, updating, and cloning drives via direct access to the Flash Disk.

Host Simulator

used for monitoring, programming, and controlling a drive remotely from a PC over the built-in ethernet port of the drive. Parameter changes, status display, and graphing of internal variables are its main functions.

Debug Tool

this tool is used to display the diagnostic screens of the drive for diagnosing drive problems or improving performance via the built-in ethernet port of the drive.

ToolSuite Launcher

see ToolSuite definition.

Torque

The force that produces (or attempts to produce) rotation, as in the case of a motor.

Uploading

Uploading is a process by which information is transmitted from the drive to a remote device such as a PC. The term uploading implies the transmission of an entire file of information (e.g., the system program) rather than continued interactive communications between the two devices. The use of a PC for uploading requires communications software to be available on the PC.

Variable frequency drive (VFD)

A VFD is a device that takes a fixed voltage and fixed frequency AC input source and converts it to a variable voltage, variable frequency output that can control the speed of an AC motor.

Vector control

Vector control is one of two available application modes of the Perfect Harmony drive. Vector control mode means that the control algorithm of the drive consists of a *closed loop* speed control component and a *closed loop* torque control component. Since vector control applications require (a) precisely controlled starting torques ($\pm 0.1\%$), (b) precisely controlled speeds ($\pm 0.1\%$), and/or (c) fast response, such applications use either an encoder or a magnetic pickup for direct speed control feedback. Typical vector control applications include centrifuges, extruders and test stands. Compare with *standard control*.

VHZ

Is an acronym for Volts per Hertz control, one of six control modes in the NXG drive. This mode is intended for multiple motors connected in parallel. Therefore, it disables spinning load and fast bypass. This is essentially open-loop vector control with de-tuned (smaller bandwidth obtained by reducing the gain) current regulators.

Abbreviations

This appendix contains a list of symbols and abbreviations commonly used throughout the Perfect Harmony series of manuals.

Abbreviation	Meaning
•	Boolean AND function
+	Addition or Boolean OR
Σ	Summation
μ	Microsecond
A	Amp, Ampere
AC	Alternating Current
accel	Acceleration
A/D	Analog to Digital Converter
ADC	Analog to Digital Converter
AI	Analog Input
alg	Analog
avail	Available
BIL	Basic Impulse Level
BTU	British thermal units
C	Centigrade or Capacitor
cap	Capacitor
CCB	Cell Control Board
ccw	Counter clockwise
CE	Formerly European Conformity, now true definition
CFM	Cubic feet per minute
CLVC	Closed Loop Vector Control
cmd	Command
com	Common
conn	Connector
CPS	Control Power Supply
CPU	Central Processing Unit
CSMC	Closed Loop Synchronous Motor Control
CT	Current Transformer
cu	Cubic

Abbreviation	Meaning
curr, I	Current
cw	Clockwise
D	Derivative (PID), depth
D/A	Digital-to-analog (converter)
db	Decibel
DC	Direct Current
DCR	Digital Control Rack
DCS	Distributed Control System
decel	Deceleration
deg, °	Degrees
DHMS	Down hole monitoring system
div	Division
dmd	Demand
e	Error
EC	Electrically Commutated
ELV	Extra Low Voltage
EMC	Electromagnetic Compatibility
EMF	Electromotive Force
EMI	Electromagnetic Interference
EPS	Encoder Power Supply
ESD	Electrostatic Discharge
ESP	Electrical Submersible Pump
ESTOP, e-stop	Emergency Stop
fb, fdbk	Feedback
ffwd	Feed Forward
FLC	Full Load Current
freq	Frequency
ft, '	Feet
fwd	Forward
gnd	Ground
GUI	Graphical User Interface
H	Height
H ₂ O	Water
hex	Hexadecimal
hist	Historic
hp	Horsepower
hr	Hour
HV	High Voltage
HVAC	Heating, Ventilation, Air Conditioning
HVF	Harmonic Voltage Factor
Hz	Hertz

Abbreviation	Meaning
I	Integral (PID)
ID	Identification
IEC	International Electrotechnical Commission
IEEE	Institute of Electrical and Electronic Engineers
IGBT	Insulated Gate Bipolar Transistor
in	Input
in, “	Inches
INH	Inhibit
I/O	Input(s)/Output(s)
IOB	I/O Breakout Board
IOC	Instantaneous Overcurrent
IP	Input Protection
k	1,000 (e.g., Kohm)
kHz	KiloHertz
kV	Kilo Volts
kVA	One Thousand Volt Amps
kW	Kilowatt
L	Inductor
LAN	Local Area Network
lbs	Pounds (weight)
LCD	Liquid Crystal Display
ld	Load
LED	Light-emitting Diode
LFR	Latch Fault Relay
lim	Limit
LOS	Loss Of Signal
lps	Liters Per Second
mA	Milliamperes
mag	Magnetizing
max	Maximum
MCC	Motor Control Center
mg	Milligram
min	Minimum, Minute
msec	Millisecond(S)
msl	Mean Sea Level
MV	Medium Voltage
mvlt	Motor Voltage
MW	Megawatt
NC	Normally Closed
NEMA	National Electrical Manufacturer's Association
NMI	Non-Maskable Interrupt

Abbreviation	Meaning
No	Normally Open
NVRAM	Non-Volatile Random Access Memory
NXG	Next Generation Control
NXG II	Next Generation Control II
oamp	Output Current
OLVC	Open Loop Vector Control
O-M	Overmodulation
OOS	Out of Saturation (IGBT)
overld	Overload
P	Proportional (PID)
Pa	Pascals
pb	Push Button
PC	Personal Computer or Printed Circuit
PCB	Printed Circuit Board
PID	Proportional Integral Derivative
PLC	Programmable Logic Controller
PLL	Phase Locked Loop
pot	Potentiometer
pp	Peak-to-peak
ppm	Parts per Million
PPR	Pulses per Revolution
PQM	Power Quality Meter
ProToPS™	Process Tolerant Protection Strategy
PSDBP	Power Spectral Density Break Point
psi	Pounds Per Square Inch
pt	Point
PT	Potential Transformer
PWM	Pulse Width Modulation
Q1,Q2,Q3,Q4	Output Transistor Designations
rad	Radians
RAM	Random Access Memory
ref	Reference
rev	Reverse, Revolution(S)
RFI	Radio Frequency Interference
RLBK	Rollback
rms	Root-mean-squared
RPM	Revolutions Per Minute
RTD	Resistance Temperature Detector
RTU	Remote Terminal Unit
RX	Receive (RS232 Communications)
s	Second(s)

Abbreviation	Meaning
SCB	Signal Conditioning Board
SCR	Silicon Controlled Rectifier
sec	Second(s)
ser	Serial
SMC	Synchronous Motor Control
SOP	Sum of Products; System Operating Program
spd	Speed
stab	Stability
std	Standard
sw	Switch
T1, T2	Output Terminals T1 and T2
TB	Terminal Block
TBD	To Be Determined
TCP/IP	Transmission Control Protocol/Internet Protocol
THD	Total Harmonic Distortion
TOL	Thermal Overload
TP	Test Point
trq, τ	Torque
TX	Transmit (RS232 Communications)
UPS	Uninterruptable Power Supply
V	Voltage, Volts
VA	Volt-Amperes
VAC	Volts AC
var	Variable
VDC	Volts DC
vel	Velocity
VFD	Variable Frequency Drive
V/Hz	Volts per Hertz
vlt	Voltage(s), Volts
VSI	Voltage Source Inverter
W	Width, Watts
WAGO	Expansion I/O System
xfrm, xformer	Transformer

Operators and Precedence

C.1 Operators and Precedence

There are two forms of operators that can be used in a source line of the system program. These forms are *unary operators* (requiring only a single operand) and *binary operators*.

There is a single unary operator: the negate operator. This operator takes the form of a slash character ("/") which precedes a single input symbol. This operator forms the inverse logic equivalent of the symbol immediately following it for incorporation into the statement evaluation. It has higher precedence than the binary operators, which means it is evaluated before the evaluation of any binary operations.

NOTICE

The "/" symbol must be followed by an input symbol.

For example, the expression:

/Zero_O

equates to:

NOT Zero_O.

If the input variable "Zero_O" were FALSE, then "/Zero_O" would equate to TRUE.

There are two binary operators: AND and OR. These operators take the form of an asterisk ("*") and a plus sign ("+"), respectively. These operators correspond to the Boolean AND and OR functions. Unlike the unary NOT operator (which requires only a single variable), each of these operators requires two variables, which surround the operator.

The binary operators "+" and "*" serve to form the simple Boolean combination of the combined expression preceding the operator and the symbol (possibly negated) immediately following the operator. Parentheses are not allowed to force expression evaluation. The expression must be formed with left to right precedence and must be expanded to simple form.

Refer to the Boolean truth tables in Table C-1 for functional descriptions of the operators.

Table C-2 shows the precedence of operations. Table C-3 shows syntax examples.

Table C-1: Boolean Truth Table for the NOT, AND and OR Functions

NOT Function		AND Function			OR Function		
A	/A	A	B	A*B	A	B	A+B
False	True	False	False	False	False	False	False
True	False	False	True	False	False	True	True
		True	False	False	True	False	True
		True	True	True	True	True	True

Table C-2: Precedence of Operations

Type of Operation	Symbol	Meaning	Precedence
Unary Operation	/	Not	High (performed first)
Binary Operation	*	And	:
Binary Operation	+	Or	Low (performed last)

Table C-3: Syntax Examples

Example	Description
C = A + B;	Correct, C equals A OR B
C = A * B + D;	Correct, C equals (A AND B) OR D
C = A + B * D;	Correct, C equals A OR (B AND D)
C = A * B + A * D;	Correct, C equals (A AND B) OR (A AND D)
C = A * (B + D);	Incorrect, parentheses not allowed
C = A + /B;	Correct, C equals A OR (NOT B)
/C = A * B;	Incorrect, negation not permitted on output side

The term “sum-of-products” comes from the application of Boolean algebraic rules to produce a set of terms or conditions that are grouped in a fashion that represents parallel paths (ORing) of required conditions that all must be met (ANDing). This would be equivalent to branches of connected contacts on a relay logic ladder that connect to a common relay coil. In fact, the notation can be used as a shortcut to describe the ladder logic.

First let us examine the rules of Boolean algebra. The set of rules that apply in this logical math are broken into three sets of laws: commutative, associative, and distributive. The operators are “AND” (abbreviated with the “.” character [or “*” character from the keyboard]), “OR” (abbreviated with the “+” character), and “NOT” (abbreviated with a line above the operand, e.g., A [or a preceding “/” character from the keyboard]). The commutative, associative, and distributive rules are shown in Table C-4.

Table C-4: Boolean Laws

Commutative ^a	Associative ^a	Distributive ^a
$A + B = B + A$	$A + (B + C) = (A + B) + C$	$A (B + C) = AB + AC$
$AB = BA$	$A (BC) = (AB) C$	

a. The syntax "AB" implies $(A \cdot B)$

Table C-5: General Rules of Boolean Math

General Rules	General Rules	General Rules ^a
$A \cdot 0 = 0$	$A + 0 = A$	$A + AB = A$
$A \cdot 1 = A$	$A + 1 = 1$	$A (A + B) = A$
$A \cdot A = A$	$A + A = A$	$(A + B) (A + C) = A + BC$
$A \cdot \bar{A} = 0$	$A + \bar{A} = 1$	$A + \bar{A}B = A + B$
$\bar{\bar{A}} = A$		

a. The syntax "AB" implies $(A \cdot B)$

Add to this DeMorgan's Theorem which states "the complement of the intersection (AND) of any number of sets equals the union (OR) of their complements" which, simply stated, means that if you invert a grouping of elements, you invert the individual elements and also change the logical relationship between them. So you can change from an OR to an AND function, for example:

$$\overline{(A + B)} = (\bar{A} \cdot \bar{B})$$

or from an AND to an OR function, for example:

$$\overline{(A \cdot B)} = (\bar{A} + \bar{B})$$

By using these rules, any logical statement can be reduced to the sum (+) of products ($\cdot$) or the ORing of ANDed terms as illustrated in the following example:

$$O = AB + \bar{B}\bar{C}D + C\bar{D}\bar{F};$$

The SOP file, as mentioned above, is written with a text editor or a word processor set for pure ASCII text (having a .TXT file extension) with no control or formatting codes with the exception of horizontal tabs (ASCII code 09h) and carriage returns (0Dh). Only printable characters and spaces (20h) can be used. The file consists of the following format:

Item	Description
Drive type specifier	This must reside on the first line of the file prefixed with the pound sign (#) and followed with the name of the drive (in the case of Perfect Harmony, this would be #Harmony;)
Header	A comment field containing the following information: Title - Siemens LD A Perfect Harmony drive Program part number Customer name Sales order number and Siemens drive part number Drive description Original SOP date File name Engineer Name (Originator) Revision history (date and change description) Note: A comment is any text within the file, preceded by a semi-colon, which is used exclusively for informational purposes and is ignored by the compiler.
Operators	Comment field containing operators and symbols
I/O specifier	Comment field describing the system input and output flags as they relate to the external system. This would include any user faults and notes on menu settings, such as Comparator setups and XCL settings, as they apply to the system program (more on this later). These can (and should) be grouped logically to allow easy access to information and to make the SOP more understandable.
User fault messages	Assigns the text to be displayed when this particular user fault is activated.
Main logic section	All the equations and assignments for the configuration, annunciation, and operation of the drive. These should be logically arranged with careful consideration given to the order of evaluation of the equations.

C.2 Ladder Logic Translation

It was mentioned above that the sum-of-products notation can represent ladder logic. In actuality, it is very easy to directly translate between the two. For example, consider the equation or statement:

$$Z = \bar{A}BC + D\bar{E}F + FGH;$$

Translated into the notation of the limited ASCII characters available in a common text editor, the statement would read as follows (note that the components are separated at "ORs" and stacked for clarity).

$$\begin{aligned} Z = & /A*B*C \\ & + D*/E*F \\ & + F*G*H; \end{aligned}$$

This statement can be pictorially represented by breaking each statement down in the following manner:

1. First, the output variable (in this case Z) is represented by a coil to the right of the ladder.
2. Second, each product term (the variables separated by the asterisk) is represented by a single line of contacts connecting to the coil.
3. All the product terms that are summed (separated by the plus sign) are represented by parallel paths to the same coil.
4. All non-inverted contacts are represented by normally open (NO) contacts, while the inverted terms are represented by normally closed (NC) contacts.

The resulting ladder logic is illustrated in Figure C-1.




Figure C-1: Ladder Logic Representation of a Boolean Expression - Example 1

Conversely, if the ladder logic shown in Figure C-2 is desired, it could be converted into a sum-of-products statement. The procedure would be the inverse of the previous, and is enumerated below.

1. First place the label of the output relay coil to the left, with an equals sign following.
2. Next, start in each path from left to the connection to the coil on the right, writing the label for each contact with the asterisk representing the AND or product operator in between.
3. In front of each NC contact, place a forward slash representing the inversion or NOT operator (shown in the equations as a bar over the variable name).

4. Repeat this for each parallel path using the OR (sum) operator (+) in between each grouping of product terms.
5. Finally, the statement is terminated by a semicolon to represent the end of the statement.





Figure C-2: Ladder Logic Representation of a Boolean Expression - Example 2

Ethernet Connections

D.1 Direct Connection


Direct connection is intended for either a single PC connected to the drive using an Ethernet crossover cable, or a small network hub or switch connecting multiple drives to one or more PCs.



D.1.1 Required Items for a Single Ethernet Direct Connection

- Crossover patch cable: this allows you to connect directly with the drive without a hub or server
- Coupler

D.1.2 Required Items for a Single PC Multiple Drive Ethernet Connection Support



- EtherFast 10/100 5 port HUB
- Ethernet Cat5 Cable

NOTICE
This configuration also allows for more than one PC.


D.1.3 Configuring a PC to Work with a Direct Connection

NOTICE


Windows® NT/XP/2000 and Windows® Vista each have different procedures for the configuration of network parameters.

D.1.3.1 Windows® XP /2000


1. From the Start Menu, select “Settings” and click “Control Panel” as shown below:




2. Within the Control Panel, double click on the “Network and Internet Connections” icon.




3. Select “Network Connections”.



4. The Network Connections dialog window displays. Highlight “Local Area Connection” and right-click to display a pop-up window containing a list of parameters. Select “Properties” to display the “Local Area Connections Properties” window.



- From the “Local Area Connection Properties” window select the “Internet Protocol TCP/IP” connection that your PC uses (there may be more than one).



- Choose the “Use the following IP address” radio button.





Table D-1: Addresses of PC and Drive¹

Device	IP Address
PC	a.b.m.n
Drive	a.b.x.y

¹Where *a*, *b*, *m*, *n*, *x*, and *y* can be integers between 0 and 255.

7. Set the IP addresses for both the drive and the PC. In a direct connection, you will need to set the IP addresses of both the PC running the ToolSuite, and for the drive as well. The addresses will not be completely arbitrary. Siemens recommends that the first number of both addresses be between 128 and 191 for class B network settings. You may select class A or C settings, if desired. The connection will function regardless of the class settings. The first two numbers (octets) of the drive's IP address **must** be the same as the first two numbers of the PC's IP address. *For example, if you assign 172.16.20.15 as the drive's IP address, the PC's IP address must be 172.16.x.y, where the combination of x and y must be different than 20.15.*
8. Set the drive's IP address using keypad parameter ID 9310.
9. Next, set the subnet mask for the PC and the drive. In the "Subnet Mask:" field of the IP Address page, enter a value of 255.255.0.0. This value is the default for a class B network. The subnet mask must be the same for both the PC and the drive. Set the drive's subnet mask using keypad parameter ID 9320.
10. Set the gateway for the drive and the PC. Stay in the TCP/IP Properties dialog box and click on the "Gateway" tab. Assign a valid arbitrary address number to the PC's gateway in the "New Gateway" field. This address can be arbitrary (i.e. 0.0.0.0) because a direct connection does not actually use a gateway. *This virtual gateway that you are creating for the direct connection does not physically exist. It is only to satisfy the software.* After entering the address in the "New Gateway" field, go to the keypad on the front of the drive, and enter the same gateway address in parameter ID 9330.


11. Click “OK”. The “Connection Properties” window appears.




12. Click “OK”. Windows may ask you if would like to restart your computer so that the changes can take effect. Click “Yes” to restart.

D.1.3.2 Windows® Vista

1. From the Start Menu, select “Network” and click “Open” to display the available network connections.



2. Click the “Local Area Connection” button to display the “Local Area Connections Properties” dialog window. From this window select Internet Protocol Version 4 (TCP/IPv4) to display its dialog box.



3. Select the “Use the following IP address” radio button.




Table D-2: Addresses of PC and Drive¹

Device	IP Address
PC	a.b.m.n
Drive	a.b.x.y

¹Where *a*, *b*, *m*, *n*, *x*, and *y* can be integers between 0 and 255.

- Set the IP addresses for both the drive and the PC. In a direct connection, you will need to set the IP addresses of both the PC running the ToolSuite, and for the drive as well. The addresses will not be completely arbitrary. Siemens recommends that the first number of both addresses be between 128 and 191 for class B network settings. You may select class A or C settings, if desired. The connection will function regardless of the class settings. The first two numbers (octets) of the drive's IP address **must** be the same as the first two numbers of the PC's IP address. *For example, if you assign 172.16.20.15 as the drive's IP address, the PC's IP address must be 172.16.x.y, where the combination of x and y must be different than 20.15.*
- Set the drive's IP address using keypad parameter ID 9310.
- Next, set the subnet mask for the PC and the drive. In the "Subnet Mask:" field of the IP Address page, enter a value of 255.255.0.0. This value is the default for a class B network. The subnet mask must be the same for both the PC and the drive. Set the drive's subnet mask using keypad parameter ID 9320.
- Set the gateway for the drive and the PC. Assign a valid arbitrary address number to the PC's gateway in the "Default gateway:" field. This address can be arbitrary (i.e. 0.0.0.0) because a direct connection does not actually use a gateway. This virtual gateway that you are creating for the direct connection does not physically exist. It is only to satisfy the software. After entering gateway address here, go to the keypad on the front of the drive, and enter the same gateway address in parameter ID 9330. Click "OK".
- Click "OK" on the next window's dialog box. Windows may ask you if you would like to restart your computer so that the changes can take effect. Click "Yes" to restart.

Index

A

abbreviations 165
AND 161

B

binary operators 171
Boolean algebra 152, 161
 Boolean Theory 61
Bootable Default Disk Procedure 107, 111, 114, 119,
123, 128

C

cabinets 6
cells damage due to overheating 7
Change Default Editor 64
CMP 152
compilation error 67
Compile Process 66
compiler 152
Compiler Error Messages 83
Compiler Operation 79
Configuration Update Utility 106, 131, 145
 features 107
Configuring Drive Tool 32
control power 7
 warning on disconnecting 7
Copy Setup Files 107, 132

D

Debug Tool 51
Direct Connection 179
Directory Filename Associations 73
disconnect switch 6
Downloading System Program 80
drive configuration 18
Drive configurator 51
Drive Control Features 25
drive name 53
Drive Status Features 25
Drive Tool Pull Down Menu 26
Drive Variable Graphing Features 19

drive-to-machinery coordination 61

E

electrostatic discharge precautions 8
ELV 6
Error Message 94
Ethernet (TCP/IP) Communications 33
exposed connections 6
extra low voltage 6

F

Fault or Alarm Displays 36
Flag Names 78
Flash Disk Files 111
fork truck tines 7
Freeze on fault 48
Freeze on trigger 49

G

glossary 151
Graphing Display 41
ground 6, 8, 166

H

hazardous voltages 6
hazards
 electrical 6
 mechanical 7
Header 93

I

IGBTs 156
input control logic 61
Input Flags 76
Input Source File 68
installation 12, 14
IP address 53, 185

L

- ladder logic 61
- lethal voltages 5
- lifting precautions 7
- list of symbols 165
- lock-out/tag-out
 - procedures 6
- logic functions 61
 - logic 61
- LVD 157

M

- maintenance 6
- maintenance qualified individuals 6
- medium voltage warning about control power 7
- Multiple Drive Ethernet Connection 178

N

- New Drive 53
- NXG Debug Tool 51
- NXG Drive Tool 17

O

- Operating Debug Tool 56
- Operating Drive Tool 36
- OR 158
- output control logic 61
- Output Flags 76
- Output Hex File 80
- overheating 7

P

- PC and Drive Addresses 183, 186
- PED 158
- Post Processing of Data 50
- product type selector 71
- Product Types 72

Q

- qualified individual (for troubleshooting and maintainance) 6

R

- resonance avoidance 160
- Reverse Compiler 87

S

- safety precautions and warnings 5
- SOP 61
 - Development Process 65
 - Source File 73
 - Text File Format 74
 - Utilities Tool 61, 63
 - Utility Terminology 62
- sound pressure 7
- start/stop control logic 61
- Starting the Debug Tool 51
- storage safety precautions 6
- successful compilation 67
- Sum-Of-Products notation 61
- symbol 165
- System Program 61, 77, 78, 111, 114, 123, 171, 174
 - timers 77
- System Requirements 51, 105, 131, 145
- System Type Identification 71

T

- target Directory 64
- target source file 64
- Terminal Emulation Method 82
- Termination 83
- thermally hot components 5
- Time intervals 78
- Tool Suite
 - Host Files 128
 - Installation 15
 - Setup 10
 - Software components 11
- transporting precautions 7
- troubleshooting (qualified individuals only) 6

U

- unary operators 171
- Update flash disk files 111
- Upload/Download utility method 81
- Uploading System Program 87
- Utilities tab 63

V

Variables 42

W

warning on disconnect
control power 7

