


INSTALLATION AND SERVICE MANUAL commercial packaged ventilation system units model MPR (for units with 24 digit model numbers)



Model MPR Commercial Packaged Ventilation System Unit (C-Cabinet size shown)



⚠ WARNING

Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death, and could cause exposure to substances which have been determined by various state agencies to cause cancer, birth defects or other reproductive harm. Read the installation, operating and maintenance instructions thoroughly before installing or servicing this equipment.

⚠ WARNING

This unit contains R-410A high pressure refrigerant. Hazards exist that could result in personal injury or death. Installation, maintenance, and service must only be performed by an HVAC technician qualified in R-410A refrigerant and using proper tools and equipment. Due to much higher pressure of R-410A refrigerant, **DO NOT USE** service equipment or tools designed for refrigerants other than R410A.

⚠ WARNING

FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings exactly could result in serious injury, death or property damage.

Be sure to read and understand the installation, operation and service instructions in this manual.

Improper installation, adjustment, alteration, service or maintenance can cause serious injury, death or property damage.

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

WHAT TO DO IF YOU SMELL GAS:

- **Do not try to light any appliance.**
- **Do not touch any electrical switch, do not use any phone in your building.**
- **Leave the building immediately.**
- **Immediately call your gas supplier from a phone remote from the building. Follow the gas supplier's instructions.**
- **If you cannot reach your gas supplier, call the fire department.**

Installation and service must be performed by a qualified installer, service agency or the gas supplier.

Inspection on Arrival

1. Inspect unit upon arrival. In case of damage, report it immediately to transportation company and your local factory sales representative.
2. Check rating plate on unit to verify that power supply meets available electric power at the point of installation.
3. Inspect unit upon arrival for conformance with description of product ordered (including specifications where applicable).

THIS MANUAL IS THE PROPERTY OF THE OWNER.
PLEASE BE SURE TO LEAVE IT WITH THE OWNER WHEN YOU LEAVE THE JOB.

SPECIAL PRECAUTIONS

SPECIAL PRECAUTIONS

THE INSTALLATION AND MAINTENANCE INSTRUCTIONS IN THIS MANUAL MUST BE FOLLOWED TO PROVIDE SAFE, EFFICIENT AND TROUBLE-FREE OPERATION. IN ADDITION, PARTICULAR CARE MUST BE EXERCISED REGARDING THE SPECIAL PRECAUTIONS LISTED BELOW. FAILURE TO PROPERLY ADDRESS THESE CRITICAL AREAS COULD RESULT IN PROPERTY DAMAGE OR LOSS, PERSONAL INJURY, OR DEATH. THESE INSTRUCTIONS ARE SUBJECT TO ANY MORE RESTRICTIVE LOCAL OR NATIONAL CODES.

HAZARD INTENSITY LEVELS

1. **DANGER:** Indicates an imminently hazardous situation which, if not avoided, WILL result in death or serious injury.
2. **WARNING:** Indicates a potentially hazardous situation which, if not avoided, COULD result in death or serious injury.
3. **CAUTION:** Indicates a potentially hazardous situation which, if not avoided, MAY result in minor or moderate injury.
4. **IMPORTANT:** Indicates a situation which, if not avoided, MAY result in a potential safety concern.

DANGER

Appliances must not be installed where they may be exposed to a potentially explosive or flammable atmosphere.

WARNING

1. Failure to follow proper lifting instructions could result in property damage, serious injury, or death. Lifting should only be done by a qualified rigging company. Use ALL lifting points. Test lift to ensure proper balance and rigging. Never lift in high winds.
2. Disconnect power supply before making wiring connections or working on this equipment. Follow all applicable safety procedures to prevent accidental power up. Failure to do so can result in injury or death from electrical shock or moving parts and may cause equipment damage.
3. For units equipped for dual power supply sources, both sources of power must be disconnected to prevent electrical shock and equipment damage.
4. All appliances must be wired strictly in accordance with the wiring diagram furnished with the appliance. Any wiring different from the wiring diagram could result in a hazard to persons and property.
5. Any original factory wiring that requires replacement must be replaced with wiring material having a temperature rating of at least 105°C.
6. Ensure that the supply voltage to the appliance, as indicated on the serial plate, is not 5% greater than the rated voltage.
7. All field gas piping must be pressure/leak tested prior to operation. Never use an open flame. Use a soap solution or equivalent for testing.
8. Gas pressure to appliance controls must never exceed 14" W.C. (1/2 psi).
9. To reduce the opportunity for condensation, the minimum sea level gas input to the appliance, as indicated on the serial plate, must not be less than 5% below the rated input, or 5% below the minimum rated input of dual rated units.
10. When the dead front disconnect switch(es) (for main unit and/or powered convenience outlet option) is in the "OFF" position, supply power remains energized at the line (supply) side of the dead front disconnect switch(es). The switch body is located inside of another junction box to protect against contact with the live wiring. The junction box must not be disassembled unless the main power supply from the building to the unit is

WARNING

- de-energized.
11. This unit contains R-410A high pressure refrigerant. Hazards exist that could result in personal injury or death. Installation, maintenance, and service must only be performed by an HVAC technician qualified in R-410A refrigerant and using proper tools and equipment. Due to much higher pressure of R-410A refrigerant, DO NOT USE service equipment or tools designed for refrigerants other than R410A.
 12. The power supply wiring for the Energy Recovery Section comes from a single point power connection on the unit. Disconnect power supply at model MPR before making wiring connections to prevent electrical shock and equipment damage.
 13. When servicing or repairing this equipment, use only factory-approved service replacement parts. A complete replacement parts list may be obtained by contacting Modine Manufacturing Company. Refer to the rating plate on the appliance for complete appliance model number, serial number, and company address. Any substitution of parts or controls not approved by the factory will be at the owner's risk.

CAUTION

1. Appliances are designed for outdoor installation only. DO NOT LOCATE APPLIANCES INDOORS.
2. Ensure that the supply voltage to the appliance, as indicated on the serial plate, is not 5% less than the rated voltage.
3. Purging of air from gas lines should be performed as described in ANSI Z223.1 - latest edition "National Fuel Gas Code", or in Canada in CAN/CGA-B149 codes.
4. Units not approved for use in potable water systems.
5. Do not operate the unit with steam. The coil is not designed for steam condensate removal which can damage the unit.
6. Hot water supplied to the hot water heating option must not exceed 180°F temperature or 75 PSIG pressure.
7. When servicing the unit, some components may be hot enough to cause pain or injury. Allow time for cooling of hot components before servicing.
8. Do not overcharge the refrigeration system. This can lead to elevated compressor discharge pressure and possibly flooding the compressor with liquid. This may result in compressor failure not covered under warranty.
9. Do not reuse any mechanical or electrical component which has been wet. Such components must be replaced.

IMPORTANT

1. To prevent premature heat exchanger failure, do not locate ANY gas-fired appliances in areas where corrosive vapors (i.e. chlorinated, halogenated or acid) are present in the atmosphere.
2. A properly designed drain with trap must be installed immediately after the unit evaporator coil condensate drain pan connection. Failure to do so will result in condensate that cannot properly drain from the unit,

TABLE OF CONTENTS / SI (METRIC) CONVERSION FACTORS / UNIT LOCATION

IMPORTANT

eventually causing the drain pan to fill. To prevent damage to the building or unit, a drain pan float switch is included as standard and will disable the unit if the maximum condensate level is reached.

3. To prevent premature heat exchanger failure, the input to the appliance, as indicated on the serial plate, must not exceed the rated input by more than 5%.
4. To prevent premature heat exchanger failure, check to be sure the blower has been set to deliver the proper airflow for the application. Refer to page 17 for Blower Adjustments.
5. Start-up and adjustment procedures must be performed by a qualified service agency.
6. All scroll compressors requires the correct supply power phase rotation. Phase reversal may result in compressor failure not covered under warranty. Refer to the Start-Up Procedure section.
7. All refrigeration checks must be made by a qualified R-410A refrigeration technician.
8. Do not release refrigerant to the atmosphere. When adding or removing refrigerant, all national, state/ province, and local laws must be followed.
9. On units with the electric preheat option, to prevent premature heat exchanger failure, check to be sure the blower has been set to deliver the proper airflow for the application. Refer to page 17 for Blower Adjustments.
10. The exhaust fan is not designed for high temperature or smoke control exhaust applications. Exhaust air temperature must not exceed 104°F. Operating the exhaust fan above 104°F will result in failure of the exhaust fan.

SI (METRIC) CONVERSION FACTORS

To Convert	Multiply By	To Obtain	To Convert	Multiply By	To Obtain
"W.C.	0.24	kPa	CFH	1.699	m ³ /min
psig	6.893	kPa	Btu/ft ³	0.0374	mJ/m ³
°F	(°F-32) x 0.555	°C	pound	0.453	kg
inches	25.4	mm	Btu/hr	0.000293	kW
feet	0.305	meters	gallons	3.785	liters
CFM	0.028	m ³ /min	psig	27.7	"W.C.

Special Design Requests

Modine Manufacturing Company will sometimes build units with special features as requested by the customer. This manual only covers standard features and does not include any changes made for special feature requests by the customer. Units built with special features are noted with an SPO (Special Product Order) Number on the Serial Plate

Storage Prior to Installation

If the unit is stored outside prior to installation, the unit should be covered.

TABLE OF CONTENTS

Inspection on Arrival	1
Special Precautions.....	2
SI (Metric) Conversion Factors	3
Special Design Requests	3
Storage Prior to Installation.....	3
Unit Location	4
Installation	4-15
Combustible Material and Service Clearances	4-5
Roof Curb Installation	4
General Rigging Instructions/Unit Installation	6-7
Duct & Condensate Drain Installation	8
Electrical Connections	9
Gas Connections	10
Vent Terminals and Combustion Air Hoods.....	11
Gas Heating Option Condensate Drains & Traps	14
Hot Water Piping Connections	15
Start-Up Procedure	16-29
General.....	16
Blower Adjustments	17
Airflow Proving Switch and Dirty Filter Switch.....	19
Variable Air Movement Applications	19
Checking Refrigerant Charge	20
Gas Heating Option.....	21
Energy Recovery Option (B-Cabinet units only)	28
Unit Features/Options Location Drawings.....	30-35
Dimensions/Weights	36-44
B-Cabinet Size Unit without Energy Recovery.	36
B-Cabinet Size Unit with Energy Recovery.	38
C-Cabinet Size Unit.....	40
D-Cabinet Size Unit.....	42
Base Model Weights.....	44
Option and Accessory Pressure Drop Tables	45-47
Maintenance	48-50
Service & Troubleshooting	51-55
Serial Plates	56
Model Nomenclature	57-59
Commercial Warranty.....	Back Page

UNIT LOCATION

! DANGER

Appliances must not be installed where they may be exposed to potentially explosive or flammable atmosphere.

! CAUTION

Appliances are designed for outdoor installation only. DO NOT LOCATE APPLIANCES INDOORS.

IMPORTANT

To prevent premature heat exchanger failure, do not locate ANY gas-fired appliances in areas where corrosive vapors (i.e. chlorinated, halogenated or acid) are present in the atmosphere.

Location Recommendations


1. When locating the packaged rooftop unit, Model MPR, consider general space and cooling/heating requirements and availability of gas and electrical supply.
2. Be sure the structural support at the unit location site is adequate to support the weight of the unit and any other required support structure. For proper operation the unit must be installed in a level horizontal position.
3. All mechanical equipment generates some sound and vibration that may require attenuation. Locating the equipment away from the critical area is desirable within ducting limitations. Frequently, units can be located above utility areas, corridors, restrooms, and other non-critical areas. Generally, a unit should be located within 15 feet of a primary support beam. Smaller deflections mean lesser vibration and noise transmission. For critical applications, please consult with an acoustical attenuation expert.
4. Do not install units in locations where the flue products (if equipped with a gas fired heating option) can be drawn into the adjacent building openings such as windows, fresh air intakes, etc.
5. Be sure that the minimum clearances to combustible materials and recommended service clearances are maintained. For units with the gas heating option, be sure clearances are maintained to the combustion air inlet louvers and power exhauster discharge cover. Units are designed for installation on non-combustible surfaces with the minimum clearances shown in Figure 5.1.
6. On units that have fresh air openings, a method must be provided to prevent water and debris from entering the unit such as a rainhood, which is available as an accessory from Modine. Where possible, install the unit so that the inlet is not facing into the prevailing wind to prevent water entrainment.
7. The exhaust fan is not designed for high temperature or smoke control exhaust applications. Exhaust air temperature must not exceed 104°F. Operating the exhaust fan above 104°F will result in failure of the exhaust fan.

Roof Curb Installation

An optional roof curb is available to simplify site preparation and raise the unit above roof water and snow level for drainage. It can be installed in advance of the unit. The curb is shipped knocked down with separate instructions (Literature #MCP15-590) for its assembly, flashing, and sealing with the roof. The following are some general guidelines for roof curb installed units:


1. The roof structure must be adequately designed to support the live weight load of the unit and any other required support structure. The roof curb should be supported at points no greater than five feet apart. Additional truss reinforcement should be provided, if necessary.
2. Roof curbs supplied by Modine are fabricated from 10 gauge galvanized steel and supplied knocked down for assembly on the job site. The curb consists of two side pieces, two end pieces, gasketing, four joiner angles, four 2x4 inch wood nailing strips, nuts, bolts, and washers.
3. Outside dimensions must be held when installing curb. Top surface must be level and straight to ensure weather-tightness. If roof is pitched it will be necessary to construct a sub-base on which to install the curb. All corners must be square.
4. All dimensions are +1/8 inch.
5. When a roof curb is used in conjunction with factory supplied discharge and/or return air connectors, the ductwork can be fastened to the connectors prior to the unit installation. The connectors will accept 90° flanged ductwork (see Figure 7.1).
6. Final electric and gas connections must be made after unit is installed to allow for tolerance in setting of unit on curb. For electrical power supply allow approximately eight feet of wire, plus provisions for weathertight flexible conduit for connection to unit, as required by local codes.
7. Maintain a 12-inch minimum height from top of roof deck to top of curb.
8. Caulk butt joints after curb is assembled and installed on roof structural members and roof flashing is added.
9. For improved sound attenuation, line the roof deck within the curb area with 2" acoustic fiberglass.

Figure 4.1 - Typical Curb Details



CLEARANCES / ROOF CURB INSTALLATION

Figure 5.1 - Combustible Material & Service Clearances



GENERAL RIGGING INSTRUCTIONS / UNIT INSTALLATION

General Rigging Instructions

⚠ WARNING

Failure to follow proper lifting instructions could result in property damage, serious injury, or death. Lifting should only be done by a qualified rigging company. Use ALL lifting points. Test lift to ensure proper balance and rigging. Never lift in high winds.

Lifting Lug Installation

Before attaching lifting equipment, verify location of lifting lugs or eyes. B- and C-Cabinet sized units have the lifting lugs or eyes factory installed as follows:

- B-Cabinet sized units without Energy Recovery include (4) eye bolts at each corner on the top of the unit.
- B-Cabinet sized units with Energy Recovery include (6) lifting lugs on the base, one at each corner and one on each length-wise side of the unit between the corners.
- C-Cabinet sized units include (4) eye bolts at each corner on the top of the unit. For units that include the shipped separate Energy Recovery Module (model ERM) option, refer to the latest revision of the Installation and Service Manual, #MCP15-520, that shipped with the ERM for separate rigging instructions.
- D-Cabinet sized units must have the lifting lugs installed in the unit base assembly prior to rigging as follows:
 1. Locate the lifting lug kit box, kit # 66802, located in the supply fan compartment.
 2. Install the kit per the "Installation Instructions, Lifting Lugs D-Cabinet", #MCP15-505, included with the kit.
 3. After installing the kit, verify that all (4) lugs are installed following the instructions in Step 2. Verify that each lug is secured using (4) Grade 5 bolts provided with the kit. Each bolt must be torqued to 75 ft-lb.

Unit Rigging and Lifting


Rigging and lifting of the units should only be done by a qualified rigging company. With the lifting lugs or eyes identified and installed, the units can be lifted by crane or helicopter.

1. Follow site preparation instructions for the roof curb or equipment stand before installation.
2. Check the Serial Plate(s) of unit with plans to be sure unit is properly located. Although units may look outwardly similar, their function, capacities, options, and accessories will often vary.
3. Check unit dimensions of both the unit base and the curb or stand on which the unit will be installed.
4. If the unit will be installed on a roof curb:
 - a. Thoroughly clean and dry the top of the curb surface.
 - b. Lay a bead of weather resistant caulking on top perimeter of roof curb as illustrated in Figure 7.1. Note: If roof curb is supplied by Modine, full perimeter gasket material is supplied and caulking is not necessary.
5. When lifting the equipment, connect sturdy steel cables, chains, or straps with eye loops as illustrated in Figure 6.1. For stability in lifting and lowering and to prevent damage to the unit, include a spreader bar as illustrated in Figure

6.1. Avoid twisting or uneven lifting of the unit. The cable length from the lifting point on the unit to the spreader bar should always be longer than the distance between the outer lifting points.

6. Test lift the unit to check for proper rigging balance before hoisting to the desired installation location.
7. Once lifted to the installation location, orient the hoisted unit to match the ductwork locations and set evenly on the curb or stand.
8. Following the instructions in this manual, make final unit connections to the electric power supply and remote control circuits. Connect the gas lines to the unit heating compartment. Seal all utility line clearance holes on the unit after connections are completed so they are watertight.

Figure 6.1 - Typical Rigging for Model MPR




DUCT INSTALLATION AND UTILITY CONNECTIONS

Duct Installation

1. The unit is designed to accept 90° flanged ductwork on both the supply and return air openings. Refer to the roof curb or the unit base dimensional drawings to determine the location of the openings.
2. Acoustic duct liners are recommended on all internal supply and return air ducts.
3. When ductwork is installed prior to unit arrival, flexible connections should be included to make connections easier and to simplify possible future service.
4. When a roof curb is used in conjunction with factory supplied discharge and/or return air connectors, the ductwork can be fastened to the connectors prior to the unit installation. The connectors will accept 90° flanged ductwork (see Figure 7.1).

Figure 7.1 - Discharge and/or Return Air Connectors



5. To assure proper air flow from the unit, follow these duct design recommendations:
 - a. Be sure ducts are properly sized and installed.
 - b. As a general rule, all discharge ducts should have a straight run of at least three (3) hydraulic duct diameters before making turns in the ductwork.

Hydraulic Duct Diameter for Rectangular Ducts = $4A/P$

Hydraulic Duct Diameter for Circular Ducts = D

where:

A = Cross Sectional Area of Rectangular Duct

P = Perimeter of Rectangular Duct

D = Diameter of Round Cut

- c. Wherever turns in the duct work are made, include turning vanes.
- d. Supply air ducts in a "T" configuration should be avoided to prevent air temperature stratification. If this configuration must be used, provide appropriate mixing devices and/or the necessary straight duct length before the "T" to provide uniformly mixed air temperature delivery to both supply air duct trunks.

Utility Connections

Utility and control connections can be made to the unit from the bottom or through the fixed side panels. Holes can be field drilled in fixed side panels to accommodate utility connections as shown on the unit dimensional drawings and the utility entrance location area label located on the unit. All gas and electrical connections to the unit must be weatherized so they are watertight.

CONDENSATE DRAIN INSTALLATION

Evap Condensate Drain Trap Installation


IMPORTANT

A properly designed drain with trap must be installed immediately after the unit evaporator coil condensate drain pan connection. Failure to do so will result in condensate that cannot properly drain from the unit, eventually causing the drain pan to fill. To prevent damage to the building or unit, a drain pan float switch is included as standard and will disable the unit if the maximum condensate level is reached.

All units require a drain system with a condensate trap to be connected to the condensate drain pan connection which is accessible from the exterior of the unit casing. Failure to install a condensate drain trap may result in condensate overflowing from the drain pan, causing damage to the unit and building. See Figure 30.1 or 31.1 for location. The drain system is to be installed as follows:


1. The condensate drain pan includes a 1-1/4" female NPT stainless steel connection accessible from the exterior of the unit casing. Do not reduce the drain diameter. A drain pan connection kit is shipped loose for field installation to allow connection exterior to the casing. Refer to Figure 8.1 for assembly details.

Figure 8.1 - Condensate Drain Pan Connection Kit



2. The drain line should include provisions for disconnecting the line at or near the unit for maintenance/servicing of the unit. The drain line must not interfere with access panels, which are removable for maintenance/service.
3. The drain line must include a trap immediately after the unit, as shown in Figure 8.2. Failure to do so will result in condensate that cannot properly drain from the unit, eventually causing the drain pan to fill and overflow. If the drain pan overflows, significant damage can occur to the unit and/or building on which the unit is installed. A drain pan float switch is included as standard and will disable the unit if the maximum condensate level is reached.
4. The design of the trap is critical to ensure proper drainage. If the trap is not constructed properly with the dimensions as outlined in the following instructions, air could be drawn through the drain pipe and into the system or could back up into the drain pan.
 - The drain is located on the suction side of the main supply air fan, resulting in a negative pressure relative to outside the unit cabinet. The trap height must be at least 6" to account for maximum negative pressure, including allowance for dirty filters. Note that the trap height is the difference in height from the drain connection of the unit to the leaving side of the trap. Refer to Figure 8.2.

Figure 8.2 - Condensate Drain Trap Installation



- The trap depth must be $\frac{1}{2}$ x the trap height. For example, if the trap height is the minimum 6", the trap depth must be 3" (see Figure 8.2).
 - For maintenance, it is recommended to have a capped cleanout at the top of the trap as shown in Figure 8.2.
5. After the exit from the trap, the drain must be pitched down from the unit connection at least 1" for every 10 feet of horizontal run to promote proper drainage. If the local installation code allows, the drain can be run to a waste water system.
 6. If the trap may experience below freezing temperatures during non-cooling periods, heating wraps must be used to avoid water from freezing in and damaging the trap and drain system.
 7. The trap must be primed before the unit is put into operation and properly maintained on a regular schedule. Refer to the Start-Up Procedure section and the Maintenance section for additional guidance.

ELECTRICAL CONNECTIONS

Electrical Connections

⚠ WARNING

1. Disconnect power supply before making wiring connections or working on this equipment. Follow all applicable safety procedures to prevent accidental power up. Failure to do so can result in injury or death from electrical shock or moving parts and may cause equipment damage.
2. For units equipped for dual power supply sources, both sources of power must be disconnected to prevent electrical shock and equipment damage.
3. All appliances must be wired strictly in accordance with the wiring diagram furnished with the appliance. Any wiring different from the wiring diagram could result in a hazard to persons and property.
4. Any original factory wiring that requires replacement must be replaced with wiring material having a temperature rating of at least 105°C.
5. Ensure that the supply voltage to the appliance, as indicated on the serial plate, is not 5% greater than rated voltage.

⚠ CAUTION

Ensure that the supply voltage to the appliance, as indicated on the serial plate, is not 5% less than the rated voltage.


1. Installation of wiring must conform with local building codes, or in the absence of local codes, with the National Electric Code ANSI/NFPA 70 - Latest Edition. Unit must be electrically grounded in conformance to this code. In Canada, wiring must comply with CSA C22.1, Part 1, Electrical Code.
2. Two copies of the job specific wiring diagram are provided with each unit, one permanently affixed to the inside of the door of the controls compartment and the other as a loose copy with the literature packet that ships with the unit. Refer to this diagram for all wiring connections.
3. Control wiring consists of both 24V analog control wiring and low current digital control signal wiring. To avoid signal interference, the two types should be run in separate conduits. If run in the same conduit, the digital signal wiring should be shielded at one end of the wiring run. Wiring should be twisted, stranded, and shielded communication wire.
4. The wire gauge must be sized according to the National Electric Code or CSA code based on amp draw and length of run. Refer to Table 9.1 for maximum wire lengths and the number of wires that can be wired to each low voltage terminal block based on the wire gauge being used.

Table 9.1 - 24V and Digital Control Wire Lengths

Minimum Recommended Wire Gauge	Maximum Distance from Control Device to Unit	
	24V Control Wiring	Digital Control Wiring
22	n/a	120
20	n/a	200
18	75	300
16	125	500
14	175	n/a

5. For field wiring to the factory terminal strip, the terminal strip connections are designed to clamp down on the wires. To properly connect the wires to the terminal strip:
 - Push a small flat-head screwdriver into the square hole on the terminal. Press firmly until the screwdriver hits the back stop and opens the terminal (see Figure 9.1).
 - Remove approximately 3/8" of insulation from the end of the wire and push the stripped wire into the oval hole in the terminal.
 - Remove the screwdriver. Pull on the wire to make sure that it is securely clamped in the terminal.
 - Make sure that the terminal clamp is in contact with bare wire (insulation removed).

Figure 9.1 - Terminal Strip Wiring



6. Depending on the configuration of the unit controls, there may be sensors that are field installed. Review the unit ordered to verify that the sensors supplied match the configuration of the unit. The following are sensors that may be included for field installation:
 - **Supply Air Temperature Sensor**
This sensor is required on all units and should be mounted in the supply air ductwork downstream of the unit. The sensor should be located at least 5 feet, but not more than 20 feet downstream from the unit discharge.
 - **Space Temperature/Humidity Sensor**
This sensor is required on all units that have space temperature/humidity reset control. The sensor is to be wall-mounted in the space at a height of approximately 5 feet from the floor.
 - **Building Pressure Sensor**
This sensor is required on all units that have space pressure control, either through modulating dampers or variable frequency drive control on the supply air blower. The sensor is to be mounted inside a control panel in the space and includes two pressure taps. One pressure tap is for outside atmospheric pressure reference, the other is for sampling the space pressure.
 - **Duct Pressure Sensor**
This sensor is required on all units that have duct pressure control through variable frequency drive control on the supply air blower. The sensor is to be mounted with the sensing probe inserted into the supply duct. The atmospheric pressure sampling tap is left open.

ELECTRICAL CONNECTIONS / GAS CONNECTIONS

- **Space CO₂ Sensor**

This sensor is required on all units that have demand based ventilation control. The sensor is to be mounted in the space at a height of approximately 5 feet from the floor.

- **Duct Mounted Smoke Detector**

When ordered as a field installed accessory, the detector should be mounted in the supply air or return air ductwork.

For further instructions on the above sensor(s), refer to the installation instructions that shipped with the sensor(s).

7. If the unit is a C-Cabinet sized unit with a Modine supplied Energy Recovery Module, Model ERM, the wiring connection between the MPR unit and the ERM unit must be made by extending the loose end of the wire drop located in the MPR unit outside air damper section, through the transition duct between units, and connected to the ERM control panel. Refer to the Installation & Service Manual that shipped with the ERM (Literature #MCP15-520) for additional instructions. If the unit is a B-Cabinet sized unit with integral Energy Recovery, the unit is already factory wired to the Energy Recovery section.
8. The power supply to the unit must be protected with a fused or circuit breaker disconnect switch. Refer to the Figures on pages 32 through 35 for the location of the factory installed dead front disconnect option, if provided. Field installed disconnect switches should be mounted where required by the National Electric Code. Refer to the Model Serial plate for MCA and MOP values for the unit.
9. The power supply must be within +/-5% percent of the voltage rating and each phase must be balanced within 2 percent of each other. If not, advise the utility company.
10. External electrical service connections that must be installed include:
 - a. Supply power (120, 208, 240, 480, or 600 volts).
 - b. Thermostats, building pressure sensors, or any other accessory control devices that may be supplied (24 volts).
11. All outdoor electrical connections must be weatherized to prevent moisture from entering the electrical compartment.
12. Electrical connections are made in the controls cabinet and can be run through the bottom or side of the unit. Refer to the unit and base dimensional drawings for locations of wiring entrance. Refer to the wiring diagram for the terminal location of all low voltage wiring.

REVIEW BEFORE PROCEEDING

**THIS SECTION APPLIES TO UNITS WITH
OPTIONAL GAS HEAT
(MODEL DIGIT 17=2 OR 3).**

**IF THE UNIT DOES NOT HAVE GAS HEAT,
SKIP TO PAGE 15.**

Gas Connections

WARNING

1. All field gas piping must be pressure/leak tested prior to operation. Never use an open flame. Use a soap solution or equivalent for testing.
2. Gas pressure to appliance controls must never exceed 14" W.C. (1/2 psi).
3. To reduce the opportunity for condensation, the minimum sea level gas input to the appliance, as indicated on the serial plate, must not be less than 5% below the rated input, or 5% below the minimum rated input of dual rated units.

CAUTION

Purging of air from gas supply line should be performed as described in ANSI Z223.1 - latest edition "National Fuel Gas Code", or in Canada in CAN/CGA-B149 codes.

IMPORTANT

To prevent premature heat exchanger failure, the input to the appliance, as indicated on the serial plate, must not exceed the rated input by more than 5%.

1. Installation of piping must conform with local building codes, or in the absence of local codes, with the National Fuel Gas Code, ANSI Z223.1 (NFPA 54) - Latest Edition. In Canada, installation must be in accordance with CAN/CGA-B149.1 for natural gas units and CAN/CGA-B149.2 for propane units.
2. Piping to units should conform with local and national requirements for type and volume of gas handled, and pressure drop allowed in the line. Refer to Table 11.1 to determine the cubic feet per hour (cfh) for the size of unit to be installed. Using this cfh value and the length of pipe necessary, determine the pipe diameter from Table 11.2. Where several units are served by the same main, the total capacity, cfh and length of main must be considered. While the gas connection(s) on the unit may be smaller than 1", do not use pipe sizes smaller than 1" leading up to the unit. At the unit, reduce the pipe size down to the appropriate size (refer to Table 11.1 for connection sizes). Table 11.2 allows for a 0.3" W.C. pressure drop in the supply pressure from the building main to the unit. The inlet pressure to the unit must be 6-7" W.C. for natural gas and should not drop below 6.0" W.C. when the unit is operating. When sizing the inlet gas pipe diameter, make sure that the unit supply pressure can be met after the 0.3" W.C. has been subtracted. If the 0.3" W.C. pressure drop is too high, refer to the Gas Engineer's Handbook for other gas pipe capacities.

GAS CONNECTIONS

Table 11.1 - Natural Gas Heating Gas Consumption

Digit 6	Digit 18	Furnace Size (Btu/hr)	Gas Consumption (CFH) ①	Gas Connection
B	F	150,000	143	1/2"
	G	200,000	190	3/4"
	H	250,000	238	3/4"
	J	300,000	286	3/4"
	K	400,000	381	3/4"
	R	175,000	167	1/2"
	S	225,000	214	3/4"
C ②	T	310,000	295	3/4"
	J	300,000	286	3/4"
	K	400,000	381	1"
	L	500,000	476	1"
	L	600,000	571	1"
D ③	U	350,000	333	1"
	V	450,000	429	1"
	K	400,000	381	1.5" x 2
	L	500,000	476	1.5" x 2
	M	600,000	571	1.5" x 2
	Q	800,000	762	1.5" x 2
	1	900,000	857	1.5" x 2
	2	1,000,000	952	1.5" x 2
3	1,200,000	1143	1.5" x 2	
4	1,400,000	1333	1.5" x 2	
5	1,600,000	1524	1.5" x 2	

- ① Natural gas consumption based on a heating value of 1050 Btu/cu. ft.
- ② C-Cabinet units consist of two furnaces that together total the value shown in Table 11.1.
- ③ D-Cabinet units consist of two furnaces that together total the value shown in Table 11.1 for sizes up to 800,000 Btu/hr. For sizes over 800,000 Btu/hr, the unit consists of four furnaces that together total the value shown in Table 11.1.

Table 11.2 - Gas Pipe Capacities (Cu. Ft. per Hour) ④

Pipe Length (feet)	Gas Pipe Diameter			
	1"	1-1/4"	1-1/2"	2"
10	520	1050	1600	3050
20	350	730	1100	2100
30	285	590	890	1650
40	245	500	760	1450
50	215	440	670	1270
60	195	400	610	1150
70	180	370	560	1050
80	170	350	530	990
90	160	320	490	930
100	150	305	460	870
125	130	275	410	780
150	120	250	380	710


- ④ Gas pipe capacities based on gas pressure up to 14" W.C. through Schedule 40 pipe with a pressure drop of 0.3" W.C. for Natural gas with a specific gravity of 0.60.

3. The gas piping to the unit can enter the unit from the side of the unit (refer to the unit dimensions) or from below (refer to the base dimensions). A drill locator sticker and dimple is located on the side of the unit to indicate the safe area for drilling the hole for side gas pipe entry on B- and C-Cabinet sized units. D-Cabinet sized units include a holes with grommets for side pipe entry. Install a ground joint union with brass seat and a manual shut-off valve external of the unit casing, and adjacent to the unit for emergency shut-off and easy servicing of controls, including a 1/8" NPT plugged tapping accessible for test gauge connection (see Figure 11.1). Verify the manual shut-off valve is gas tight on an annual basis.

NOTE: For bottom piped units, some local codes may require a manual shutoff valve external to the unit casing. In this case, the gas piping must exit the unit through the side, followed by the manual shut-off valve, piped back into the unit side, and lead to an additional union and manual shut-off valve.

- 4. Provide a sediment trap before each unit in the line where low spots cannot be avoided (see Figure 11.1).
- 5. When Pressure/Leak testing pressures above 14" W.C. (1/2 psi), close the field installed shut-off valve, disconnect the appliance and its combination gas control from the gas supply line, and plug the supply line before testing. When testing pressures 14" W.C. (1/2 psi) or below, close the manual shut-off valve on the appliance before testing.

Figure 11.1 - Recommended Sediment Trap/Manual Shut-off Valve Installation



- ① Valve is in the "OFF" position when handle is perpendicular to pipe.

GAS HEATING OPTION VENT TERMINALS AND COMBUSTION AIR HOODS

Vent Terminals and Combustion Air Hoods

1. Do not operate the units without the factory supplied (shipped loose) power exhauster vent system/vent termination(s) or combustion air hoods if applicable. Refer to Table 12.1 to determine how many terminals and hoods are required based on the model MPR nomenclature.
2. Do not modify or obstruct the combustion air inlet louvers or the power exhauster discharge cover terminations.
3. Do not add any vents other than those supplied by the manufacturer. For units that require vent extension kits, refer to Literature #MCP15-574, "Installation Instructions, Extended Vent Kit, Model MPR Gas Heat".

Table 12.1 - Power Exhauster Vent Terminal and Combustion Air Hood Quantity

Digit 6	Digit 18	Furnace Size (Btu/hr)	Furnace Type	Field Installed Qty	
				Vent Terminals	Combustion Air Hoods
B	F	150,000	Non-Condensing	1	n/a
	G	200,000			
	H	250,000			
	J	300,000			
	K	400,000	Condensing	1	n/a
	R	175,000			
	S	225,000			
C	T	310,000	Non-Condensing	2	n/a
	J	300,000			
	K	400,000			
	L	500,000	Condensing	2	n/a
	L	600,000			
	U	350,000			
D	V	450,000	Non-Condensing	2	2
	K	400,000			
	L	500,000			
	M	600,000	Non-Condensing	4	2
	Q	800,000			
	1	900,000			
	2	1,000,000			
	3	1,200,000			
	4	1,400,000			
5	1,600,000				


For specific instructions on each configuration in Table 12.1, refer to the appropriate section from the following sections titled:

- Non-Condensing Furnaces (B, C, or D-Cabinet), or
- Condensing Furnace (B-Cabinet), or
- Condensing Furnace (C-Cabinet)

Non-Condensing Furnaces (B, C, or D-Cabinet)

For Non-Condensing furnace types, as determined from Table 12.1, refer to Figure 12.1 for vent termination installation details, otherwise skip to the section titled Condensing Furnaces. For units that require vent extension kits, refer to Literature #MCP15-574, "Installation Instructions, Extended Vent Kit, Model MPR Gas Heat".


Figure 12.1 - Power Exhauster Vent Terminal for Non-Condensing Gas Furnace Option



② C-Cabinet sized unit shown with two vent terminals. B-Cabinet sized units have only one and D-Cabinet with have either one on each side of the cabinet (two total) or two on each side of the cabinet (four total).

For D-Cabinet units, the furnace doors must have the combustion air hoods field installed as shown in Figure 12.2, using the screws included with the kit. Once complete, proceed to the "Start-Up" section.

Figure 12.2 - Combustion Air Hood Installation (D-Cabinet only)



Also shown are the vent terminals for reference.

GAS HEATING OPTION VENT TERMINALS AND COMBUSTION AIR HOODS

Condensing Furnaces (B-Cabinet)

For B-Cabinet units with Condensing furnace types, as determined from Table 12.1 on page 12, refer to Figures 13.1 and 13.2 for vent termination installation details. The installation steps are as follows:

- Step 1:** Insert short vent pipe length into the vent pipe reducer. Insert that assembly into the rubber coupling on the power exhauster outlet. Tighten the clamp on the flexible coupling to secure the vent pipe.
- Step 2:** Insert the outer vent pipe with termination elbow through the enclosure wall grommet and into the vent pipe section installed in Step 1.

Once complete, proceed to the “Condensate Drain and Trap Installation” section.

Condensing Furnaces (C-Cabinet)

Figure 13.1 - Power Exhauster Vent Terminal for Condensing Gas Furnace Option





Figure 13.2 - Orientation of Installed Vent Terminal for Condensing Gas Furnace Option (B-Cabinet)



For C-Cabinet units with Condensing furnace types, as determined from Table 12.1 on page 12, refer to Figures 13.3 and 13.4 for vent termination installation details. The installation steps are as follows:

- Step 1:** Insert small diameter outside vent pipe termination through enclosure wall grommet and into the flexible rubber coupling on the right side power exhaust outlet. Tighten the clamp on the flexible coupling to secure the vent pipe.
- Step 2:** Insert large diameter inner vent pipe assembly into the flexible rubber coupling on the left side power exhaust outlet. Tighten the clamp on the flexible coupling to secure the vent pipe.
- Step 3:** Insert large diameter outside vent pipe termination through enclosure wall grommet and into the interlocking joint of the inner vent pipe assembly from Step 2.
- Step 4:** Verify that the bird screens are inserted in the outlet elbow.

Once complete, proceed to the “Condensate Drain and Trap Installation” section.

Figure 13.3 - Power Exhauster Vent Terminal for Condensing Gas Furnace Option





Figure 13.4 - Orientation of Installed Vent Terminal for Condensing Gas Furnace Option (C-Cabinet)




GAS HEATING OPTION CONDENSATE DRAIN AND TRAP INSTALLATION

Condensate Drain and Trap Installation (Condensing Furnace Type Only)

For Condensing furnace types, as determined from Table 12.1 on page 12, during heating operation, condensate is produced in the furnace sections. The installation requires condensate drain systems from each furnace section, as shown in Figures 14.1 and 14.2 and described below. Condensate trap kits are provided with the unit.


1. For proper heating system performance, the condensate drain system must include a trap for each furnace. B-Cabinet units have one furnace while C-Cabinet units have two furnaces.
2. All joints must be watertight to prevent leakage of condensate. The drains must be extended down through the base of the unit and into the heated space below.
3. Each heat exchanger drain assembly includes a threaded elbow that is oriented down. Once the male threaded PVC adapters, included with the kit, are glued to the PVC drain pipe (by others) that extends into the space, they are to be routed up through the holes in the unit base pan and screwed into the elbow connections. The threads must be sealed to prevent leaks.
4. Unions are recommended to permit maintenance of the drains and to facilitate service of the heater. A union is shown on both sides of each trap.
5. A vacuum breaker is required after each trap. The vacuum breaker should be constructed so that dirt and debris do not enter and clog the drain system.
6. Local code permitting, the condensate drain systems may be joined after the traps and connected to a sanitary drain within the building. Because the condensate produced is acidic, some municipalities may require that the condensate be neutralized before being discharged into the sanitary sewer. A condensate neutralizer tube kit is available from Modine to reduce the pH of the condensate. A single tube can be used for drains that are joined after the traps providing the tube is installed after the junction. Refer to the instructions that come with the kit.
7. For proper operation, the traps must be primed with water. The traps must be installed with the higher side connected to the heater and the lower side connected to the drain.
8. If there is an opportunity that the temperature in the space will fall below freezing during non-operating periods, the condensate drain systems and secondary heat exchanger must be completely drained to prevent freeze damage. Alternately, heat tape can be applied to the drain pipe system in accordance with the heat tape manufacturers instructions.

Figure 14.1 - Furnace Condensate Drain/Trap System ①



① C-Cabinet sized unit shown with two condensate drain systems. B-Cabinet sized units require only one drain system.

Figure 14.2 - Drain System Trap/Vacuum Breaker



HOT WATER PIPING CONNECTIONS

REVIEW BEFORE PROCEEDING

THIS SECTION APPLIES TO UNITS WITH OPTIONAL HOT WATER HEAT (MODEL DIGIT 17=4).


IF THE UNIT DOES NOT HAVE HOT WATER HEAT, SKIP TO PAGE 16.

CAUTION

- Units not approved for use in potable water systems.
- Do not operate the unit with steam. The coil is not designed for steam condensate removal which can damage the unit.
- Hot water supplied to the hot water heating option must not exceed 180°F temperature or 75 PSIG pressure.

- Models with a factory installed hot water heating coil (for use with water or propylene glycol fluids) are supplied with 1-1/2" sweat connections (1.625").

Figure 15.1 - Hot Water Coil Connections



- The entering water temperature (EWT) supplied to the heating coil must not exceed 180°F.
- The fluid flow rate must not exceed 50 gallons/minute (GPM) and fluid pressure must not exceed 75 psi.
- It is recommended to use an inhibited glycol solution that is designed for HVAC applications for corrosion protection and freeze protection for the lowest possible outside air temperatures for the installed location. Failure to protect against freezing can result in damage to the coil and property.
- Provide adequate pipe hangers, supports, or anchors to secure the piping system independently of the coil to prevent excess vibration and stress that can damage the piping and joints.
- All field brazing and welding should be performed using high quality materials and an inert gas purge (such as nitrogen) to reduce oxidation of the internal surface of the coil.
- System piping should be flexible enough to allow for thermal expansion and contraction of the coil and piping components.
- Refer to Figures 15.2 and 15.3 for typical piping system design and the following recommended items:
 - Install shut-off valves in lines to and from the unit to allow for maintenance or replacement of the coil without shutting down and draining the entire system.
 - Install unions for ease of piping component/coil removal.
 - Include a circuit setter in the return line to regulate flow.

- On 3-way valve control configurations, include a balancing valve between the supply line and control valve to balance the system.
 - Include a hose bib drain valve on the bottom of the supply manifold to allow for periodic flushing of the system to remove sediments from the coil.
 - Include a pipe line strainer on the supply line to prevent sediment from reaching the coil.
 - Include an air vent at the top of the return manifold to bleed off accumulated air in the system. Air in the system will generate noise and may cause water hammer that can damage the joints of the piping and coil.
 - Include either a 2-way or 3-way modulating control valve designed for a 0-10VDC control signal. The valves will be automatically modulated by the unit's Carel controller to maintain the supply air temperature setpoint. Note that the control valve must be a normally open, spring return type valve. This is to allow hot water to flow through the coil for freeze protection when the unit is shut down. Refer to the Freeze Stat Option section for additional detail.
 - Hot water pipes should be insulated to reduce heat loss and to prevent overheating of the end compartment.
- Leak test the coil and connections as outlined in the Start-Up section.

Figure 15.2 - Typical 2-Way Piping Installation (piping and components by others)





Figure 15.3 - Typical 3-Way Piping Installation (piping and components by others)



Optional Factory Installed Freeze Stat

When equipped with the optional Coil Freeze Stat, an auto-resetting capillary type freeze stat (see Figure 50.1) is factory installed immediately below and across the face of the hot water coil. The stat is set to trip at 40°F (adjustable) and will automatically reset when the coil temperature rises 5°F above the setpoint. If the stat has tripped, the unit controls would respond by closing the outdoor air damper, opening the return air damper (if applicable), de-energize the supply air fan, open the hot water coil valve 100%, and log the alarm on the controller. The freeze stat can be removed from the unit for servicing as discussed in the Maintenance section.

START-UP PROCEDURE

General

WARNING

1. When the dead front disconnect switch(es) (for main unit and/or powered convenience outlet option) is in the "OFF" position, supply power remains energized at the line (supply) side of the dead front disconnect switch(es). The switch body is located inside of another junction box to protect against contact with the live wiring. The junction box must not be disassembled unless the main power supply from the building to the unit is de-energized.
2. For units equipped for dual power supply sources, both sources of power must be disconnected to prevent electrical shock and equipment damage.

CAUTION

When servicing the unit, some components may be hot enough to cause pain or injury. Allow time for cooling of hot components before servicing.

IMPORTANT

1. To prevent premature heat exchanger failure, check to be sure the blower has been set to deliver the proper airflow for the application. Refer to page 17 for Blower Adjustments.
 2. Start-up and adjustment procedures must be performed by a qualified service agency.
 3. All scroll compressors requires the correct supply power phase rotation. Phase reversal may result in compressor failure not covered under warranty. Refer to the Start-Up Procedure section.
 4. The exhaust fan is not designed for high temperature or smoke control exhaust applications. Exhaust air temperature must not exceed 104°F. Operating the exhaust fan above 104°F will result in failure of the exhaust fan.
1. Turn off power to the unit at the disconnect switch. If equipped with gas heating option, turn all hand gas valves to the "OFF" position.
Note: The dead front disconnect switch, if included, is factory installed in the controls/compressor compartment section (refer to the figures on pages 32 through 35). The disconnect switch is designed so that it must be turned "OFF" before entry to the compartment can be obtained. When in the "OFF" position, power is disconnected to all unit wiring electrically following the switch (see WARNING).
 2. For units equipped for dual power supply sources, both sources of power must be disconnected to prevent electrical shock and equipment damage.
 3. Open the power compartment, controls compartment, and blower access doors.
 4. Check that the supply voltage matches the unit supply voltage listed on the Unit Serial Plate. For units equipped for dual power supply sources, the voltage on both the main feed and the auxiliary feed must match the unit supply voltage listed on the Unit Serial Plate.
 5. Check that fuses or circuit breakers are in place and sized correctly.
 6. Verify that all wiring is secure and properly protected. Trace circuits to ensure that the unit has been wired according to the wiring diagram.
 7. Check that all electrical and gas connections are weatherized.
 8. For C-Cabinet sized units, if the unit is installed with a Modine supplied Energy Recovery Module, Model ERM, verify that the wiring connection between the MPR unit and the ERM unit has been properly installed. If the unit is a B-Cabinet sized unit with integral Energy Recovery, the unit is already factory wired to the Energy Recovery section.
 9. For units with gas heating, check to ensure that the combustion air inlet louvers and the power exhauster discharge cover (Non-Condensing as determined from Table 12.1 on page 12) or the vent elbow terminations (Condensing as determined from Table 12.1 on page 12) are free from obstructions.
 10. For units with condensing gas heating, check that the condensate drain system is properly installed and the trap has has been primed with water.
 11. For units with Hot Water Heat (Digit 17=4), check the following:
 - Open air vents so that air is eliminated from within the coil circuitry and headers. Verify that vents and drains are not obstructed and do discharge a stream of water.
 - Open all required valves to fill the coil. Once the coil is full, close all air vents.
 - Perform an initial hydrostatic leak test of all brazed, threaded or flanged joints, valves and interconnecting piping, and the hot water coil. Recheck the coil level and correct if necessary.
 - When the setup is found to be leak free, flush the coil through the drain valve to eliminate grease, oil, flux and sealing compounds present from the installation.
 - Recheck the coil and all connections for water leaks.
 - Check water flow rates and pressure drops and compare to design.
 - Check that the hot water supplied to the coil does not exceed 180°F temperature or 75 PSIG pressure. Verify that the appropriate glycol mixture is used for freeze protection.
 12. Check to see that there are no obstructions to the intake and discharge of the unit.
 13. Verify that the belts are aligned in the sheave grooves properly and are not angled from sheave to sheave.
 14. On belt driven blowers, blower bearings are permanently lubricated unless they are pillow block bearings or if they have grease fittings. For motors or blower bearings that are not permanently lubricated, lubricate according to the manufacturer's instructions. Refer to the Maintenance section on page 48.
 15. Check to make sure that all filters are in place and that they are installed properly according to direction of air flow. Pleat direction must be vertical to ensure optimum performance.
 16. Perform a visual inspection of the unit to make sure no damage has occurred during installation.

START-UP PROCEDURE - CONTINUED

17. Check that the evaporator drain pan drain trap has been primed with water.
18. Turn on power to the unit at the disconnect switch.
Note: Units include one blower door switch per access door (one on B- and C-Cabinet, two on D-Cabinet) that are factory installed inside the blower access section door(s). When a blower section door is opened, the switch is opened and interrupts power to the low voltage circuit and de-energizes the blower motor controller. D-Cabinet units also have the same switches on the evaporator/hot gas reheat coil access sections.
19. Check the Carrier microprocessor controller and supply fan blower motor for electrical operation. If the unit is equipped with the optional building power exhauster module (with or without energy recovery), check the blower motor for electrical operation. If these do not function, recheck the wiring diagram. Check to ensure that none of the Control Options (for example, smoke detector, etc.) have tripped.
20. Check to make sure that the damper(s) operate properly without binding.
21. Check that the supply power wiring is wired with the correct phase rotation. For units equipped for dual power supply sources, correct phase rotation must be verified on both the main feed and the auxiliary feed. Incorrect phase rotation can damage the equipment. Check the phase rotation as follows:
 - **For units equipped with single speed motor starters on the supply fan:** Check the blower wheel for proper direction of rotation when compared to the air flow direction arrow on the blower housing. Blower wheel rotation, not air movement, must be checked as insufficient air will be delivered if the blower wheel is running backwards. If the blower wheel is rotating in the opposite direction, the phase reversal must be corrected by changing the incoming power feed legs at the supply to the unit, NOT the individual components on the unit. Recheck for proper rotation.
 - **For units equipped with a variable frequency drive on the supply fan:** The VFD will correct the phase rotation for the supply fan, but will not correct the phase rotation for the rest of the unit, therefore observing the supply blower wheel rotation direction is not an accurate indicator of correct phase rotation. Scroll compressors will only compress in one rotational direction. Verification of proper rotation direction is made by observing that suction pressure drops and discharge pressure rises when the compressor is energized. Reverse rotation will result in no pressure differential as compared to normal values. There is no negative impact on durability caused by operating the compressors in the reversed direction for a short period of time (under one hour) but should not be allowed to operate longer than the time it takes to verify rotation. If the compressor is rotating in the opposite direction, the phase reversal must be corrected by changing the incoming power feed legs at the supply to the unit, NOT at the compressor. Recheck for proper rotation.
22. Check the blower speed (rpm). Refer to Blower Adjustments for modification.
23. Check the motor speed (rpm).
24. Check the motor voltage. On three phase systems, check to make sure all legs are in balance.
25. Check the motor amp draw to make sure it does not exceed the motor nameplate rating. Check all legs to ensure system is balanced.
26. For units equipped for dual power supply sources, the unit should be started separately on the main power feed and again on the auxiliary power feed to verify proper unit and control operation.
Note: Units equipped for dual power supply sources have the unit power wiring separated into two circuits as follows:
 - Circuit #1
 - Compressors
 - Condenser fans
 - Electric heating section (if applicable).
 - Energy recovery wheel (if applicable)
 - Circuit #2
 - Main unit controller
 - Supply fan
 - Dampers
 - Gas heating section (if applicable)
 - Exhaust fan (if applicable)
 - Energy recovery wheel bypass damper (if applicable)When operating in a full power state with the main power feed, both Circuit #1 and Circuit #2 should be powered. When operating in a low power state with the auxiliary power feed, only Circuit #2 should be powered.

Blower Adjustments

The units are designed for ease of airflow adjustments, within a range, for field balancing against actual external static pressure conditions. If the static pressure external to the unit is above or below the original design point for the unit, the blower will deliver an airflow volume that is lower or higher than required. When equipped with the building exhaust option (with or without energy recovery), the air balancing must be performed for both the main unit supply fan, as well as the exhaust fan.

The blower speed (supply and/or exhaust blowers) may be adjusted to achieve the desired air volume, provided:

- The allowable temperature rise range and the maximum supply air temperature for heating is not exceeded as shown in Table 18.1, and
- The airflow is within the allowable limits shown on the serial plate for both heating and cooling, and
- The total static pressure does not exceed the limit shown on the unit serial plate, and
- It is within the range of adjustability for the unit, and
- The motor amp draw must not exceed the motor nameplate rating.

The blower speed adjustment method is dependant on the following configurations:

- **Direct Drive** where the blower is driven directly by the motor as seen in Figure 18.1. This is the current standard supply fan configuration for all units.
- **Belt Drive** where the blower is driven by the motor with a belt and sheaves as seen in Figure 18.2. This is the current standard exhaust fan configuration (if equipped) for all units. It was also used on supply fans for units shipped before 2018.

Once the blower/motor configuration of the unit is determined, follow the appropriate instructions in the sections on the following pages.

START-UP PROCEDURE - CONTINUED

Figure 18.1 - Direct Drive Blower Example




Figure 18.2 - Belt Drive Blower Example




Table 18.1 - Allowable Temperature Rise Range and Maximum Supply Air Temperature

Casing Size	Heat Type	Rating	Eff	Temp Rise	Allowable Temp Rise Range	Max Supply Air Temp
Digit 6	Digit 17	Digit 18	(for formula)	Digit 19		
B	1	A, B, C, D	1.00	N	1 - 100°F	100°F
	2 or 3	F, G, H, J, K	0.81	L	30 - <70°F	130°F
		R, S, T	0.94	N	30 - 100°F	
C	1	A, B, C, D, E	1.00	N	1 - 100°F	100°F
	2 or 3	J	0.81	N	30 - 75°F	130°F
		K, L, M	0.81	L	30 - <70°F	
				H	70 - 100°F	
		U, V	0.81	L	30 - <70°F	100°F
H	70 - 100°F					
D	1	A, B, C, D, E	1.00	N	1 - 100°F	100°F
	2 or 3	K	0.81	L	30 - 75°F	130°F
		L, M, Q	0.81	L	30 - <70°F	
				H	70 - 100°F	
		1, 4	0.81	H	70 - 120°F	
2, 3, 5	H	60 - 120°F				

Blower Adjustments – Direct Drive Fans

All direct drive supply fan speed adjustments can be performed with the Modine Control System programmable microprocessor controller. There are two ways to access the menus:

1. Using the user interface on the main unit controller.
2. Using the pGD1 Digital Display/Interface Module.

For guidance on either method above, refer to the latest revision of the following documents for additional warnings, cautions, controller location, instructions, and menu navigation:

- Controls Manual, MCP15-525.
- pGD1 Digital Display/Interface Module Installation Instructions, MCP15-543.

The blower adjustments are made as follows:

1. Ensure unit is running at the maximum airflow setting for the control type selected. For example, if the unit has Multi-Speed or Variable Speed fan control, ensure the unit is operating at the highest speed setting.
2. On the keypad navigate to menu “G. Service -> f. SERVICE SETTINGS”. At this menu, you will be prompted to enter the Service password of 1500.
3. Navigate to “c. Control Settings” and scroll to the “Supply Fan Control (CS6)” screen. See Figure 18.3.

Figure 18.3 - Control Settings Screen CS6



4. Adjust the Air Balance Adj parameter up or down to obtain the design airflow given the actual static pressure.
5. In the event you are unable to increase or decrease the motor speed to the desired air balance please consult your factory representative.
6. Check the motor amps to ensure the maximum motor amp rating is not exceeded. For units equipped with a VFD, measure the amps at the incoming lines to the motor. If the unit has dual supply fans, measure each motor individually. Verify airflow volume and repeat steps above for further adjustment.
7. If equipped with gas heat, turn on the gas and initiate burner operation. For guidance, refer to the Controls Manual.
8. Verify the temperature rise and supply air temperature of the heating section do not fall outside the range or exceed the maximums shown in Table 18.1. Airflow can be approximated with the following formula:

$$CFM = (\text{Input Btu/hr} \times \text{Eff}) / (1.08 \times \text{Temp Rise})$$

where Eff (Efficiency) is determined from Table 18.1


START-UP PROCEDURE - CONTINUED

Blower Adjustments – Belt Drive Fans

All belt drive supply fan and, if applicable, exhaust fan speed adjustments can be made with the adjustable sheave on the blower motor as follows:

1. Turn off power to the unit at the disconnect switch. If equipped with gas heat option, turn all hand gas valves to the "OFF" position.
2. Loosen the belt tension and remove the belt.
3. On the motor sheave, loosen the set screw on the side away from the motor (see Figure 19.1).

Figure 19.1 - Motor Sheave Adjustment



4. To increase the blower speed, turn the adjustable half of the sheave inward. To decrease the blower speed, turn the adjustable half of the sheave outward. The sheave half is adjustable in ½ turn (180°) increments. Each ½ turn represents approximately a 2-5% change in blower speed and airflow volume.
5. Tighten the set screw on the flat portion of the sheave shaft.
6. Replace the belt and verify that the belts are aligned in the sheave grooves properly and are not angled from sheave to sheave.
7. Turn on power to the unit and initiate blower motor operation. For guidance, refer to the Controls Manual.
8. Check the motor amps to ensure the maximum motor amp rating is not exceeded. Verify airflow volume and repeat steps above for further adjustment.
9. If equipped with gas heat, turn on the gas and initiate burner operation. For guidance, refer to the Controls Manual.
10. Verify the temperature rise and supply air temperature of the heating section do not fall outside the range or exceed the maximums shown in Table 18.1. Airflow can be approximated with the following formula:

CFM = (Input Btu/hr x Eff) / (1.08 x Temp Rise)
where Eff (Efficiency) is determined from Table 18.1
11. After 24 hours of operation, retighten the setscrews to the torque listed in the owners manual on the bearing, sheave, and blower wheel to avoid damage to the unit.

Air Flow Proving Switch / Optional Dirty Filter Switch

The air flow proving switch is factory installed in the blower compartment. The purpose of the air flow proving switch is to cut power to the controls if a positive pressure is not measured by the switch. This could be caused by a lack of air movement through the evaporator coil or heat exchanger.

The optional dirty filter pressure switch is factory installed in the filter section. The dirty filter pressure switch monitors the pressure differential between the two sides of the filters. When the filters become dirty, the differential pressure increases and trips the pressure switch which initiates an alarm from the Carel controller. The pressure differential switch must be field set because setting the switch requires the blower to be in operation and the ductwork to be installed.

Setting the Air Flow Proving or Dirty Filter Switch

1. Ensure that the unit filters are clean. Replace if necessary.
2. Using the Modine Control System controller interface, start blower operation.
3. Turn the set screw of the pressure switch clockwise until it stops.
4. With the wires removed from the common and normally open terminals of the switch, measure continuity and turn the adjustment screw counter-clockwise until the switch makes. Then turn the adjustment screw one additional turn counter-clockwise to account for dirty filters or other system static changes.

Variable Air Movement Applications

Units may be supplied with variable frequency drives for applications where variable air volume is required. The minimum air flow may be varied between 50 and 100% of the full speed air flow depending on the controls selection of the unit, but never less than the following:

- B-Cabinet units: 1100 CFM
- C-Cabinet units: 3000 CFM
- D-Cabinet units: 4000 CFM
- All units with Gas Heat: Minimum airflow as listed on the Gas Heat Serial Plate

Refer to the Controls Manual for additional information.

START-UP PROCEDURE - CONTINUED

Checking Refrigerant Charge

WARNING

This unit contains R-410A high pressure refrigerant. Hazards exist that could result in personal injury or death. Installation, maintenance, and service must only be performed by an HVAC technician qualified in R-410A refrigerant and using proper tools and equipment. Due to much higher pressure of R-410A refrigerant, DO NOT USE service equipment or tools designed for refrigerants other than R410A.

CAUTION

Do not overcharge the refrigeration system. This can lead to elevated compressor discharge pressure and possibly flooding the compressor with liquid. This may result in compressor failure not covered under warranty.

IMPORTANT

1. All refrigeration checks must be made by a qualified R-410A refrigeration technician.
2. Do not release refrigerant to the atmosphere. When adding or removing refrigerant, all National, State/Province, and local laws must be followed.

Refrigerant charge can be verified by checking both superheat and subcooling. B- and C-Cabinet units have one circuit and D-Cabinet units have two circuits. The following procedure is to be done for each refrigeration circuit.

1. Check the evaporator coil to be sure there are no obstructions to airflow.
2. From the Modine Control System controller interface, create a call for cooling. If the unit has the hot gas reheat option, the hot gas reheat valves must be closed.
3. The unit must be operated at near to full load operation before checking the refrigerant charge. The unit operation should be stabilized, typically after 10-15 minutes of operation.
4. Measure subcooling as follows:
 - a. Read the gauge pressure at the liquid line test port (refer to the figures on pages 32 through 35). Note the saturation temperature on the gauge.
 - b. Measure the temperature of the liquid line at a point near where the pressure reading was taken.
 - c. Subtract the measured liquid line temperature from the saturation temperature to determine the liquid subcooling. For units without the hot gas reheat option, the subcooling should be 10-15°F. For units with the hot gas reheat option, the subcooling should be 5-15°F.
5. Measure the superheat as follows:
 - a. Read the gauge pressure at the suction line close to the compressor. Note the saturation temperature on the gauge.
 - b. Measure the temperature of the suction line at a point near where the pressure reading was taken.

- c. Subtract the saturated temperature from the measured suction line temperature to determine the evaporator superheat. The superheat should be 8-12°F.
6. Determine if the system is undercharged or overcharged and correct as follows:
 - a. Undercharged: Typically, superheat is too high and subcooling is too low. Refrigerant should be added.
 - b. Overcharged: Typically, superheat is too low and subcooling is too high. Refrigerant should be removed.
 7. After adding or removing refrigerant, allow the system to stabilize for 10-15 minutes before making any other adjustments.
 8. Repeat the steps above until the subcooling and superheat are within the range specified.
 9. Repeat the above procedure for the 2nd circuit on D-Cabinet units.
 10. Once the correct charge has been established, operate the unit reheat mode to verify correct operation.

Table 20.1 - Refrigerant Charge

Casing Size	Unit Tons	Hot Gas Reheat		Refrigerant Charge per Circuit (lbs.)	# of Circuits
		Digit 6	Digits 4-5		
B	07		0	17.0	1
			1 or 2	20.0	
	10		0	17.0	
			1 or 2	20.5	
	13		0	23.0	
			1 or 2	28.5	
	15		0	24.0	
			1 or 2	28.5	
	20		0	28.5	
			1 or 2	35.5	
C	15		0	35.0	1
			1 or 2	39.0	
	20		0	37.0	
			1 or 2	42.0	
	26		0	38.0	
			1 or 2	44.0	
	30		0	39.0	
			1 or 2	46.0	
D	30		0	34.5	2
			1 or 2	45.0	
	40		0	36.0	
			1 or 2	46.5	
	52		0	Future	
			1 or 2	Future	
	60		0	Future	
			1 or 2	Future	

START-UP PROCEDURE - CONTINUED

REVIEW BEFORE PROCEEDING

**THIS SECTION APPLIES TO UNITS WITH
OPTIONAL GAS HEAT
(MODEL DIGIT 17=2 OR 3).**

**IF THE UNIT DOES NOT HAVE GAS HEAT,
SKIP TO PAGE 28.**

Gas Heating Option

The Gas Heating Option requires gas pressure be measured and adjusted as required at several points on the unit. The following steps must be completed:

Identify the Gas Control Type

Before you begin, review the furnace serial plate to determine the model installed. The serial plate is located on the right hand access door for the furnace section. Refer to Pages 56 through 59 for Serial Plate and Model Nomenclature information. Note that the furnace serial plate is separate from the unit (model MPR) serial plate.

Digit 11 of the furnace model number denotes the type of gas control used. These are defined below:

- 4 - Indicates two heat exchangers using basic modulating controls with United Technologies ignition. Manifold pressure of both heat exchangers is varied simultaneously based on demand. Power exhausters operate at a constant speed.
- 6 - Indicates a single heat exchanger with Beckett advanced modulation control which varies the manifold pressure and power exhauster speed based on demand. High turn down and more consistent efficiency are possible with this control.
- 8 - Indicates two or more heat exchangers; one equipped with advanced Beckett modulation master control and the other(s) equipped with non-modulating single input slave control. The slave heat exchanger(s) is controlled and monitored by the master control and will turn on or off depending on demand.

Check/Adjust Pressure Upstream of Unit

With the field installed manual gas shut-off valve in the "OFF" position, recheck the gas supply pressure at the field installed manual shut-off valve. The inlet pressure should be 6"-7" W.C. on natural gas, while all the burners are operating, but never more than 14" W.C. when the burners are off. If inlet pressure is too high, install an additional pressure regulator upstream of the combination gas control.

Check/Adjust Pressure at Combination Gas Valve

1. Open the field installed manual gas shut-off valve and set the combination gas control valve to the "ON" position. Note for C- and D-Cabinet sized units, the Gas Heating Option consists of two or more heating sections. For this step, only one combination gas valve is to be set to the "ON" position.
2. Enable the unit controls. For furnace models with furnace model Digit 11=6, the LED readout on the furnace control board (Figure 23.1) will briefly display the furnace size. Verify that the model readout is correct for the unit being started.
3. Ensure that the supply fan blower is operating at the proper airflow and adjust the Modine Control System control setpoint to create a call for heat. Refer to the Controls Manual for instructions on changing the setpoint.
4. Check the ignition control and gas valve for electrical operation.
5. Check to make sure that the main gas valve opens while the supply fan blower is operating.
6. Check the gas pressure at the INLET to the combination gas control valve (refer to figures on pages 24 through 26) and adjust as needed to maintain 6"-7" W.C. while the burners are operating at high fire. This pressure is required for proper ignition and to attain the rated input of the unit. If this pressure cannot be obtained, the gas supply is undersized and needs to be corrected or the gas supplier must be contacted.
7. Check gas pressure on the OUTLET of the combination gas control valve (refer to figures on pages 24 through 26) when the burners are functioning. This should be set to 4.0" W.C. for all furnaces with furnace model Digit 11=4, or 6. For C-Cabinet furnaces with furnace model Digit 11=8, only the right hand modulated heat exchanger is set to 4.0" W.C. The left hand fixed input heat exchanger is set to 3.5" W.C. Adjust the gas control valve regulator as needed (see gas valve instruction sheet for location.)
8. Check to ensure that gas controls sequence properly (see Controls Manual).
9. For units with multiple heat exchangers, repeat steps 3 through 8 for each heat exchanger before proceeding to the next step.

Check/Adjust Pressure at Manifold

The following steps are required to check/adjust the manifold pressure on modulated heat exchangers. For units with furnace model Digit 11=4, this process applies to both heat exchangers and is conducted on one heat exchanger at a time. For all other units, this process applies to only one heat exchanger, normally the lower right heat exchanger on multiple heat exchanger units.


1. Move the field installed manual shut-off valve to the "OFF" position.
2. Remove the 1/8" pipe plug in the pipe tee of the furnace.
3. Attach a digital or "U" tube type water manometer which is at least 12" high and capable of reading to 0.1" W.C.
4. The Maxitrol EXA modulating valve series (refer to figures on pages 24 through 26) has a cover secured with two screws that must be removed. Once removed, there are a bank of (3) DIP switches and two buttons and a communication LED for the user interface as shown in Figure 22.1.
5. Verify that the DIP switches are properly set to the settings shown in Figure 22.1.
6. Move the field installed manual gas shut-off valve to the "ON" position.
7. Adjust the High Fire Setting as follows:
 - a. Enable the unit controls.
 - b. For units with furnace model Digit 11=6 or 8, place the furnace control into the "Checkout Test Mode" as described on the next page and set the Fire Rate Input to 10.0.
 - c. Press and hold Button #1 on the modulating valve until the LED lights solid red, then release.
 - d. With the valve now in the high fire setting mode, confirm

START-UP PROCEDURE - CONTINUED

or adjust the high fire manifold pressure to be 3.5" W.C. If the pressure needs to be adjusted, press or hold Button #1 to increase gas flow and press or hold Button #2 to decrease gas flow.

- e. If 3.5" W.C. cannot be attained, recheck the inlet gas pressure as described previously. After addressing any issues, if 3.5" W.C. still cannot be attained, step the valve closed using button #2 to the point where manifold pressure begins to be impacted. If the pressure at that point is less than 3.3" W.C., corrective action is required.
- f. Save the setting by simultaneously holding Buttons #1 and #2 until the LED turns OFF. If this is not performed within 5 minutes, the control will default to the previously saved settings and return to normal operating mode.

Figure 22.1 - Maxitrol Modulating Valve Adjustments



8. Adjust the Low Fire Setting as follows:
 - a. For units with furnace model Digit 11=6 or 8, place the furnace control into the "Checkout Test Mode" as instructed in the next section and set the Fire Rate Input to 2.0.
 - b. Press and hold Button #2 on the modulating valve until the LED light blinks red, then release.
 - c. With the valve now in the low fire setting mode, confirm or adjust the low fire manifold pressure to be no less than the minimum shown on the furnace serial plate in the box called "Min. Manifold Pressure". If the pressure needs to be adjusted:

Press or hold Button #1 to increase gas flow and press Button #2 to decrease gas flow. It is best to push and release button #2 to single step the valve to the minimum manifold pressure. Pressing and holding the button is likely to cause the valve to close too far and lose flame.
 - d. Save the setting by simultaneously holding Buttons #1 and #2 until the LED turns OFF. If this is not performed within 5 minutes, the control will default to the previously saved settings and return to normal operating mode.
9. For furnace models with Digit 11=6 or 8, if no errors or alerts were recorded by the board (these will be on the 3 LED displays as an "A" or "E" followed by a number), proceed to the next step. If any alerts or errors were logged by the board, refer to the "Clearing Furnace Control Board

Error Codes" section in the next column to clear the errors.

10. For furnace models with Digit 11=6 or 8, verify the furnace control board and modulating valve is communicating properly by adjusting the Fire Rate Input on the control board from 10.0 to 2.0 with the up and down buttons.
 - The high fire manifold pressure may be in the range of 3.3" W.C to 3.5" W.C. at the 10.0 Fire Rate Input setting.
 - The low fire manifold pressure must not go below 0.2" W.C. at the 2.0 Fire Rate Input setting. If the manifold pressure drops below 0.2"W.C. or flame is lost, repeat the "Check/Adjust Pressure at Combination Gas Valve" section on the previous page and then repeat the "Low Fire Setting" sequence described above.
11. Once the setting of the modulating valve has been completed, replace the valve cover that was removed earlier.
12. Move the field installed manual shut-off valve to the "OFF" position, remove the manometer, and replace the 1/8" pipe plug.
13. After the plug is in place, move the field installed manual shut-off valve to the "ON" position and recheck the pipe plug for gas leaks with soap solution.
14. For units with furnace model Digit 11=4, repeat the entire process for the 2nd furnace.

Placing Furnace Control Into "Checkout Test Mode"

(Applies to furnace models with Digit 11=6 or 8)

The furnace control board (Figure 23.1) has functionality to be put it in a manual operation "Checkout Test Mode" for testing purposes as noted in the previous sections for checking and setting gas pressure. To enter that mode, perform the following steps:

1. The Checkout Test mode is only available when the furnace control board detects an "E09" error condition (No Firing Rate Input). To accomplish this, temporarily disconnect wire #804 from the furnace control board and create a call for heat from the main Carel controller. Be sure to insulate the end of the signal wire so it cannot cause a short.
2. Press the MODE button for at least 4 seconds until the LED display changes to display "Lo9".
3. Press the DOWN button briefly to change the display to "tSt", and then briefly press the MODE button to enter the Checkout Test mode.
4. When the Checkout Test mode is entered, the control board will initiate a normal ignition sequence with the Firing Rate Input set to a simulated 10.0 VDC. The simulated Firing Rate Input can be set to different 1.0 VDC step values from 10V to 2V. A 10V signal will give maximum fire rate while a 2V signal will give the minimum fire rate. Once burner ignition has been achieved and the control enters the RUN mode, the normal runtime data parameters, including the Firing Rate, will be continuously displayed on the furnace control board LED indicators.
5. If a lockout error condition occurs, or the MODE button is depressed for more than 4 seconds, or there is no push button activity for 30 minutes, then the Checkout Test mode will be exited.

Clearing Furnace Control Board Error Codes

1. Fault codes can be reviewed by pressing the MODE button for at least 4 seconds until the LED display changes to display "Lo9". Refer to Figure 23.1 for location of buttons and LED display.
2. Briefly press the MODE button again to review the fault codes. Up to 15 fault codes are stored and can be reviewed

START-UP PROCEDURE - CONTINUED

by pressing the UP or DOWN buttons. Codes will be displayed followed by the number of days since the fault was detected.

- To clear the fault codes from memory, press the DOWN button until "CLR" is displayed. Press and hold the MODE button to clear the memory. The board will then revert to normal operation.

Figure 23.1 - Furnace Master Control Board (Furnace models with Digit 11=6 or 8 only)






Figure 23.2 - Furnace Slave Control Board (Furnace models with Digit 11=8) ①



① This applies to C- and D-Cabinet sized units with furnace model Digit 11=8. Refer to Figure 23.3 for identifying which furnace is the Master and which furnace(s) are the Slave(s).

Figure 23.3 - Furnace Master/Slave Locations




② Furnace locations are shown for reference, not the location of the furnace controls. Refer to the figures on pages 25 through 27 for controls location.

Final Check

- Operate furnace (all furnaces for units with multiple heat exchangers) at high fire and verify that gas pressure to the INLET of the combination gas control valve is maintained at 6"-7" W.C. If the pressure cannot be maintained at 6"-7" W.C. while operating at high fire, the gas supply system is undersized and must be corrected and the entire check and adjustment of gas pressures section must be repeated.
- Once all gas pressures have been checked and are at the proper settings, shut the unit down and move the field installed manual shut-off valve to the "OFF" position.
- Remove all testing equipment and replace any hardware (plugs, covers, etc.). For furnace models with Digit 11=6, replace wire #804 that was temporarily removed when the control was placed in the "Checkout Test Mode".
- Close the unit access doors.

START-UP PROCEDURE - CONTINUED

Figure 24.1 - Gas Heat Option Gas Controls - B-Cabinet Sized Units



START-UP PROCEDURE - CONTINUED

Figure 25.1 - Gas Heat Option Gas Controls - C-Cabinet Sized Units


<p>81% Efficiency Option (Digit 18 = J, K, L or M)</p>	
<p>90% Efficiency Option (Digit 18 = U or V)</p>	<p>NOTE: For this option, only the left-side furnace is shown. The right-side furnace will be nearly identical.</p>

- | | |
|--|---|
| <ul style="list-style-type: none"> 1 Power exhauster 2 Maxitrol EXA STAR modulating gas valve (right-hand furnace only) 3 Main combination gas valve 4 High limit control 5 VB1200 master furnace control board (for right-side furnace) 6 VB1201 slave furnace control board (for left-side furnace) 7 Direct spark ignition control board | <ul style="list-style-type: none"> 8 Not Applicable 9 Vent differential pressure proving switch 10 Direct spark ignitor 11 Manifold tee pressure tap 12 Flame sensor 13 Manifold piping with gas orifices 14 Not applicable 15 Heat exchanger tube drain tray with drain line |
|--|---|

- 1 Power exhauster
- 2 Maxitrol EXA STAR modulating gas valve
- 3 Main combination gas valve (hidden behind Item #5)
- 4 High limit control
- 5 Solid state ignition control board
- 6 Valve state relay to Carel controller
- 7 Not applicable
- 8 Not Applicable
- 9 Vent differential pressure proving switch
- 10 Direct spark ignitor
- 11 Manifold tee pressure tap
- 12 Flame sensor
- 13 Manifold piping with gas orifices
- 14 Condensate drain float switch


START-UP PROCEDURE - CONTINUED

Figure 26.1 - Gas Heat Option Gas Controls - D-Cabinet Sized Units - 800,000 Btu/hr and Smaller (81% Eff)



START-UP PROCEDURE - CONTINUED

Figure 27.1 - Gas Heat Option Gas Controls - D-Cabinet Sized Units - 900,000 Btu/hr and Larger (81% Eff)



START-UP PROCEDURE - CONTINUED

**REVIEW
BEFORE
PROCEEDING**

THE FOLLOWING SECTION APPLIES ONLY TO B-CABINET SIZED UNITS WITH OPTIONAL ENERGY RECOVERY EXHAUST OPTION (MODEL NOMENCLATURE DIGIT 6=B AND DIGIT 21=A, B, OR C).

IF THE UNIT DOES NOT HAVE THIS OPTION, SKIP TO PAGE 30.①

① If the unit is a C-cabinet size and has energy recovery exhaust, refer to the latest revision of literature #MCP15-520 for the Start-Up Procedure for the Model ERM Energy Recovery Module.

Energy Recovery Exhaust Option

WARNING

1. The power supply wiring for the Energy Recovery Section comes from a single point power connection on the unit. Disconnect power supply at model MPR before making wiring connections to prevent electrical shock and equipment damage.
2. For units equipped for dual power supply sources, both sources of power must be disconnected to prevent electrical shock and equipment damage.


IMPORTANT

1. On units with the electric preheat option, to prevent premature heat exchanger failure, check to be sure the blower has been set to deliver the proper airflow for the application. Refer to page 17 for Blower Adjustments.
 2. The exhaust fan is not designed for high temperature or smoke control exhaust applications. Exhaust air temperature must not exceed 104°F. Operating the exhaust fan above 104°F will result in failure of the exhaust fan.
1. Turn off power to the unit at the disconnect switch. If equipped with gas heating option, turn all hand gas valves to the "OFF" position.
Note: The dead front disconnect switch, if included, is factory installed in the controls/compressor compartment section (refer to the figures on pages 32 through 35). The disconnect switch is designed so that it must be turned "OFF" before entry to the compartment can be obtained. When in the "OFF" position, power is disconnected to all unit wiring electrically following the switch (see WARNING).
 2. For units equipped for dual power supply sources, both sources of power must be disconnected to prevent electrical shock and equipment damage.
 3. Open the power compartment, controls compartment, and blower access doors. Refer to Figure 29.1 for location of doors and internal components.
 4. Check that the supply voltage matches the unit supply voltage listed on the Unit Serial Plate. Verify that all wiring is secure and properly protected. Trace circuits to insure that the unit has been wired according to the wiring diagram.
 5. Check that fuses or circuit breakers are in place and sized correctly.
 6. Check to see that there are no obstructions to the intake and discharge of the unit.

7. Check the belt tension and sheave alignment for the exhaust blower.
8. Most motors are permanently lubricated for long life and are identified as such on the motor nameplate. Most blower bearings are permanently lubricated as well, except for pillow block bearings or those identified with grease fittings. For motors or blower bearings that are not permanently lubricated, lubricate according to the manufacturer's instructions.
9. Check to make sure that all filters are in place and that they are installed properly according to direction of air flow.
10. Perform a visual inspection of the unit to make sure no damage has occurred during installation.
11. Turn on power to the unit at the disconnect switch.
Note: The unit includes a blower door switch that is factory installed inside the blower section door on the access side of the unit. When the blower section door is opened, the switch is opened and interrupts power to the low voltage circuit and de-energizes the motor starter that controls blower motor operation.
12. Check the Modine Control System controller and exhaust fan blower motor for electrical operation. If this does not function, recheck the wiring diagram. Check to insure that none of the Control Options have tripped.
13. Check to make sure that the economizer wheel bypass damper (if equipped) opens properly without binding.
14. Check the blower wheel for proper direction of rotation when compared to the air flow direction arrow on the blower housing. Blower wheel rotation, not air movement, must be checked as insufficient air will be delivered with the blower wheel running backwards.
15. Check the blower speed (rpm). Refer to Blower Adjustments for modification.
16. Check the motor speed (rpm).
17. Check the motor voltage. Check to make sure all legs are in balance.
18. Check the motor amp draw to make sure it does not exceed the motor nameplate rating. Check all legs to insure system is balanced.
19. Check that the energy recovery wheel rotates. The wheel is factory set to rotate at approximately 20RPM to maximize latent heat transfer.
20. Check the energy recovery wheel voltage and amp draw to make sure it does not exceed the motor nameplate rating.

UNIT COMPONENT IDENTIFICATION / LOCATION

Figure 29.1 - Controls Cabinet - Energy Recovery Section (B-Cabinet only, if equipped) ①



- | | |
|---|---|
| 2 (S) Controls compartment with side wiring entrance | 15 (S) Outside air filters |
| 3 (S) Power distribution block | 16 (O) Outside air filters pressure drop switch |
| 4 (S) Carel pCOxs microprocessor controller | 17 (S) Blower door switch |
| 5 (O) Exhaust fan motor starter (unless VFD controlled, see #19) | 18 (S) Outside air enthalpy sensor |
| 6 (S) Exhaust fan motor circuit breaker | 19 (O) Exhaust fan variable frequency drive (unless motor starter controlled, see #5) |
| 7 (S) Energy recovery wheel drive motor circuit breaker | 20 (S) Exhaust fan motor |
| 8 (S) Energy recovery wheel drive motor motor starter | 21 (S) Exhaust fan plenum fan |
| 9 (S) High and low voltage wiring terminal strip with ground terminals | 22 (S) Exhaust fan belt drive/auto belt tensioner access (access door removed) |
| 10 (O) Exhaust air filters | 23 (O) Inlet hood |
| 11 (O) Exhaust air filters pressure drop switch | 24 (S) Exhaust hood (not pictured) |
| 12 (S) Energy recovery wheel | 25 (O) Economizer bypass damper actuator compartment |
| 13 (O) Energy recovery wheel pressure drop switch | 26 (O) Energy recovery wheel rotation detection sensor (not pictured) |
| 14 (O) Energy recovery wheel electric preheat assembly with control compartment | |


(S) = standard (O) = optional

① Location of components is typical, but may change depending on the unit configuration.

UNIT COMPONENT IDENTIFICATION / LOCATION

ALL FIGURES ON THIS PAGE ARE FOR B- AND C-CABINET SIZED UNITS


Figure 30.1 - Blower/Evaporator/Filter/Damper Sections ①



- 1 (O) GFCI convenience outlet (not shown here, refer to Figure 24.1)
- 2 (S) Blower door switch
- 3 (S) Airflow proving switch
- 4 (S) Supply fan motor with direct drive fan
- 5 (O) Hot gas reheat circuit shut-off valves (one located in controls compartment for C-Cabinet sized units)
- 6 (S) Electronic expansion valve
- 7 (S) Refrigeration circuit sight glass
- 8 (O) Hot gas reheat coil
- 9 (S) Distributor and distributor piping (not all distributor tubes shown)
- 10 (S) High capacity evaporator coil
- 11 (O) 4" secondary filters, MERV 13 or 16
- 12 (S) 2" primary filters, MERV 10 (standard), 13, or 15
- 13 (O) Dirty filter pressure switch (not shown)
- 14 (S/O) Outside air damper (standard on units with outside air)
- 15 (S/O) Modulating damper actuator (standard on units with outside air)
- 16 (S) Mixed air temperature sensor (standard on all units with outside and return air dampers)
- 17 (S) Outside air enthalpy sensor
- 18 (O) Return air damper
- 19 (O) Modulating damper actuator
- 20 (O) Return air enthalpy sensor
- 21 (O) Return air smoke detector
- 22 (S) Evaporator drain pan drain connection
- 23 (O) Gas or electric heat module (gas shown)
- 24 (O) Gas heating high limit control (standard if gas heat)
- 25 (O) Gas heating power exhaust outlet (standard if gas heat)
- 26 (O) Gas heat auxiliary electric heat (not pictured)

(S) = standard (O) = optional

Figure 30.2 - Condenser Section ①




- 1 (S) Condenser fan housing
- 2 (S) Condenser fan motors
- 3 (S) Refrigerant filter/dryer assembly
- 4 (S) Liquid line pressure transducer
- 5 (S) PF™ aluminum microchannel coils
- 6 (S) Schraeder valve pressure test port

(S) = standard (O) = optional

① Pictured is the C-Cabinet sized unit. Component locations are similarly placed on the B-Cabinet sized unit. Location of components is typical, but may change depending on the configuration of the unit.

Figure 30.3 - Optional Data Port ②




② Pictured is the OPTIONAL weatherproof RJ-11 jack for connection of the Remote User Interface Module (optional accessory) to the unit to allow real-time diagnostics without opening the cabinet or shutting the unit off.

UNIT COMPONENT IDENTIFICATION / LOCATION

ALL FIGURES ON THIS PAGE ARE FOR D-CABINET SIZED UNITS

Figure 31.1 - Compressor/Condenser/Blower/Evaporator/Filter/Damper Sections ①




- | | |
|--|--|
| 1. (S) Blower door switch | 17. (O) Return air damper |
| 2. (S) Airflow proving switch (not shown, located on opposite side) | 18. (O) Modulating damper actuator |
| 3. (S) Direct drive supply fan(s)/motor(s) | 19. (O) Return air enthalpy sensor |
| 4. (O) Hot gas reheat valves | 20. (O) Return air smoke detector |
| 4A. Circuit #1 and #2 shut-off valves | 21. (S) Evaporator drain pan drain connection |
| 4B. Circuit #1 and #2 3-way modulating valves | 22. (O) Gas or electric heat module (gas shown) |
| 5. (S) Electronic expansion valves | 23. (O) Gas heat auxiliary electric heat (not pictured) |
| 6. (S) Refrigeration circuit sight glasses | 24. (O) Gas supply connection point |
| 7. (O) Hot gas reheat coil | 25. (S) Condenser fans/motors |
| 8. (S) Distributor and distributor piping (not all distributor tubes shown) | 26. (S) Refrigerant filter/dryer assembly (located behind panel) |
| 9. (S) High capacity evaporator coil | 27. (S) Liquid line pressure transducer |
| 10. (O) 4" secondary filters, MERV 13 (not shown) | 28. (S) PF™ aluminum microchannel coils (one displayed clear for purposes of providing condenser fan/motor detail) |
| 11. (S) 2" primary filters, MERV 10 (standard), 13, or 15 | 29. (S) Schraeder valve pressure test ports |
| 12. (O) Dirty filter pressure switch (not shown) | 30. (S) Tandem Compressor Set #1 (Digital Modulating-On/Off) |
| 13. (S/O) Outside air damper (standard on units with outside air) | 31. (S) Tandem Compressor Set #2 (On/Off-On/Off) |
| 14. (S/O) Damper actuator (standard on units with outside air) | 32. (S) Power Cabinet (refer to page 35) |
| 15. (S/O) Mixed air temperature sensor (standard on units with outside and return air dampers) | 33. (O) Deadfront Disconnect Switch Handle |
| 16. (S) Outside air enthalpy sensor | |

Standard (O) = Optional

① Location of components is typical, but may change depending on the configuration of the unit.

UNIT COMPONENT IDENTIFICATION / LOCATION

Figure 32.1 - Controls Cabinet - B-Cabinet Sized Units ①




- | | |
|--|---|
| 1 Not applicable | 19 (O) Power exhaust fan contactor/variable frequency drive circuit breaker |
| 2 (S) Condenser fan motor circuit breakers | 20 (S) Main controls step-down transformer primary circuit breaker |
| 3 (O) Hot gas reheat circuit shut-off valves (not shown, located in coil compartment) | 21 (O) Gas heating circuit step-down transformer primary circuit breaker |
| 4 (O) Hot gas reheat modulating valves | 22 (O) Convenience outlet step-down transformer primary circuit breaker (if factory powered) |
| 5 Not applicable | 23 (O) Convenience outlet step-down transformer secondary circuit breaker (if factory powered) |
| 6 (S) Tandem digital scroll compressor set (7 ton nominal units feature a single modulating digital compressor, all others are tandem) | 24 (S) Main controls step-down transformer secondary circuit breaker |
| 7 (S) Carel EVD superheat/electronic expansion valve controller | 25 (S) High voltage wiring terminal strip with ground terminals |
| 8 (S) Carel microprocessor controller (main) | 26 (S) High voltage power distribution block |
| 9 (S) Carel Ultracap for EVD controller | 27 (S) Compressor #1 contactor |
| 10 (S) Low voltage wiring terminal strip with ground terminals | 28 (S) Compressor #2 contactor |
| 11 (S) Low voltage wiring channels | 29 (S) Condenser fan variable frequency drive (not pictured, only applies to Model Digit 11=A or B) |
| 12 (S) Low voltage transformer for Carel microprocessor controller (behind item 33) | 30 (O) Supply fan variable frequency drive |
| 13 Not applicable | 31 (O) Gas heating circuit step-down transformer (behind item 33) |
| 14 (S/O) Double pole, double throw relay(s) | 32 (O) Factory powered convenience outlet disconnect switch |
| 15 (S) High voltage wiring channels | 33 (O) Main unit deadfront disconnect |
| 16 (O) Supply voltage/phase monitor | |
| 17 (S) Condenser fan variable frequency drive circuit breaker (not pictured, only applies to Model Digit 11=A or B) | |
| 18 (O) Supply fan variable frequency drive circuit breaker | |

(S) = standard (O) = optional

① Location of components is typical, but may change depending on the configuration of the unit.

UNIT COMPONENT IDENTIFICATION / LOCATION

Figure 33.1 - Controls Cabinet - C-Cabinet Sized Units ①
For units where unit serial number Digit 12=2 (Carel EVD Superheat Controller)




- | | |
|---|--|
| 1 (S) High voltage power distribution block | 19 (O) Power exhaust fan contactor/variable frequency drive circuit breaker |
| 2 (S) Condenser fan motor circuit breakers (qty. 2 on 15 ton, 3 on 20-30 ton) | 20 (S) Main controls step-down transformer primary circuit breaker |
| 3 (O) Hot gas reheat circuit shut-off valve (not shown, located in coil compartment) | 21 (O) Gas heating circuit step-down transformer primary and secondary circuit breakers |
| 4 (O) Hot gas reheat modulating valves | 22 (O) Convenience outlet step-down transformer primary circuit breaker (if factory powered) |
| 5 Not applicable | 23 (O) Convenience outlet step-down transformer secondary circuit breaker (if factory powered) |
| 6 (S) Tandem digital scroll compressor set | 24 (S) Main controls step-down transformer secondary circuit breaker |
| 7 (S) Carel EVD superheat/electronic expansion valve controller with Carel Ultracap | 25 (S) High voltage wiring terminal strip with ground terminals |
| 8 (S) Carel microprocessor controller (main) | 26 (S) Compressor crankcase heater circuit breaker |
| 9 (S) Carel microprocessor controller (expansion module) | 27 (S) Compressor contactors |
| 10 (S) Low voltage wiring terminal strip with ground terminals | 28 (O) Condensing gas heating strip heater contactor |
| 11 (S) Low voltage wiring channels | 29 (S) Condenser fan variable frequency drive |
| 12 (S) Low voltage isolation transformer for Carel microprocessor controller | 30 (S) Supply fan motor starter
(O) Supply fan variable frequency drive |
| 13 Not Applicable | 31 (S) Solid state relay for Carel controller |
| 14 (S/O) Double pole, double throw relay(s) (ex: smoke detector interlock, exhaust fan interlock, etc.) | 32 (O) Factory powered convenience outlet disconnect switch |
| 15 (S) High voltage wiring channels | 33 (O) Main unit deadfront disconnect |
| 16 (O) Supply voltage/phase monitor | 34 (O) Auxiliary / Supplementary electric heat circuit breaker |
| 17 (S) Condenser fan variable frequency drive circuit breaker | |
| 18 (O) Supply fan variable frequency drive circuit breaker | |

(S) = standard (O) = optional

① Location of components is typical, but may change depending on the configuration of the unit. For units where unit serial number Digit 12=1 (Emerson EC3 Superheat Controller), refer to previous version Installation & Service Manual MCP15-500.6 for location of components.

UNIT COMPONENT IDENTIFICATION / LOCATION


Figure 34.1 - Controls Cabinet - D-Cabinet Sized Units ①



① Location of components is typical, but may change depending on the configuration of the unit.

UNIT COMPONENT IDENTIFICATION / LOCATION

Figure 35.1 - Power Cabinet - D-Cabinet Sized Units ①




- | | |
|--|---|
| <ol style="list-style-type: none"> 1. (O) Gas Heat Control Transformer Secondary Circuit Breaker 2. (O) Wiring Terminals for Item #1 3. (O) Phase Monitor Relay 4. (O) Gas Heat Control Transformer 5. (S) 24V Control Transformer 6. (O) Auxiliary Electric Heat (Gas Heat Option) Fuses 7. (O) Powered GFCI Convenience Outlet Option consisting of: <ol style="list-style-type: none"> a. Disconnect Switch b. Transformer Primary Fuses c. Secondary Circuit Breaker d. Terminal Strip e. Transformer f. Convenience Outlet Junction Box (outlet accessible from Low Voltage Control Cabinet (see Figure 34.1)) 8. (S) Main High Voltage Power Distribution Block 9. (O) Supply Fan VFD #2 Fuses (dual blower 15 or 20HP only) 10. (S) Compressor Power Distribution Block 11. (S) Supply Fan VFD #1 Fuses 12. (S) Compressor Circuit Breakers 13. (S) Compressor Contactors | <ol style="list-style-type: none"> 14. (O) Main Factory Mounted Disconnect Switch 15. (S) Supply Fan Power Distribution Block (dual blower 1-10HP) 16. (S) Supply Fan VFD #1 (not pictured is Supply Fan VFD #2 for dual blower 15 or 20HP) 17. (S) Supply Fan Overloads (dual blower 1-10HP) 18. (S) Ground Lug 19. (S) Main Ground Bus Bar 20. (S) Sub Feeder Fuses 21. (S) Terminal Strip for Power Distribution 22. (S) Ground Terminal Blocks 23. (S) Condenser Fan Fuses and Bus Bar 24. (S) Compressor Crankcase Heater Fuses 25. (S) Control Transformer Primary Fuses 26. (O) Gas Heat Control Transformer Primary Fuses 27. (O) Phase Monitor Relay Fuses 28. (S) Cabinet Cooling Device |
|--|---|

(S) = standard (O) = optional

① Location of components is typical, but may change depending on the configuration of the unit.

DIMENSIONS - B-CABINET SIZE UNIT (NO ENERGY RECOVERY)

Figure 36.1 - Unit Dimensions (inches)



DIMENSIONS - B-CABINET UNIT BASE/ROOF CURB (NO ENERGY RECOVERY)

Figure 37.1 - Unit Base Dimensions (inches)




Figure 37.2 - Roof Curb Dimensions (inches)





Table 37.1 - Roof Curb Weight (approx) - lbs.

Section	Description	Weight
Roof Curb	14" - Insulated	174
	14" - Uninsulated	179
	24" - Insulated	268
	24" - Uninsulated	273

DIMENSIONS - B-CABINET SIZE UNIT (WITH ENERGY RECOVERY)

Figure 38.1 - Unit Dimensions (inches)



DIMENSIONS - B-CABINET UNIT BASE/ROOF CURB (W/ ENERGY RECOVERY)

Figure 39.2 - Unit Base Dimensions (inches)




Figure 39.2 - Unit Roof Curb Dimensions (inches)





Table 39.1 - Roof Curb Weight (approx) - lbs.

Section	Description	Weight
Roof Curb	14" - Insulated	259
	14" - Uninsulated	266
	24" - Insulated	394
	24" - Uninsulated	401

DIMENSIONS - C-CABINET SIZE UNIT

Figure 40.1 - Unit Dimensions (inches)



DIMENSIONS - C-CABINET SIZE UNIT BASE / ROOF CURB

Figure 41.1 - Unit Base Dimensions (inches)




Figure 41.2 - Roof Curb Dimensions (inches)





Table 41.1 - Roof Curb Weight (approx) - lbs.

Section	Description	Weight
Roof Curb	14" - Insulated	210
	14" - Uninsulated	205
	24" - Insulated	318
	24" - Uninsulated	310

DIMENSIONS - D-CABINET SIZE UNIT

Figure 42.1 - Unit Dimensions (inches)



DIMENSIONS - D-CABINET SIZE UNIT BASE / ROOF CURB

Figure 43.1 - Unit Base Dimensions (inches)





Figure 43.2 - Roof Curb Dimensions (inches)



BASE MODEL WEIGHTS

Table 44.1 - Approximate Base Model Weight - (lbs.)

Section	Description	Cabinet Size			
		B	C	D	
Base Unit	MPR07	2377			
	MPR10	2489			
	MPR13	2570			
	MPR15	2585	2710		
	MPR20	2685	2894		
	MPR26		2898		
	MPR30		2907	6464	
	MPR40			6656	
	MPR52			6862	
	MPR60			6862	
Dampers	Fresh Air Only	40	45	200	
	Fresh and Return Air	80	95	362	
Hot Gas Reheat	MPR07	22			
	MPR10	22			
	MPR13	26			
	MPR15	26	64		
	MPR20	26	64		
	MPR26		64		
	MPR30		64	70	
	MPR40			70	
	MPR52			80	
	MPR60			80	
Supply Air Blower (Direct Drive)	ANPL 11"	33			
	ANPL 12"	34			
	ANPA 12"	35			
	ANPA 14"	51			
	ANPA 16"	57	57		
	ANPA 16" Dual		114		
	ANPA 20"		97	97	
	ANPA 25"			163	
Motors (most common)	1HP	40	40	40	
	1-1/2HP	40	40	40	
	2HP	50	50	50	
	3HP	80	80	80	
	5HP	95	95	95	
	7-1/2HP	160	160	160	
	10HP	220	220	220	
	15HP	310	310	310	
Power Option	Deadfront Disconnect	Convenience Outlet			
	60A & 100A	None	5	5	5
		Powered by Unit	45	45	45
		Powered by Others	7	7	7
	200A & 400A	None	10	10	10
		Powered by Unit	50	50	50
		Powered by Others	12	12	12
	600A	None			15
		Powered by Unit			55
		Powered by Others			18
	None	None	0	0	0
Powered by Others		2	2	2	

Section	Description	Cabinet Size			
		B	C	D	
Heat Option ①	Electric	20kW	164	164	
		40kW	174	174	328
		60kW	185	185	
		80kW	195	195	348
		100kW	205	205	
		120kW			370
		160kW			390
		200kW			410
		Natural Gas	150MBH	128	
	200MBH		154		
	250MBH		154		
	300MBH		234	256	
	400MBH		234	308	308
	500MBH			308	308
	600MBH			313	468
	800MBH				468
	900MBH				616
	1000MBH				616
	1200MBH				936
	1400MBH			936	
1600MBH			936		
Auxiliary Electric Heat Adder	20kW	164	164		
	40kW			328	
Integral Energy Recovery Wheel Option ②	Energy Recovery Wheel Section	None	0		
		28" Wheel	1002		
		36" Wheel	1041		
		48" Wheel	1200		
	Exhaust Air Blower	None	0		
		11"	114		
		16"	126		
		20"	148		
	Motors (most common)	1HP	40	②	②
		1-1/2HP	40		
		2HP	50		
		3HP	80		
		5HP	95		
		7-1/2HP	160		
	Energy Wheel Electric Preheat	None	0		
20kW Nominal		164			
Inlet Hood	(Ships loose for field installation)	68	72	112	

- ① If equipped with the hot water heat option, please consult the Breeze AccuSpec selection program for the option weight.
- ② For weights of Energy Recovery Module on C-Cabinet (if applicable), refer to the latest revision of literature #MCP15-520.
- ③ 20kW electric preheat is derated for 208V and 230V.
- ④ Auxiliary Electric Heat Adder is available for certain Natural Gas heat ratings and is additive to the Natural Gas heat weight.

OPTION AND ACCESSORY PRESSURE DROP TABLES

Table 45.1 - Pressure Drop Data - B-Cabinet Sized Unit Supply Fan ①

Feature		1111	1250	1500	1750	2000	2250	2500	2750	3000	3250	3500	3750	4000	4250	4500	4750	5000	5250	5500	5750	6000	
Unit	Evaporator Coil	7 & 10 Ton	0.06	0.08	0.10	0.13	0.16	0.19	0.22	0.25	0.28	0.31	0.35	0.38	0.42	0.46	0.50	0.54	0.58	0.62	0.67	0.71	0.76
		13, 15, & 20 Ton	0.05	0.05	0.07	0.09	0.11	0.13	0.15	0.18	0.20	0.22	0.25	0.27	0.30	0.33	0.36	0.39	0.42	0.45	0.48	0.51	0.55
Unit	Hot Gas Reheat Coil	7 & 10 Ton	0.01	0.01	0.01	0.02	0.02	0.02	0.03	0.03	0.03	0.04	0.04	0.04	0.05	0.05	0.06	0.06	0.06	0.07	0.07	0.08	0.08
		13, 15, & 20 Ton	0.01	0.01	0.01	0.01	0.02	0.02	0.02	0.02	0.03	0.03	0.03	0.03	0.04	0.04	0.04	0.05	0.05	0.05	0.06	0.06	0.06
Filters	2" Primary	MERV 10	0.01	0.01	0.01	0.01	0.02	0.02	0.03	0.03	0.04	0.04	0.05	0.05	0.06	0.06	0.07	0.07	0.08	0.09	0.09	0.10	0.11
		MERV 13	0.03	0.03	0.04	0.05	0.06	0.07	0.08	0.08	0.09	0.10	0.11	0.12	0.13	0.14	0.15	0.16	0.17	0.19	0.20	0.21	0.22
		MERV 15	0.02	0.02	0.03	0.04	0.05	0.06	0.07	0.07	0.08	0.09	0.10	0.11	0.12	0.13	0.14	0.15	0.16	0.18	0.19	0.20	0.21
	4" Secondary	MERV 13	0.05	0.05	0.06	0.07	0.08	0.09	0.10	0.10	0.11	0.12	0.13	0.14	0.15	0.16	0.17	0.18	0.19	0.21	0.22	0.23	0.24
MERV 16		0.02	0.03	0.03	0.03	0.04	0.04	0.05	0.05	0.06	0.06	0.07	0.07	0.08	0.08	0.09	0.09	0.10	0.10	0.11	0.12	0.12	
Air Control	Rainhood	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.02	
	Dampers	0.00	0.00	0.00	0.00	0.01	0.01	0.01	0.01	0.01	0.01	0.02	0.02	0.02	0.03	0.03	0.03	0.04	0.04	0.04	0.05	0.05	
Electric Heat	20kW	0.00	0.00	0.00	0.00	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.02	
	40kW	-	-	0.01	0.01	0.01	0.02	0.02	0.02	0.02	0.02	0.03	0.03	0.03	0.03	0.03	0.03	0.04	0.04	0.04	0.04	0.04	
	60kW	-	-	-	-	0.03	0.03	0.04	0.04	0.04	0.05	0.05	0.06	0.06	0.06	0.07	0.07	0.07	0.08	0.08	0.08	0.09	
	80kW	-	-	-	-	-	-	-	0.04	0.04	0.05	0.05	0.06	0.06	0.06	0.07	0.07	0.07	0.08	0.08	0.08	0.09	
Gas Heat	150MBH	High Temp Rise	0.03	0.03	0.04	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
		Low Temp Rise	-	-	-	0.05	0.06	0.07	0.08	0.10	0.11	0.13	0.15	-	-	-	-	-	-	-	-	-	-
	200MBH	High Temp Rise	-	-	0.06	0.08	0.09	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
		Low Temp Rise	-	-	-	-	-	0.10	0.11	0.13	0.16	0.18	0.21	0.24	0.27	0.31	0.34	0.38	-	-	-	-	-
	250MBH	High Temp Rise	-	-	-	-	0.09	0.11	0.14	-	-	-	-	-	-	-	-	-	-	-	-	-	-
		Low Temp Rise	-	-	-	-	-	-	-	0.13	0.16	0.18	0.21	0.24	0.27	0.31	0.34	0.38	0.43	0.47	0.52	0.57	0.62
	300MBH	High Temp Rise	-	-	-	-	-	0.07	0.08	0.09	0.11	-	-	-	-	-	-	-	-	-	-	-	-
		Low Temp Rise	-	-	-	-	-	-	-	-	-	0.08	0.09	0.11	0.12	0.13	0.14	0.16	0.17	0.19	0.20	0.22	0.23
	400MBH	High Temp Rise	-	-	-	-	-	-	-	-	0.11	0.12	0.14	0.15	0.17	-	-	-	-	-	-	-	-
		Low Temp Rise	-	-	-	-	-	-	-	-	-	-	-	-	-	0.13	0.14	0.16	0.17	0.19	0.20	0.22	0.23
175MBH	-	-	-	0.10	0.13	0.16	0.19	0.22	0.26	0.30	0.34	0.39	0.44	0.49	0.54	0.59	0.65	-	-	-	-	-	
225MBH	-	-	-	-	0.13	0.16	0.19	0.22	0.26	0.30	0.34	0.39	0.44	0.49	0.54	0.59	0.65	0.71	0.78	0.84	0.91	-	
310MBH	-	-	-	-	-	-	-	0.17	0.20	0.23	0.25	0.28	0.32	0.35	0.38	0.42	0.46	0.49	0.53	0.58	0.62	-	
Gas Heat + Aux/ Supplemental Electric	150MBH	High Temp Rise	0.03	0.04	0.04	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
		Low Temp Rise	-	-	-	0.05	0.06	0.08	0.09	0.11	0.12	0.14	0.17	-	-	-	-	-	-	-	-	-	-
	200MBH	High Temp Rise	-	-	0.07	0.08	0.10	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
		Low Temp Rise	-	-	-	-	-	0.10	0.12	0.14	0.17	0.19	0.22	0.25	0.28	0.32	0.36	0.40	-	-	-	-	-
	250MBH	High Temp Rise	-	-	-	-	0.10	0.12	0.15	-	-	-	-	-	-	-	-	-	-	-	-	-	-
		Low Temp Rise	-	-	-	-	-	-	-	0.14	0.17	0.19	0.22	0.25	0.28	0.32	0.36	0.40	0.44	0.49	0.54	0.59	0.64
	300MBH	High Temp Rise	-	-	-	-	-	0.07	0.09	0.10	0.12	-	-	-	-	-	-	-	-	-	-	-	-
		Low Temp Rise	-	-	-	-	-	-	-	-	-	0.09	0.11	0.12	0.13	0.14	0.16	0.17	0.19	0.20	0.22	0.23	0.25
	400MBH	High Temp Rise	-	-	-	-	-	-	-	-	0.12	0.13	0.15	0.16	0.18	-	-	-	-	-	-	-	-
		Low Temp Rise	-	-	-	-	-	-	-	-	-	-	-	-	-	0.14	0.16	0.17	0.19	0.20	0.22	0.23	0.25
175MBH	-	-	-	0.11	0.13	0.16	0.20	0.23	0.27	0.31	0.35	0.40	0.45	0.50	0.55	0.61	0.67	-	-	-	-	-	
225MBH	-	-	-	-	0.13	0.16	0.20	0.23	0.27	0.31	0.35	0.40	0.45	0.50	0.55	0.61	0.67	0.73	0.80	0.86	0.93	-	
310MBH	-	-	-	-	-	-	-	0.18	0.21	0.24	0.27	0.30	0.33	0.36	0.40	0.43	0.47	0.51	0.55	0.59	0.64	-	
Energy Recovery Module	2" MERV 10 OA Filters	0.01	0.02	0.03	0.03	0.04	0.05	0.06	0.06	0.07	0.08	0.09	0.10	0.11	0.12	0.13	0.15	0.16	0.17	0.18	0.20	0.21	
	Electric Preheat	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	
	28" Wheel	0.52	0.59	0.72	0.85	0.99	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
	36" Wheel	-	-	0.43	0.51	0.59	0.67	0.76	0.85	0.94	1.03	-	-	-	-	-	-	-	-	-	-	-	-
	48" Wheel	-	-	-	-	-	0.38	0.43	0.48	0.53	0.59	0.64	0.70	0.75	0.81	0.87	0.93	0.99	1.06	1.12	1.19	1.25	

Table 37.2 - Pressure Drop Data - Exhaust Fan ①

Feature		1111	1250	1500	1750	2000	2250	2500	2750	3000	3250	3500	3750	4000	4250	4500	4750	5000	5250	5500	5750	6000
Energy Recovery Module	2" MERV 10 RA Filters	0.01	0.02	0.03	0.03	0.04	0.05	0.06	0.06	0.07	0.08	0.09	0.10	0.11	0.12	0.13	0.15	0.16	0.17	0.18	0.20	0.21
	28" Wheel	0.65	0.72	0.86	1.00	1.15	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	36" Wheel	-	-	0.57	0.65	0.74	0.83	0.92	1.01	1.11	1.20	-	-	-	-	-	-	-	-	-	-	-
	48" Wheel	-	-	-	-	-	0.54	0.59	0.65	0.70	0.76	0.82	0.88	0.94	1.01	1.07	1.14	1.20	1.27	1.34	1.41	1.48

① Option and accessory static pressure drop data shown are approximate. Please consult the Breeze AccuSpec selection program for static pressure drop data at conditions other than shown above.

OPTION AND ACCESSORY PRESSURE DROP TABLES

Table 46.1 - Pressure Drop Data - C-Cabinet Sized Unit Supply Fan ①②

Feature		3000	3250	3500	3750	4000	4250	4500	4750	5000	5250	5500	6000	6500	7000	7500	8000	8500	9000	9500	10000	12000	
Unit	Evaporator Coil	0.11	0.13	0.15	0.16	0.18	0.20	0.21	0.23	0.25	0.27	0.29	0.32	0.36	0.40	0.44	0.49	0.53	0.58	0.62	0.67	0.87	
	Hot Gas Reheat Coil	0.05	0.05	0.05	0.05	0.05	0.05	0.05	0.05	0.05	0.05	0.05	0.06	0.06	0.07	0.08	0.08	0.09	0.10	0.11	0.13	0.18	
Filters	2" Primary	MERV 10	0.02	0.02	0.02	0.03	0.03	0.03	0.04	0.04	0.04	0.05	0.05	0.06	0.07	0.07	0.08	0.09	0.10	0.11	0.11	0.12	0.16
		MERV 13	0.06	0.06	0.07	0.08	0.08	0.09	0.09	0.10	0.11	0.11	0.12	0.13	0.15	0.16	0.17	0.19	0.20	0.22	0.23	0.25	0.31
		MERV 15	0.05	0.05	0.06	0.07	0.07	0.08	0.08	0.09	0.10	0.10	0.11	0.12	0.14	0.15	0.16	0.18	0.19	0.21	0.22	0.24	0.30
	4" Secondary	MERV 13	0.08	0.08	0.09	0.10	0.10	0.11	0.11	0.12	0.13	0.13	0.14	0.15	0.17	0.18	0.19	0.21	0.22	0.24	0.25	0.27	0.33
		MERV 16	0.03	0.04	0.04	0.05	0.05	0.06	0.06	0.06	0.07	0.07	0.08	0.09	0.10	0.11	0.12	0.13	0.15	0.16	0.17	0.19	0.25
Air Control	Rainhood	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.02	0.02	0.02	0.02	0.02	0.04	
	Dampers	0.01	0.01	0.01	0.01	0.02	0.02	0.02	0.02	0.02	0.03	0.03	0.04	0.04	0.05	0.05	0.06	0.07	0.08	0.09	0.10	0.14	
Electric Heat	20kW	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.02	0.02	0.02	0.02	0.02	
	40kW	0.02	0.02	0.02	0.02	0.02	0.02	0.02	0.02	0.03	0.03	0.03	0.03	0.03	0.04	0.04	0.04	0.04	0.05	0.05	0.05	0.06	
	60kW	0.03	0.03	0.03	0.03	0.03	0.04	0.04	0.04	0.04	0.04	0.05	0.05	0.05	0.06	0.06	0.07	0.07	0.08	0.08	0.08	0.10	
	80kW	0.04	0.04	0.04	0.04	0.05	0.05	0.05	0.05	0.06	0.06	0.06	0.07	0.07	0.08	0.08	0.09	0.09	0.10	0.10	0.11	0.13	
	100kW	-	0.04	0.04	0.04	0.05	0.05	0.05	0.05	0.06	0.06	0.06	0.07	0.07	0.08	0.08	0.09	0.09	0.10	0.10	0.11	0.13	
Gas Heat	300MBH	0.07	0.08	0.09	0.10	0.11	0.12	0.14	0.15	0.17	0.19	0.21	0.25	0.30	0.35	-	-	-	-	-	-	-	
	400MBH	High Temp Rise	0.09	0.10	0.11	0.13	0.14	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
		Low Temp Rise	-	-	-	-	-	0.13	0.14	0.15	0.17	0.18	0.20	0.24	0.28	0.33	0.37	0.43	0.48	0.54	0.61	-	-
	500MBH	High Temp Rise	-	-	-	0.13	0.14	0.16	0.18	0.19	0.21	0.23	-	-	-	-	-	-	-	-	-	-	-
		Low Temp Rise	-	-	-	-	-	-	-	-	-	-	0.20	0.24	0.28	0.33	0.37	0.43	0.48	0.54	0.61	0.67	0.98
	600MBH	High Temp Rise	-	-	-	-	-	-	0.21	0.23	0.25	0.27	0.29	0.33	-	-	-	-	-	-	-	-	-
		Low Temp Rise	-	-	-	-	-	-	-	-	-	-	-	-	0.37	0.42	0.46	0.51	0.56	0.61	0.66	0.71	0.94
	350MBH	High Temp Rise	0.14	0.16	0.18	0.21	0.23	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
		Low Temp Rise	-	-	-	-	-	0.22	0.25	0.28	0.31	0.33	0.36	0.42	0.47	0.53	0.58	0.64	0.70	0.75	0.81	-	-
	450MBH	High Temp Rise	-	-	-	0.21	0.23	0.26	0.28	0.31	0.34	0.36	-	-	-	-	-	-	-	-	-	-	-
Low Temp Rise		-	-	-	-	-	-	-	-	-	-	0.36	0.42	0.47	0.53	0.58	0.64	0.70	0.75	0.81	0.87	1.09	
Gas Heat + Aux/ Supplemental Electric	300MBH	0.08	0.09	0.09	0.11	0.12	0.13	0.14	0.16	0.18	0.20	0.22	0.26	0.31	0.36	-	-	-	-	-	-	-	
	400MBH	High Temp Rise	0.10	0.11	0.12	0.13	0.15	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
		Low Temp Rise	-	-	-	-	-	0.13	0.15	0.16	0.18	0.19	0.21	0.25	0.29	0.34	0.39	0.44	0.50	0.56	0.62	-	-
	500MBH	High Temp Rise	-	-	-	0.13	0.15	0.17	0.18	0.20	0.22	0.24	-	-	-	-	-	-	-	-	-	-	-
		Low Temp Rise	-	-	-	-	-	-	-	-	-	-	0.21	0.25	0.29	0.34	0.39	0.44	0.50	0.56	0.62	0.69	1.00
	600MBH	High Temp Rise	-	-	-	-	-	-	0.22	0.24	0.26	0.28	0.30	0.34	-	-	-	-	-	-	-	-	-
		Low Temp Rise	-	-	-	-	-	-	-	-	-	-	-	-	0.39	0.43	0.48	0.52	0.57	0.62	0.68	0.73	0.96
	350MBH	High Temp Rise	0.14	0.17	0.19	0.21	0.24	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
		Low Temp Rise	-	-	-	-	-	0.23	0.26	0.29	0.32	0.34	0.37	0.43	0.48	0.54	0.60	0.66	0.71	0.77	0.83	-	-
	450MBH	High Temp Rise	-	-	-	0.21	0.24	0.26	0.29	0.32	0.35	0.37	-	-	-	-	-	-	-	-	-	-	-
Low Temp Rise		-	-	-	-	-	-	-	-	-	-	0.37	0.43	0.48	0.54	0.60	0.66	0.71	0.77	0.83	0.88	1.12	
Energy Recovery Module	2" MERV 10 OA Filters	0.04	0.04	0.05	0.05	0.06	0.06	0.07	0.07	0.08	0.09	0.09	0.11	0.12	0.13	0.15	0.16	0.18	-	-	-	-	
	Electric Preheat	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	-	-	-	-	
	48" Wheel	0.50	0.55	0.60	0.65	0.70	0.76	0.81	0.86	0.92	0.98	1.03	1.15	-	-	-	-	-	-	-	-	-	
	58" Wheel	0.34	0.37	0.41	0.44	0.48	0.51	0.55	0.59	0.63	0.67	0.71	0.79	0.87	0.96	1.05	1.14	1.23	-	-	-	-	

Table 38.2 - Pressure Drop Data - Exhaust Fan ①

Feature		3000	3250	3500	3750	4000	4250	4500	4750	5000	5250	5500	6000	6500	7000	7500	8000	8500	9000	9500	10000	12000
Energy Recovery Module	2" MERV 10 RA Filters	0.04	0.04	0.05	0.05	0.06	0.06	0.07	0.07	0.08	0.09	0.09	0.11	0.12	0.13	0.15	0.16	0.18	-	-	-	-
	48" Wheel	0.66	0.71	0.76	0.82	0.87	0.93	0.98	1.04	1.10	1.16	1.22	1.34	-	-	-	-	-	-	-	-	-
	58" Wheel	0.50	0.53	0.57	0.61	0.65	0.68	0.72	0.77	0.81	0.85	0.89	0.98	1.07	1.16	1.26	1.36	1.46	-	-	-	-

① Option and accessory static pressure drop data shown are approximate. Please consult the Breeze AccuSpec selection program for static pressure drop data at conditions other than shown above.

② If equipped with the hot water heat option, please consult the Breeze AccuSpec selection program for static pressure drop at design conditions.

OPTION AND ACCESSORY PRESSURE DROP TABLES

Table 47.1 - Pressure Drop Data - D-Cabinet Sized Unit Supply Fan ①②

Feature			4000	5000	6000	7000	8000	9000	10000	11000	12000	13000	14000	15000	16000	17000	18000	
Unit	Evaporator Coil	30 & 40 Ton	0.17	0.24	0.32	0.41	0.51	0.62	0.73	0.86	0.99	-	-	-	-	-	-	
		52 & 60 Ton	-	-	-	Future	Future	Future	Future	Future	Future	Future	Future	Future	Future	Future	Future	Future
	Hot Gas Reheat Coil	30 & 40 Ton	0.05	0.06	0.09	0.11	0.13	0.16	0.19	0.22	0.26	-	-	-	-	-	-	-
		52 & 60 Ton	-	-	-	Future	Future	Future	Future	Future	Future	Future	Future	Future	Future	Future	Future	Future
Filters	2" Primary	MERV 10	0.01	0.02	0.03	0.04	0.04	0.05	0.06	0.07	0.08	0.09	0.10	0.11	0.12	0.14	0.15	
		MERV 13	0.05	0.07	0.08	0.10	0.12	0.13	0.15	0.17	0.19	0.21	0.23	0.25	0.27	0.30	0.32	
		MERV 15	0.02	0.03	0.04	0.06	0.07	0.08	0.10	0.11	0.13	0.15	0.17	0.19	0.21	0.23	0.25	
	4" Secondary	MERV 13	0.04	0.05	0.06	0.07	0.08	0.09	0.10	0.12	0.13	0.15	0.16	0.18	0.20	0.22	0.24	
Air Control	Rainhood		0.00	0.00	0.00	0.00	0.01	0.01	0.01	0.01	0.01	0.01	0.02	0.02	0.02	0.02	0.03	
	Dampers		0.00	0.01	0.01	0.01	0.02	0.02	0.03	0.04	0.04	0.05	0.06	0.07	0.08	0.09	0.10	
Electric Heat	40kW		0.03	0.04	0.04	0.05	0.06	0.07	0.07	0.08	0.09	0.09	0.10	0.11	0.12	0.12	0.13	
	80kW		0.01	0.02	0.02	0.03	0.03	0.03	0.04	0.04	0.04	0.05	0.05	0.05	0.06	0.06	0.06	
	120kW		0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.02	0.02	0.02	0.02	0.02	0.02	0.02	
	160kW		-	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.02	0.02	0.02	0.02	0.02	0.02	0.02	
	200kW		-	-	-	0.01	0.01	0.01	0.01	0.01	0.02	0.02	0.02	0.02	0.02	0.02	0.02	
Gas Heat	400MBH	Low Temp Rise	0.08	0.11	0.16	0.21	0.27	0.34	0.43	-	-	-	-	-	-	-	-	
		High Temp Rise	0.09	0.14	-	-	-	-	-	-	-	-	-	-	-	-	-	
	500MBH	Low Temp Rise	-	-	0.16	0.21	0.27	0.34	0.43	0.52	0.62	-	-	-	-	-	-	
		High Temp Rise	-	0.13	0.17	-	-	-	-	-	-	-	-	-	-	-	-	
	600MBH	Low Temp Rise	-	-	-	0.15	0.17	0.20	0.22	0.25	0.28	0.32	0.35	0.39	-	-	-	
		High Temp Rise	-	-	0.17	0.21	0.25	-	-	-	-	-	-	-	-	-	-	
	800MBH	Low Temp Rise	-	-	-	-	-	0.20	0.22	0.25	0.28	0.32	0.35	0.39	0.42	0.46	0.51	
		High Temp Rise	-	-	-	0.51	0.64	0.79	-	-	-	-	-	-	-	-	-	
	1000MBH	High Temp Rise	-	-	-	-	0.64	0.79	0.96	1.15	1.35	-	-	-	-	-	-	
	1200MBH	High Temp Rise	-	-	-	-	-	0.53	0.63	0.73	0.84	0.96	1.09	1.22	-	-	-	
1400MBH	High Temp Rise	-	-	-	-	-	-	-	0.73	0.84	0.96	1.09	1.22	-	-	-		
1600MBH	High Temp Rise	-	-	-	-	-	-	-	-	0.84	0.96	1.09	1.22	1.36	1.51	1.67		
Gas Heat + Aux/ Supplemental Electric	400MBH	Low Temp Rise	0.11	0.15	0.20	0.26	0.33	0.41	0.50	-	-	-	-	-	-	-	-	
		High Temp Rise	0.12	0.18	-	-	-	-	-	-	-	-	-	-	-	-	-	
	500MBH	Low Temp Rise	-	-	0.20	0.26	0.33	0.41	0.50	0.60	0.71	-	-	-	-	-	-	
		High Temp Rise	-	0.17	0.21	-	-	-	-	-	-	-	-	-	-	-	-	
	600MBH	Low Temp Rise	-	-	-	0.20	0.23	0.26	0.30	0.33	0.37	0.41	0.45	0.50	-	-	-	
		High Temp Rise	-	-	0.21	0.26	0.31	-	-	-	-	-	-	-	-	-	-	
800MBH	Low Temp Rise	-	-	-	-	-	0.26	0.30	0.33	0.37	0.41	0.45	0.50	0.54	0.59	0.64		

① Option and accessory static pressure drop data shown are approximate. Please consult the Breeze AccuSpec selection program for static pressure drop data at conditions other than shown above.

MAINTENANCE

WARNING

1. When the dead front disconnect switch(es) (for main unit and/or powered convenience outlet option) is in the "OFF" position, supply power remains energized at the line (supply) side of the dead front disconnect switch(es). The switch body is located inside of another junction box to protect against contact with the live wiring. The junction box must not be disassembled unless the main power supply from the building to the unit is de-energized.
2. For units equipped for dual power supply sources, both sources of power must be disconnected to prevent electrical shock and equipment damage.
3. This unit contains R-410A high pressure refrigerant. Hazards exist that could result in personal injury or death. Installation, maintenance, and service must only be performed by an HVAC technician qualified in R-410A refrigerant and using proper tools and equipment. Due to much higher pressure of R-410A refrigerant, DO NOT USE service equipment or tools designed for refrigerants other than R410A.

CAUTION

When servicing the unit, some components may be hot enough to cause pain or injury. Allow time for cooling of hot components before servicing.

IMPORTANT

Start-up and adjustment procedures must be performed by a qualified service agency.

All cooling and heating equipment should be serviced before each season to assure proper operation. The following items may require a more frequent service schedule based on the environment in which the unit is installed, and the frequency of the equipment operation.

Before You Begin

1. Turn off power to the unit at the disconnect switch. If equipped with gas heating option, turn all hand gas valves to the "OFF" position.
Note: The dead front disconnect switch, if included, is factory installed in the controls/compressor compartment section (refer to the figures on pages 32 through 35). The disconnect switch is designed so that it must be turned "OFF" before entry to the compartment can be obtained. When in the "OFF" position, power is disconnected to all unit wiring electrically following the switch (see WARNING).
2. For units equipped for dual power supply sources, both sources of power must be disconnected to prevent electrical shock and equipment damage.
3. Open the power compartment, controls compartment, and blower access doors. Refer to Figure 29.1 for location of doors and internal components.
4. Check that the supply voltage matches the unit supply voltage listed on the Unit Serial Plate. Verify that all wiring is secure and properly protected. Trace circuits to insure

that the unit has been wired according to the wiring diagram.

5. Check that fuses or circuit breakers are in place and sized correctly.

Fan Assembly

Direct drive fans include a direct coupled motor. Belt drive fan assemblies include the bearings, drive sheaves, belts, and auto belt tensioner.

For belt driven fans, most bearings are permanently lubricated, except for pillow block bearings or those identified with grease fittings. For blower bearings that are not permanently lubricated, lubricate according to the manufacturer's instructions. Bearings should be checked for any unusual wear and replaced if needed.

For belt driven fans, drive sheaves should be checked at the same time the bearings are inspected. Check to make sure the sheaves are in alignment and are securely fastened to the blower and motor shafts.

Belt should be rechecked shortly after the unit has been installed to check that the belt tension is being maintained by the auto belt tensioner. After the initial start-up, monthly checks are recommended for belt wear.

Electrical Wiring

The electrical wiring should be checked annually for loose connections or deteriorated insulation.

Motors

Most motors require lubrication and are identified as such on the motor nameplate. For motors that are not permanently lubricated, lubrication intervals are recommended by the motor manufacturer based on a number of factors, including motor speed, operating hours, temperature, etc. Lubricate the motor according to the manufacturer's instructions.

Filters

If the unit is supplied with a dirty filter switch, replace the filters any time the Modine Control System controller provides a dirty filter alarm notice.

Units without a dirty filter pressure switch should have the filters checked monthly. Replace if necessary. In dirty atmospheres, filter maintenance may be required more often. Pleat direction must be vertical to ensure optimum performance.

Outdoor Air Sensor, Supply Air Sensor, and Return Air Sensor (if applicable)

1. Remove sensor from mounting bracket.
2. Remove any dust or dirt that may be clogging the screen material covering the air sample inlet openings on the end of the sensor probe. If required, remove the screened tip of the sensor and use a neutral detergent and water solution to clean the screen material. Do not use ethyl alcohol, hydrocarbons, ammonia, or derivatives.

MAINTENANCE - CONTINUED

Cooling Coil Drain Pan and Drain System

The drain pan, trap, and drain pipe must be cleaned regularly to avoid blockage that can reduce or stop water flow as follows:

1. At the beginning of the cooling season, inspect and clean the entire cooling coil cabinet and condensate drain pan to remove contaminants.
 2. Inspect and clean the condensate drain trap and piping. The use of a cleanout opening at the top of the trap (see Figure 8.2) can help facilitate this maintenance.
 3. Fill the trap with water to ensure proper operation and replace the cap on the cleanout opening to close the system.
 4. During the end of cooling season shutdown of the system, disconnect and remove all water from the trap and drain to prevent freeze damage. If local building codes permit, the trap may be filled with an antifreeze solution.
 5. If the unit is used year round, regularly inspect and clean the cooling coil cabinet, condensate drain pan, and trap/drain system to ensure proper function.
 6. Depending on climate, freeze protection of the trap may be required during non-cooling days.
3. The heat exchanger should be checked annually for cracks. If a crack is detected, the heat exchanger should be replaced before the unit is put back into service.
 4. The gas valves and piping should be checked annually for general cleanliness and tightness.
 5. The gas controls should be checked to ensure that the unit is operating properly.
 6. If equipped with the standard efficiency (81%) gas heat option:
 - a. Inspect and clean the condensate drain tray located under the heat exchanger tube openings.
 - b. Inspect and clean the condensate drain tubes located on the end of the drain tray that are routed to the outside of the cabinet. Ensure that the tubes are not kinked or blocked.
 7. If equipped with the hybrid efficiency (D-Cabinet only) or high efficiency (90% or 94%) gas heat option:
 - a. Inspect and clean the condensate drain trap and piping.
 - b. Fill the trap with water to ensure proper operation.
 - c. If a condensate neutralizer tube is installed, recharge per the neutralizer tube manufacturer's instructions.
 - d. Check the condensate overflow switch for cleanliness and proper operation.

Refrigeration System Coil Maintenance

1. Periodically, inspect the coils (evaporator, condenser, and hot gas reheat if applicable) for signs of corrosion and leaks. Repair and replacement of the coil and the connecting piping, valves, etc., must be performed as needed by a qualified technician.
2. Should the coil surface need cleaning, caution should be exercised in selecting the cleaning solution as well as the cleaning equipment. Improper selection can result in damage to the coil and/or health hazards. Cleaning solutions must not be corrosive or cause damage to copper tube/aluminum fin, or all aluminum coils. Clean the coil from the leaving air-side so that foreign material will be washed out of the coil rather than pushed further in. Be sure to carefully read and follow the cleaning fluid manufacturer's recommendations before using any cleaning fluid.

Note: The condenser coil is constructed of aluminum materials and contains refrigerant under high pressure. Do not use acidic solutions to clean the coil, as it could lead to corrosion.

Inlet Hood

If the unit is equipped with an outside air inlet hood, check to ensure the inlet screen behind the hood is clean and free of debris.

Duct Furnace

When providing annual maintenance for the duct furnace, keep the unit free from dust, dirt, grease and foreign matter. Pay particular attention to:

1. The power exhauster discharge opening and the combustion air inlet louvers.
 2. The main burner orifices (avoid the use of hard, sharp instruments capable of damaging surfaces for cleaning these orifices). To check the main burner orifices, see Manifold Assembly Removal section on the next page.
1. Shut off gas and electric supply.
 2. Open the duct furnace control access compartment doors.
 3. Disconnect gas manifold at ground union joint.
 4. Remove the screws holding the manifold to the heat exchanger support.
 5. Slide the manifold through the manifold bracket.
 6. Clean the orifices as necessary.
 7. Slide the manifold back into the manifold bracket and reinstall the screws that hold the manifold to the heat exchanger support.
 8. Reconnect the gas line to the manifold at the ground joint union.
 9. Turn on the electric and gas supply.
 10. Check the ground union joint for leaks with a soap solution. Tighten if necessary.
 11. Close the duct furnace control access compartment doors.

Manifold Assembly Removal

MAINTENANCE - CONTINUED

Hot Water Heat Coil Maintenance

If the unit is supplied with a factory installed hot water heat coil, check the following:


1. Periodically, inspect the coils for signs of corrosion and leaks. Repair and replacement of the coil and the connecting piping, valves, etc., must be performed as needed by a qualified technician.
2. **For cleaning the external surface of the coil and fins with compressed air and/or vacuum:** The coil can remain in the unit or be removed. Use compressed air blown into the leaving air side of the coil and/or vacuum from the entering air side of the coil to avoid pushing foreign material further into the coil.
3. **For cleaning the external surface of the coil and fins with a cleaning solution:** The coil must be removed from the unit. Caution should be exercised in selecting the cleaning solution as well as the cleaning equipment. Improper selection can result in damage to the coil and/or health hazards. Cleaning solutions must not be corrosive or cause damage to copper tube/aluminum fin coils. Be sure to carefully read and follow the cleaning fluid manufacturer's recommendations before using any cleaning fluid.
4. Maintain the circulated fluid free of sediment, corrosive products and biological contaminants. Periodic testing of the fluid followed by any necessary corrective measures along with maintaining adequate fluid velocities and proper filtering of the fluid is required.

Hot Water Freeze Stat

If the unit is supplied with a factory installed hot water coil freeze stat, check the following:

1. Disconnect the control wiring from the freeze stat terminals.
2. Remove the screws holding the freeze stat side access panel. Refer to Figure 50.1.

Figure 50.1 - Optional Factory Installed Hot Water Coil Freeze Stat



3. Slide the freeze stat assembly out.
4. Examine the freeze stat capillary for cleanliness and/or obstructions as necessary. Ensure the capillary has no kinks or breaks (replace if either of these conditions is present).
5. Replace the freeze stat assembly in reverse order. In replacing the assembly, be certain that the capillary support frame is properly located and supported. Do not force the side access panel. It will not fit if the frame is not properly aligned.
6. Reconnect the control wiring to the freeze stat terminals.

Energy Recovery Exhaust Assembly

If the unit is equipped with a Modine supplied Energy Recovery Exhaust section, check the following:

1. The energy recovery wheel drive belt is subject to natural stretching which may affect wheel rotation and energy recovery performance. The belt should be checked periodically, especially within the first 400 hours of operation. If too loose, the belt must be shortened by removing the belt from the drive motor pulley, remove the belt linkage using a small Phillips head screwdriver, cut the belt to the required length, and reattach the belt linkage and tighten.
2. The bearings are permanently lubricated and under normal operating conditions maintenance is not required.
3. The wheel is to be checked for cleanliness. In most cases, the counterflow airflow will allow the rotary wheel to self-clean itself of contaminants that may adhere to the surface of the wheel. In situations where self-cleaning is not sufficient, the wheel can be cleaned with compressed air or high pressure water (room temperature water only). To clean the wheel, slide the wheel housing out of the unit casing. Apply the air or water jet evenly and at right angles to the wheel, being careful not to get any water on the inside of the unit casing. Use care not to damage the wheel physically and do not use chemicals.
4. Check wheel to housing seals and replace if worn.

Energy Recovery Wheel Electric Preheat

When providing annual maintenance for the electric preheat (if equipped), keep the unit free from dust, dirt, grease and foreign matter. Pay particular attention to:

1. The heating elements should be checked annually for cracks and discoloration. If a crack is detected, the heating elements should be replaced before the unit is put back into service. If the elements are dark gray, airflow across the heating elements should be checked to ensure that a blockage has not occurred or the blower is operating properly.
2. The electrical connections should be checked annually for general cleanliness and tightness.
3. The controls should be checked to ensure that the unit is operating properly.

Repeat Start-Up Procedure

Once complete, repeat applicable Start-Up Procedure steps as shown starting on page 16.

SERVICE & TROUBLESHOOTING

WARNING

When servicing or repairing this equipment, use only factory-approved service replacement parts which may be obtained by contacting Modine Manufacturing Company. Refer to the rating plate on the unit for complete unit model number, serial number, and company address. Any substitution of parts or controls not approved by the factory will be at the owner's risk.

CAUTION

Do not reuse any mechanical or electrical components which has been wet. Such component must be replaced.

IMPORTANT

Start-up and adjustment procedures must be performed by a qualified service agency.

To check most of the Possible Remedies in the troubleshooting guide on the following pages, refer to the applicable sections of this manual. The troubleshooting tables are as follows:

- Tables 51.1 and 52.1 - Main Unit
- Tables 54.1 and 55.1 - Gas Heat Option with furnace model Digit 11=6 or 8.

Table 51.1 - Troubleshooting

Trouble	Possible Cause	Possible Remedy
A. Power Failure	1. Disconnect not turned on.	1. Turn on disconnect switch
	2. Blown fuses or open circuit breaker	2. Check and replace or reset
	3. Main power supply for unit turned off	3. Turn on power at main panel
B. Motor Failure	1. See Problem "A"	1. See Problem "A"
	2. Failed motor	2. Check and replace
	3. Loose wiring to motor	3. Check and tighten
	4. Motor overloaded	4. Reset motor starter and check motor load
	5. Improper supply voltage	5. Check and correct
C. Blower Not Turning or Turns Slow	1. See Problems "A" and "B"	1. See Problems "A" and "B"
	2. Broken drive belt	2. Check and replace
	3. Motor undersized for application	3. Contact Factory
	4. Motor voltage too low	4. Check and correct
	5. Supply power line sizing too small	5. Check and correct
	6. Controls are in Unoccupied mode	6. Wait for Occupied mode or override
	7. Controller alarm	7. Check and correct
	8. Blower door open	8. Close the door
D. Insufficient Airflow	1. Motor running backwards	1. Check and correct motor wiring to phase rotation of supply power, reverse any two lines to motor
	2. Fan speed setting too low	2. Check and correct
	3. Dirty or clogged filters or coils	3. Check and clean or replace
	4. Duct system has more static pressure drop than expected	4. Check and correct
	5. Lack of straight duct at unit discharge outlet	5. Install straight duct at discharge outlet, as outlined in the Duct Installation section of this Manual or contact Factory
	6. Dampers and/or discharge registers are closed	6. Check and correct
E. Excessive Airflow	1. Fan speed setting too high	1. Check and correct
	2. Filters not in place	2. Check and reinstall filters
	3. Ductwork grilles or registers not installed	3. Check and install
	4. Duct system has less static pressure drop than expected	4. Check and correct
	5. Access door is open	5. Close all unit side access doors

SERVICE & TROUBLESHOOTING - CONTINUED

Table 52.1 - Troubleshooting (Continued)

Trouble	Possible Cause	Possible Remedy	
F. Compressor(s) Do Not Operate	1. See Problems "A" and "B"	1. See Problems "A" and "B"	
	2. Controls are in Unoccupied mode	2. Wait for Occupied mode or override	
	3. Ambient lockout	3. Check and wait or override	
	4. Low pressure lockout	4. Check and wait or override	
	5. High pressure lockout	5. Check and wait or override	
	6. Inter-stage delay	6. Check and wait or override	
	7. Airflow proving switch not closing	7. Check and correct	
	8. Thermostat not calling for cooling	8. Check and wait or override	
	9. Drain pan float switch open	9. Check switch, check drain line (pan, trap, piping) for proper drainage, and verify trap is primed with water	
G. Compressor(s) Do Not Cycle Off	1. Supply air temperature not satisfied	1. Compressors will remain on until the supply air setpoint is satisfied	
H. Dampers Do Not Operate	1. See Problem "A"	1. See Problem "A"	
	2. Failed damper motor(s)	2. Check and replace	
	3. Loose wiring to damper motor(s)	3. Check and tighten	
	4. Controls are in Unoccupied mode	4. Wait for Occupied mode or override	
	5. Ambient lockout	5. Check and wait or override	
I. Electric Heat Not Functioning	1. See Problem "A"	1. See Problem "A"	
	2. See Problem "D"	2. See Problem "D"	
	3. Thermostat not calling for heat	3. Check and wait or override	
	4. Limit switches are open	4. Check and correct	
	5. Overload relay is tripped	5. Check and correct	
	6. Failed heat modules	6. Check and replace	
J. Gas Heat Not Functioning Properly	1. See Problem "A"	1. See Problem "A"	
	2. See Problem "D"	2. See Problem "D"	
	3. Thermostat not calling for heat	3. Check and wait or override	
	4. Limit switches are open	4. Check and correct	
	5. Main gas supply not turned on	5. Check and correct	
	6. Air in gas line	6. Purge per instructions	
	7. Loose wiring to ignition controls or gas valves	7. Check and tighten	
	8. Failed ignition controller or gas valve	8. Check and replace	
	9. Failed flame sensor	9. Check and replace	
	10. Improper supply air temperature sensor installation	10. Check and correct	
	11. Flame rollout or flashback	11a. Main pressure too high (correct to 14" W.C. max)	
		11b. Orifice too large (verify they match the serial plate)	
		11c. Manifold pressure too low (reset)	
	12. Not enough heat	12a. Unit cycling on high limit (check airflow)	
12b. Main pressure too low (must be 6" W.C. minimum)			
12c. Unit undersized for conditions			
12d. Improper supply air temperature sensor installation			
13. Too much heat	13a. Manifold pressure too high (correct to 3.5" W.C.)		
	13b. Defective or improperly wired controls		
14. Clogged condensate drain line (94% and 90% gas heat option only)	14. Check condensate drain line, clear as required.		

PAGE INTENTIONALLY LEFT BLANK

SERVICE & TROUBLESHOOTING - CONTINUED

Table 54.1 - Furnace Master Control Board (VB1200) Error Codes

(Applies to B-, C-, and D-Cabinet Units with Gas Heat Option furnace model number Digit 11=6 or 8) ①

Display Code	Description	Additional comments and notes
888	Board Failure (<i>Up to 10 sec @ power up</i>)	Verify 24 VAC signal input at connector J6.
Off	UP Mode: Burner state = Off	Normal Operation
Pur	UP Mode: Burner state = Purge	
Ign	UP Mode: Burner state = Ignition	
HEA	UP Mode: Burner state = Warmup	
Run	UP Mode: Burner state = Run	
rEt	UP Mode: Burner state = Retry (<i>with A01 or A02</i>)	Retry delay following either a failed ignition or a flame loss.
A01	Failed ignition attempt	
A02	Lost Flame	Ignition was successful but then flame disappeared.
A03	Insufficient Combustion Air	Blocked vent with actuator position de-rated by >20% from FRI setting.
A04	Limited Low Fire (<i>due to Lost Flame Auto-Adaptation</i>)	Flame loss at low fire results in an auto-adjustment limit of the burner turndown by adjusting the minimum modulation voltage during the rest of the current cycle or until a CPU reset.
A05	Weak Flame Signal	Flame presence signal of less than 1.5µA indicates an aged flame rod.
A06	No Low Fire Mode (<i>due to Hi Gas Pressure at Low Fire</i>)	The Gas Pressure is not modulating down to low fire.
A07	Loss of Inducer Motor Control	The Air Pressure is not modulating down at minimum inducer drive.
A08	Air Sensor Null Pressure Check out-of-tolerance	The Air Pressure sensor zero reading appears to be out-of-tolerance.
A99	COM Error – Slaves	CRC errors, serial bus loaded down or possibly poor cable/routing.
E01	Failed Ignition	Four failed ignition attempts have occurred.
E02	Primary Limit Failure	Verify Primary Limit input at connector J8 and fuse at F1.
E03	Modulation Valve Failure	The Valve Actuator did not reach a Park or Full On position.
E04	Air Sensor Failure - <i>Pressure Reading Low</i>	Includes air switch failure to open during pre-purge switch check, includes insufficient air lockout due to blocked vent.
E05	Air Sensor Failure - <i>Pressure Reading High</i>	Includes air switch failure to close during pre-purge switch check.
E06	Gas Sensor Failure - <i>Pressure Reading Low</i> (<i>Possible modulating valve actuator misalignment</i>)	Verify Gas Pressure Sensor signal input at connector J13.
E07	Gas Sensor Failure - <i>Pressure Reading High</i> (<i>Possible modulating valve actuator misalignment</i>)	Significant Gas Pressure detected during the Off burner state.
E08	Improper Flame	
E09	No Firing Rate Input	The thermostat “W” input is calling for heat but the FRI is < 2.0 V.
A20	Slave Furnace A COM Missing	Loss of a previously established serial communication link.
A21	Slave Furnace A Lockout	Refer to VB1201 slave board diagnostics table.
A30	Slave Furnace B COM Missing	Loss of a previously established serial communication link.
A31	Slave Furnace B Lockout	Refer to VB1201 slave board diagnostics table.
A40	Slave Furnace C COM Missing	Loss of a previously established serial communication link.
A41	Slave Furnace C Lockout	Refer to VB1201 slave board diagnostics table.
Eid	Invalid I.D. Plug Installed	

① To clear furnace control board error codes, refer to the section “Clearing Furnace Control Board Error Codes” on page 23.

SERVICE & TROUBLESHOOTING - CONTINUED

Table 55.1 - Furnace Slave Control Board (VB1201) Error Codes

(Applies only to C- and D-Cabinet Units with Gas Heat Option furnace model number Digit 11=8) ①

Color	Flashes	Condition
Error Conditions		
N/A	Off	No power to the control board
Red	Steady On	Hard lockout on control fault or no 24 VAC.
	1	Insufficient inducer air pressure when inducer is on.
	2	Inducer air pressure is too high when inducer is off.
	3	Flame circuitry failure - flame is on when it should be off or it is off when it should be on.
	4	Gas valve failure.
	5	Gas valve safety relay failure.
	6	Reserved
	7	Primary limit failure
	8	Gas valve in test mode
	9	Safety startup failed to validate inducer air path.
Normal and Warning Conditions		
Green	Slow	Standby - no communication link established
	Rapid	Standby - in communication with Bus Master
	1	Call for heat, no gas
	2	Call for heat, gas
Yellow	2	Call for heat, gas, flame rod aged
	Rapid	Retry

MODEL IDENTIFICATION & SERIAL PLATES/NUMBERS

Model Identification

Depending on options included, the unit may have more than one Serial Plate. Figure 56.1 shows the Serial Plate for the main unit, while Figure 56.2 shows the Serial Plate for the gas heat option. When servicing, repairing or replacing parts on these units, locate the model Serial Plate of the unit and always give the complete Model Number and Serial Number of the unit. The Serial Plate is located on the door of the controls cabinet. For a complete description of the model number, see the Model Nomenclature on pages 57-59. Serial plates shown are examples and may vary slightly from what is on the actual unit(s). Refer to the unit(s) for the actual serial plates.

Figure 56.1
Serial Plate Example - B & C-Cabinet Units


Modine Manufacturing Company 1500 DeKoven Avenue Racine, WI 53403-2552 Phone: 800-828-4328		PACKAGED ROOF TOP COMMERCIAL UNIT FOR OUTDOOR INSTALLATION FOR OPTIONAL HEATING AND ERM SECTION SEE SECTION SERIAL PLATE FOR MORE INFORMATION.		 Intertek 9900100 DESIGN CONFORMS TO: UL STD 1995 CERTIFIED TO CAN/CSA C22.2 NO. 236 APPROVED FOR USE BY THE CEC			
MODEL NUMBER MPR30CE1A1ASU16K1DNDNNNN	VOLTS 460	PHASE 3	HERTZ 60	WIRE DIAGRAM 8H001234-1234			
CIRCUIT # 106.8	MIN. CIRCUIT AMP(S) 110.0	MAX. CIRC. BRK. (AMP) 125	UNIT SETTINGS SUPPLY FAN RPM 1825 EXT. STATIC 1.23 inH ₂ O SUPPLY FAN CFM 3000 HEAT MAX OUTLET °F 120 HEAT ATR °F 54.3	SHUT DOWN INSTRUCTIONS (1) TURN OFF ALL POWER. (2) CLOSE ANY GAS OR WATER VALVES.			
CIRCUIT # 106.8	MIN. CIRCUIT AMP(S) 110.0	MAX. CIRC. BRK. (AMP) 125	UNIT SETTINGS SUPPLY FAN RPM 1825 EXT. STATIC 1.23 inH ₂ O SUPPLY FAN CFM 3000 HEAT MAX OUTLET °F 120 HEAT ATR °F 54.3	SHUT DOWN INSTRUCTIONS (1) TURN OFF ALL POWER. (2) CLOSE ANY GAS OR WATER VALVES.			
MOTORS (OPER MOTOR)	QTY.	HP	VOLTS	FLA	RPM	RLA	LRA
COMPRESSOR (MOD)	1		460		26.9	173	
COMPRESSOR (FIXED)	1		460		26.9	173	
SUPPLY FAN	1	5.0	460	7.6	1800		
CONDENSER FAN	3	1.5	460	2.7	1200		
POWER EXH. (OPT.)	N/A						
ERM WHEEL (OPT.)	1	0.5	460	0.5	1700		
ERM BLOWER (OPT.)	1	3	460	4.8	1800		
GAS FURNACE (OPT.)	N/A						
SHORT CIRCUIT CURRENT: 50A RMS SYMMETRICAL 480V MAXIMUM PER UL STD 1995, OUTLET AIR TEMPERATURE SHALL NOT EXCEED 200°F							
ELECTRIC HEAT							
ERM FREHEAT (OPT.)	N/A						
MAIN HEAT (OPT.)	460	94	75				
AUX. HEAT (OPT.)	N/A						
HOT WATER HEAT (OPT.)							
MAX. WATER TEMP. (°F)	N/A						
OPERATING PRES. (psig)	N/A						
REPLACEMENT PARTS AND SERVICE: For parts ordering, contact the parts wholesaler or the manufacturer's representative serving your area. When inquiring about parts, always provide model number, serial number, description, and any S/N number. For service, contact your local qualified installation and service contractor or appropriate utility company.							

Figure 56.2
Serial Plate Example - D-Cabinet Unit


Modine Manufacturing Company 1500 DeKoven Avenue Racine, WI 53403-2552 Phone: 800-828-4328		PACKAGED ROOF TOP COMMERCIAL UNIT FOR OUTDOOR INSTALLATION FOR OPTIONAL HEATING AND ERM SECTION SEE SECTION SERIAL PLATE FOR MORE INFORMATION.		 Intertek 9900100 DESIGN CONFORMS TO: UL STD 1995 CERTIFIED TO CAN/CSA C22.2 NO. 236 APPROVED FOR USE BY THE CEC			
MODEL NUMBER MPR40DA3D1ECX15S1DNDNNNN	VOLTS 230	PHASE 3	HERTZ 60	WIRE DIAGRAM 8H001234-1234			
CIRCUIT # 375.5	MIN. CIRCUIT AMP(S) 375.5	MAX. CIRC. BRK. (AMP) 400	UNIT SETTINGS SUPPLY FAN RPM 1825 EXT. STATIC 1.23 inH ₂ O SUPPLY FAN CFM 3000 HEAT MAX OUTLET °F 120 HEAT ATR °F 54.3	SHUT DOWN INSTRUCTIONS (1) TURN OFF ALL POWER. (2) CLOSE ANY GAS OR WATER VALVES.			
CIRCUIT # 375.5	MIN. CIRCUIT AMP(S) 375.5	MAX. CIRC. BRK. (AMP) 400	UNIT SETTINGS SUPPLY FAN RPM 1825 EXT. STATIC 1.23 inH ₂ O SUPPLY FAN CFM 3000 HEAT MAX OUTLET °F 120 HEAT ATR °F 54.3	SHUT DOWN INSTRUCTIONS (1) TURN OFF ALL POWER. (2) CLOSE ANY GAS OR WATER VALVES.			
MOTORS (OPER MOTOR)	QTY.	HP	VOLTS	FLA	RPM	RLA	LRA
COMPRESSOR (MOD)	1		230		33.3	239	
COMPRESSOR (FIXED)	3		230		33.3	239	
SUPPLY FAN	1	15	230	42	1800		
CONDENSER FAN	4	1	230	7.4	1200		
POWER EXH. (OPT.)	N/A						
ERM WHEEL (OPT.)	N/A						
ERM BLOWER (OPT.)	N/A						
GAS FURNACE (OPT.)	N/A						
SHORT CIRCUIT CURRENT: 50A RMS SYMMETRICAL 230V MAXIMUM PER UL STD 1995, OUTLET AIR TEMPERATURE SHALL NOT EXCEED 200°F							
ELECTRIC HEAT							
ERM FREHEAT (OPT.)	N/A						
MAIN HEAT (OPT.)	230	376	150				
AUX. HEAT (OPT.)	N/A						
HOT WATER HEAT (OPT.)							
MAX. WATER TEMP. (°F)	N/A						
OPERATING PRES. (psig)	N/A						
REPLACEMENT PARTS AND SERVICE: For parts ordering, contact the parts wholesaler or the manufacturer's representative serving your area. When inquiring about parts, always provide model number, serial number, description, and any S/N number. For service, contact your local qualified installation and service contractor or appropriate utility company.							

Figure 56.3
Serial Plate Example - B-Cabinet Furnace



Modine Manufacturing Company 1500 DeKoven Avenue Racine, WI 53403-2552 Phone: 800-828-4328		OUTDOOR GAS-FIRED DUCT FURNACE FOR INDUSTRIAL / COMMERCIAL USE CHAUDIERE A GAZ A CONDUIT FOUR EXTERIEUR / POUR USAGE INDUSTRIEL/COMMERCIAL		 Intertek 9900100 DESIGN CONFORMS TO: UL STD 1995 CERTIFIED TO CAN/CSA C22.2 NO. 236 APPROVED FOR USE BY THE CEC	
MODEL NUMBER FSP0150SSN6L0A	INPUT RATING 30000	MIN. INPUT PRESS. FOR PURPOSE OF INPUT ADJUSTMENT / PRESSION MIN. D'ALIMENTATION EN GAZ MIN. ADJUSTE	6	IN W.C. PO. CD E.	
SERIAL NUMBER 11051413-1033	MAX. INPUT PRESS. FOR PURPOSE OF INPUT ADJUSTMENT / PRESSION MAX. D'ALIMENTATION EN GAZ MAX. ADJUSTE	3.5	IN W.C. PO. CD E.		
TYPE OF GAS NAT. GAS	MIN. MAINTFOLD PRESSURE PRESSION A LA TUBERIE D'ALIMENTATION	0.2	IN W.C. PO. CD E.		
TEMPERATURE RISE RANGE ELEVATION DE TEMPERATURE	30-70 °F	MIN. MAINTFOLD PRESSURE PRESSION A LA TUBERIE D'ALIMENTATION MIN	0.25	IN W.C. PO. CD E.	
0 TO 2000 FT. 0 ET 610 M.	(IN CANADA) 2000 TO 4600 FT. 610 ET 1370 M.	AIR THROUGHPUT DEBIT D'AIR	4	IN W.C. PO. CD E.	
INPUT BTU/H DEBIT CALORIFIQUE BTU/HEURE	1500000	MAXIMUM EXTERNAL STATIC PRESSURE PRESSION STATIQUE EXTERIEUR MAXIMUM	4	IN W.C. PO. CD E.	
OUTPUT BTU/H RENDREMENT BTU/HEURE	121500	MAX. VOLTS	120	PHASE	1
ORIFICE SIZE DIM. DE L'INJECTEUR	#44	HERTZ	60	AMPS	2.2
TAG	0	GENERAL: 1. FOR OUTDOOR INSTALLATIONS ONLY. 2. MINIMUM AMBIENT TEMPERATURE -40°F. 3. FOR INSTALLATION DOWNSTREAM OF REFRIGERATION SYSTEMS. 4. INSTALL ON THE POSITIVE PRESSURE SIDE OF AIR CIRCULATING BLOWER. 5. FOR UNITS WITH MANUAL RESET HIGH LIMIT SWITCH, RESET BUTTON IS LOCATED IN ELECTRICAL JUNCTION BOX. 6. (IN USA) FOR INSTALLATIONS ABOVE 2000 FEET DEBATE 4 PERCENT FOR EACH 1000 FEET OF ELEVATION ABOVE SEA LEVEL.			
RECOMMENDED SERVICE CLEARANCE / RECOMMANDATION DE SERVICE RECOMMENDE ACCESS SIDE 48 IN / COTE D'ACCES 6 IN					
COMMON REPLACEMENT PARTS For parts ordering, contact the parts wholesaler or the manufacturer's representative serving your area. When inquiring about parts, always provide model number, serial number, description, and part number. When ordering parts, provide part number listed. For service, contact your local qualified installation and service contractor or appropriate utility company.					

Figure 56.4
Serial Plate Example - C & D-Cabinet Furnaces

Modine Manufacturing Company 1500 DeKoven Avenue Racine, WI 53403-2552 Phone: 800-828-4328		OUTDOOR GAS-FIRED DUCT FURNACE FOR INDUSTRIAL / COMMERCIAL USE CHAUDIERE A GAZ A CONDUIT FOUR EXTERIEUR / POUR USAGE INDUSTRIEL/COMMERCIAL		 Intertek 9900100 DESIGN CONFORMS TO: UL STD 1995 CERTIFIED TO CAN/CSA C22.2 NO. 236 APPROVED FOR USE BY THE CEC	
MODEL NUMBER FQP1600SSN8H0A	INPUT RATING 100000	MIN. INPUT PRESS. FOR PURPOSE OF INPUT ADJUSTMENT / PRESSION MIN. D'ALIMENTATION EN GAZ MIN. ADJUSTE	6	IN W.C. PO. CD E.	
SERIAL NUMBER 11051413-1037	MAX. INPUT PRESS. FOR PURPOSE OF INPUT ADJUSTMENT / PRESSION MAX. D'ALIMENTATION EN GAZ MAX. ADJUSTE	3.5	IN W.C. PO. CD E.		
TYPE OF GAS NAT. GAS	MIN. MAINTFOLD PRESSURE PRESSION A LA TUBERIE D'ALIMENTATION	0.25	IN W.C. PO. CD E.		
TEMPERATURE RISE RANGE ELEVATION DE TEMPERATURE	70-120 °F	MIN. MAINTFOLD PRESSURE PRESSION A LA TUBERIE D'ALIMENTATION MIN	0.25	IN W.C. PO. CD E.	
0 TO 2000 FT. 0 ET 610 M.	(IN CANADA) 2000 TO 4600 FT. 610 ET 1370 M.	AIR THROUGHPUT DEBIT D'AIR	4	IN W.C. PO. CD E.	
INPUT BTU/H DEBIT CALORIFIQUE BTU/HEURE	1600000	MAXIMUM EXTERNAL STATIC PRESSURE PRESSION STATIQUE EXTERIEUR MAXIMUM	4	IN W.C. PO. CD E.	
OUTPUT BTU/H RENDREMENT BTU/HEURE	1296000	MAX. VOLTS	120	PHASE	1
ORIFICE SIZE DIM. DE L'INJECTEUR	#44	HERTZ	60	AMPS	5.2
TAG	0	GENERAL: 1. FOR OUTDOOR INSTALLATIONS ONLY. 2. MINIMUM AMBIENT TEMPERATURE -40°F. 3. FOR INSTALLATION DOWNSTREAM OF REFRIGERATION SYSTEMS. 4. INSTALL ON THE POSITIVE PRESSURE SIDE OF AIR CIRCULATING BLOWER. 5. FOR UNITS WITH MANUAL RESET HIGH LIMIT SWITCH, RESET BUTTON IS LOCATED IN ELECTRICAL JUNCTION BOX. 6. (IN USA) FOR INSTALLATIONS ABOVE 2000 FEET DEBATE 4 PERCENT FOR EACH 1000 FEET OF ELEVATION ABOVE SEA LEVEL.			
RECOMMENDED SERVICE CLEARANCE / RECOMMANDATION DE SERVICE RECOMMENDE ACCESS SIDE 48 IN / COTE D'ACCES 6 IN					
COMMON REPLACEMENT PARTS For parts ordering, contact the parts wholesaler or the manufacturer's representative serving your area. When inquiring about parts, always provide model number, serial number, description, and part number. When ordering parts, provide part number listed. For service, contact your local qualified installation and service contractor or appropriate utility company.					

	LEFT	RIGHT
HEAT EXCHANGER DESCRIPTION	SLAVE A	SLAVE B
INPUT BTU/H DEBIT CALORIFIQUE BTU/HEURE	0 TO 2000 FT. 0 ET 610 M. 40000	0 TO 2000 FT. 0 ET 610 M. 40000
ORIFICE SIZE DIM. DE L'INJECTEUR	#36	#36
HEAT EXCHANGER DESCRIPTION	SLAVE C	MASTER
INPUT BTU/H DEBIT CALORIFIQUE BTU/HEURE	0 TO 2000 FT. 0 ET 610 M. 40000	0 TO 2000 FT. 0 ET 610 M. 40000
ORIFICE SIZE DIM. DE L'INJECTEUR	#36	#36

MODEL NOMENCLATURE

Model Nomenclature

As noted in the previous section, units may have more than one Serial Plate. If the unit has the gas heat option, the furnace will have its own model number separate from the main unit.

- Table 57.1 shows the nomenclature for the gas heat section option.
- Tables 58.1 and 59.1 on the following pages show the nomenclature for the main unit.

Table 57.1 - Model Nomenclature - Gas Furnace Option for Model MPR

Digits	Indicates	Description	Value	Cabinet		
				B	C	D
1,2,3	Furnace Model Prefix	Single, Standard Efficiency	FSP	•		
		Single, High Efficiency Condensing	FSC			
		Dual, Standard Efficiency	FMP		•	
		Dual, High Efficiency Condensing	FMC			
1,2,3	Furnace Model Prefix	Dual, Standard Efficiency	FDP			•
		Quad, Standard Efficiency	FQP			
		Quad, High Efficiency Hybrid	FQH			
		Dual, High Efficiency Condensing	FDC			
4,5,6,7	Furnace Input Rating	0150 - 150,000 Btu/hr thru 1600 - 1,600,000 Btu/hr	See Next Column	See Unit Nomenclature		
8	Heat Exchanger	409 Stainless Steel Heat Exchanger	S	•	•	•
9	Ignition System	Direct Spark Ignition	S	•	•	•
10	Gas Type	Natural Gas	N	•	•	•
11	Modulating Capacity Control	Gas Only, Multiple	4		•	
		Gas & Power Exhaust, Single	6	•		
		Gas and Power Exh Master, Staged Slave(s)	8		•	•
12	Air Temperature Rise	High Air Temperature Rise	H	•	•	•
		Low Air Temperature Rise	L			
		Not Applicable	N			
13	Not Used	Not Currently Used	0	•	•	•
14	Furnace Supply Voltage	115V/1ph (transformer from main supply voltage)	A	•	•	•

(Continued on next page)

MODEL NOMENCLATURE - MODEL MPR

Table 58.1 - Model Nomenclature - Main Unit

Digits	Indicates	Description	Value	Cabinet				
				B	C	D		
1, 2, 3	Unit Type	Commercial Packaged Ventilation Unit	MPR	•	•	•		
4, 5	Unit Nominal Cooling	7, 10, or 13 ton	07, 10, 13	•	•	•		
		15 or 20 ton	15, 20	•	•	•		
		26 ton	26	•	•	•		
		30 ton	30	•	•	•		
6	Cabinet Size	40, 52, or 60 ton	40, 52, 60	•	•	•		
		Refer to Dimensions	B, C, D	•	•	•		
7	Air Control Configuration	OA & RA Dampers	No Exhaust	A	•	•	•	
			Energy Recovery Exhaust	B	•	•	•	
			Power Exhaust	C	•	•	•	
		OA Dampers (No RA)	No Exhaust	D	•	•	•	
			Energy Recovery Exhaust	E	•	•	•	
			Power Exhaust	F	•	•	•	
8	Evaporator Coil	High Capacity 4 Row, 14fpi DX Coil	No E-Coat	1	•	•	•	
			With E-Coat	2	•	•	•	
		High Capacity 6 Row, 14fpi DX Coil	No E-Coat	3	•	•	•	
			With E-Coat	4	•	•	•	
9	Compressor Staging	Tandem Digital Scroll (Digital Modulating + On/Off) (10-30 ton units)	A	•	•	•		
		Single Digital Scroll (Modulating Digital) (7 ton units only)	B	•	•	•		
		Dual Tandem Digital Scroll [(Digital Modulating - On/Off) & (On/Off - On/Off)]	D	•	•	•		
10	Hot Gas Reheat	No Hot Gas Reheat	0	•	•	•		
		Modulating Hot Gas Reheat	1	•	•	•		
		Modulating Hot Gas Reheat with E-Coat	2	•	•	•		
11	Condensator Arrangement	VFD Head Pressure Control	Microchannel Coils	A	•	•	•	
			Microchannel Coils with E-Coat (UV)	B	•	•	•	
		Modulating EC Motor Head Pressure Control	Microchannel Coils	E	•	•	•	
			Microchannel Coils with E-Coat (UV)	F	•	•	•	
12	Supply Blower Configuration	Wheel Size (inches)	Belt Drive ①	Direct Drive				
			ANPA ②	ANPL ②	ANPA ②	ANPL ②		
		11	-	1	-	K	•	•
		12	-	-	4	L	•	•
		14	-	-	7	M	•	•
		16	2	-	8	N	•	•
		20	3	-	A	Q	•	•
		25	5	-	C	S	•	•
		28	6	-	-	-	•	•
		16 Dual	-	-	E	U	•	•
25 Dual	-	-	J	Y	•	•		
13	Supply Blower Motor HP ③	1 HP	C or Q	•	•	•		
		1-1/2 HP	D or R	•	•	•		
		2 HP	E or S	•	•	•		
		3 HP	F or T	•	•	•		
		5 HP	G or U	•	•	•		
		7-1/2 HP	H or V	•	•	•		
		10 HP	J or W	•	•	•		
		15 HP	K or X	•	•	•		
20 HP	L or Y	•	•	•				
14	Blower Motor Type	Supply Fan Motor	Exhaust Fan Motor					
		ODP 1800 RPM	1800 RPM or N/A	1	•	•	•	
		ODP 3600 RPM	1800 RPM or N/A	A	•	•	•	
		ODP 1200 RPM	1800 RPM or N/A	G	•	•	•	
		TE 1800 RPM	1800 RPM or N/A	2	•	•	•	
		TE 3600 RPM	1800 RPM or N/A	B	•	•	•	
		TE 1200 RPM	1800 RPM or N/A	H	•	•	•	
15	Unit Supply Voltage	208V/3ph	4	•	•	•		
		230V/3ph	5	•	•	•		
		460V/3ph	6	•	•	•		
		575V/3ph (not available on 52/60 ton D-Cabinet)	7	•	•	•		
16	Power Options	Deadfront Disconnect	Convenience Outlet					
		None	None	N	•	•	•	
			Power by Others	Z	•	•	•	
		60A	None	D	•	•	•	
			Unit Powered	E	•	•	•	
		100A	Power by Others	F	•	•	•	
			None	G	•	•	•	
		200A	Unit Powered	H	•	•	•	
			Power by Others	J	•	•	•	
		400A	None	K	•	•	•	
			Unit Powered	L	•	•	•	
		600A	Power by Others	M	•	•	•	
			None	P	•	•	•	
		600A	Unit Powered	Q	•	•	•	
Power by Others	R		•	•	•			
600A	None	S	•	•	•			
	Unit Powered	T	•	•	•			
600A	Power by Others	U	•	•	•			

MODEL NOMENCLATURE - MODEL MPR - CONTINUED

Table 59.1 - Model Nomenclature - Main Unit (Continued from previous page)

Digits	Indicates	Description	Value	Cabinet		
				B	C	D
17	Heating Section Type	None	0	•	•	•
		Electric	1	•	•	•
		Natural Gas	2	•	•	•
		Natural Gas with 20kW (nominal) Aux/Supplemental Electric Heat	3	•	•	•
		Natural Gas with 40kW (nominal) Aux/Supplemental Electric Heat	3			•
		Hot Water (C-Cabinet Only)	4			
18	Nominal Heat Capacity	No Heating	N	•	•	•
		20kW Electric - (derate for 208V/3ph)	A	•	•	
		40kW Electric - (derate for 208V/3ph)				•
		40kW Electric - (derate for 208V/3ph)			•	•
		80kW Electric - (derate for 208V/3ph)	B			•
		60kW Electric - (derate for 208V/3ph)			•	•
		120kW Electric - (derate for 208V/3ph)	C			•
		80kW Electric - (derate for 208V/3ph)			•	•
		160kW Electric - (derate for 208V/3ph)	D			•
		100kW Electric - (derate for 208V/3ph)			•	•
		200kW Electric - (derate for 208V/3ph)	E			•
		150 MBH Gas - 80%			•	
		200 MBH Gas - 80%	F			
		250 MBH Gas - 80%	G			
		300 MBH Gas - 80%	H			
		400 MBH Gas - 80%	J		•	
		500 MBH Gas - 80%	K		•	•
		600 MBH Gas - 80%	L		•	•
		620 MBH Gas - 90%	M			•
		800 MBH Gas - 80%	P			•
		800 MBH Gas - 80%	Q			•
		175 MBH Gas - 94%	R		•	
		225 MBH Gas - 94%	S		•	
		310 MBH Gas - 94%	T		•	
		350 MBH Gas - 90%	U			•
		450 MBH Gas - 90%	V			•
		900 MBH Gas - 80%	1			•
		1000 MBH Gas - 80%	2			•
		1200 MBH Gas - 80%	3			•
		1400 MBH Gas - 80%	4			•
		1600 MBH Gas - 80%	5			•
		850 MBH Gas - 86%	6			•
		950 MBH Gas - 86%	7			•
		1220 MBH Gas - 86%	8			•
1420 MBH Gas - 86%	9			•		
19	Temperature Rise	Hot Water Coil (only available on C-Cabinet)	W		•	
		Not Applicable	N	•	•	•
		High Air Temp Rise (70°F to 100°F)	H	•	•	•
		Low Air Temp Rise (30°F to under 75°F)	L	•	•	•
20	Heat Control	No Heating	N	•	•	•
		Modulating	D	•	•	•
21	Nominal Wheel Diameter ④	None (or Not Applicable for C- and D-Cabinet)	N	•	•	•
		28"	A	•		
		36"	B	•		
		48"	C	•		
22	Exhaust Blower Configuration ④	None (or Not Applicable for C- and D-Cabinet)	N	•	•	•
		11" Backward Inclined Plenum Fan	1	•		
		16" Backward Inclined Airfoil Plenum Fan	2	•		
23	Exhaust Blower Motor HP ③④	20" Backward Inclined Airfoil Plenum Fan	3	•		
		None (or Not Applicable for C-Cabinet)	N	•	•	•
		1 HP	C or Q	•		
		1-1/2 HP	D or R	•		
		2 HP	E or S	•		
		3 HP	F or T	•		
		5 HP	G or U	•		
		7-1/2 HP	H or V	•		
10 HP	J or W	•				
24	Energy Wheel Preheat ④	None (or Not Applicable for C- and D-Cabinet)	N	•	•	•
		20kW (nominal) Electric	2	•		

① Supply fans with belt drive are no longer offered and are shown for historical purposes. All units shipped after December, 2017 are direct drive supply fans.
 ② ANPA are airfoil fans, ANPL are non-airfoil fans.
 ③ C through L include a Motor Starter, Q through Y include a Variable Frequency Drive (VFD).
 ④ MPR C-Cabinet units that interface to energy recovery exhaust will always be "N". The Wheel Diameter, Exhaust Blower Configuration, Exhaust Blower Motor HP, and Energy Wheel Preheat is called out in the ERM model nomenclature, when applicable, on C-Cabinet sized units. All D-Cabinet units are "N".

COMMERCIAL WARRANTY

Seller warrants its products to be free from defects in material and workmanship, EXCLUSIVE, HOWEVER, of failures attributable to the use of materials substituted under emergency conditions for materials normally employed. This warranty covers replacement of any parts furnished from the factory of Seller, but does not cover labor of any kind and materials not furnished by Seller, or any charges for any such labor or materials, whether such labor, materials or charges thereon are due to replacement of parts, adjustments, repairs, or any other work done. This warranty does not apply to any equipment which shall have been repaired or altered outside the factory of Seller in any way so as, in the judgment of Seller, to affect its stability, nor which has been subjected to misuse, negligence, or operating conditions in excess of those for which such equipment was designed. This warranty does not cover the effects of physical or chemical properties of water or steam or other liquids or gases used in the equipment.

BUYER AGREES THAT SELLER'S WARRANTY OF ITS PRODUCTS TO BE FREE FROM DEFECT IN MATERIAL AND WORKMANSHIP, AS LIMITED HEREIN, SHALL BE IN LIEU OF AND EXCLUSIVE OF ALL OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, WHETHER ARISING FROM LAW, COURSE OF DEALING, USAGE OF TRADE, OR OTHERWISE, **THERE ARE NO OTHER WARRANTIES, INCLUDING WARRANTY OF MERCHANTABILITY OR FITNESS FOR PURPOSE, WHICH EXTEND BEYOND THE PRODUCT DESCRIPTION CONFIRMED BY BUYER AND SELLER AS OF THE DATE OF FINAL AGREEMENT.**

This warranty is void if the input to the product exceeds the rated input as indicated on the product serial plate by more than 5% on gas-fired and oil-fired units, or if the product in the judgment of SELLER has been installed in a corrosive atmosphere, or subjected to corrosive fluids or gases, been subjected to misuse, negligence, accident, excessive thermal shock, excessive humidity, physical damage, impact, abrasion, unauthorized alterations, or operation contrary to SELLER'S printed instructions, or if the serial number has been altered, defaced or removed.

BUYER AGREES THAT IN NO EVENT WILL SELLER BE LIABLE FOR COSTS OF PROCESSING, LOST PROFITS, INJURY TO GOODWILL, OR ANY OTHER CONSEQUENTIAL OR INCIDENTAL DAMAGES OF ANY KIND RESULTING FROM THE ORDER OR USE OF ITS PRODUCT, WHETHER ARISING FROM BREACH OF WARRANTY, NONCONFORMITY TO ORDERED SPECIFICATIONS, DELAY IN DELIVERY, OR ANY LOSS SUSTAINED BY THE BUYER.

BUYER'S REMEDY FOR BREACH OF WARRANTY, EXCLUSIVE OF ALL OTHER REMEDIES PROVIDED BY LAW, IS LIMITED TO REPAIR OR REPLACEMENT AT THE FACTORY OF SELLER, ANY COMPONENT WHICH SHALL, WITHIN THE APPLICABLE WARRANTY PERIOD DEFINED HEREIN AND UPON PRIOR WRITTEN APPROVAL, BE RETURNED TO SELLER WITH TRANSPORTATION CHARGES PREPAID AND WHICH THE EXAMINATION OF SELLER SHALL DISCLOSE TO HAVE BEEN DEFECTIVE; EXCEPT THAT WHEN THE PRODUCT IS TO BE USED BY BUYER AS A COMPONENT PART OF EQUIPMENT MANUFACTURED BY BUYER, BUYER'S REMEDY FOR BREACH, AS LIMITED HEREIN, SHALL BE LIMITED TO ONE YEAR FROM DATE OF SHIPMENT FROM SELLER. FOR GAS-FIRED PRODUCTS INSTALLED IN HIGH HUMIDITY APPLICATIONS AND UTILIZING STAINLESS STEEL HEAT EXCHANGERS, BUYER'S REMEDY FOR BREACH, AS LIMITED HEREIN, SHALL BE LIMITED TO TEN YEARS FROM DATE OF SHIPMENT FROM SELLER.

These warranties are issued only to the original owner-user and cannot be transferred or assigned. No provision is made in these warranties for any labor allowance or field labor participation. Seller will not honor any expenses incurred in its behalf with regard to repairs to any of Seller's products. No credit shall be issued for any defective part returned without proper written authorization (including, but not limited to, model number, serial number, date of failure, etc.) and freight prepaid.

OPTIONAL SUPPLEMENTAL WARRANTY

Provided a supplemental warranty has been purchased, Seller extends the warranty herein for an additional four (4) years on certain compressors. Provided a supplemental warranty has been purchased, Seller extends the warranty herein for an additional four (4) years or nine (9) years on certain heat exchangers.

EXCLUSION OF CONSUMABLES & CONDITIONS BEYOND SELLER'S CONTROL

This warranty shall not be applicable to any of the following items: refrigerant gas, belts, filters, fuses and other items consumed or worn out by normal wear and tear or conditions beyond Seller's control, including (without limitation as to generality) polluted or contaminated or foreign matter contained in the air or water utilized for heat exchanger (condenser) cooling or if the failure of the part is caused by improper air or water supply, or improper or incorrect sizing of power supply.

<u>Component</u> Applicable Models	"APPLICABLE WARRANTY PERIOD"
<u>Heat Exchangers</u> Gas-Fired Units except MPR Models	TEN YEARS FROM DATE OF FIRST BENEFICIAL USE BY BUYER OR ANY OTHER USER, WITHIN TEN YEARS FROM DATE OF RESALE BY BUYER OR ANY OTHER USER, WITHIN TEN YEARS FROM DATE OF RESALE BY BUYER IN ANY UNCHANGED CONDITION, OR WITHIN ONE HUNDRED TWENTY-SIX MONTHS FROM DATE OF SHIPMENT FROM SELLER, WHICHEVER OCCURS FIRST
<u>Heat Exchangers</u> Low Intensity Infrared Units , Gas Heat option on MPR models <u>Compressors</u> Condensing Units for Cassettes	FIVE YEARS FROM DATE OF FIRST BENEFICIAL USE BY BUYER OR ANY OTHER USER, WITHIN FIVE YEARS FROM DATE OF RESALE BY BUYER OR ANY OTHER USER, WITHIN FIVE YEARS FROM DATE OF RESALE BY BUYER IN ANY UNCHANGED CONDITION, OR WITHIN SIXTY-SIX MONTHS FROM DATE OF SHIPMENT FROM SELLER, WHICHEVER OCCURS FIRST
<u>Burners</u> Low Intensity Infrared Units <u>Compressors</u> MPR Models <u>Other</u> Components excluding Heat Exchangers, Coils, Condensers, Burners, Sheet Metal	TWO YEARS FROM DATE OF FIRST BENEFICIAL USE BY BUYER OR ANY OTHER USER, WITHIN TWO YEARS FROM DATE OF RESALE BY BUYER IN ANY UNCHANGED CONDITION, OR WITHIN THIRTY MONTHS FROM DATE OF SHIPMENT FROM SELLER, WHICHEVER OCCURS FIRST
<u>Heat Exchangers/Coils</u> Indoor and Outdoor Duct Furnaces and System Units, PSH/BSH, Steam/Hot Water Units, Oil-Fired Units, Electric Units, Cassettes, Vertical Unit Ventilators <u>Compressors</u> Vertical Unit Ventilators <u>Burners</u> High Intensity Infrared Units <u>Sheet Metal Parts</u> All Products	ONE YEAR FROM DATE OF FIRST BENEFICIAL USE BY BUYER OR ANY OTHER USER, WITHIN ONE YEAR FROM DATE OF RESALE BY BUYER IN ANY UNCHANGED CONDITION, OR WITHIN EIGHTEEN MONTHS FROM DATE OF SHIPMENT FROM SELLER, WHICHEVER OCCURS FIRST

As Modine Manufacturing Company has a continuous product improvement program, it reserves the right to change design and specifications without notice.



Modine Manufacturing Company
1500 DeKoven Avenue
Racine, WI 53403
Phone: 1.800.828.4328 (HEAT)
www.modinevac.com