

OPERATING INSTRUCTIONS

CANDY FLOSS MACHINE



After working continuously for one hour, you should pause for 20 minutes and water clean the machine before re-starting,

1. Press the switch to turn on the machine and wait for 1-2 minutes. Observe whether the machine runs smoothly when the spinning head of the machine is rotating. If the vibration is too severe, the machine needs to be adjusted. It must be ensured that the machine is placed stably.
2. After 1-2 minutes turn on the 'Heat' button. Warm up the machine for approximately 5 minutes.
3. First, pour one scoop of sugar into the centre of the spinning head and have your bamboo or cardboard stick ready.



4. After about 3 seconds, the cotton candy starts to squirt out.

Take a bamboo or cardboard stick and rotate it anti-clockwise a few times along the inner wall of the bowl. Then, place the stick horizontally and rotate it over the spinning head to form cotton candy.

Different shapes can be made by tilting the sticks.

5. After making enough cotton candy, turn off the heat button.

6. Once the heat button is turned off, use the scoop to pour a scoopful of water into the spinning head (caution the steam will be hot). Use a paper towel or clothe to wipe around bowl.

7. Once cooled, the motor can be turned off

8. To make more cotton candy, repeat the above steps

Cleaning

1. You can return the machine unclean, and we will clean and sanitise.

2. Do not wash the machine with detergents such as washing powder.

3. Do not immerse the machine directly in water.



IMPORTANT NOTICE

1. Minors are prohibited from using this product.
2. Do not put the wire close to the hot surface. Do not immerse the lugs on the machine in water
3. When not in use or before cleaning, turn off the heat switch, and wait for it to cool down before turning off and unplugging from the power supply.
4. Do not touch the rotating spinning head when the machine is working. Do not reach your hands into the bowl until the sugar is gone. To avoid burns, do not move the machine while it is working.
5. Long-term continuous operation should be avoided. **After working continuously for one hour, you should pause for 20 minutes and water clean the machine before re-starting**, which will greatly extend the service life of the motor.
6. Whether it is cleaning, maintenance and other related work, the power should be turned off first, and the power plug should be unplugged.
7. The machine is not allowed to run without sugar for a long time.
8. Cleaning agents are not allowed to be used during cleaning to prevent the cleaning agents remaining on the machine



Watch a video for some tips and tricks...scan the below QR code...



If you need assistance, call me anytime: 0423 167 166. Have fun!