



[en] Instruction manual

B14M42.5AU



## en Table of contents

Important safety information	4
Causes of damage	5
Energy and environment tips	5
Saving energy	5
Environmentally-friendly disposal	5
Your new appliance	6
Control panel	6
Operating modes	
Your accessories	
Accessories	
Inserting accessories	
Shelf positions	
Optional accessories	
Before using the appliance for the first time	
Setting the clock	
Cleaning the appliance	
Operating the appliance	
Switching on the appliance	
Switching off the appliance	
Electronic clock	
Clock display	
Timer	
Cooking time	
End of operation	
Preset operation	
Setting the clock	
Checking, correcting or deleting settings	
Baking	
Baking on one level	
Baking on two or more levels	
Baking table	
Baking table for ready-made products  Tips and tricks	
Roasting and braising	
<u> </u>	
RoastingBraising	
Tables for roasting and braising	
Tips and tricks	
Grilling	
Circo-roasting	
Radiant grilling	
Grilling table	
Yoghurt	
Defrosting	
Defrosting with CircoTherm®	
Defrost	
Preserve	
Cleaning and care	
Cleaning the appliance exterior	
Cleaning the cooking compartment	
Self-cleaning surfaces	
Removing and fitting the appliance door	
Cleaning the door panels	
Cleaning the hook-in racks	

Faults and repairs	22
Replacing the oven light bulb	
Changing the door seal	23
After-sales service	23
E number and FD number	23
Test dishes	24

Additional information on products, accessories, replacement parts and services can be found at **www.neff-international.com** and in the online shop **www.neff-eshop.com** 

## **⚠** Important safety information

Read these instructions carefully. Only then will you be able to operate your appliance safely and correctly. Retain the instruction manual and installation instructions for future use or for subsequent owners.

This appliance is only intended to be fully fitted in a kitchen. Observe the special installation instructions.

Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transport.

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under warranty.

This appliance is intended for domestic use only. The appliance must only be used for the preparation of food and drink. The appliance must be supervised during operation. Only use this appliance indoors.

This appliance is intended for use up to a maximum height of 2000 metres above sea level.

This appliance may be used by children over the age of 8 years old and by persons with reduced physical, sensory or mental capabilities or by persons with a lack of experience or knowledge if they are supervised or are instructed by a person responsible for their safety how to use the appliance safely and have understood the associated hazards.

Children must not play with, on, or around the appliance. Children must not clean the appliance or carry out general maintenance unless they are at least 8 years old and are being supervised.

Keep children below the age of 8 years old at a safe distance from the appliance and power cable.

Always slide accessories into the cooking compartment correctly. See "Description of accessories in the instruction manual."

#### Risk of fire!

- Combustible items stored in the cooking compartment may catch fire. Never store combustible items in the cooking compartment. Never open the appliance door if there is smoke inside. Switch off the appliance and unplug it from the mains or switch off the circuit breaker in the fuse box.
- A draught is created when the appliance door is opened. Greaseproof paper may come into contact with the heating element and catch fire. Do not place greaseproof paper loosely over accessories during preheating. Always weight down the greaseproof paper with a dish or a baking tin. Only cover the surface required with greaseproof paper. Greaseproof paper must not protrude over the accessories.

### Risk of burns!

- The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.
- Accessories and ovenware become very hot. Always use oven gloves to remove accessories or ovenware from the cooking compartment.
- Alcoholic vapours may catch fire in the hot cooking compartment. Never prepare food containing large quantities of drinks with a high alcohol content. Only use small quantities of drinks with a high alcohol content. Open the appliance door with care.

## Risk of scalding!

- The accessible parts become hot during operation. Never touch the hot parts. Keep children at a safe distance.
- When you open the appliance door, hot steam may escape. Open the appliance door with care. Keep children at a safe distance.
- Water in a hot cooking compartment may create hot steam. Never pour water into the hot cooking compartment.

## Risk of injury!

Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.

### Risk of electric shock!

- Incorrect repairs are dangerous. Repairs may only be carried out by one of our trained after-sales engineers. If the appliance is faulty, unplug the mains plug or switch off the fuse in the fuse box. Contact the after-sales service.
- The cable insulation on electrical appliances may melt when touching hot parts of the appliance. Never bring electrical appliance cables into contact with hot parts of the appliance.
- Do not use any high-pressure cleaners or steam cleaners, which can result in an electric shock.
- When replacing the cooking compartment bulb, the bulb socket contacts are live. Before replacing the bulb, unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
- A defective appliance may cause electric shock. Never switch on a defective appliance. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.

## Causes of damage

#### Caution!

- Accessories, foil, greaseproof paper or ovenware on the cooking compartment floor: do not place accessories on the cooking compartment floor. Do not cover the cooking compartment floor with any sort of foil or greaseproof paper. Do not place ovenware on the cooking compartment floor if a temperature of over 50 °C has been set. This will cause heat to accumulate. The baking and roasting times will no longer be correct and the enamel will be damaged.
- Water in a hot cooking compartment: do not pour water into the cooking compartment when it is hot. This will cause steam. The temperature change can cause damage to the enamel.
- Moist food: do not store moist food in the cooking compartment when it is closed for prolonged periods This will damage the enamel.
- Fruit juice: when baking particularly juicy fruit pies, do not pack the baking tray too generously. Fruit juice dripping from the baking tray leaves stains that cannot be removed. If possible, use the deeper universal pan.
- Cooling with the appliance door open: only allow the cooking compartment to cool when it is closed. Even if the appliance door is only open a little, front panels of adjacent units could be damaged over time.
- Very dirty door seal: If the door seal is very dirty, the appliance door will no longer close properly when the appliance is in use. The fronts of adjacent units could be damaged. Always keep the door seal clean.
- Appliance door as a seat, shelf or worktop: Do not sit on the appliance door, or place or hang anything on it. Do not place any cookware or accessories on the appliance door.
- Inserting accessories: depending on the appliance model, accessories can scratch the door panel when closing the appliance door. Always insert the accessories into the cooking compartment as far as they will go.
- Carrying the appliance: do not carry or hold the appliance by the door handle. The door handle cannot support the weight of the appliance and could break.

## **Energy and environment tips**

Here you can find tips on how to save energy when baking and roasting and how to dispose of your appliance properly.

## Saving energy

Only preheat the oven if this is specified in the recipe or in the operating instruction tables.

Use dark, black lacquered or enamelled baking tins. They absorb the heat particularly well.

Open the appliance door as little as possible during cooking, baking or roasting.

It is best to bake several cakes one after the other. The cooking compartment is still warm. This may reduce the baking time for the second cake.

For longer cooking times, you can switch the oven off 10 minutes before the end of the cooking time and use the residual heat to finish cooking.

## **Environmentally-friendly disposal**

Dispose of packaging in an environmentally-friendly manner.




This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

# Your new appliance

In this section, you will find information on

- the control panel
- the operating modes

## **Control panel**



Controls and indicators		Use/meaning		
Oven				
1	Operating mode selector	Selects the required operating mode (see section: Operating the appliance)		
2	Temperature selector	Sets the required temperature (see section: Operating the appliance)		
3	Temperature selector indicator light	Appliance on or off (see section: Operating the appliance)		
Electronic o	elock			
4	Electronic clock display	Displays the time; also includes clock functions (see section: Electronic clock)		
5 4>	Clock function button	Selects the desired clock function (see section: Electronic clock)		
6	Rotary selector	Makes settings within a clock function (see section: Electronic clock)		

### Pop-out operating knob

The rotary, temperature and operating mode selectors can all be popped out. Push the required operating knob to pop it in or out.

## **Operating modes**

Here is an overview of your appliance's operating modes.

Operating mode		Use	
&	CircoTherm®	For baking and roasting on one or more levels	
	Top/bottom heating	For baking and roasting on one level. Ideal for cakes with moist toppings (e.g. cheese-cake)	
Ĭ	Circo-roasting	For poultry and larger pieces of meat	
	Full-surface grill	For large quantities of flat, small items for grilling (e.g. steaks, sausages)	

Operating mode Use		Use
Bottom heating  For food and baked items on which you want a crust to form, or which browning on the underside.		For food and baked items on which you want a crust to form, or which need more browning on the underside.
		Switch on Bottom heating at the end of the baking time for a short time only.
*	Defrost setting	For gently defrosting pieces of meat, bread and delicate baked goods (e.g. cream gateau)
$\triangle$	Interior lighting	Useful for cleaning and care of the cooking compartment

## Your accessories

In this section, you will find information on

- Your accessories
- the correct way to insert the accessories into the cooking compartment
- the shelf positions
- the optional accessories


#### Accessories

The following accessories are included with your appliance:



#### Wire rack

for baking in baking tins, roasting in roasting dishes and grilling



grilling and collecting drops of liquid during cooking



for roasting and grilling

**Note:** The wire insert is always used together with the universal pan. In this combination, the wire insert is placed in the universal pan.


**Note:** The baking tray and universal pan may become distorted when the appliance is in operation. This is caused by the considerable temperature differences acting on the accessories. These differences may occur if only a part of the accessory is covered with food, or if frozen items such as pizza are placed on the accessory.

### Inserting accessories

The accessories are equipped with a locking function. The locking function prevents the accessories from tilting when they are pulled out. The accessories must be inserted into the cooking compartment correctly for the tilt protection to work properly.


When inserting the wire rack, check

- that the lug (a) is pointing downwards
- that the lug (a) is in the rear part of the wire rack




When inserting the baking tray or the universal pan, check

- that the lug (a) is in the rear part of the of the accessory
- that the sloping edge of the accessory faces towards the appliance door when it is inserted



### **Shelf positions**



The cooking compartment has four shelf heights. The shelf heights are counted from the bottom up.

Note: Do not use shelf height 2 when baking and roasting with & CircoTherm®. This will adversely affect air circulation and your baking and roasting results will not be as good.

### Optional accessories

You can buy optional accessories from your after-sales service or from specialist retailers. A comprehensive range of products for your appliance can be found in our brochures or on our home page.

Optional accessories	Ordering no.
System steamer	N8642X3
Roasting pan, enamelled	Z1272X0
Glass pan	Z1262X0
CLOU® 4x telescopic shelf with full extension	Z1755X2
Bread-baking stone	Z1913X0

## Before using the appliance for the first time

In this section, you can read about

- How to set the clock after connecting up your appliance
- How to clean your appliance before using it for the first time

### Setting the clock

**Note:** When you press the ⟨□⟩ clock function button, you have 3 seconds to set the clock using the rotary selector. Should this have been insufficient for you, you can amend the clock time later.

 ${\it \square}:{\it \square}{\it \square}$  flashes in the clock display.

 Briefly press the ⟨□⟩ clock function button to go to the setting mode.

The  $\triangleleft \triangleright$  and  $\bigcirc$  symbols light up.  $\wr 2: \square \square$  appears in the clock display.

**2.** Set the current time using the rotary selector. Your setting is accepted after 3 seconds.

#### Changing the clock

To subsequently change the time, press the  $\triangleleft \triangleright$  clock function button repeatedly until the  $\triangleleft \triangleright$  and  $\bigcirc$  symbols light up again. Change the time with the rotary selector.



## Cleaning the appliance

Clean your appliance before using it for the first time.

- 1. Remove the accessories from the cooking compartment.
- **2.** Completely remove any residual packaging (e.g. chips of polystyrene) from the cooking compartment.
- **3.** Clean the accessories and cooking compartment with hot soapy water (see section: Cleaning and care).
- **4.** Keep the kitchen ventilated while the appliance is heating up. Heat with Top/bottom heat  $\square$  at 240 °C for 60 minutes.
- Afterwards, wipe the cooled cooking compartment with hot, soapy water.
- **6.** Clean the outside of the appliance with a soft, damp cloth and soapy water.

## Operating the appliance


In this section, you can read about


- how to switch your appliance on and off
- how to select an operating mode and temperature

## Switching on the appliance

- **1.** Turn the operating mode selector (figure A) until the desired operating mode is selected.
- Turn the temperature selector (figure B) until the desired temperature is selected.

The 1 indicator light will remain lit while the appliance is heating up and during any subsequent heating.





## Switching off the appliance

- 1. Turn the operating mode selector back to the o position.
- 2. Turn the temperature selector back to the position.

After the appliance is switched off, the cooling fan may continue to run.

## **Electronic clock**

In this section, you can read about

- how to set the timer
- how to switch your appliance off automatically (cooking time and end of operation)
- how to switch your appliance on and off automatically (preset operation)
- how to set the time

## **Clock display**



- 1 Clock function button
- 2 Rotary selector

Cloc	k function	Use
$\triangle$	Minute minder	You can use the minute minder as an egg timer or a kitchen timer. The appliance does not switch on or off automatically
<del>   </del>	Cooking time	The appliances switches off automatically after a cooking time setting has elapsed (e.g. $l:30$ hours)
$\rightarrow$	End of operation	The appliance switches off automatically at a set time (e.g. 12:30 o'clock)
	Preset operation	The appliance switches on and off automatically. Cooking time and end of operation have been combined.
9	Clock	Setting the clock

#### **Notes**

- Between the times 22:00 and 5:59 the clock display is dimmed if you do not make any settings in that period or no clock function is activated.
- When you set a clock function, the time interval increases when you set higher values (e.g. cooking time up to !:☐☐h to the minute, using !:☐☐h to the nearest 5 minutes).
- For the △ minute minder, I→I cooking time, →I end of operation and preselection mode clock functions, a signal sounds when the settings have elapsed and the △ or →I symbol flashes. To cancel the audible signal before it ends, press the 〈I〉 clock function button.
- Briefly press the ⟨□⟩ clock function button to select a clock function. You then have 3 seconds to set the selected clock function. After this time, the setting mode is exited automatically.

#### Switching the clock display on and off

- Press and hold the ⟨□⟩ clock function button for 6 seconds.
   The clock display switches off. If a clock function is active, the associated symbol remains lit.
- 2. Press the ⟨□⟩clock function button briefly. The clock display switches on.

#### **Timer**

- Press the ⟨□⟩ clock function button repeatedly until the ⟨□⟩ and □ symbols light up.
- **2.** Set the duration using the rotary selector (e.g.  $5:\overline{U}\overline{U}$  minutes). The setting is applied automatically. Then the clock is displayed again and the minute minder starts counting down.




### Cooking time

Automatic switch-off after a cooking time setting has elapsed.

- **1.** Set the operating mode and temperature. The appliance heats up.
- 2. Press the ⟨□⟩clock function button repeatedly until the ⟨□⟩and I→I symbols light up.

3. Set the cooking time with the rotary selector (e.g. 1:30 hours).

The setting is applied automatically. The time is then displayed again and the set cooking time counts down.



Once the cooking time has elapsed, the appliance switches off automatically.

- **1.** Turn the operating mode and temperature selector back to the O position.
- **2.** Press the  $\triangleleft \triangleright$  clock function button to exit the clock function.

### **End of operation**

Automatic switch-off at a set time.

- **1.** Set the operating mode and temperature. The appliance heats up.
- Press the ⟨□⟩ clock function button repeatedly until the ⟨□⟩ and → symbols light up.
- 3. Set the end of operation using the rotary selector (e.g. 12:3□ o'clock).

The setting is applied automatically. The clock is then displayed again.



The appliance switches off automatically at the time set for the end of operation.

- **1.** Turn the operating mode and temperature selector back to the o position.
- 2. Press the  $\triangleleft \triangleright$  clock function button to exit the clock function.

### **Preset operation**

The appliance switches on automatically, then switches off automatically at the time preselected for the end of operation. To set this function, combine the cooking time and end of operation clock functions.

Bear in mind that food which spoils easily should not be left in the cooking compartment for too long.

- **1.** Set the operating mode and temperature. The appliance heats up.
- 2. Press the ⟨□⟩clock function button repeatedly until the ⟨□⟩and I→I symbols light up.
- 3. Set the cooking time with the rotary selector (e.g. 1:3₽ hours).

The setting is applied automatically.

- **4.** Press the ⟨□⟩clock function button repeatedly until the ⟨□⟩and → symbols light up.
- 5. Set the end of operation using the rotary selector (e.g. 12:30 o'clock).

- **6.** Turn the operating mode and temperature selector back to the o position.
- **7.** Press the  $\triangleleft \triangleright$  clock function button to exit the clock function.

## Setting the clock

You can only change the clock when no other clock function is active.

- Press the ⟨▷ clock function button repeatedly until the ⟨▷ and ⊗ symbols light up.
- **2.** Set the clock using the rotary selector. The setting is applied automatically.



## Checking, correcting or deleting settings

- **1.** To check your settings, press the ⟨□⟩ clock function button repeatedly until the corresponding symbol lights up.
- 2. If necessary, you can correct your setting using the rotary selector.
- **3.** If you wish to cancel your setting, turn the rotary selector anticlockwise to the original value.

## **Baking**

In this section, you will find information on

- Baking on one level
- Baking on two or more levels
- The baking table
- The baking table for ready-made products
- Tips and tricks for baking

**Note:** Do not use shelf height 2 when baking with & CircoTherm®. The air circulation is impaired and this will have a negative effect on your baking.

We recommend that you use dark-coloured metal baking tins.


Tinplate and glass dishes increase the baking time required and the cake will not brown evenly.

If you wish to bake using tinplate tins and  $\square$  Top/bottom heat, you should use shelf position 1.

Always slide the universal pan in carefully as far as it will go and make sure that the sloping edge is facing the appliance door.


### Baking on one level

If you are baking on one level with & CircoTherm®, always place a round tin in the centre of the wire rack (figure A) and always place a loaf tin diagonally (figure B).





If you are baking on one level with &CircoTherm®, always place two round baking tins diagonally to each other on the wire rack (figure C).



### Baking on two or more levels


If you are baking on more than one level, only use the & CircoTherm® operating mode.


Bear in mind that your items may brown at different rates on each level. The items on the top level will brown more quickly and can be taken out earlier.

#### Two baking tins on two levels

When baking with two round baking tins or two baking trays, slide a wire rack in at shelf position 1 and a wire rack in at shelf position 3.

Place the lower baking tin to the left (figure A) and the upper baking tin to the right (figure B) on the wire rack.






#### Four baking tins on two levels

When baking with four round baking tins, slide a wire rack in at shelf position 1 and a wire rack in at shelf position 3.

Always place baking tins on the wire rack (figure C).



### **Baking table**

The details given in the table are guidelines and apply to dark baking tins. The values may vary depending on the type and amount of the dough/mixture and on the baking tin.

We recommend that you set the lower of the specified temperatures the first time. Lower temperatures will generally allow more even browning.

If you are baking according to your own recipe, use similar recipes in the table as a guide.

Observe the notes in the table about preheating.

Meal	Setting	Level	Temperature in °C	Time in minutes
Victoria sponge cake	æ	1	160 - 170*	25 - 30
		2	160 - 170*	20 - 30
		1 + 3	150 - 160*	25 - 35
Scones	æ	1	180 - 200*	10 - 15
		3	210 - 220*	8 - 10
		1 + 3	180 - 200*	10 - 15
Small cakes	æ	1	160 - 170*	20 - 30
		3	150 - 160*	25 - 35
		1 + 3	150 - 160*	25 - 35

<sup>\*</sup> Preheat oven

<sup>\*\*</sup> Preheat the oven to 130 °C

Meal	Setting	Level	Temperature in °C	Time in minutes
Light fruit cake	&	1	140 - 150*	80 - 100
Rich fruit cake	&	1	140 - 150*	220 - 240
Jam tarts	&	1	190 - 200*	15 - 20
		3	200 - 210*	15 - 20
	<u>&amp;</u>	1 + 3	190 - 200*	20 - 25
Swiss roll	&	1	180 - 190*	10 - 15
		2	190 - 200*	10 - 15
Tart	&	1	160 - 170*	50 - 60
		1	180 - 190*	50 - 60
		1 + 3	160 - 170*	50 - 60
Pies	&	1	170 - 180*	65 - 75
		1 + 3	170 - 180*	65 - 75
Biscuits	&	1	160 - 170*	15 - 20
		2	170 - 180*	15 - 20
		2	170 - 180*	15 - 20
		1 + 3 + 4	160 - 170*	20 - 25
Meringue	愚	1	80*	100 - 130
		3	80*	100 - 130
Pavlova	&	1	90 - 100**	90 - 120
		3	80 - 90**	90 - 120
Fruit crumble	&	1	170 - 180*	45 - 55
		2	190 - 200*	45 - 55
Yorkshire pudding	&	1	200 - 220*	15 - 20
		2	220 - 230*	15 - 20
	<u>&amp;</u>	1 + 3	200 - 220*	15 - 20
Vol au vents	&	1	190 - 200*	20 - 30
Quiche	&	1	180 - 200*	45 - 55
		1	190 - 210*	45 - 55
(White) bread	&	1	210 - 220*	20 - 25
		1	220 - 230*	20 - 25
Homemade pizza	&	1	190 - 200*	20 - 30
		2	210 - 220*	20 - 30
		1 + 3	180 - 190*	35 - 45
Jacket potatoes	&	1	160 - 170	60 - 70
		2	170 -180	60 - 70
		1 + 3	160 - 170	65 - 75

<sup>\*</sup> Preheat oven

## Baking table for ready-made products

#### Notes

- Use the universal pan
- Only use greaseproof paper that is suitable for the selected temperature
- Spread chips out in a single layer
- Turn frozen potato products half way through the baking time
- Only season frozen potato products after they have finished baking
- Leave a little space between the dough when baking bread rolls. Do not place too many in the universal pan

- Cover the lasagne with plenty of cheese so that the top browns evenly
- Do not use frozen products with freezer burn
- Do not use frozen products that are heavily frosted
- Follow the manufacturer's instructions.

The details given in the table are guidelines and apply to the universal pan.

We recommend that you set the lower of the specified temperatures the first time. Lower temperatures will generally allow more even browning.

If you are baking on more than one level, only use the & CircoTherm® operating mode.

Observe the notes in the table about preheating.

<sup>\*\*</sup> Preheat the oven to 130  $^{\circ}\text{C}$ 

Meal	Setting	Level	Temperature in °C	Time in minutes
Frozen pizza	&	1	180 - 200*	15 - 25
		2	190 - 210*	15 - 25
	&	1 + 3	170 - 190*	20 - 30
Chilled pizza	&	1	200 - 210*	10 - 15
		2	190 - 210*	10 - 15
Part-baked white bread	&	1	180 - 190*	10 - 20
		2	190 - 200*	10 - 20
	&_	1 + 3	170 - 180*	15 - 20
Oven chips	&	1	180 - 200*	25 - 30
		2	190 - 210*	25 - 30
Potato wedges	&	1	180 - 190*	20 - 25
		2	190 - 200*	20 - 25
Croquettes	&	1	180 - 190*	25 - 30
		2	190 - 200*	25 - 30
Fish fingers	&	1	180 - 200*	15 - 20
		2	190 - 210*	15 - 20
Lasagne, frozen (400 g)	&	1	180 - 190*	40 - 45
Lasagne, frozen (1200 g)	&	1	180 - 190*	45 - 50
Lasagne, chilled (400 g)	愚	1	170 - 180*	35 - 40
		2	190 - 200*	35 - 40
Lasagne, chilled (1200 g)	愚	1	170 - 180*	40 - 45
		2	190 - 200*	40 - 45

<sup>\*</sup> Preheat oven

## Tips and tricks

The cake is too light in colour	Check the shelf height.		
	Check whether you have used the bakeware that we have recommended.		
	Place your tin on the wire rack and not on the baking tray.		
	If the shelf height and the bakeware are correct, then you should either extend the baking time or increase the temperature.		
The cake is too dark	Check the shelf height.		
	If the shelf height is correct, you should either shorten the baking time or reduce the temperature.		
The cake is unevenly browned in the bak-	Check the shelf height.		
ing tin	Check the temperature.		
	Make sure that your baking tin is not placed directly in front of the air outlets in the rear panel of the cooking compartment.		
	Check that the baking tin is in the correct position on the wire rack.		
The cake is too dry	Set a slightly higher temperature and a slightly shorter baking time.		
The cake is too moist in the centre	Set a slightly lower temperature.		
	Note: Higher temperatures may not mean shorter baking times (cooked on the outside, but not on the inside).		
	Select a longer baking time and allow the cake mixture to prove for longer.		
	Add less liquid to the mixture.		
The cake collapses when you take it out of	Use less liquid for the mixture.		
the oven	Set a longer baking time or a slightly lower temperature.		
The specified baking time is not correct	For small items, check the quantity on the baking tray. Small items must not be touching each other.		
Frozen products are not browned evenly after baking	Check whether the frozen product is unevenly pre-browned before baking. This uneven browning will remain after the baking time.		
Several cakes on one level are unevenly browned	Check the position of the baking tins on the wire rack.		

Frozen products are not browned, not crispy or the specified times are not correct	Remove ice from frozen products before baking. Do not use frozen products that are heavily frosted
Saving energy	Only preheat the appliance when it is specified in the baking table that you should do so.
	Use dark baking tins as these absorb the heat better.
	Make use of the residual heat with longer baking times and switch the oven off 5 - 10 minutes before the end of the baking time.

## Roasting and braising

In this section, you will find information on

- Roasting
- Braising
- Tables for roasting and braising
- Tips and tricks

# There is a risk of injury if you use roasting dishes that are not heat-resistant!

Only use roasting dishes that are marked as being suitable for use in the oven.

Do not use shelf height 2 when roasting with  $\blacksquare$  CircoTherm $\blacksquare$ . The air circulation would be impaired and this will have a negative effect on your roast.

### Roasting

Roasting dish without a lid is used for roasting.

While the meat is roasting, the liquid in the roasting dish will evaporate. If necessary, carefully add more hot liquid.

When you are roasting using  $\square$  Top/bottom heat, turn the roast approximately half to two thirds of the way through the roasting time.

#### Roasting in the universal pan

Juices escape from the roasting meat and are collected in the universal pan. You can use these juices as the basis for a tasty gravy.

Deglaze the pan of the juices with hot water, stock, wine or similar. Bring to the boil, thicken with cornflour, season and pass through a sieve if necessary.

You can also cook side dishes (e.g. vegetables) at the same time as roasting meat in the universal pan.

For smaller joints, you can use a smaller roasting dish instead of the universal pan. Place this directly on the wire rack.

#### Roasting in the universal pan with insert grid

Place the wire insert in the universal pan with the lower area facing downwards and slide them in together at the same shelf position.

For fatty meat and poultry, add ½ to ¼ litre water to the universal pan, depending on the size and type of the joint.

### **Braising**

For braising, a roasting dish with a lid is used. Ensure that the roasting dish and lid fit together well and close properly.

First, sear the meat if required.

Add the meat, vegetables and liquid to the roasting dish in equal proportions and place the dish with the lid closed on the wire rack at shelf position 1.

While the meat is braising, the liquid in the roasting dish will evaporate. Pour in more liquid if required.

## Tables for roasting and braising

The details given in the table are guidelines and apply to food placed in a cold oven and for meat taken directly from the refrigerator.

#### **Poultry**

The information in the tables applies to unstuffed poultry. Turn the poultry after half of the cooking time.

#### Lean meat

Coat lean meat with fat or oil as required and cover it with strips of bacon.

#### Cooking time and temperature

The cooking time and temperature depend on the size, height, type and quality of the food and the roasting dish.

As a general rule: the larger the item, the lower the temperature and the longer the roasting time.

You should set the lower of the specified temperatures the first time. Lower temperatures will generally allow more even browning.

The values for cooking time apply to 0.5 - 2 kg of food. For greater weights, reduce the temperature and increase the cooking time. For multiple pieces, apply the cooking time for the weight of the heaviest piece.

### Standing time

At the end of the cooking time, switch the oven off and leave the roast to stand for approximately 10 minutes in the cooking compartment with the door closed. The recommended standing time is not included in the cooking times specified.

Meal	Setting	Level	Temperature in <sup>o</sup> C	Time in minutes (per 500 g)
Duck	B	1	180*	20 + 20
		2	190 - 200*	20 + 20
Beef				
Slow roast joint	&	1	140*	40 + 40
		2	150*	40 + 40

<sup>\*</sup> Preheat oven

<sup>\* +</sup> time for Yorkshire pudding

Meal	Setting	Level	Temperature in <sup>o</sup> C	Time in minutes (per 500 g)
Top side / top rump	æ	1	160*	30 + 25
		2	190*	30 + 25
Lamb				
Leg	&	1	170*	30 + 25
		2	200*	30 + 25
Shoulder (bone-in)	&	1	170*	25 + 20
		2	200*	25 + 20
Shoulder (boned and rolled)	&	1	170*	30 + 25
		2	200*	30 + 25
Rack of lamb	&	1	180*	25 + 25
		2	200*	25 + 25
Pork				
Roast joint	<b>&amp;</b>	1	180*	35 + 35
		2	180*	35 + 35
Loin joint	&	1	180*	30 + 30
		2	180*	30 + 30
Belly	<b>&amp;</b>	1	160*	30 + 25
		2	190*	30 + 25
Gammon				
Joint	&	1	160*	30 + 30
		2	190*	30 + 30
Chicken				
Whole chicken	₽	1	170 - 180*	20 + 25
		2	190 - 200*	20 + 25
Portion (boned)	 &	1	190*	20 + 25
		2	200 - 210*	20 + 25
Quarter	₽ B	1	190*	20 + 25
		2	200 - 210*	20 + 25
Turkey				
Drumstick	æ	1	180*	20 + 20
Crown	<b>&amp;</b>	1	160*	25 + 20
Whole	æ	1	150 - 160*	25 + 25
Complete Meal				
with beef	₽.	1 + 3	160*	30 + 25**
with chicken	 &	1 + 3	180*	20 + 25
* Prohoat oven	<u> </u>			

<sup>\*</sup> Preheat oven

<sup>\* +</sup> time for Yorkshire pudding

Casseroles	Setting	Level	Temperature in <sup>o</sup> C	Time in minutes (per 500 g)
Diced meat (beef, pork, lamb, chicken)	丛	1	140	40 + 80
		1	140*	40 + 80
Braising steak	丛	1	140	45 + 80
		1	140*	45 + 80
Chicken pieces (boned)	丛	1	140	50 + 70
		2	140	50 + 70

<sup>\*</sup> Preheat oven

## Tips and tricks

Crust too thick and/or roast too dry	Reduce the temperature or shorten the roasting time.
	Check the shelf height.
Crust too thin	Increase the temperature or switch on the grill briefly at the end of the roasting time.
The meat is not cooked right through	Remove any accessories that are not required from the cooking compartment.
	Increase the roasting time.
	Check the core temperature of the joint using a meat thermometer.
Steam in the cooking compartment is condensing on the appliance door	The steam dries during the course of the cooking. If there is an excessive volume of steam, you can carefully open the door briefly to dissipate the steam more quickly.
The meat is burned slightly during braising	Add the meat, vegetables and liquid to the roasting dish in equal proportions.
	The roasting dish and lid must fit together well and close properly.
	Reduce the temperature.

## Grilling

In this section, you will find information on

- Grilling in general
- Circo-roasting
- Radiant grilling
- The grilling table

#### Caution!

Material damage due to effect of heat: The temperature generated in the cooking compartment is very high. Keep the appliance door closed when using the grill. Never grill with the appliance door open.

#### **Notes**

- It is preferable to use the universal pan with wire insert for grilling
- Place the insert grid into the universal pan and slide the two in together at the shelf position specified in the grilling table
- Always place the food to be grilled in the centre of the wire rack
- If you are grilling more than one piece of meat, make sure that they are the same sort of meat and that they are of similar thickness and weight.
- Use the wire rack for particularly large quantities. Insert the wire rack at the shelf position indicated in the grilling table. To prevent the oven from becoming dirty, insert the universal pan one level lower.

## **Circo-roasting**

The SCirco-roasting operating mode is particularly suitable for poultry or meat (e.g. roast pork with crackling) that is to be crispy.

Turn large items of food after approximately half to two-thirds of the grilling time. For items of food with rind, place them on the wire rack rind-side down for the first half of the grilling time.

Pierce duck and goose skin under the wings and legs to allow the fat to escape.

Depending on the type of food you are cooking, the cooking compartment may become very dirty when you cook food using Circo-roasting. You should therefore clean the cooking compartment after every use so that the dirt does not become burnt on.

At the end of the cooking time, switch the grill off and leave the food to stand for approximately 10 minutes in the cooking compartment with the door closed. The recommended standing time is not included in the grilling times specified.

## Radiant grilling

For flat items to be grilled, use the T full-surface grill.

Brush the items to be grilled with a little oil according to taste.

Turn the items after half to two-thirds of the grilling time.

You can influence the grilling result by changing the position of the wire rack.

## Wire rack posi- Application



Place the wire insert in the universal pan with the lower area facing downwards: Suitable for grill items that should be predominantly well-done



Place the wire insert in the universal pan with the lower area facing upwards: Suitable for grill items that should be cooked predominantly rare to medium-rare

**Note:** Always use the universal pan in the standard position (not the other way up).



## Grilling table

The details given in the table are guidelines and apply to the enamelled universal pan with wire insert. The values may vary depending on the type and amount of items to be grilled.

You should set the lower of the specified temperatures the first time. A lower temperature will generally provide more even browning.

The values refer to food placed in the oven when it is cold and for meat taken directly from the refrigerator.

Meal	Setting	Level	Temperature in <sup>o</sup> C	Time in minutes
Beef				
Steaks, high 2 - 3 cm	<b>""</b>	4	270*	1st side: 9 - 12
				2 <sup>nd</sup> side: 5 - 7
Burgers, high 1 - 2 cm	<b>""</b>	4	270	1st side: 8 - 10
				2 <sup>nd</sup> side: 6 - 8
Lamb				
Leg	THE STATE OF THE S	2	170 - 190	120 - 150***
Shoulder (bone-in)	<b>X</b>	2	170 - 190	100 - 130***
Shoulder (boned and rolled)	<b>\\\\</b>	2	170 - 190	120 - 150***
Steaks, high 2 - 3 cm	<b>""</b>	4	270	1st side: 5 - 7
				2 <sup>nd</sup> side: 3 - 5
Chops, high 2 - 3 cm	<b>""</b>	4	270	1 <sup>st</sup> side: 6 - 8
				2 <sup>nd</sup> side: 4 - 7
Pork				
Roast joint	<b>X</b>	2	180 - 200	120 - 150***
Steaks, high 1 - 2 cm	<b>""</b>	4	270*	1st side: 8 - 10
				2 <sup>nd</sup> side: 5 - 8
Chops, high 2 - 3 cm	<b>""</b>	4	270	1 <sup>st</sup> side: 10 - 12
				2 <sup>nd</sup> side: 8 - 10
Burgers, high 1 - 2 cm		4	270	1st side: 8 - 10
				2 <sup>nd</sup> side: 6 - 8
Sausages, ø 2 - 4 cm	<b>""</b>	4	270	12 - 16**
Gammon				
Steaks, high 1 - 2 cm	<b>""</b>	4	270	1 <sup>st</sup> side: 9 - 12
				2 <sup>nd</sup> side: 5 - 7
Chicken				
Drumsticks	<b>~</b>	3	250	1st side: 15 - 17
				2 <sup>nd</sup> side: 10 - 13
Breast (boneless)	<b>""</b>	4	250	1 <sup>st</sup> side: 12 - 15
				2 <sup>nd</sup> side: 7 - 10
Whole chicken	[ <del>*</del>	2	200 - 230	70 - 90***
Quarter	Image: Control of the	2	210 - 230	40 - 50***
Fish				
Whole fish, e.g. trout		3	220	1 <sup>st</sup> side: 10 - 15
				2 <sup>nd</sup> side: 10 - 15
		2	220	15 - 25
Filets	<b>""</b>	4	220	1st side: 8 - 12
				2 <sup>nd</sup> side: 7 - 10

<sup>\*</sup> Preheat for 3 minutes

\*\* Turn frequently

\*\*\*Turn after half of the time

## **Yoghurt**

You can also use the appliance to make home-made yoghurt: The heat of the 🗟 cooking compartment light is used for this.

- Remove accessories and hook-in racks, telescopic shelves or separate fitting systems.
- 2. Heat 1 litre of long-life milk (3.5 % fat) or fresh pasteurised milk to 40  $^{\circ}\text{C}$ 
  - Bring 1 litre of fresh milk to the boil once and allow to cool down to 40  $^{\circ}\text{C}.$
- 3. Add 150 g of set yoghurt to the warm milk, stir in and fill the jars or bowls evenly. Do not pour more than 200 ml into any single container.

- 4. Cover the filled containers with a suitable lid or cling film.
- Preheat the oven at 100 °C for 15 minutes using the fullsurface grill.
- **7.** Evenly space the containers over the cooking compartment floor, then close the appliance door.
- **8.** After 8 hours, switch off the 🗟 cooking compartment light and place the containers in the refrigerator for at least 12 hours.

## **Defrosting**

In this section, you can read about

- how to defrost using CircoTherm®
- how to use the <a> Defrost operating mode</a>

## **Defrosting with CircoTherm®**

Use A CircoTherm® to defrost and cook frozen products.

#### **Notes**

- Frozen products that have been defrosted (meat in particular) require shorter cooking times than fresh products
- The cooking time for frozen meat increases by the defrosting time
- Always defrost frozen poultry before cooking so that you can remove the giblets
- Cook frozen fish at the same temperatures as fresh fish
- You can place large quantities of ready made frozen vegetables in aluminium dishes in the cooking compartment at the same time
- Use shelf height 1 when defrosting on one level, and shelf heights 1 + 3 when using two levels
- Observe the instructions on the packaging when using frozen foods.

Frozen meals	Tempera- ture in °C	Defrosting time in min- utes
Raw frozen products/ foods	50	30 - 90
Bread/Bread rolls (750 - 1,500 g)	50	30 - 60
Dry, frozen tray bakes	60	45 - 60
Moist, frozen tray bakes	50	50 - 70

#### **Defrost**

Using defrost setting 🚼 you can defrost delicate pastries particularly well (e.g. cream cakes).

- **1.** Switch on the Toperating mode.
- Defrost the frozen food for 25-45 minutes, depending on type and size.
- **3.** Remove the frozen food from the cooking compartment and let it thaw for 30 45 minutes.

With small quantities (pieces), the defrosting time is shortened to 15-20 minutes and the extended defrosting time is shortened to 10-15 minutes.

## **Preserve**

## A Risk of injury!

Preserving jars containing incorrectly preserved food can burst. Please observe the following instructions:

- Fruit and vegetables must be fresh and in good condition
- Only use clean and undamaged preserving jars
- The preserving jars must not touch each other in the cooking compartment during preserving

With  $\blacksquare$  CircoTherm®, the cooking compartment can be used to preserve the contents of up to six ½, 1 or 1½ litre preserving jars at the same time.

#### **Notes**

- For each preserving process, only use preserving jars that are the same size and contain the same food.
- Pay attention to cleanliness when preparing and closing the preserving jars.
- Only use heat resistant rubber rings.
- You cannot preserve the following food in your appliance: the contents of tin cans, meat, fish or pie filling.

#### Preparing fruit

- 1. Wash fruit and, depending on the type, peel, remove the seeds and finely chop.
- 2. Fill the preserving jars with fruit up to approx. 2 cm below the
- 3. Fill the preserving jars with hot, skimmed sugar solution (approx. ½ I for a one litre jar).

To one litre water:

- approx. 250 g sugar for sweet fruit
- approx. 500 g sugar for sour fruit

#### **Preparing vegetables**

- Wash vegetables and depending on the type, clean and finely chop.
- Fill the preserving jars with vegetables up to approx. 2 cm below the rim.
- 3. Fill the preserving jars immediately with hot, boiled water.

#### Closing the preserving jars

- 1. Wipe the rims of the preserving jars with a clean, damp cloth.
- 2. Put a wet rubber ring and lid in place and close the jars with the clips.

#### Starting the preserving process

- 1. Insert the universal pan at shelf height 1.
- Position the preserving jars in a triangle without them touching each other.



- 3. Pour ½ litre of hot water (approx. 80 °C) into the universal pan.
- 4. Set & CircoTherm® at 160 °C.
  - Preserving jars containing ½ or 1 litre will start to bubble after approx. 50 minutes
  - Preserving jars containing 1½ litres will start to bubble after approx. 60 minutes

#### **Ending the preserving process**

For fruit, gherkins and tomato purée:

- 1. Turn off the appliance, once all preserving jars are bubbling.
- **2.** Allow the preserving jars to stand in the closed cooking compartment for several minutes longer.
  - Raspberries, strawberries, cherries or gherkins: approx.
     5 10 minutes
  - Other fruit: approx. 10 15 minutes
  - Tomato or apple purée: approx. 15 20 minutes

#### For vegetables:

- 1. Reduce the temperature to 100 °C once all the preserving jars are bubbling. Allow the preserving jars to continue bubbling for approx.60 minutes in the closed cooking compartment.
- 2. Switch off the appliance.
- **3.** Allow the preserving jars to stand in the closed cooking compartment for approx. 15 30 minutes longer.

#### Removing the preserving jars

- **1.** Place the preserving jars on a clean cloth, cover and protect from draughts.
- 2. Remove clips only when the jars are cold.

## Cleaning and care

In this section, you will find information on

- cleaning and care of your appliance
- Cleaning agents and aids

### Risk of short circuit!

Do not use high-pressure cleaners or steam jet cleaners to clean your appliance.

#### Caution!

Surface damage due to incorrect cleaning: Do not use any

- harsh or abrasive cleaning agents
- cleaning agents that contain alcohol
- abrasive cleaning aids such as steel wool or scourers.

Observe the specifications in the tables.

**Note:** Highly recommended cleaning and care products can be purchased through our after-sales service. Observe the manufacturer's instructions.

#### Cleaning the appliance exterior

Appliance part/surface	Cleaning agent/aid
Stainless steel surfaces	Apply commercially available washing-up liquid with a soft, damp cloth or chamois; dry with a soft cloth.
	Use cleaners for matted stainless steel if very dirty.
Painted surfaces	Apply commercially available washing-up liquid with a soft, damp cloth or chamois; dry with a soft cloth.
Control panel	Apply commercially available washing-up liquid with a soft, damp cloth or chamois; dry with a soft cloth.
	Do not use glass cleaners or glass scrapers.
Door panels	Use a commercially available glass cleaner or washing-up liquid with a soft, damp cloth or chamois; dry with a soft cloth.
	The inner door panel on the appliance door has a coating which reduces the temperature and reflects the heat. The view through the appliance door is not impaired by this. When the appliance door is open, this coating can have the effect of a light-coloured film. This is part of the design and is not due to any quality defect.

## Cleaning the cooking compartment

#### Caution!

Risk of damaging the surface. Do not clean the appliance while still warm, even if using oven cleaners specially intended for this purpose.

#### **Notes**

- Enamel is baked on at very high temperatures during manufacture. This can cause some slight colour variation. This is normal and does not affect its function.
- The edges of thin trays cannot be completely enamelled. As a result, these edges may be rough. Anti-corrosion protection is still guaranteed, however.

Appliance part	Cleaning agent/aid
Enamel surfaces (smooth surface)	To facilitate cleaning, you can switch on the interior lighting and detach the appliance door if necessary.
	Apply commercially available washing-up liquid or a vinegar solution with a soft, damp cloth or chamois; dry with a soft cloth.
	Soften baked-on food residues with a damp cloth and detergent.
	We recommend using oven cleaner if the oven is very dirty. Observe the manufacturer's instructions when cleaning with an oven cleaner.
	Leave the cooking compartment open to dry after cleaning.
Self-cleaning surfaces (rough surface)	Please see the notes in section: Self-cleaning surfaces
Door seal	Hot soapy water
Hook-in racks	Hot soapy water: Soak and clean with a dish cloth or brush.
Telescopic shelves	Hot soapy water: Clean with a dish cloth or a brush.
	Do not remove the lubricant while the pull-out rails are pulled out – it is best to clean them when they are pushed in.
	Do not soak or clean in the dishwasher.
Accessories	Soak in hot soapy water, clean with a brush and sponge or wash in the dishwasher.

#### Keeping the appliance clean

To avoid getting the cooking compartment dirty,

- clean the cooking compartment after each use, as dirt will bake on the next time it is heated up, and this can only be removed with difficulty
- always remove flecks of limescale, grease, starch and albumin (e.g. egg white) immediately
- Use the universal pan to bake very moist cakes
- use suitable ovenware when roasting (e.g. roasting dish) or a roasting sheet (see section: Accessories)

#### Self-cleaning surfaces

The rear wall and ceiling of the cooking compartment are coated with self-cleaning enamel. This coating absorbs and disintegrates splashes from baking and roasting while the oven is in operation.

Large splashes only disappear after the oven has been used several times.

Colour variations on the self-cleaning surfaces have no effect on the self-cleaning function.

#### Caution!

Damage to surfaces on self-cleaning areas due to applying oven cleaner. Never clean the self-cleaning surfaces with oven cleaner

If oven cleaner accidentally gets onto self-cleaning surfaces, remove it immediately with a sponge and plenty of water.

#### Caution!


Damage to surfaces on self-cleaning areas due to the use of abrasive and acidic cleaning agents and aids.

Do not use cleaning agents containing abrasive substances or

Do not use abrasive cleaning aids such as steel wool or scourers.

## Removing and fitting the appliance door

You can remove the appliance door to clean it more thoroughly.




The hinges of the appliance door may snap shut with great force. Always open the hinge locking lever fully when removing the appliance door and close it fully after refitting. Do not reach into the hinge.

## A Risk of injury!

If the appliance door has only been unhinged on one side, do not reach into the hinge. The hinge can snap back with great force. Call the after-sales service.


#### Removing the appliance door


- 1. Open the appliance door fully.
- 2. Open the locking levers on the left and right-hand side fully.



The hinges are secured and cannot snap closed.


- **3.** Close the appliance door until resistance becomes noticeable (figure A)
- **4.** With both hands, grip the door on the left and right-hand side, close the door a little more and pull it out (figure B).






#### Fitting the appliance door

- **1.** Insert the hinges in the left and right-hand holders (figure C). The notch on both hinges must engage.
- 2. Open the appliance door fully.
- **3.** Close the locking levers on the left and right-hand side fully (figure D).





The appliance door is secured and can no longer be removed.

4. Close the appliance door.

### Cleaning the door panels

To facilitate cleaning, you can remove the inner door panels from the appliance door.

## A Risk of injury!

The components inside the appliance door may have sharp edges. Take care not to cut yourself. Wear protective gloves.


## A Risk of injury!


The appliance must not be used again until the door panels and appliance door have been correctly fitted.

### Removing the door panel

**Note:** Before removing, make a note of which way round the door panel is fitted, so that it is not refitted the wrong way round.


- 1. Unhook the appliance door and lay it on a soft, clean surface with the front side facing downwards (see section: Removing and installing the appliance door).
- **2.** Pull off the cover at the top of the appliance door. Press in the tabs on the left and right using your fingers (fig.A).
- 3. Lift the door panel slightly and pull it out (Fig. B).






#### Removing the intermediate panel

Lift the intermediate panel slightly and pull it out towards you.



#### Cleaning

Clean the door panel with glass cleaner and a soft cloth.




Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.

#### Fitting the intermediate panel

**Note:** During installation, make sure that the lettering "top right" is upside down at the bottom left.

Insert the intermediate panel towards the back as far as it will go.



#### Fitting the door panel

 Insert the door panel at an angle towards the back into both brackets as far as it will go. The smooth surface must face outwards.



- 2. Put the cover back in place and press on it until it clicks in place.
- 3. Refit the appliance door.


## Cleaning the hook-in racks


You can remove the hook-in racks for easier cleaning.

# A Risk of burning due to hot components in the cooking compartment!


Wait until the cooking compartment has cooled down.


- **1.** Push the hook-in rack upwards at the front and unhook to the side (figure A).
- Pull the hook-in rack forwards at the rear and unhook to the side (figure B).





- Clean the hook-in rack with washing-up liquid and a sponge or brush.
- **4.** Align the hook-in rack with the indentation (a) facing downwards, so that the shelf heights match.
- **5.** Insert the hook-in rack at the rear as far as it will go and push to the rear (figure C).
- **6.** Insert the hook-in rack at the front as far as it will go and push downwards (figure D).





## Faults and repairs

It is not always necessary to call the after-sales service. Sometimes, you can find a remedy yourself. You will find some tips for troubleshooting in the following table.

### A Risk of electric shock!

- Work on the appliance electronics may only be performed by a specialist.
- Always disconnect the appliance from the power supply when work is carried out on the electronics. Switch off the circuit breaker or remove the fuse from your household fuse box.

Problem	Possible cause	Remedial action		
Electrical function is faulty (e.g. indicator lamps do not light up)	Circuit-breaker faulty	Check circuit-breakers in the fuse box and replace if necessary		
Liquid or thin dough runs to one side	Appliance not installed level	Check the appliance installation (see the Installation instructions)		
☐:☐☐ flashes in the clock display	There was a power cut	Reset the clock (see section: Electronic clock)		
Electronically controlled functions are mal- functioning	Energy surges (e.g. lightning strike)	Reset the function concerned		
Smoke is generated during roasting or grilling	Fat is burning on the grill element	Continue grilling or roasting until the fat on the grill element is burnt away		
	Wire rack or universal pan inserted incorrectly	Check the shelf levels (see section: Roasting or Grilling)		
Higher levels of condensation are generated in the cooking compartment	Normal occurrence (e.g. when baking cakes with very moist toppings or roasting a large joint)	Open the appliance door briefly from time to time during operation		
Enamelled accessories have matt, light-coloured marks	Normal occurrence caused by dripping meat or fruit juices	Not possible		
Door panels are misted up	Normal occurrence caused by temperature differences	Heat the appliance up to 100 °C and then switch off again after 5 minutes		

## Replacing the oven light bulb

Replace faulty oven light bulbs.

You can obtain replacement light bulbs from customer service or specialist retailers: E14, 220 - 240 V, 40 W, heat resistant to 300 °C. Only use these oven light bulbs.

## Risk of electric shock!

Disconnect the appliance from the power supply. Switch off the circuit breaker or remove the fuse from the household fuse box.

- Place a tea towel in the cold cooking compartment to prevent damage.
- 2. Turn the glass cover anticlockwise and remove it.




- 3. Replace the oven light bulb with a bulb of the same type.
- 4. Screw on the glass cover again.
- 5. Remove the tea towel and switch on the circuit breaker.

**Note:** If the glass cover cannot be unscrewed: use rubber gloves to turn it. You can order a special removal tool through the after-sales service (order no. 613634)

## Changing the door seal

If the door seal is defective, it must be replaced. Replacement seals for your appliance can be obtained from the after-sales service.

The door seal is attached in four places (figure A). When replacing it, disconnect and attach the hooks at all four points (figure B).





Check again to ensure that the seal is seated correctly in the corners in particular.

## After-sales service

Our after-sales service is there for you if your appliance needs to be repaired. We will always find the right solution in order to avoid unnecessary visits from a service technician.

#### E number and FD number

When calling us, please give the product number (E no.) and the production number (FD no.) so that we can provide you with the correct advice. The rating plate containing these numbers can be found on the right-hand side of the oven door. You can make a note of the numbers of your appliance and the telephone number of the after-sales service in the space below to save time should it be required.

E no. FD no.

#### After-sales service ®

Please note that there will be a fee for a visit by a service technician in the event of a malfunction, even during the warranty period.

Please find the contact data of all countries in the enclosed customer service list.

### To book an engineer visit and product advice

**GB** 0344 892 8989

Calls charged at local or mobile rate.

**IE** 01450 2655

0.03 € per minute at peak. Off peak 0.0088 € per minute

Rely on the professionalism of the manufacturer. You can therefore be sure that the repair is carried out by trained service technicians who carry original spare parts for your appliances.

## **Test dishes**

These tables have been produced for test institutes to facilitate the inspection and testing of the various appliances.

Test dishes tested to standard EN 50304/EN 60350 (2009) and IEC 60350.

Please note the information in the tables about preheating. The table values do not include Rapid heat up.


**Note:** For baking, use the lower of the temperatures indicated first.


Baking	Setting	Level	Temperature in °C	Time in minutes	Cookware
Shortbread		3	140 - 150**	20 - 30	Baking tray***
	<b>&amp;</b>	1	140 - 150**	20 - 30	Baking tray***
	<b>&amp;</b>	1 + 3	140 - 150**	25 - 35	2x baking tray***
	<b>&amp;</b>	1 + 3 + 4	130 - 140**	35 - 50	3x baking tray***
Small cakes (x 20)		3	160 - 170*	25 - 30	Baking tray***
	<b>&amp;</b>	1	150 - 160*	25 - 30	Baking tray***
	<b>&amp;</b>	1 + 3	140 - 150*	30 - 40	2x baking tray***
	<b>&amp;</b>	1 + 3 + 4	140 - 150*	35 - 45	3x baking tray***
Fat-free sponge cake		2	160 - 170**	25 - 35	Springform cake tin**** ø 26 cm
	<b>&amp;</b>	1	160 - 170**	25 - 35	Springform cake tin**** ø 26 cm
Apple pie	æ	1	170 - 180**	70 - 80	2x Springform cake tin**** ø 20 cm (see figure A)
	æ	1 + 3	170 - 180**	65 - 75	2x Springform cake tin**** ø 20 cm (see figure B)

<sup>\*</sup> Preheat for 10 minutes

When baking apple pie using & CircoTherm®, place both springform cake tins next to each other on the wire rack (figure A).

If you are baking German apple pie on two levels, place the lower baking tin to the left on the wire rack and the upper baking tin to the right on the wire rack (figure B),





Grilling	Setting	Level	Temperature in °C	Time in minutes	Cookware
White bread		3 + 4	275*	0.5 - 2	Universal pan + wire rack
Beef steaks		3 + 4	270	20 - 25**	Universal pan + wire rack

<sup>\*</sup> Preheat for 10 minutes

<sup>\*\*</sup> Preheat oven

<sup>\*\*\*</sup> Only use original baking trays, order no. Z1342X0

<sup>\*\*\*\*</sup> Use a black Springform cake tin

<sup>\*\*</sup> Turn after 3/3 of the time

Constructa-Neff Vertriebs-GmbH Carl-Wery-Straße 34 D-81739 München GERMANY



9001135189

950710