

# Information for new scooter owners

Congratulations on the purchase of your new scooter!

Maintenance is a vital part of caring for your scooter. Here is a guideline to help make sure you keep your scooter happy and healthy.

1. First oil change should be done at **100** miles. Be sure to use oil designed for a scooter. We recommend Bel Ray, Amsoil, or Valvoline. After the first oil change, change oil every **1000** miles.
2. Transmission oil change will need to be done at **300** miles. After first change, it will need to be changed every **6000** miles.
3. Valves should be adjusted at around **600** miles.
4. If you plan to store your scooter without riding for more than a month, we suggest using a trickle charger on your battery and drain the gas from the carburetor to prevent clogs.
5. The belt should be checked at **4000** miles.
6. Check the air pressure in your tires often. They should have 30psi in the front and 35psi in the rear. If the tire pressure is low, it will affect the handling and safety.

\*If you have any concerns about your scooter, we are always here to help. You could also bring your scooter to us for oil changes. Our price list is below.

**Oil Change     \$37.00**

**Transmission oil change     \$36.00**

**Valve adjustment     \$49.00**

**Thank you from The Kiss My Gas  
Powersports Family. Ride Safe**