



**NORDBO**  
ROBOTICS

**Manual Version 1.6**  
**For Nordbo Controller Software Version 1.2**



FT Tracker for Mimic

## **User Manual**

Tracker Specific Manual



**Copyright**

Copyright © 2022 Nordbo Robotics. All Rights Reserved. No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose without the written permission of Nordbo Robotics.

**Disclaimer**

The information provided in this documentation contains general descriptions of the use, of one or more of Nordbo Robotics' products. Following this document's instruction for installation and use must not be considered a substitute for making a risk assessment and testing the specific application and setup. Neither Nordbo Robotics nor any of our affiliates or subsidiaries shall be held responsible for the consequences that arise from misuse of – or misunderstanding of – any information stated in this document.

If any instructions are considered unclear it is the user's responsibility to contact Nordbo Robotics for clarification of the issue(s) before making use of said unclear instructions.

If the user has any suggestions for improvements, amendments, or if errors have been found in this release, please notify Nordbo Robotics.

Nordbo Robotics reserves the right to make refinements or changes without notice.

**Warranty**

Warranty void if products are opened. The warranty further excludes failure resulting from improper use or installation, normal wear and tear, abuse, accidents, neglect, fire, water, lightning, or other acts of nature, causes external to the product, or other factors beyond Nordbo Robotics control.

**Contact**

Nordbo Robotics A/S

📍 Noatunvej 2

5000 Odense, Denmark

☎ +45 81 81 98 81

✉ [info@nordbo-robotics.com](mailto:info@nordbo-robotics.com)

CVR/VAT: DK 34697728

# Contents

1.1.	Intended Use.....	3
1.2.	Prerequisites.....	3
1.3.	Safety Warnings.....	3
<b>2.</b>	<b>Getting to Know Mimic with FT Tracker .....</b>	<b>4</b>
2.1.	Mimic with FT Tracker at a Glance .....	5
<b>3.</b>	<b>FT Tracker Information .....</b>	<b>6</b>
3.1.	Mimic FT Tracker Contents.....	7
<b>4.</b>	<b>How to Setup Hardware.....</b>	<b>8</b>
4.1.	Setting Up the Tracker .....	9
<b>5.</b>	<b>How to Configure the Software .....</b>	<b>10</b>
5.1.	Setting the Correct IP.....	11
	Web Interface .....	11
5.2.	Real Time View.....	16
5.3.	Network .....	17
<b>6.</b>	<b>How to Use the Mimic with FT Tracker.....</b>	<b>18</b>
6.1.	Usage.....	19
<b>7.</b>	<b>Specifications .....</b>	<b>20</b>
7.1.	Technical Specifications .....	21
	Force Sensor (NRS-6050-D80) – Technical Specifications.....	21
	Converter – Technical Specifications.....	22
7.2.	Mechanical Dimensions.....	23
	Mimic FT Standard Handle .....	23
<b>8.</b>	<b>Support and Troubleshooting .....</b>	<b>24</b>
8.1.	FAQ.....	25
8.2.	Support Requests .....	25

# Before you Begin

## 1.1. Intended Use

This document serves as a guide for the installation of Nordbo Robotics' Mimic joystick for a manipulator. This guide does not provide any information about risk assessment which must be carried out before initiating any robot movements.

## 1.2. Prerequisites

It is required that the person executing the instructions of this manual has a basic knowledge of working with software related to the specific manipulator being used. Furthermore, it is expected that the person using this manual understands the risks related to working with robots.

## 1.3. Safety Warnings

Following instructions must be read thoroughly by anyone intending to use this product.



### **WARNING!**

This symbol indicates that potentially hazardous, dangerous, or unwanted situations can arise from not following the instructions correctly. If safety instructions are not followed properly it may result in death, personnel injury, or equipment damage.

Before attempting to connect the hardware to the robot, it is important to ensure that the robot cannot move unintentionally. For maximum safety, it is recommended to power off the robot before attempting to connect the hardware for the Tracker to the robot.

The robot must always be **powered off** before attempting to connect wires to the robot's controller, or when connecting cables between any of Nordbo Robotics' products.

The product may be damaged if dropped on hard surfaces. Be aware that connectors can break if the user pulls or overtightens the cables.

Nordbo Robotics is not liable for any damage or injury resulting from the use of the product.

## 2. Getting to Know Mimic with FT Tracker

---

## 2.1. Mimic with FT Tracker at a Glance

The FT Tracker for Mimic allows the user to record Trajectories by guiding the robot by hand.

The FT Tracker consists of a force- torque sensor and a handle. With these attached to the robot, the user can track complex movements (illustrated in [Figure 1](#)).

The FT Tracker provides the Mimic software with the force-torque applied to the handle. The Mimic software converts the force-torque to a change in the position and orientation in 3D-space applied to the robot TCP.



Figure 1 - Recording a movement with Mimic FT

### 3. FT Tracker Information

---

### 3.1. Mimic FT Tracker Contents

Picture	Referred to as	Description
	1x USB Flash drive	Contains documentation and URCap (only for Mimic UR)
  	1x FT Tracker for Mimic <ul style="list-style-type: none"> <li>1x Mimic FT Standard Handle</li> <li>1x NRS-6050-D80-UR Kit (installed in the FT Tracker)               <ul style="list-style-type: none"> <li>1x NRS-6050-D80</li> <li>1x NRS-ETH-2</li> <li>1x Flange Kit (3x flanges)</li> <li>1x USB w. URCap</li> </ul> </li> </ul>	The Tracker is the object that captures position and movements.  The FT Tracker is used to guide the robot by hand. NRS-6050-D80 is the force sensor. The NRS-ETH is the Tracker Controller.
	1x UR Flange for Mimic with FT	Standard flange that comes with the FT Tracker to get started. Enables mounting of the Tracker on a UR robot.  Follows ISO 9409-1 (cobot interface).
	3x Vibration dampers	Limits noise produced by the setup.
	3x M4x16 Hexagon Socket	Used to mount Mimic FT Standard Handle with NRS-6050-D80 (preinstalled).

## 4. How to Setup Hardware

---

## 4.1. Setting Up the Tracker

**Figure 2** depicts the complete hardware setup of the FT Tracker.




Figure 2 - The Mimic FT Tracker Setup

## 5. How to Configure the Software

---

## 5.1. Setting the Correct IP

### Web Interface

The web interface is the main user interface for the FT Tracker. It can be reached by typing the IP address of the FT Tracker into a browser.

#### Default IP: 192.168.1.100

To the left of every page is a menu with links to every configuration page as well as an overview showing information about the system (see example in [Figure 3](#)). This information includes the version of the firmware currently running on the FT Tracker, the serial number of the FT Tracker and the status of the system.




Figure 3 - Example of Web Interface (Real Time View)

Before the FT Tracker can be accessed, the network settings may need to be configured. The following section explains how to connect to the Mimic FT Controller using a Windows PC.



#### Note:

NRC-ETH had default IP 192.168.0.100



NRC-ETH-2 has default IP 192.168.1.100





**Step 1. Connect the FT Tracker's power supply and connect to a PC using an ethernet cable.**

**Step 2. Open Network & Internet settings by right-clicking on the Wi-Fi/LAN icon in the menu.**




Figure 4

**Step 3. Click "Change adapter options".**




Figure 5

**Step 4. Right-click on "Ethernet 3" and select "properties."**



**Note:** "Ethernet 3" may have a different number than "3".




Figure 6

**Step 5. Select Internet Protocol Version 4 (TCP/IPv4) and click "Properties".**




Figure 7

## Step 6. Set the IP address

Set the IP address to 192.168.1.100

Set the Subnet mask to 255.255.255.0




Figure 8

## Step 7. Access the real-time view using a browser by typing the IP address 192.168.1.100.




Figure 9

## 5.2. Real Time View

The landing page of the web interface is the Real Time View. This page allows the user to verify the functionality of the FT Tracker. A live graph displays the force and torque applied to the sensor. Below the graph is the current force torque value displayed.





Figure 10

### 5.3. Network

The Network page allows configuration of network settings for the FT Tracker.

By default, DHCP is disabled and the IP address is 192.168.1.100. Enabling DHCP will disallow configuration of the IP address, Subnet mask and Default gateway. The default Hostname is NordboFT but can be changed through the interface.

Click Save once complete to apply the configuration.



The screenshot shows the 'Network' configuration page of the Nordbo Robotics interface. On the left is a sidebar with the Nordbo Robotics logo and navigation links: Real Time View, Record, Hemisphere, Network (selected), and About. The main content area is titled 'Network' and contains the following settings:

- ☐ Enable DHCP
- IP address: 192.168.1.100
- Subnet mask: 255.255.255.0
- Default gateway: 192.168.1.1
- Hostname: NRS-PT
- Save** button

At the bottom of the page is a dark footer bar with the following text: Nordbo Robotics A/S • Agerhatten 27A, entrance 4, 1st , DK-5220 Odense SØ • www.nordbo-robotics.com • support@nordbo-robotics.com • +45 8181 9881

## 6. How to Use the Mimic with FT Tracker

---

## 6.1. Usage

The FT Tracker is meant to be used together with the Mimic software platform.

The sensor measures the force and torque applied to it. The change in force and torque is converted to change in the robot TCP (Tool Center Point), and thereby a movement.



Figure 11

## 7. Specifications

---

## 7.1. Technical Specifications

### Force Sensor (NRS-6050-D80) – Technical Specifications

Description		Metric
<b>Compatibility</b>		Windows, Linux, UR & Codesys
<b>Diameter, Ø</b>		80 mm
<b>Height, H</b>		22 mm
<b>Weight</b>		300 g
<b>Operating conditions, temperature</b>		0° to 50°
<b>Operating conditions, humidity</b>		< 85%
<b>Hysteresis</b>		< 0,2 %
<b>Crosstalk</b>		< 5 %
<b>Power requirement (CAN)</b>		5 VDC @ 250 mA
<b>Power requirement (Ethernet)</b>		6-40 VDC @ 1000 mA
<b>Sample rate</b>		< 1000 Hz
Fx Fy	<b>Max force</b>	± 500 N
	<b>Resolution*</b>	0,015 N
	<b>Overload</b>	700 N
	<b>Signal noise**</b>	0,025 N
	<b>Noise-free resolution</b>	0,1 N
	<b>Full scale non-linearity</b>	< 4%
	<b>Axis deformation</b>	30 µm
Fz	<b>Max force</b>	± 500 N
	<b>Resolution*</b>	0,015 N
	<b>Overload</b>	1200 N
	<b>Signal noise**</b>	0,032 N
	<b>Noise-free resolution</b>	0,15 N
	<b>Full scale non-linearity</b>	< 4%
	<b>Axis deformation</b>	27 µm
Tx Ty	<b>Max torque</b>	± 10 Nm
	<b>Resolution*</b>	0,32*10 <sup>-3</sup> Nm
	<b>Overload</b>	15 Nm
	<b>Signal noise**</b>	0,35*10 <sup>-3</sup> Nm
	<b>Noise-free resolution</b>	1,5*10 <sup>-3</sup> Nm
	<b>Axis deformation</b>	0,2°
Tz	<b>Max torque</b>	± 5 Nm
	<b>Resolution*</b>	0,25*10 <sup>-3</sup> Nm
	<b>Overload</b>	15 Nm
	<b>Signal noise**</b>	0,4*10 <sup>-3</sup> Nm
	<b>Noise-free resolution</b>	0,002 Nm
	<b>Axis deformation</b>	0,05°

\*The resolution describes the minimal increment of the different axis. The range and resolution of the sensor may vary depending on factory calibration. It can be expected that a calibrated sensor has a measuring deviation below 3% but is depending on the temperature and humidity of the environment.

\*\*Signal noise is defined as the standard deviation of a one second signal without load

## Converter – Technical Specifications

Description	Metric
<b>Model</b>	NRS-ETH
<b>Compatibility</b>	Windows, Linux, UR & Codesys
<b>Width, W</b>	55 mm
<b>Length, L</b>	91 mm (incl. connectors)
<b>Height, H</b>	39 mm
<b>Weight</b>	115 g
<b>Operating temperature</b>	0° to 50°
<b>Operating humidity</b>	< 85 %
<b>Power requirement (CAN)</b>	5 VDC @ 100 mA
<b>Power requirement (Ethernet)</b>	6-40 VDC @ 500 mA

## 7.2. Mechanical Dimensions

### Mimic FT Standard Handle

The TCP (Tool Center Point) is illustrated in [Figure 12](#). This is need when the TCP needs to set, relative to the robot interface (see [Figure 13](#)). [Figure 14](#) depicts the mechanical dimensions of the FT Tracker.




Figure 12 - Mimic FT Standard Handle TCP




Figure 13 - Relation between robot interface and FT Tracker




Figure 14 - Mechanical Dimensions of FT Tracker

## 8. Support and Troubleshooting

---

## 8.1. FAQ

Type	No.	Question	Answer
Common	1	How do I restart the FT Tracker?	To restart the FT Tracker, disconnect the power source and connect it again.

## 8.2. Support Requests

For questions, feature requests, and general support, please visit [support.nordbo.io](https://support.nordbo.io) and create a ticket. We highly value feedback on our products and you can help us improve the product by sharing your experience.



**NORDBO**  
ROBOTICS

Nordbo Robotics A/S

📍 Noatunvej 2

5000 Odense, Denmark

☎ +45 81 81 98 81

✉ [info@nordbo-robotics.com](mailto:info@nordbo-robotics.com)

CVR/VAT: DK 34697728

[www.nordbo-robotics.com](http://www.nordbo-robotics.com)

