

10148

06 - 2016



Instruction manual

AQUACIAT LP/ILD (150-600)

CONNECT TOUCH



PREFACE

The goal of this document is to give a broad overview of the main functions of the Connect Touch control system used to control AQUACIAT LD air-cooled liquid chillers and AQUACIAT ILD reversible heat pumps with 39 to 160 kW cooling/heating capacity.

Instructions in this manual are given as a guide to good practice in the installation, start-up and operation of the control system. This document does not contain full service procedures for the correct operation of the equipment. To ensure the correct operation of the machine, rules provided in this manual as well as IOM Machine should be followed.

The support of a qualified Service Engineer is strongly recommended to ensure optimal operation of the equipment as well as the optimization of all available functionalities.

Note that this document may refer to optional components and certain functions, options or accessories may not be available for the specific unit. The cover images are solely for illustration and form no part of any offer for sale or any sale contract.

IMPORTANT: All screenshots of the user interface provided in this manual include text in English. After changing the language of the system, all labels will be in the language selected by the user.

Please read all instructions prior to proceeding with any work. Pay attention to all safety warnings.

The information provided herein is solely for the purpose of allowing customers to operate and service the equipment and it is not to be reproduced, modified or used for any other purpose without the prior consent of the Manufacturer.

ACRONYMS/ABBREVIATIONS

In this manual, the refrigeration circuits are called circuit A and circuit B. Compressors in circuit A are labelled A1, A2, A3, whereas compressors in circuit B are labelled B1, B2.

BMS	Building Management System
DGT	Discharge Gas Temperature
DHW	Domestic Hot Water
EHS	Electric Heater Stage
EXV	Electronic Expansion Valve
FC	Free Cooling
LED	Light Emitting Diode
LEN	Sensor Bus (internal communication bus linking the basic board to slave boards)
Local-Off/LOFF	Operating type: Local Off
Local-On/L-C	Operating type: Local On mode
Local-Schedule/L-SC	Operating type: Local On following a time schedule
Master mode/Mast	Operating type: Master unit (master/slave assembly)
Network mode/Net	Operating type: Network
Remote mode/Rem	Operating type: Remote contacts
OAT	Outdoor Air Temperature
SCT	Saturated Condensing Temperature
SST	Saturated Suction Temperature
EWT	Entering Water Temperature
LWT	Leaving Water Temperature

The cover photos are solely for illustration and form no part of any offer for sale or any sale contract. The manufacturer reserves the right to change the design at any time without notice.

CONTENTS

PREFACE	2	7 - SETTING UP CONNECT TOUCH – DISPLAY MENU STRUCTURE	19
ACRONYMS/ABBREVIATIONS	2	7.1 Main menu.....	19
1 - SAFETY CONSIDERATIONS	4	7.2 Configuration menu (CONFIG)	25
1.1 Safety guidelines	4	7.3 Network Parameters menu (NETWORKS) ..	29
1.2 Safety precautions.....	4	7.4 Alarm menu	29
2 - CONTROL OVERVIEW	5	8 - STANDARD CONTROL OPERATIONS AND OPTIONS	30
2.1 Control system.....	5	8.1 Unit start/stop control.....	30
2.2 System functionalities.....	5	8.2 Heating / Cooling / Standby	31
2.3 Operating modes	5	8.3 Heating / Cooling selection.....	32
2.4 Connect Touch.....	5	8.4 Supplementary heating (heat pumps).....	32
3 - CONTROL COMPONENTS	6	8.5 Pump control	33
3.1 Chiller / Heat pump control	6	8.6 Hydronic kit option	34
3.2 Features overview	6	8.7 Control point	34
4 - HARDWARE	7	8.8 Free cooling option	35
4.1 Control boards.....	7	8.9 Capacity limitation	36
4.2 Electrical box	7	8.10 Capacity control.....	36
4.3 Power supply to boards	7	8.11 Night mode	37
4.4 Light emitting diodes.....	7	8.12 Holidays.....	37
4.5 Pressure transducers.....	7	8.13 Desuperheater option	37
4.6 Temperature sensors.....	7	8.14 Defrost cycle for heat pumps	37
4.7 Actuators	8	8.15 Master/Slave assembly.....	37
4.8 Terminal block connections	8	9 - DIAGNOSTICS	38
5 - HOW TO USE THE CONNECT TOUCH INTERFACE	10	9.1 Control diagnostics.....	38
5.1 Connect Touch menu structure	11	9.2 Alarms description.....	39
5.2 Connect Touch buttons	12	10 - MAINTENANCE	42
5.3 Read the welcome screen	13		
5.4 Explore the synoptic screen.....	13		
5.5 Start/Stop the unit.....	13		
5.6 Set the schedule.....	14		
5.7 Manage display settings	15		
5.8 Monitor unit parameters.....	16		
5.9 Modify unit parameters	17		
5.10 Override system configuration	17		
6 - WEB CONNECTION	18		
6.1 Web interface	18		
6.2 Open the web interface.....	18		
6.3 Manage web browser settings	18		

1 - SAFETY CONSIDERATIONS

1.1 Safety guidelines

Installation, start-up and servicing of equipment can be hazardous if certain factors particular to the installation are not considered: operating pressures, electrical components, voltages, and the installation site (elevated plinths and built-up structures).

Only qualified installation engineers and fully trained technicians are authorised to install and start the equipment.

All instructions and recommendations provided in the service guide, installation and operation manuals, as well as on tags and labels fixed to the equipment, components and other accompanying parts supplied separately, must be read, understood and followed.

Failure to comply with the instructions provided by the manufacturer may result in injury or product damage.

- Apply all safety standards and practises.
- Wear safety glasses and gloves.
- Use the proper tools to move heavy objects.
- Move units carefully and set them down gently.

CAUTION

Only qualified service technicians should be allowed to install and service the equipment.

1.2 Safety precautions

Only personnel qualified in accordance with IEC (International Electrotechnical Commission) recommendations may be permitted access to electrical components.

It is particularly recommended that all sources of electricity to the unit should be shut off before any work is begun. Shut off the main power supply at the main circuit breaker or isolator.

IMPORTANT: The equipment uses and emits electromagnetic signals. Tests have shown that the equipment conforms to all applicable codes with respect to electromagnetic compatibility.

CAUTION

Risk of electrocution! Even when the main circuit breaker or isolator is switched off, specific circuits may still be energised as they may be connected to a separate power source.

CAUTION

Risk of burns! Electrical currents may cause components to get hot. Handle the power cable, electrical cables and conduits, terminal box covers and motor frames with great care.

2 - CONTROL OVERVIEW

2.1 Control system

AQUACIAT LD (Cooling-only units) and AQUACIAT ILD (Heat pumps) units come with a Connect Touch control that serves as the user interface and configuration tool for the communicating devices.

Connect Touch is an electronic control system used to regulate the following types of units:

- AQUACIAT LD air-cooled liquid chillers
- AQUACIAT ILD reversible heat pumps

Connect Touch can function as a stand-alone system or it may be connected to the building management system using the Modbus TCP/IP, BACnet/IP communication, or Lon communication.

The units may be fitted with standard fixed-speed fan control system or the optional variable-speed fan drives which can reduce the unit energy use during occupied and unoccupied periods, provide condensing or evaporating pressure control and smooth fan start.

For both chillers and heat pumps the system may control fixed-speed pumps or variable-speed pumps with a hydronic module.

IMPORTANT: This document may refer to some optional components and certain functions, options or accessories may not be available for the specific unit.

Hybrid system

The Connect Touch control provides the hybrid system solution that allows for hot water production. In the case of low outdoor temperature, the boiler can operate as the source of warm water for the air-conditioning system or, depending on configuration; it may also be used to produce domestic hot water (DHW).

The domestic hot water option can be configured only by service technicians.

2.2 System functionalities

The system controls the start-up of the compressors needed to maintain the desired heat exchanger entering and leaving water temperature. It constantly manages the operation of the fans in order to maintain the correct refrigerant pressure in each circuit and monitors safety devices that protect the unit against failure and guarantee its optimal functioning.

2.3 Operating modes

The control can operate in three independent modes:

- **Local mode:** The unit is controlled by commands from the user interface.
- **Remote mode:** The unit is controlled by dry contacts.
- **Network mode:** The unit is controlled by network commands (Modbus RTU). Data communication cable is used to connect the unit to the RS485 communication bus.

When the control operates autonomously (Local or Remote), it retains all of its control capabilities but does not offer any of the features of the Network.

CAUTION

Emergency stop! The Network emergency stop command stops the unit regardless of its active operating type.

2.4 Connect Touch

Connect Touch control system:

- Allows users to control the unit via the Connect Touch user interface.
- Provides web connectivity technology.
- Supports Enhanced Control Management (M2M, Cristo Control, Power Control) for multiple chillers/heat pump configuration.
- Provides direct BMS integration capabilities (Modbus TCP/IP as standard, BACnet/IP option or Lon option).

3 - CONTROL COMPONENTS

3.1 Chiller / Heat pump control

The control manages a number of mechanisms that allow the unit to operate effectively.

Connect Touch controls compressors, fixed or variable speed fans, fixed or variable speed pumps for evaporator/condenser, and more.

3.2 Features overview

Standard features	AQUACIAT LD	AQUACIAT ILD
4.3" touch screen	x	x
BMS connection	x	x
Scroll compressor technology	x	x
Diagnostics	x	x
Language packs	x	x
Web connectivity	x	x
E-mail transmission	x	x
Anti-freeze protection	x	x
Cooling control	x	x
Heating control		x
Defrost mechanism		x
Additional features		
Desuperheater	o	o
Fixed or variable speed pumps	o	o
Free Cooling	o	o
High static fan	o	o
Variable speed fans	o	o
Hybrid system		o
Domestic hot water production		o
Boiler control		o
Electric heaters control		o
Communication options		
Modbus RTU (RS485)	x	x
Modbus TCP/IP	x	x
BACnet/IP	o	o
LonTalk	o	o

* "X" indicates a standard feature, whereas "O" indicates an option.

4 - HARDWARE

4.1 Control boards

All boards making up the Connect Touch control system are installed inside the electrical cabinet. They communicate via an internal LEN bus.

The system may embrace up to three (3) SIOB boards, where the first board is used to manage all major inputs and outputs of the controller, whereas the second SIOB board is used to support either the third compressor of circuit A or two compressors of circuit B. The third SIOB board is used only in the case of hybrid heat pump option.

Note that the first SIOB board is also referred to as the main board – the main board continuously monitors the information received from various pressure and temperature probes. Accordingly, the Connect Touch control starts the program that controls the unit.

At the same time, up to two (2) AUX1 boards can be installed. The first AUX1 board may provide additional inputs and outputs used to monitor chiller water system cooling temperature (Master/Slave assembly), leakage charge detection readings, electric heating or boiler operation. This board is used only for smaller units (units with only one fan) that have any of the aforementioned options available (electric heaters, boiler, etc.). The second AUX1 board is optional and it is used for units with the dry cooler option. It provides information required to control the free cooling cycle.

4.2 Electrical box

The electrical box includes all boards controlling the unit and the user interface.

4.3 Power supply to boards

All boards are supplied from a common 24 VAC supply referred to earth.

In the event of a power supply interrupt, the unit restarts automatically without the need for an external command. However, any faults active when the supply is interrupted are saved and may in certain cases prevent a given circuit or the unit from restarting.

CAUTION

Maintain correct polarity when connecting the power supply to the boards, otherwise the boards may be damaged.

4.4 Light emitting diodes

All boards continuously check and indicate the proper operation of their electronic circuits. A light emitting diode (LED) lights on each board when it is operating properly.

- The red LED flashing for a two-second period indicates correct operation. A different rate indicates a board or a software failure.
- The green LED flashes continuously on all boards to show that the board is communicating correctly over its internal bus (LEN bus). If the green LED is not flashing, this indicates a LEN bus wiring problem or a configuration issue.

4.5 Pressure transducers

Three types of transducers (high pressure, low pressure, water pressure) are used to measure various pressures in each circuit. These transducers deliver 0 to 10 VDC. They are connected to the SIOB board.

Discharge pressure transducers (high pressure type)

These transducers measure the discharge pressure in each circuit. They are used to control condensing pressure or high pressure load shedding. Discharge pressure sensors are mounted on the discharge line piping of each circuit.

Suction pressure transducers (low pressure type)

These transducers measure the suction pressure in each circuit. They are used to control EXV, evaporating pressure (in heating mode) and monitor suction pressure safeties related to the compressor operating envelope. Suction pressure sensors are located on the common suction piping of each circuit.

Pump inlet/outlet water pressure transducers (water pressure type, hydronic kit option)

These transducers measure the hydronic kit pump inlet/outlet water pressure and monitor the water flow. Pump inlet/outlet water pressure sensors are mounted on the optional hydronic kit.

4.6 Temperature sensors

Temperature sensors constantly measure the temperature of various components of the unit, ensuring the correct operation of the system.

Water heat exchanger entering and leaving water temperature sensors

The water heat exchanger entering and leaving water temperature sensors are used for capacity control and safety purposes.

Outdoor air temperature (OAT) sensor

This sensor measuring the outdoor air temperature is used for start-up, setpoint temperature reset and frost control.

Suction gas temperature sensors

These sensors measure the suction gas temperature. They are used for the EXV control. Suction gas temperature sensors are located at the suction side of each circuit.

Outdoor coil outlet suction gas temperature sensors

When there are multiple outdoor coils in one refrigerant circuit these sensors are used in order to ensure that all outdoor coils are used equally.

Master/slave water sensor (optional)

This sensor measures the common water temperature in the master/slave system capacity control. It is installed only in the case of master/slave units.

Defrost temperature sensors (heat pumps)

These sensors are used to determine the end of the defrost cycle for a given circuit.

4 - HARDWARE

4.7 Actuators

Electronic expansion valve

The electronic expansion valve (EXV) is used to adjust the refrigerant flow to changes in the operating conditions of the machine. The high degree of accuracy with which the piston is positioned provides precise control of the refrigerant flow and suction superheat.

Water flow switch

For units without internal pumps, the water flow switch configuration allows for the automatic control of the minimum water flow setpoint of the water flow switch. The configuration depends on the unit size and is made automatically at the start-up. If the flow switch fails, the alarm condition shuts off the unit.

Water heat exchanger pumps (optional)

The controller can regulate one or two fixed speed or variable speed water heat exchanger pumps and takes care of the automatic changeover between these pumps (see also "Pump control" on page 33).

Four-way valve (heat pumps only)

The control actuates the four-way valve for cooling / heating mode and defrost sessions.

4.8 Terminal block connections

Connections available at the user terminal block may vary depending on the selected options. The following table summarizes the connections at the user terminal block.

IMPORTANT: Some contacts can be accessed only when the unit operates in Remote mode.

Description	Board	Connector / Input / Output	Terminal	Remarks
On/Off Switch	SIOB (1)	-	32-33	Used for the unit on/off control (Remote mode)
Second Setpoint Switch	SIOB (1)	-	65-66	Used to switch between setpoints
Limit Switch #1	SIOB (1)	-	73-74	Used to control demand limit
Limit Switch #2	SIOB (1)	-	75-76	Used to control demand limit
Heat/Cool Select	SIOB (1)	J3 / DI-06	-	Used to switch between cooling and heating when the unit is in Remote mode (Heat pumps only)
Desuperheater switch	SIOB (1)	J3 / DI-07	-	Heat recovery is allowed
Analogue Limitation	SIOB (1)	-	43-44	4-10 mA input for setpoint reset
Water Pump #1	SIOB (1)	J6 / IN03-DO-03	-	The control can regulate one or two evaporator pumps and automatically change over between the two pumps
Water Pump #2	SIOB (1)	J6 / IN04-DO-04	-	As above
Running Relay	SIOB (1)	J23 / DO-05	-	Indicates if the unit is ready to start or operating
Alarm relay	SIOB (1)	J22 / DO-06	-	Indicates alarms
<i>Electric heating (unit size: 150 to 300)</i>				
Electrical Heat Stage #1	AUX1 (1)	-	51-52	Used to manage electric heating stage (1)
Electrical Heat Stage #2	AUX1 (1)	-	53-54	Used to manage electric heating stage (2)
Electrical Heat Stage #3	AUX1 (1)	-	55-56	Used to manage electric heating stage (3)
Boiler or Electrical Heat Stage #4	AUX1 (1)	-	57-58	Used to manage boiler heating or electric heating stage (4)
<i>Electric heating (unit size: 302 to 600)</i>				
Electrical Heat Stage #1	SIOB (2)	-	51-52	Used to manage electric heating stage (1)
Electrical Heat Stage #2	SIOB (2)	-	53-54	Used to manage electric heating stage (2)
Electrical Heat Stage #3	SIOB (2)	-	55-56	Used to manage electric heating stage (3)
Boiler or Electrical Heat Stage #4	SIOB (2)	-	57-58	Used to manage boiler heating or electric heating stage (4)

Volt free contact on/off and cooling/heating

On/off contacts and cooling/heating contacts are configured as follows:

	Off	Cooling	Heating	Auto
On/Off contact [ON_OFF_SW] *	open	closed	closed	open
Cooling/heating contact [HC_SW]	open	open	closed	closed

*Please note that for chillers only the On/Off contact configuration is applicable.

Off : Unit is stopped.

Cooling: Unit is allowed to start in Cooling.

Heating: Unit is allowed to start in Heating (heat pumps only).

Auto : Unit can run in Cooling or Heating in accordance with changeover values. If the auto changeover is enabled (Heat/Cool Select [HC_SEL], GENUNIT), the operating mode is selected based on OAT.

4 - HARDWARE

Volt-free setpoint selection contact

This dry contact input is used to switch between setpoints. It is active only when the control is in Remote mode.

	Cooling		Heating	
	Stp 1	Stp 2	Stp 1	Stp 2
Setpoint selection contact [SP_SW]	open	closed	open	closed


Volt-free demand limit selection contact

Three steps demand limit based on two dry contacts can be used to limit unit capacity.

	100%	Limit 1	Limit 2	Limit 3
	Demand limit switch 1 [LIM_SW1]	open	closed	open
Demand limit switch 2 [LIM_SW2]	open	open	closed	closed

Please note that when the LIM_SW1 is closed, then electric heating will be disabled.


5 - HOW TO USE THE CONNECT TOUCH INTERFACE



- | | |
|---|------------------------------------|
| ① Home button | ⑧ OAT (Outdoor Air Temperature) |
| ② Main menu button | ⑨ Condenser fans |
| ③ Heat exchanger (evaporator / condenser) | ⑩ EXV (Electronic Expansion Valve) |
| ④ Compressor | ⑪ Setpoint |
| ⑤ User lock (restricted access to menus) | ⑫ LWT (Leaving Water Temperature) |
| ⑥ Unit status | ⑬ EWT (Entering Water Temperature) |
| ⑦ Alarm display | ⑭ Water pump (optional) |

Connections

Connections are located on the bottom of the controller.



Features of Connect Touch user interface

- 4.3" colour touch screen with quick display of alarms, current unit operating status, etc.
- Resistive touch screen technology
- Web connectivity
- Custom language support

Connect Touch provides access to the following screens:


- Welcome screen (splash screen)
- Synoptic screen
- Operating mode selection screen
- Data/configuration screens
- Password entry and language selection screen
- Alarms screen
- Parameter modification screen
- Time schedule screen

WARNING

If the user interface is not used for a long period, the Welcome screen is displayed, and then it goes blank. The control is always active and the operating mode remains unchanged. Press anywhere on the screen and the Welcome screen will be displayed.

5 - HOW TO USE THE CONNECT TOUCH INTERFACE











5.1 Connect Touch menu structure











5 - HOW TO USE THE CONNECT TOUCH INTERFACE

5.2 Connect Touch buttons

HOME SCREEN

Home button	Main Menu button	Back button
 Home screen displayed	 Main Menu displayed	 Go back to the previous screen
Login button	Start/Stop button	Alarm button
 Basic access	 Unit is stopped	 No alarm active on the unit
 User access	 Unit is running	 Blinking icon: Partial alarm (one circuit affected by the existing alarm) or Alert (no action taken on the unit).  Steady icon: Alarm(s) active on the unit.

OTHER SCREENS


Login screen	Parameters screen(s)
 Login: Confirm advanced access login	 Save changes
 Logout: Reset the user level access and go to the splash screen	 Cancel your modifications
Force screen (override)	Navigation buttons
 Set force: Override the current command (if possible)	 Displayed when the menu includes more than one page: Go to the previous page
 Remove force: Remove the forced command	 Displayed when the menu includes more than one page: Go to the next page

5 - HOW TO USE THE CONNECT TOUCH INTERFACE

5.3 Read the welcome screen

The Welcome screen is the first screen shown after starting the user interface. It displays the application name as well as the current software version number.

- To exit the Welcome screen and go to the Home screen, press the **Home** button.



- Home button
- Software version number
- Information message box

Information message box


The information box displayed in the status bar at the bottom of the screen includes relevant messages regarding the current user action.

MESSAGE	STATUS
COMMUNICATION FAILURE!	Equipment controller did not respond while reading the table content.
ACCESS DENIED!	Equipment controller denies access to one of the tables.
LIMIT EXCEEDED! Save changes?	The value entered exceeds the parameter limit. Modifications have been made. The exit must be confirmed by pressing Save or Cancel.
HIGHER FORCE IN EFFECT!	Equipment controller rejects Force or Auto command.
Too many users connected ! Please try again later ...	Too many users connected at the same time (WEB INTERFACE ONLY).

5.4 Explore the synoptic screen

The Synoptic screen allows you to monitor the vapour-refrigeration cycle. The diagram indicates the current status of the unit, giving information on the unit capacity, the status of water heat exchanger pumps, and the pre-defined setpoint parameter.

All unit functions can be accessed by pressing the **Main menu** button.




The bell located in the upper-right part of the screen lights when any fault is detected.

IMPORTANT: The synoptic screen display may vary depending on pumps configuration.

5.5 Start/Stop the unit

With the unit in the Local off mode, press the **Start/Stop** button to display the list of operating modes and select the required mode.

Local On	Local On: The unit is in the local control mode and allowed to start.
Local Schedule	Local Schedule: The unit is in the local control mode and allowed to start if the period is occupied.
Network	Network: The unit is controlled by network commands and allowed to start if the period is occupied.
Remote	Remote: The unit is controlled by external commands and allowed to start if the period is occupied.
Master	Master: The unit operates as the master in the master/slave assembly and allowed to start if the period is occupied.




IMPORTANT: When entering the menu, please note that the currently selected item corresponds to the last running operating mode. This screen is displayed only when the unit is currently not running. If the unit was in the running state, then the Confirm stop message would be displayed.

5 - HOW TO USE THE CONNECT TOUCH INTERFACE

5.5 Start/Stop the unit (cont.)


To start the unit

1. Press the **Start/Stop** button.
2. Select the required Machine Mode.
3. The Welcome screen will be displayed.



To stop the unit

1. Press the **Start/Stop** button.
2. Confirm the unit shutdown by pressing **Confirm Stop** or cancel the unit shutdown by pressing the **Back** button.



5.6 Set the schedule


The control incorporates two time schedules, where the first one (OCCPC01S) is used for controlling the unit start/stop, whereas the second one (OCCPC02S) is used for controlling the dual setpoint.

The control offers the user the possibility of setting eight occupancy periods where each occupancy period includes the following elements to be defined:

- Day of the week: Select the days when the period is occupied.
- Occupancy time ("occupied from" to "occupied to"): Set occupancy hours for the selected days.
- Timed Override Extension: Extend the schedule if necessary. This parameter can be used in the case of some unplanned events. Example: If the unit is normally scheduled to run between 8:00 to 18:00, but one day you want the air-conditioning system to operate longer, then set this timed override extension. If you set the parameter to "2", then the occupancy will end at 20:00.

To set the unit start/stop schedule

1. Go to the Main menu.
2. Navigate to the Configuration menu (logged-in users only) and select **Schedule** (SCHEDULE).
3. Go to **OCCPC01S**.
4. Select appropriate check boxes to set the unit occupancy on specific days.
5. Define the time of occupancy.
6. When the time schedule is set, the selected period will be presented in the form of the green band on the timeline.
7. Press the **Save** button to save your changes or the **Cancel** button to exit the screen without making modifications.



- ① Selection of days for the time schedule
- ② Start/end of the schedule
- ③ Save
- ④ Cancel
- ⑤ Previous time period
- ⑥ Next time period

IMPORTANT: Only logged-in users are allowed to access the Configuration menu (see also "User login" on page 15).

5 - HOW TO USE THE CONNECT TOUCH INTERFACE


5.7 Manage display settings

The User Login screen allows the user to select the language of the controller, change the system of measurement (imperial or metric) and provide a password to gain access to more control options.

To access the User Login screen, press the **Login** button in the upper-right corner of the screen.

5.7.1 Security access settings

User-level security ensures that only authorised users are allowed to modify critical unit parameters.



- ① Cursor indicating the selected language
- ② Logged-in button
- ③ Logged-off button
- ④ Password dialog box
- ⑤ System of measurement: Metric/Imperial

IMPORTANT: Only logged-in users are allowed to access the Configuration menu.

WARNING

It is strongly recommended to change the default password of the user interface to exclude the possibility of changing any parameters by an unqualified person.

Only people qualified to manage the unit should be familiarized with the password.

5.7.2 User login

Only logged-in users can access configurable unit parameters. By default, user password is "11".

To log in as user

1. Press the **Login** button to open User Login Screen.
2. Press the Password box.



3. A dialog box appears.




4. Provide the password (11) and press OK.
5. The User Login screen appears.
6. Press the **Save** button to save your changes or the **Cancel** button to exit the screen without making modifications.

5.7.3 Password change

User password can be modified in the User Configuration menu.

To change your password

1. Go to the Main menu.
2. Navigate to the Configuration menu (logged-in users only) and select **User Configuration** (USERCONF) .
3. Select the User Password box and provide your new password.
4. Press **OK**. The User Configuration screen appears.
5. Press the **Save** button to save your changes or the **Cancel** button to exit the screen without making modifications.


5 - HOW TO USE THE CONNECT TOUCH INTERFACE

5.7.4 Display language

Display language can be modified in the User Login Screen on the user interface.

To change a display language

1. Press the **Login** button to open User Login Screen.
2. Select the new language of the display.



3. Press the **Save** button to save your changes or the **Cancel** button to exit the screen without making modifications.

IMPORTANT: Connect Touch allows users to add new languages to the control.

To learn more about language customization, please contact your local Manufacturer representative.

5.7.5 System of measurement

The control offers the possibility of selecting the system of measurement displayed on the user interface.

To change a system of measurement

1. Press the **Login** button to open User Login Screen.
2. Select the system of measurement.




3. Press the **Save** button to save your changes or the **Cancel** button to exit the screen without making modifications.

5.8 Monitor unit parameters

The Main menu screen provides access to the main control parameters, including general parameters, inputs and outputs status, etc.


- To access the menu, press the **Main menu** button located in the upper-left part of the Synoptic screen.
- Specific unit parameters can be accessed by pressing the icon corresponding to the desired category.
- To go back to the Synoptic screen, press the **Home** button.



5.8.1 General unit parameters

The General parameters screen provides access to a set of general unit parameters.

- To access the General parameters screen, go to the Main menu and select **General Parameters** (GENUNIT).
- Press the **Up/Down** buttons to navigate between the screens.




- ① Forceable point

5 - HOW TO USE THE CONNECT TOUCH INTERFACE

5.9 Modify unit parameters

The Configuration menu gives access to a number of user-modifiable parameters such as pump configuration, schedule menu, etc. The Configuration menu is password-protected (see also "User login" on page 15).




- Press the field corresponding to the parameter to be modified and introduce all the necessary changes.
- Press the **Up/Down** buttons to navigate between the screens.
- Once all the necessary modifications have been made, press the **Save** button to save your changes or the **Cancel** button to exit the screen without making modifications.

5.10 Override system configuration

In some cases it is possible to override system configuration. The override screen provides the option to issue the command overriding the current operation of the unit.

To access the override screen, press the forceable point of the data screen. Note that not all parameters can be overridden by the control.



- ① Forced value
- ② Set force
- ③ Auto

6 - WEB CONNECTION

6.1 Web interface


The Connect Touch control can be accessed via a web browser (Internet Explorer, Mozilla Firefox, etc.). Connection is from a PC using a web browser with Java.

CAUTION

Use firewalls and VPN for secure connection.

6.2 Open the web interface

To access the Connect Touch control, enter the IP address of the unit in the address bar of the web browser.



Unit default address: 169.254.0.1. This address can be changed.

IMPORTANT: Only two web connections can be authorised at the same time.

CAUTION

For security reasons the unit cannot be started / stopped via the web interface.

All other operations, including monitoring unit parameters or unit configuration, can be performed via the web browser interface.

6.3 Manage web browser settings

Minimum web browser configuration:

- Internet Explorer (version 8 or higher) or Mozilla Firefox (version 26 or higher). In the advanced connection options add the unit IP address to the exceptions list. Do not use a proxy server.
- Java platform (version 6 or higher). In the control panel, clear the *Keep temporary files on my computer* check box and use a direct connection.

IMPORTANT: Two users can be connected simultaneously with no priority between them. Note the last modification is always taken into account.

7 - SETTING UP CONNECT TOUCH – DISPLAY MENU STRUCTURE

7.1 Main menu

Icon	Displayed text*	Description	Name
	General Parameters	General parameters	GENUNIT
	Temperature	Temperatures	TEMP
	Pressure	Pressures	PRESSURE
	Setpoint	Setpoints	SETPOINT
	Inputs	Inputs status	INPUTS
	Outputs	Outputs status	OUTPUTS
	Pump Status	Pump status	PUMPSTAT
	DC Free Cooling Status	Free Cooling status	FCOOL_ST
	Miscellaneous Status	Miscellaneous status	MSC_STAT
	Runtime	Run times	RUNTIME
	Modes	Modes status	MODES
	Configuration Menu	Configuration menu	CONFIG

* Depends on the selected language (English by default).

CAUTION

Since specific units may not include additional features, some tables may contain parameters that cannot be configured for a given unit.

7 - SETTING UP CONNECT TOUCH – DISPLAY MENU STRUCTURE



General Parameters Menu – GENUNIT

Point name	Status	Unit	Displayed text*	Description
1 CTRL_TYP	0 to 2	-	Local=0 Net.=1 Remote=2	Operating mode: 0 = Local, 1 = Network, 2 = Remote
2 STATUS	xxx	-	Running Status	Unit running status: 0 = Off, 1 = Running, 2 = Stopping, 3 = Delay, 4 = Trip out, 5 = Ready, 6 = Override, 7 = Defrost, 8 = Run Test, 9 = Test
3 ALM	xxx	-	Alarm State	Alarm status
4 min_left	0 to 0	min	Minutes Left for Start	Minutes left before the unit start-up
5 HEATCOOL			Heat/Cool status	Heating/Cooling status
6 HC_SEL	0 to 2	-	Heat/Cool Select	Heating/Cooling selection
7			0=Cool 1=Heat 2=Auto	0=Cool, 1=Heat, 2=Auto
8 SP_SEL	0 to 2	-	Setpoint Select	Setpoint select
9			0=Auto. 1=Spt1. 2=Spt2	0 = Auto, 1 = Setpoint 1, 2 = Setpoint 2
10 SP_OCC	no/yes	-	Setpoint Occupied?	Setpoint occupied?
11 CHIL_S_S	disable/enable	-	Net.: Cmd Start/Stop	Unit start/stop via Network: When the unit is in Network mode, start/stop command can be forced
12 CHIL_OCC	no/yes	-	Net.: Cmd Occupied	Unit time schedule via Network: When the unit is in Network mode, the forced value can be used instead of the real occupancy state
13 CAP_T	0 to 100	%	Percent Total Capacity	Total unit capacity
14 CAPA_T	0 to 100	%	Circuit A Total Capacity	Total capacity, circuit A
15 CAPB_T	0 to 100	%	Circuit B Total Capacity	Total capacity, circuit B
16 DEM_LIM	0 to 100	%	Active Demand Limit Val	Active demand limit value: When the unit is Network mode, the minimum value will be used compared to the status of the external limit switch contact and the demand limit switch setpoint
17 SP	-	°C / °F	Current Setpoint	Current setpoint
18 CTRL_PNT	-20.0 to 67.0 -4.0 to 153.0	°C °F	Control Point	Control point: Water temperature that the unit must produce
19 EMSTOP	disable/enable	-	Emergency Stop	Emergency stop

* Depends on the selected language (English by default).



Temperature Menu – TEMP

Point name	Status	Unit	Displayed text*	Description
1 EWT	-	°C / °F	Entering Water Temp	Entering water temperature: Used for capacity control
2 LWT	-	°C / °F	Leaving Water Temp	Leaving water temperature: Used for capacity control
3 OAT	-	°C / °F	External Temperature	Outdoor air temperature: Used to determine a number of control mechanisms such as heat/cool changeover, heater operation, defrost cycle
4 CHWSTEMP	-	°C / °F	Common Master/Slave Temp	Common master/slave temperature
5 SCT_A	-	°C / °F	Saturated Cond Tmp A	Saturated condensing temperature, circuit A
6 SST_A	-	°C / °F	Saturated Suction Tmp A	Saturated suction temperature, circuit A
7 SCT_B	-	°C / °F	Saturated Cond Tmp B	Saturated condensing temperature, circuit B
8 SST_B	-	°C / °F	Saturated Suction Tmp B	Saturated suction temperature, circuit B
9 DEFRT_A	-	°C / °F	Defrost Temp Cir A	Defrost temperature, circuit A (heat pumps only)
10 DEFRT_2	-	°C / °F	Defrost Temp Second Coil	Defrost temperature on the second coil on circuit A (heat pumps only)
11 sgtc1	-	°C / °F	Suction Gas Temp Coil 1	Suction gas temperature coil 1
12 sgtc2	-	°C / °F	Suction Gas Temp Coil 2	Suction gas temperature coil 2

* Depends on the selected language (English by default).

7 - SETTING UP CONNECT TOUCH – DISPLAY MENU STRUCTURE



Pressure Menu – PRESSURE

Point name	Status	Unit	Displayed text*	Description
1 DP_A	-	kPa / PSI	Discharge Pressure A	Compressor discharge pressure, circuit A
2 SP_A	-	kPa / PSI	Suction Pressure A	Compressor suction pressure, circuit A
3 DP_B	-	kPa / PSI	Discharge Pressure B	Compressor discharge pressure, circuit B
4 SP_B	-	kPa / PSI	Suction Pressure B	Compressor suction pressure, circuit B

* Depends on the selected language (English by default).



Inputs Menu – INPUTS

Point name	Status	Unit	Displayed text*	Description
1 ONOFF_SW	open/close	-	Remote On/Off Switch	Remote On/Off switch
2 HC_SW	open/close	-	Remote Heat/Cool Switch	Remote Heat/Cool switch
3 on_ctrl	xxx	-	Current Control	Current control status: Off, On Cool, On Heat, On Auto
4 SETP_SW	open/close	-	Remote Setpoint Switch	Remote setpoint switch
5 LIM_SW1	open/close	-	Limit Switch 1	Demand limit switch 1
6 LIM_SW2	open/close	-	Limit Switch 2	Demand limit switch 2
7 LIM_ANAL	-	mA	Limit Analog Input	Limit Analog Input 4-20 mA
8 FLOW_SW	open/close	-	Flow Switch	Water exchanger flow switch
9 leak_v	-	V	Leakage detector #1 val	Leakage detector 1
10 leak_2_v	-	V	Leakage detector #2 val	Leakage detector 2
11 DSHT_SW	open/close	-	Desuperheater Switch	Desuperheater switch
12 PWRIN_ST	open/close	-	Power Input Stable	Power input stable
13 HP_SWA	open/close	-	HP Switch Circuit A	High pressure switch, circuit A
14 HP_SWA3B	open/close	-	HP Switch Circuit A3/B	High pressure switch, circuit A or circuit B

* Depends on the selected language (English by default).



Outputs Menu – OUTPUTS

Point name	Status	Unit	Displayed text*	Description
1 CP_A1	off/on	-	Compressor A1 Output	Compressor A1 status
2 CP_A2	off/on	-	Compressor A2 Output	Compressor A2 status
3 CP_A3	off/on	-	Compressor A3 Output	Compressor A3 status
4 FAN_A1LS	off/on	-	Fan A1LS Output	Fan A1 low speed status
5 FAN_A1HS	off/on	-	Fan A1HS Output	Fan A1 high speed status
6 FAN_A2LS	off/on	-	Fan A2LS Output	Fan A2 low speed status
7 FAN_A2HS	off/on	-	Fan A2HS Output	Fan A2 high speed status
8 HD_POS_A	-	%	Head Pressure Position A	Head pressure, circuit A
9 EXVPosA	-	%	EXV Position Circuit A	EXV position, circuit A
10 EXVNPoSA	-	%	EXV Next Pos Circuit A	EXV next position, circuit A
11 RV_A	off/on	-	4 Way Refrigerant ValveA	4-way refrigerant valve, circuit A: Used to manage cooling/heating/defrost operation (heat pumps)
12 CP_B1	off/on	-	Compressor B1 Output	Compressor B1 status
13 CP_B2	off/on	-	Compressor B2 Output	Compressor B2 status
14 FAN_B1LS	off/on	-	Fan B1LS Output	Fan B1 low speed status
15 FAN_B1HS	off/on	-	Fan B1HS Output	Fan B1 high speed status
16 HD_POS_B	-	%	Head Pressure Position B	Head pressure, circuit B
17 EXVPosB	-	%	EXV Position Circuit B	EXV position, circuit B
18 EXVNPoSB	-	%	EXV Next Pos Circuit B	EXV next position, circuit B
19 RV_B	off/on	-	4 Way Refrigerant ValveB	4-way refrigerant valve, circuit B: Used to manage cooling/heating/defrost operation (heat pumps)
20 C_HEATER	off/on	-	Cooler & Drain Pan Heatr	Water exchanger / Drain pan heater
21 BOILER	off/on	-	Boiler Command	Boiler status
22 EHS_STEP	-	-	Electrical Heat Stage	Electric heating stages
23 ALARM_R	off/on	-	Alarm Relay Status	Alarm relay status
24 RUN_R	off/on	-	Running Status	Unit ON relay
25 OIL_VALV	off/on	-	Oil Valve Status	Oil valve status

* Depends on the selected language (English by default).

7 - SETTING UP CONNECT TOUCH – DISPLAY MENU STRUCTURE



Pump Status Menu – PUMPSTAT

Point name	Status	Unit	Displayed text*	Description	
1	CPUMP_1	off/on	-	Water Pump #1 Command	Water pump 1 command
2	CPUMP_2	off/on	-	Water Pump #2 Command	Water pump 2 command
3	ROT_PUMP	no/yes	-	Rotate Pumps Now?	Water pumps rotation
4	W_P_IN	-	kPa / PSI	Inlet Water Pressure	Inlet water pressure
5	W_P_OUT	-	kPa / PSI	Outlet Water Pressure	Outlet water pressure
6	WP_CALIB	no/yes	-	Water Pressure Calibrat	Water pressure calibration
7	WP_OFFST	-	kPa / PSI	Water Pressure Offset	Water pressure offset
8	DP_FILTR	-	kPa / PSI	Delta Water Press. Filt	Delta water pressure filtration
9	WP_MIN	-	kPa / PSI	Mini Water Pressure	Minimum water pressure
10	WAT_FLOW	-	l/s / GPS	Water Flow	Water flow status
11	CAPPOWER	-	kW	Actual Power Capacity	Actual power capacity
12	p_dt_spt	-	^C / ^F	Water DT Setpoint	Water discharge temperature setpoint
13	p_dp_spt	-	kPa / PSI	Water DP Setpoint	Water discharge pressure setpoint
14	drvp_pct	-	%	Pump Drive Percent	Pump drive percent
15	drvp_pwr	-	kW	Pump Drive Power	Pump drive power
16	drvp_i	-	A	Pump Drive Amps	Pump drive (A)
17	drvp_ver	xxx	-	Pump Drive Version	Pump drive version

* Depends on the selected language (English by default).



DC Free Cooling Status Menu – FCOOL_ST

Point name	Status	Unit	Displayed text*	Description	
1	fc_oat	0 to 0	°C / °F	Free Cooling OAT	Free Cooling OAT
2	fc_lwt	0 to 0	°C / °F	FC Leaving Water Temp	Free Cooling LWT
3	fc_wloop	0 to 0	°C / °F	FC Water Loop Temp	Free Cooling water loop temperature
4	m_fcool	no/yes	-	Free Cooling Mode Active	Free Cooling mode – status
5	fc_cap	0 to 100	%	FC Capacity	Capacity in Free Cooling mode
6	fc_fanst	0 to 7	-	FC Fan Stage	Number of fan stages in Free Cooling
7	FC_HOUR	0 to 999999	hour	FC Operating Hours	Free Cooling running time
8	FC_FAN1S	0 to 999999	-	FC Fan Stage 1 Start	Number of starts, FC fan stage 1
9	FC_FAN1H	0 to 999999	-	FC Fan Stage 1 Hours	Operating hours, FC fan stage 1
10	FC_FAN2S	0 to 999999	-	FC Fan Stage 2 Start	Number of starts, FC fan stage 2
11	FC_FAN2H	0 to 999999	-	FC Fan Stage 2 Hours	Operating hours, FC fan stage 2
12	FC_FAN3S	0 to 999999	-	FC Fan Stage 3 Start	Number of starts, FC fan stage 3
13	FC_FAN3H	0 to 999999	-	FC Fan Stage 3 Hours	Operating hours, FC fan stage 3
14	FC_FAN4S	0 to 999999	-	FC Fan Stage 4 Start	Number of starts, FC fan stage 4
15	FC_FAN4H	0 to 999999	-	FC Fan Stage 4 Hours	Operating hours, FC fan stage 4
16	FC_FAN5S	0 to 999999	-	FC Fan Stage 5 Start	Number of starts, FC fan stage 5
17	FC_FAN5H	0 to 999999	-	FC Fan Stage 5 Hours	Operating hours, FC fan stage 5
18	FC_FAN6S	0 to 999999	-	FC Fan Stage 6 Start	Number of starts, FC fan stage 6
19	FC_FAN6H	0 to 999999	-	FC Fan Stage 6 Hours	Operating hours, FC fan stage 6
20	FC_FAN7S	0 to 999999	-	FC Fan Stage 7 Start	Number of starts, FC fan stage 7
21	FC_FAN7H	0 to 999999	-	FC Fan Stage 7 Hours	Operating hours, FC fan stage 7

* Depends on the selected language (English by default).

7 - SETTING UP CONNECT TOUCH – DISPLAY MENU STRUCTURE



Miscellaneous Status Menu – MSC_STAT

Point name	Status	Unit	Displayed text*	Description	
1	m_ecomp	no/yes	-	Eco Pump Mode Active	Pump is stopped periodically when the unit is in Standby mode
2				HYBRID HP	Heat pump and additional options setting
3	HH_WST	-40.0 to 100.0 -40.0 to 212.0	°C °F	Hybrid Water System Temp	Heat pump water system temperature (temp. of water that goes into a building)
4	hh_blwt	0 to 0	°C / °F	Boiler Leaving Water Tmp	Boiler leaving water temperature
5	hh_dhwt	0 to 0	°C / °F	DHW Collector LWT	DHW leaving water
6	HH_DHWDM	no/yes	-	DHW Demand ?	DHW demand status
7	HH_OPHR	no/yes	-	Off-Peak Hour ?	Peak hour status
8	hh_3wvst		-	3Ways Valve Status	3-way valve status
9	hh_boflt	no/yes	-	Boiler Fault	Boiler fault
10	m_hhpb	no/yes	-	Boiler Mode Active	Boiler mode status: Additional heating or DHW mode active
11	m_hhph	no/yes	-	Heat Pump Mode Active	Heat pump mode status
12	hh_bcap	0 to 100	%	Boiler Capacity	Current boiler capacity
13	HH_HPHR	0 to 999999	hour	Heat Pump Operating Hrs	Operating hours, heat pump
14	HH_BHR	0 to 999999	hour	Boiler Operating Hours	Operating hours, boiler

* Depends on the selected language (English by default).



Runtime Menu – RUNTIME

Point name	Status	Unit	Displayed text*	Description	
1	hr_mach	-	hour	Machine Operating Hours	Unit operating hours
2	st_mach	-	-	Machine Starts Number	Number of unit starts
3	hr_cp_a1	-	hour	Compressor A1 Hours	Operating hours, compressor A1
4	st_cp_a1	-	-	Compressor A1 Starts	Number of starts, compressor A1
5	hr_cp_a2	-	hour	Compressor A2 Hours	Operating hours, compressor A2
6	st_cp_a2	-	-	Compressor A2 Starts	Number of starts, compressor A2
7	hr_cp_a3	-	hour	Compressor A3 Hours	Operating hours, compressor A3
8	st_cp_a3	-	-	Compressor A3 Starts	Number of starts, compressor A3
9	hr_cp_b1	-	hour	Compressor B1 Hours	Operating hours, compressor B1
10	st_cp_b1	-	-	Compressor B1 Starts	Number of starts, compressor B1
11	hr_cp_b2	-	hour	Compressor B2 Hours	Operating hours, compressor B2
12	st_cp_b2	-	-	Compressor B2 Starts	Number of starts, compressor B2
13	hr_cpum1	-	hour	Water Pump #1 Hours	Operating hours, water pump 1
14	hr_cpum2	-	hour	Water Pump #2 Hours	Operating hours, water pump 2
15	hr_fana1	-	hour	Circuit A Fan #1 Hours	Operating hours, fan 1, circuit A
16	st_fana1	-	-	Circuit A Fan #1 Starts	Number of starts, fan 1, circuit A
17	hr_fana2	-	hour	Circuit A Fan #2 Hours	Operating hours, fan 2, circuit A
18	st_fana2	-	-	Circuit A Fan #2 Starts	Number of starts, fan 2, circuit A
19	hr_fanb1	-	hour	Circuit B Fan #1 Hours	Operating hours, fan 1, circuit B
20	st_fanb1	-	-	Circuit B Fan #1 Starts	Number of starts, fan 1, circuit B
21	nb_def_a	-	-	Circuit A Defrost Number	Defrost session number, circuit A
22	nb_def_b	-	-	Circuit B Defrost Number	Defrost session number, circuit B

* Depends on the selected language (English by default).

7 - SETTING UP CONNECT TOUCH – DISPLAY MENU STRUCTURE

Modes Menu – MODES

Point name	Status	Unit	Displayed text*	Description
1 m_delay	no/yes	-	Delay Active	Delay active (when switching between modes)
2 m_2ndspt	no/yes	-	Second Setpoint Active	Second setpoint active (during unoccupied periods)
3 m_reset	no/yes	-	Reset Active	Reset is active
4 m_limit	no/yes	-	Demand Limit Active	Demand limit active
5 m_ramp	no/yes	-	Ramp Loading Active	Ramp loading active
6 m_cooler	no/yes	-	Cooler Heater Active	Water exchanger heater active
7 m_pmprot	no/yes	-	Pump Rot Active	Pump rotation active
8 m_pmpper	no/yes	-	Pump Per Active	Periodical pump start active
9 m_night	no/yes	-	Night Low Noise Active	Night low noise mode active
10 m_SM	no/yes	-	System Manager Active	System Manager active
11 m_leadla	no/yes	-	Master Slave Active	Master/Slave active
12 m_auto	no/yes	-	Auto Changeover Active	Auto changeover active
13 m_heater	no/yes	-	Electric Heat Active	Electric heating active
14 m_lo_ewt	no/yes	-	Heating Low EWT Lockout	Heating low EWT lockout
15 m_boiler	no/yes	-	Boiler Active	Boiler active
16 m_ice	no/yes	-	Ice Mode Active	Ice mode active
17 m_defr_a	no/yes	-	Defrost Active On Cir A	Defrost active, circuit A
18 m_defr_b	no/yes	-	Defrost Active On Cir B	Defrost active, circuit B
19 m_sst_a	no/yes	-	Low Suction Circuit A	Low suction temperature, circuit A
20 m_sst_b	no/yes	-	Low Suction Circuit B	Low suction temperature, circuit B
21 m_dgt_a	no/yes	-	High DGT Circuit A	High discharge gas temperature, circuit A
22 m_dgt_b	no/yes	-	High DGT Circuit B	High discharge gas temperature, circuit B
23 m_hp_a	no/yes	-	High Pres Override Cir A	High pressure override, circuit A
24 m_hp_b	no/yes	-	High Pres Override Cir B	High pressure override, circuit B
25 m_sh_a	no/yes	-	Low SuperHeat Circuit A	Low superheat, circuit A
26 m_sh_b	no/yes	-	Low SuperHeat Circuit B	Low superheat, circuit B

* Depends on the selected language (English by default).





Setpoint Menu – SETPOINT

Point name	Status	Default	Unit	Displayed text*	Description	
1 csp1		-28.9 to 20.0	7.0	°C	Cooling Setpoint 1	Cooling setpoint 1
		-20.0 to 68.0	44.6	°F		
2 csp2		-28.9 to 20.0	7.0	°C	Cooling Setpoint 2	Cooling setpoint 2
		-20.0 to 68.0	44.6	°F		
3 hsp1		25.0 to 55.0	38.0	°C	Heating Setpoint 1	Heating setpoint 1
		77.0 to 131.0	100.4	°F		
4 hsp2		25.0 to 55.0	38.0	°C	Heating Setpoint 2	Heating setpoint 2
		77.0 to 131.0	100.4	°F		
5 ramp_sp		0.1 to 1.1	0.6	°C	Heating Ramp Loading	Ramp loading
		0.2 to 2.0	1.0	°F		
6 cauto_sp		3.9 to 50.0	23.9	°C	Cool Changeover Setpt	Cool changeover setpoint
		39.0 to 122.0	75.0	°F		
7 hauto_sp		0 to 46.1	17.8	°C	Heat Changeover Setpt	Heat changeover setpoint
		32.0 to 115.0	64.0	°F		
8 lim_sp1		0 to 100	100	%	Switch Limit Setpoint 1	Switch limit setpoint 1
9 lim_sp2		0 to 100	100	%	Switch Limit Setpoint 2	Switch limit setpoint 2
10 lim_sp3		0 to 100	100	%	Switch Limit Setpoint 3	Switch limit setpoint 3
11 min_sct		26.7 to 60.0	40.0	°C	Desuperheater Min Sct	Desuperheater minimum saturated condensing temperature
		80.0 to 140.0	104.0	°F		

* Depends on the selected language (English by default).

7 - SETTING UP CONNECT TOUCH – DISPLAY MENU STRUCTURE

7.2 Configuration menu (CONFIG)

Icon	Displayed text*	Description	Name
	General Config	General configuration	GENCONF
	Pump Configuration	Pump configuration	PUMPCONF
	Heat/Cool Config	Heat / Cool configuration	HCCONFIG
	Reset Config	Reset configuration	RESETCFG
	User Configuration	User configuration	USERCONF
	Miscellaneous Configuration	Miscellaneous configuration menu	MISC_CFG
	Schedule	Schedule menu	SCHEDULE
	Holiday	Holiday menu	HOLIDAY
	Broadcast	Broadcast menu	BROADCAST
	Date/Time	Date/time configuration	DATETIME
	Control Identification	Control identification	CTRL_ID
	Network Parameters	Network parameters (Modbus configuration)	NETWORKS

* Depends on the selected language (English by default).

CAUTION

Since specific units may not include additional features, some tables may contain parameters that cannot be configured for a given unit.

7 - SETTING UP CONNECT TOUCH – DISPLAY MENU STRUCTURE



General Config Menu – GENCONF

Point name	Status	Default	Unit	Displayed text*	Description	
1	lead_cir	0 to 2	0	-	Cir Priority Sequence	Circuit priority sequence
				-	0=Auto 1=A Lead 2=B Lead	0 = Automatic changeover 1 = Circuit A lead 2 = Circuit B lead
2	seq_typ	no/yes	no	-	Staged Loading Sequence	Staged loading sequence (dual-circuit units)
3	ramp_sel	no/yes	no	-	Ramp Loading Select	Ramp loading sequence
4	off_on_d	1 to 15	1	min	Unit Off to On Delay	Unit OFF to ON delay
5	nh_limit	0 to 100	100	%	Night Capacity Limit	Night capacity limitation
6	nh_start	00:00	00:00	-	Night Mode Start Hour	Night mode start hour
7	nh_end	00:00	00:00	-	Night Mode End Hour	Night mode end hour

* Depends on the selected language (English by default).



Pump Configuration Menu – PUMPCONF

Point name	Status	Default	Unit	Displayed text*	Description	
1	pump_seq	0 to 4	0	-	Water Pumps Sequence	Water pumps sequence
				-	0 = No Pump 1 = One Pump Only 2 = Two Pumps Auto 3 = Pump#1 Manual 4 = Pump#2 Manual	0 = No pump 1 = One pump only (units with one pump) 2 = Two pumps automatic control 3 = Pump 1 selected (units with two pumps) 4 = Pump 2 selected (units with two pumps)
2	pump_del	24 to 3000	48	hour	Pump Auto Rotation Delay	Pump automatic rotation delay
3	pump_per	no/yes	no	-	Pump Sticking Protection	Pump sticking protection
4	pump_sby	no/yes	no	-	Stop Pump During Standby	Pump stopped when the unit is in standby (Heat pumps only)
5	pump_loc	no/yes	yes	-	Flow Checked if Pump Off	Water flow is checked when the pump is off

* Depends on the selected language (English by default).



Heat/Cool Config Menu – HCCONFIG

Point name	Status	Default	Unit	Displayed text*	Description	
1	auto_sel	no/yes	no	-	Auto Changeover Select	Heating/Cooling automatic changeover
2	cr_sel	0 to 3	0	-	Cooling Reset Select	Cooling reset
3	hr_sel	0 to 3	0	-	Heating Reset Select	Heating reset
				-	0=None, 1=OAT, 2=Delta T, 3= Analog 4-20mA	0 = No reset 1 = Reset based on OAT 2 = Reset based on delta T 3 = Reset based on analog input 4-20 mA
4	heat_th	-20.0 to 0.0 -4.0 to 32.0	-15.0 5.0	°C °F	Heating OAT Threshold	Heating OAT threshold
5	boil_th	-15.0 to 15.0 5.0 to 59.0	-9.9 14.2	°C °F	Boiler OAT Threshold	Boiler OAT threshold (heat pumps only)
6	ehs_th	-5.0 to 21.1 23.0 to 70.0	5.0 41.0	°C °F	Elec Stage OAT Threshold	Electric heating stage OAT threshold
7	both_sel	no/yes	no	-	HSM Both Command Select	HSM command
8	ehs_back	no/yes	no	-	1 Elec Stage For Backup	Electric heating stage for back-up
9	ehs_pull	0 to 60	0	min	Electrical Pulldown Time	Electrical pull-down time: It defines the time between starting the unit and determining whether the electric heating stage should be started
10	ehs_defr	no/yes	no	-	Quick EHS For Defrost	Quick electric heating used for defrost

* Depends on the selected language (English by default).

7 - SETTING UP CONNECT TOUCH – DISPLAY MENU STRUCTURE



Reset Config Menu– RESETCFG

Point name	Status	Default	Unit	Displayed text*	Description
1				COOLING RESET	Cooling reset parameters
2	oatcr_no	-10.0 to 51.7 14.0 to 125.0	°C °F	OAT No Reset Value	OAT no reset value
3	oatcr_fu	-10.0 to 51.7 14.0 to 125.0	°C °F	OAT Full Reset Value	OAT full reset value
4	dt_cr_no	0 to 13.9 0 to 25.0	^C ^F	Delta T No Reset Value	Delta T no reset value
5	dt_cr_fu	0 to 13.9 0 to 25.0	^C ^F	Delta T Full Reset Value	Delta T full reset value
6	l_cr_no	0 to 20	mA	Current No Reset Value	Current no reset value
7	l_cr_fu	0 to 20	mA	Current Full Reset Value	Current full reset value
8	cr_deg	-16.7 to 16.7 -30.0 to 30.0	^C ^F	Cooling Reset Deg. Value	Cooling reset deg. value
9				HEATING RESET	Heating reset parameters
10	oathr_no	-10.0 to 51.7 14.0 to 125.0	°C °F	OAT No Reset Value	OAT no reset value
11	oathr_fu	-10.0 to 51.7 14.0 to 125.0	°C °F	OAT Full Reset Value	OAT full reset value
12	dt_hr_no	0 to 13.9 0 to 25.0	^C ^F	Delta T No Reset Value	Delta T no reset value
13	dt_hr_fu	0 to 13.9 0 to 25.0	^C ^F	Delta T Full Reset Value	Delta T full reset value
14	l_hr_no	0 to 20	mA	Current No Reset Value	Current no reset value
15	l_hr_fu	0 to 20	mA	Current Full Reset Value	Current full reset value
16	hr_deg	-16.7 to 16.7 -30.0 to 30.0	^C ^F	Heating Reset Deg. Value	Heating reset deg. value

* Depends on the selected language (English by default).



User Configuration Menu – USERCONF

Point name	Status	Default	Unit	Displayed text*	Description
1	use_pass	-	11	-	User Password The password required to access User Configuration menu
2	alert_r	no/yes	no	-	Alarm Relay for Alerts? Alarm relay status. Alarm output relay is used for "alarm" + "alert"

* Depends on the selected language (English by default).



Miscellaneous Configuration Menu – MISC_CFG

Point name	Status	Default	Unit	Displayed text*	Description
1				HYBRID HP CONFIG	Heat pump configuration
2	hh_dtmax	30 to 600	360	min	Max DHW Cycle Time Maximum DHW cycle time
3	hh_minht	-25.0 to 5.0 -13.0 to 41.0	-10.0 14.0	°C °F	Min OAT in Mech Heating Minimum OAT when running mechanical heating
4	hh_oatph	-20.0 to 25.0 -4.0 to 77.0	7.0 44.6	°C °F	OAT HP Stop Peak Hour OAT heat pump stop peak hour
5	hh_oatop	-20.0 to 25.0 -4.0 to 77.0	2.0 35.6	°C °F	OAT HP Stop Off-Peak Hr OAT heat pump stop off-peak hour

* Depends on the selected language (English by default).



Schedule Menu – SCHEDULE

Point name	Status	Default	Unit	Displayed text*	Description
1	OCCPC01S	-	-	-	OCCPC01S - Schedule Menu Unit on/off time schedule
2	OCCPC02S	-	-	-	OCCPC02S - Schedule Menu Unit setpoint selection time schedule

* Depends on the selected language (English by default).

7 - SETTING UP CONNECT TOUCH – DISPLAY MENU STRUCTURE



Holiday Menu – HOLIDAY

	Point name	Status	Default	Unit	Displayed text*	Description
1	HOL-MON	0-12	0	-	Holiday Start Month	Holiday start month
2	HOL-DAY	0-31	0	-	Start Day	Holiday start day
3	HOL-LEN	0-99	0	-	Duration (days)	Holiday duration (days)

* Depends on the selected language (English by default).



Broadcast Menu – BROADCAST (BROADCASTS)

	Point name	Status	Default	Unit	Displayed text*	Description
1	broadcst	0 to 2	2		Activate	Not applicable
OAT Broadcast						
2	oatbusnm	0 to 239	0		Bus	Bus number of the unit with the outdoor temperature sensor
3	oatlocad	0 to 239	0		Element	Element number of the unit with outdoor temperature
4	dayl_sel	disable/enable	disable		Daylight Savings Select	Summer/winter time activation (Daylight saving selection)
Daylight Savings Select – Summer time (entering)						
5	Startmon	1 to 12	3		Month	Month
6	Startdow	1 to 7	7		Day of Week (1=Monday)	Day of the week (1 = Monday)
7	Startwom	1 to 5	5		Week Number of Month	Week of the month
Daylight Savings Select – Winter time (leaving)						
8	Stopmon	1 to 12	10		Month	Month
9	Stopdow	1 to 7	7		Day of Week (1=Monday)	Day of the week (1 = Monday)
10	Stopwom	1 to 5	5		Week Number of Month	Week of the month

* Depends on the selected language (English by default).



Date/Time Menu – DATETIME

	Point name	Status	Default	Unit	Displayed text*	Description
Date (DD/MM/YY)						
1	d_of_m	1 to 31	-		Day of month	Day of the month
2	month	1 to 12	-		Month of year	Month
3	year	0 to 99	-		Year	Year
4	dow	Monday-Sunday	-		Day of Week	Day of the week
Time (HH:MM)						
5	hour	0 to 24	hour		Hour	Hour
6	minute	0 to 59	min		Minute	Minutes
Daylight Saving Time On						
7	dlig_on	no/yes	-		Daylight sav. time on	Daylight saving time on/off
8		no/yes	-		Today is a holiday	The present day is a holiday
9	tom_hol	no/yes	-		Tomorrow is a holiday	The following day is a holiday

* Depends on the selected language (English by default).





Control Identification Menu – CTRL_ID

	Point name	Status	Default	Unit	Displayed text*	Description
1			AQLD / AQILD		Device description	Device
2					Location description	Location
3			ECG-SR-XXY		Software Part Number	Software version
4					Serial Number	Serial number (MAC address)

* Depends on the selected language (English by default).

7 - SETTING UP CONNECT TOUCH – DISPLAY MENU STRUCTURE

7.3 Network Parameters menu (NETWORKS)

Icon	Displayed text*	Description	Name
	ModbusRTU Config.	Modbus RTU configuration	MODBUSRS
	Modbus TCP/IP Config.	Modbus over TCP/IP configuration	MODBUSIP

* Depends on the selected language (English by default).

NOTE: To learn more about the Modbus option and its configuration, please refer to Modbus documentation.

CAUTION

Since specific units may not include additional features, some tables may contain parameters that cannot be configured for a given unit.



ModbusRTU Config Menu – MODBUSRS




Point name	Status	Default	Unit	Displayed text*	Description	
1	modrt_en	no/yes	0	-	RTU Server Enable	RTU server enabled
2	ser_UID	1 to 255	1	-	Server UID	Server unique identification
3	metric	no/yes	1	-	Metric Unit	Metric unit selection
4	swap_b	0 to 1	0	-	Swap Bytes	Swap bytes option
5				0 = Big Endian		0 = Big Endian
6				1 = Little Endian		1 = Little Endian
7	baudrate	9600 to 38400	9600	-	Baudrate	Baud rate
8	parity	0 to 4	0	-	Parity	Parity
9				0 = no parity		0 = no parity
10				1 = odd parity		1 = odd parity
11				2 = even parity		2 = even parity
12				3 = force parity low		3 = force parity low
13				4 = force parity high		4 = force parity high
14	stop_bit	0 to 1	0	-	Stop bit number	Stop bit number
15				0= one stop bit		0 = one stop bit
16				1= two stop bit		1 = two stop bit



Modbus TCP/IP Config Menu – MODBUSIP

Point name	Status	Default	Unit	Displayed text*	Description	
1	modip_en	no/yes	0	-	TCP/IP Server Enable	TCP/IP Server Enable
2	ser_UID	1 to 255	1	-	Server UID	Server unique identification
3	port_nbr	0 to 65535	502	-	IP Port Number	IP Port Number
4	metric	no/yes	1	-	Metric Unit	Metric unit selection
5	swap_b	0 to 1	0	-	Swap Bytes	Swap bytes option
6				0 = Big Endian		0 = Big Endian
7				1 = Little Endian		1 = Little Endian

7.4 Alarm menu

Icon	Displayed text*	Description	Name
	Reset Alarms	Alarm reset	ALARMRST
	Current Alarms	Current alarms	CUR_ALM
	Alarm History	Alarm history	ALMHIST1

* Depends on the selected language (English by default).

8 - STANDARD CONTROL OPERATIONS AND OPTIONS

8.1 Unit start/stop control

The unit state is determined based on a number of factors, including its operating type, active overrides, open contacts, master/slave configuration, or alarms triggered due to operating conditions.

The table given below summarizes the unit control type [ctrl_typ] and its running status with regard to the following parameters:

- **Operating type:** This operation type is selected using the Start/Stop button on the user interface.

LOFF	Local off
L-C	Local on
L-SC	Local schedule
Rem	Remote
Net	Network
Mast	Master unit

- **Start/stop force command [CHIL_S_S]:** Start/stop force command can be used to control the chiller state in the Network mode.
Command set to stop: The unit is halted.
Command set to start: The unit runs in accordance with schedule 1.
- **Remote start/stop contact status [Onoff_sw]:** Start/stop contact status can be used to control the chiller state in the Remote operating type.
- **Master control type [ms_ctrl]:** When the unit is the master unit in a two-chiller master/slave arrangement, the master unit may be set to be controlled locally, remotely or via network.
- **Start/stop schedule [chil_occ]:** Occupied or unoccupied status of the unit.
- **Network emergency stop command [EMSTOP]:** If activated, the unit shuts down regardless of the active operating type.
- **General alarm:** The unit shuts down due to failure.

Active operating type						Parameter status						Result	
LOFF	L-C	L-SC	Rem	Net	Mast	Start/stop force command	Remote start/stop contact	Master control type	Start/stop time schedule	Network emergency shutdown	General alarm	Control type	Unit state
						-	-	-	-	enable	-	-	off
						-	-	-	-	-	yes	-	off
						active	-	-	-	-	-	local	off
							active	-	unoccupied	-	-	local	off
							active	-	off	-	-	remote	off
							active	-	unoccupied	-	-	remote	off
							active	disable	-	-	-	network	off
							active	-	unoccupied	-	-	network	off
							active	-	local	unoccupied	-	local	off
							active	-	off	remote	-	remote	off
							active	-	remote	unoccupied	-	remote	off
							active	disable	-	network	-	network	off
							active	-	network	unoccupied	-	network	off
						active	-	-	-	disable	no	local	on
						active	-	-	-	occupied	no	local	on
							active	-	occupied	disable	no	remote	on
							active	-	occupied	disable	no	remote	on
							active	-	occupied	disable	no	remote	on
							active	enable	-	-	no	network	on
							active	-	occupied	disable	no	local	on
							active	-	occupied	disable	no	remote	on
							active	-	occupied	disable	no	remote	on
							active	-	occupied	disable	no	remote	on
							active	-	occupied	disable	no	remote	on
							active	enable	-	network	no	network	on

IMPORTANT: When the unit is stopping or there is a demand to stop the unit, compressors are stopped consecutively. In case of emergency stop, all compressors are stopped at the same time.

8 - STANDARD CONTROL OPERATIONS AND OPTIONS

8.2 Heating / Cooling / Standby

The Connect Touch control determines the heat/cool state of the unit.

CHILLERS MAY OPERATE ONLY IN COOLING MODE.

HEAT PUMPS MAY OPERATE IN COOLING OR HEATING MODE.

In the case of heat pumps, the user may enable the **automatic heat/cool** changeover option (auto_sel, HCCONFIG – Heat/Cool Config). The option must be set manually by the user (by default, this automatic changeover is disabled).

- When the outdoor air temperature exceeds the cooling threshold, then the cooling mode is started.
- When the outdoor air temperature is below the heating threshold, then the heating mode is started.
- When the outdoor air temperature is between the abovementioned changeover setpoints, then the unit is neither cooling nor heating. It is in Standby mode which means that compressors are stopped and the water pump may be running with no mechanical cooling or heating. However, it is possible to have the pump stopped in Standby mode if the [pump_sby] parameter in the Pump Configuration menu (PUMPCONF) is set to "yes".




Figure 2: Heating / Cooling changeover for heat pumps.

Operating mode control

The operating mode, i.e. cooling or heating, is determined based on the following parameters:

- **Control type:** Local, Remote or Network.
- **Local heat/cool selection [hc_sel]:** Heat/Cool selection when the unit is running in Local mode.
- **Remote heat/cool selection [onsw_cr]:** Heat/Cool selection when the unit is running in Remote mode.
- **Network heat/cool selection [HC_SEL]:** Heat/Cool selection when the unit is running in Network mode.
- **Outdoor air temperature [OAT]:** Heat/Cool setpoint selection when the automatic changeover has been enabled.

Control type	Heat/Cool (Local)	Heat/Cool (Remote)	Heat/Cool (Network)	Outdoor Air Temperature **	Operating mode
local	cool	-	-	-	cool
local	heat	-	-	-	heat
local	auto*	-	-	>cauto_sp + 1 K	cool
local	auto*	-	-	<hauto_sp - 1 K	heat
local	auto*	-	-	hauto_sp + 1 K < oat < cauto_sp - 1 K	standby
local	-	on_cool	-	-	cool
local	-	on_heat	-	-	heat
local	-	on_auto	-	>cauto_sp + 1 K	cool
local	-	on_auto	-	<hauto_sp - 1 K	heat
remote	-	on_cool	-	-	cool
remote	-	on_heat	-	-	heat
remote	-	on_auto	-	>cauto_sp + 1 K	cool
remote	-	on_auto	-	<hauto_sp - 1 K	heat
remote	-	on_auto	-	hauto_sp + 1K < oat < cauto_sp - 1K	standby
network	-	-	cool	-	cool
network	-	-	heat	-	heat
network	-	-	auto*	>cauto_sp + 1 K	cool
network	-	-	auto*	<hauto_sp - 1 K	heat
network	-	-	auto*	hauto_sp + 1K < oat < cauto_sp - 1 K	standby

* If auto changeover has been selected through user configuration; otherwise, by default set to "cooling".

** cauto_sp = cooling changeover setpoint; hauto_sp = heating changeover setpoint; oat = outdoor air temp.

8 - STANDARD CONTROL OPERATIONS AND OPTIONS

8.3 Heating / Cooling selection


As mentioned earlier in the document Heating/Cooling selection applies only to heat pumps. Heating/Cooling selection can be controlled in various ways, depending on the active operating type. The cooling mode is selected by default.

Heating/Cooling can be determined:

- Locally at the unit using the HC_SEL item in the GENUNIT menu.
- Remotely via the heating/cooling selection contact if the unit is in the Remote mode.
- Via a network command if the unit is in the Network mode.

Heating/Cooling mode can be set manually by the user or automatically by the control. When heating/cooling is automatic, the outdoor air temperature determines the heat/cool/standby changeover (cauto_sp and hauto_sp, SETPOINT). The automatic changeover is optional and requires user configuration (HC_SEL, GENUNIT- General Parameters).

To set cooling / heating / auto mode

1. Navigate to the Main menu.
2. Select **General Parameters**  (GENUNIT).
3. Set Heat/Cool Select [HC_SEL].


Heat/Cool Select [HC_SEL]	
0	Cooling
1	Heating
2	Automatic changeover

To enable heating/cooling auto changeover

1. Navigate to the Configuration menu (logged-in users only).
2. Select **Heat/Cool Config**  (HCCONFIG).
3. Set Auto Changeover Select [auto_sel].


Auto Changeover Select [auto_sel]	
No/Yes	Yes

To set cool changeover setpoint

1. Navigate to the Main menu.
2. Select **Setpoint**  (SETPOINT).
3. Set Cool Changeover Setpt [cauto_sp].

Cool Changeover Setpt [cauto_sp]	
3.9 to 50.0°C	23.9°C
39.0 to 122.0°F	75.0°F

To set heat changeover setpoint

1. Navigate to the Main menu.
2. Select **Setpoint**  (SETPOINT).
3. Set Heat Changeover Setpt [hauto_sp].

Heat Changeover Setpt [hauto_sp]	
0 to 46.1°C	17.8°C
32.0 to 115.0°F	64.0°F

NOTE: In order to change the cooling/heating setpoint, you must be first logged in as a user (see also section "User login" on page 15).

8.4 Supplementary heating (heat pumps)

AQUACIAT ILD heat pumps may be fitted with a boiler or electric heaters.

The **boiler** is used as heating replacement when mechanical heating is not possible or insufficient due to low outdoor air temperature. It may also be used to provide domestic hot water when needed.


Electric heaters can be turned on to satisfy the heating demand when mechanical heating is insufficient.

8.4.1 Boiler control

The boiler can be activated when the unit is down due to a detected failure or it may also be used as supplementary heating when the operating conditions are not suitable for mechanical heating.

Boiler is activated when the outdoor air temperature is below the user-configured boiler OAT threshold, which is by default set to -10°C (14°F).

To set boiler OAT threshold

1. Navigate to the Configuration menu (logged-in users only).
2. Select **Heat/Cool Config**  (HCCONFIG).
3. Set Boiler OAT Threshold [boil_th].

Boiler OAT Threshold [boil_th]	
-15.0 to 15.0°C	-9.9°C
5.0 to 59.0°F	14.2°F

8.4.2 Electric heating control


Electric heating stages can be activated as additional heating when OAT is below the user-configured electric heating OAT threshold, which is by default set to 5°C (41°F).

Electric heating is allowed when all of the following conditions are met:

- Unit is running at 100% capacity.
- Electric pull-down time elapsed [ehs_pull].
- OAT is below the OAT threshold [ehs_th].

There are four electric heating stages where the last electric heating stage is used for back-up. It means that normally only three heating stages are allowed and the fourth one is used only when the unit is down due to a detected fault or the heating protection is active.

To set electric heating OAT threshold

1. Navigate to the Configuration menu (logged-in users only).
2. Select **Heat/Cool Config**  (HCCONFIG).
3. Set Elec Stage OAT Threshold [ehs_th].

Elec Stage OAT Threshold [ehs_th]	
-5.0 to 21.0°C	5.0°C
23.0 to 70.0°F	41.0°F

IMPORTANT: Electric heating is NOT allowed when the demand limit is active on the unit (see also section 8.9).

8 - STANDARD CONTROL OPERATIONS AND OPTIONS

8.5 Pump control

The control system can manage one or two water exchanger pumps, determining each pump on/off state and its speed. Both pumps cannot run together. The pump is turned on when this option is configured and when the unit is running.

The pump is turned off when the unit is shut down due to an alarm, unless the fault is a frost protection error. The pump can be started in particular operating conditions when the water exchanger heater is active.

If the pump has failed and another pump is available, the unit is stopped and started again with the second pump. If there is no pump available, the unit shuts down.

Configuration options may differ depending on the number and type of pumps available (single speed pumps or variable speed pumps).

8.5.1 Variable speed pumps control

AQUACIAT LD chillers and AQUACIAT ILD heat pumps may be fitted with one or two variable speed pumps.

Variable speed pumps give the possibility of saving the pumping energy cost, providing precise water flow control and improving the overall performance of the system. The frequency inverter continuously regulates the flow rate to minimize the pump power consumption at full load and part load.

Water flow management methods are as follows:

- 1) Fixed speed control (the control ensures a constant pump speed based on compressor capacity).
- 2) Water flow control based on constant water delta pressure (the control continuously acts on the pump speed to ensure a constant delta pressure).
- 3) Water flow control based on constant delta T on the water exchanger.


IMPORTANT: Pump speed configuration can be performed only by service technicians.

8.5.2 Pumps configuration

The control can command internal fixed speed or variable speed pumps as well as customer pumps. Variable speed pumps may also be configured as fixed speed pumps.

Basic pump configuration can be performed via the Configuration menu (PUMPCONF – Pump Configuration). Only logged-in users can access the menu. The unit must be stopped.

To set pumps sequence


1. Navigate to the Configuration menu (logged-in users only).
2. Select **Pump Configuration**  (PUMPCONF).
3. Set Water Pumps Sequence [pump_seq].

Water Pumps Sequence [pump_seq]	
0	No Pump
1	One Pump Only
2	Two Pumps Auto
3	Pump#1 Manual
4	Pump#2 Manual

8.5.3 Automatic pumps selection

If two pumps are controlled and the reversing function has been selected (PUMPCONF – Pump Configuration), the control balances the pump run time to match the configured pump changeover delay. If this delay has elapsed, the pump reversing function is activated.

To set pump automatic rotation delay

1. Navigate to the Configuration menu (logged-in users only).
2. Select **Pump Configuration**  (PUMPCONF).
3. Set Pump Rotation Delay [pump_del].

Pump Rotation Delay [pump_del]	
24 to 3000h	48h

8.5.4 Customer pumps configuration

Units fitted with external pumps may have only fixed speed pumps available. Customer pumps may be configured as follows:

Pump available	Pumps sequence (pump_seq, PUMPCONF)
No pump	0 (no pump)
One single speed pump	1 (one pump only)
Two single speed pumps	2 (two pumps auto) 3 (pump#1 manual) 4 (pump#2 manual)

Units with customer pumps are fitted with the flow switch, allowing for the water flow control. For more information about actuators, see Water flow switch in section 4.7.


8.5.5 Pumps protection

The control provides the option to automatically start the pump each day at 14:00 for 2 seconds when the unit is off.

If the unit is fitted with two pumps, the first pump is started on even days and the second pump is started on odd days. Starting the pump periodically for a few seconds extends the lifetime of the pump bearings and the tightness of the pump seal.

Periodical pump quick start can be selected via the Configuration menu (PUMPCONF – Pump Configuration).

To set periodical pump quick start

1. Navigate to the Configuration menu (logged-in users only).
2. Select **Pump Configuration**  (PUMPCONF).
3. Set Pump Sticking Protection [pump_per].


Pump Sticking Protection [pump_per]	
No/Yes	Yes

8.5.6 Eco pump mode

When the unit is in Standby mode (heating or cooling demand is satisfied), the Connect Touch control may be configured to stop the pump periodically in order to save energy.

This option can be configured only by service technicians.

To verify the Eco Pump configuration

1. Navigate to the Main menu.
2. Select **Miscellaneous Status**  (MSC_STAT).
3. Verify Eco Pump Mode Active [m_ecopmp].

Eco Pump Mode Active [m_ecopmp]	
No/Yes	

8 - STANDARD CONTROL OPERATIONS AND OPTIONS

8.6 Hydronic kit option

The hydronic kit option allows for continuous monitoring of the water flow rate (PUMPSTAT – Pump Status).

The hydronic kit provides the option to measure the following parameters:

- Inlet and outlet water pressure.
- Water exchanger flow rate.

The water flow rate is based on the pressure difference between the inlet and outlet pressures and the pressure drop curves.

Hydronic kit option with variable speed pumps

For units with variable speed pumps, this option allows for the automatic adjustment of the pump speed necessary to maintain the correct water flow rate.

Water flow control can be based on compressor usage, constant delta pressure or constant temperature difference. See also "Variable speed pumps control" on page 33.



8.7 Control point

The control point represents the water temperature that the unit must produce. The required capacity can be decreased depending on the unit load operating conditions.

Control point = Active setpoint + Reset

The control point is calculated based on the active setpoint and the reset calculation. The forced value can be used instead of any other setpoint calculation only when the unit is in the Network operating type.

To verify the control point

1. Navigate to the Main menu.
2. Select **General Parameters**  (GENUNIT).
3. Verify Control Point [CTRL_PNT]: 

8.7.1 Active setpoint

Two setpoints can be selected, where the first setpoint is used during occupied periods, whereas the second one is used during unoccupied periods.

Depending on the current operation type, the active setpoint can be selected manually via the Main menu on the user interface, with the volt-free user contacts, with network commands or automatically with the setpoint time schedule (schedule 2).

The following tables summarise possible selections depending on the control operating type (Local / Remote / Network) and the following parameters:

- Heating or Cooling operating mode [HC_SEL]: Heat/Cool Select (GENUNIT – General Parameters).
- Setpoint selection [SP_SEL]: Setpoint Select permits selection of the active setpoint if the unit is in the Local operating type (GENUNIT – General Parameters).
- Setpoint switch status [SETP_SW]: Remote Setpoint Switch (INPUTS – Inputs).
- Occupied state of dual setpoint time schedule [SP_OCC]: Schedule for setpoint selection.

LOCAL OPERATING TYPE

Heating/Cooling	Setpoint selection (Local)	Setpoint switch	Schedule 2 status	Active setpoint
Cooling	sp-1	-	-	Cooling setpoint 1
Cooling	sp-2	-	-	Cooling setpoint 2
Cooling	auto	-	occupied	Cooling setpoint 1
Cooling	auto	-	unoccupied	Cooling setpoint 2
Heating	sp-1	-	-	Heating setpoint 1
Heating	sp-2	-	-	Heating setpoint 2
Heating	auto	-	occupied	Heating setpoint 1
Heating	auto	-	unoccupied	Heating setpoint 2

REMOTE OPERATING TYPE

Heating/Cooling	Setpoint selection (Local)	Setpoint switch	Schedule 2 status	Active setpoint
Cooling	-	sp1	-	Cooling setpoint 1
Cooling	-	sp2	-	Cooling setpoint 2
Cooling	-	auto	occupied	Cooling setpoint 1
Cooling	-	auto	unoccupied	Cooling setpoint 2
Heating	-	sp1	-	Heating setpoint 1
Heating	-	sp2	-	Heating setpoint 2
Heating	-	auto	occupied	Heating setpoint 1
Heating	-	auto	unoccupied	Heating setpoint 2

NETWORK OPERATING TYPE

Heating/Cooling	Setpoint selection (Local)	Setpoint switch	Schedule 2 status	Active setpoint
Cooling	sp-1	-	-	Cooling setpoint 1
Cooling	sp-2	-	-	Cooling setpoint 2
Cooling	auto	-	occupied	Cooling setpoint 1
Cooling	auto	-	unoccupied	Cooling setpoint 2
Cooling	auto	-	-	Cooling setpoint 2
Heating	sp-1	-	-	Heating setpoint 1
Heating	sp-2	-	-	Heating setpoint 2
Heating	auto	-	occupied	Heating setpoint 1
Heating	auto	-	unoccupied	Heating setpoint 2
Heating	auto	-	-	Heating setpoint 2

8 - STANDARD CONTROL OPERATIONS AND OPTIONS

8.7.2 Reset

Reset means the active setpoint is modified so that less machine capacity is required. In the cooling mode the setpoint is increased, whereas in the heating mode it is decreased.

The reset can be based on the following possibilities:


- OAT that gives the measure of the load trends for the building.
- Return water temperature (ΔT provides the average building load).
- Dedicated 4-20 mA input.

The reset source and the reset parameters can be configured in the Main menu (RESETCFG – Reset Config). In response to a change in the reset source (e.g. OAT), the setpoint is normally reset to optimise unit performance.

The amount of reset is determined by linear interpolation based on the following parameters:

- A reference at which reset is zero (no reset value).
- A reference at which reset is maximum (full reset value).
- The maximum reset value.

Reset example in Cooling mode:



20	Reset based on OAT	25
0	Reset based on delta T	3
4	Reset based on analog input	20
no_reset	Selection	full_reset

Legend:

- A: Maximum reset value
- B: Reference for zero reset
- C: Reference for maximum reset
- D: Building load

8.8 Free cooling option

AQUACIAT LD chillers and AQUACIAT ILD heat pumps may be fitted with a dry cooler that enables power consumption reduction which amounts to energy and cost savings.

The installation of a dry cooler allows for "free cooling" – a method of using low outdoor air temperature as an aid to chilling water that is later used in the air-conditioning system. The system is the most effective when the outdoor air temperature is below 0°C (32°F).

Starting free cooling

The free cooling mode is ENABLED when the free cooling OAT [fc_oat] is below the water loop temperature and the start threshold:

$$fc_oat < fc_wloop - fc_start$$


fc_oat : Free Cooling OAT

fc_wloop: Free Cooling Water Loop Temperature

fc_start : Free Cooling Start Threshold (service access only)

NOTE: [fc_wloop] and [fc_oat] temperatures measured by the control are read-only values that can be verified in the DC Free Cooling Status menu (FCOOL_ST).


To verify Dry Cooler water loop temp.

1. Navigate to the Main menu.
2. Select **DC Free Cooling Status**  (FCOOL_ST).
3. Verify Free Cooling Water Loop Temp [fc_wloop].

FC Water Loop Temp [fc_wloop]

°C / °F

To verify Free Cooling OAT

1. Navigate to the Main menu.
2. Select **DC Free Cooling Status**  (FCOOL_ST).
3. Verify Free Cooling OAT [fc_oat].

Free Cooling OAT [fc_oat]

°C / °F

Stopping free cooling

If it turns out that the cooling power of the dry cooler is not enough in order to reach the cooling setpoint, then the mechanical cooling will be started.

Free Cooling is normally stopped when the free cooling OAT [fc_oat] is above the water loop temperature and the start/stop threshold:

$$fc_oat > fc_wloop - fc_start + fc_stop$$

fc_oat : Free Cooling OAT

fc_wloop: Free Cooling Water Loop Temperature

fc_start : Free Cooling Start Threshold (service access only)

fc_stop : Free Cooling Stop Threshold (service access only)

When FC capacity is at 100%, then mechanical cooling can be started.

8 - STANDARD CONTROL OPERATIONS AND OPTIONS

8.9 Capacity limitation


Connect Touch control system allows for constant control of the unit capacity by setting its maximum allowable capacity.

Capacity limitation is expressed in percentage, where a limit value of 100% means that the unit may run with its full capacity (no limitation is implemented).

The unit capacity can be limited:

- By means of user-controlled volt-free contacts. The unit capacity can never exceed the limit setpoint activated by these contacts.
- By lag limit [LAG_LIM] set by the master unit in the master/slave assembly. If the unit is not in the Master/Slave assembly, the lag limit value is equal to 100%.
- By night mode limitation control. The demand limit value in the night mode is selectable if the value is below the selected capacity limit.


To set limit setpoints

1. Navigate to the Main menu.
2. Select **Setpoint**  (SETPOINT).
3. Set Switch Limit Setpoint 1 / 2 / 3 [lim_sp1 / 2 / 3].

Switch Limit Setpoint 1 / 2 / 3 [lim_sp1 / 2 / 3]

0 to 100%	100%
-----------	------


To verify lag limit set by the master unit

1. Navigate to the Main menu.
2. Select **General Parameters**  (GENUNIT).
3. Verify Lag Capacity Limit Value [LAG_LIM].

Lag Capacity Limit Value [LAG_LIM]

0 to 100%	100%
-----------	------

To set the night mode limit


1. Navigate to the Configuration menu (logged-in users only).
2. Select **General Config**  (GENCONF).
3. Set Night Capacity Limit [nh_limit].

Night Capacity Limit [nh_limit]

0 to 100%	100%
-----------	------

Based on the limit source, the active demand limit value [DEM_LIM] is set to the lowest possible value. DEM_LIM can be forced by Network.

To verify active demand limit value

1. Navigate to the Main menu.
2. Select **General Parameters**  (GENUNIT).
3. Verify Active Demand Limit Val [DEM_LIM].

Active Demand Limit Val [DEM_LIM]

0 to 100%	-
-----------	---

8.10 Capacity control

The control adjusts the capacity to keep the water exchanger temperature at its setpoint. Compressors are started and stopped in a sequence designed to equalize the number of starts (value weighted by their operating time).


8.10.1 Circuit loading sequence

This function determines in which order the circuit capacity is changed. Compressor loading is managed by starting/stopping compressors. Two types of sequencing, i.e. balanced and staged loading sequence, are available and can be configured by the user via the user interface (GENCONF – General Config).

Balanced loading sequence: The control maintains equal capacity between all circuits as the machine loads and unloads. Balanced loading sequence is the default sequence employed by the control.

Staged loading sequence: The control loads the lead circuit completely before the lag circuit is started. When the load is decreasing, the lag circuit is unloaded first. Staged loading sequence is active when one of the circuits is shut down due to its failure; the circuit is in capacity override mode; or the remaining circuits are shut down or fully charged.

To set the circuit loading sequence

1. Navigate to the Configuration menu (logged-in users only).
2. Select **General Config**  (GENCONF).
3. Set Staged Loading Sequence [seq_typ].

Staged Loading Sequence [seq_typ]

No/Yes	No (staged loading NOT active)
--------	--------------------------------


8.10.2 Capacity for multi-circuit units

For units with more than one circuit, the lead/lag function determines which circuit is the lead circuit and which circuit is the lag circuit. This function controls the start/stop sequence of two refrigeration circuits called circuit A and circuit B.

The circuit authorised to start first is the lead circuit. Lead circuit is used first for capacity increases and at the same time should be decreased first when decreasing capacity. The lead/lag circuits can be selected manually or automatically (Cir Priority Sequence, GENCONF – General Config).

- **Manual lead/lag circuit determination:** Circuit A or circuit B selected as the lead circuit. The selected circuit takes priority over another circuit.
- **Automatic lead/lag circuit determination:** The control system determines the lead circuit to equalise the operating time of each circuit (value weighted by the number of start-ups of each circuit). As a result, the circuit with the lowest number of operating hours always starts first.

To set circuit priority

1. Navigate to the Configuration menu (logged-in users only).
2. Select **General Config**  (GENCONF).
3. Set Cir Priority Sequence [lead_cir].

Cir Priority Sequence [lead_cir]

0	Auto
1	Circuit A lead
2	Circuit B lead

8 - STANDARD CONTROL OPERATIONS AND OPTIONS

8.11 Night mode

Night mode allows users to configure the unit to operate with specific parameters in a specific time period. During the night period, the unit capacity is limited. The number of operating fans is reduced (in cooling mode only), so that the noise level is reduced.

The night period is defined by a start time and an end time that are the same for each day of the week. The Night mode settings or the maximum capacity value can be configured via the Configuration menu (GENCONF – General Config).


IMPORTANT: Only logged-in users can modify the night mode settings.

8.12 Holidays

This function is used to define 16 holiday periods. Each period is defined by three parameters: the month, the start day and the duration of the holiday period.

During the holiday periods the controller will be in occupied or unoccupied mode, depending on the periods validated as holidays. Each holiday period can be modified by the user via the Configuration menu (HOLIDAY – Holiday Menu).

To modify holiday periods

1. Navigate to the Configuration menu (logged-in users only).
2. Select **Holiday**  (HOLIDAY).
3. Choose the holiday period, e.g. HOLDY_01.
4. Set Holiday Start Month [HOL-MON], Start Day [HOL-DAY], Duration (days) [HOL-LEN].


Holiday Start Month [HOL-MON]	
0-12	0
Start Day [HOL-DAY]	
0-31	0
Duration (days) [HOL-LEN]	
0-99	0

8.13 Desuperheater option

AQUACIAT LD chillers and AQUACIAT ILD heat pumps may be fitted with a desuperheater that allows for better energy management.

The desuperheater is used to extract the high pressure, high temperature heat from the refrigerant to "desuperheat" it to a lower pressure refrigerant. The vapour that goes into the desuperheater is not fully condensed; therefore, the refrigerant vapour must be channelled to a separate heat exchanger where the condensing process occurs.

To set minimal condensing setpoint

1. Navigate to the Main menu.
2. Select **Setpoint**  (SETPOINT).
3. Set Desuperheat Min Sct [min_sct].

Desuperheat Min Sct [min_sct]	
26.7 to 60.0°C	40.0°C
80.0 to 140.0°F	104.0°F

8.14 Defrost cycle for heat pumps

When the outdoor air temperature is low and the ambient humidity is high, the probability of frost forming on the surface of the outdoor coil increases. The frost covering the outdoor coil may decrease the air flow across the coil and lead to lower performance of the unit. To remove the frost from the coil, the control initiates the defrost cycle when necessary.

During the defrost cycle, the circuit is forced into the cooling mode. To prevent the water loop from cooling down, optional electric heating may be started. The defrost cycle lasts until the end of defrost temperature is achieved.

8.15 Master/Slave assembly

The control system allows for master/slave control of two units linked by the network (proprietary protocol). The master unit can be controlled locally, remotely, or by network commands, while the slave unit remains in Network mode. All control commands to the master/slave assembly (start/stop, setpoint selection, demand limit, etc.) are handled by the unit configured as the master. The commands are transmitted automatically to the slave unit.

If the master chiller is turned off while the master/slave function is active, then the slave chiller will be stopped. Under certain circumstances, the slave unit may be started first to ensure that the run times of the two units are equalised.

In the event of a communication failure between the two units, each unit will return to an autonomous operating mode until the fault is cleared. If the master unit is stopped due to an alarm, the slave unit is authorised to start.

IMPORTANT: Master/slave assembly can be configured only by service technicians.

9 - DIAGNOSTICS

The control system has many fault tracing aid functions, protecting the unit against risks that could result in the failure of the unit.

Connect Touch gives quick access to monitor all unit operating conditions. If an operating fault is detected, the alarm is triggered.


Note that some alarms are used only to warn against potentially dangerous situations and they may have no effect on the unit when triggered; however, failure to acknowledge these warnings may have negative impact on the operation of the system or the unit itself.

Please perform all corrective actions if indicated. For example, in the case of alarms beginning with 130-xx, please contact the service agency immediately in order to proceed with the required servicing procedure(s).

9.1 Control diagnostics

The user interface allows the quick display of the unit status.


- The blinking bell icon indicates that there is an alarm, but the unit is still running.
- The highlighted bell icon indicates that the unit is shut down due to a detected fault.



9.1.1 Current alarms

All currently active alarms can be found in the Current Alarms menu. In addition to the description of the alarm, the control provides information such as date and time the alarm occurred. The control may display up to ten (10) current alarms.

To access the list of currently active alarms

1. Press the **Alarm** button in the upper-right part of the screen.
2. Select **Current Alarms**  (CUR_ALM).
3. The list of active alarms will be displayed.

CAUTION


In the event of a power supply interrupt, the unit restarts automatically without the need for an external command. However, any faults active when the supply is interrupted are saved and may in certain cases prevent a circuit or a unit from restarting.

9.1.2 Alarms reset

Alarms can be reset without stopping the machine. Only logged-in users can reset alarms (see also "User login" on page 15). The alarm can be reset either automatically or manually through the user interface or the web interface (Reset Alarms menu).

Note that the Reset Alarms menu displays up to five (5) alarm codes which are currently active on the unit.


To reset alarms manually

1. Press the **Alarm** button in the upper-right part of the screen.
2. Select **Reset Alarms**  (ALARMRST).
3. Set the Alarm Reset to "Yes" and press the **Set Force** button.

9.1.3 Alarm history

Information regarding resolved alarms is stored in the Alarm history menu.

To access alarms history

1. Press the **Alarm** button in the upper-right part of the screen.
2. Select **Alarm History**  (ALMHIST1).

9.1.4 Alarm codes

Each alarm has a code associated with a particular fault. The alarm codes are displayed in the **Reset Alarms** menu, while the **Current Alarms** menu and the **Alarm History** menu include the description of the alarm.

9.1.5 E-mail notifications

The control provides the option to define one or two recipients who receive e-mail notifications each time the new alarm occurs or all existing alarms have been reset.

NOTE: E-mail notifications can be set only by service technicians.

9 - DIAGNOSTICS

9.2 Alarms description

Alarms

Code	Name	Description	Reset	Action taken	Possible cause
4601	AUX1_COM_F	Loss of communication with AUX1 Board	Automatic, if communication is re-established	Unit shuts down	Bus installation fault, communication error
4602	FC_AUX1_COM_F	Loss of communication with Free Cooling Board 1	Automatic, if communication is re-established	Free Cooling is stopped	Bus installation fault, communication error
4901	SIOB_CIR_A_COM_F	Loss of communication with SIOB Board Number A	Automatic, if communication is re-established	Circuit A shuts down	Bus installation fault, communication error
4902	SIOB_CIR_B_COM_F	Loss of communication with SIOB Board Number B	Automatic, if communication is re-established	Circuit B shuts down	Bus installation fault, communication error
4903	HH_SIOB_F	Loss of communication with SIOB Board Number 3	Automatic, if communication is re-established	Unit shuts down	Bus installation fault, communication error
7001	ILL_FACT_CONF_F	Illegal configuration	Manual	Unit shuts down	The unit size has been configured with the wrong value
8000	INI_FACT_CONF_F	Initial factory configuration required	Automatic, if configuration is entered	Unit shuts down	The unit size has not been configured
9001	M_S_CONFIG_F	Master chiller configuration error	Automatic, if master/slave configuration returns to normal	Master/slave mode is stopped	Master/slave configuration error
10001	COOLER_FREEZE_F	Water Exchanger Freeze Protection	Automatic (the first alarm in the last 24 h) or Manual	Unit shuts down, the water exchanger pump is running	No water flow, defective thermistor
10005	LOW_SUCTION_A_F	Circuit A Low Saturated Suction Temperature	Automatic (the first alarm in the last 24 h) or Manual	Circuit A shuts down	Pressure transducer defective, EXV blocked or lack of refrigerant
10006	LOW_SUCTION_B_F	Circuit B Low Saturated Suction Temperature	Automatic (the first alarm in the last 24 h) or Manual	Circuit B shuts down	Pressure transducer defective, EXV blocked or lack of refrigerant
10008	HIGH_SH_A_F	Circuit A High Superheat	Manual	Circuit A shuts down	Pressure transducer defective, temperature sensor defective, EXV blocked or lack of refrigerant
10009	HIGH_SH_B_F	Circuit B High Superheat	Manual	Circuit B shuts down	Pressure transducer defective, temperature sensor defective, EXV blocked or lack of refrigerant
10011	LOW_SH_A_F	Circuit A Low Superheat	Manual	Circuit A shuts down	Pressure transducer defective, temperature sensor defective, EXV blocked or lack of refrigerant
10012	LOW_SH_B_F	Circuit B Low Superheat	Manual	Circuit B shuts down	Pressure transducer defective, temperature sensor defective, EXV blocked or lack of refrigerant
10014	COOLER_LOCK_F	Exchanger Interlock Failure	Automatic (if the unit was stopped) or Manual	Unit shuts down	Customer interlock input set on
10016	CPA1_REVERSE_ROT_F	Compressor A1 Not Started Or Pressure Increase not Established	Manual	Compressor A1 shuts down	Compressor breaker or fuse fault, compressor switch open
10017	CPA2_REVERSE_ROT_F	Compressor A2 Not Started Or Pressure Increase not Established	Manual	Compressor A2 shuts down	Compressor breaker or fuse fault, compressor switch open
10018	CPA3_REVERSE_ROT_F	Compressor A3 Not Started Or Pressure Increase not Established	Manual	Compressor A3 shuts down	Compressor breaker or fuse fault, compressor switch open
10020	CPB1_REVERSE_ROT_F	Compressor B1 Not Started Or Pressure Increase not Established	Manual	Compressor B1 shuts down	Compressor breaker or fuse fault, compressor switch open
10021	CPB2_REVERSE_ROT_F	Compressor B2 Not Started Or Pressure Increase not Established	Manual	Compressor B2 shuts down	Compressor breaker or fuse fault, compressor switch open
10029	LOSS_COM_SM_F	Loss of communication with System Manager	Automatic, if communication is re-established	Unit returns to the stand-alone mode	Bus installation fault
10030	LOSS_COM_MS_F	Master/Slave communication Failure	Automatic, if communication is re-established	Master/Slave operation is disabled, the unit returns to the stand-alone mode	Bus installation fault
10031	EMSTOP_F	Unit is in Network emergency stop	Automatic, if emergency stop is deactivated	Unit shuts down	Network emergency stop command
10032	COOL_PUMP1_F	Water Pump 1 Default	Manual	Unit is restarted with another pump running; If no pump is available, the unit shuts down	Water flow switch or water pump fault
10033	COOL_PUMP2_F	Water Pump 2 Default	Manual	Unit is restarted with another pump running; If no pump is available, the unit shuts down	Water flow switch or water pump fault

9 - DIAGNOSTICS

Code	Name	Description	Reset	Action taken	Possible cause
10037	REPEATED_HIGH_DGT_A_F	Circuit A Repeated High Discharge Gas Overrides	Automatic (no discharge gas overrides within 30 min) or Manual	None	Repetitive capacity decreases
10038	REPEATED_HIGH_DGT_B_F	Circuit B Repeated High Discharge Gas Overrides	Automatic (no discharge gas overrides within 30 min) or Manual	None	Repetitive capacity decreases
10040	REPEATED_LOW_SST_A_F	Circuit A Repeated Low Suction Temp Overrides	Manual	Circuit A shuts down	Repetitive capacity decreases
10041	REPEATED_LOW_SST_B_F	Circuit B Repeated Low Suction Temp Overrides	Manual	Circuit B shuts down	Repetitive capacity decreases
10043	HEAT_LOW_EWT_F	Low Entering Water Temperature In Heating	Automatic	None	Low entering fluid temperature in Heating mode
10063	HP_SWITCH_A_F	Circuit A High pressure switch Failure	Manual	Circuit A shuts down	High pressure switch is open, compressor fault
10064	HP_SWITCH_B_F	Circuit B High pressure switch Failure	Manual	Circuit B shuts down	High pressure switch is open, compressor fault
10097	SENSORS_SWAP_F	Water Exchanger Temperature Sensors Swapped	Manual	Unit shuts down	Input and output temperature reversed
10099	FLUIDE_FAIL	Possible Refrigerant Leakage Failure	Automatic	None	Refrigerant leak detected
10101	FC_PROCESS_F	Free Cooling Process Failure	Automatic	Free Cooling is stopped	Installation fault
10102	HH_3WV_POS_F	Hybrid Heat Pump Incorrect DHW Valve Position	Automatic	Boiler is stopped	DHW valve fault
10103	HH_DHW_CYCLE_F	Hybrid Heat DHW Cycle Time Too Long	Automatic, the alarm disappears 12 hours after stopping the DHW production	Domestic Hot Water production is stopped	3-way valve fault
11202	WL_PRESS_ZERO_ERROR_F	Water Loop : Delta Pressure Error	Automatic, if water pressure delta returns to normal	Unit shuts down	Too low or high water pressure reading
11203	WL_PRESS_TOO_LOW_F	Water Loop : Pressure Too Low	Automatic, if water pressure reading returns to normal and the alarm occurred up to 6 times in the last 24 h (otherwise manual)	Unit shuts down	Pump inlet pressure is below 60 kPa
11204	WL_PUMP_NOT_STARTED_F	Water Loop : Pump Not Started	Automatic	Pump is stopped	Too low or high pump pressure reading
11206	WL_PUMP_OVERLOAD_F	Water Loop : Pump Overload	Automatic	None	Water pressure drop too low
11207	WL_LOW_FLOW_F	Water Loop : Flow Too Low	Automatic, if water flow reading returns to normal	Pump is stopped	Water loop pressure drop too high
11208	WL_PRESS_CROSS_F	Water Loop : Pressure Sensors Crossed	Manual	Unit shuts down	Pressure sensors crossed
11209	WL_LOW_PRESS_WARNING_F	Water Loop : Low Pressure Warning	Automatic, if water pressure reading returns to normal	None	Water pressure is below 60 kPa
12001	DP_A_F	Circuit A Discharge Pressure Transducer Failure	Automatic, if sensor voltage reading returns to normal	Circuit A shuts down	Defective transducer
12002	DP_B_F	Circuit B Discharge Pressure Transducer Failure	Automatic, if sensor voltage reading returns to normal	Circuit B shuts down	Defective transducer
12004	SP_A_F	Circuit A Suction Pressure Transducer Failure	Automatic, if sensor voltage reading returns to normal	Circuit A shuts down	Defective transducer
12005	SP_B_F	Circuit B Suction Pressure Transducer Failure	Automatic, if sensor voltage reading returns to normal	Circuit B shuts down	Defective transducer
12024	WP_IN_F	Water Exchanger Entering Fluid Transducer Failure	Automatic, if sensor voltage reading returns to normal	Unit shuts down	Defective transducer
12025	WP_OUT_F	Water Exchanger Leaving Fluid Transducer Failure	Automatic, if sensor voltage reading returns to normal	Unit shuts down	Defective transducer
15001	COOL_EWT_F	Water Exchanger Entering Fluid Thermistor Failure	Automatic, if thermistor reading returns to normal	Unit shuts down	Defective thermistor
15002	COOL_LWT_F	Water Exchanger Leaving Fluid Thermistor Failure	Automatic, if thermistor reading returns to normal	Unit shuts down	Defective thermistor
15003	DEFROST_T_A_F	Circuit A Defrost Thermistor Failure	Automatic, if thermistor reading returns to normal	Cooling mode: Unit continues to operate Heating mode: Circuit A shuts down	Defective thermistor
15004	DEFROST_T_B_F	Circuit B Defrost Thermistor Failure	Automatic, if thermistor reading returns to normal	Cooling mode: Unit continues to operate Heating mode: Circuit B shuts down	Defective thermistor

9 - DIAGNOSTICS

Code	Name	Description	Reset	Action taken	Possible cause
15010	OAT_F	OAT Thermistor Failure	Automatic, if thermistor reading returns to normal	Unit shuts down	Defective thermistor
15011	CHWSTEMP_F	MASTER/Slave Common Fluid Thermistor Failure	Automatic, if thermistor reading returns to normal	Master/Slave operation is disabled, each unit returns to the stand-alone mode	Defective thermistor
15012	SUCTION_T_A_F	Circuit A Suction Gas Thermistor Failure	Automatic, if thermistor reading returns to normal	Circuit A shuts down	Defective thermistor
15013	SUCTION_T_B_F	Circuit B Suction Gas Thermistor Failure	Automatic, if thermistor reading returns to normal	Circuit B shuts down	Defective thermistor
15044	SGTC1_F	Coil Suction Gas Thermistor Sensor 1 Failure	Automatic, if thermistor reading returns to normal	Circuit A shuts down	Defective thermistor
15045	SGTC2_F	Coil Suction Gas Thermistor Sensor 2 Failure	Automatic, if thermistor reading returns to normal	Circuit B shuts down	Defective thermistor
15046	FC_WLOOP_F	Free Cooling Water Loop Thermistor Failure	Automatic, if thermistor reading returns to normal	Free cooling is stopped	Defective thermistor
15047	FC_LWT_F	Free Cooling Leaving Water Thermistor Failure	Automatic, if thermistor reading returns to normal	Free cooling is stopped	Defective thermistor
15048	FC_OAT_F	Free Cooling OAT Water Thermistor Failure	Automatic, if thermistor reading returns to normal	OAT sensor reading (instead of FC OAT sensor) is used	Defective thermistor
15049	HH_WST_F	Hybrid Heat Pump: Water System Thermistor Failure	Automatic, if thermistor reading returns to normal	Boiler is used for DHW only	Defective thermistor
15050	HH_BLWT_F	Hybrid Heat Pump: Boiler Leaving Water Thermistor Failure	Automatic, if thermistor reading returns to normal	Boiler operation disabled	Defective thermistor
15051	HH_DHW_TEMP_F	Hybrid Heat Pump: Domestic Hot Water Thermistor Failure	Automatic, if thermistor reading returns to normal	Domestic Hot Water mode is disabled	Defective thermistor
16001	DRV_FAN_A_F	Circuit A Variable Speed Fan Failure	Automatic	Circuit A shuts down	Speed controller fault
17001	DRV_FAN_B_F	Circuit B Variable Speed Fan Failure	Automatic	Circuit B shuts down	Speed controller fault
19001	DRV_WTR_PUMP_F	Water pump Variable Speed Drive Failure	Automatic	Unit is restarted with another pump running. If no pump is available, the unit shuts down.	Speed controller fault
57001	SIOB_LOW_VOLT_CIRA_F	Circuit A SIOB Low Voltage Failure	Automatic, if the alarm occurred up to 6 times in the last 24 h (otherwise manual)	Unit shuts down	Unstable electrical supply or electrical issue
57002	SIOB_LOW_VOLT_CIRB_F	Circuit B SIOB Low Voltage Failure	Automatic, if the alarm occurred up to 6 times in the last 24 h (otherwise manual)	Unit shuts down	Unstable electrical supply or electrical issue
130nn	SERVICE_MAINTNANCE_ALERT	Service maintenance alert	Manual	None: Contact Manufacturer service	Servicing required
13005	FGAS_ALERT	Fgas check required	Manual	None: Contact Manufacturer service	Servicing required

NOTE: When the "action taken" given in the table above is defined as "none", it means that the alarm message is displayed, but no action is taken on the unit.

10 - MAINTENANCE

In order to ensure the optimal operation of the equipment as well as the optimization of all the available functionalities, it is recommended to activate a Maintenance Contract with your local Manufacturer Service Agency.

The contract will ensure your equipment is regularly inspected by specialists so that any malfunction is detected and corrected quickly and no serious damage can occur to your equipment.

The Manufacturer provides a wide range of service contracts which embrace the assistance of highly qualified HVAC engineering professionals ready to help if needed. The Maintenance contracts represent not only the best way to ensure the maximum operating life of your equipment, but also, through the expertise of qualified personnel, the optimal tool to manage your system in a cost-effective manner.

To find the best type of contract that will meet all of your expectations, please contact your local Manufacturer representatives.



Siège social

Avenue Jean Falconnier B.P. 14
01350 Culoz - France
Tel. : +33 (0)4 79 42 42 42
Fax : +33 (0)4 79 42 42 10
info@ciat.fr - www.ciat.com

**Compagnie Industrielle
d'Applications Thermiques**
S.A. au capital de 26 728 480 €
R.C.S. Bourg-en-Bresse B 545.620.114



ISO9001 • ISO14001
OHSAS 18001

CIAT Service

Tel. : 08 11 65 98 98 - Fax : 08 26 10 13 63
(0,15 € / mn)

Non-contractual document. With the thought of material improvement
always in mind, CIAT reserves the right, without notice
to proceed with any technical modification.



Avec Ecofolio
tous les papiers
se recyclent.