



MONARCH INSTRUMENT

Instruction Manual



SLS-115/230 **Smart Laser Sensor**

15 Columbia Drive
Amherst, NH 03031 USA

Phone: (603) 883-3390

Fax: (603) 886-3300

E-mail: support@monarchinstrument.com

Website: www.monarchinstrument.com

Safeguards and Precautions



Diode Laser

Max. output power: **<5 milliwatts**

Wavelength: **650 nanometers** (visible light)

Min. divergence: **0.5 milliradian**

Output: **Continuous (CW)**

Laser hazard classification: **Class 3R, "Caution"**

Laser hazards

- **Eye injury from beam** - Do not look into the direct or reflected beam; can cause eye injury up to 110 ft (34 m) away.
- **Visual interference (glare) with pilots and drivers** - Interferes with vision up to 2400 ft (730 m) away. Can be a distraction up to 4.5 miles (7.3 km) away. **NEVER point any laser towards aircraft or vehicles; it is unsafe and illegal.**

Safe use guidance

Class 3R lasers are safe when handled carefully. Do not look into the beam. Avoid accidental exposure to eyes. Do not aim at aircraft. **This is not a toy.** Always supervise children.

Manufacturer:

Monarch Instrument
15 Columbia Drive
Amherst, NH 03031 USA
Country of Origin: USA
Contact info: www.monarchinstrument.com



Read and follow all instructions in this manual carefully, and retain this manual for future reference.

Do not use this instrument in any manner inconsistent with these operating instructions or under any conditions that exceed the environmental specifications stated.

This instrument is not user serviceable. For technical assistance, contact the sales organization from which you purchased the product.

WARNING - Use only the "PR Universal" charger supplied with the product.



In order to comply with EU Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE): This product may contain material which could be hazardous to human health and the environment. **DO NOT DISPOSE** of this product as unsorted municipal waste. This product needs to be **RECYCLED** in accordance with local regulations, contact your local authorities for more information. This product may be returnable to your distributor for recycling - contact the distributor for details.

TABLE OF CONTENTS:

1.0	OVERVIEW.....	1
2.0	INDICATORS AND SWITCHES.....	1
3.0	QUICK START GUIDE.....	3
4.0	CONNECTION DETAIL	4
5.0	OPERATION	5
	5.1 Auto Mode	6
	5.2 Manual Mode	6
6.0	ADVANCED FEATURE (TARGET POLARITY).....	7
7.0	AIMING THE LASER.....	7
8.0	RS232	8
9.0	CHARGING	9
10.0	SPECIFICATIONS.....	9
	10.1 Laser Specifications	9
	10.2 General.....	10
	10.3 Installation Environment	12
	10.4 Compliance.....	12
11.0	OPTIONS AND ACCESSORIES.....	BACK

Symbols on the unit and in this manual:



Warning Laser Beam



Caution Read Manual



Direct current



Alternating current

Monarch Instrument's Limited Warranty applies. See www.monarchinstrument.com for details.

Warranty Registration and Extended Warranty coverage available online at www.monarchinstrument.com.

1.0 OVERVIEW

The Smart Laser Sensor (SLS) is a self-contained unit intended to be used to make non-contact speed measurements from rotating targets at distances up to 65 feet (19.8 m) or to provide non-contact reference points to balancing equipment. Refer to Section 6.0 for an overview of operation. The unit will output one (TTL Compatible) pulse per revolution and has the ability to compute the RPM internally and output the ASCII values to any equipment capable of receiving an RS232 input. For best performance use reflective tape for the target.

2.0 INDICATORS AND SWITCHES




Figure 1 SLS Indicators and Switches

1. On Target LED

Lit whenever the sensor is receiving a reflected signal back from the target. As the frequency increases, it will be on solid unless the measured frequency is not stable. This is useful in setting up the unit.

- 2. Laser On LED** Blinks when unit is first turned on. Remains lit when the laser beam is on.
- 3. Auto/Gain LED** On solid whenever the unit is in the Auto mode. It also blinks from 1 to 8 times to indicate the current gain whenever the gain is changed.
- 4. Power LED** (Dependent on the Power switch location)
- On position: GREEN when the batteries are charged.
 Blinks AMBER when the batteries are low.
- Charge position: Blinks RED when fast charging for very low batteries.
 Blinks AMBER when slow charging.
 Steady AMBER when the batteries are fully charged.
- 5. Polarity switch** Selects either a positive or negative output pulse.
- 6. Learn/Gain button**
- In Auto Mode: Press and hold until the On Target LED blinks regularly or is on solid.
- In Manual Mode: Press to change gain ranges.
- 7. Sensitivity Adjust knob** Turn fully counterclockwise to select Auto mode or manually adjust sensitivity threshold.
- 8. Power switch** Turns unit On or Off. When the unit is switched to Off/Charge and a charger is plugged into the unit, the batteries will charge.

3.0 QUICK START GUIDE

Note: Refer to Figure 1 for switch and button locations.

- 3.1 Slide Power switch (8) to “On”.
- 3.2 Rotate Sensitivity Adjust knob (7) fully counterclockwise to the “Auto” position.
- 3.3 Aim the laser dot perpendicular to the target - reflective tape, contrasting color or keyway.
- 3.4 If the On Target LED (1) is not on, push and hold the Red Learn/Gain button (6) until the On Target LED (1) blinks regularly. Note that at higher RPMs the LED will be on solid.
- 3.5 If after completing step 3.4, the On Target LED (1) blinks erratically or not at all, rotate the Sensitivity Adjust knob (7) slowly from 1 to 9 until the LED blinks regularly or is on solid.
- 3.6 If after completing steps 3.1-3.5, the On Target LED (1) blinks erratically or not at all:
 - 3.6.1 Move the sensor closer to the target and ensure it is perpendicular to the target. Repeat steps 3.1-3.5.
 - 3.6.2 Increase the contrast/reflectivity of the target. Repeat steps 3.1-3.5.
- 3.7 Once the On Target signal is obtained, use the Polarity Switch (5) to select a compatible output pulse for your application.

4.0 CONNECTION DETAIL

The unit has an input power jack for DC power or recharging the batteries. Use only the PR Universal charger supplied.

The unit also has a five-pin DIN output socket for Pulse outputs and RS232. An 8-foot [2.5 m] cable with a DIN plug and BNC connector is supplied. The BNC plug is connected to the SO output. A variety of optional cables are available including: tinned wire termination, 1/8 inch [3.5 mm] mono plug, or DB9 for RS-232.





Figure 2 Connection Details

Refer to Table 1 and [Figure 3](#) for the output socket connection detail:

Pin	Description	Wire Color (of cable)
1	RS232 Receive (input to sensor)	Red
2	Common	Orange [BNC -]
3	SO (PNP Output) TTL compatible output	Yellow [BNC +]
4	RS232 Transmit (output from sensor)	White
5	OC (NPN Output)	Black

Table 1 Output Connections

Figure 3 Pin Connections



5.0 OPERATION

Note: Refer to [Figure 1](#) for switch and button locations.

Turn the unit on by moving the Power switch (8) to the **On** position. The unit may be operated from the internal batteries and/or the charger/power supply. The internal batteries will be trickle charged when using the AC charger/power supply. To turn the unit off, slide the Power switch (8) to the **Off/Charge** position. If the charger is plugged in, the batteries will charge.

The sensor emits a laser beam, which is reflected back by a target (reflective tape/paint, keyway, contrasting colors, etc). This reflected light is sensed and amplified then compared to a threshold level (sensitivity) - the lower the threshold level, the more 'sensitive' the sensor is. Whenever the amplified signal is above the threshold, the output goes high (positive

pulse) or low (negative pulse). The user can select either a positive or a negative output pulse using the Polarity switch (5).

The gain of the input amplifier and the sensitivity can be adjusted manually or automatically. This allows the unit to be used with many types of targets at various distances and contrasting color conditions. To select the Auto mode, turn the Sensitivity Adjust knob (7) fully counterclockwise, otherwise you are in the Manual mode. Reflective tape and high contrast color applications should be able to use the Auto mode.

5.1 Auto Mode

Make sure the Sensitivity Adjust knob (7) is fully counterclockwise and the **Auto/Gain** LED (3) is on. Aim the laser at your target. Press and hold the Learn/Gain button (6) until the **On Target** LED (1) blinks regularly or is on solid (depending on the RPM of the target). Release the Learn/Gain button. The **Auto/Gain** LED will blink to show what gain has been selected. Refer to Table 2.

In many applications, this is all that is needed. In cases where the target is marginal, the user may need to manually adjust the sensitivity after trying the Auto mode.

5.2 Manual Mode

Aim the laser at your target. Turn the Sensitivity Adjust knob (7) between **Min** and **Max** until the **On Target** LED (1) starts blinking or comes on solid. If you can't get a good setting, change the gain.

Number of blinks	Gain
1 Strong Signal	X 1
2	X 2
3	X 4
4	X 5
5	X 8
6	X 10
7	X 16
8 Weak Signal - Move Closer	X 32

Table 2 Auto/Gain Blinks

Press and release the Learn/Gain button (6) to change the gain of the input amplifier. Each time the button is pressed, the gain is changed. The **Auto/Gain** LED (3) will blink to show what gain has been selected. If the button is held down, the gain will increase automatically after each LED ‘blink’ pattern. Refer to Table 2. The larger the gain, the weaker the signal being picked-up. Using a large gain for a strong signal is not recommended since the input will saturate.

6.0 ADVANCED FEATURE (TARGET POLARITY)

The input circuitry can be set to optimally work with two different target types: a reflective (white, shiny) target on a mostly non-reflective (black, dull) background or a non-reflective (black, dull) target on a mostly reflective (white, shiny) background. These will be referred to as a white target or a black target. When the unit is first turned on, the **On Target** LED (1) will indicate which target type the sensor is set up for. While the **Laser On** LED (2) is blinking, the **On Target** LED will be on for a white target or off for a black target. The unit will still work when set up for the “wrong” target type, but it won’t have as great a range. When set for a white target, the unit triggers on the black to white transition. When set for a black target, the unit triggers on the white to black transition.

To change the setting, move the Polarity switch (5) to the left (positive pulse) for a white target or to the right (negative pulse) for a black target. Turn the Sensitivity Adjust knob (7) to **Max**. Press and hold the Learn/Gain button (6) until the **Auto/Gain** LED (3) blinks.

7.0 AIMING THE LASER

The proper operation of the Laser Sensor is dependent upon the alignment to and reflectivity of the target. In order to aim the beam it is necessary to stand behind the sensor and view the target along the plane of the beam.

Do not stare directly into the laser beam or the reflected light. For targets greater than 5 feet and up to 65 feet from the sensor, mount the laser on a tripod using the ¼ - 20 bushing on the bottom of the unit and attach T-5 reflective tape to the target.

To aid in locating the laser dot over a large distance, hold a piece of white cardboard or equivalent in front of the laser. Progressively move the white surface closer to the desired target. Then adjust the aim of the laser as necessary.

In areas of high ambient light (outdoors), performance can be enhanced at long distances by slipping a piece of black tube with a minimum inner diameter of 0.6 inches, over the nose piece to act as an extension nose piece. This tube should not deflect the beam in any way.

8.0 RS232

Baud rate = 9600, 8 bits, 1 stop bit, no parity.

When the unit is turned on, it will send out: “SLS<lf><cr>Vx.x<lf><cr>0.0<cr>”. Where <lf> is the linefeed character, <cr> is a carriage return character, and x.x is the firmware version number.

The unit will send out the current RPM as a right justified 7-digit ASCII number that will always include a decimal point followed by carriage return. The update rate is a function of the speed of the target and will not exceed twice per second.

Examples:

1234.56<cr>

123456.<cr>

___0.0<cr> (_ = space character)

9.0 CHARGING

Slide the Power switch (8) to the **Off/Charge** position and plug in the charger. The **Power** LED (4) will blink red while the unit is fast charging. The **Power** LED will blink amber when slow (trickle) charging. It will be solid amber when the batteries are fully charged.

Note: If the charger is plugged in when the Power switch is the on position, the batteries will be trickle charged during operation.

CAUTION: Use only the supplied PR-Universal charger with the sensor.

10.0 SPECIFICATIONS

Note: Product specifications are subject to change without notice.


10.1 Laser Specifications

Classification: Class 3R (per IEC 60825-1 Edition 3 2014)
Complies with 21CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, date June 24, 2007.

Maximum Laser Output: <5mW
Pulse Duration: Continuous
Laser Wavelength: 650 nm
Beam Divergence: < 0.5 mrad
Beam Diameter: 4 x 7 mm typical at 2 meters
Laser Diode Life: 8,000 hours MTBF (1 year warranty)

Laser is on when this indicator is illuminated.

AVOID EXPOSURE
LASER RADIATION IS EMITTED
FROM THIS APERTURE.



10.2 General

Operating Range: Up to 65 feet depending on target reflectivity:

1/2" reflective tape (T-5) @3600 RPM: up to 65 ft. (19.8 m) or
up to 75° from target

White/Black contrast @3600 RPM: up to 3 ft. (91 cm) or up
to 45° from target

Black mark on dental drill: up to 4 in. (10 cm) at
over 260,000 RPM

Max RPM: 500,000 RPM

Min. Trigger Duration: 10 µsec

Indicators: LEDs for On Target, Laser On, Auto/Gain, Power/
Charge

Modes: Normal (manual) or Auto, and charging

Normal mode – manual adjustment of sensitivity / gain


Auto mode – auto learn, automatic gain control

Sensitivity Adjust: Single Turn knob on top panel in Normal mode

Voltage Requirements:

Operational: Internal: rechargeable batteries

External: +9 V  1VA


Charging: External: +9 V  3VA


Batteries: Internal 4 “AA” rechargeable NiCd 700mAh

Run Time: Over 6 hours continuous operation from fully
charged batteries @ 70 °F (21 °C)

Charge Time: Typically less than 3 hours @ 70 °F (21 °C)

PR Universal Charger:


Input: 100-240 V , 50-60 Hz

Output: 9 V , Dry location use only

Check charger label for power information.

Pulse Output:

SO: Source Output - Square Wave 0 to 3.9V typical @ 15mA (PNP to 4.2V, 4.7K ohms to common) (TTL Compatible)

OC: Open Collector - Switches to common, External pull up resistor to user supplied power (max 24 V ) required

Polarity: Positive or Negative pulse (switch selectable)

RS232: Transmit Out – ASCII value of RPM (Accuracy \pm 0.002% of reading)


Settings: 9600 baud, 8 bits, 1 stop, No Parity

Connector: Circular DIN 5 Socket - Common, (Outputs) SO, OC, (Serial RS232) Transmit, Receive

Mounting: 1/4-20 UNC Bushing included (Tripod Mount)

Weight: 10.6 oz (300.5 grams) excluding cable and charger

Dimensions: 5.38" (13.67cm) L (including snout) x 2.53" (6.42cm) W x 2.25" (5.72cm) H (including knob and feet)



10.3 Installation Environment

Installation Category II per IEC 664

Pollution Degree Level II per IEC 61010-1

Temperature: 32 to 104 °F (0 to +40 °C) operating
14 to 158 °F (-10 to +70 °C) storage

Humidity: Maximum relative humidity of 80% for temperatures up to 88 °F (31 °C) decreasing linearly to 50% relative humidity at 104 °F (40 °C)

10.4 Compliance

Please visit our website www.monarchinstrument.com to download our EU Declaration of Conformity for this product.

11.0 OPTIONS AND ACCESSORIES

T-5	Reflective Tape, 5 foot [1.5 m] roll, ½ inch [13 mm] wide
T-5WP	Waterproof Reflective Tape (honeycomb pattern), 5 foot [1.5 m] roll, 1 inch [25 mm] wide
SLS-CA-BNC	Cable assembly with BNC connector (SO)
SLS-CA-W	Cable assembly with tinned leads
SLS-CA-P	Cable assembly with 1/8 inch [3.5 mm] mono plug (SO)
SLS-CA-RS232	Cable assembly with DB9 connector for RS232
SLS Battery Pack	Replacement rechargeable Ni-Cd batteries
PR Universal	Recharger/Power Supply with assorted adapter plugs

Check out some of our other product lines...



Tachometers



Stroboscopes



Track-It™ Data Loggers

Printed in the U.S.A.

Copyright 2016 Monarch Instrument, all rights reserved

1071-4859-114-0916