


SETTING PROGRAMMES FOR THE VT-36 CONTROLLER

- The VT-36 Programmable Controller has the flexibility to be able to run multiple sets of steps in a programme with a number of UP-Ramp sets and DOWN-Ramp sets.
- The Controllers' standard default setting is set to run on 8 Steps (Cycle A). This allows the user to run 2x UP-Ramps sets and 2x DOWN-Ramp sets.
- You can change the Controller to 16 Steps (Cycle A&B) in the Global Parameters. This will allow the user to run a maximum of either 4x UP-Ramp sets, and 2x DOWN-Ramp sets <u>OR</u> 2x UP-Ramp sets and 4x DOWN-Ramp sets.

Fig 1.







Client Programme Data

3 UP ramps only

	Program - Cycle A				
	Туре	Controller Input	Detail	Comments	
1a	Delay			No Delay	
2a	1st Ramp Up	0040	Deg C / Hour		
3a	1st Set Temperature	0200	Deg C		
4a	1st Soak		Hours & Minutes		
5a	2nd Ramp Up	0060	Deg C / Hour		
6a	2nd Set Temperature	0600	Deg C		
7a	2nd Soak		Hours & Minutes		
8a	1st Ramp (down)		Deg C / Hour	No data to reflect	
9a	1st Set Temperature (down)		Deg C	No data to reflect	
10a	1st Soak (down)		Hours & Minutes	No data to reflect	
11a	2nd Ramp (down)		Deg C / Hour	No data to reflect	
12a	2nd Set Temperature (down)		Deg C	No data to reflect	

	Program - Cycle B					
	Туре	Controller Input	Detail	Comments		
1b	Not Available on Cycle B					
2b	3rd Ramp Up	0100	Deg C / Hour			
	3rd Set Temperature	1000	Deg C			
3b	3rd Soak		Hours & Minutes			
4b	4th Ramp Up		Deg C / Hour			
5b	4th Set Temperature		Deg C			
6b	4th Soak		Hours & Minutes			
7b	1st Ramp (down)		Deg C / Hour	No data to reflect		
8b	1st Set Temperature (down) for 16 Steps		Deg C	No data to reflect		
9b	1st Soak (down) for 16 Steps		Hours & Minutes	No data to reflect		
10b	2nd Ramp (down) for 16 Steps		Deg C / Hour	No data to reflect		
11b	2nd Set Temperature (down) for 16 Steps	,	Deg C	No data to reflect		

Programme Data entering:

ENTERING DATA FOR A 16-STEP PROGRAMME (BOTH CYCLE A & B)

- 1 Ensure no programme is running.
- Select the programme you wish to set.
- 3 Return to the default screen (Kiln temperature should be on the display).
- Hold down the "f" key for 5 seconds. The display will change to P-01. You are now in the Global Parameter Setting (page 7 in your manual).
- $5\,$ Use the UP arrow key to select "P-15" (This is the parameter to change from 8 to 16 steps)
- 6 Press the RIGHT arrow key once. You will see "0001" on the display.
- 7 Change "0001" to "0002" by using the UP arrow key.
- 8 Press the "f" key twice to return to the default screen.
- 9 You have now set your controller to run 16 steps (2 Cycles)
- 10 Enter your programme data as per your table above (fig 1).

Note: When you are entering data in CYCLE B you will see a red dot on the bottom right corner of the controller display. This indicates that you are in CYCLE B.