



### INSTRUCTIONS FOR SPORTOGO 40" AND 24" BALLS

1. Remove plug from inner bladder located inside material cover.
2. Use an air compressor to inflate or one of our Double Action Hand pumps that are sold separately. (Please see the warnings section at the bottom of this sheet).
3. **NOTE: THE BLADDER WILL BECOME TIGHT AT 24" (OR AT 13" FOR A 24" BALL); KEEP PUMPING UNTIL THE COVER IS SMOOTH.**
4. Replace plug and secure hook and loop closure.

### WASHING INSTRUCTIONS

1. To wash outer cover, deflate inner bladder completely and remove bladder from outer cover.
2. Wash in cold water using laundry detergent.
3. **DO NOT** use bleach.
4. Dry with **LOW HEAT** or drip dry.
5. After material cover is dry, insert bladder back into material cover being careful to locate inflation hole near hook and loop opening. Re-inflate ball.

### WARNINGS

1. Is using an air compressor to inflate ball, inflate ball slowly until outer cover is smooth.
2. **DO NOT** over-inflate ball.
3. **DO NOT** stand on ball or play near stairs.
4. **DO NOT** strike ball with head (**NO HEADERS**)
5. Keep away from heat or open flame.
6. Avoid contact with sharp objects.
7. Be Safe! Play away from the street.
8. Adult supervision strongly recommended.