

Operator's Guide



CN201 & CX201 Suction Sweeper

Part No
7018550
(GB)

Revision Level F

(VM Euro 5 & Stage 3a)

Foreword	F
General Arrangement	1
Controls	2
Operation	3
Optional Equipment	4
Johnston Visual Module (JVM)	5
Routine Maintenance	6
Conformity Certificates	7

Foreword

The Johnston CN201, CX201 Compact Sweeper represents the highest grade of craftsmanship and reliability that makes Johnston a world leader in sweeping technology.

This machine is designed for the removal of spoil on traffic or pedestrian areas and litter collection using the wanderhose, and should only be driven by trained operatives.

This machine should not be used for sweeping hot or burning substances. In the unlikely event of a fire, normal powder or foam fire fighting equipment can be used on this product.

An operator should receive training in the follow elements:

1. Safety observations/notices.
2. Transit driving.
3. Correct use of auto hopper safety prop.
4. Correct use of seat controls and steering column adjustment.
5. In-cab controls - various switch functions and controls.
6. External controls.
7. Front brush setting, adjustment and changing.
8. Nozzle height setting operation, reverse lift function and Powathrust switch.
9. Daily and weekly maintenance items.
10. Sweeping bulky items, i.e. bottles and cans.
11. The correct way to mount and dismount kerbs.
12. Load discharge.
13. Driving/operational assessment.
14. End of day cleaning, rear mesh and water drainage screens.

Johnston Sweepers can provide operator training upon request.

We would point out that it is the employers responsibility to carry out his own Risk Assessment on the equipment in his particular working environment and work application.

This handbook should be carefully studied. In it you will find instructions for the operation and maintenance of your Johnston Sweeper.

It is vitally important that the operator and maintenance staff have a copy of this book. The life of the machine will depend upon following these instructions in respect of regular maintenance and correct operating methods.

It is important that only genuine Johnston spare parts are used when servicing and maintaining the sweeper. This is especially important for consumables, filters etc, as the use of non-genuine parts may cause premature failure and invalidation of warranty.

When carrying out maintenance or part replacement, additional explanatory illustrations may be found in the Parts Manual, which shows and lists hardware, and availability of spares with the orientation and positions of the various components.

Abbreviations Used :

LH	=	Left Hand	L	=	Left
RH	=	Right Hand	R	=	Right



Safety Notice



The universal safety symbol is used throughout this guide to indicate information which is essential for health and safety for all operating personnel



Warning



The use of CB radios and other electrical equipment in the sweeper should be properly suppressed (EMC) to prevent the possibility of interference with the sweepers electronic systems

Johnston® is a registered trade mark of Johnston Sweepers Limited.

All copyrights and rights reserved. The reproduction, distribution and utilisation of this document as well as the communication of its contents to others without express authorisation is prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

Every endeavour has been made to ensure that the information contained in this Operator's Guide is correct, but due to continuous product development, the Company reserve the right to alter its contents without notice. This document should not be interpreted as being part of a formal contract.

For further information and enquiries please contact;

Johnston Sweepers Limited

Curtis Road, Dorking, Surrey RH4 1XF, UK

Tel: +44 (0)1306 884722

Fax: +44 (0)1306 884151

E-mail: enquiries@johnstonsweepers.com

Web: www.johnstonsweepers.com

Page Issue Levels

Page	Issue	Changed	Page	Issue	Changed
Front Page	F	Y	Foreword 1	A	
Foreword 2	A		Foreword 3	F	Y
1:1	A		1:2	C	
1:3	A		1:4	A	
2:1	A		2:2	C	
2:3	C		2:4	A	
2:5	C		2:6	C	
2:7	C		2:8	C	
2:9	C		2:10	C	
2:11	C		2:12	B	
2:13	C		2:14	A	
3:1	E		3:2	F	Y
3:3	C		3:4	A	
3:5	C		3:6	C	
3:7	C		3:8	A	
3:9	C		3:10	C	
3:11	A		3:12	C	
3:13	E		3:14	E	
4:1	C		4:2	A	
4:3	F	Y	4:4	F	Y
5:1	A		5:2	A	
5:3	A		5:4	C	
5:5	C		5:6	C	
5:7	C		5:8	C	
5:9	A		5:10	A	
5:11	C		5:12	A	
5:13	A		5:14	A	
6:1	A		6:2	A	
6:3	D		6:4	F	Y
6:5	Y	Y	6:6	F	Y
6:7	A		6:8	F	Y
6:9	A		6:10	E	
6:11	A		6:12	F	Y
6:13	C		6:14	A	
6:15	A		6:16	A	
6:17	A		6:18	A	
7:1	C		7:2	C	
7:3	C		7:4	C	
7:5	C		7:6	C	

All Copyright and rights are the property of Johnston Sweepers Ltd.

CHAPTER **1**

General Arrangement

Table of Contents

Subject	Page
Exterior	1 : 2
Hopper & Engine Compartment	1 : 3

General Arrangement - Exterior




All Copyright and rights are the property of Johnston Sweepers Ltd.

Wheels & Tyres: Front 6.50 R10
Rear 225/75 R10

Pressure: Front 6.2 bar (90 psi)
Rear 5.75 bar (83.5 psi)

Wheel Nut Torque: 250 Nm (180 lb.ft)

General Arrangement - Hopper and Engine Compartment



All Copyright and rights are the property of Johnston Sweepers Ltd.

General Arrangement - Component Key

1. Beacon
2. Rear Side Cover (both sides)
3. Front Side Cover (both sides)
4. Securing Eye (x4)
5. Tool Kit

6. High Level Worklamps
7. Water Spray Jets
8. Headlights
9. Daytime Running Lights
10. Indicator Lights

11. Front Towing Eye
12. Low Level Worklights
13. Suction Nozzle
14. Suction Fan Inspection Cover
15. Recirculation Water Tank Filler

16. Suction Fan
17. Wanderhose
18. Hopper Mesh Baskets
19. Recirculating Water Filter Screens
20. Sludge Drainage Channels

21. Hopper Door Lever
22. Rear Strobe Lights
23. Rear Arrowboard
24. Radiator
25. Hydraulic Tank Level Gauge

26. Rear Grille / Working Platform
27. Hopper Safety Props
28. Engine Coolant Reservoir
29. Transmission Oil Reservoir
30. Engine Air Cleaner

31. Hopper Lift Emergency Pump
32. Hydraulic Tank and Filler
33. Transmission Oil Filter
34. Fuel Filter
35. Battery

36. Engine Oil Dipstick
37. Supawash
38. Side Water Tank & Filler
39. Nozzle Duct Water Supply Valve
40. Nozzle Duct Blanking Flap Lever

41. Brake Fluid Reservoir
42. Hydrant Equipment
43. Recirculation Water Tank Access Covers / Filters


CHAPTER

2

Controls


Table of Contents

Subject	Page
General Layout	2 : 2
Overhead Console	2 : 3
Johnston Visual Module (JVM)	2 : 4
Front Centre Console	2 : 5
Rear Centre Console	2 : 6
Handbrake/Dump Valve Lever	2 : 8
Arm Rest Controller	2 : 9
Steering Column Switches	2 : 12
Foot Controls	2 : 13
Drivers Seat Adjustment	2 : 13

In-Cab Operating Controls**General Layout****Key**

-
- | | |
|-----------------------------------|------------------------------|
| A - Overhead Console | G - Arm Rest Controller |
| C - Johnston Visual Module (JVM) | H - Steering Column |
| D - Front Centre Console | J - Foot Controls |
| E - Rear Centre Console | L - Driver's Seat Adjustment |
| F - Handbrake / Dump Valve Levers | M - OBD Port |

Overhead Console - A





Symbol	Switch	Description
	A1	Radio/MP3 Player
	A2	Head/Side Lights.
	A3	Rear Fog Lights.
	A4	Worklights.
	A5	Heated Windscreen.
	A6	Speakers.
	A7	Interior Light.
	A8	PTO Function - Gritter / Spreader ** First position; off. Second position; activates gritter/spreader when travelling in a forward direction only. Third position; activates gritter/spreader continuously. Note: Functions only with work mode engaged.
	C	Johnston Visual Module - JVM (see next page).

** Optional Winter Equipment

All Copyright and rights are the property of Johnston Sweepers Ltd.

Johnston Visual Module (JVM) - C


Symbol	Switch	Description
	C1	Brake Failure Warning
	C2	<i>Not used.</i>
	C3	Engine Fault
	C4	OBD Emission Fault
	C5	Engine Pre-Heating
	C6	Handbrake Warning Light
	C7	Main Beam
	C8	Side Lights
	C9	Direction Indicators
	C10	Rear Fog Lights


All Copyright and rights are the property of Johnston Sweepers Ltd.

Johnston Visual Module (JVM) - C


Symbol	Switch	Description
	C11	USB Port.
	C12	Soft key F1.
	C13	Soft key F2.
	C14	Rotary / push-button control.
	C15	Soft key F3.
	C16	Soft key F4.



For detailed information on JVM display functions/operation refer to Chapter 5.

Front Centre Console - D



Symbol	Switch	Description
	D1	Windscreen washer bottle.
	D2	Pen tray.
	D3	Auxiliary power socket.

Rear Centre Console - E


Symbol	Switch	Description
	E1	Heater valve - rotate the valve anticlockwise to achieve warm air and clockwise for colder air.
	E2	Air distribution - recirculate/fresh.
	E3	Heater fan - 2 speed - to optimise heater performance open/close diffusers as required.
	E4*	Air conditioning ON / OFF.
	E5*	High pressure washer - pressing switch activates water pump to allow use of hand lance located behind the rear of the cab.
	E6*	4WS - When switch is selected the vehicle will automatically enable/disable 4WS when transit/work mode is selected. Therefore 2WS functionality will be enabled as required. (patent pending)
	E7	Water sprays - first position activates sprays with fan and brushes. Second position will immediately activate water sprays.
	E8	Suction fan - may be used with wanderhose when nozzle duct is blanked with flap. May also be used at any time during sweeping operations to run the fan.


* Optional Equipment

Symbol	Switch	Description
	E9	Beacon.
	E10	Hopper raise/lower - pressing switch forwards raises tank backwards lowers hopper.
		
	E11	Ignition switch - ACC - Accessory position, enables radio to operate whilst engine is switched OFF. ON - Turn ignition ON, use switch H2b to start engine.
	E12*	Climate Control;
		Recirculation - Press for more than one second to display external temperature for six seconds.
		Airflow - Press to increase / decrease airflow as required.
		Temperature - Press to increase / decrease temperature as required.
		Press for five seconds to change compressor state between 'AC' or 'ECON'.

* Optional Equipment

Handbrake / Dump Valve Lever - F

Item	Description
F1a	Handbrake
F1b	Dump valve lever



To release the handbrake in an emergency if the engine is inoperative;


Unscrew silver disc anti-clockwise until plunger releases disc.

Pump plunger disc until solid; i.e. until plunger can no longer be depressed.

Hydraulic handbrake is released at this point, the vehicle is able to be moved after releasing handbrake control.

Before commencing normal vehicle operation, push in silver disc & turn clockwise until fully locked.

Arm Rest Controller - G



Symbol	Switch	Description
	G1	Nozzle hop down.
	G2	Nozzle hop up (for ingestion of bulky objects).
	G3*	Nozzle flap - close
	G4*	Nozzle flap - open
		} option for ingestion of leaves or bulky items.
	G5	Brush - speed increase.
	G6	Brush - speed decrease.
	G7	Cruise control - pressing switch momentarily will set cruise control active at the current forward speed. Pressing the switch again, or applying the brakes, will cancel the setting. Note: Functions only with work mode engaged.


*Optional Equipment

All Copyright and rights are the property of Johnston Sweepers Ltd.


Symbol	Switch	Description
	G8	Engine speed increase - Increases engine speed to a maximum of 1480 rpm when in work mode.
	G9	Engine speed decrease - reduces engine speed to a minimum of 1000 rpm.
	G10	Sweep selector - rotates fan, brushes, water sprays and lowers all sweep gear used for left hand sweeping. ** Rotates snow broom if fitted. In this mode brush pressure will revert to LH last set setting after 6 seconds.
	G11	Sweep off - cancels fan, brushes, water sprays and returns sweep gear to stowed position. Also if G14 is activated, stops third brush rotation if switch.
	G12	Right hand sweep selector - rotates fan, brushes, water sprays and lowers all sweep gear to the RH position. ** Rotates snow broom if fitted. In this mode brush pressure will revert to RH last set setting after 6 seconds.
	*G13	Third brush rotation – clockwise – pressing switch rotates brush for LH sweep.
	G14	Shuffle button (sweeper only, not available with 3rd brush) - In work mode press and hold to automatically move vehicle in a backwards direction with sweepgear engaged. Release button to return to normal mode of travel / sweeping. Note: Reversing camera will auto-engage on selection of the shuffle button.
	*G14	Third brush functions on/off – enables third brush functions for switches G10, G12, G16 & G17. *Optional Equipment ** Optional Winter Equipment

Symbol	Switch	Description
	*G15	Third brush rotation – clockwise – pressing switch rotates brush for RH sweep.
	G16	a - increases LH brush pressure. a - lowers front-mounted winter equipment.** b - decreases LH brush pressure. b - raises front-mounted winter equipment.** c - moves LH brush in. c - slews front-mounted winter equipment to the left.** d - moves LH brush out. d - slews front-mounted winter equipment to the right.**
	G17	a - increases RH brush pressure. b - decreases RH brush pressure. c - moves RH brush out. d - moves RH brush in. * Third brush functions for G16 and G17 are activated when switch G14 is engaged.
	*G16	a – lowers brush. b – raises brush. c – traverses brush arm right. d – traverses brush arm left.
	*G17	a – tilts brush head forward. b – tilts brush head backward. c – swivels brush head right. d – swivels brush head left.
		*Optional Equipment ** Optional Winter Equipment

All Copyright and rights are the property of Johnston Sweepers Ltd.


Steering Column Switches - H


Symbol	Switch	Description
	H1	<p>Lighting</p> <p>Main/dip beam - pushing lever down activates main beam. Lifting lever flashes head lamps.</p> <p>Horn - pushing button in activates horn.</p> <p>Indicators - pushing lever forward, right indicator. Pulling lever backwards, left indicator.</p> <p>Wash/wipe - pressing collar in activates water jets.</p> <p>Turning switch to</p> <ul style="list-style-type: none"> - Intermittent wipe. - Slow wipe. - Fast wipe.
	H2	Transmission drive selector.
	H2a	<p>Forward/reverse</p> <ul style="list-style-type: none"> - pushing lever forwards selects forward direction. - pulling lever backwards selects reverse direction.
	H2b	<ul style="list-style-type: none"> - With switch E10 set to ON position and foot brake J2 depressed, pressing button will start engine (if not already running). - With engine running pressing button will engage work mode @ 1000 rpm unless the GO pedal is depressed. - Whilst in work/transit mode with reverse selected, pressing button will activate night silent function (mutes reverse bleeper), an icon will illuminate on the JVM. <p>Turn OFF ignition to cancel night silent function.</p>
	H3	<p>Pulling lever towards driver unlocks the column, allowing it's reach (pulling upwards) / rake (pushing downwards) to be adjusted.</p>
	H4	<p>Hazard warning flasher - push to activate, when activated flashes red.</p> <p>Note: This hazard warning signal device should be used in accordance with the road vehicle lighting regulations and should NOT be used whilst sweeping.</p>




Foot Controls - J

Item	Description
J1	<p>Powathrust switch - Pressing pedal will activate full brush pressure for 10 seconds. After 10 seconds the brush pressure will return to the previous operating value.</p> <p>Pressing J1 when selecting reverse holds the nozzle and brushes in the working position.</p>
J2	<p>Brake pedal - activates 4-wheel brakes.</p>
J3	<p>GO pedal - increases vehicle speed when depressed. Reduces speed when relaxed.</p>



Drivers Seat Adjustment - L



Item	Description
L1	<p>Pull knob to lower seat, push knob to raise it.</p>
L2	<p>Moving lever vertically allows the seat to slide forwards and backwards to the desired position.</p>
L3	<p>Lift lever to adjust the rake of the seat back cushion.</p> <p>*Heated seat option - seat will automatically heat up on low ambient temperature and is thermostatically controlled.</p> <p>*Optional Equipment</p>

All Copyright and rights are the property of Johnston Sweepers Ltd.

CHAPTER

3

Operation

Table of Contents

Subject	Page
Driving and Safety Precautions	3 : 2
Essential Daily Check List	3 : 2
Noise and Vibration	3 : 4
Towing Vehicle	3 : 5
Emergency Hand Pump	3 : 5
Securing Vehicle	3 : 5
Craning Vehicle	3 : 5
Operating Procedures	3 : 6
Brush Settings	3 : 8
Suction Nozzle Operation and Settings	3 : 9
Sweeping Conditions	3 : 10
Load Discharge	3 : 12
Wanderhose Operation (Option)	3 : 12
End of Day Routine	3 : 13
Sweeping in Cold Temperatures	3 : 13
Rear Grille / Step	3 : 14



Driving and Safety Precautions



- The drive foot pedal with its inching feature, propels the vehicle when depressed and enables braking when released. Extra care **MUST** be exercised with the control on tight turning manoeuvres, during acceleration, when slowing down and during transit mode.
- The brakes used on this vehicle can become affected by minor surface oxidation. If the brakes have not been used for a period of time, the initial use of the brakes can be compromised.

It is recommended that before driving any distance, the brakes are applied in a controlled manner, to ensure the brakes perform correctly.

- The steering control provides for extreme manoeuvrability with a non-reactive steering 'feel', therefore care **MUST** be exercised in transit mode to resist moving the steering wheel with erratic movements.
- **ALWAYS** reduce vehicle speed before making any sharp turns.
- Exercise extra care when traversing inclines or ramps.
- **DO NOT** drive the vehicle with the hopper in the raised position.
- Ensure transmission column switch is in neutral and the handbrake is on when the machine is left unattended with the engine running.
- Ensure that the hopper safety props are used at **ALL TIMES** whilst the hopper is in the raised position.

Essential Daily Check List

Before operating the vehicle for either sweeping or driving, ensure that the following list of checks are carried out.

Engine and Transmission

Ensure -

1. The engine is filled to the correct level with approved engine oil. Top up if necessary with an SAE 10W/40 multigrade oil to the correct specification.
2. There is sufficient diesel fuel in the fuel tank. The fuel should be to BS 2869 and can contain no more than 5% bio diesel.
3. The cooling system is full and protected by antifreeze to the correct strength, 50% concentration. Top up via the radiator header tank to the maximum level.

4. The transmission oil reservoir is filled to the correct level. Top up if necessary with T46 multigrade hydraulic oil.
5. Drain fuel filter of water if JVM icon is illuminated.
6. Clean / replace air filter elements if icon is displayed on the JVM.
7. There are no visible fuel, water or hydraulic oil leaks.



The fuel system is self bleeding and any fuel lines should not be loosened in the event of running out of fuel, as high pressure fuel could escape and cause injury.

Cab and Chassis

Ensure -

1. The driver's seat and steering column are adjusted for a comfortable driving position.
2. The lights, indicators, horn, brakes etc. work correctly.
3. The windscreen washer bottle has adequate water in it.
4. The brake fluid reservoir is filled to the correct level. Top up as required.
5. The tyres are in good condition and are inflated to the correct pressures.

Sweeping System

Ensure -

1. The hydraulic oil tank is filled to the correct level i.e. middle window of hydraulic tank level gauge. Top up if necessary with T46 multigrade hydraulic oil.
2. The clean water and recirculation water system tanks have adequate water in them.
3. The water spray jets are not blocked and provide an even spray system.
4. All wearing parts (brushes, suction fan, nozzle, trunking, intake duct, meshes etc.), are in good condition.
5. The suction fan is clean and free from debris, as well as being in good mechanical order.
6. The suction fan inspection cover is correctly and securely fitted into position.
7. The sweep system, especially the brush arms, function correctly as they are particularly vulnerable to damage.
8. There are no visible water or hydraulic oil leaks.

Noise and Vibration

Noise Levels

All noise levels are given at maximum engine operating speeds, but in normal operation are likely to be lower than the figures quoted.

In cab noise level with the windows closed 71 dB(A).

External noise levels at one metre distance of the side of the machine i.e. wanderhose operation, are 89 dB(A).

Noise levels at 3 metres in front of the machine (manual pavement sweeping into the gutter) are 81 dB(A).

The sound power level L_{WA} is 103 dB(A).



Ear defenders are recommended when working around the machine

Vibration

All dynamic prime mover components are resiliently mounted to minimise vibrations. Vibration levels in accordance with 2006/42/EC as amended.

Hand-arm

The vector sum weighted root mean square acceleration values ($a_{h,w}$) during recommended sweeping/ washing activities do not exceed 2.5 m/s².

Whole body

The dominant axis weighted root mean square acceleration values (a_w) during recommended sweeping/ washing activities do not exceed 0.5 m/s².

Conditions of test - body empty and water tanks full on public thoroughfare.

The Control of Vibration at Work Regulations 2005 Directive 2002/44/EEC.

In accordance with the above Regulation the operators of the machine over a typical duty cycle will be subjected to an 8 hour energy equivalent acceleration A(8) below the Exposure Action Level (EAV) for both Hand-arm and Whole Body Vibration. These Limits are:

Hand-arm: EAV 2.5m/s²


Whole body: EAV 0.5m/s²

Towing the Vehicle

The vehicle may be towed at a maximum of 5 mph by attaching a tow rod or cable to the front eye or rear (if fitted).

Emergency Hand Pump

A hand pump is provided which can be used to raise the hopper to service the engine in the event of a malfunction. To lower the hopper, firstly operate the hand pump to raise the hopper sufficiently to ensure the hopper props can be stowed. The hopper may then be lowered by turning on the ignition switch and operating the hopper lower switch.




Securing the Vehicle

When the sweeper is transported on a vehicle, two holes are provided on each side of the chassis for the fitting of the securing eyes (provided in the tool kit) in order that the sweeper can be secured on the transporter.




These securing eyes are not suitable for lifting or craning the machine.



Craning the Vehicle

The vehicle may be lifted using conventional lifting systems that are slung from the vehicle road wheels.



Weight – W	Dimension – A	Condition
2700 kg.	0,73 metres	Empty
4000 kg.	0,63 metres	Loaded

⊙ = Centre of Gravity

All Copyright and rights are the property of Johnston Sweepers Ltd.

Operating Procedures



The machine is designed for operating between -15°C and 46°C.
When operating below 5°C refer to information later in this chapter.

Engine Starting

1. Carry out essential daily check list.
2. Before starting ensure that the handbrake is on and the transmission column switch is in neutral.
3. To start engine;
 - 3a. In cold weather turn ignition key to ON position until glow plug indicator  on JVM disappears. Depress foot brake and press button on transmission steering column switch to start engine.
 - 3b. When engine is warm turn ignition key to ON position, depress foot brake and press button to start engine.
 - 3c. Turning ignition key to ACC position will enable the radio to be operated without the engine running.



On starting the engine the brushes automatically lift and stow for a period of 8 seconds. During this period you cannot activate work mode.

Activating work mode switch with the engine running, will set the engine to a speed of 1000 rpm. The RPM is matched if it is between 1000 and 1480 when selected. Up to a maximum of 1480rpm i.e. if you are driving down the road at 2200rpm, pressing the work mode button will set engine rpm to 1480.



If there is a system fault an alarm will sound (3 beeps) to indicate a fault condition on the JVM display.

Refer to Chapter 5 for further information.

Emergency Engine Starting

In the event of a failure of the foot brake switch/circuit (no rear brake lights), the engine will not start. In this event press the Powathrust pedal, red stop button on the armrest controller and the yellow button on gear stalk to start engine. For safety reasons this method should only be used for emergency starting.

Driving Only (Transit Mode)

1. Select transmission column switch to either forward or reverse mode.
2. Release handbrake and depress GO pedal until a desired speed is reached. During this mode a maximum engine speed of 2000 rpm on CN201 and 2250 rpm on CX201. The maximum road speed of 40 kph (25 mph) can be attained on a CN201 and 50 kph (32 mph) on a CX201.

Note: The maximum speed in reverse is 13 kph.

Sweeping (Work Mode)

1. Ensure nozzle duct blanking flap lever is in the open position.
3. Select 4WS button, if required.
2. Engage work mode switch. The work mode revs will default to 1000 rpm when selected unless the engine speed is increased by depressing the GO pedal before selecting. (**Note:** maximum work mode revs 1480 rpm).
3. Select LH or RH sweeping. Pressing required switch rotates fan, brushes, activates water sprays and lowers all sweepgear to either LH or RH position.
4. Select transmission column switch to forward mode.
5. Release handbrake and depress GO pedal.
6. The brush speed may be adjusted using switch (G5 or G6) and the pressure on each brush can be independently controlled using the respective joystick.
7. Suction performance can be increased by pressing the engine speed increase switch to desired performance of up to 1480 rpm. Depressing engine speed decrease switch will reduce engine speed to a minimum of 1000 rpm.

Cruise Control

A switch is provided to set a sweeping speed. Press the GO pedal to reach the required sweeping speed. Press the cruise control switch, this will set the sweeping speed. The foot can be removed from the pedal. Reprising the switch or operation of the foot brake will cancel this function.

During cruise mode pressing the GO pedal will increase road speed for special manoeuvres. Releasing the pedal will revert to preset cruise speed.

Shuffle Button


Use the arm rest controller Shuffle Button if a swept area requires additional sweeping or to reverse out of a blind corner/alleyway and continue sweeping.

Brush Settings

The brush is supported on a pivoting arm which incorporates a shock absorber mechanism to withstand frontal impacts and allows it to float against the kerb when sweeping.



The brush angle should be correctly set, i.e. not flat on the road but angled so that about 120° of the circumference is towards the front kerb side in contact with the road.



A = Brush tilt adjustment bolts

B = Quick release retaining nuts

C = Grease nipple

Note: The brushes and nozzle may be lowered without the engine running by using the service menu on the JVM. For safety reasons, once the brush has been lowered for adjustment (with the engine running), ensure the engine is shut down. The brush will remain lowered for adjustment.



Sharp objects warning - there can be a risk of injury from sharp objects such as discarded hypodermic needles becoming lodged in the sweeping system. The use of 'needle stick gloves' is recommended when changing brushes, using the wanderhose/Littasnatch and when cleaning out the machine.

Brush Replacement

The brushes should be replaced when the tines are worn down to 100mm.

Engage work mode and move brushes apart, stop engine and remove ignition key.

Loosen the 4 retaining nuts (B), rotate brush stock to release from top plate. Apply one pump of grease to grease nipple (C). Refit new brush ensuring the brush is rotated to the correct end of the slot to ensure brush security.


Suction Nozzle Operation and Settings

Operation of the suction nozzle is in conjunction with the brushes when depressing the sweep selector switch. If the fan and nozzle only is required, then this can be achieved with fan only switch in conjunction with the nozzle lower switch. The nozzle is always lifted automatically when reverse gear is selected or when the sweep selector switch is returned to the central position (pressing Powathrust pedal holds nozzle on ground when reversing).

It is also possible to lift the nozzle using the 'nozzle hop' control during the sweeping operation for ingestion of bulky objects or when leaf sweeping. If leaf flap option is fitted this can also be used to allow bulky objects or leaves to be ingested into the nozzle.

For effective operation and thorough cleansing, the setting of the nozzle gap to the road surface is very important. The setting is the distance between the road surface and the suction head slide. The air gap should be between 5 - 10 mm. Adjustment of this gap should be done with the nozzle standing on a level surface and is made by raising or lowering the three wheels/skids that the nozzle runs on.

Suction Nozzle Adjustment



The adjustment is carried out by lowering the nozzle onto the 3 height setting anvils provided, then releasing the adjusting bolts and adjusting the nozzle to the desired height.

A = Setting Anvil

B = Height Adjustment

Note: The rubber tongue in the suction nozzle must also be in good condition, along with the retaining strap which locates at the rear edge of the tongue. If the tongue is torn in anyway it may affect the suction performance of the machine.

Sweeping Conditions

Sweeping in Wet Conditions

1. When operating in wet conditions and the recirculation water tank becomes full drain off excess water using dump valve lever whilst positioned over a drain. The JVM screen will display a recirculation water level high icon.

Sweeping in Dry Conditions

1. Prior to sweeping, ensure the recirculation water tank is full and the hopper is filled with 100 - 200 mm of water. This can be checked by looking through the hopper door. It will not be necessary to use the dump valve lever (F1b) under these conditions.
2. In dry conditions use the water sprays to prevent dust being generated by rotating brushes.

Sweeping Bulky Materials/Leaves

1. The nozzle hop control may be used to ingest bulky materials, cans and boxes or during the leaf sweeping season to aid the pick up of leaves.
2. When leaf sweeping, a slower brush speed should be used. Position brushes as desired, some machines may have the adjustable leaf lifter flap option fitted.
3. Once section is cleared, return nozzle to normal position by pressing and sweep over area again. Use leaf flap* if fitted and shuffle button if required.

To Stop Sweeping

1. Press sweep off switch to cancel fan, brushes, water sprays and to return sweep gear to stowed position.
2. De-select work mode switch with the column switch in neutral.

To Stop Engine

Allow engine to idle for a brief period, return ignition key to OFF position to stop engine.

*Option

Blocked Nozzle or Nozzle Duct

1. With the machine stationary and the nozzle and suction operating, open the adjustable leaf flap nozzle (if fitted) to increase the airflow and see if the obstruction clears.
 2. If not, again with the nozzle and suction operating raise and lower the nozzle and see if the blockage clears.
 3. If still blocked, switch off the engine, open the hopper door and check that the mesh screens are clear of debris and that the hopper is not full.
 4. If the mesh screens are blocked, clean them and providing the hopper is not full return the machine to service and check the nozzle performance.
 5. If the hopper is full the machine should be emptied at the nearest waste site.
 6. If the screens are clear, the hopper not full and debris is still not being picked up, it may be that the nozzle trunking or inlet tube is blocked.
 7. With the vehicle parked on level ground, carefully raise the hopper and rest it on the hopper prop position. Switch off the vehicle engine.
 8. Inspect the nozzle trunking and inlet tube. Using the two piece hoe if available or a suitable size broom handle or rod, clear any debris. When the ducts are clear, restart engine, lower the hopper and return the machine to service.
- N.B. Adequate use of water from the brush mounted sprays and the recirculation water system lubricates the hoses and ducts and helps reduce blockages.

Load Discharge



The disposal of sweepings should be in accordance with the local waste disposal regulations.

- Ensure the machine is standing on firm ground and the tipping area is clear of personnel before opening and closing the rear door.
- DO NOT raise a loaded body on any grade greater than 5% as stability could be affected.
- DO NOT shunt the load in order to aid discharge, or drive with the hopper in the raised position.

Before load discharge, 'dump' all dirty recirculating water using the recirculating water dump valve whilst positioned over a suitable drainage facility.

1. Reverse vehicle up to skip or tipping area. The load may be dumped into containers of up to 1.5M in height.

Note: Hopper will not tip if the rear cover to the engine compartment is open.

2. Engage handbrake. Open hopper door using hopper door release lever.
3. Raise hopper to full discharge position using the hopper lift/lower switch. Check hopper safety props have activated. Clean out hopper. A hoe is available as an option to assist cleaning.
4. Wash out hopper and recirculation water tank. Refill recirculation water tank.
5. Once load discharge is complete, stow safety props and lower hopper using hopper lift/lower switch.

Wanderhose Operation (Option)

1. Apply handbrake.
2. Blank off intake duct using nozzle duct blanking flap lever and close of water feed to suction nozzle.
3. Select work mode with engine running.
4. Increase engine speed up to 1480 rpm, depending upon material to be picked up.
5. Select fan only switch.
6. Unclip wanderhose boom from the roof of the hopper ready for cleaning.
7. The wanderhose may be used with a single operator whilst the vehicle is stationary or with a second operator when the wanderhose may be used with the vehicle moving slowly.

End Of Day Routine

Cleansing may be effected using a steam cleaning unit or the high pressure washer (option).

1. Ensure all doors and windows are shut and the hydraulic oil and fuel filler caps are secure.
2. Clean out hopper mesh screen, recirculating screens and sludge drainage channels.
3. Remove recirculation water tank filter and open dump valve using cab control lever. Clean tank thoroughly.
4. Clean out internal bore of suction hose, suction nozzle and channel brushes.
5. Generally clean down the exterior of the machine.

At the end of the cleaning operation close the tank dump valve and refill the tank ready for the next day or shift. At this stage run the recirculation water pump for a few seconds to flush some clean water through the pump and into the inlet duct to clean the system.

Sweeping in Cold Temperatures

Operating temperature 0°C to +5°C

For sweeping in cold conditions around freezing point e.g. early in the morning in frosty conditions, it is possible to use the two water systems on the machine. It is preferable however to either fill the tanks with warm water or fill them as normal and leave the machine in a heated garage overnight.

The recirculation system will function as normal as the water to a certain extent will be heated by the hydraulic oil cooler located within the tank. The water sprays to the brushes can also be used as normal, provided there is no danger of icing from the water sprayed onto the road.

Operating temperature -5°C to 0°C

Do not use or fill the water spray system for the brushes. Dust suppression can still be effected using the recirculation system. This should be filled with warm water or filled and left in a heated garage overnight to warm the water.


Operating temperature -15°C to -5°C

It is possible to use the machine for short periods with both water tanks dry. However, some dust will be exhausted from the machine and premature wear may be experienced on some components.

Note: Do not operate the machine dry with an empty recirculation tank for extended periods as this could lead to overheating of the hydraulic oil.

Rear Grille / Step

The step is situated below the radiator at the rear of the machine.



The step can be accessed by pulling the lower edge away from the machine and hinging it upward. It is secured by lifting it above a horizontal position and pushing it in towards the back of the machine and lowering it into the working position. There are location pins at either end of the grille. Ensure that both pins are engaged correctly. Open out the centre section.

To lower the step, stow the centre section then lift the step above horizontal and pull backwards away from the machine to disengage the latch. Lower the step until it is secured onto the magnetic catches.

Access to rear mesh baskets

1. With the machine on firm level ground and the hopper in the lowered position, open the hopper door.
2. Deploy the rear grille/step as described above.
3. Carefully remove one basket by releasing the retaining clip at the rear of the basket, unhook the basket and remove.
4. Place the basket on the step.
5. Descend from the step and remove basket from step for cleaning.
6. Repeat process for removing second basket.
7. Clean baskets and ensure mesh screens are in good working condition.
8. Refit baskets one at a time by following the above procedure in reverse.
9. Stow the rear grille/step in accordance with the procedure detailed above.

CHAPTER

4

Optional Equipment

Table of Contents

Subject	Page
High Pressure Washer	4 : 2
Third Brush Option	4 : 3
Winter Equipment	4 : 4


High Pressure Washer

Safety Precautions



- Care **MUST** be taken not to damage sign written areas when cleaning. See special notes for cleaning vehicles with vinyl livery below.
- **ALWAYS** keep pressure equipment in good condition and regularly maintained, particularly at joints and unions.
- The use of safety goggles is recommended in case of deflected spray/debris.
- **NEVER** direct a high pressure nozzle at the skin as the fluid may penetrate the underlying tissue etc. and cause serious injury.

Special notes for cleaning vehicles with vinyl livery or reflective markings


The supawash hand lance or similar can be used for cleaning areas of the vehicle with vinyl or reflective markings subject to the following precautions being taken




- The spray angle should be maintained between 90 and 75 degrees to the panel ✓



- The nozzle distance should be greater than 1 metre minimum from the panel ✓



- The spray pattern should be a wide fan pattern ✓



- The nozzle pressure should be 80 bar (1000PSI) max ✓
- The water temperature should not exceed 60 °C ✓
- Do not use acid or solvent cleaning solutions ✗

Alternative Methods

- Do Clean with a sponge or soft cloth using cold or warm water with a soap or detergent, followed by a cold water rinse ✓

The high pressure washer may be used to clean down the vehicle at the end of a shift or day's work. The unit is operated using the dash mounted rocker switch, ensuring the sweep controls are in the neutral position and the machine is in work mode.

The hand lance and reel are mounted between the rear of the cab and the hopper. Two jets are provided in the nozzle, a fan spray jet and a pencil jet. To change between the jets, the trigger should be released and the gun rotated through 180°, this will automatically select the alternative jet.

Frost Precautions

In cold weather, with the possibility of freezing temperatures, the water system should be drained to prevent freezing up when leaving the machine outside overnight. The recirculation tank can be drained by operating the dump valve by way of the cab controlled lever. This action will drain all water from the system including the pump and hose. The lost water spray system can be drained using each of the drain valves located at the front of each tank.

When empty, the clean water pump and hoses should be drained by operating the pump for a short period of time. If the optional high pressure washer pump is fitted, it is essential to drain the pump hose reel and gun, again by operating the pump for a short period of time until the system is purged of water.

Note : DO NOT run the high pressure pump dry for excessive periods.

Third Brush Option

Operation

For details on third brush switch functions refer to Chapter 2.

To operate third brush it is necessary for work mode to be engaged.

Third brush controls on the arm rest controller are activated by pressing the third brush function switch.

Position brush arm as required using arm rest controller joysticks.

To select clockwise rotation of brush; press LH third brush rotation switch. Anticlockwise rotation is selected by pressing RH third brush rotation switch.

Adjust brush head angle using arm rest controller joystick.

The rotation speed of third brush and main brushes is controlled by using brush speed increase / decrease switches.

Dust suppression is achieved by operating water spray switch.

The third brush should be fitted by trained engineers. Fitting instructions may be found in the maintenance manual.

Winter Equipment

Gritter / Spreader

Turn on engine and engage work mode.



Press switch to activate Gritter / Spreader mode of operation.

Gritter / Spreader has three modes of operation;



First position; off.



Second position; activates gritter/spreader when travelling in a forward direction only.



Third position; activates gritter/spreader continuously.

Note: Gritter / Spreader functions only with work mode engaged.
 Standard sweeper equipment is disabled when gritter is active.
 Gritter disabled when standard sweeper equipment is active.
 Park standard sweeper equipment to activate gritter.

Gritter Only



Icon will display on JVM screen when second/third PTO switch position has been selected. The icon has three display states;
 Off - not operational.
 Flashing - standby.
 Static - operational.

Snowplough / Broom Only

For details on snowplough / broom joystick functions refer to page 2:11.

Broom Only



Press to activate snow broom.



Use switches to control rotational speed of the snow broom.
 Last rotational speed setting is activated when switching between activate and deactivate mode.
 Speed setting is reset when switching off vehicle ignition.



Press to deactivate snow broom.

Disengage work mode to auto-park front-mounted Winter Equipment.

See maintenance manual for remove and refit instructions of Winter Equipment.

Front-mounted winter equipment will not auto park on initial machine start up for safety reasons. To initially lift front-mounted equipment engage work mode and use joystick functions; refer to page 2:11.

CHAPTER

5**Johnston Visual Module (JVM)****Table of Contents**

Subject	Page
Description	5 : 3
Location of Components	5 : 3
Switching On	5 : 4
Transit and Work Mode Icons	5 : 5
Menu Navigation	5 : 6
Vehicle Logging (Data Capture)	5 : 7
System Faults	5 : 8
Main Menu	5 : 11
Reverse Aid Camera	5 : 12
Display Settings	5 : 13

J-Plex - The Johnston Sweeper Control System


J-Plex II is an electronic road sweeper control system which uses multiplex technology to enable multiple control signals to be combined into one common signal which can then be transmitted and received down a pair of wires (serial communication). This eliminates a substantial number of wires and connections from the vehicle's electrical system, which in turn reduces the size of wiring harnesses and increases reliability. Wiring from Input/Output (I/O) devices such as switches or hydraulic valves is via a local I/O collecting module called a node. On the C201 range of sweepers, the J-Plex control system consists of a Johnston Visual Module (JVM) screen and 4 remote I/O nodes mounted around the sweeper. The JVM acts as the master control unit and communicates between each external node via a CANbus control network.

JVM provides:-

- The operator interface with the powerful diagnostic features provided by J-Plex.
- The ability to check the status of Inputs and Outputs.
- Information about the vehicle - speed, fuel tank contents, etc.
- Data capture - hours sweeping, distance travelled, etc.

J-Plex is in constant communication with Tx5, the transmission controller. Tx5 receives signals from the accelerator pedal and sensors within the vehicle and adjusts engine/hydrostatic transmission settings accordingly. J-Plex diagnostic capability extends to Tx5.

Location of J-Plex Components




- 1) Internal Control Node (IN) : On rear internal wall of cab, behind RH seat/soft trim.
- 2) Chassis Node (CN) : Mounted to exterior of recirculation water tank.
- 3) Tx5 Node (Tx5) : Mounted to exterior of recirculation water tank.
- 4) Johnston Visual Module (JVM) : Centrally mounted in the overhead console.
- 5) Arm Rest Node (AN) : Within the arm rest controller, attached to cab centre tunnel.


After switching on the vehicle ignition the JVM will display a Splash Screen for 2.5 seconds;




The JVM will then display a Service Notification Screen for five seconds;



After which the JVM will display the Transit Mode Screen;




When work mode is selected (by selecting steering column switch H2b) the Work Mode Sreen will be displayed;



All Copyright and rights are the property of Johnston Sweepers Ltd.

Key to Transit and Work Mode Screen Icons



Information Bar

- 1. Low Oil Pressure
- 2. Low Transmission Oil
- 3. Low Engine Coolant
- 4. Low Water Level
- 5. Low Hydraulic Oil Level

- 6. Air Filter Service Due
- 7. Water In Fuel
- 8. Hopper Up
- 9. Service 1 Overdue
- 10. Service A Overdue

- 11. Service B Overdue
- 12. Service C Overdue
- 13. Service 1 Due
- 14. Service A Due
- 15. Service B Due

- 16. Service C Due
- 17. 4WS Warning
- 18. 4WS Error
- 19. 4WS Active
- 20. Alternator not charging

- 21. Weight Limit Exceeded

Transit and Work Mode

- 22. LH Sweep Active
- 23. Water Pump Sweep Active
- 24. Water Pump Continuous
- 25. Night Silent Active
- 26. Cruise Control Active

- 27. Recirculation Water Tank Full/100%
- 28. Recirculation Water Low Level Warning
- 29. RH Sweep Active

General

- 30. High Engine Coolant Temperature
- 31. Normal Engine Coolant Temperature
- 32. Low Level Fuel
- 33. Normal Fuel Level
- 34. ECO Mode Active
- 35. Working Mode Active



- 36. PTO Function - Gritter/Spreader
- 37. Winter Equipment Fitted

All Copyright and rights are the property of Johnston Sweepers Ltd.

Menu Navigation


When the JVM is displaying either transit or work modes the following menus may be accessed by pressing the relevant soft keys;

Soft Key	Description
	Vehicle Logging
	1.1 Part Totals
	Pressing the reset soft key will reset the part totals back to zero.
	1.2 Grand Totals
	1.3 Daily Totals






1.4 Service Hours




1.4 USB Download
(Data Capture)

Insert an Johnston approved USB stick into the USB port (located on front of the JVM - bottom lefthand side).

Press centre button on JVM to download Part / Grand / Daily totals as required.



Key to Logging Screen Icons



- 1. Engine Hours
- 2. Engine Hours - Work
- 3. Total Distance
- 4a. Total Distance - Swept
- 4b. Total Distance - Washed
- 5. Average Work Mode - RPM
- 6. Average Work Mode - Speed
- 7. Average Fuel Consumption
- 8. Average Fuel Consumption - Work Mode
- 9. Engine Hours - Last Service
- 10. Engine Hours - Till Next Service

All Copyright and rights are the property of Johnston Sweepers Ltd.

Soft Key	Description
----------	-------------




System Faults

Should a system fault occur in any of the following vehicle systems a fault icon soft key will appear on the transit / work mode screen; CANbus Network (Menu 4.2)
 Hydraulic Valve Outputs (Menu 4.3)
 Transmission Controller (Menu 4.9.1)
 4WS Valve Block (Menu 4.10.2)

Pressing the fault icon soft key will display the relevant fault mode screen.

CANbus Network Faults

Rotate centre button on JVM to move halo; press button to select node on CANbus network that is showing a fault condition.



An example fault condition on the CANbus network is displayed opposite.

Should a fault occur within the CANbus network it will be accompanied by one or more emergency codes.


Node ID : 0x10
 O/S Version : 2.10.00.00

Emergency Code(s) : #1 2354 #5 2354 #9 2354
 #2 6002 #6 6002 #10 6002
 #3 6300 #7 6300 #11 6300
 #4 1258 #8 1258 #12 1258


All Copyright and rights are the property of Johnston Sweepers Ltd.

Hydraulic Valve Output Faults

Rotate centre button on JVM to move halo; press button to select valve block that is showing a fault condition.




An example of a fault condition on a valve block is displayed opposite.




Transmission Controller (Tx5) Faults

An example transmission controller fault screen is displayed opposite.

Faults are indicated by a red cross or valve icon. Press the red soft key icon (if displayed) to access additional fault condition information.





An example of additional faults are displayed opposite. Each fault will include an emergency code.



4WS Valve Block

An example 4WS Valve Block fault screen is displayed opposite.


Key to system fault icons

Transmission Controller (Tx5)

- | | |
|--------------------|---------------------------------|
| 1. 5V External | 15. Internal |
| 2. Brake Lights | 16. J1939 |
| 3. Bypass Valve | 17. High Battery Supply Voltage |
| 4. Cranking Output | 18. Low Battery Supply Voltage |
| 5. Drive Pedal | |

- 6. Foot Brake Switch
- 7. Forward Valve
- 8. Gear Switch
- 9. Reverse Light
- 10. Reverse Valve

- 11. Safety Valve
- 12. Speed Sensor
- 13. Tier 3 Actuator
- 14. General

Hydraulic Valves

- 19. Short to Ground
- 20. Short Circuit
- 21. Open Circuit

Miscellaneous


- 22. No comms

Soft Key **Description**



Main Menu

Rotate central button on JVM to move halo; press button to select menu as required.




Main menus are as follows;

- | | |
|--|---|
| <ul style="list-style-type: none"> 1. System Information 2. CANbus Information 3. Valve Outputs 4. Palm Node
 5. Switch Inputs 6. Special Inputs 7. Special Outputs 8. Engine Information | <ul style="list-style-type: none"> 9. Transmission Controller (Tx5) 10. 4WS Control (option) 11. Service Menu 12. Set Pressures
 13. Display Settings 14. System Security 15. Vehicle Setup |
|--|---|

Menu 4.1 details both the Serial Number and Chassis Number of the vehicle.

Both numbers should be quoted when contacting Johnston Sweepers for servicing and maintenance issues.



Menu 4.15 shows the configuration of the vehicle for all standard and optional equipment.

Note:

For full details of the main menu please refer to the C201 maintenance manual.



All Copyright and rights are the property of Johnston Sweepers Ltd.

Soft Key	Description	
	Reverse Aid Camera	
	Pressing the Camera Maximise soft key will display the reverse aid camera in full screen display mode.	
	Pressing the Camera Minimise soft key will return the reverse aid camera to normal display mode.	


All Copyright and rights are the property of Johnston Sweepers Ltd.

Display Settings

Menu 4.13 contains three menus which assist the operator in altering the following JVM settings;


- 4.13.1 Date and Time
- 4.13.2 Brightness and Contrast
- 4.13.3 Camera Brightness, Contrast and Colour Saturation

Rotate the centre button to move the halo and press to select the display setting menu as required.



Menu 4.13.1 Date and Time


Rotate centre button to move halo. Press to select item, halo colour will change to red. Rotate button to change setting. Press button to enable further changes to date and time settings.



Menu 4.13.2 Brightness and Contrast

JVM display brightness and contrast may be altered for day and nighttime use. The brightness of the soft keys may be altered to suit the operator's requirements.


Rotate centre button to move halo. Press to select item, halo colour will change to red. Rotate button to change setting. Press button to enable further changes to brightness and contrast as required.



Menu 4.13.2 Brightness, Contrast and Colour Saturation

Brightness, contrast and colour saturation of the reverse aid camera may be altered to suit the operator's requirements.

Rotate centre button to move halo. Press to select item, halo colour will change to red. Rotate button to change setting. Press button to enable further changes as required.



CANbus Diagnostics

Node Status

Each Node connected in the "Sweeper" (CANopen) Network transmits a "Heartbeat" message to indicate its status.



The following Icons are used to display each state:



Operational
Node is OK.



Stopped
Internal node error.
CANbus network error.



Pre-operational
Initial start-up in progress.
OS update in progress.
CANbus network error.



No Communication
Node disconnected.
No power (fuse blown).
CANbus network fault.
Node error (software or hardware).

CHAPTER

6

Routine Maintenance

Table of Contents

Subject	Page
Safety Precautions	6 : 2
Maintenance Schedules	6 : 3
Service Point Locations	6 : 7
Fuse Applications	6 : 11
Lubrication Chart and Approved Lubricants	6 : 16

Safety Precautions**Safety Notice****DO NOT**

- Work on or around the engine whilst it is running except to adjust idle settings.
- Remove coolant bottle cap when the engine is hot. Release the cap slowly, otherwise there is a risk of being scalded by escaping coolant.
- Touch any part of the engine exhaust system without first allowing it to cool sufficiently.
- Drain engine oil until it has cooled, to avoid scalding.
- Work under a vehicle supported by a jack before lowering the vehicle onto sturdy axle stands or similar.
- Disconnect hydraulic or water pipes whilst the engine is running.
- Approach fan inlet whilst the fan is running.
- Disconnect the battery within 15 seconds of operating the ignition key to the off position.
- Put fingers under the recirculation pump due to rotating blade.

ALWAYS

- Ensure the machine is standing on firm, level ground and there are no obstructions above or to the rear before raising the hopper.
- Ensure that the hopper is resting on the hopper prop, or extended maintenance prop, before working underneath the raised hopper - See Maintenance Section of the Technical Manual.
- Keep hands, loose clothing, hair etc. well clear of moving parts.
- Use approved safety platforms/gantries when working above ground level. Get a second person to check periodically when only one person is working on access equipment or inside the body.
- Disconnect the vehicle battery and all the CANbus nodes when working on the electrical system or when carrying out any welding on the vehicle. Failure to observe this can cause damage to the nodes.
- Remove ignition key when working on the vehicle. Ensure all personnel are clear of the vehicle before restarting engine.
- Ensure all guards and covers are refitted after servicing.

Regular Maintenance

It is impossible to over emphasise the importance of regular maintenance, inspections and running adjustments to maintain efficiency and obtain trouble free service from the machine. Always refer to maintenance guide.

Attention is also drawn to the initial first service and post delivery check over between the first 20-50 hours operation of the machine.

'Next service' will be indicated to the operator via the JVM. For A, B, C and D services a pre-warning will be given at startup.



20-50 Hour Initial Service

- 1a. Drain engine oil and renew oil filter, refill engine with oil to the correct level.
Overfilling the engine oil WILL cause damage to both the engine and CSF (Catalytic Soot Filter).
- 1b. Reset the Oil Dilution Flag in the engine ECU;
 - Turn ignition key to 'ON' position to start the pre-heating phase of the glow plugs.
 - Fully depress the GO Pedal five times within a 10 second period.
 Carrying out the procedure outlined in 1b ensures that the condition of the CSF (which is a non-serviceable item) is maintained.
2. Renew high pressure hydraulic return line filter.
3. Check engine fan belt(s) for wear (standard and/or air con).
4. Check security of all external nuts, screws, mountings etc.
5. 4WS only torque gimbal bearing pre-load to 140Nm (103lb.ft) using tool 7012202. Check condition of the skid plates for wear, replace if needed.
6. Check battery terminal condition and clean if necessary.
7. Check engine coolant level, top up as required (50 hour & A service intervals only).
8. Renew transmission oil filter - 19/24 Bar pump (50 hour & A service intervals only).

Maintenance Schedules

Refer to engine user handbook for more detailed instructions on engine servicing.

Daily Maintenance - This can be carried out by a trained operative.

Check the following items and replenish as required;

1. Engine oil level.
2. Engine coolant level.

3. Hydraulic oil level in main reservoir.
4. Hydraulic oil level in transmission oil header tank.

Check the following items;

5. Air cleaner, only if service indicator is illuminated on JVM.
6. Radiator, charge air cooler and oil cooler are free from obstruction/build up.
7. Fan belt is in good condition.
8. Windscreen washer bottle has adequate fluid.
9. For any fluid leaks.
10. Driver's seat and steering column are adjustable.
11. Tyre pressures and condition (Front = 6.2 bar / 90 psi, Rear = 5.75 bar / 83.5 psi).
12. Security of wheel nuts, 250Nm (180 lb.ft).
13. Mechanical damage to sweeping equipment.
14. Suction fan is clean and free of debris.
15. Brush and wear angles. Replace and adjust as required.
16. Water tanks have adequate water.
17. Front water jet sprays and filters, clean/unblock as required.
18. Correct operation of lighting equipment, wiper washers and horn.
19. Suction nozzle ground clearance is 5mm, adjust if necessary.
20. Suction filter screen and de-watering screens are clean and not blocked.
21. Hopper mesh, side screens, ducts and sludge drainage channels are clean and not blocked.
22. Check handbrake and footbrake for correct operation.
23. Water recirculation system and ensure tank top filter is clean. Clean out tank using the dump valve, ensuring that the pump is also cleaned.

Weekly Maintenance - Daily Maintenance plus the following;

Check the following items -

1. Check & grease all steering equipment. x8 points front axle, x14 on 4 wheel steer option including rear steer ram & pivots.
2. Front suspension strap pivots for freedom of movement and wear.
3. Hopper fan wear and build up of debris on blades.

4. Suction nozzle, flap tie, trunking and hopper inlet duct for wear and replace if necessary.
5. If engine fault lamps C3 or C4 are illuminated the engine requires workshop repair.
6. Routing of electrics, hydraulic services for chafing/leaks.
7. All rubber seals, replace if necessary.
8. Keep engine compartment clean.
9. Check brake master cylinder fluid level, replenish as required.
10. Ensure the air intake ducts on the front of the hopper are clear of debris.
11. Wheel nut torque settings, 250Nm (180 lb.ft).
12. Drain water from the fuel filter if indicated on the JVM.
13. Lubricate the JSL equipment; including suction nozzle castor wheels (if fitted).
14. Carry out full vehicle function road test.

**Service A - Every 300 hours
(plus 50 hour service items)**

1. Drain out diesel fuel filter canister and renew fuel filter.
2. Lubricate door locks with special grease.
3. Replace main air filter.
4. Check the air intake circuit is clean and the intercooler pipe is sealed correctly.
5. Check the dust discharge circuit is clean.
6. Check the tightness of vacuum pump and related system.
7. Check the vacuum circuit pipes are sealed correctly.
8. 4WS only check gimbal bearing pre-load torque setting 140Nm (103lb.ft) using tool 7012202. Check condition of the skid plates for wear, replace if needed.
9. Replace EGR and TVA valve filter.

**Service B - Every 600 hours
(plus 50 hour & A service items)**

1. Check engine coolant level and concentration gives -39°C frost protection (B Service Only).
2. Check steering system for correct operation; 2WS and/or 4WS.
3. Remove brake drums and inspect front and rear brakes, clean out drums as required. Inspect linings and replace if damaged or worn below 2mm. Refit drums and check brake adjustment.

**Service C - 12 monthly maintenance or every 1500 hours
(plus 50 hour, A & B service items)**

1. Renew transmission filter - 19/24 Bar pump.
2. Renew water tank filter.
3. Replace safety air filter.
4. Check brake fluid level and top up if required.
5. Renew hydraulic suction filter (x2 fitted to Winter/3rd Brush option).
6. Renew hydraulic oil (sweep circuit).
7. Renew engine coolant with a mixture of 50/50 antifreeze/water.
8. Check CSF using diagnostic equipment, perform forced regeneration or renew filter as required.
9. Check front wheel bearings and re-pack with grease.
10. Check all torque settings, see maintenance manual.
11. Carry out a decelerator test.
11. Carry out a 'road test' to check all relevant functions. Check and record pressures, see maintenance manual for procedures.

**Service D - 24 monthly maintenance or every 3000 hours
(plus 50 hour, A, B and C service items)**

1. Replace brake fluid.
2. Renew clear hose to transmission header bottle, replace cable ties.
3. Renew engine fan belt(s) (standard and/or air con).




Used oils and filters should be disposed of in accordance with local waste disposal regulations.





These procedures should be carried out by qualified service personnel.

Tool Kit

In order to assist completion of the maintenance schedules, a tool kit is provided. This, along with a hand pump handle are normally located underneath the passenger seat. Access to this equipment is gained by opening the flap at the front of the seat base.



Service Point Locations



Key

A	Transmission Reservoir	H	Hydraulic Oil Tank
B	Air Cleaner Intake Duct	I	Radiator
C	Engine Coolant Expansion Tank	J	Engine Oil Dipstick
D	Fuel Tank Filler	K	Fuel Filter
E	Fuel Tank	L	Air Cleaner
F	Hydraulic Oil Tank Filler		
G	Engine Oil Filler		

Hydraulic Reservoir

Oil level checking - the correct method for checking the oil in the hydraulic reservoir is with the hopper lowered. The oil level should fill the centre window of the tank level gauge and just be visible in the top window.

Air Cleaner


If between scheduled maintenance attendances the JVM display shows the filter requires servicing then the following should be applied:

Open rear door of machine to access air cleaner.

Release for retaining clips and remove cover.

Withdraw the main element from the air cleaner body 'G'.


It will be noted that the smaller secondary element (safety element) housed within the body is not usually removed during periodical servicing, it ensures that dust cannot enter the engine in the event of main filter damage.



The safety element should be changed every third time the main element is serviced. Inspect the clean element for damage by placing a bright light inside and looking through the element. Any thin spots, pin holes or other damage will render the element unfit for further use.

Clean the inside of the filter body, 'G' ensuring all dust and debris is removed, do not use petrol. Inspect all joints and hoses for leaks, renew where necessary. Reassemble the cleaner ensuring all joints are leakproof.

Oil Filter Locations



- A = Sweep System Oil Filter
- B = Transmission Filter
- C = Engine Oil Filter (RHS)
- D = Fuel Filter (LHS)


All Copyright and rights are the property of Johnston Sweepers Ltd.

Fan Impeller Wear

An Inspection hatch is provided in the fan case mounted on top of the body.



Remove the ignition key to immobilise the engine before starting work.



Remove plate (A) after releasing the two retaining bolts.

Access can be gained to the side of the fan and the space between the blades can be cleaned with a scraper. Any debris at the eye of the fan should be removed to prevent vibration. This is achieved by removing the blanking plate over the eye of the fan inside of the hopper roof.


The fan impeller should be replaced when any blade thickness (B) is less than 1.5mm.

Jacking up the Vehicle


When jacking up the front of the vehicle, it is recommended that a 3000 Kg. trolley jack be applied to the centre of the front axle. For the rear wheels the jack should be applied to the points shown below, in line with the rear wheels.

DO NOT apply the jack to the crossmember directly underneath the engine sump, it is not designed for this purpose.

Front and Rear Jacking Point Location (Trolley Jack)




A = Jacking Point - Trolley Jack




C = Jacking Points - Trolley Jack

Front and Rear Jacking Points (Bottle Jack)



B = Jacking Point - Bottle Jack
E = Check Strap Pivot Grease Point
(coil suspension only)




D = Jacking Point - Bottle Jack

All Copyright and rights are the property of Johnston Sweepers Ltd.

Fuse Applications

General Layout - Fuses




- A - Rear Cab - Fuses
- B - Rear Cab - Relays
- C - Steering Column Fuses
- D - Overhead Console Fuses
- E - Battery Box Fuses (Euro 5 / Tier 3)




Before replacing fuses, ensure that all switches and the vehicle ignition are turned OFF to prevent any damage to the vehicle electronics.

Rear Cab Fuses - A

Fuse No.	Description	Type	Rating (Amps)
A01	Systems/Ignition	Blade	10
A02	Ignition Switch, Radio, OBD	Blade	5
A03	Safety Feed Internal Node	Blade	20
A04	Standard Feed Internal Node	Blade	20
A05	Armrest Node	Blade	5
A06	Indicator (Ignition Feed)	Blade	10
A07	Indicator (Battery Feed)	Blade	10
A08	Headlight Master Fuse	Blade	15
A09	Wiper, Screen Wash, Horn	Blade	15
A10	Worklamps (Low Level)	Blade	15
A11	Water Pump (Brushes)	Blade	10
A12	Heater Fan	Blade	15
A13	Beacon	Blade	7.5
A14	Drivers Seat	Blade	15
A15	Worklamps (High Level)	Blade	10
A16	Autolube	Blade	1
A17	Auxiliary Power	Blade	7.5
A18	<i>Reserved</i>	<i>Spare</i>	
A19	Condenser Fan (Air Conditioning)	1 1/4" x 1/4"	20


Rear Cab Relays - B

Relay No.	Description
K001	Ignition Relay
K002	Indicator Timer Module
K003	Headlight Relay
K004	Heater Fan Low-Speed (Air Conditioning)
K005	Condensor Fan (Air Conditioning)
K006	Worklamp (auto-cancel)
K007	Water Pump (Brushes)




Note: Access fuses/relays by sliding LH seat forwards and removing soft trim panel.

All Copyright and rights are the property of Johnston Sweepers Ltd.

Steering Column Fuses - C


Access fuses by removing plastic cover on top of steering column trim.



Fuse No.	Description	Type	Rating (Amps)
C1	LH indicator	Blade	7.5
C2	RH indicator	Blade	7.5
C3	LH Headlamp	Blade	10
C4	RH Headlamp	Blade	15
C5	<i>Spare</i>		
C6	<i>Spare</i>		


Overhead Console Fuses - D

Access fuses by pulling down passenger sun visor.



Fuse No.	Description	Type	Rating (Amps)
B1	Side lights and instrument illumination	Blade	5
B2	Heated windscreen and mirrors	Blade	25
B3	Johnston Visual Module (JVM) display	Blade	10
B4	<i>Spare</i>		
B5	<i>Spare</i>		
B6	<i>Spare</i>		


**Euro 5 Engine
Battery Box - E**



Access fuse by removing battery box cover.

Fuse No.	Description	Type	Rating (Amps)
FE01	Main Fuse	Mega power fuse	100
FE02	Glow Plugs	Mega power fuse	60
FE03	Engine - Fuse 1	Blade	10
FE04	Engine - Fuse 2	Blade	15
FE05	Engine Systems	Blade	7.5
FE06	Cranking Relay	Blade	30
FE07	Fuel Heater	Blade	20
FE08	Chassis Node - Fuse 1	Blade	20
FE09	Chassis Node - Fuse 2	Blade	20
FE10	Transmission Node - Fuse 1	Blade	20
FE11	Transmission Node - Fuse 2	Blade	20
K010	Engine Main Relay		
K011	Glow Plug Relay		
K012	Cranking Relay		
K013	Fuel Heater Relay		

Stage 3a Engines
Battery Box - E




Access fuse by removing battery box cover.

Fuse No.	Description	Type	Rating (Amps)
FE01	Main fuse	Mega power fuse	100
FE02	Glow plugs	Mega power fuse	60
FE08	Chassis Node - Fuse 1	Blade	20
FE09	Chassis Node - Fuse 2	Blade	20
FE10	Transmission Node - Fuse 1	Blade	20
FE11	Transmission Node - Fuse 2	Blade	20
FE13	Cranking	Blade	30
FE14	Cold Start	Blade	3
K015	Cranking Relay		
K016	Cold Start Relay		
K017	Glow Plug Relay		


All Copyright and rights are the property of Johnston Sweepers Ltd.

Lubrication Chart

7* = Handbrake cable bell crank
 10* = Brake fluid reservoir



All Copyright and rights are the property of Johnston Sweepers Ltd.



C200 Approved Lubricants									
Oil Type Grade	Capacity	Johnston		Shell	BP	Castrol	Mobil	Q8	Chevron
		Part No.							
1. Engine 10W40, API C1-4, ACEA E6	9.2 L (Euro 5) 6.4 L (Tier 3)	94-79		Rimula Signia 10W/40	-	Enduron Low SAPS 10W/40	Delvac XHP LE 10W-40	Q8 T905	-
2. Hydraulic System	55L	94-12		Tellus T46 Multigrade	Bartan HV46	Hyspin AWH46	DTE 15M	Handel 46	Rando HDZ46
3. Transmission System	12L	94-12		Tellus T46 Multigrade	Bartan HV46	Hyspin AWH-M46	DTE 15M	Handel 46	Rando HDZ46
4. Transmission Wheel Motors	0.6L	39663		Spirex EP90	Gear Oil EP90	Hypoy EP9075W-90	Mobilube HO90	T 45 90	Multigear 80/W90
5. Front Wheel Bearings	-	-		Retinax LX2	Energrease L2	Piroplex Red	Mobilube XHP222	Rembrandt 3	Hytex EP2
6. Grease Nipple		-		Retinax A	Energrease L2	LM Grease	Mobilube Grease MP	Rembrandt EP 2	Multifak EP2
7. Spray Lubricant		94-61		SPECIAL PTFE LUBRICANT GREASE					
8. Antifreeze	6.5L	94-21		TOTAL COOLANT CAPACITY 13L : 50% CONCENTRATION REQUIRED					
9. Battery Terminals	-	-		PETROLEUM JELLY					
10. Brake System	1L	6906		BRAKE FLUID DOT 4 SPEC					
11. HP Water System	0.3L	39666		AVILUBE 583 SYNTHETIC OR KLUBER SYNTHESCO MT 68 IMPORTANT – ONLY THESE OILS SHOULD BE USED					
The above oils are those approved by Johnston Sweepers. Other manufacturer's oils must be of equivalent grade.									

CHAPTER

7

Conformity Certificates

Table of Contents

Subject	Page
EC Declaration of Conformity Certificate	7 : 2
EC Declaration of Conformity Certificate (Noise Emission)	7 : 3
EUnited PM10 Emission Test Certificate	7 : 4
Identification & Permitted Weights	7 : 5

DECLARATION OF CONFORMITY (CE)

Manufacturer's Name: Johnston Sweepers Limited

Manufacturer's Address: Curtis Road, Dorking, Surrey,
England, RH4 1XF.

declares that:

Product Name: Johnston Road Surface Cleaner

Product Type(s): C101
C25, C40, C50
CX200, CN200, CW200
CX201, CN201, CW201
5000, CX400, CN400

Product Options: All


Product Serial Number:

conforms to the following standards:

E.C. Council Directive 2006/42/EC and amendments.

BS EN 13019 : 2008. Machines for Road Surface Cleaning
Safety Requirements.

Clive Offley
Compact Sweeper Division
06/07/11



All Copyright and rights are the property of Johnston Sweepers Ltd.

**EC DECLARATION OF CONFORMITY
(NOISE EMISSION IN THE ENVIRONMENT BY EQUIPMENT
FOR USE OUTDOORS: DIRECTIVE 2000/14/EC)**

Manufacturer's Name: Johnston Sweepers Limited

Manufacturer's Address: Curtis Road, Dorking,
Surrey, RH4 1XF, England.

Technical Documentation maintained by: Research and Development Department,
Johnston Sweepers Limited,
Curtis Road, Dorking,
Surrey, RH4 1XF, England.

**Johnston Sweepers Ltd. hereby declares that the following
equipment conforms to the requirements of EC Directive 2000/14/EC:**

Description of Equipment: EC Directive 2000/14/EC, Annex 1, Item 46:
Power sweeper

Product Name and Description: Johnston Compact C101, CL201, CW201,
CN201 & CX201 hydrostatic sweepers with
Euro 5 engines.

Maximum Measured Sound Power Level (L_{WA}): 102dB(A)

Guaranteed Maximum Sound Power Level (L_{WA}): **103dB(A)**

Conformity Assessment Procedure: Internal control of production
(Ref: Annex V - 2000/14/EC)


Other EC Directives applied to this equipment: 98/37/EC and amendments

Place and Date of this Declaration: Johnston Sweepers Limited,
Curtis Road, Dorking, Surrey, RH4 1XF,
England.

September 2010

Signed by:

C.F. Offley
Engineering Director
Johnston Sweepers Ltd



Issue : 06

All Copyright and rights are the property of Johnston Sweepers Ltd.



We hereby declare this Road Sweeper* has been tested and certified according to the EUUnited PM10 Emission Test for Road Sweepers and fulfills the requirements of the test year stated.

Manufacturer's Name: Johnston Sweepers Limited

Manufacturer's Address: Curtis Road, Dorking, Surrey, England, RH4 1XF

declares that:

Product Name: Johnston Road Surface Cleaner

Product Type(s): V500, V550, V650, V800
C101, C200, C400

C. Offley
Engineering Director
Johnston Sweepers Ltd.
01/09/10



*according to;
European Standard EN15429-1:2007 Sweepers - Part 1: Classification and Terminology

All Copyright and rights are the property of Johnston Sweepers Ltd.

Identification & Permitted Weights

		
a.	Type Approval No	<input type="text"/>
b.	Vehicle Ident. No VIN	<input type="text"/>
c.	Gross Vehicle Mass	<input type="text"/>
d.	Gross Train Mass	<input type="text"/>
e.	Front Axle Mass	<input type="text"/>
f.	Rear Axle Mass	<input type="text"/>
g.	 Serial No <input type="text"/> 	
	Johnston Sweepers Ltd, Castle Road, Sittingbourne, ME10 3JP, UK	

The vehicle identification plate is located in the cab and contains the following data;

- a. Type Approval Number
- b. Vehicle Identification Number
- c. Gross Vehicle Mass
- d. Gross Train Mass
- e. Front Axle Mass
- f. Rear Axle Mass
- g. Serial Number

Note:

Please state the Serial Number / Vehicle Registration Number and/or Vehicle Identification Number whenever you contact a Johnston Sweepers dealer or customer service centre.

All Copyright and rights are the property of Johnston Sweepers Ltd.

CHAPTER

6

Routine Maintenance

Table of Contents

Subject

Page

All Copyright and rights are the property of Johnston Sweepers Ltd.