


Please read this manual carefully before using this machine and keep it properly for future reference.

I. Applications

It can be applicable for welding PVC-P, PE, TPO, ECB, CSPE, EPDM, PVDF and other Coated fabric covering, foil and homogeneous or coating sealing film and PE coating fabric.


II. Notice

1. Unplug the tools before opening it to avoid of being hurt by exposed wires or component inside the machine with power
2. Incorrect use of it can cause fire and explosion hazard because of high temperature, especially near combustible materials and explosive gases.
3. Don't touch heater tube and nozzle when they are hot. They may cause burns. Don't point hot air flow in the direction of people or animals.
4. The voltage rating stated on the welder must correspond to line/mains voltage (230V). The drop cable / wire with protective earthed conductors can only be used.
5. To ensure operator safety and reliable operation of equipment, the power supply must be installed power supply and leakage protection at the construction site.
6. It must be running at the correct use of manipulation of the operator, or they may cause a fire or explosion caused by high temperature.
7. Don't use welder in the water, or on a muddy construction site, to avoid flooding, rain or moisture.



In order to prevent the machine from being damaged during transportation, the machine is fixed in the steel packing box with screws. When using the machine for the first time, it is necessary to loosen three machine fixing screws and take them out to remove the


machine from the packing box, as shown in the figure above



Technical Parameters

Voltage	230	V
Frequency	50/60	Hz
power	3600	W
Temperature	0~620℃ (32~1148 F)	
Welding speed	1~12	m/min
Welding width	40	mm
Size(L*W*H)	520*275*815	mm
Weight	20	kg


- 1. Drive silica roller
- 2. Drive roller
- 3. Round belt
- 4. Nozzle
- 5. Pulley
- 11 Hot gun fixed slider
- 12 Hot gun positioning handle
- 13 Guide wheel
- 14 Guide wheel support block
- 15 Hot Gun Fixed Seat
- 21. Counterweight block 1
- 22. Counterweight block
- 23. Universal wheel
- 24. Handrail
- 25. Clamp



Description

6. Hot Gun Fixed Plate	16 Locator Fixed Column	26. Movable handle
7. Pulley connecting rod	17 Laser Line Locator	27. General power line
8. Belt wheel fixing block	18 Hot gun power cord	28. Cable connector
9. Floor Plate	19 Gun	29. Handle
10. Guide	20 Handle screw	30. Lifting handle
31. Side wheel		

iv. Controller Panel



- ON/OFF switch (38) is used for open the main power of the welder.
- Open ON/OFF switch (38), LCD display is shown as figure 1, the hot air blower is under natural wind without heating.
- Press the button (37) and (36), the screen shows as Figure 2 and the hot air blower starts to heat until to the setting temperature.
- If press the bottoms (37) and (36) at the same time, LCD display shows as figure 1, the hot air blower is under natural wind without heating.
- When the welding nozzle is at the right position, press the moving switch (39) and the welder starts to move and weld. It will stop move if you press the moving switch again.
- When the welder starts to move, the LCD display shows as figure 3.
- The knob (40) is used to adjust the air flow of the air gun, increase the air flow by rotating clockwise, and reduce the air flow by rotating counter-clockwise.



Figure 1

Current temp.
Setting temp.



Current speed
Setting speed

Figure 2

Current temp.
Setting temp.



Current speed
Setting speed

Figure 3

VI. Welding parameters setting


1. Welding temperature

Using bottoms Temperature setting knob+  and Temperature setting knob-  to set the required temperature. You can set the temperature according to the welding materials and the ambient temperature. LCD display will show the set temperature and the current actual temperature.

2. Welding speed:

Using bottoms Speed setting knob+  and Speed setting knob-  on the panel to set the required speed according to the welding temperature. LCD display will show the set speed and the current actual speed.

3. Air volume:

Using the button on the panel  to set the air volume, increase the air volume clockwise and reduce the air volume counterclockwise. When the ambient temperature is too low and the current temperature can not reach the set temperature, the air volume can be reduced appropriately.

- The machine has a memory function parameters, namely when you use the welder next time, the welder will automatically use the last set of parameters without having to re-set parameters.

VII. Positioning the welder

Pressure Lift lever (30) to lift machine, move it to welding position (the edge of upper membrane should keep in the same alignment with Drive silica roller (1) and the edge of Guide wheel (13), as shown in figure 4.




Figure 4

VI. Using Condition

1. The distance between hot air nozzle and ground should be shown as figure 5 (We have adjusted the distance) .
2. The distance between hot air nozzle and Drive roller should be shown as figure 6 (We have adjusted the distance) . You can adjust Hot air nozzle adjusting screw figure 7 if the distance is not right.




Figure 5




Figure 6




Figure 4

VI. Welding steps

1. Setting welding parameters (see above).

2. When the temperature reaches the set value.

3. Welding machine positioning.

4. Pull up the positioning handle (12) of the air gun, lift the air gun (19), lower the air nozzle (4) and make it close to the submerged membrane. Move the air gun to the left to insert the air nozzle into the overlap membrane and make the air nozzle in place. At this time, the welding machine will walk automatically for welding.

5. Always pay attention to the position of the guide wheel (13) and adjust it by touching the handle (24) lightly if it deviates from the position.

6. Pull up the positioning handle (12) of the air gun after welding, move the air nozzle to the right until it stops, and rotate upward until it is locked.

7. After welding, press the button on the control panel at the same time and make the air gun in the state of blowing cold air to cool the air nozzle.



and



8. Turn off the power supply



with the power switch.

VI. Routine maintenance

Use steel brush to clean the hot air nozzle.

Clean the air inlet at the back of the hot air blower