

# REMOS



## REMOS GX

Maintenance Handbook

Revision 03

---



## Imprint

Maintenance Manual REMOS GX - Revision R03

prepared according to ASTM F2483-05

REMOS AG  
Franzfelde 31  
D – 17309 Pasewalk

[www.remos.com](http://www.remos.com)  
[service@remos.com](mailto:service@remos.com)

G E R M A N Y

Copyright REMOS AG

© REMOS 2007-2014, all rights reserved

## List of Effective Pages

Total number of pages in this publication is 295 consisting of the following:

| Section | Title                                   | Page            | Revision |
|---------|---|-----------------|----------|
|         | Title                                   | Title           | 03       |
|         | List of Effective Pages                 | A               | 03       |
| 1       | General Description                     | 1-1 thru 1-8    | 03       |
| 2       | Ground Handling                         | 2-1 thru 2-16   | 03       |
| 3       | Fuselage                                | 3-1 thru 3-12   | 03       |
| 4       | Wings-and-Empennage                     | 4-1 thru 4-12   | 03       |
| 5       | Landing Gear                            | 5-1 thru 5-38   | 03       |
| 6       | Aileron Control                         | 6-1 thru 6-12   | 03       |
| 7       | Wing Flap Control                       | 7-1 thru 7-14   | 03       |
| 8       | Elevator Control                        | 8-1 thru 8-8    | 03       |
| 9       | Trim Control                            | 9-1 thru 9-6    | 03       |
| 10      | Rudder Control                          | 10-1 thru 10-8  | 03       |
| 11      | Engine                                  | 11-1 thru 11-28 | 03       |
| 12      | Fuel-System                             | 12-1 thru 12-20 | 03       |
| 13      | Propeller                               | 13-1 thru 13-14 | 03       |
| 14      | Utility Systems                         | 14-1 thru 14-10 | 03       |
| 15      | Instrument System                       | 15-1 thru 15-40 | 03       |
| 16      | Electrical Systems                      | 16-1 thru 16-20 | 03       |
| 17      | Structural-Repair                       | 17-1 thru 17-14 | 03       |
| 18      | Continuing Airworthiness and Inspection | 18-1 thru 18-12 | 03       |
|         | Imprint                                 |                 |          |

Do not exchange pages. Replace the entire manual in case of update.

## Section 1

### *General Description*

| <b>Table of Contents</b>                    | <b>Section</b> |
|---|----------------|
| 1.1 Aircraft Description .....              | 2              |
| 1.2 Aircraft Specifications .....           | 2              |
| 1.3 Equipment List .....                    | 3              |
| 1.4 Sources to Purchase Parts .....         | 3              |
| 1.5 Disposable Replacement Parts .....      | 3              |
| 1.6 Engine Specifications .....             | 4              |
| 1.7 Weight and Balance Information .....    | 5              |
| 1.7.1 Center of gravity determination ..... | 5              |
| 1.7.2 CG-Calculation .....                  | 5              |
| 1.8 Tire Inflation Pressure .....           | 7              |
| 1.9 Approved Oils and Capacities .....      | 7              |
| 1.10 Torque Values .....                    | 7              |
| 1.11 General Safety Information .....       | 8              |

---



## 1.1 Aircraft Description

REMOS GX Series aircraft, described in this manual, are high wing monoplanes of all composite carbon fiber monocoque construction. These aircraft are equipped with a fixed tricycle landing gear. The aircraft is equipped either with composite (glass fiber) main landing gear struts, featuring fixed wheel fairings or with steel gear struts and removable wheel spats and a steerable nose gear. Two place seating is standard. Each aircraft is equipped with a 4-stroke, four cylinder, horizontally opposed, water cooled Rotax 912 UL/S aluminum alloy engine, driving a fixed pitch or ground adjustable propeller.

## 1.2 Aircraft Specifications

Primary specifications of the aircraft, with dimensions based on gross weight, are given in figure 1-1. If these dimensions are used for constructing a hangar or computing clearances, remember that such factors as tire pressure or load distributions may result in some dimensions that are somewhat different from those listed.

Figure 1-1

|   |  |
|---|--|
| Gross Weight.....                                   | 1320 lb  |
| Fuel Capacity.....                                  | 22 gal.  |
| Oil Capacity.....                                   | Min 2.1 qts.<br>Max. 3.1 qts.  |
| Engine Model (Refer to ROTAX Operators Manual)..... | Rotax 912 UL-S2  |
| Propeller (Fixed Pitch).....                        | 66" F.Ili Tonini<br>21.5 deg @ 19.7 in<br>66" Woodcomp<br>21.5 deg @ 19.7 in |
| Propeller (Ground Adjustable).....                  | 70" Sensenich<br>23.0 deg @ 26.0 in<br>65.0" Neuform<br>23.0 deg @ 24.4 in   |
| Main Wheel Tires.....                               | 6.00 x 4, min 6PR<br>15 x 6.00-6, min. 6PR                                   |
| Pressure.....                                       | 29 - 34 psi  |
| Nose Wheel Tire.....                                | 4.00 x 4, min 4PR  |
| Pressure.....                                       | 29 - 34 psi  |
| Aileron Deflection                                  |  |
| Up.....   | 21°, +/- 1°  |
| Down.....   | 12°, +/- 1°  |
| Wing Flap Deflection .....                          | 0° to 40°, +0° / -1°   |

|                                 |             |
|---------------------------------|-------------|
| Rudder Deflection               |             |
| Right.....                      | 28°, +/- 2° |
| Left.....                       | 28°, +/- 2° |
| Elevator Deflection             |             |
| Up.....                         | 29°, +/- 1° |
| Down.....                       | 19°, +/- 1° |
| Elevator Trim Tab Deflection    |             |
| Up.....                         | 15°, +/- 5° |
| Down.....                       | 25°, +/- 5° |
| Principal Dimensions            |             |
| Wing Span.....                  | 30.7'       |
| Length.....                     | 21.7'       |
| Vertical Stabilizer Height..... | 7.5'        |
| Track Width.....                | 6.9'        |
| Tail Span.....                  | 9.1'        |

### **1.3 Equipment List**

Factory installed equipment is listed in the Pilot Operating Handbook. Additional installed equipment and alterations have to be considered when performing weight and balance calculation and. If a ballistic recovery system is installed from the factory, this is already included in the factory weight and balance calculation form.

### **1.4 Sources to Purchase Parts**

Spare parts may be ordered at

**REMOS AG**  
Franzfelde 31  
D-17309 Pasewalk  
G E R M A N Y  
Phone: +49 (0) 3973 225519-0  
E-mail: service@remos.com

Or at any REMOS Service Center. Have a frequent look at the REMOS website [www.remos.com](http://www.remos.com).

### **1.5 Disposable Replacement Parts**

Disposable parts are not defined for the REMOS GX in general. All parts may be used on condition. Only following parts shall be used after disassembly: Cu rings, safety wire, self locking nuts, cotter pins.

If parts need to be exchanged during maintenance, they are defined in the maintenance checklist.

## 1.6 Engine Specifications

The ROTAX 912 Series engines are 4-stroke, 4 cylinder horizontally opposed, spark ignition engines, featuring one central camshaft with push rods – OHV. Cylinder heads are liquid cooled. Lubrication system is a dry sump forced type. It is equipped with dual breakerless capacitor discharge ignition and two constant velocity carburetors. Prop drive is via reduction gear with integrated shock absorber and overload clutch. Specific engine data are given in the latest ROTAX operator's manual.

|                      |            |  |
|----------------------|------------|--|
| Manufacturer         |            | Bombardier-Rotax   |
| Engine type          |            | 912 UL-S2  |
| Max. Power           | take-off   | 73.6 kW / 100 HP @ 5,800min-1 for max. 5 min.  |
|                      | Max. cont. | 69.9 kW / 95 HP @ 5,500min-1   |
| Fuel qualities       |            | EN225 Super Plus, min. RON95<br>ASTM D4814, min. AKI91<br>ASTM D910 AVGAS100LL<br>ASTM D7547 UL91<br>HJELMCO AVGAS 91/96UL<br>HJELMCO AVGAS 91/98UL<br><br>up to 10% permitted in accordance with<br>REMOS NOT-001 |
| Usable fuel quantity |            | 21 US gallons  |
| Total fuel quantity  |            | 22 US gallons  |
| Fuel pressure        |            | max. 2.2 psi<br>min. 5.8 psi   |
| Engine oil           |            | Synthetic or semi-synthetic motorcycle oil with<br>gearbox additives. Do not use aircraft oil.   |
| Oil rating           |            | API-SG or higher ,see ROTAX SI-912-016   |
| Oil viscosity        |            | chose viscosity according to climate conditions,<br>preferable 10W-40, 5W-40 or 5W-50,<br>see ROTAX SI-912-016   |
| Engine oil capacity  |            | min. 2.1 qts<br>max. 3.1 qts   |
| Recommended oil      |            | AEROSHELL Sport PLUS 4 10W-40  |
| Oil pressure         |            | max. 102 psi (cold start)<br>min. 12 psi (below 3,500min-1)<br>29 ... 73 psi (above 3,500min-1)  |
| Oil temperature      |            | max. 266°F<br>min. 120°F   |
| Coolant              |            | BASF Glysantin Protect Plus/G48  |
| Mixing ratio         |            | 1:1 (Glysantin : Water)  |
| Temperature          |            | max. 275°F   |

## 1.7 Weight and Balance Information

To perform a successful weight and balance calculation, the center of gravity "C.G." has to be determined with all installed equipment, including engine oil, cooling liquid, but without fuel. Figure 1-4 shows how to conduct the C.G. determination. All measurements including a listing of all installed equipment have to be noted in the separate weight and balance calculation form (an example is given in figure 1-5.). This form has to be placed in the aircraft, so every pilot will be able to conduct his specific weight and balance calculation prior to each flight.

### 1.7.1 Center of gravity determination

- **Required Tools:** Weighing scales, flexible clear hose, plummet, ruler
- **Required Parts:** None
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center


To determine "CG", put the aircraft on 3 weighing scales, positioned on a level surface. Before weighing, a level wing main chord has to be established (use pads underneath scales). A check-mark reference point (R.P.) on the leading edge of the left wing, adjacent to the wing root, is provided to ease examination. To level the wing main chord, use a flexible clear hose, filled with water, as a spirit level. The total weight  $G = G1 + G2$ , has to be used for calculating "CG", located at the distance "X" behind R.P.

### 1.7.2 CG-Calculation

A specific C.G.-calculation recommendation which has to be carried out prior to each flight is provided in the Pilot Operating Handbook.


|        |   |
|--------|---|
| ♦ NOTE | For information only! Actual table may differ in values and layout. |
|--------|---|

Figure 1-4



The template for the weight and balance report including equipment list as shown in Fig. 1-5 is available on request at REMOS AG.

Figure 1-5

| Weight & Balance and Equipment List   |  | N xxxxx  |                                  |
|---|--|--|----------------------------------|
| Type of Aircraft: REMOS GX  |  | Minimum Equipment List   |                                  |
| Serial Number: XXX  |  | Description  | Type                             |
|   |  |  | location [mm/inch]               |
| <b>Technical Data</b><br>1. Reference Point R.P. Wing Leading Edge Fuselage<br>2. Reference Line R.L. Wing Main Chord   |  | Magnetic Compass   | C2400 or equivalent -250 -9,8    |
|   |  | Airspeed Indicator   | REMOS specification -250 -9,8    |
|   |  | Altitude Indicator   | 4FGH40 or equivalent -250 -9,8   |
|   |  | SkyView (primary screen)   | SV-D700 -250 -9,8                |
|   |  | SkyView (EMO module)   | SV-EMO-220 -150 -5,9             |
|   |  | Engine   | R912 UL-S, SNxxxxxxx -1010 -39,8 |
|   |  | Propeller  | CR3-65 -1350 -53,1               |
|   |  | Airbox w/ carb preheat   | REMOS -660 -26,0                 |
|   |  | ELT  | Artes ME406 900 35,4             |
|   |  | Position Lights w/ ACL   | AeroLEDs NS90 40 1,6             |
|   |  | Tailight w/ ACL  | AeroLEDs Suntail 4700 185,0      |
|   |  | Main Landing Gear Steel 4.00-6   | REMOS 950 37,4                   |
|   |  | Nose Landing Gear Steel 4.00-4   | REMOS -660 -26,0                 |
|   |  | Safety Belts LH  | 8-2520MDMON22-68 340 13,4        |
|   |  | Safety Belts RH  | 8-2520MDMON22-68 340 13,4        |
|   |  | Recovery System  | BRG 6-1350, SNxxxxx 1240 48,8    |
| <b>Component Weights</b><br>[ kg ] [ lb ]<br>Wing right 28,2 62,1<br>Wing left 28,6 63,0<br>Fuselage 258,8 569,9<br>Stabilizer 6,8 15,0<br>Wing Struts 8,2 18,1<br>Total Empty Weight 330,6 728,1<br>Useful Load 289,6 641,9<br>Gross Weight 600,0 1320,0 |  | <b>Equipment - Options</b><br>Description Type location [mm/inch]  |                                  |
| <b>Partial Weight</b><br>[ kg ] [ lb ]<br>Nosegear G1 70,3 154,7<br>Maingear G2 260,3 573,3<br>Total Weight 330,6 728,1   |  | SkyView (ADAHR3 module) DYNON SV-ADAHR3-200 -250 -9,8<br>SkyView (backup battery No.1) DYNON SV-BAT-320 -350 -13,8<br>SkyView (GPS module) DYNON SV-GPS-250 1350 53,1<br>SkyView (remote transponder) DYNON SV-KPNDR-261 -350 -13,8<br>Blind Encoder SDD120-RS232 -490 -19,3<br>Intercom GARMIN GMA240 -250 -9,8<br>COM GARMIN SL40 -250 -9,8<br>GPS GARMIN aera500 -250 -9,8<br>ELT ARTEX ME406 950 37,4<br>el. Fuel Pump Pierburg or equivalent 950 37,4<br>Cabin Heating System REMOS -860 -33,9<br>Oil Vent. REMOS -1260 -49,6<br>Dual Throttle REMOS -250 -9,8<br>Jetstix G303 0 0,0<br>12V Receptacle REMOS -250 -9,8<br>Tailight Incl. ACL AeroLEDs Suntail 4700 185,0<br>Wingtip Pos. Lights Incl. ACL AeroLEDs NS90 40 1,6<br>Landing Light AEROSUN 1600 40 1,6<br>Instrument Lights REMOS -250 -9,8<br>Door Vents REMOS -40 -1,6<br>Door Gas Springs REMOS 590 23,2<br>Door Fairings and Pockets REMOS 0 0,0<br>Luggage Comp. REMOS 960 37,8<br>Luggage Pocket Net REMOS 710 28,0<br>Luggage Pocket Mats REMOS 710 28,0<br>Leather/Fabric Seats REMOS 500 19,7<br>Floor Mats REMOS -350 -13,8<br>Wing Strut Fairings REMOS 500 19,7<br>Nose Landing Gear Fairing REMOS -750 -29,5<br>Main Landing Gear Fairings REMOS 650 25,6<br>Wing Folding Mechanism REMOS 980 38,6<br>Ventilation System REMOS 40 1,6<br>Sun Visors REMOS 40 1,6<br>Recovery System BRG 6-1350, SNxxxxx 1240 48,8 |                                  |
| <b>Leverarm</b><br>[ mm ] [ in ]<br>R.P. to Nosewheel a 734 28,9<br>Nose- to Mainwheel b 1375 54,1  |  |  |                                  |
|  $\text{Center of Gravity } x = \frac{G2 \times b}{G1 + G2} - a$   |  |  |                                  |
| <b>Center of Gravity</b><br>mm inch<br>empty C.G. 848 33,7<br>aft limit 245 9,6<br>front limit 415 16,3   |  |  |                                  |
| Date of Weighing 24. Feb. 2012<br>Date of Equipment List 24. Feb. 2012<br>Date of Preparation of this Document 24. Feb. 2012  |  |  |                                  |
| Signature/Stamp Inspector   |  |  |                                  |

## 1.8 Tire Inflation Pressure

Maintain tire pressure at the air pressure specified in figure 1-1. When checking tire pressure, examine tires for wear, cuts, bruises and spillage. Remove oil, grease and mud from tires with soap and water.

## 1.9 Approved Oils and Capacities

In general we recommend referring to the latest ROTAX 912 Series engine operator's manual to check for suitable engine oil. Nevertheless may be obtained from ROTAX Service Instructions SI-912-016 in its actual revision.

|                |   |
|----------------|---|
| <b>CAUTION</b> | <p>If engine is mainly run on AVGAS more frequent oil changes will be required. See ROTAX Service Information SI-912-016, latest edition. At the selection of suitable lubricants also refer to the ROTAX Service Information SI-912-016 latest edition.</p> <p>The use of multi-grade oils is recommended. Multi-viscosity grade oils are less sensitive to temperature variations than single-grade oils. They are suitable for use in all seasons, ensure rapid lubrication of all engine components at cold start and multi-viscosity oils get less fluid at higher temperatures.</p> |
|----------------|---|

## 1.10 Torque Values

A Chart of recommended nut torque values is shown in figure 1-7. These torque values are recommended for all installation procedures contained in this manual, except where other values are stipulated. They are not to be used for checking tightness of installed parts during service.

Figure 1-7

|          |                    |
|----------|--------------------|
| M4.....  | 4 Nm / 35 in.lb.   |
| M5.....  | 6 Nm / 53 in.lb.   |
| M6.....  | 10 Nm / 88 in.lb.  |
| M8.....  | 24 Nm / 212 in.lb. |
| M10..... | 35 Nm / 310 in.lb. |

|                |                                 |
|----------------|---------------------------------|
| <b>CAUTION</b> | DO NOT REUSE SELF-LOCKING NUTS. |
|----------------|---------------------------------|

### **1.11 General Safety Information**

- This aircraft shall never be operated at locations, airspeeds, altitudes or other circumstances from which a successful no-power landing cannot be made after sudden engine stoppage.
- Aerobatics are prohibited.
- Whether you are a qualified pilot or a novice, complete knowledge of the aircraft, its controls and operation is mandatory before venturing solo. Flying any type of aircraft involves a certain amount of risk. Be informed and prepared for any potentially hazardous situation associated with flying.
- A recognized training program and continued education for piloting an aircraft is absolutely necessary for all aircraft pilots. Make sure you also obtain as much information as possible about your aircraft, its maintenance and operation from your dealer.
- Respect all government or local rules pertaining to flight operation in your flying area. Fly only when and where conditions, topography and airspeeds are safest.
- Select and use proper aircraft instrumentation -- only approved instrumentation may be installed.
- Before flight, ensure that all engine controls are operative. Make sure all controls can be easily reached in case of emergency.
- Unless in a run up area, never run the engine with the propeller turning while on the ground. Do not operate engine if bystanders are close.
- In the interest of safety, the aircraft must not be left unattended while the engine is running.
- Keep an aircraft log and respect engine and aircraft maintenance schedules. Keep the engine in top operating condition at all the times. Do not operate any aircraft which is not properly maintained or has engine operating irregularities which have not been corrected.
- Since special tools, equipment and certification may be required, servicing shall only be performed by repairmen specified in this manual.
- To eliminate possible injury or damage, ensure any loose equipment or tools are properly secured before starting the engine.
- When in storage, protect the engine and fuel system from contamination and exposure.
- Certain areas, altitudes and conditions present greater risk than others. The engine may require carburetor recalibration or humidity or dust/sand preventive equipment, or additional maintenance may be required.
- Never operate the engine and gearbox without sufficient quantities of lubricating oil.
- Periodically verify level of coolant.
- Never exceed maximum rated rpm. Allow the engine to cool at idle for several minutes before turning off.

## Section 2

### *Ground Handling, Servicing, Cleaning, Lubrication and Inspection*

| <b>Table of Contents</b>                    | <b>Section</b> |
|---|----------------|
| 2.1. Ground Handling.....                   | 2-3            |
| 2.1.1. Towing .....                         | 2-3            |
| 2.1.2. Hoisting.....                        | 2-3            |
| 2.1.3. Jacking.....                         | 2-3            |
| 2.1.4. Parking.....                         | 2-3            |
| 2.1.5. Tie-Down .....                       | 2-4            |
| 2.1.6. Flyable Storage.....                 | 2-7            |
| 2.1.6.1. Returning Aircraft to Service..... | 2-7            |
| 2.1.7. Temporary Storage.....               | 2-7            |
| 2.1.7.1. Inspection during Storage.....     | 2-7            |
| 2.1.7.2. Returning Aircraft to Service..... | 2-8            |
| 2.2. Servicing .....                        | 2-8            |
| 2.2.1. Fuel .....                           | 2-8            |
| 2.2.2. Fuel Drains .....                    | 2-8            |
| 2.2.3. Engine Oil .....                     | 2-8            |
| 2.2.4. Engine Induction Air Filter .....    | 2-9            |
| 2.2.5. Battery .....                        | 2-9            |
| 2.2.6. Tires.....                           | 2-10           |
| 2.2.7. Hydraulic Brake System .....         | 2-11           |
| 2.3. Cleaning.....                          | 2-11           |
| 2.3.1. Windshield and Windows .....         | 2-11           |
| 2.3.2. Plastic Trim .....                   | 2-12           |
| 2.3.3. Painted Surfaces .....               | 2-12           |
| 2.3.4. Aluminum Surfaces.....               | 2-12           |
| 2.3.5. Engine and Engine Compartment .....  | 2-12           |
| 2.3.6. Upholstery and Interior .....        | 2-13           |
| 2.3.7. Propeller .....                      | 2-13           |
| 2.3.8. Wheels.....                          | 2-13           |
| 2.4. Lubrication .....                      | 2-14           |
| 2.5. Inspection .....                       | 2-14           |



|        |                               |      |
|--------|-------------------------------|------|
| 2.5.1. | Inspection Requirements ..... | 2-14 |
| 2.5.2. | Inspection Charts .....       | 2-15 |
| 2.5.3. | Inspection Guidelines .....   | 2-15 |

---

## 2.1 Ground Handling

### 2.1.1 Towing

Moving the aircraft by hand is accomplished by using the wing struts, prop roots and the fixed part of the horizontal tail as push points. Since there is no tow bar applicable at the nose gear, you have to press down the tail cone adjacent to the fin to raise the nose wheel off the ground. With the nose wheel clear of ground, the aircraft can be turned by pivoting it about the main wheels.

### 2.1.2 Hoisting

The aircraft may be lifted with a hoist of at least 1000 lb (0.5 tons) capacity by using suitable slings. To apply the slings, the wings have to be folded back first (refer to Pilot Operating Handbook). Now the wing main bolt brackets at the fuselage are accessible. Using a suitable securing bolt the slings can be hooked in at those brackets.

### 2.1.3 Jacking

Refer to paragraph 2.3. The aircraft does not feature further jacking points except for changing main wheels on the steel main gear. Jacking with the composite gear installed requires one person to lift the aircraft by pushing up the wing at the wing tip, while a second person has to put a jack beneath the main wheel strut adjacent to the fuselage. A piece of foam must be inserted between jack and fuselage so that no damage will occur to the paint.

### 2.1.4 Parking

Parking precautions depend principally on local conditions. As a general precaution, set parking brake or chock the wheels and lock the controls. In severe weather and high wind conditions, tie down the aircraft as outlined in paragraph 2.1.5 if a hangar is not available.

#### ■ CAUTION

Do not set parking brakes during cold weather (when accumulated moisture may freeze the brakes) or when brakes are overheated.

## 2.1.5 Tie-Down

When parking the aircraft in the open, head into the wind if possible. Secure control surfaces by using the seat belts and set brakes. After completing the preceding, proceed as follows:

### 2.1.5.1 Wing Tie Down

A special tie down ring is installed at the strut. Later versions of the GX are equipped with a thread in the outer portion of the wing, rings are provided to be screwed into these threads. Apply a rope to the upper end of the struts or to the rings. You may even use a chain when using rings.

Apply the lower end to a fixation point on the ground. Use tires filled with concrete, rings in the apron or at least solid anchors. Take care for correct angles of the ropes or chains. They shall point vertically downward from the wing to the ground, an angle of not more than 20deg outward is recommended. Never tolerate the strings to point inward. Make sure the rope is straight, tight and without slack.



on strut

correct tie-down

on wingtip



loose rope

**NEVER**


## 2.1.5.2 Propeller Tie Down

Wrap a rope around the propeller spacer, just in the gap between cowling and spinner. Apply the lower end to a fixation point on the ground. Use tires filled with concrete, rings in the apron or at least solid anchors. Take care for correct angles of the ropes or chains. They shall point vertically downward from the nose to the ground; an angle forward of not more than 20 deg is recommended. Never wrap the rope around the propeller spinner in order to avoid damages and scratches.



## 2.1.5.3 Tail Tie Down

The GX is equipped with a tie-down point in the tail skid. Apply the upper end of a rope to that tie-down and the lower end to a fixation point on the ground. Use tires filled with concrete, rings in the apron or at least solid anchors. Take care for correct angles of the ropes or chains. They shall point vertically downward from the tail to the ground, an angle backward of not more than 20deg is recommended.



### **2.1.6 Flyable Storage**

Flyable storage is defined as a maximum of 30 days non-operational storage and/or the first 20 hours of intermittent engine operation.

During the 30 day non-operational storage or the first 20 hours of intermittent engine operation, every seventh day the propeller shall be rotated through 10 revolutions, without running the engine. If the aircraft is stored outside, tie-down in accordance with paragraph 2.1.5. In addition, the Pitot tube, static air vents, air vents, openings in the engine cowling, and or similar openings shall have protective covers installed to prevent entry of foreign material. After 30 days, aircraft should be flown for 30 minutes or ground run-up until oil has reached operating temperature of at least 215°F for at least 15 minutes.

#### **2.1.6.1 Returning Aircraft to Service**

After flyable storage, returning the aircraft to service is accomplished by performing a thorough pre-flight inspection. At the end of the first 20 hours of engine operation, drain engine oil and replace external oil filter element. Service the engine with correct grade and quantity of engine oil. Refer to figure 1-3 and paragraph 1.5 for correct grade of engine oil.

### **2.1.7 Temporary Storage**

Temporary storage is defined as aircraft in a non-operational status for a maximum of 90 days. The aircraft is made from composite materials and epoxy resin. This construction will allow storing the aircraft for long periods without damage to the airframe. Regardless we recommend storing the aircraft in a dry hanger to keep paintwork and metal parts in good condition. For storage periods not to exceed 90 days, the following methods of treatment are suggested:

- a. Fill fuel tank with correct grade of gasoline.
- b. Clean and wax aircraft thoroughly.
- c. Clean any oil or grease from tires and coat tires with a tire preservative. Cover tires to protect against grease and oil.
- d. Rotate wheels every 30 days to change supporting points and prevent flat spotting the tires.
- e. Seal or cover all openings which could allow moisture and/or dust to enter.
- f. Remove battery and store in a cool dry place, charge battery as required.
- g. Seal all engine openings exposed to the atmosphere using suitable plugs or none-hygroscopic tape. Attach a red streamer at each point that a plug or tape is installed.
- h. If the aircraft is to be stored outside, perform the procedures outlined in paragraph 2.1.5. In addition, the Pitot tube, static ports, air vents, opening in the engine cowling and other similar openings should have protective covers installed to prevent entry of foreign material.
- i. Attach a warning placard to the propeller to the effect that the propeller shall not be moved while the engine is in storage.

#### **2.1.7.1 Inspection during Storage**

Remove dust accumulations as frequently as possible, clean and wax as required.

## 2.1.7.2 Returning Aircraft to Service

After temporary storage, use the following procedures to return aircraft to service:

- a. Check tires for proper inflation.
- b. Check battery and install.
- c. Check the oil sump has proper quantity of engine oil (Refer to Pilot Operating Handbook and/or Rotax Operator's Manual for instructions).
- d. Service induction air filter and remove warning placard from propeller.
- e. Remove materials used to cover openings.
- f. Check fuel tank and fuel lines for moisture and sediment. Drain enough fuel to eliminate moisture and sediment.
- g. Perform a thorough pre-flight inspection, then start and warm-up engine.

## 2.2 Servicing

Maintenance interval is 100h for all REMOS aircraft, except of the first maintenance event that is due after 25h. In case of prevailing use of AVGAS 100LL oil change interval is reduced to 50h. Refer to ROTAX SI-912-016. In that case only an oil change is required, but no further maintenance.

### 2.2.1 Fuel

Fuel tank should be filled immediately after flight to lessen moisture condensation. Tank capacity is listed in Section 1. The recommended fuel grade to be used is given in figure 1-6.

### 2.2.2 Fuel Drains

A fuel drain is located at the bottom of the fuel tank. The drain valve is accessed from beneath the fuselage adjacent to the main landing gear. To activate: push up the white plastic tube. To drain all fuel from the tank without holding the valve depressed a lock mechanism is built in. To activate the lock mechanism, push up the white plastic tube and rotate it until it locks.

### 2.2.3 Engine Oil (Refer to Section 1-7)

Check engine lubrication oil with the oil dipstick located in the oil tank, located on the right hand side of the firewall, immediately after engine has been stopped. To check the oil level, it is important to turn the propeller a few times in operating direction until you can hear some kind of bubbling noise coming out of the oil expansion tank. Please be sure to remove the key from the ignition switch before turning the propeller. This is the only way to check the engine oil level correctly. (Refer also to the ROTAX Engine Operator's Manual).

Engine oil should be drained while the engine is still hot so that more positive draining is obtained. Refer to the inspection charts for required intervals for oil and filter changes. Change oil at least every 12 months even if less than the specified hours have accumulated. Reduce this period for prolonged operation in dusty areas, in cold climates where sludgy conditions exist, or where short flights and long idle periods are encountered, which cause sludgy conditions.

|                |   |
|----------------|---|
| <b>CAUTION</b> | Do not operate with less than the minimum engine oil level on dipstick marking. |
|----------------|---|

### **2.2.4 Engine Induction Air Filter (Refer to Figure 2-1)**

The induction air filter keeps dust and dirt from entering the induction system. The value of maintaining the air filter in a good clean condition can never be overstressed. More engine wear is caused through the use of dirty or damaged air filter than is generally believed. The frequency with which the filter should be removed, inspected and cleaned will be determined primarily by aircraft operating conditions. A good general rule however, is to remove, inspect and clean the filter at least every 50 hours of engine operating time and more frequently if warranted by operating conditions. Due to reasons of flight safety the filter should be replaced or cleaned according to the manufacturer's instruction every 100 hours of engine operation time or one year, whichever should occur first.

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | The aircraft is equipped with an oiled K&N Pre-Charger Filter Element, which can be cleaned and re-oiled when necessary. Its special design provides extended servicing intervals. For proper cleaning and re-oiling the use of K&N air filter cleaner is recommended and K&N air filter oil is required. |
|---------------|---|

|                  |  |
|------------------|--|
| <b>■ CAUTION</b> | The filter has to be replaced if damaged, if in doubt filter has to be replaced as a precaution to flight safety. Be sure air box is clean before installing a new filter. |
|------------------|--|


### **2.2.5 Battery**

The installed battery needs no further servicing, except checking cable connections. It is important to check battery voltage when the aircraft is out of service for more than two weeks. Battery voltage has to maintain at least 12.0 volts without engine running and all equipment switched off, master switch in "off" position (regular voltage 12.5 volts). If voltage does indicate 12.2 volts or less it has to be charged and maintained.

Lead batteries may be charged with conventional battery charger suitable for this type of batteries. Newer aircraft are equipped with LiFePo4 batteries. This type of battery needs a special type of charger. Those chargers are mostly sold for RC-airplanes. To avoid damage to the battery, do not use inappropriate or inexpensive chargers. Contact REMOS for recommendations of appropriate charging systems.



Figure 2-1



## 2.2.6 Tires

Maintain tire pressure at the air pressure specified in figure 1-1. When checking tire pressure, examine tires for wear, cuts, bruises and spillage. Remove oil, grease and mud from tires with soap and water.

|               |  |
|---------------|--|
| ♦ <b>NOTE</b> | Recommended tire pressures should be maintained. Especially in cold weather, remember that any drop in temperature of the air inside a tire causes a corresponding drop in air pressure. |
|---------------|--|

### **2.2.7 Hydraulic Brake System**

Check brake master cylinder and refill with correct grade of brake fluid. To refill, DOT 4 automobile brake fluid is required, as specified in the inspection chart, and no aircraft hydraulic fluid must ever be used! Bleed the brake system to remove entrapped air whenever there is a spongy response to the brake lever. Refer to paragraph 5.2.5 for filling and bleeding the brake system.

## **2.3 Cleaning**

Keeping the aircraft clean is important. Besides maintaining the appearance of the aircraft, cleaning makes inspection and maintenance easier.

### **2.3.1 Windshield and Windows**

Windows should be cleaned carefully with plenty of fresh water and a mild detergent, using the palm of the hand to feel and dislodge any caked dirt or mud. A sponge, soft cloth, or chamois may be used, but only as a means of carrying water to the acrylic. Rinse thoroughly, and then dry with a clean moist chamois. Do not rub the acrylic with a dry cloth as this builds up an electrostatic charge which attracts dust. Oil and grease may be removed by rubbing lightly with a soft cloth moistened with a suitable solvent.

|                  |  |
|------------------|--|
| <b>■ CAUTION</b> | When cleaning the windshields, do NOT use gasoline, alcohol, benzene, acetone, carbon tetrachloride, fire extinguisher fluid, deicer fluid, lacquer thinner, or glass window cleaning spray. These solvents will soften and craze the acrylic windows. |
|------------------|--|

|                  |   |
|------------------|---|
| <b>■ CAUTION</b> | Before using any cleaner, read the instructions on the container and test it on an inconspicuous place in the fabric to be cleaned. |
|------------------|---|

After washing, the acrylic windshield and windows should be cleaned with an aircraft windshield cleaner. Apply the cleaner with soft cloths and rub with moderate pressure. Allow the cleaner to dry, then wipe it off with soft flannel cloths. A thin, even coat of special acrylic window polish will fill-in minor scratches and help prevent further scratching. Do not use a canvas cover on the windshield or windows unless freezing rain or sleet is anticipated since the cover may scratch the acrylic surface.

|                  |   |
|------------------|---|
| <b>■ CAUTION</b> | Do not use any lacquer polish like carnauba wax on the acrylic windows. |
|------------------|---|

### **2.3.2 Plastic Trim**

The instrument panel, plastic trim and control knobs need only do be wiped with a damp cloth. Oil and grease on the control sticks and control knobs can be removed with a cloth moistened with a suitable solvent. Volatile solvents, such as mentioned in paragraph 2.3.1 must never be used since they soften and craze the plastic.

### **2.3.3 Painted Surfaces**

The painted exterior surfaces of the aircraft, under normal conditions, require a minimum of polishing and buffing. Approximately two weeks are required for acrylic paint to cure completely; in most cases, the curing period will have been completed prior to delivery of the aircraft. In the event that polishing or buffing is required within the curing period, it is recommended that the work is done by an experienced painter. Generally, the painted surfaces can be kept bright by washing with water and mild soap, followed by a rinse with water and drying with cloths or chamois. Harsh or abrasive soaps or detergents which could cause scratches should never be used. After the curing period, the aircraft may be waxed with a good automotive wax. A heavier coating of wax on the leading edge of the wing and tail and on the engine nose cap will help reduce the abrasion encountered in these areas.

### **2.3.4 Aluminum Surfaces**

The aluminum surfaces of some parts require a minimum of care due to their anodized coating, but should never be neglected. Many good aluminum cleaners are available from commercial suppliers of aircraft products. Household type detergent soap powders are effective cleaners, but should only be used very cautiously since some of them are strongly alkaline and will cause damage.

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | It is highly recommended to conserve aluminum surfaces after cleaning with a suitable wax or spray oil or at least once per month. |
|---------------|--|

### **2.3.5 Engine and Engine Compartment**

The engine should be kept clean since dirty cooling fins may support overheating of the engine. Also, cleaning is essential to minimize any danger of fire and provide for easier inspection of components. The entire engine cowling may be removed to facilitate engine and interior cowl cleaning. Wash down the engine and components with a suitable solvent, then dry thoroughly with compressed air.

|                  |   |
|------------------|---|
| <b>■ CAUTION</b> | Particular care should be given to electrical equipment before cleaning. Solvent should not be allowed to enter magnetos, starter, alternator, voltage regulator and the like. Hence, these components should be protected before saturating the engine with solvent. Any fuel, oil and air openings should be covered before washing the engine with solvent. Caustic cleaning solutions should not be used. After cleaning engine re-lubricate all control arms and moving parts. |
|------------------|---|

### **2.3.6 Upholstery and Interior**

Keeping the upholstery and interior clean prolongs upholstery fabric and interior trim life. To clean the interior, brush or vacuum clean the upholstery and carpet to remove dust and dirt. Then clean upholstery with a sponge moistened with fresh water, wipe plastic trim with a damp cloth. Oil spots and stains may be cleaned with household spot removers, used sparingly. To clean the interior, proceed as follows:

- a. Brush or vacuum clean the upholstery and carpet to remove dust and dirt.
- b. Clean upholstery with a sponge moistened with fresh water
- c. Wipe plastic trim with a damp cloth.
- d. Oil spots and stains may be cleaned with household spot removers, used sparingly. Before using any solvent, read the instructions on the container and test it on an obscure place in the fabric to be cleaned. Never saturate the fabric with volatile solvent; it may damage the padding and backing material. Scrape sticky material from the fabric with a dull knife, then spot clean the area.

|                  |  |
|------------------|--|
| <b>■ CAUTION</b> | Before using any cleaner, read the instructions on the container and test it on an inconspicuous place in the fabric to be cleaned. Never saturate the fabric with volatile solvent; it may damage the padding and backing material. Scrape sticky material from the fabric with a dull knife, then spot clean the area. |
|------------------|--|

### **2.3.7 Propeller**

Wash hub and blades with a soft cloth and suitable cleaning solvent, then dry thoroughly with compressed air. The hub of the Sensenich or Neuform propeller are made of anodized aluminum, Tonini or Woodcomp prop feature a zinc coated pressure plate.

|                  |   |
|------------------|---|
| <b>■ CAUTION</b> | Do not use gasoline, alcohol, benzene, acetone, or lacquer thinner. These solvents will soften and damage the lacquer finish. |
|------------------|---|

### **2.3.8 Wheels**

The wheels should be washed periodically and examined for corrosion, cracks and dents in the wheel halves or hubs. If defects are found, remove and repair in accordance with Section 5. Discard cracked wheel halves, of hubs and install new parts.

## 2.4 Lubrication

The REMOS GX is constructed with minimum number of lubrication point. For these points, lubrication regular grease is used. The following listing shows all points which have to be lubricated frequently.

- a. Wing main bolts
- b. Wing ball joints (plastic ball) at wing folding mechanism
- c. Stabilizer mounting bolts

It is recommended to clean and lubricate all hinges and control system joints and bearings with spray oil like WD40 or equivalent.

When changing wheels it is recommended to lubricate wheel axles before reassembling to prevent them from corrosion and keep wheel changing easier with the composite main gear installed. Not applicable with the steel main gear fitted.

## 2.5 Inspection

### 2.5.1 Inspection Requirements

As required by Federal Aviation Regulations, all civil aircraft of U.S. registry must undergo a complete inspection (annual) each twelve calendar months.

In addition to the required Annual Inspection, aircraft operated commercially (for hire) must also have a complete aircraft inspection every 100 hours of operation.

|        |   |
|--------|---|
| ◆ NOTE | REMOS strongly recommends that privately operated aircraft undergo the 100hrs inspection interval, too. |
|--------|---|

### **2.5.2 Inspection Charts**

The first inspection has to be performed after the first 25 hours of service, all following intervals are performed after 100h of operation. To conduct these inspections it is mandatory to use the **REMOS Service and Maintenance Checklist** (latest issue).

### **2.5.3 Inspection Guidelines**

- a. Moveable Parts for: lubrication, servicing, security of attachment, binding, excessive wear, safetying, proper operation, proper adjustment, correct travel, cracked fittings, security of hinges, defective bearings, cleanliness, corrosion, deformation, sealing and tension.
- b. Fluid Lines and Hoses for: leaks, cracks, dents, kinks, chafing, proper radius, security, corrosion, deterioration, obstruction and foreign matter.
- c. Metal Parts for: security of attachment, cracks, metal distortion, broken spot welds, corrosion, condition of paint and any other apparent damage.
- d. Composite Parts for: cracks, dents, de-lamination.
- e. Wiring for: security, chafing, burning, defective insulation, loose or broken terminals, heat deterioration and corroded terminals.
- f. Bolts in Critical Areas for: correct torque in accordance with torque values given in the chart in Section 1, when installed or when visual inspection indicates the need for a torque check.
- g. Filters and Fluids for: cleanliness, contamination and/or replacement at specified intervals.
- h. Aircraft File: Miscellaneous data, information and licenses are a part of the aircraft file. Check that the following documents are up-to-date and in accordance with current Federal Aviation Regulations. Most of the items listed are required by the United States Federal Aviation Regulations.

#### To be displayed in the aircraft at all times:

- a. Aircraft Airworthiness Certificate
- b. Aircraft Registration Certificate

#### To be carried in the aircraft at all times:

- a. Weight and Balance and associated papers (latest copy of the Repair and Alteration Form if applicable).
- b. Aircraft Equipment List.

#### To be made available upon request:

- a. Aircraft Log Book

*Intentionally left blank*

## Section 3

### *Fuselage*

| Table of Contents |                           | Section |
|-------------------|---------------------------|---------|
| 3.1               | Windshield and Windows    | 2       |
| 3.1.1             | Description               | 2       |
| 3.1.2             | Waxing                    | 2       |
| 3.1.3             | Repairs                   | 2       |
| 3.1.3.1           | Scratches                 | 2       |
| 3.1.3.2           | Cracks                    | 4       |
| 3.1.4             | Replacement               | 4       |
| 3.1.4.1           | Removal                   | 4       |
| 3.1.4.2           | Installation              | 4       |
| 3.2               | Cabin Doors               | 5       |
| 3.2.1             | Removal and Installation  | 5       |
| 3.2.2             | Cabin Door Latches        | 5       |
| 3.2.3             | Lock                      | 5       |
| 3.2.3.1           | Removal and Installation  | 5       |
| 3.3               | Seats                     | 10      |
| 3.3.1             | Description               | 10      |
| 3.3.2             | Upholstery                | 10      |
| 3.4               | Baggage Compartment       | 10      |
| 3.5               | Safety Provisions         | 10      |
| 3.5.1             | Safety Belts              | 10      |
| 3.5.2             | Ballistic Recovery System | 10      |
| 3.5.2.1           | Description               | 10      |
| 3.5.3             | Baggage Pocket Nets       | 10      |
| 3.6               | Bill of Materials         | 11      |



### **3.1 Windshield and Windows**

#### **3.1.1 Description**

The windshield and windows are single-piece acrylic plastic panels glued to the fuselage and sealed with a silicone bead around, to achieve the best possible aerodynamics and eliminate wind noises as much as possible.

#### **3.1.2 Waxing**

- **Required Tools:** Fine-grade wax, batting
- **Required Parts:** None
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

Waxing will fill in minor scratches in clear plastic and help protect the surface from further abrasion. Use a good grade of commercial wax applied in a thin, even coat. Bring wax to a high polish by rubbing lightly with a clean, dry flannel cloth.

#### **3.1.3 Repairs**

Damaged window panels and windshield may be removed and replaced if damage is extensive. However, certain repairs as prescribed in the following paragraphs can be made successfully without removing the damaged part from aircraft. Three types of temporary repairs for cracked plastic are possible. No repairs of any kind are recommended on highly-stressed or compound curves where repair would be likely to affect pilot's field of vision. Curved areas are more difficult to repair than flat areas and any repaired area is both structurally and optically inferior to the original surface.

##### **3.1.3.1 Scratches**

- **Required Tools:** Sandpaper, rubber pad, buffing compound, batting, automobile body cleaner or fine-grade wax
- **Required Parts:** None
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

Scratches on clear plastic surfaces can be removed by hand-sanding operations followed by buffing and polishing, if steps below are followed carefully.

- a. Wrap a piece of No. 3000 (or finer) sandpaper or abrasive cloth around a rubber pad or wood block. Rub surface around scratch with a circular motion, keeping abrasive constantly wet with clean water to prevent scratching surface further. Use minimum pressure and cover an area large enough to prevent formation of "Bull's eyes" or other optical distortions.
- b. Continue sanding operation, using progressively finer grade abrasives until scratches disappear. Do not skip one grade of abrasive!
- c. When scratches have been removed, wash area thoroughly with clean water to remove all gritty particles. The entire sanded area will be clouded with minute scratches which must be removed to restore transparency.
- d. Apply first tallow or buffering compound to a motor-driven buffing wheel. Hold wheel against plastic surface, moving it constantly over damaged area until cloudy appearance disappears. A 2000-feet-per-minute surface speed is recommended to prevent overheating and distortion. (Example: 750 rpm polishing machine with a 10 inch buffing bonnet.)
- e. When buffing is finished, wash area thoroughly and dry with a soft flannel cloth. Allow surface to cool and inspect area to determine if full transparency has been restored. Apply a thin coat of hard wax and polish surface lightly with a clean flannel cloth.
- f. Minute hairline scratches can often be removed by rubbing with commercial automobile body cleaner or fine-grade rubbing compound. Apply with a soft clean, dry cloth or imitation chamois.

**■ CAUTION**

Do not use a coarse grade of abrasive. No. 3000 is of maximum coarseness.

**◆ NOTE**

Polishing can be accomplished by hand but will require a considerably longer period of time to attain the same result as produced by a buffing wheel.

**◆ NOTE**

Rubbing plastic surface with a dry cloth will build up an electrostatic charge which attracts dirt particles and may eventually cause scratching of surface. After wax has hardened, dissipate this charge by rubbing surface with a slightly damp chamois. This will also remove dust particles which have collected while wax is hardening.

### 3.1.3.2 Cracks

- **Required Tools:** 1/8" drill, aircraft dope
  - **Required Parts:** Rubber sheet, fabric, wood strips, bolts and nuts
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- 
- a. When a crack appears, drill a hole at end of crack to prevent further spreading. Hole should be approximately 1/8 inch in diameter, depending on length of crack and thickness of material.
  - b. Temporary repairs to flat surfaces can be accomplished by placing a thin strip of wood over each side of surface and inserting small bolts through wood and plastic. A cushion of sheet rubber or aircraft fabric should be placed between wood and plastic on both sides.
  - c. A temporary repair can be made on a curved surface by placing fabric patches over affected areas. Secure patches with aircraft dope or lacquer thinner.

This type of repairs is used as a temporary measure ONLY, and as soon as facilities are available, panel should be replaced.

### 3.1.4 Replacement

#### 3.1.4.1 Removal

- **Required Tools:** Jig saw, crowbar, power drill, abrasive paper
  - **Required Parts:** None
  - **Level of Maintenance:** Heavy
  - **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center
- 
- a. Cut out the old window using a jig saw without causing damage to the fuselage.
  - b. Remove the remaining border of the window by the use of a crowbar and sand of old glue to get a smooth joining surface at the fuselage or door shell.

#### 3.1.4.2 Installation

- **Required Tools:** Standard metric tools, REMOS-Weld adhesive
  - **Required Parts:** Window as required
  - **Level of Maintenance:** Heavy
  - **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center
- 
- a. Sand the faying surface of window and fuselage, using abrasive paper of 320 grain size.
  - b. Clean the window opening on the fuselage (about 2 inch width) with appropriate solvent.
  - c. Apply REMOS-Weld adhesive to the joining surfaces of fuselage/door shell.
  - d. Tap the window to the fuselage opening and wipe away excessive glue, while smoothing the gap between window and fuselage/door shell. Let the glue cure for 24 hours at 65° F.

## 3.2 Cabin Doors

### 3.2.1 Removal and Installation

To remove cabin doors unlock and open the doors, unplug the support gas struts from the door bracket. Do not unplug the gas struts while doors are not in fully open position. Withdraw safety pin from both hinges on top of the doors. Installation is carried out in reverse order.

### 3.2.2 Cabin Door Latches

The cabin door latch contains three locking bolts operated by a rotary door handle (inside and outside each door). Rotating the handle forward will lock while spinning backward will unlock the doors. It is no adjustment, lubrication or servicing required to the latch system.

### 3.2.3 Lock

#### 3.2.3.1 Removal and Installation

- **Required Tools:** Standard metric tools
- **Required Parts:** Door handle decal set, Loctite 243 (medium strength)
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center


In addition, a cylinder and key type lock is installed in both outside door handles. The procedure to replace the lock is given in the following listing (refer to figure 3-2):

- a. Remove inside bezel (6) and door trim panel (5).
- b. Remove decals (9) from door handle (7) to get access to its retaining screws (8)
- c. Remove door handle (7)
- d. Refer to figure 3-3 and proceed with the following steps:
- e. Disconnect control rod (8).
- f. Unscrew complete door lock assembly (12) from outer door shell by removing its four fixing screws (11).
- g. Remove decals from outer door handle (16).
- h. Remove outer door handle by unscrewing its four retaining screws (9).
- i. Remove lock (14) and remember position for re-installation.
- j. Assemble in reverse order.

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Use Loctite type 243 to secure retaining screws when installing a new key lock. |
|---------------|---|

In figure 3-3 to 3-4 detailed instructions are provided, if further servicing or replacement of components is required to the door lock system.

Figure 3-1



◆ NOTE

There are two different versions of some parts (1, 3, 6, 7, 8) given in the upper picture. Please tell our service center your preferred color (silver/blue anodized) in case of purchase.

Figure 3-2




Figure 3-3




Figure 3-4







Figure 3-5





### **3.3 Seats**

#### **3.3.1 Description**

The standard pilot and co-pilot seat is made from one-piece carbon fiber monocoque, equipped with a 3 position fore and aft adjustment. Seat adjustment is not possible while seated.

#### **3.3.2 Upholstery**

Due to the wide selection of fabrics, styles and colors, it is impossible to depict each particular type of upholstery. Major work, if possible, should be accomplished by an experienced mechanic.

Materials and tools will vary with job. Scissors for trimming upholstery to size and a dull-bladed putty knife are the only tools required for most trim work. Use industrial rubber cement to hold mats and fabric edges in place.

### **3.4 Baggage Compartment**

The baggage compartment is located behind the pilot seat. It is a one-piece carbon fiber container, held in place by 2 screws located on it's face plate and one screw at the inside bottom. After removing these screws the baggage compartment can be withdrawn from the bulkhead.

### **3.5 Safety Provisions**

#### **3.5.1 Safety Belts**

4-point safety belts are installed for pilot and co-pilot seat to provide maximum safety. Safety belts are tied to latches screwed to the cabin structure. Belts should be replaced if frayed or cut, latches are defective or stitching is broken. Attaching parts should be replaced if excessively worn or defective.

#### **3.5.2 Ballistic Recovery System**

##### **3.5.2.1 Description**

The REMOS GX is prepared for the installation of a MAGNUM parachute rescue system. Description and installation is included in the parachute installation manual G3-8 RE RS 080, available on request at REMOS AG.

#### **3.5.3 Baggage Pocket Nets**

- **Required Tools:** Standard metric tools
- **Required Parts:** Pocket nets
- **Level of Maintenance:** Heavy
- **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center

Behind each seat, a mold for lightweight baggage is provided covered by a pocket net. The maximum weight capacity must not exceed 5 lb each. Nets should be replaced when frayed or cut or frame is broken.

## 3.6 Bill of Materials

| Fig. No. | Item No. | Order No. | Part No.         | Qty. per Assy | Description  | Appl. S/N |
|----------|----------|-----------|------------------|---------------|--|-----------|
| 3-1      | 1        | 700437    | G3-8 FU-11-10-00 | 1             | Ventilation Window Assy blue anodized                      | Till 304  |
|          | 1        | 700437    | G3-8 FU-11-10-00 | 1             | Ventilation Window Assy colorless anodized                 | 304 ff    |
|          | 2        | 100343    |                  | 1             | Straight Pin 3x20 DIN 6325                                 | All       |
|          | 3        | 100518    | G3-8 FU-11-10-01 | 1             | Ventilation Lever blue anodized                            | Till 304  |
|          | 3        | 100518    | G3-8 FU-11-10-01 | 1             | Ventilation Lever colorless anodized                       | 304 ff    |
|          | 4        | 101039    |                  | 1             | Spiral Spring 17x2,64x0,5                                  | All       |
|          | 5        | 102537    |                  | 2             | Dowel Pin 3x10 DIN 7346                                    | All       |
|          | 6        | 100519    | G3-8 FU-11-10-02 | 1             | Ventilation Handle blue anodized                           | Till 304  |
|          | 6        | 100519    | G3-8 FU-11-10-02 | 1             | Ventilation Handle colorless anodized                      | 304 ff    |
|          | 7        | 100517    | G3-8 FU-11-10-03 | 1             | Ventilation Hub blue anodized                              | Till 304  |
|          | 7        | 100517    | G3-8 FU-11-10-03 | 1             | Ventilation Hub colorless anodized                         | 304 ff    |
|          | 8        | 100520    | G3-8 FU-11-10-06 | 1             | Ventilation Face Plate blue anodized                       | Till 304  |
|          | 8        | 100520    | G3-8 FU-11-10-06 | 1             | Ventilation Face Plate colorless anodized                  | 304 ff    |
|          | 9        | 100104    |                  | 2             | Countersunk Head Hexagon Socket Screw M3x10 vz DIN 7991    | All       |
|          | 10       | 102275    |                  | 2             | Truss Head Hexagon Socket Screw M3x10 ISO 7380 A2          | All       |
| 3-2      | 1        | 100511    | G3-8 FU-11-30-07 | 1             | Fuselage Door Panel Inside                                 | All       |
|          | 2        | 100188    |                  | 4             | Lens Head Hexagon Socket Screw M4x12                       | All       |
|          | 3        |           | G3-8 FU-11-10-05 | 1             |  | All       |
| 3-3      | 1        | 100103    |                  | 2             | Countersunk Head Hexagon Socket Screw M3x8 vz DIN 7991     | All       |
|          | 2        | 100508    | G3-8 FU-11-30-04 | 1             | Fuselage Door Handle LH Inside                             | All       |
|          |          | 100510    | G3-8 FU-11-30-05 | 1             | Fuselage Door Handle RH Inside                             | All       |
| 3-4      | 1        | 100101    |                  | 4             | Countersunk Head Hexagon Socket Screw M3x10 vz DIN 7991    | All       |
|          | 2        | 100507    | G3-8 FU-11-30-02 | 1             | Fuselage Door Handle LH Outside                            | All       |
|          |          | 100509    | G3-8 FU-11-30-03 | 1             | Fuselage Door Handle RH Outside                            | All       |
|          | 3        | 100102    |                  | 4             | Cylinder Head Hexagon Socket Screw M3x8 vz DIN912 8.8      | All       |
|          | 4        | 100514    |                  | 1             | Lock   | All       |
|          | 5        | 100113    |                  | 4             | Cylinder Head Hexagon Socket Screw M4x16 vz DIN912 8.8     | All       |
|          | 6        | 100233    |                  | 4             | Washer 4,3 DIN125 FormA Steel vz                           | All       |
|          | 7        | 100123    |                  | 1             | Countersunk Head Hexagon Socket Screw M4x12 vz DIN7991 8.8 | All       |
|          | 8        | 100504    | G3-8 FU-11-20-14 | 1             | Door Lock Bearing Bush                                     | All       |
|          | 9        | 100503    | G3-8 FU-11-20-10 | 1             | Door Lock Bell Crank                                       | All       |
|          | 10       | 100212    |                  | 1             | Self-locking Hexagon Nut M4 DIN985 vz                      | All       |
|          | 11       | 100233    |                  | 1             | Washer 4,3 DIN125 FormA Steel                              | All       |

| Fig. No. | Item No. | Order No. | Part No.         | Qty. per Assy | Description  | Appl. S/N |
|----------|----------|-----------|------------------|---------------|--|-----------|
| 3-5      | 1        | 100500    | G3-8 FU-11-20-11 | 1             | Door Lock Distance Bush Arrestor                           | All       |
|          | 2        | 100122    |                  | 3             | Cylinder Head Hexagon Socket Screw M4x8 vz DIN912 8.8      | All       |
|          | 3        | 100213    |                  | 1             | Hexagon Nut M4 DIN934                                      | All       |
|          | 4        | 101038    |                  | 1             | Tension Spring   | All       |
|          | 5        | 100233    |                  | 5             | Washer 4,3 ISO 7091 vz                                     | All       |
|          | 6        | 100113    |                  | 1             | Cylinder Head Hexagon Socket Screw M4x16 vz DIN912 8.8     | All       |
|          | 7        | 100212    |                  | 2             | Self-locking Hexagon Nut M4 DIN985 vz                      | All       |
|          | 8        | 100512    | G3-8 FU-11-20-08 | 1             | Door Lock Safety Catch                                     | All       |
|          | 9        | 100148    |                  | 1             | Cylinder Head Hexagon Socket Screw M6x10 vz DIN912 8.8     | All       |
|          | 10       | 100253    |                  | 1             | Washer M6 DIN 552 6,4x18x1,5                               | All       |
|          | 11       | 100266    |                  | 1             | Spring Washer 6,4 DIN 137 vz                               | All       |
|          | 12       | 101037    |                  | 1             | O-Ring 10x2  |           |
|          | 13       | 102092    |                  | 1             | Washer M10 ISO 7093 vz                                     |           |
|          | 14       | 100103    |                  | 2             | Countersunk Head Hexagon Socket Screw M3x8 vz DIN 7991     |           |
|          | 15       | 100505    | G3-8 FU-11-20-12 | 2             | Door Lock Distance Bush Handle Inside                      |           |
|          | 16       | 100498    | G3-8 FU-11-20-06 | 1             | Door Lock Central Plate                                    |           |
|          | 17       | 100499    | G3-8 FU-11-20-15 | 1             | Door Lock Master Bush                                      |           |
|          | 18       | 100211    |                  | 2             | Self-locking Hexagon Nut M3 DIN985 vz                      |           |
|          | 19       | 100123    |                  | 1             | Countersunk Head Hexagon Socket Screw M4x12 vz DIN7991 8.8 |           |
|          | 20       | 100504    | G3-8 FU-11-20-14 | 1             | Door Lock Bearing Bush                                     |           |
|          | 21       | 100513    | G3-8 FU-11-20-13 | 1             | Door Lock Bushing  |           |
|          | 22       | 100497    | G3-8 FU-11-20-07 | 1             | Door Lock Mount  |           |
|          | 23       | 100101    |                  | 4             | Countersunk Head Hexagon Socket Screw M3x10 vz DIN 7991    |           |

## Section 3

### *Fuselage*

| Table of Contents |                           | Section |
|-------------------|---------------------------|---------|
| 3.1               | Windshield and Windows    | 2       |
| 3.1.1             | Description               | 2       |
| 3.1.2             | Waxing                    | 2       |
| 3.1.3             | Repairs                   | 2       |
| 3.1.3.1           | Scratches                 | 2       |
| 3.1.3.2           | Cracks                    | 4       |
| 3.1.4             | Replacement               | 4       |
| 3.1.4.1           | Removal                   | 4       |
| 3.1.4.2           | Installation              | 4       |
| 3.2               | Cabin Doors               | 5       |
| 3.2.1             | Removal and Installation  | 5       |
| 3.2.2             | Cabin Door Latches        | 5       |
| 3.2.3             | Lock                      | 5       |
| 3.2.3.1           | Removal and Installation  | 5       |
| 3.3               | Seats                     | 10      |
| 3.3.1             | Description               | 10      |
| 3.3.2             | Upholstery                | 10      |
| 3.4               | Baggage Compartment       | 10      |
| 3.5               | Safety Provisions         | 10      |
| 3.5.1             | Safety Belts              | 10      |
| 3.5.2             | Ballistic Recovery System | 10      |
| 3.5.2.1           | Description               | 10      |
| 3.5.3             | Baggage Pocket Nets       | 10      |
| 3.6               | Bill of Materials         | 11      |

### **3.1 Windshield and Windows**

#### **3.1.1 Description**

The windshield and windows are single-piece acrylic plastic panels glued to the fuselage and sealed with a silicone bead around, to achieve the best possible aerodynamics and eliminate wind noises as much as possible.

#### **3.1.2 Waxing**

- **Required Tools:** Fine-grade wax, batting
- **Required Parts:** None
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

Waxing will fill in minor scratches in clear plastic and help protect the surface from further abrasion. Use a good grade of commercial wax applied in a thin, even coat. Bring wax to a high polish by rubbing lightly with a clean, dry flannel cloth.

#### **3.1.3 Repairs**

Damaged window panels and windshield may be removed and replaced if damage is extensive. However, certain repairs as prescribed in the following paragraphs can be made successfully without removing the damaged part from aircraft. Three types of temporary repairs for cracked plastic are possible. No repairs of any kind are recommended on highly-stressed or compound curves where repair would be likely to affect pilot's field of vision. Curved areas are more difficult to repair than flat areas and any repaired area is both structurally and optically inferior to the original surface.

##### **3.1.3.1 Scratches**

- **Required Tools:** Sandpaper, rubber pad, buffing compound, batting, automobile body cleaner or fine-grade wax
- **Required Parts:** None
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

Scratches on clear plastic surfaces can be removed by hand-sanding operations followed by buffing and polishing, if steps below are followed carefully.

- a. Wrap a piece of No. 3000 (or finer) sandpaper or abrasive cloth around a rubber pad or wood block. Rub surface around scratch with a circular motion, keeping abrasive constantly wet with clean water to prevent scratching surface further. Use minimum pressure and cover an area large enough to prevent formation of "Bull's eyes" or other optical distortions.
- b. Continue sanding operation, using progressively finer grade abrasives until scratches disappear. Do not skip one grade of abrasive!
- c. When scratches have been removed, wash area thoroughly with clean water to remove all gritty particles. The entire sanded area will be clouded with minute scratches which must be removed to restore transparency.
- d. Apply first tallow or buffering compound to a motor-driven buffing wheel. Hold wheel against plastic surface, moving it constantly over damaged area until cloudy appearance disappears. A 2000-feet-per-minute surface speed is recommended to prevent overheating and distortion. (Example: 750 rpm polishing machine with a 10 inch buffing bonnet.)
- e. When buffing is finished, wash area thoroughly and dry with a soft flannel cloth. Allow surface to cool and inspect area to determine if full transparency has been restored. Apply a thin coat of hard wax and polish surface lightly with a clean flannel cloth.
- f. Minute hairline scratches can often be removed by rubbing with commercial automobile body cleaner or fine-grade rubbing compound. Apply with a soft clean, dry cloth or imitation chamois.

**■ CAUTION**

Do not use a coarse grade of abrasive. No. 3000 is of maximum coarseness.

**◆ NOTE**

Polishing can be accomplished by hand but will require a considerably longer period of time to attain the same result as produced by a buffing wheel.

**◆ NOTE**

Rubbing plastic surface with a dry cloth will build up an electrostatic charge which attracts dirt particles and may eventually cause scratching of surface. After wax has hardened, dissipate this charge by rubbing surface with a slightly damp chamois. This will also remove dust particles which have collected while wax is hardening.

### 3.1.3.2 Cracks

- **Required Tools:** 1/8" drill, aircraft dope
  - **Required Parts:** Rubber sheet, fabric, wood strips, bolts and nuts
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- 
- a. When a crack appears, drill a hole at end of crack to prevent further spreading. Hole should be approximately 1/8 inch in diameter, depending on length of crack and thickness of material.
  - b. Temporary repairs to flat surfaces can be accomplished by placing a thin strip of wood over each side of surface and inserting small bolts through wood and plastic. A cushion of sheet rubber or aircraft fabric should be placed between wood and plastic on both sides.
  - c. A temporary repair can be made on a curved surface by placing fabric patches over affected areas. Secure patches with aircraft dope or lacquer thinner.

This type of repairs is used as a temporary measure ONLY, and as soon as facilities are available, panel should be replaced.

### 3.1.4 Replacement

#### 3.1.4.1 Removal

- **Required Tools:** Jig saw, crowbar, power drill, abrasive paper
  - **Required Parts:** None
  - **Level of Maintenance:** Heavy
  - **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center
- 
- a. Cut out the old window using a jig saw without causing damage to the fuselage.
  - b. Remove the remaining border of the window by the use of a crowbar and sand of old glue to get a smooth joining surface at the fuselage or door shell.

#### 3.1.4.2 Installation

- **Required Tools:** Standard metric tools, REMOS-Weld adhesive
  - **Required Parts:** Window as required
  - **Level of Maintenance:** Heavy
  - **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center
- 
- a. Sand the faying surface of window and fuselage, using abrasive paper of 320 grain size.
  - b. Clean the window opening on the fuselage (about 2 inch width) with appropriate solvent.
  - c. Apply REMOS-Weld adhesive to the joining surfaces of fuselage/door shell.
  - d. Tap the window to the fuselage opening and wipe away excessive glue, while smoothing the gap between window and fuselage/door shell. Let the glue cure for 24 hours at 65° F.

## 3.2 Cabin Doors

### 3.2.1 Removal and Installation

To remove cabin doors unlock and open the doors, unplug the support gas struts from the door bracket. Do not unplug the gas struts while doors are not in fully open position. Withdraw safety pin from both hinges on top of the doors. Installation is carried out in reverse order.

### 3.2.2 Cabin Door Latches

The cabin door latch contains three locking bolts operated by a rotary door handle (inside and outside each door). Rotating the handle forward will lock while spinning backward will unlock the doors. It is no adjustment, lubrication or servicing required to the latch system.

### 3.2.3 Lock

#### 3.2.3.1 Removal and Installation

- **Required Tools:** Standard metric tools
- **Required Parts:** Door handle decal set, Loctite 243 (medium strength)
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

In addition, a cylinder and key type lock is installed in both outside door handles. The procedure to replace the lock is given in the following listing (refer to figure 3-2):


- a. Remove inside bezel (6) and door trim panel (5).
- b. Remove decals (9) from door handle (7) to get access to its retaining screws (8)
- c. Remove door handle (7)
- d. Refer to figure 3-3 and proceed with the following steps:
- e. Disconnect control rod (8).
- f. Unscrew complete door lock assembly (12) from outer door shell by removing its four fixing screws (11).
- g. Remove decals from outer door handle (16).
- h. Remove outer door handle by unscrewing its four retaining screws (9).
- i. Remove lock (14) and remember position for re-installation.
- j. Assemble in reverse order.

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Use Loctite type 243 to secure retaining screws when installing a new key lock. |
|---------------|---|

In figure 3-3 to 3-4 detailed instructions are provided, if further servicing or replacement of components is required to the door lock system.



Figure 3-1



◆ NOTE

There are two different versions of some parts (1, 3, 6, 7, 8) given in the upper picture. Please tell our service center your preferred color (silver/blue anodized) in case of purchase.

Figure 3-2




Figure 3-3




Figure 3-4





Figure 3-5



### **3.3 Seats**

#### **3.3.1 Description**

The standard pilot and co-pilot seat is made from one-piece carbon fiber monocoque, equipped with a 3 position fore and aft adjustment. Seat adjustment is not possible while seated.

#### **3.3.2 Upholstery**

Due to the wide selection of fabrics, styles and colors, it is impossible to depict each particular type of upholstery. Major work, if possible, should be accomplished by an experienced mechanic.

Materials and tools will vary with job. Scissors for trimming upholstery to size and a dull-bladed putty knife are the only tools required for most trim work. Use industrial rubber cement to hold mats and fabric edges in place.

### **3.4 Baggage Compartment**

The baggage compartment is located behind the pilot seat. It is a one-piece carbon fiber container, held in place by 2 screws located on it's face plate and one screw at the inside bottom. After removing these screws the baggage compartment can be withdrawn from the bulkhead.

### **3.5 Safety Provisions**

#### **3.5.1 Safety Belts**

4-point safety belts are installed for pilot and co-pilot seat to provide maximum safety. Safety belts are tied to latches screwed to the cabin structure. Belts should be replaced if frayed or cut, latches are defective or stitching is broken. Attaching parts should be replaced if excessively worn or defective.

#### **3.5.2 Ballistic Recovery System**

##### **3.5.2.1 Description**

The REMOS GX is prepared for the installation of a MAGNUM parachute rescue system. Description and installation is included in the parachute installation manual G3-8 RE RS 080, available on request at REMOS AG.

#### **3.5.3 Baggage Pocket Nets**

- **Required Tools:** Standard metric tools
- **Required Parts:** Pocket nets
- **Level of Maintenance:** Heavy
- **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center

Behind each seat, a mold for lightweight baggage is provided covered by a pocket net. The maximum weight capacity must not exceed 5 lb each. Nets should be replaced when frayed or cut or frame is broken.

## 3.6 Bill of Materials

| Fig. No. | Item No. | Order No. | Part No.         | Qty. per Assy | Description  | Appl. S/N |
|----------|----------|-----------|------------------|---------------|--|-----------|
| 3-1      | 1        | 700437    | G3-8 FU-11-10-00 | 1             | Ventilation Window Assy blue anodized                      | Till 304  |
|          | 1        | 700437    | G3-8 FU-11-10-00 | 1             | Ventilation Window Assy colorless anodized                 | 304 ff    |
|          | 2        | 100343    |                  | 1             | Straight Pin 3x20 DIN 6325                                 | All       |
|          | 3        | 100518    | G3-8 FU-11-10-01 | 1             | Ventilation Lever blue anodized                            | Till 304  |
|          | 3        | 100518    | G3-8 FU-11-10-01 | 1             | Ventilation Lever colorless anodized                       | 304 ff    |
|          | 4        | 101039    |                  | 1             | Spiral Spring 17x2,64x0,5                                  | All       |
|          | 5        | 102537    |                  | 2             | Dowel Pin 3x10 DIN 7346                                    | All       |
|          | 6        | 100519    | G3-8 FU-11-10-02 | 1             | Ventilation Handle blue anodized                           | Till 304  |
|          | 6        | 100519    | G3-8 FU-11-10-02 | 1             | Ventilation Handle colorless anodized                      | 304 ff    |
|          | 7        | 100517    | G3-8 FU-11-10-03 | 1             | Ventilation Hub blue anodized                              | Till 304  |
|          | 7        | 100517    | G3-8 FU-11-10-03 | 1             | Ventilation Hub colorless anodized                         | 304 ff    |
|          | 8        | 100520    | G3-8 FU-11-10-06 | 1             | Ventilation Face Plate blue anodized                       | Till 304  |
|          | 8        | 100520    | G3-8 FU-11-10-06 | 1             | Ventilation Face Plate colorless anodized                  | 304 ff    |
|          | 9        | 100104    |                  | 2             | Countersunk Head Hexagon Socket Screw M3x10 vz DIN 7991    | All       |
|          | 10       | 102275    |                  | 2             | Truss Head Hexagon Socket Screw M3x10 ISO 7380 A2          | All       |
| 3-2      | 1        | 100511    | G3-8 FU-11-30-07 | 1             | Fuselage Door Panel Inside                                 | All       |
|          | 2        | 100188    |                  | 4             | Lens Head Hexagon Socket Screw M4x12                       | All       |
|          | 3        |           | G3-8 FU-11-10-05 | 1             |  | All       |
| 3-3      | 1        | 100103    |                  | 2             | Countersunk Head Hexagon Socket Screw M3x8 vz DIN 7991     | All       |
|          | 2        | 100508    | G3-8 FU-11-30-04 | 1             | Fuselage Door Handle LH Inside                             | All       |
|          |          | 100510    | G3-8 FU-11-30-05 | 1             | Fuselage Door Handle RH Inside                             | All       |
| 3-4      | 1        | 100101    |                  | 4             | Countersunk Head Hexagon Socket Screw M3x10 vz DIN 7991    | All       |
|          | 2        | 100507    | G3-8 FU-11-30-02 | 1             | Fuselage Door Handle LH Outside                            | All       |
|          |          | 100509    | G3-8 FU-11-30-03 | 1             | Fuselage Door Handle RH Outside                            | All       |
|          | 3        | 100102    |                  | 4             | Cylinder Head Hexagon Socket Screw M3x8 vz DIN912 8.8      | All       |
|          | 4        | 100514    |                  | 1             | Lock   | All       |
|          | 5        | 100113    |                  | 4             | Cylinder Head Hexagon Socket Screw M4x16 vz DIN912 8.8     | All       |
|          | 6        | 100233    |                  | 4             | Washer 4,3 DIN125 FormA Steel vz                           | All       |
|          | 7        | 100123    |                  | 1             | Countersunk Head Hexagon Socket Screw M4x12 vz DIN7991 8.8 | All       |
|          | 8        | 100504    | G3-8 FU-11-20-14 | 1             | Door Lock Bearing Bush                                     | All       |
|          | 9        | 100503    | G3-8 FU-11-20-10 | 1             | Door Lock Bell Crank                                       | All       |
|          | 10       | 100212    |                  | 1             | Self-locking Hexagon Nut M4 DIN985 vz                      | All       |
|          | 11       | 100233    |                  | 1             | Washer 4,3 DIN125 FormA Steel                              | All       |



| Fig. No. | Item No. | Order No. | Part No.         | Qty. per Assy | Description  | Appl. S/N |
|----------|----------|-----------|------------------|---------------|--|-----------|
| 3-5      | 1        | 100500    | G3-8 FU-11-20-11 | 1             | Door Lock Distance Bush Arrestor                           | All       |
|          | 2        | 100122    |                  | 3             | Cylinder Head Hexagon Socket Screw M4x8 vz DIN912 8.8      | All       |
|          | 3        | 100213    |                  | 1             | Hexagon Nut M4 DIN934                                      | All       |
|          | 4        | 101038    |                  | 1             | Tension Spring   | All       |
|          | 5        | 100233    |                  | 5             | Washer 4,3 ISO 7091 vz                                     | All       |
|          | 6        | 100113    |                  | 1             | Cylinder Head Hexagon Socket Screw M4x16 vz DIN912 8.8     | All       |
|          | 7        | 100212    |                  | 2             | Self-locking Hexagon Nut M4 DIN985 vz                      | All       |
|          | 8        | 100512    | G3-8 FU-11-20-08 | 1             | Door Lock Safety Catch                                     | All       |
|          | 9        | 100148    |                  | 1             | Cylinder Head Hexagon Socket Screw M6x10 vz DIN912 8.8     | All       |
|          | 10       | 100253    |                  | 1             | Washer M6 DIN 552 6,4x18x1,5                               | All       |
|          | 11       | 100266    |                  | 1             | Spring Washer 6,4 DIN 137 vz                               | All       |
|          | 12       | 101037    |                  | 1             | O-Ring 10x2  |           |
|          | 13       | 102092    |                  | 1             | Washer M10 ISO 7093 vz                                     |           |
|          | 14       | 100103    |                  | 2             | Countersunk Head Hexagon Socket Screw M3x8 vz DIN 7991     |           |
|          | 15       | 100505    | G3-8 FU-11-20-12 | 2             | Door Lock Distance Bush Handle Inside                      |           |
|          | 16       | 100498    | G3-8 FU-11-20-06 | 1             | Door Lock Central Plate                                    |           |
|          | 17       | 100499    | G3-8 FU-11-20-15 | 1             | Door Lock Master Bush                                      |           |
|          | 18       | 100211    |                  | 2             | Self-locking Hexagon Nut M3 DIN985 vz                      |           |
|          | 19       | 100123    |                  | 1             | Countersunk Head Hexagon Socket Screw M4x12 vz DIN7991 8.8 |           |
|          | 20       | 100504    | G3-8 FU-11-20-14 | 1             | Door Lock Bearing Bush                                     |           |
|          | 21       | 100513    | G3-8 FU-11-20-13 | 1             | Door Lock Bushing  |           |
|          | 22       | 100497    | G3-8 FU-11-20-07 | 1             | Door Lock Mount  |           |
|          | 23       | 100101    |                  | 4             | Countersunk Head Hexagon Socket Screw M3x10 vz DIN 7991    |           |

## Section 4

### *Wings and Empennage*

| <b>Table of Contents</b> | <b>Section</b>                      |
|--------------------------|-------------------------------------|
| 4.1                      | Wings..... 4-2                      |
| 4.1.1                    | Description..... 4-2                |
| 4.1.2                    | Installation..... 4-2               |
| 4.2                      | Wing Struts ..... 4-5               |
| 4.2.1                    | Description..... 4-5                |
| 4.2.2                    | Removal and Installation ..... 4-5  |
| 4.3                      | Horizontal Stabilizer..... 4-7      |
| 4.3.1                    | Description..... 4-7                |
| 4.3.2                    | Removal and Installation ..... 4-7  |
| 4.4                      | Vertical Stabilizer ..... 4-8       |
| 4.4.1                    | Description..... 4-10               |
| 4.4.2                    | Removal and Installation ..... 4-11 |
| 4.5                      | Bill of Materials ..... 4-11        |



## 4.1 Wings

### 4.1.1 Description

Each all composite wing is a monocoque type, made from carbon fiber sandwich components. Each wing contains one main spar and suitable ribs for the attachment of the skin. The outer skin consists of a carbon fiber sandwich construction all over. Each wing assembly provides full composite ailerons and flaps constructed from carbon fiber sandwich materials. A colored navigation light is installed to each removable carbon fiber wing tip. The right wing is containing a landing light system installed to the mean section of the leading edge.

Both wings provide a special mechanism to fold them back for storing or transportation of the aircraft. Refer to the REMOS GX Pilot Operating Handbook, for instructions about folding and re-installing wings.

### 4.1.2 Installation

- **Tools required:** Standard metric tools
- **Parts required:** Refer to figure 4-1
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

Wing installation in general has to be carried out in reverse order to removal but we strongly recommend to read the following instructions prior to start installation:


|                  |  |
|------------------|--|
| <b>▲ WARNING</b> | Insecurely connected, improper operation of control surfaces or insecurely locked fasteners will lead to loss of control of the aircraft!! |
|------------------|--|

#### 4.1.2.1 Installing Strut to Fuselage

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | All struts are providing a "Top" marking, which has to point upward when installed, while leading edge (rounded edge) has to point forward. |
|---------------|---|

Connect wing strut first to the fuselage and support as suitable, so that no damage occurs to the attachment and strut bearing. In figure 4-1 the correct installation of the strut-fuselage connection is given. Take care that leading edge of the profiled wing strut is pointing forward. It may be helpful to apply a small amount of grease to both chamfered washer prior to installation. Take also care for the right orientation of those washers, otherwise the folding mechanism of the wings will not operate properly and damage to the strut could be caused

Figure 4-1



## CAUTION

Watch for the correct installation of the cone washers (2) as shown in illustration 4-1. Damage to the struts may occur and folding of the wings will not be possible if those washers are installed in a wrong way! Tighten castle nut (3) hand tight and secure with a new cotter pin.

### 4.1.2.2 Installing Wing to Fuselage

To install the wing to the fuselage at least two persons are required!

- Insert the plastic ball into the guide cage at the wing root (left and right ball joints are different; each plastic ball provides a marking matching with the appropriate bracket at the fuselage).
- Hold wing in a position to be aligned with the fuselage, leading edge pointing to the ground (wing root pointing forward), so that ball bearing guide cage and ball bracket at the fuselage are side by side.
- Apply the plastic ball into the guide cage at the wing root, so that it is possible to push it over the bracket at the fuselage and insert its fixation screw. Do not overtighten this screw. While doing so a second person has to support the wing at the outboard end, so that no part of the wing skin will touch the fuselage.
- Now the wing outboard end can be moved forward slowly, make sure that the wing will not spin around its axis. If the wing has reached its forward position one person at the wing root has to spin it till the connection latches have aligned with the fuselage latches.

**Great care has to be taken, that no damage will occur to the wing surfaces during rigging of the wing by scratching on the fuselage sided wing fittings!**

- Take care that flap drive engages to the fuselage and apply pressure to the wing tip, so that the latches on the wing root and fuselage engage and the wing mainbolt could be pushed through its guide tube. Ensure that the wing mainbolt has engaged completely and secure it with a Fokker needle.


**◆ NOTE**

Support of the wing outboard end is required till the strut has been connected to the wing attachment.

**4.1.2.3 Connecting Strut to Wing**

Figure 4-2 is showing how to apply the connection bolts at the strut-wing attachment. It may be helpful for installation to apply grease to both chamfered washers prior to installation.

Figure 4-2

**■ CAUTION**

Watch for the correct installation of the cone washers (2) as shown in illustration 4-2. Damage to the struts may occur and folding of the wings will not be possible if those washers are installed in a wrong way! Tighten castle nut (3) hand tight and secure with a new cotter pin (5).

When removing or reassembling of the Eye Bearing Assy (7) is required, use Loctite 243 (medium strength) for installation and torque hand tight. Look to it that Eye Bearing Assy and Wing Strut fit together.

## 4.2 Wing Struts

### 4.2.1 Description

Each wing has a single lift strut. The strut itself is available in two different versions: Steel und CFRP. The steel strut consists of streamlined composite fairings riveted and glued to an inner steel tube with welded end fittings for attachment to the fuselage and wing brackets.

The CFRP strut is a one-piece, monocoque costume-made part of the wing and is half as heavy as the normal steel strut.

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | Installation and removal of the struts is always the same, no matter what kind of strut is used. |
|---------------|--|

### 4.2.2 Removal and Installation

Refer to the paragraph 4.1.2.1 and 4.1.2.3.

Figure 4-3





Figure 4-4



## 4.3 Horizontal Stabilizer

### 4.3.1 Description

The horizontal stabilizer is primarily of all composite monocoque construction, consisting of outer shell and ribs, no spar is included. Hinges are located on the trailing edge to support the elevator.

### 4.3.2 Removal and Installation

- **Required Tools:** REMOS Bolt-Removal Tool (recommended)
- **Required Parts:** None
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

Removal and installation of the stabilizer is quite easy, but needs two persons to perform:

- a. Remove the tail cover.
- b. Disconnect the trim actuator connector.
- c. Disconnect the elevator control rod by opening the quick-release connector (push button and slide back the securing tube).
- d. Support stabilizer by a second person.
- e. Withdraw Fokker-needle and remove both stabilizer bolts to the left.
- f. Remove stabilizer.
- g. Install horizontal stabilizer by reversing preceding steps and check operation of trim system.

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | Stabilizer bolts are different in length, therefore each bolt provide a marking for installation: "V" means front bolt, "H" means rear bolt. |
|---------------|--|

|                  |  |
|------------------|--|
| <b>■ CAUTION</b> | Ensure that both Fokker needles are engaged to the stabilizer bolts. |
|------------------|--|

Figure 4-5




Figure 4-6





Figure 4-7





## 4.4 Vertical Stabilizer

### 4.4.1 Description

The vertical stabilizer is part of the fuselage structure.

Figure 4-8




Figure 4-9



## 4.4.2 Removal and Installation

- **Required Tools:** Standard metric tools, edge cutter
  - **Required Parts:** Safety wire (1.0 mm)
  - **Level of Maintenance:** Heavy
  - **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center
- 
- a. Disconnect tail navigation light quick-disconnect (Only if equipped with tail navigation light).
  - b. Relieve cable tension at cable tensioner (Figure 10-3).
  - c. Disconnect cables from rudder.
  - d. Remove lower hinge bolt and slide rudder upward to disengage upper hinge bolt.
  - e. Reverse preceding steps for installation.
  - f. Rig system in accordance with applicable paragraph in this section and safety clevises, secure hinge bolt by wire.

## 4.5 Bill of Materials

| Fig. No. | Item No. | Order No. | Part No.         | Qty. per Assy | Description                                      | Appl. S/N |
|----------|----------|-----------|------------------|---------------|--|-----------|
| 4-1      | 1        | 100831    | G3-8_ST-01-00-13 | 1             | Fit-Bolt M8x10x34                                |           |
|          | 2        | 100832    | G3-8_ST-01-00-14 | 4             | Cone-Washer Wing Strut                           |           |
|          | 3        | 100383    |                  | 2             | Flat Castle Nut M8 DIN 979 A4                    |           |
|          | 4        | 102968    |                  | 2             | Washer 8x14x1 DIN 988 A2                         |           |
|          | 5        | 103106    |                  | 2             | Cotter Pin 2x20 DIN94 A4                         |           |
|          | 6        | 101720    | G3-8_ST-01-00-25 | 1             | Wingstrut Cover 43x1                             |           |
|          | 7        | 100612    | G3-8_FU-06-00-00 | 1             | Assembly Fuselage Strut Bracket left             |           |
|          |          | 100614    | G3-8_FU-06-00-01 | 1             | Assembly Fuselage Strut Bracket right            |           |
|          | 8        | 101893    |                  | 4             | Blind Rivet Truss Head 4x8 St/St A2K             |           |
| 4-2      | 1        | 100831    | G3-8_ST-01-00-13 | 1             | Fit-Bolt M8x10x34                                |           |
|          | 2        | 100832    | G3-8_ST-01-00-14 | 4             | Cone-Washer Wing Strut                           |           |
|          | 3        | 100383    |                  | 2             | Flat Castle Nut M8 DIN 979 A4                    |           |
|          | 4        | 102968    |                  | 2             | Washer 8x14x1 DIN 988 A2                         |           |
|          | 5        | 103106    |                  | 2             | Cotter Pin 2x20 DIN94 A4                         |           |
|          | 6        | 101720    | G3-8_ST-01-00-25 | 1             | Wingstrut Cover 43x1                             |           |
|          | 7        | 102192    | G3-8_WG-04-05-00 | 1             | Assy Wing Strut Swivel Bracket + Boltnut Spliced |           |
|          | 8        | 101893    |                  | 4             | Blind Rivet Truss Head 4x8 St/St A2K             |           |
| 4-3      | 1        | 100825    | G3-8_ST-00-00-04 | 1             | Wingstrut Weldment                               |           |
|          | 2        | 700438    | G3-8_ST-00-00-03 | 1             | Assy Wingstrut Left + Cover                      |           |
|          |          | 700440    |                  |               | Assy Wingstrut Right + Cover                     |           |
| 4-4      | 1        | 103392    | G3-8_ST-00-00-30 | 1             | Wingstrut CFRP                                   |           |
| 4-6      | 1        | 100568    | G3-8_HT-10-01-07 | 1             | Stabilizer Bearing-Bolt-Rearward-Short           |           |
|          | 2        | 100677    | G3-8_HT-10-01-05 | 2             | Stabilizer Hexnut-Bolt-Bearing                   |           |
|          | 3        | 102128    |                  | 2             | Washer 16x22x1 DIN 988 A2                        |           |
|          | 4        | 100674    | G3-8_HT-10-01-04 | 1             | Stabilizer Bolt-Bearing Short                    |           |
|          | 5        | 100675    | G3-8_HT-10-01-03 | 1             | Stabilizer Bolt-Bearing Long                     |           |
|          | 6        | 101064    |                  | 1             | Fokker Needle 35x1.5                             |           |
|          | 7        | 100567    | G3-8_HT-10-01-08 | 1             | Stabilizer Bearing-Bolt-Front-Long               |           |
| 4-7      | 1        | 100673    | G3-8_HT-10-01-00 | 1             | Bracket Stabilizer-Elevator                      |           |
|          | 2        | 101152    |                  | 1             | Socket 6x8 BB 0608 DP4                           |           |
|          | 3        | 102156    |                  | 2             | Lens Head Screw M5x16 ISO 7380 A2                |           |

## Section 5

### *Landing Gear and Brakes*

| <b>Table of Contents</b> | <b>Section</b>                                      |
|--------------------------|---|
| 5.1                      | Landing Gear, General Description ..... 3           |
| 5.1.1                    | Trouble Shooting ..... 3                            |
| 5.1.2                    | Composite Main Gear ..... 3                         |
| 5.1.2.1                  | Main Landing Gear Removal and Installation ..... 4  |
| 5.1.2.2                  | Main Wheel Removal ..... 5                          |
| 5.1.2.2.1                | Main Wheel Disassembly ..... 6                      |
| 5.1.2.2.2                | Main Wheel Inspection and Repair..... 8             |
| 5.1.2.2.3                | Main Wheel Reassembly ..... 9                       |
| 5.1.2.3                  | Main Wheel Installation ..... 9                     |
| 5.1.3                    | Steel Main Gear ..... 11                            |
| 5.1.3.1                  | Main Landing Gear Removal and Installation ..... 11 |
| 5.1.3.2                  | Main Landing Gear Disassembly..... 12               |
| 5.1.3.3                  | Main Landing Gear Reassembly ..... 15               |
| 5.1.3.3.1                | Main Wheel Disassembly ..... 17                     |
| 5.1.3.4                  | Main Wheel Installation ..... 18                    |
| 5.1.4                    | Nose Gear, General Description ..... 19             |
| 5.1.4.1                  | Removal and Installation ..... 20                   |
| 5.1.4.2                  | Nose Wheel Removal and Installation..... 21         |
| 5.1.4.2.1                | Disassembly ..... 22                                |
| 5.1.4.2.2                | Inspection ..... 23                                 |
| 5.1.4.2.3                | Reassembly ..... 24                                 |
| 5.1.4.3                  | Wheel Fork Removal and Installation..... 24         |
| 5.1.4.4                  | Spring Assembly Removal and Installation ..... 25   |
| 5.1.4.5                  | Nose Wheel Steering System..... 26                  |
| 5.1.4.5.1                | Steering Adjustment ..... 26                        |
| 5.1.4.6                  | Wheel Balancing..... 27                             |
| 5.2                      | Brake System, General Description ..... 27          |
| 5.2.1                    | Trouble Shooting ..... 28                           |
| 5.2.2                    | Brake Master Cylinder ..... 28                      |
| 5.2.2.1                  | Removal and Installation ..... 29                   |
| 5.2.2.2                  | Inspection ..... 30                                 |

|         |  |    |
|---------|--|----|
| 5.2.3   | Hydraulic Brake Hoses .....                      | 30 |
| 5.2.4   | Wheel Brake Assemblies.....                      | 30 |
| 5.2.4.1 | Removal.....                                     | 31 |
| 5.2.4.2 | Inspection .....                                 | 31 |
| 5.2.4.3 | Reassembly .....                                 | 32 |
| 5.2.4.4 | Installation.....                                | 32 |
| 5.2.4.5 | Check Brake Lining Wear.....                     | 32 |
| 5.2.4.6 | Brake Pad Installation.....                      | 33 |
| 5.2.5   | Brake System Bleeding .....                      | 34 |
| 5.2.6   | Parking Brake System (refer to figure 5-25)..... | 34 |
| 5.3     | Bill of Materials .....                          | 35 |

---

### 5.1 Landing Gear, General Description

Either a hollow composite main landing gear or steel spring struts may be installed on all REMOS GX aircraft. The brake system is attached to the wheel by a separate torque plate. Wheels with disc-type brakes and tube-type tires are installed.

All models are equipped with steerable nose gear. The nose gear provides shock absorbing rubber elements. The nose wheel is steerable with the rudder pedals up to a maximum pedal deflection. Nose and main wheel speed fairings may be used as desired. With the composite main gear, wheel pants are a non detachable part of the system.

Figure 5-1



#### 5.1.1 Trouble Shooting

| Trouble                                | Probable Cause           | Remedy  |
|--|--------------------------|---|
| Aircraft leans to one side             | Incorrect tire inflation | Inflate to pressure specified in figure 1-1.  |
|  | Swingarm broken          | Exchange swingarm                             |
| Tires wears excessively                | Incorrect tire inflation | Inflate to pressure specified in figure 1-1.  |
|  | Dragging brakes          | Refer to paragraph 5.2.2.                     |
|  | Wheel bearing damaged    | Install new part (s)                          |
|  | Wheels out of balance    | Correct in accordance with paragraph 5.1.3.3. |
| Wheel bounce evident on smooth surface | Out of balance condition | Correct in accordance with paragraph 5.1.3.3. |

#### 5.1.2 Composite Main Gear

Figure 5-1 illustrates the composite main landing gear. The illustrations should be used in conjunction with the following procedures during removal and installation of component parts. Disassembly, inspection and repair, and reassembly of the main wheel configurations are described in separate paragraphs for each configuration. The webbed wheels are consisting of two aluminum flanges and a hub. The flanges are attached to the wheel hub by thru-bolts and nuts as shown in figure 5-5. During assembly of the main wheel the thru-bolt self locking nuts, shall be tightened evenly and torqued to the value specified in paragraph 5.1.2.2.3.

## 5.1.2.1 Main Landing Gear Removal and Installation


- **Required Tools:** Standard metric tools
- **Required Parts:** 2 x Self-Locking Nut M14x1.5
- **Level of Maintenance:** Heavy
- **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center

The following procedural steps remove the landing gear as a complete assembly. Refer to applicable paragraphs for removal of the individual components.

- a. Remove main gear fairing from the bottom of the fuselage.
- b. Remove pilot and copilot seat (refer to Section 3).
- c. Remove baggage compartment (refer to Section 3).
- d. Remove cable ties securing the brake line distributor to the fuselage (accessible when baggage compartment is removed).
- e. Drain hydraulic brake fluid from brake lines.
- f. Disconnect hydraulic brake line at the brake line distributor.
- g. Hoist or jack aircraft in accordance with Section 2.
- h. Remove both bolts attaching main gear to fuselage.
- i. Remove main gear assembly.

Installation of the main gear has to be carried out in reversed order to removal.

Figure 5-2



## 5.1.2.2 Main Wheel Removal

- **Required Tools:** Standard metric tools
- **Required Parts:** None
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

To remove main wheel follow steps from a to e, outlined in paragraph 5.1.2.1 and then proceed as described below (refer to figure 5-3):


- a. Hoist or jack aircraft in accordance with Section 2.
- b. Remove wheel axis from the wheel fairing.
- c. Withdraw main wheel assembly from the wheel fairing.
- d. Drain hydraulic brake fluid from brake line.
- e. Disconnect hydraulic brake line at the brake cylinder.

### ◆ NOTE

If tire, brake pads or brake disc have to be replaced, it is not necessary to drain and disconnect the brake line.



Figure 5-3



## 5.1.2.2.1 Main Wheel Disassembly

- **Required Tools:** Standard metric tools
  - **Required Parts:** None
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- 
- a. Unscrew brake disc and withdraw complete brake assembly from wheel hub.
  - b. Remove valve core and deflate tire. Break tire beads loose from wheel rims.
  - c. Remove thru-bolts and separate wheel halves, removing tire, tube, hub and torque plate.
  - d. Remove wheel bearings from wheel hub.

### ▲ WARNING

Injury can result from attempting to separate wheel halves with the tire inflated. Avoid damaging wheel flanges when breaking tire beads loose.

Figure 5-4




Figure 5-5




Figure 5-6


**◆ NOTE**

Figure 5-6 shows the school version of the main wheel. This wheel is only available for the metal main gear. Parts not listed in Figure 5-6 are the same as in Figure 5-5.

**5.1.2.2.2 Main Wheel Inspection and Repair**

- **Required Tools:** Standard metric tools
  - **Required Parts:** None
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- 
- a. Clean all metal parts in solvent and dry thoroughly.
  - b. Inspect wheel halves for cracks. Cracked wheel halves shall be discarded and new parts used. Sand out nicks, gouges, and corroded areas. When the protective coating has been removed, the area should be cleaned thoroughly, primed with zinc chromate and painted with aluminum lacquer.
  - c. If excessively warped or scored, or worn to a thickness of 0.130-inch, brake disc should be replaced with a new part. Sand smooth small nicks and scratches.
  - d. Carefully inspect bearings for damage and discoloration or noises when rotating.

## 5.1.2.2.3 Main Wheel Reassembly

- **Required Tools:** Standard metric tools
  - **Required Parts:** Loctite 243 (medium strength)
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- a. Insert wheel bearing to the wheel hub.
  - b. Insert thru-bolts through wheel hub, torque plate in the inner wheel half.
  - c. Position tire and tube on outboard wheel half with the tube inflation valve through hole in wheel half.
  - d. Place the outboard wheel half to position on inboard wheel half. Apply a light force to bring wheel halves together.
  - e. While maintaining a light force on the wheel halves assemble a washer and a nut on one thru-bolt and tighten snugly.
  - f. Assemble the remaining washers on the thru-bolts and torque to 88 in. lb. (10 Nm), use Loctite 243 for securing.
  - g. Place brake assembly into the inboard wheel half and insert brake disc retaining screws and torque to 53 in. lb. (6 Nm), secure them additional by safety-wire.

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Brake assemblies of right and left side are different, When installed to the wheel, brake cylinder must be located behind wheel axle, while bleed valve is pointing downward. Refer to figure 5-3 and 5-4 and 5-5, 5-6 for a detailed illustration. |
|---------------|---|

|                  |   |
|------------------|---|
| <b>■ CAUTION</b> | Uneven or improper torque of thru-bolts can cause failure of bolts, with resultant wheel failure. |
|------------------|---|

## 5.1.2.3 Main Wheel Installation

- **Required Tools:** Standard metric tools,
- **Required Parts:** DOT 4 hydraulic fluid, tie wraps
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center


Main Wheel Installation is done in reverse order to removal. When installing wheel assembly to wheel fairing, ensure that the torque lever of the brake assembly has engaged to the retaining pivot located at the inboard side of the wheel fairing. Check thoroughly for sufficient space between brake line and tire. Refer to figure 5-7.

After completing installation, fill and bleed hydraulic lines and attach fuel hose distributor to its bracket inside the fuselage and secure with cable ties.

|               |   |
|---------------|---|
| ◆ <b>NOTE</b> | It may be helpful for bleeding all air off the hydraulic system, to lower the aircrafts tail. |
|---------------|---|

|                |  |
|----------------|--|
| <b>CAUTION</b> | Does not use aircraft brake fluid, doing so will cause damage to the cylinder seals. DOT 4 automobile brake fluid must be used only. |
|----------------|--|

Figure 5-7



### **5.1.3 Steel Main Gear**

Figure 5-18 illustrates the steel main landing gear. The illustrations should be used in conjunction with the following procedures during removal and installation of component parts. Disassembly, inspection and repair, and reassembly of the main wheel configurations are described in separate paragraphs for each configuration.

#### **5.1.3.1 Main Landing Gear Removal and Installation**


- **Required Tools:** Standard metric tools
- **Parts required:** 2 x Self-Locking Nut M14x1.5
- **Level of Maintenance:** Heavy
- **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center

The following procedural steps remove the landing gear as a complete assembly. Refer to applicable paragraphs for removal of the individual components.

- a. Unscrew main gear fairing from the bottom of the fuselage.
- b. Remove pilot and copilot seat (refer to Section 3).
- c. Remove baggage compartment (refer to Section 3).
- d. Remove cable ties securing the brake line distributor to the fuselage (accessible when baggage compartment is removed).
- e. Drain hydraulic brake fluid from brake lines.
- f. Disconnect hydraulic brake line at the brake hose distributor.
- g. Hoist or jack aircraft in accordance with Section 2.
- h. Remove both fixing bolts attaching main gear to fuselage.
- i. Remove main gear assembly.

Installation of the main gear has to be carried out in reversed order to removal.

Figure 5-8



### 5.1.3.2 Main Landing Gear Disassembly

- **Required Tools:** Standard metric tools
- **Required Parts:** None
- **Level of Maintenance:** Heavy
- **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center

Refer to figure 5-9 to 5-13 as illustrated guide to conduct the following procedure.

- a. Remove the wheel pants retaining screws from the fairing.
- b. Withdraw the fairing to the top.
- c. Loosen and remove wheel nut from wheel axle.
- d. Remove and discard securing washer from wheel axle.
- e. Unscrew brake disc from wheel assembly and/or disconnect brake hose from brake assembly (not applicable with the REMOS brake system installed).
- f. Withdraw brake assembly and brake disc from wheel hub.
- g. Remove the spring strut fixing screws at the center beam (see figure 5-11).
- h. Withdraw the complete strut assembly



- i. Remove the upper strut retaining screws and slide off the complete fairing
- j. For overhaul or exchange unscrew the strut fairing from the wheel hub cover.

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | Remember the position of the nyloc collar bush inside the fairing like illustrated in figure 5-9. Take care to relocate it when reassembling the fairing. Use Loctite 243 (medium strength) at all fairing retaining screws at reassembly. |
|---------------|--|

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | There are two ways to remove the wheel from the wheel axle, Version A and B are given in figure 5-10. |
|---------------|---|

Figure 5-9




Figure 5-10






Figure 5-11




Figure 5-12





Figure 5-13




### 5.1.3.3 Main Landing Gear Reassembly

- **Required Tools:** Standard metric tools, wire cutting pliers
- **Required Parts:** Loctite 243 (medium strength), ties wraps
- **Level of Maintenance:** Heavy
- **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center

Landing Gear reassembly is done in reverse order to disassembly. Refer to figure 5-8 to figure 5-12 for detailed information. In figure 5-14 important fastening torques and securing information are given to be followed up.

Figure 5-14



◆ NOTE

It is permissible to operate the aircraft without wheel fairings, intersection fairings landing gear fairings and/or fuselage belly fairings detached. It is strongly recommended to remove the intersection fairings when flying with the wheel fairings removed.

To have the wheel fairings attached the landing gear fairings, intersection fairings and fuselage belly fairings need to be installed.

## 5.1.3.3.1 Main Wheel Disassembly


- **Required Tools:** Standard metric tools,
- **Required Parts:** None
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

Refer to figure 5-15.

- a. Remove the wheel pant retaining screws from the fairing.
- b. Withdraw the fairing to the top.
- c. Loosen and remove wheel nut from wheel axle.
- d. Remove and discard securing washer from wheel axle.
- e. Withdraw brake assembly ,brake disc and wheel from wheel hub.

Take care that the brake disc and brake pads are clean and free from grease.

Figure 5-15



## 5.1.3.4 Main Wheel Installation

- **Required Tools:** Standard metric tools, wire cutting pliers, bleed kit
- **Required Parts:** DOT 4 hydraulic fluid, Loctite 243 (medium strength), Locking Plate 16x30 (Order Nr. 102322)
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center


Main Wheel Installation is done in reverse order to removal. When installing wheel assembly to wheel axle, ensure that the torque lever of the brake assembly has engaged to the torque bolt located at the anchor plate assembly. Check thoroughly for sufficient space between brake line and tire; refer to figure 5-16. Detailed information how to install the wheel fairing are given in figures 5-9, 5-10 & 5-14.

After completing installation, fill and bleed hydraulic lines.

### ■ CAUTION

Do not use aircraft brake fluid, doing so will cause damage to the cylinder seals. DOT 4 automobile brake fluid must be used only.

Figure 5-16




#### **5.1.4 Nose Gear, General Description**

The nose gear on the REMOS GX consists of a dip tube (nose gear strut), guided by three maintenance-free slide bearings which are hold by brackets laminated to the fuselage. Rubber spring elements are deferred over the dip tube which carries a wheel fork made from steel at its lower end.

The nose gear is controlled by the foot pedals and enables an effective steering of the aircraft when on the ground. Spring deflection provided is about 2.9 in (75 mm).

The composite nose landing gear is no longer available. To ensure operation of aircraft equipped with FRP nose landing gears the steel nose landing gear needs to be installed. A fairing for the steel nose landing gear (pos. 5 of fig. 5-17) with the look of the FRP nose landing gear is available.

Figure 5-17



## 5.1.4.1 Removal and Installation

- **Required Tools:** Standard metric tools
- **Parts required:** None
- **Level of Maintenance:** Heavy
- **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center

Refer to figure 5-18 as illustrated guide to conduct the following procedure.


- a. Remove engine cowling for access.
- b. Weight or tie-down tail of aircraft to raise nose wheel off the floor.
- c. Remove the fit bolt (7) from the sliding translator (6) inside the cabin.
- d. Remove both retaining screws on top of the nose gear strut (1).
- e. Withdraw nose gear strut from the bottom of the fuselage.

Installation of nose gear is done in reversed order to removal. Apply grease to the slider and strut prior to installation, this will ease the reassembly.

|        |   |
|--------|---|
| ◆ NOTE | Inside the nose gear strut a slider (5) is provided, after removing the fit bolt (7), this slider may fall down into the strut tube. Pick it up for reuse at installation of the nose gear. |
|--------|---|

|        |  |
|--------|--|
| ◆ NOTE | It may be helpful to slacken the rudder control wire tension, to ease withdrawing the strut of its slide bearings. |
|--------|--|

Figure 5-18



## 5.1.4.2 Nose Wheel Removal and Installation

- **Required Tools:** Standard metric tools
- **Required Parts:** Securing washer
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center


Refer to figure 5-19 as illustrated guide and follow the steps below.

- a. Remove the wheel fairing retaining screws and slide the fairing upward.
- b. Remove the wheel nut and withdraw the wheel axle.
- c. Remove the nose wheel assembly from the wheel fork.

Installation of the nose wheel is done in reversed order to removal. After installing the wheel axle, apply a new securing washer and torque wheel nut to 221 in.lb. (25 Nm).



Figure 5-19



◆ NOTE

It is permissible to operate the aircraft with the nose landing gear fairing detached.

## 5.1.4.2.1 Disassembly

- **Required Tools:** Standard metric tools
- **Required Parts:** None
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

Refer to figure 5-20 as illustrated guide and follow the steps below.

- Remove valve core and deflate tire. Break tire beads loose from wheel rims.
- Remove thru-bolts (1) and separate wheel halves, removing tire, tube and hub.
- Remove wheel bearings (4) from wheel hub (5).


**▲ WARNING**

Injury can result from attempting to separate wheel halves with the tire inflated. Avoid damaging wheel flanges when breaking tire beads loose. A scratch, gouge, or nick may cause wheel failure.

**◆ NOTE**

Watch for position of spacer sleeve (6).

Figure 5-20



### 5.1.4.2.2 Inspection

- **Required Tools:** Depending on condition
- **Required Parts:** None
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

- a. Clean all metal parts in solvent and dry thoroughly.
- b. Inspect wheel halves for cracks. Cracked wheel halves shall be discarded and new parts used. Sand out nicks, gouges, and corroded areas. When the protective coating has been removed, the area should be cleaned thoroughly, primed with zinc chromate and painted with aluminum lacquer.
- c. Carefully inspect bearings for damage and discoloration or noises when rotating. Do not try to re-lubricate the sealed bearings. If in doubt about bearing condition, replace bearings.

### 5.1.4.2.3 Reassembly

- **Required Tools:** Standard metric tools
- **Required Parts:** None
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

Refer to figure 5-20 as illustrated guide and follow the steps below.

- a. Insert wheel bearings (4) and spacer sleeve (6) to the wheel hub (5).
- b. Apply washers (2) to thru-bolts (1) and insert through wheel half (3) and wheel hub (5).
- c. Position tire and tube on wheel half with the tube inflation valve through hole in wheel half (3).
- d. Place one wheel half to position on other wheel half. Apply a light force to bring wheel halves together.
- e. While maintaining the light force assemble a washer and nut on one thru-bolt (1) and tighten snugly.
- f. Assemble the remaining washers and nuts on the thru-bolts (1) and torque to 88 in. lb. (10 Nm).

|                  |   |
|------------------|---|
| <b>■ CAUTION</b> | Uneven or improper torque of thru-bolt nuts can cause failure of bolts, with resultant wheel failure. |
|------------------|---|

### 5.1.4.3 Wheel Fork Removal and Installation

- **Required Tools** Standard metric tools
- **Required Parts:** Self-locking nuts
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center


Refer to figure 5-21 as illustrated guide and follow the steps below, assumed that the wheel fairing already has been removed.

- a. Remove thru-bolt (1) and clamping bolts (2)
- b. Withdraw wheel fork downward.

Installation of the wheel fork is done in reversed order to removal. Use new self-locking nuts for thru-bolt and clamping bolts and torque to 53 in.lb. (6 Nm).

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Remember position of wheel fairing bracket (4), if installed. |
|---------------|---|

Figure 5-21




#### 5.1.4.4 Spring Assembly Removal and Installation

- **Required Tools:** Standard metric tools
- **Required Parts:** None
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

Refer to figure 5-22 as illustrated guide, assumed that the wheel fork already has been removed, as described in previous paragraph.

Figure 5-22



#### **5.1.4.5 Nose Wheel Steering System**

Nose wheel steering is accomplished through the use of the rudder pedals. Steering rod assemblies connect the nose gear steering.

##### **5.1.4.5.1 Steering Adjustment**

- **Required Tools:** Standard metric tools
- **Required Parts:** Self-locking nuts
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

Since the nose wheel steering and rudder system are interconnected, adjustment to one system may affect the other system. Section 10 of this manual contains rigging instructions for the rudder system. Follow the instructions below for adjusting the nose gear with the rudder pedals.

In figure 5-23 the interconnection between nose gear and rudder pedals is shown (to be omitted the nose gear assembly and fuselage structure).


Refer to figure 5-23 as illustrated guide and follow the steps below.

- a. Loosen the locking screws (1) on both control rods (2).
- b. Align rudder pedals (5) with nose gear wheel (not illustrated).
- c. Tighten locking screws (1) and torque to 53 in. lb. (6 Nm).

**CAUTION**

Doing so may have an effect on the rudder surface alignment, requiring adjustment of the rudder control wires (4). Refer to Section 10 in this manual for rigging instructions of the rudder system.

Figure 5-23



#### **5.1.4.6 Wheel Balancing**


Since uneven tire wear is usually the cause of wheel unbalance, replacing the tire probably will correct this condition. Tire and tube manufacturing tolerances permit a certain amount of static unbalance. If a wheel shows evidence of unbalance during service, it may be statically balanced.

### **5.2 Brake System, General Description**

The hydraulic brake system consists of a master cylinder including reservoir, located between both seats. A brake hose connects the master cylinder to a distributor, located behind the cabin bulkhead. Two brake hoses run from the distributor to each wheel brake cylinder.

An illustrated overview is given in figure 5-24.

Figure 5-24



## 5.2.1 Trouble Shooting

| Trouble                | Probable Cause   | Remedy   |
|------------------------|--|--|
| Dragging Brakes        | Brake lever binding.   | Check and adjust properly.   |
|                        | Worn or broken return spring (in master cylinder).                       | Install a new cylinder.  |
|                        | Restrictions in hydraulic lines or restriction in master cylinder valve. | Drain brake lines and clean inside of the brake line with filtered compressed air. |
|                        | Worn, scored or warped brake disc.                                       | Install new disc and brake linings.  |
|                        | Damaged or accumulated dirt restricting free movement of brake parts.    | Clean and repair or install new parts as necessary.                                |
| Brakes Fail to Operate | Leak in system.  | Install new parts.   |
|                        | Air in system.   | Bleed system.  |
|                        | Lack of fluid in master cylinder.  | Fill and bleed system.   |
|                        | Master cylinder defective.   | Install a new cylinder.  |

## 5.2.2 Brake Master Cylinder


The brake master cylinder, located between seats, is actuated by applying pressure at the top of the brake lever. A small reservoir is incorporated onto the master cylinder for the fluid supply.

In figure 5-25 a detailed illustration of the brake master cylinder assembly is given, to provide a reference for identifying each of the components used.

### CAUTION

Do NOT use aircraft brake fluid because this will damage the sealings of the brake cylinder. The use of DOT 4 automotive brake fluid is permitted only!

Figure 5-25



## 5.2.2.1 Removal and Installation

- **Required Tools:** Standard metric and imperial tools, bleed kit
  - **Required Parts:** Loctite 243 (medium strength)
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center
- a. Remove bleeder screws at wheel brake assemblies and drain hydraulic fluid from brake cylinder.
  - b. Remove seats, parking brake valve lever, master cylinder filler cap and center panel cover for access to the brake master cylinder.
  - c. Disconnect brake line from master cylinder assembly and remove master cylinder from its bracket.
  - d. Unscrew parking brake valve and brake lever from master cylinder.
  - e. Reverse the preceding steps to install brake master cylinders, then fill and bleed brake system in accordance with paragraph 5.2.5.

### ◆ NOTE

Use Loctite 243 (medium strength) or similar for reassembling the thread cores to parking brake valve and brake master cylinder.



### 5.2.2.2 Inspection

The master cylinder is limited to cleaning; always install a new master cylinder if any defects are determined. Use automobile clean hydraulic fluid or new DOT 4 brake fluid.

**CAUTION**

Do not use aircraft hydraulic fluid because this will damage the master cylinder sealings.

### 5.2.3 Hydraulic Brake Hoses


All hydraulic hoses used for the brake system are flexible plastic hoses covered by a metal shielding. All hoses provide appropriate connectors to provide an easy replacement.

### 5.2.4 Wheel Brake Assemblies

The wheel brake assemblies use a disc which is attached to the main wheel with a torque plate fixed by the thru-bolts and a floating brake assembly.

In figure 5-26 the system and brake line connection is illustrated as a guide.

Figure 5-26



## 5.2.4.1 Removal

To remove brake system from the wheel, refer to paragraph 5.1.2.2 and 5.1.2.2.1. Drain hydraulic fluid from brake hoses prior to disconnecting the brake assembly.


After the brake assembly is disconnected you could remove disc and brake linings from the assembly.

## 5.2.4.2 Inspection

- **Required Tools:** Standard metric and imperial tools
  - **Required Parts:** None
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- 
- a. Clean all parts except brake linings and O-rings in dry cleaning solvent and dry thoroughly.
  - b. New O-rings are usually installed at each time they are removed. If O-ring reuse is necessary, they should be wiped with a clean cloth saturated in new automobile hydraulic fluid (DOT 4) and inspected for damage.
  - c. Check brake lining for deterioration and maximum permissible wear. See paragraph 5.2.4.5.
  - d. Inspect brake cylinder bore for scoring. A scored cylinder will leak or cause rapid O-ring wear. Install new break cylinder.
  - e. If the anchor bolts on the brake assembly are nicked or gouged, they shall be sanded smooth to prevent binding with the pressure plate or torque plate.
  - f. Inspect wheel brake disc for a minimum thickness of 0.135-inch. If brake disc is below minimum thickness, install a new part.

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Thorough cleaning is important. Dirt and chips are the greatest single cause of malfunctions in the hydraulic brake system. |
|---------------|---|

Figure 5-27



### 5.2.4.3 Reassembly

Lubricate parts with clean DOT 4 automobile hydraulic fluid and assemble components with clean automobile DOT 4 hydraulic fluid and assemble components with care to prevent damage to O-rings.

#### 5.2.4.4 Installation

Installation of wheel brake assembly is done in reversed order to removal, refer to paragraph 5.2.4.1.

#### 5.2.4.5 Check Brake Lining Wear

New brake lining should be installed when they are worn to a minimum thickness of 0.08 inch. Visually compare 3/32-inch strip of material held adjacent to each lining to measure the thickness of the lining.

## 5.2.4.6 Brake Pad Installation

- **Required Tools:** Standard metric tools, riveting tool
- **Required Parts:** Brake pads, rivets
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

Refer to figure 5-27 as illustrated guide and follow the steps below.

- a. Remove bolts (9) securing back plate (8) and remove back plate.
- b. Slide pressure plate (4) off anchor bolts/slide bearing sleeve (9)/(7).
- c. Place back plate (8) on a table with lining side down flat. Center a 3/32-inch (or slightly smaller) punch in the rolled rivet and hit the punch sharply with a hammer. Punch out all rivets (3)/(6) securing the linings (5) to the back plate (8) and pressure plate (4) in the same manner.
- d. Clamp the flat side of the anvil in a vise.
- e. Align new lining on back plate and place brake rivet in hole with rivet head in the lining. Place head against the anvil.
- f. Center the rivet setting punch on the lips of the rivet. While holding the back plate down firmly against the lining, hit punch with a hammer to set the rivet.
- g. Repeat blows on the punch with a hammer to set the rivet. Repeat blows on the punch until lining is firmly against back plate.
- h. Realign the lining on the back plate and install and set rivets in the remaining holes.
- i. Install a new lining on pressure plate in the same manner.
- j. Position pressure plate on anchor bolts and place cylinder in position so that anchor bolts slide into the torque plate.
- k. Install back plate with bolts and washers.

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | New rivets kit is provided with every brake lining set. |
|---------------|---|

## 5.2.5 Brake System Bleeding

- **Required Tools:** Standard imperial tools, bleed kit
- **Required Parts:** DOT 4 hydraulic brake fluid
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

Bleeding with a clean hydraulic pressure source connected to the wheel cylinder bleeder is recommended.

- a. Remove brake master cylinder filler plug and screw flexible hose with appropriate fitting into the filler hole at top of the master cylinder.
- b. Immerse the free end of the flexible hose in a container with enough hydraulic fluid to cover the end of the hose.
- c. Connect a clean hydraulic pressure source, such as a hydraulic hand pump or Hydro Fill unit, to the bleeder valve in the wheel cylinder.
- d. As fluid is pumped into the system, observe the immersed end of the hose at the master brake cylinder for evidence of air bubbles being forced from the brake system. When bubbling has ceased, remove bleeder source from wheel cylinder and tighten the bleeder valve.

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | Ensure that the free end of the hose from the master cylinder remains immersed during the entire bleeding process. |
|---------------|--|

|                  |  |
|------------------|--|
| <b>■ CAUTION</b> | Do not use aircraft brake fluid because this will damage the master cylinder sealings. DOT 4 automobile brake fluid must be used only. |
|------------------|--|

## 5.2.6 Parking Brake System (refer to figure 5-25)

The parking brake system consists of a control lever behind the master brake cylinder. To engage the parking brake, depress the brake lever and rotate the parking brake control lever to the right. To release the parking brake, rotate the control lever counter clockwise.

## 5.3 Bill of Materials

| Fig. No. | Item No. | Order No. | Part No.         | Qty. per Assy | Description                                     | Appl. S/N |
|----------|----------|-----------|------------------|---------------|---|-----------|
| 5-2      | 1        | 100591    | E4-52.01.00      | 1             | GRP Main gear                                   | -         |
|          | 2        | 700691    | G3-8 MG-10-00-01 | 2             | Main wheel Matco Pre-Assy                       | All       |
|          | 3        | 102008    | G3-8 MG-01-00-11 | 2             | Main gear Mainbolt GX                           | All       |
|          | 4        | 100532    | G3-8 MG-01-00-06 | 2             | Washer 15x23x1.7 Main gear Mainbolt             | All       |
|          | 5        | 102143    |                  | 2             | Self-locking hexagon nut M14x1,5 DIN985         | All       |
| 5-4      | 1        | 700691    | G3-8 MG-10-00-01 | 1             | Main wheel Matco Pre-Assy                       | All       |
|          | 2        | 103247    | G3-8 MG-10-01-00 | 1             | Brake Disc                                      | All       |
|          | 3        | 100600    | G3-8 MG-30-01-00 | 1             | Axle Shaft Matco Brake                          | All       |
| 5-5      | 1        | 100134    |                  | 3             | Allen Screw M5x12 DIN 912 8.8                   | All       |
|          | 2        | 100544    | G3-8 MG-10-30-01 | 3             | Brake disc-Adapter Matco                        | All       |
|          | 3        | 100345    |                  | 6             | Pin 3x12 DIN 6325                               | All       |
|          | 4        | 100112    |                  | 6             | Allen Screw M4x10 DIN 912 8.8                   | All       |
|          | 5        | 103247    | G3-8 MG-10-01-00 | 1             | Brake Disc                                      | All       |
|          | 6        | 101045    |                  | 1             | Ball Bearing 6004 2RS                           | All       |
|          | 7        | 100540    | G3-8 MG-10-10-04 | 1             | Wheel hub Main wheel                            | All       |
|          | 8        | 101044    |                  | 1             | Ball Bearing 6003 2RSH                          | All       |
|          | 9        | 100537    | G3-8 MG-10-10-01 | 1             | Torque Plate                                    | All       |
|          | 10       | 100539    | G3-8 MG-10-10-03 | 1             | Main wheel Inboard Wheel Half                   | All       |
|          | 11       | 100538    | G3-8 MG-10-10-02 | 1             | Main wheel Outboard Wheel Half (Hole for valve) | All       |
|          | 12       | 100231    |                  | 6             | Washer 6,4 DIN 125 Form A                       | All       |
|          | 13       | 100144    |                  | 6             | Allen Screw M6x20 DIN 912 8.8                   | All       |
|          | 14       | 102252    |                  | 1             | Tube Main wheel                                 | All       |
|          | 15       | 102251    |                  | 1             | Tire Main wheel                                 | All       |
| 5-6      | 1        | 102677    | G3-8 MG-10-10-05 | 1             | Main gear Mainwheel Wheel Adapter               | All       |
|          | 2        | 100154    |                  | 6             | Allen Screw M6x50 DIN 912 8.8                   | All       |
|          | 3        | 102689    |                  | 1             | Tube School Wheel 15x600-6                      | -         |
|          | 4        | 102690    |                  | 1             | Tire School Wheel 15x600-6                      | -         |
| 5-7      | 1        | 100531    | G3-8 MG-41-01-03 | 1             | Torquebolt GRP Main gear                        | All       |
|          | 2        | 100524    | G3-8 MG-01-00-03 | 1             | Washer 17x23x1.7 Wheel axle Main gear           | All       |
|          | 3        | 100523    | G3-8 MG-01-00-02 | 1             | Hex nut 16x1 Wheel axle Main gear               | All       |
|          | 4        | 100286    |                  | 1             | Cotter Pin 1.6x18 DIN 94 Steel vz               | All       |
|          | 5        | 100522    | G3-8 MG-01-00-01 | 1             | Wheel Axle GFRP Main gear                       | All       |
| 5-8      | 1        | 102008    | G3-8 MG-01-00-11 | 2             | Main gear Mainbolt GX                           | All       |
|          | 2        | 100532    | G3-8 MG-01-00-06 | 2             | Washer 15x23x1.7 Main gear Mainbolt             | All       |
|          | 3        | 102143    |                  | 2             | Self-locking hexagon nut M14x1,5 DIN985         | All       |
|          | 4        | 102304    | G3-8 MG-40-01-05 | 2             | Main gear Strut RF                              | All       |
|          | 5        | 102668    | G3-8 MG-40-02-23 | 1             | Main gear Wheel-Hub Cover left                  | All       |
| 5-8      | 6        | 102667    | G3-8 MG-40-02-21 | 1             | Main gear Wheel-Hub Cover right                 | All       |
|          |          | 102670    | G3-8 MG-40-02-22 | 1             | Main gear RF Wheel Fairing left                 | All       |
|          | 7        | 102669    | G3-8 MG-40-02-20 | 1             | Main gear RF Wheel Fairing right                | All       |
|          |          | 102672    | G3-8 MG-40-02-25 | 1             | Main gear RF Strut Fairing left                 | All       |
|          |          | 102671    | G3-8 MG-40-02-24 | 1             | Main gear RF Strut Fairing right                | All       |
|          | 8        | 102674    | G3-8 MG-40-02-29 | 1             | Main gear Fuselage Fairing left                 | All       |
|          |          | 102673    | G3-8 MG-40-02-28 | 1             | Main gear Fuselage Fairing right                | All       |
|          | 9        | 102302    | G3-8 MG-40-00-02 | 1             | Main gear Strut bracket Assy                    | All       |

| Fig. No. | Item No. | Order No. | Part No.         | Qty. per Assy | Description                                      | Appl. S/N |
|----------|----------|-----------|------------------|---------------|--|-----------|
| 5-9      | 1        | 100189    |                  | 6             | Lens Head Screw Hexagon Socket M4x12 ISO 7380 FL | All       |
|          | 2        | 102325    |                  | 5             | Lens Head Screw with Flange M6x12                | All       |
|          | 3        | 102332    |                  | 1             | Collar Bush 6x18x3.5                             | All       |
|          | 4        | 102331    |                  | 1             | Rubber Washer 11x18x1                            | All       |
|          | 5        | 102333    |                  | 1             | Nylon Washer 6x18x2                              | All       |
| 5-10     | 1        | 102322    |                  | 1             | Locking Plate 16x30 DIN462, A4                   | All       |
|          | 2        | 102358    |                  | 1             | Hex Nut M16x1.5, DIN936, A2K                     | All       |
| 5-11     | 1        | 102672    | G3-8 MG-40-02-25 | 1             | Main gear RF Strut Fairing left                  | All       |
|          |          | 102671    | G3-8 MG-40-02-24 | 1             | Main gear RF Strut Fairing right                 | All       |
|          | 2        | 102302    | G3-8 MG-40-00-02 | 1             | Main gear Strut bracket Assy                     | All       |
|          | 3        | 100224    |                  | 1             | Self-locking Hexagon Nut M8                      | All       |
|          | 4        | 100239    |                  | 2             | Washer 8.4 DIN126 Steel                          | All       |
|          | 5        | 102330    |                  | 1             | Allen Screw M8x40 DIN912 8.8                     | All       |
|          | 6        | 101880    |                  | 2             | Lock Washer M8                                   | All       |
|          | 7        | 102326    |                  | 2             | Cylinder Head Screw M8x60 DIN912 10.9 A2C        | All       |
| 5-12     | 1        | 100189    |                  | 6             | Lens Head Screw Hexagon Socket M4x12 ISO 7380 FL | All       |
|          | 2        | 102324    |                  | 4             | Lens Head Tapping Screw M3,9x13 Delta Seal       | All       |
|          | 3        | 102306    | G3-8 MG-40-01-13 | 1             | Main gear Bearing Strut-Fairing                  | All       |
| 5-13     | 1        | 102305    | G3-8 MG-40-01-00 | 1             | Main gear Wheel-Axle RF                          | All       |
|          | 2        | 102303    | G3-8 MG-40-00-01 | 1             | Main gear Ancorplate RF Assy                     | All       |
|          | 3        | 102304    | G3-8 MG-40-01-05 | 1             | Main gear Strut RF                               | All       |
|          | 4        | 100142    |                  | 4             | Allen Screw M5x10 DIN912 8.8                     | All       |
|          | 5        | 102155    |                  | 2             | Lens Head Screw Hexagon Socket M5x10 ISO7380 A2  | All       |
|          | 6        | 100232    |                  | 3             | Washer 5.3 DIN125 Form A Steel                   | All       |
|          | 7        | 102323    |                  | 2             | Speed Nut M5                                     | All       |
|          | 8        | 100945    |                  | 1             | Pipe Clamp B12mm D8mm                            | All       |
|          | 9        | 101880    |                  | 2             | Lock Washer M8                                   | All       |
|          | 10       | 102327    |                  | 2             | Allen Screw M8x50 DIN912 10.9                    | All       |
|          | 11       | 102647    | G3-8 MG-40-01-27 | 1             | Main gear Bracket FBV left                       | All       |
|          |          | 102648    | G3-8 MG-40-01-26 | 1             | Main gear Bracket FBV right                      | All       |
|          | 12       | 100129    |                  | 2             | Allen Screw M5x16 DIN912 8.8                     | All       |
| 5-15     | 1        | 700691    | G3-8 MG-10-00-01 | 1             | Main wheel Matco Pre-Assy                        | All       |
|          | 2        | 103247    | G3-8 MG-10-01-00 | 1             | Brake Disc                                       | All       |
|          | 3        | 100542    | G3-8 MG-30-01-01 | 1             | Axle Shaft Matco Brake                           | All       |
| 5-17     | 1        | 100690    | G3-8 CS-20-00-07 | 1             | Steering Arm Nose Wheel                          | All       |
|          | 2        | 100818    | G3-8 NG-01-00-00 | 1             | Nose Gear Dip Tube                               | All       |
|          | 3        | 700683    | G3-8 NG-10-00-00 | 1             | Spring Package Nose gear Assy                    | All       |
|          | 4        | 100824    | G3-8 NG-40-00-00 | 1             | Wheel fork Assy                                  | All       |
|          | 5        | 102666    | G3-8 NG-02-00-00 | 1             | Nose gear Wheel fairing RF                       | All       |
|          | 6        | 700612    | G3-9 NG-50-00-00 | 1             | Nose gear Nose wheel Complete                    | All       |
| 5-18     | 1        | 100129    |                  | 2             | Allen Screw M5x16 DIN912 8.8                     | All       |
|          | 2        | 100814    | G3-8 NG-01-00-06 | 1             | Nose gear Lockring Top                           | All       |
|          | 3        | 100218    |                  | 2             | Self-locking Hexagon Nut M5 DIN985               | All       |
|          | 4        | 101157    |                  | 1             | O-Ring 34x5                                      | All       |
|          | 5        | 100689    | G3-8 CS-20-01-19 | 1             | Pedal Nose Wheel Steering Arm Slide Block        | All       |
|          | 6        | 100690    | G3-8 CS-20-00-07 | 1             | Steering Arm Nose Wheel                          | All       |
|          | 7        | 100152    |                  | 1             | Allen Screw M6x45 DIN912 8.8                     | All       |

| Fig. No. | Item No. | Order No. | Part No.         | Qty. per Assy | Description                                     | Appl. S/N |
|----------|----------|-----------|------------------|---------------|---|-----------|
| 5-19     | 1        | 102325    |                  | 2             | Lens Head Screw with Flange M6x12 A2/70         | All       |
|          | 2        | 102333    |                  | 2             | Nylon Washer 6x18x2                             | All       |
|          | 3        | 102331    |                  | 2             | Rubber Washer 11x18x1                           | All       |
|          | 4        | 102332    |                  | 2             | Collar Bush 6x18x3.5                            | All       |
|          | 5        | 100819    | G3-8 NG-01-00-01 | 1             | Nose gear Wheel-Axle RF                         | All       |
|          | 6        | 100820    | G3-8 NG-01-00-02 | 2             | Nose gear Distance Sleeve-RF                    | All       |
|          | 7        | 700612    | G3-9 NG-50-00-00 | 1             | Nose gear Nose wheel Complete                   | All       |
|          | 8        | 102155    |                  | 1             | Lens Head Screw M5x10 ISO7380 FL A2             | All       |
|          | 9        | 102238    |                  | 1             | Nut M14x1.5 ISO4035 A2                          | All       |
|          | 10       | 102237    |                  | 1             | Lock Washer 14x30x0.8 DIN462, A2                | All       |
| 5-20     | 1        | 100145    |                  | 5             | Allen Screw M6x30 DIN912 8.8                    | All       |
|          | 2        | 100231    |                  | 10            | Washer 6.4 DIN125 Form A Steel                  | All       |
|          | 3        | 100547    | G3-8 NG-50-10-03 | 1             | Nose gear Nosewheel Wheelhalf-Vent Left         | All       |
|          | 4        | 101045    |                  | 2             | Ball Bearing 6004 2RS                           | All       |
|          | 5        | 100549    | G3-8 NG-50-10-01 | 1             | Nosegear Nosewheel Wheelhub                     | All       |
|          | 6        | 100815    | G3-8 NG-50-10-02 | 1             | Nosewheel Distance Sleeve Short                 | All       |
|          | 7        | 100548    | G3-8 NG-50-10-04 | 1             | Nosegear Nosewheel Wheelhalf Right              | All       |
|          | 8        | 100221    |                  | 5             | Self-locking Hexagon Nut M6 DIN985              | All       |
|          | 9        | 101056    |                  | 1             | Tube 4.00-4                                     | All       |
|          | 10       | 101055    |                  | 1             | Tire 4.00-4 4PR                                 | All       |
| 5-21     | 1        | 100153    |                  | 1             | Allen Screw M6x55 DIN912 8.8                    | All       |
|          | 2        | 100130    |                  | 2             | Allen Screw M5x20 DIN912 8.8                    | All       |
|          | 3        | 102323    |                  | 1             | Speed Nut M5                                    | All       |
|          | 4        | 102155    |                  | 1             | Lens Head Screw M5x10 ISO7380 FL A2             | All       |
|          | 5        | 102649    | G3-8 NG-01-00-13 | 1             | Nosegear Bracket Wheel Fairing                  | All       |
|          | 6        | 100221    |                  | 1             | Self-locking Hexagon Nut M6 DIN985              | All       |
|          | 7        | 100231    |                  | 2             | Washer DIN125 Form A Steel                      | All       |
|          | 8        | 100218    |                  | 2             | Self-locking Hexagon Nut M5 DIN985              | All       |
| 5-22     | 1        | 101156    |                  | 1             | Deep Groove Ball Thrust Bearing 51107G 35x52x12 | All       |
|          | 2        | 100813    | G3-8 NG-01-00-11 | 1             | Nosegear Bearing Dust Cover                     | All       |
|          | 3        | 100816    | G3-8 NG-10-01-00 | 23            | Guide Ring                                      | All       |
|          | 4        | 101159    |                  | 24            | O-Ring 36x9                                     | All       |
|          | 5        | 100817    | G3-8 NG-10-01-01 | 1             | Guide Ring Bottom                               | All       |
| 5-23     | 1        | 100112    |                  | 2             | Allen Screw M4x10 DIN912 8.8                    | All       |
|          | 2        | 100684    | G3-8 CS-20-00-05 | 1             | Assembly Nose Wheel Drive                       | All       |
|          | 3        | 100690    | G3-8 CS-20-00-07 | 1             | Steering Arm Nose Wheel                         | All       |
|          | 4        | 100697    | G3-8 CS-50-00-02 | 1             | Control Wire Rudder                             | All       |
| 5-24     | 1        | 101046    |                  | 1             | Brake Distributor 3F                            | All       |
|          | 2        | 101047    |                  | 1             | Brake Line 1400mm                               | All       |
|          | 3        | 100543    | G3-8 MG-30-02-00 | 1             | Matco Brake Assy                                | All       |



| Fig. No. | Item No. | Order No. | Part No.         | Qty. per Assy | Description                            | Appl. S/N |
|----------|----------|-----------|------------------|---------------|--|-----------|
| 5-25     | 1        | 100535    | G3-8 MG-01-00-09 | 1             | Bolt Grip Handle                       | All       |
|          | 2        | 100533    | G3-8 MG-01-00-08 | 2             | Grip Handle Brake Lever                | All       |
|          | 3        | 100534    | G3-8 MG-01-00-07 | 1             | Brake Lever colorless anodized         | 304 ff.   |
|          | 4        | 101040    |                  | 1             | Brake Master Cylinder PS16             | All       |
|          | 5        | 101041    |                  | 1             | Brake Fluid Reservoir                  | All       |
|          | 6        | 100521    | G3-8 MG-01-00-00 | 2             | Threaded Couping G1/8 R1/8             | All       |
|          | 7        | 101042    |                  | 1             | Shut Off Valve 1/8"                    | All       |
|          | 8        | 101043    |                  | 1             | Fitting 45°                            | All       |
|          | 9        | 100221    |                  | 1             | Self Locking Hexagon Nut M4 DIN985     | All       |
|          | 10       | 100189    |                  | 1             | Allen Screw M4x12 DIN912 8.8           | All       |
|          | 11       | 100536    |                  | 6             | Lens Head Screw M4x12 ISO7380 FL A2-70 | All       |
|          | 12       | 100150    |                  | 2             | Allen Screw M6x25 DIN912 8.8           | All       |
|          | 13       | 100212    |                  | 2             | Self Locking Hexagon Nut M6 DIN985     | All       |
|          | 14       | 100121    | G3-8 MG-01-00-10 | 1             | Mounting Bracket Master Cylinder       | All       |
| 5-26     | 1        | 101047    |                  | 1             | Brake Line 1400mm                      | All       |
|          | 2        | 101043    |                  | 1             | Fitting 45°                            | All       |
|          | 3        | 100521    | G3-8 MG-01-00-00 | 1             | Threaded Couping G1/8 R1/8             | All       |
|          | 4        | 100543    | G3-8 MG-30-02-00 | 1             | Matco Brake Assy                       | All       |
| 5-27     | 1        | 100601    | G3-8 MG-30-02-06 | 1             | Brake Pads                             | All       |

## Section 6

### Structures – Aileron Control System

| Table of Contents | Section                                     |
|-------------------|---|
| 6.1               | Aileron Control System, Description ..... 2 |
| 6.1.1             | Trouble Shooting ..... 2                    |
| 6.1.2             | Control Stick Linkage, Description..... 3   |
| 6.1.2.1           | Removal and Installation ..... 4            |
| 6.1.3             | Aileron Control Rods, Description ..... 4   |
| 6.1.3.1           | Removal and Installation ..... 4            |
| 6.1.4             | Bell Cranks, Description ..... 5            |
| 6.1.5             | Ailerons, Description..... 6                |
| 6.1.5.1           | Removal and Installation ..... 6            |
| 6.1.5.2           | Repair ..... 7                              |
| 6.1.6             | Rigging..... 8                              |
| 6.2               | Aileron Trim Tab ..... 8                    |
| 6.3               | Bill of Materials ..... 10                  |

## 6.1 Aileron Control System, Description


The aileron control system is comprised of push-pull rods and bell cranks, which link the control sticks to the ailerons. Refer to figure 6-1 as a general overview.

### 6.1.1 Trouble Shooting

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Due to remedy procedures in the following trouble shooting chart it may be necessary to re-rig system, and if so then refer to paragraph 6.1.6. |
|---------------|---|

| Trouble  | Probable Cause   | Remedy                                     |
|--|--|--|
| Lost motion in control sticks.                   | Broken brackets or worn rod end bearings.                  | Replace worn or broken parts.              |
|  | Sprung bell cranks.  | Replace bell crank.                        |
| Resistance to control stick movement.            | Bell cranks distorted or damaged.                          | Replace bell crank.                        |
| Control stick not centered with aileron neutral. | Improper adjustment of aileron push-pull rods.             | Adjust in accordance with paragraph 6.1.6. |
| Incorrect aileron travel                         | Push-pull rods not adjusted properly.                      | Adjust in accordance with paragraph 6.1.6. |
|  | Control stick adjustment-screws are not adjusted properly. | Adjust in accordance with paragraph 6.1.6. |


Figure 6-1



## 6.1.2 Control Stick Linkage, Description

Both control sticks are linked together by a control rod system to ensure synchronous movement. The linkage is located beneath two fiberglass-panels on the floor of the cabin right in front of the seats. A translator connects the control stick linkage to the aileron linkage, which uses several bell cranks to establish the connection to the control surfaces. An illustration of the control stick linkage is given in figure 6-2.

Figure 6-2



## 6.1.2.1 Removal and Installation

- **Required Tools:** Standard metric tools, wire cutting pliers
- **Required Parts:** Self-locking nuts as required
- **Level of Maintenance:** Heavy
- **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center

In general the control stick linkage needs no regular servicing, due to replacement of other parts of the aileron control system, it may be required to readjust the correct travel of the ailerons and access to the linkage will be required.

- a. Remove both seats from the cabin.
- b. Remove fabric stick cover from the stick linkage cover panels and remove cover panels itself.
- c. Remove stick grips and disconnect wiring from stick switches.
- d. Remove wiring from stick tubes and linkage (remember position of stick wiring and cable ties, for reinstallation).
- e. Remove sticks and linkage from their brackets on the bottom of the aircraft.

### ■ CAUTION

If stick wiring is not installed correctly, binding of sticks and cracking or chafing of wiring will occur and may cause fire.

Reassembly is done in reverse order to steps outlined above. Tighten screws and bolts to a torque in accordance to the values given in Section 1.

### ■ CAUTION

DO NOT REUSE SELF-LOCKING NUTS.

## 6.1.3 Aileron Control Rods, Description

Aileron control rods are running from the control stick linkage joint through the fuselage to the aileron control surfaces providing several bell cranks. The whole aileron control rod system needs no regular servicing.

### 6.1.3.1 Removal and Installation

- **Required Tools:** Standard metric tools
- **Required Parts:** None
- **Level of Maintenance:** Heavy
- **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center

To get access to the aileron control rods, both wings provide access flaps. Routing of the control rods within the fuselage will be visible, if baggage compartment is removed (refer to Section 3). Additionally, the center cover (located between both seats) and the control stick floor covers can be removed if required. When necessary to replace parts of the control rod system, always use new self-locking nuts and torque to the values given in Section 1. Detailed information is given in figure 6-3 and 6-4.

## 6.1.4 Bell Cranks, Description

The aileron control rod system provides various bell cranks, located in the fuselage and in the wings, refer to figure 6-3 and 6-4 for detailed illustration. Bell cranks need no regular servicing.

Figure 6-3





Figure 6-4



## 6.1.5 Ailerons, Description

Ailerons are made from carbon fiber composite material, hinged to the outer trailing edge of the wings.

### 6.1.5.1 Removal and Installation


Refer to figure 6-5 as guide for successfully conducting this procedure.

- **Parts required:** Standard metric tools
  - **Required Parts:** Loctite 243 (medium strength), self-locking nuts as required
  - **Level of Maintenance:** Heavy
  - **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center
- a. Disconnect push-pull rod at aileron horn (A).
  - b. Unscrew and remove wing position light cover and wing tip (3) as long as the aileron hinge (5) at the tip (B).
  - c. Slide aileron (2) in tip direction and remove from its hinge bolts (9).
  - d. Install aileron in reverse order to the preceding steps.
  - e. Secure outer hinge screws (7) with Loctite 243 medium strength.
  - f. If rigging was correct and push-pull rod adjustment was not disturbed, it should not be necessary to rig system.

#### ◆ NOTE

Use new self-locking nuts and torque to the values given in Section 1.

Figure 6-5



#### **6.1.5.2 Repair**

Repair is limited to replace slide bearings or hinge bolts and restoring dents or smaller cracks on edges. Since ailerons are designed as sandwich construction parts, it is strongly recommended to replace or return to factory for repair, if larger deterioration of the skin is detected.



## 6.1.6 Rigging

- **Required Tools:** Standard metric tools
- **Required Parts:** Safety wire, self-locking nuts as required
- **Level of Maintenance:** Heavy
- **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center

To achieve a correct aileron setting it is required that flaps have been set to the "up" position correctly first.

- a. Disconnect push-pull rod at aileron horn.
- b. Adjust aileron push-pull rod to achieve alignment of ailerons and wing flaps and reconnect to aileron horn.
- c. Check or adjust center position of control stick (adjustment can be done at the top end of the vertical rod, routed behind the left (pilot) seat.
- d. Check the maximum permissible travel of the ailerons as outlined in Section 1. If required set to correct travel, using the adjustment-screws located on the control stick linkage adjacent to each stick hub.
- e. Align ailerons and wing flaps and hold in that position (i.e. secure with clamp).
- f. Finally check ailerons for correct travel, using an inclinometer.

|               |                                 |
|---------------|---------------------------------|
| <b>◆ NOTE</b> | DO NOT REUSE SELF-LOCKING NUTS. |
|---------------|---------------------------------|

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Secure adjustment-screws with safety-wire after conducting aileron travel adjustment. |
|---------------|---|


## 6.2 Aileron Trim Tab

A trim tab is attached to the lower side of the right aileron. The trim tab is 50mm wide (30mm of it are attached to the rudder) and 150mm long. The trim tab is located on the trailing edge of the right aileron, 350mm from the inner edge. Bond Teroson Terostat MS9380 is used in the process of manufacturing. Alternative bonds may be used. It is recommended to use bond that keep certain flexibility after the curing process.

Bend the tab slightly in case the aircraft does not fly straight. In case left aileron is required bend the tab upward and vice versa. Use small steps of app. 10deg in bending and several trials to find out the optimum position of the tab.

Keep in mind: The amount of left or right aileron differs not only with tolerances of the aircraft, but significantly with the loading of the aircraft. This is typical for aircraft with a payload similar to the empty weight in case the load is not on the center line. In case of flying single solo with little fuel and maybe some baggage, right aileron is required. If now the trim tab is adjusted so that the aircraft is flying straight and the next flight is with more fuel and maybe a passenger on board, left aileron is required. The reason is asymmetric loading and shall not be associated with airframe tolerances.

Figure 6-6



## 6.3 Bill of Materials

| Fig. No. | Item No. | Order No. | Part No.          | Qty. per Assy | Description                                   | Appl. S/N |
|----------|----------|-----------|-------------------|---------------|---|-----------|
| 6-2      | 1        | 102183    | G3-8 REP-00-02-06 | 2             | Hexagon Bolt M5x50 SL42-Tol.5h6               | All       |
|          | 2        | 102181    | G3-8 REP-00-02-04 | 1             | Hexagon Bolt M6x51 SL42-Tol.6f7               | All       |
|          | 3        | 100693    | G3-8 CS-30-00-02  | 1             | Assembly Stick Left Including Item 1,4,5,7,8  | All       |
|          |          | 102897    | G3-8 CS-30-00-03  | 1             | Assembly Stick Right Including Item 1,4,5,7,8 | All       |
|          | 4        | 100218    |                   | 2             | Self-Locking Nut M5 DIN985                    | All       |
|          | 5        | 100232    |                   | 2             | Washer M5 DIN125 Form A Steel vz              | All       |
|          | 6        | 100221    |                   | 1             | Self-Locking Nut M6 DIN985 vz                 | All       |
|          | 7        | 100231    |                   | 1             | Washer M6 DIN125 Form A Steel vz              | All       |
|          | 8        | 102178    | G3-8 REP-00-02-02 | 1             | Hexagon Bolt M6x37 SL14-Tol.6f7               | All       |
|          | 9        | 100683    | G3-8 REP-00-00-06 | 1             | Plate Washer 20x6                             | All       |
|          | 10       | 100607    | G3-8 CS-10-00-01  | 1             | Control-Rod Aileron SB right                  | All       |
|          | 11       | 100606    | G3-8 CS-10-00-00  | 1             | Control-Rod Aileron SB left                   | All       |
|          | 12       | 100231    |                   | 1             | Washer M6 DIN125 Form A Steel vz              | All       |
|          | 13       | 100221    |                   | 1             | Self-Locking Nut M6 DIN985 vz                 | All       |
|          | 14       | 100694    | G3-8 CS-40-00-01  | 1             | Aileron Bridge                                | All       |
|          | 15       | 100691    | G3-8 CS-30-00-01  | 1             | Stick Bridge                                  | All       |
|          | 16       | 102967    | G3-8 REP-00-02-07 | 1             | Hexagon Bolt M6x25 SL16-TOL.6f7               | All       |
|          | 17       | 100692    | G3-8 REP-30-00-00 | 1             | Swivel Bracket Short                          | All       |
|          | 18       | 102967    | G3-8 REP-00-02-07 | 1             | Hexagon Bolt M6x25 SL16-TOL.6f7               | All       |
| 6-3      | 1        | 100610    | G3-8 CS-10-00-04  | 1             | Control-Rod Aileron Connection Top            | All       |
|          | 2        | 102967    | G3-8 REP-00-02-07 | 1             | Hexagon Bolt M6x25 SL16-TOL.6f7               | All       |
|          | 3        | 102178    | G3-8 REP-00-02-02 | 1             | Hexagon Bolt M6x37 SL14-Tol.6f7               | All       |
|          | 4        | 102967    | G3-8 REP-00-02-07 | 1             | Hexagon Bolt M6x25 SL16-TOL.6f7               | All       |
|          | 5        | 100221    |                   | 1             | Self-Locking Nut M6 DIN985 vz                 | All       |
|          | 6        | 100231    |                   | 1             | Washer M6 DIN125 Form A Steel vz              | All       |
|          | 7        | 100564    | G3-8 REP-20-01-00 | 1             | Fastener Clevis Connector                     | All       |
|          | 8        | 100609    | G3-8 CS-10-00-03  | 1             | Control-Rod Aileron KRS left                  | All       |
|          | 9        | 102180    | G3-8 REP-00-02-03 | 1             | Hexagon Bolt M6x43 SL30-Tol.6f7               | All       |
|          | 10       | 100603    | G3-8 REP-00-00-03 | 1             | Sleeve Conical                                | All       |
|          | 11       | 100608    | G3-8 CS-10-00-02  | 1             | Control-Rod Aileron KRS Bottom                | All       |
|          | 12       | 100683    | G3-8 REP-00-00-06 | 1             | Plate Washer 20x6                             | All       |
|          | 13       | 102177    | G3-8 REP-00-02-01 | 1             | Hexagon Bolt M6x30 SL15-Tol.6f7               | All       |
|          | 14       | 100694    | G3-8 CS-40-00-01  | 1             | Aileron Bridge                                | All       |
|          | 15       | 100695    | G3-8 CS-50-00-00  | 1             | Assembly Fairlead Front                       | All       |
| 6-4      | 1        | 102967    | G3-8 REP-00-02-07 | 1             | Hexagon Bolt M6x25 SL16-TOL.6f7               | All       |
|          | 2        | 100806    | G3-8 WG-08-00-01  | 1             | Aileron Control Rod                           | All       |
|          | 3        | 100743    | G3-8 WG-04-01-24  | 1             | Bracket Aileron Control                       | All       |
|          | 4        | 100805    | G3-8 WG-08-01-07  | 1             | Aileron Bell Crank Left Hand Side             | All       |
|          |          | 100807    | G3-8 WG-08-01-08  | 1             | Aileron Bell Crank Right Hand Side            |           |
|          | 5        | 100796    | G3-8 WG-08-01-05  | 1             | Wing Control Flap Fork Head Bushing           | All       |
|          | 6        | 101748    | G3-8 CS-10-01-07  | 1             | Hexagon Nut M10x1, AlZuMgCu1,5                | All       |
|          | 7        | 100804    | G3-8 WG-08-01-10  | 1             | Wing Control Flap Fork Head Bolt              | All       |
|          | 8        | 102178    | G3-8 REP-00-02-02 | 1             | Hexagon Bolt M6x37 SL14-Tol.6f7               | All       |
|          | 9        | 100231    |                   | 2             | Washer M6 DIN125 Form A Steel vz              | All       |
|          | 10       | 100803    | G3-8 REP-00-00-13 | 2             | Cone Ring 6x2                                 | All       |
|          | 11       | 100221    |                   | 1             | Self-Locking Nut M6 DIN985 vz                 | All       |

| Fig. No. | Item No. | Order No. | Part No.         | Qty. per Assy | Description                                  | Appl. S/N |
|----------|----------|-----------|------------------|---------------|--|-----------|
| 6-5      | 1        | 100751    | G3-8 WG-04-01-07 | 1             | Bearing Bolt Aileron                         | All       |
|          | 2        | 100231    |                  | 3             | Washer M6 DIN125 Form A Steel vz             | All       |
|          | 3        | 100744    | G3-8 WG-04-01-23 | 1             | Bracket Aileron X4500 Right/Left             | All       |
|          | 4        | 100155    |                  | 2             | Cylinder Head Screw M6x16 vz DIN912          | All       |
|          | 5        | 100221    |                  | 1             | Self-Locking Nut M6 DIN985 vz                | All       |
|          | 6        | 102378    | G3-8 WG-06-01-07 | 1             | Aileron Balancing Weight                     | All       |
|          | 7        | 100130    |                  | 2             | Cylinder Head Screw M5x20 vz DIN912 8.8      | All       |
|          | 8        | 100751    | G3-8 WG-04-01-07 | 1             | Bearing Bolt Aileron                         | All       |
|          | 9        | 102156    |                  | 2             | Lens Head Screw with Flange M5x16 ISO7380 A2 | All       |
|          | 10       | 100231    |                  | 1             | Washer M6 DIN125 Form A Steel vz             | All       |
|          | 11       | 100221    |                  | 1             | Self-Locking Nut M6 DIN985 vz                | All       |
|          | 12       | 100744    | G3-8 WG-04-01-23 | 1             | Wing Bracket Aileron X4500                   | All       |
|          | 13       | 100745    | G3-8 WG-04-01-21 | 1             | Wing Bracket Aileron X3795 Left              | All       |
|          |          | 100753    | G3-8 WG-04-01-22 | 1             | Wing Bracket Aileron X3795 Right             | All       |
|          | 14       | 100746    | G3-8 WG-04-01-19 | 1             | Wing Bracket Aileron X3100 Left              | All       |
|          |          | 100754    | G3-8 WG-04-01-20 | 1             | Wing Bracket Aileron X3100 Right             | All       |
|          | 15       | 100747    | G3-8 WG-04-01-17 | 1             | Wing Bracket Aileron X2425 Left              | All       |
|          |          | 100755    | G3-8 WG-04-01-18 | 1             | Wing Bracket Aileron X2425 Right             | All       |
| 6-6      | 1        | 102338    | G3-8 WG-06-01-12 | 1             | Trim Tab Aileron                             | All       |

*Intentionally left blank*

## Section 7

### *Wing Flap Control System*

| Table of Contents |  | Section |
|-------------------|--|---------|
| 7.1               | Wing Flap Control System, Description..... | 2       |
| 7.1.1             | Operational Check.....                     | 2       |
| 7.1.2             | Trouble Shooting .....                     | 3       |
| 7.1.3             | Flap Motor and Transmission Assembly ..... | 3       |
| 7.1.4             | Flap Control System .....                  | 5       |
| 7.1.5             | Indicating System, Description .....       | 6       |
| 7.1.6             | Flaps .....                                | 8       |
| 7.2               | Bill of Materials .....                    | 12      |

## **7.1 Wing Flap Control System, Description**

The wing flap control system is comprised of an electric motor and transmission assembly, push-pull rods, a bell crank and a flap position indicator. Power from the motor assembly is transmitted to the flaps by push-pull rods and a bell crank. A single piece aluminum drive shaft with an attached actuation lever for the connection to the flap motor is located inside the cabin. Both ends of the shaft are providing slots to engage into the bell crank drive shaft at each wing. A push-pull rod is attached to the bell crank to connect wing flap. Electrical power to the motor is controlled by a 3-position switch mounted on the instrument panel. The flap position indicator is calibrated to show degrees of extension. A general overview is given in figure 7-1.

### **7.1.1 Operational Check**

- a. Operate flaps through their full range of travel, observing for uneven or jumpy motion, binding and lost motion in system. Ensure flaps are moving together through their full range of travel.
- b. Attempt to overrun travel extremes and check up- and down-limit switch actuation at flaps retracted and extended position. **FLAP MOTOR MUST STOP OR DAMAGE WILL RESULT.**
- c. Check flaps for sluggishness in operation. In flight at 65 kts, indicated airspeed, flaps should fully extend in approximately 8-9 seconds and retract in approximately 6-7 seconds. On the ground, with engine running, the flaps should extend or extract in approximately 7 seconds.
- d. With flaps full UP, mount an inclinometer on one flap and set to 0°. Lower flaps to full DOWN position and check flap angle as specified in figure 1-1. Check approximate mid-range percentage setting against degrees as indicated on inclinometer.
- e. Inspect flap hinges for free play or binding (if necessary disconnect motor assembly from actuator lever inside the cabin).

Figure 7-1



## 7.1.2 Trouble Shooting

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | Due to remedy procedures in the following trouble shooting chart it may be necessary to re-rig system, refer to paragraph 7.1.6.3. |
|---------------|--|

| Trouble                          | Probable Cause                | Remedy   |
|----------------------------------|-------------------------------|--|
| Flaps fail to move.              | Blown fuse/circuit breaker.   | Replace fuse or reset circuit breaker.             |
|                                  | Defective switch.             | Replace switch.                                    |
|                                  | Defective motor.              | Remove and bench test motor. Replace if defective. |
|                                  | Broken or disconnected wires. | Run a continuity check. Connect or repair wiring.  |
|                                  | Defective Transmission.       | Replace motor assembly.                            |
|                                  | Defective limit switch.       | Replace motor assembly.                            |
| Incorrect flap travel.           | Incorrect rigging.            | Refer to paragraph 7-1.6.3.                        |
|                                  | Defective limit switch.       | Replace motor assembly.                            |
| Flaps fail to retract.           | Defective switch.             | Replace switch                                     |
|                                  | Defective limit switch        | Replace motor assembly.                            |
|                                  | Defective motor               | Replace motor assembly.                            |
| Flaps fail to extend.            | Defective switch.             | Replace switch                                     |
|                                  | Defective limit switch        | Replace motor assembly.                            |
|                                  | Defective motor               | Replace motor assembly.                            |
| Flap position indicator failure. | Broken or disconnected wires. | Run a continuity check. Connect or repair wiring.  |
|                                  | Defective indicator.          | Replace indicator.                                 |
|                                  | Defective position sensor.    | Replace motor assembly.                            |

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Limit switches, transmission and indicator position sensor are part of the motor assembly. If limit switches (sealed reed type) or position sensor is determined to be defective, they may be replaced within the motor assembly. Due to flight safety concerns we strongly recommend to replace complete motor assembly. |
|---------------|---|

## 7.1.3 Flap Motor and Transmission Assembly


### 7.1.3.1 Removal and Installation

- **Required Tools:** Standard metric Tools
- **Required Parts:** Self-locking nuts as required
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

An illustration of the flap motor assembly is given in figure 7-2.



Figure 7-2



- a. Run flaps to full DOWN position.
- b. Support flaps from outside the aircraft in that position by a second person.
- c. Disconnect motor push-pull rod from flap actuation lever (11) inside the cabin.
- d. Disconnect battery cables at the battery and insulate cable terminals as a safety precaution.
- e. Push up flaps till they lock at full UP position.
- f. Remove locking plate (3) from flap motor bracket.
- g. Unscrew eccentric bolt (4) and remove motor.
- h. Disconnect wiring from motor.
- i. Reverse the preceding steps for reinstallation.

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | Mark adjustment of eccentric bolt before removing it, this setting is required for reinstallation. The locking plate allows adjustment of the eccentric bolt in 15° steps, to achieve correct flap travel adjustment (refer to paragraph 7.1.6.3). |
|---------------|--|

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | In general, no rigging is required if motor has to be replaced, but is essential to check correct rigging in accordance with paragraph 7.1.6.3. |
|---------------|---|

### 7.1.3.2 Repair

Repair is limited to the replacement of motor and associated hardware, although some parts within the motor assembly may be replaced, we strongly recommend, always to replace the complete motor assembly as safety precaution.

### 7.1.4 Flap Control System

#### 7.1.4.1 Removal and Installation

- **Required Tools:** Standard metric tools
- **Required Parts:** Loctite 641
- **Level of Maintenance:** Heavy
- **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center

Prior to removing the flap control linkage, the motor assembly has to be removed (see paragraph 7.1.3.1) and the wings have to be folded back (refer to Pilot Operating Handbook). Refer to figure 7-2 and 7-3 for details on removal and installation.

- a. Unscrew the drive-shaft support bearing (16 / figure 7-2).
- b. Withdraw the drive-shaft (18 / figure 7-2) from the fuselage.
- c. Unscrew actuation lever clamping screws (13 / figure 7-2).
- d. Disconnect push-pull rods (figure 7-3) from wing flaps and remove bell crank assembly from wing.
- e. Reverse the preceding steps for installation.
- f. After assembling and rigging is completed, tighten all bolts and nuts as outlined in Section 1.

|        |  |
|--------|--|
| ◆ NOTE | To remove the actuation lever from the drive shaft, the whole assembly has to be heated up to 480°F. Do not partially heat up the assembly, because this would cause deterioration to the drive-shaft. |
|--------|--|

|           |   |
|-----------|---|
| ■ CAUTION | The actuation lever is installed to the drive shaft by clamping, secured with Loctite 641. Due to safety precautions we always recommend to install a new lever when it needs to be disassembled. After applying Loctite to assemble the actuation lever to the drive-shaft, you will have <b>30 minutes</b> to rig the flap control system until the Loctite will cure, therefore refer to paragraph 7.1.6.3 prior to installation of the lever. |
|-----------|---|

### 7.1.4.2 Repair

Repair consists of the replacement of defective parts only.


### 7.1.5 Indicating System, Description

Indication of flap position is provided by an LED-array gauge located on the switch panel for the Explorer, Aviator and eLITE. The flap position for the NXT/NXES is provided by the SkyView. A position sensor is part of the flap motor, and provides an appropriate voltage to the indicator gauge depended on the flap position.

#### 7.1.5.1 Repair

Repair is limited to the replacement of LED-Indicator, wiring and flap motor assembly (refer to paragraph 7.1.3.1).

Figure 7-3



## 7.1.6 Flaps

### 7.1.6.1 Removal and Installation (refer to figure 7-4 and 7-5.)

- **Required Tools:** Standard metric tools
  - **Required Parts:** Self-locking nuts and cotter pins as required
  - **Level of Maintenance:** Heavy
  - **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center
- 
- a. Run flaps to full DOWN position.
  - b. Disconnect push-pull rod (A / figure 7-4) at wing flap bracket.
  - c. Remove cotter pins and hinge bolts from hinge brackets (B / figure 7-4).
  - d. Remove flap (C / figure 7-4).
  - e. As flap is removed from wing, all washers and bushings will fall free. Retain these for reinstallation.
  - f. Reverse the preceding steps for reinstallation. If push-pull rod (figure 7-4) adjustment is not disturbed, re-rigging of system should not be necessary.
  - g. Check flap travel and rig in accordance with paragraph 7.1.6.3, if necessary.

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | Always use new cotter pins for securing the hinge bolts. |
|---------------|--|

Refer to figure 7-5 as guide for removal and installation of hinge brackets and bearings. Use Loctite 243 on all bolt connections for securing screws. Tighten bolts to a torque in accordance to the values given in Section 1.

Figure 7-4




Figure 7-5





Figure 7-6



### **7.1.6.2 Repair**

Repair is limited to replace sleeve bearings or hinge bolts and restoring dents or smaller cracks on edges. Since flaps are designed as carbon fiber sandwich components, it is strongly recommended to replace or return to factory for repair, if larger damage or deterioration of the skin is dedicated.

### **7.1.6.3 Rigging**

- **Required Tools:** Inclinometer
- **Required Parts:** Loctite 641 & 243
- **Level of Maintenance:** Heavy
- **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center

The following description has to be maintained if flap control system was reassembled completely, including installing a new actuator lever to the drive shaft inside the cabin. If only wing flaps has been replaced, check correct flap travel as outlined in Section 1 and perform steps p. to r.

- a. Operate flaps to full UP position.
- b. Loosen clamping of actuator lever inside the cabin (11 / figure 7-2).
- c. Check that flaps are locked in upper position, by pressing firmly on the upper side of the flap surface. If required push flaps up till they are locked, adjust push-pull rods (3 / figure 7-3) when necessary to ensure that flaps are locking in upper position.
- d. Temporarily tighten clamp of actuator lever inside the cabin (11 / figure 7-2).
- e. Install an inclinometer to one of the flaps and set to 0°.
- f. Run flaps to full DOWN position and check flap angle as specified in figure 1-1.
- g. If required adjust eccentric bolt at the motor-bracket connection to achieve more or less of flap angle. The eccentric bolt (4 / figure 7-2) could be adjusted in 15° steps to match with locking plate (3 / figure 7-2). The motor assembly can be moved forward and backward, causing 2° difference in full flap angle.
- h. Run flaps to full UP position and repeat step **c** to **g** as long as travel of flaps is within the limits outlined in figure 1-1.
- i. Run flaps to full UP position, mark position of actuator lever on drive shaft and loosen both clamp-screws and slide lever to the right (viewed from front).
- j. Apply **Loctite 641** to the position on the drive shaft where the actuator lever (11 / figure 7-2) has to be clamped. Slide back the lever in its marked position and tighten one clamp screw temporarily again.
- k. Operate flaps to full DOWN position and check flap angle again.
- l. Run flaps to 15° position and tighten both clamp screws to a torque value given in figure 1-2. (Secure clamp screws, using **Loctite 243**).
- m. Perform a check flight and ensure that aircraft maintains heading at full payload, with both seats occupied.
- n. If pressure to the control stick is required during normal flight, to keep wings level, adjust trim tab at the aileron to achieve level flight.

|        |  |
|--------|--|
| ◆ NOTE | It is essential that flaps are locked in upper position. Check that bell crank does override the locking position for a <u>short distance only</u> . If bell crank does override the locking position too far, you will not be able to get the full flap travel as required. |
| ◆ NOTE | After applying <b>Loctite 641</b> to the actuator lever clamp, you have <b>30 minutes</b> until the Loctite will cure, further correction to the adjustment can only be done within this time.   |
| ◆ NOTE | Remember position of washers used on the push-pull rod connecting the wing flap bracket. DO NOT REUSE SELF-LOCKING NUTS. Tighten rod connecting bolt to the torque value outlined in figure 1-2.   |



## 7.2 Bill of Materials

| Fig. No. | Item No. | Order No. | Part No.          | Qty. per Assy | Description                                       | Appl. S/N |
|----------|----------|-----------|-------------------|---------------|---|-----------|
| 7-2      | 1        | 700080    | G3-8 FU-00-00-20  | 1             | Flap Drive Mount                                  | All       |
|          | 2        | 102324    |                   | 1             | Lens Head Tapping Screw M3.9x13 Delta Seal        | All       |
|          | 3        | 100487    | G3-8 CS-80-01-04  | 1             | Locking Plate Flap                                | All       |
|          | 4        | 100486    | G3-8 CS-80-01-03  | 1             | Eccentric Bolt Flap                               | All       |
|          | 5        | 100221    |                   | 3             | Self-locking Hexagon Nut M6                       | All       |
|          | 6        | 100231    |                   | 3             | Washer 6.4 DIN125 FormA vz                        | All       |
|          | 7        | 100490    | G3-8 CS-80-01-05  | 1             | Support Feet Flap                                 | All       |
|          | 8        | 100489    | G3-8 CS-80-01-07  | 2             | Collar Bush Flap                                  | All       |
|          | 9        | 100147    |                   | 1             | Allen Screw M6x35 DIN912 8.8                      | All       |
|          | 10       | 101031    |                   | 1             | Flap Motor LA12.1P-100-12-003                     | All       |
|          | 11       | 100485    | G3-8 CS-80-00-00  | 1             | Flap Control Lever Assy                           | All       |
|          | 12       | 100232    |                   | 2 (4)         | Washer 5.3 DIN125 Form A Steel                    | All       |
|          | 13       | 100131    |                   | 2             | Allen Screw M5x25 DIN912 8.8                      | All       |
|          | 14       | 100488    | G3-8 CS-80-01-06  | 2             | Flap Control Bushing                              | All       |
|          | 15       | 100218    |                   | 2             | Self-locking Hexagon Nut M5                       | All       |
|          | 16       | 100484    | G3-8 CS-80-01-02  | 1             | Flap Control Bearing Drive Tube                   | All       |
|          | 17       | 100130    |                   | 2             | Allen Screw M5x20 DIN912 8.8                      | All       |
|          | 18       | 100483    | G3-8 CS-80-01-01  | 1             | Fuselage Flap Flaptube                            | All       |
| 7-3      | 1        | 100221    |                   | 2             | Self-locking Hexagon Nut M6                       | All       |
|          | 2        | 100683    | G3-8 REP-00-00-06 | 1             | Plate Washer 20x6                                 | All       |
|          | 3        | 100797    | G3-8 WG-08-00-04  | 1             | Bearing Lug Bolt LG 14 Assy                       | All       |
|          | 4        | 100801    | G3-8 WG-08-01-00  | 1             | Wing Control Flap Lever Actuator Part 1           | All       |
|          | 5        | 100150    |                   | 1             | Allen Screw M6x25 DIN912 8.8                      | All       |
|          | 6        | 100800    | G3-8 WG-08-01-01  | 1             | Wing Control Flap Lever Actuator Part 2           | All       |
|          | 7        | 101149    |                   | 2             | Bushing DU 16X17 BB 1617                          | All       |
|          | 8        | 100765    | G3-8 WG-04-01-13  | 1             | Wing Bracket Flap Actuator Left                   | All       |
|          |          | 100768    | G3-8 WG-04-01-14  | 1             | Wing Bracket Flap Actuator Right                  | All       |
|          | 9        | 100798    | G3-8 WG-08-01-02  | 1             | Wing Control Flap Bolt Actuator                   | All       |
|          | 10       | 100799    | G3-8 WG-08-01-03  | 1             | Wing Control Flap Tappet Actuator                 | All       |
|          | 11       | 102661    |                   | 1             | Washer 2.5 DIN125 FormA vz                        | All       |
|          | 12       | 100100    |                   | 1             | Allen Screw M2,5x12 vz DIN912 A4-70               | All       |
|          | 13       | 101731    |                   | 1             | Countersunk Head Hexagon Socket Screw M5x16 A2-70 | All       |
|          | 14       | 102967    | G3-8 REP-00-02-07 | 1             | Hexagon Bolt M6x25                                | All       |
|          | 15       | 100231    |                   | 2             | Washer 6.4 DIN125 FormA vz                        | All       |
|          | 16       | 100803    | G3-8 REP-00-00-13 | 2             | Cone Ring 6x2                                     | All       |
|          | 17       | 100796    | G3-8 WG-08-01-05  | 1             | Wing Control Flap Fork Head Bushing               | All       |
|          | 18       | 100748    | G3-8 CS-10-01-07  | 1             | Hex Nut M10x1                                     | All       |

| Fig. No. | Item No. | Order No. | Part No.         | Qty. per Assy | Description  | Appl. S/N |
|----------|----------|-----------|------------------|---------------|--|-----------|
| 7-5      | 1        | 700803    |                  | 1             | Left Wing FVK                                      | All       |
|          |          | 700804    |                  | 1             | Right Wing FVK                                     | All       |
|          | 2        | 100771    | G3-8 WG-04-01-09 | 1             | Wing Bracket Flap Left                             | All       |
|          |          | 100773    | G3-8 WG-04-01-10 | 1             | Wing Bracket Flap Right                            | All       |
|          | 3        | 102156    |                  | 2 (3)         | Lens Head Screw with Flange M5x16 ISO7380 A2       | All       |
|          | 4        | 100284    |                  | 1             | Cotter Pin 1,6x12 DIN94 Steel                      | All       |
|          | 5        | 100232    |                  | 1             | Washer 5.3 DIN125 Form A Steel                     | All       |
|          | 6        | 101151    |                  | 2             | Bushing 5X5 BB 0505 DUB                            | All       |
|          | 7        | 100772    | G3-8 WG-04-01-31 | 1             | Wing Stud 5x27 Flap                                | All       |
|          | 8        | 100786    | G3-8 WG-05-01-04 | 1             | Wing Flap Bracket Left                             | All       |
|          |          | 100787    | G3-8 WG-05-01-05 | 1             | Wing Flap Bracket Right                            | All       |
|          | 9        | 700810    |                  | 1             | Left Flap FVK                                      | All       |
|          |          | 700811    |                  | 1             | Right Flap FVK                                     | All       |
|          | 10       | 102158    |                  | 1             | Lens Head Screw Hexagon Socket M6x16 ISO7380 A2 FL | All       |
|          | 11       | 100782    | G3-8 WG-05-01-02 | 1             | Wing Flap Bearing-Lever Actuator Left              | All       |
|          |          | 100785    | G3-8 WG-05-01-03 | 1             | Wing Flap Bearing-Lever Actuator Right             | All       |
|          | 12       | 100783    | G3-8 WG-05-01-00 | 1             | Wing Flap Actuator-Bracket Left                    | All       |
|          |          | 100784    | G3-8 WG-05-01-01 | 1             | Wing Flap Actuator-Bracket Right                   | All       |
|          | 13       | 102155    |                  | 2             | Lens Head Screw Hexagon Socket M5x10 ISO7380 A2    | All       |
| 7-6      | 1        | 102807    |                  | 2             | Flap Drive Stop                                    | All       |

*Intentionally left blank*

## Section 8

### *Elevator Control System*

| Table of Contents |   | Section |
|-------------------|---|---------|
| 8.1               | Elevator Control System, Description..... | 2       |
| 8.1.1             | Trouble Shooting .....                    | 2       |
| 8.1.2             | Elevator.....                             | 3       |
| 8.1.3             | Bell Crank .....                          | 5       |
| 8.1.4             | Rigging.....                              | 6       |
| 8.2               | Bill of Materials .....                   | 7       |

---

## 8.1 Elevator Control System, Description


The elevator is operated by the pulling/pushing power transmitted from the control stick through a bell crank and a push-pull tube. An elevator trim tab is installed on the elevator and is described in Section 9. A general overview is given in figure 8-1.

### 8.1.1 Trouble Shooting

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Due to remedy procedures in the following trouble shooting chart it may be necessary to re-rig system; if so, refer to paragraph 8.1.4. |
|---------------|---|

| Trouble   | Probable Cause   | Remedy   |
|---|--|--|
| No response to control stick fore-and-aft movement.   | Quick release connector at aft end of push-pull tube disconnected. | Join quick release connector properly.               |
|   | Forward end of push-pull tube disconnected.                        | Attach push-pull tube correctly.                     |
|   | Connection between bell crank and push-pull tube disconnected.     | Attach push-pull tube correctly.                     |
| Binding or jumpy motion felt in movement of elevator. | Defective bell crank pivot bearing.                                | Replace bell crank bearing.                          |
|   | Nylon grommet bearings binding.                                    | Replace grommet.                                     |
|   | Defective elevator hinges or lubrication needed.                   | Replace defective hinges or lubricate per Section 2. |
| Elevator fails to attain prescribed travel.           | Interference beneath center cover or behind rear cabin bulkhead.   | Rig system in accordance with paragraph 8.1.4.       |

Figure 8-1




## 8.1.2 Elevator

### 8.1.2.1 Removal and Installation (refer to figure 8-2.)

- **Required Tools:** Standard metric tools
  - **Required Parts:** Self-locking Nut (M6)
  - **Level of Maintenance:** Heavy
  - **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center
- 
- a. Disconnect quick release connector at the aft end of push-pull tube (1).
  - b. Disconnect trim wiring at terminal on fuselage tail.
  - c. Unscrew the securing nut at the center of the leading edge on elevator, adjacent to actuator bracket .
  - d. Move elevator to full DOWN position.
  - e. Slide elevator to the right side, to disengage hinges.
  - f. Using care, remove elevator.
  - g. Reverse preceding steps for installation.
  - h. Rig system in accordance with applicable paragraph in this section if necessary.

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | If push-pull tube screw is not turned, rigging of trim system should not be necessary after installation of elevator. |
|---------------|---|

Figure 8-2

**8.1.2.2 Repair**

Repair may be accomplished as outlined in Section 18. Hinge sleeve bearings may be replaced as necessary. Further repair is limited to restoring dents or smaller cracks on edges. Since the elevator is designed as carbon fiber sandwich component, it is strongly recommended to replace or return to factory for repair, if larger damage or deterioration of the skin is detected.

## 8.1.3 Bell Crank

### 8.1.3.1 Removal and Installation (refer to figure 8-3.)

- **Required Tools:** Standard metric tools
  - **Required Parts:** 3x self-locking nut (M6)
  - **Level of Maintenance:** Heavy
  - **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center
- 
- a. Remove pilot seat and baggage compartment (refer to Section 3).
  - b. Disconnect forward and aft push-pull tube from bell crank(3).
  - c. Remove pivot bolt (11) and remove bell crank.
  - d. Reverse preceding steps for installation.
  - e. Check for free play of push-pull tubes and bell crank.

Figure 8-3







Figure 8-4



## 8.1.4 Rigging

- **Required Tools:** Standard metric tools, inclinometer
  - **Required Parts:** Loctite 243 (medium strength)
  - **Level of Maintenance:** Heavy
  - **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center
- 
- a. Locate neutral position of elevators by streamlining elevators with stabilizer.
  - b. Place an inclinometer on the elevator and set to zero.
  - c. Check for centered position of control stick.
  - d. If required, adjust stick center position at the aft end of push-pull tube and secure with **Loctite 243**.
  - e. Check elevator travel as outlined in figure 1-1.

## 8.2 Bill of Materials

| Fig. No. | Item No. | Order No. | Part No.          | Qty. per Assy | Description                                       | Appl. S/N |
|----------|----------|-----------|-------------------|---------------|---|-----------|
| 8-1      | 1        | 102897    | G3-8 CS-30-00-03  | 1             | Assembly Stick Right                              | 340 ff    |
|          | 2        | 100691    | G3-8 CS-30-00-01  | 1             | Assembly Stick Bridge                             | All       |
|          | 3        | 100693    | G3-8 CS-30-00-02  | 1             | Assembly Stick Left                               | All       |
|          | 4        | 100625    | G3-8 REP-10-00-00 | 1             | Assembly Roller Guide                             | All       |
|          | 5        | 100560    | G3-8 CS-10-00-05  | 1             | Control-Rod Elevator Front                        | All       |
|          | 6        | 100561    | G3-8 CS-10-00-06  | 1             | Control-Rod Elevator Rear                         | All       |
| 8-2      | 1        | 100561    | G3-8 CS-10-00-06  | 1             | Control-Rod Elevator Rear                         | All       |
|          | 2        | 101748    | G3-8 CS-10-01-07  | 1             | Hexnut M10x1                                      | All       |
|          | 3        | 100562    | G3-8 REP-20-00-00 | 1             | Assembly fastener old version                     | Till 321  |
|          | 3        | 100562    | G3-8 REP-20-00-00 | 1             | Assembly fastener new version                     | 321 ff    |
|          | 4        | 100564    | G3-8 REP-20-01-00 | 1             | Fastener Clevis Connector                         | All       |
|          | 5        | 100231    |                   | 2             | Washer 6.4 DIN 125 Form A Steel                   | All       |
|          | 6        | 100221    |                   | 1             | Self-locking Hexagon Nut M6                       | All       |
| 8-3      | 7        | 100150    |                   | 1             | Cylinder Head Screw with Hexagon Socket M6x25 8.8 | All       |
|          | 1        | 102967    | G3-8 REP-00-02-07 | 2             | Hexagon Bolt M6x25                                | All       |
|          | 2        | 100231    |                   | 2-6           | Washer 6.4 DIN 125 Form A Steel                   | All       |
|          | 3        | 100558    | G3-8 CS-11-00-03  | 1             | Assembly Elevator Bell Crank                      | All       |
|          | 4        | 100221    |                   | 1-3           | Self-locking Hexagon Nut M6                       | All       |
|          | 5        | 102061    | G3-8 CS-10-01-02  | 1             | Clevis Bolt                                       | All       |
|          | 6        | 100140    |                   | 3             | Cylinder Head Screw with Hexagon Socket M5x14 8.8 | All       |
|          | 7        | 100232    |                   | 6             | Washer 5.3 DIN 125 Form A Steel                   | All       |
|          | 8        | 100218    |                   | 3             | Self-locking Hexagon Nut M5                       | All       |
|          | 9        | 100559    | G3-8 CS-60-01-01  | 1             | Elevator Bell Crank Storing                       | All       |
|          | 10       | 100682    | G3-8 CS-60-01-02  | 1             | Elevator Bell Crank Distance Cone                 | All       |
|          | 11       | 102181    | G3-8 REP-00-02-04 | 1             | Hexagon Bolt M6x51                                | All       |
|          | 12       | 101748    | G3-8 CS-10-01-07  | 1             | Hexnut M10x1                                      | All       |
| 8-4      | 1        | 102967    | G3-8 REP-00-02-07 | 1             | Hexagon Bolt M6x25                                | All       |
|          | 2        | 100231    |                   | 2             | Washer 6.4 DIN 125 Form A Steel                   | All       |
|          | 3        | 100221    |                   | 1             | Self-locking Hexagon Nut M6                       | All       |
|          | 4        | 100560    | G3-8 CS-10-00-05  | 1             | Control-Rod Elevator Front                        | All       |
|          | 5        | 100625    | G3-8 REP-10-00-00 | 1             | Assembly Roller Guide                             | All       |

*Intentionally left blank*

## Section 9

### *Elevator Trim Control System*

| <b>Table of Contents</b>                            | <b>Section</b> |
|---|----------------|
| 9.1 Elevator Trim Control System, Description ..... | 2              |
| 9.1.1 Trouble Shooting .....                        | 2              |
| 9.1.2 Trim Tab .....                                | 2              |
| 9.1.3 Trim Tab Servo .....                          | 2              |
| 9.1.4 Trim Control System .....                     | 3              |
| 9.1.5 Indicating system .....                       | 3              |
| 9.1.6 Rigging.....                                  | 4              |
| 9.2 Bill of Materials .....                         | 6              |

## 9.1 Elevator Trim Control System, Description

The elevator trim tab, located on the left elevator, is controlled by a trim switch mounted on the left side of the switch panel (blue). Power to operate the tab is transmitted from the trim control switch by wire. An LED-array indicator, located on the left side of the switch panel (below trim switch) indicates tab position. A “nose-up” setting results in a tab-down position.

### 9.1.1 Trouble Shooting

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Due to remedy procedures in the following troubleshooting chart it may be necessary to re-rig system, refer to paragraph 9.1.6. |
|---------------|---|

| Trouble   | Probable Cause                      | Remedy  |
|---|-------------------------------------|---|
| Trim tab fails to move.                                 | Blown fuse/circuit breaker          | Replace fuse or reset circuit breaker.            |
|   | Defective trim switch.              | Replace trim switch.                              |
|   | Defective trim servo.               | Replace trim servo.                               |
|   | Broken or disconnected wiring.      | Run a continuity check. Connect or repair wiring. |
|   | Broken trim tab linkage             | Replace linkage.                                  |
| Trim indicator fails to indicate correct trim position. | Defective position sensor.          | Replace trim servo.                               |
|   | Broken or disconnected wiring.      | Run a continuity check. Connect or repair wiring. |
|   | Defective trim indicator.           | Replace trim indicator.                           |
| Incorrect trim tab travel.                              | Incorrect push-pull rod adjustment. | Refer to paragraph 9.1.6.                         |
|   | Defective trim servo.               | Replace trim servo.                               |

### 9.1.2 Trim Tab

#### 9.1.2.1 Inspection and Repair

The trim tab panel is attached to the elevator by a flexible composite hinge, therefore it cannot be removed from the elevator. The flexible hinge should be inspected due to cracks during regular service intervals. It may be find that cracks in the paint of the hinge will occur which are not structural and does not need any servicing. If cracks are concerning the hinge structure itself, refer to Section 18 for repair.

### 9.1.3 Trim Tab Servo

#### 9.1.3.1 Removal and installation

- **Required Tools:** Standard metric tools
- **Required Parts:** Cotter pin (1.6 x 20 mm)
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

Prior to removal of the trim servo, removal of the elevator is necessary, refer to Section 8.

- a. Disconnect push-pull rod (3) end from actuator bracket (2) on trim tab.
- b. Remove securing cable tie of trim servo wiring.
- c. Unscrew and remove trim servo from elevator.
- d. Reverse preceding steps for reinstallation and use a new cotter pin to secure push-pull connection at trim tab bracket.
- e. Re-rig the system in accordance with paragraph 9.1.6.

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | If push-pull rod is not turned, rigging of trim system should not be necessary after installation of the new trim servo. |
|---------------|--|

|                  |  |
|------------------|--|
| <b>■ CAUTION</b> | Check for correct movement of trim tab after reconnecting terminal wiring. A “nose-up” setting results in a tab-down position. |
|------------------|--|

## 9.1.4 Trim Control System

### 9.1.4.1 Removal and installation

The trim control system consists of a trim servo located in the elevator (refer to paragraph 9.1.3) and a control switch on the switch panel. To remove or install a new switch, unscrew the switch panel. Refer to Section 15 for detailed information about removal and installation of the switch panel.

## 9.1.5 Indicating system

To indicate the position of trim tab, an LED-indicator is installed in the switch panel (Only Explorer and Aviator). The indication for the trim tab position for the eLITE is given in the Dynon D180 and for the NXT/NXES the Sky View will provide this information. Power to the indicator is supplied by the trim tab servo.

### 9.1.5.1 Removal and Installation

- **Required Tools:** Standard metric tools, edge-cutter
  - **Required Parts:** Insulating tape, cable ties,
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- a. Disconnect battery leads and insulate as safety precaution.
  - b. Unscrew throttle lever knob, clamp nut, friction knob and ignition key retaining ring.
  - c. Unscrew and withdraw switch panel.
  - d. Unplug and remove LED trim tab position indicator.
  - e. Reverse preceding steps for reinstallation.

- f. Check for correct indication of trim tab position and re-rig as required.

◆ NOTE

Rigging of trim system should not be necessary after installation of a new trim indicator.

## 9.1.6 Rigging


- Required Tools: Standard metric tools
- Required Parts: None
- Level of Maintenance: Line
- Certification required: A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

- a. Move trim indicator needle-pointer to center position.
- b. Adjust push-pull rod end at trim tab connection to achieve a neutral setting of trim tab.
- c. Check for correct movement of trim tab. Pushing the control button to "up" position (downward) must result in a "up" reading on the indicator and a tab-down movement.

◆ NOTE

Always use a new cotter pin when reestablishing the connection of push-pull rod at the trim tab bracket.

Figure 9-1





**9.2 Bill of Materials**

| Fig. No. | Item No. | Order No. | Part No.         | Qty. per Assy | Description                | Appl. S/N |
|----------|----------|-----------|------------------|---------------|----------------------------|-----------|
| 9-1      | 1        | 101740    |                  | 2             | Counter Sunk Rivet 4x8 A2K | All       |
|          | 2        | 100678    | G3-8 HT-20-01-02 | 1             | Trim Tab Actuator Bracket  | All       |
|          | 3        | 101110    |                  | 1             | Clevis Pushrod Trim Tab    | All       |
|          | 4        | 102545    |                  | 1             | Trim Servo                 | All       |
|          | 5        | 100669    | G3-8 HT-20-01-04 | 1             | Trim Servo Bracket B       | All       |
|          | 6        | 100668    | G3-8 HT-20-01-05 | 1             | Trim Servo Bracket A       | All       |
|          | 7        | 101975    |                  | 4             | Tapping Screw 2.9x13       | All       |

## Section 10

### *Rudder Control System*

| <b>Table of Contents</b>                      | <b>Section</b> |
|---|----------------|
| 10.1 Rudder Control System, Description ..... | 2              |
| 10.1.1 Trouble Shooting .....                 | 2              |
| 10.1.2 Rudder Pedal Assembly .....            | 2              |
| 10.1.3 Rudder .....                           | 3              |
| 10.1.4 Cables and Pulleys .....               | 4              |
| 10.1.5 Rigging.....                           | 5              |
| 10.2 Rudder Trim Tab.....                     | 6              |
| 10.3 Bill of Materials .....                  | 8              |

## 10.1 Rudder Control System, Description

Rudder control is maintained through use of conventional rudder pedals which also control nose wheel steering. The system is comprised of rudder pedals, a steering rod (sliding translator), cables and pulleys, all of which link the pedals to the rudder and nose wheel steering.

### 10.1.1 Trouble Shooting

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Due to remedy procedures in the following trouble shooting chart it may be necessary to re-rig system, refer to paragraph 10.1.5. |
|---------------|---|

| Trouble                                       | Probable Cause  | Remedy  |
|---|---|---|
| Rudder does not respond to pedal movement.    | Broken or disconnected cables.                        | Connect or replace cables.                                |
| Binding or jumpy movement of rudder pedals.   | Cables too tight.                                     | Adjust cable tension in accordance with paragraph 10.1.5. |
|   | Cables not riding properly on pulleys.                | Route cables correctly over pulleys.                      |
|   | Binding, broken or defective pulleys or cable guards. | Replace defective pulleys and install guards properly.    |
|   | Defective pedal bar bearings.                         | Replace bearings.   |
|   | Worn nose gear bearings.                              | Replace bearing sleeves of dip tube.                      |
| Lost motion between rudder pedals and rudder. | Insufficient cable tension.                           | Adjust cable tension in accordance with paragraph 10.1.5. |
| Incorrect rudder travel.                      | Incorrect rigging.                                    | Rig system in accordance with paragraph 10.1.5.           |


### 10.1.2 Rudder Pedal Assembly

#### 10.1.2.1 Removal and Installation

- **Required Tools:** Standard metric tools
  - **Required Parts:** 10x self-locking nut (M6), 4x self-locking nut (M10)
  - **Level of Maintenance:** Heavy
  - **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center
- a. Disconnect cables (6) from rudder pedals.
  - b. Disconnect connecting link (7) from rudder pedals.
  - c. Unscrew brackets (8) from fuselage and remove pedal assemblies (1 & 2).
  - d. Reverse preceding steps for reinstallation.
  - e. Rig system in accordance with applicable paragraph in this section, safety cable tensioners and reinstall all items removed in step a.

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | Rudder bar assemblies should be checked for excessive wear before installation. All bearings used are maintenance free and must not be lubricated. Replace bearings if binding or slackness is determined. Do not reuse self-locking nuts. |
|---------------|--|

Figure 10-1



### 10.1.3 Rudder

#### 10.1.3.1 Removal and Installation

- **Required Tools:** Standard metric tools, edge cutter
  - **Required Parts:** Safety wire (1.0 mm)
  - **Level of Maintenance:** Heavy
  - **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center
- 
- a. Disconnect tail navigation light quick-disconnect.
  - b. Relieve cable tension at cable tensioner (Figure 10-3).
  - c. Disconnect cables from rudder.
  - d. Remove lower hinge bolt and slide rudder upward to disengage upper hinge bolt.
  - e. Reverse preceding steps for installation.
  - f. Rig system in accordance with applicable paragraph in this section and safety clevises, secure hinge bolt by wire.

#### 10.1.3.2 Repair

Repair may be accomplished as outlines in Section 17. Further repair is limited to restoring dents or smaller cracks on edges. Since the elevator is designed as carbon fiber sandwich component, it is strongly recommended to replace or return to factory for repair, if larger damage or deterioration of the skin is dedicated.


## 10.1.4 Cables and Pulleys

### 10.1.4.1 Removal and Installation

- **Required Tools:** Crimping tool
  - **Required Parts:** 2 x 2.5 mm crimp sleeves
  - **Level of Maintenance:** Heavy
  - **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center
- 
- a. Remove seats and baggage compartment (refer to Section 3).
  - b. Disconnect cables at rudder pedals (Figure 10-1).
  - c. Cut of crimp sleeves at the cable to rudder connection.
  - d. Remove pulleys and fairleads as necessary to work cables free of aircraft.
  - e. After cable is routed in position, install pulleys fairleads and cable guards. Ensure cable is positioned in pulley groove as illustrated in figure 10-2.
  - f. Rig system in accordance with applicable paragraph in this section, safety cable tensioners and reinstall all items removed in step “a”.

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | To ease routing of cables, a length of wire may be attached to end of cable before being withdrawn from aircraft. Leave wire in place, routed through structure, attach cable being installed and pull cable into position. |
|---------------|---|

Figure 10-2



## 10.1.5 Rigging

- **Required Tools:** Standard metric tools
  - **Required Parts:** Safety wire (1.0 mm)
  - **Level of Maintenance:** Heavy
  - **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center
- 
- a. Align rudder with fin to neutral position.
  - b. Adjust cables at cable tensioners (Figure 10-3) to achieve a neutral pedal setting.
  - c. Adjust cable tension for proper operation and pedal motion without binding.
  - d. Safety cable tensioners with safety wire.
  - e. Adjust length of connecting links (1 / figure 10-4) to achieve alignment of nose wheel and rudder.

### ▲ WARNING

Be sure rudder moves in correct direction when operated by pedals.

Figure 10-3





Figure 10-4




### **10.2 Rudder Trim Tab**

A trim tab is attached to the right side of the rudder. The trim tab is 60mm wide (30mm of it are attached to the rudder) and 200mm long. The trim tab is located on the trailing edge of the rudder, 350mm from the lower edge. Bond Teroson Terostat MS9380 is used in the process of manufacturing. Alternative bonds may be used. It is recommended to use bond that keep certain flexibility after the curing process.

Bend the tab slightly in case the aircraft does not fly straight. In case left rudder is required bend the tab to the left and vice versa. Use small steps of app. 10deg in bending and several trials to find out the optimum position of the tab.

Keep in mind: The amount of left or right rudder differs not only with tolerances of the aircraft, but also with the flight regime. At low airspeeds with high power more right rudder is required than in flight at high speed with the same power setting. This has aerodynamic reasons and shall not be associated with airframe tolerances.

Figure 10-5





## 10.3 Bill of Materials

| Fig. No. | Item No. | Order No. | Part No.          | Qty. per Assy | Description                                    | Appl. S/N |
|----------|----------|-----------|-------------------|---------------|--|-----------|
| 10-1     | 1        | 100688    | G3-8 CS-20-00-03  | 1             | Assembly Pedal Right                           | All       |
|          | 2        | 100687    | G3-8 CS-20-00-02  | 1             | Assembly Pedal Left                            | All       |
|          | 3        | 100229    |                   | 1             | Washer 10.5 ISO 7090                           | All       |
|          | 4        | 100226    |                   | 1             | Self Locking Nut M10x1 DIN 985                 | All       |
|          | 5        | 100686    | G3-8 CS-20-00-04  | 1             | Assembly Pedal Storing                         | All       |
|          | 6        | 100683    | G3-8 REP-00-00-06 | 1             | Plate Washer 20x6                              | All       |
|          | 7        | 100221    |                   | 1             | Self Locking Nut M6 DIN 985 vz                 | All       |
| 10-2     | 1        | 100695    | G3-8 CS-50-00-00  | 1             | Assy Fairlead Front                            | All       |
|          | 2        | 100696    | G3-8 CS-50-00-01  | 1             | Assy Fairlead Rear                             | All       |
|          | 3        | 100697    | G3-8 CS-50-00-02  | 1             | Control Wire Rudder                            | All       |
| 10-3     | 1        | 100221    |                   | 1             | Self Locking Nut M6 DIN 985 vz                 | All       |
|          | 2        | 100231    |                   | 1             | Washer 6.4 ISO 7091 vz                         | All       |
|          | 3        | 102178    | G3-8 REP-00-02-02 | 1             | Hexagon Bolt M6x37                             | All       |
|          | 4        | 102215    | G3-8 CS-50-04-04  | 1             | Cable Tensioner Collar Bushing                 | All       |
|          | 5        | 102384    | G3-8 CS-50-04-01  | 1             | Clamp Wire Ring Eye                            | All       |
|          | 6        | 102388    |                   | 1             | Nut M5 DIN934 8.8 vz Drilled, Left-Hand Thread | All       |
|          | 7        | 102387    |                   | 1             | Nut M5 DIN934 8.8 vz Drilled                   | All       |
| 10-4     | 1        | 100684    | G3-8 CS-20-00-05  | 1             | Assembly Nose Wheel Drive                      | All       |
|          | 2        | 100683    | G3-8 REP-00-00-06 | 2             | Plate Washer 20x6                              | All       |
|          | 3        | 100221    |                   | 2             | Self Locking Nut M6 DIN 985 vz                 | All       |
| 10-4     | 1        | 102337    | G3-8 FU-03-01-10  | 1             | Trim Tab Rudder                                | All       |

## Section 11

### *Engine*

| <b>Table of Contents</b>                                     | <b>Section</b> |
|--|----------------|
| 11.1 Preamble .....  | 3              |
| 11.2 Engine Cowling, Description.....                        | 3              |
| 11.2.1 Removal and Installation .....                        | 3              |
| 11.2.2 Cleaning and Inspection .....                         | 3              |
| 11.3 Engine, Description .....                               | 3              |
| 11.3.1 Trouble Shooting .....                                | 4              |
| 11.3.2 Removal.....  | 6              |
| 11.3.3 Cleaning.....   | 7              |
| 11.3.4 Accessories Removal .....                             | 7              |
| 11.3.5 Inspection .....                                      | 8              |
| 11.3.6 Engine Build-Up.....                                  | 8              |
| 11.3.7 Installation (refer to figure 11-1) .....             | 8              |
| 11.3.8 Flexible Fluid Hoses .....                            | 11             |
| 11.3.8.1 Leak Test.....                                      | 11             |
| 11.3.8.2 Replacement.....                                    | 11             |
| 11.3.9 Static Run-Up Procedure.....                          | 11             |
| 11.4 Engine Mount, Description (refer to figure 11-1.) ..... | 12             |
| 11.4.1 Removal and Installation .....                        | 12             |
| 11.4.2 Repair .....  | 12             |
| 11.4.3 Shock-Mount Pads .....                                | 12             |
| 11.5 Engine Oil System, Description .....                    | 12             |
| 11.5.1 Trouble Shooting .....                                | 13             |
| 11.5.2 Filter Element Removal and Installation .....         | 14             |
| 11.6 Engine Fuel System, Description .....                   | 14             |
| 11.6.1 Carburetor Removal and Installation .....             | 15             |
| 11.6.2 Idle Speed Adjustment .....                           | 15             |
| 11.6.3 Carburetor Synchronizing.....                         | 16             |
| 11.7 Induction Air System, Description.....                  | 16             |
| 11.7.1 Removal and Installation .....                        | 16             |
| 11.8 Ignition System, Description .....                      | 16             |
| 11.8.1 Magneto Removal and Installation .....                | 16             |

|          |   |    |
|----------|---|----|
| 11.8.2   | Magneto Check.....                      | 17 |
| 11.8.3   | Spark Plugs .....                       | 17 |
| 11.9     | Engine Controls, Description .....      | 17 |
| 11.9.1   | Rigging.....                            | 20 |
| 11.9.1.1 | Throttle Control .....                  | 20 |
| 11.9.1.2 | Choke Control.....                      | 21 |
| 11.9.1.3 | Carburetor Heat Control .....           | 21 |
| 11.9.1.4 | Oil Temperature Regulator Control ..... | 22 |
| 11.10    | Starting System, Description .....      | 22 |
| 11.10.1  | Trouble Shooting .....                  | 22 |
| 11.10.2  | Removal and Installation .....          | 23 |
| 11.11    | Exhaust System, Description.....        | 23 |
| 11.11.1  | Removal.....                            | 23 |
| 11.11.2  | Inspection .....                        | 24 |
| 11.11.3  | Installation.....                       | 24 |
| 11.12    | Extreme Weather Maintenance .....       | 26 |
| 11.12.1  | Cold Weather.....                       | 26 |
| 11.12.2  | Hot Weather.....                        | 26 |
| 11.12.3  | Dusty Conditions.....                   | 26 |
| 11.12.4  | Seacoast and Humid Areas .....          | 26 |
| 11.13    | Bill of Materials .....                 | 27 |

---

## 11.1 Preamble

This chapter only deals with the engine integration and not with the engine itself. If you need further information about the engine and its components, please refer to the ROTAX Manuals.

|             |  |
|-------------|--|
| <b>NOTE</b> | Hereby REMOS approves all publications, modifications and updates released by ROTAX. |
|-------------|--|

|             |  |
|-------------|--|
| <b>NOTE</b> | Hereby REMOS defines contrary to the ROTAX Maintenance Manual that all hoses do <b>NOT</b> need to be replaced after 5 years. REMOS approves that all hoses are used <b>ON CONDITION</b> . |
|-------------|--|

## 11.2 Engine Cowling, Description

The engine cowling is comprised of an upper and lower cowl segment. A small access door on the upper cowl provides access to the oil filler cap, and oil dipstick, as well as to check cooling fluid level. Quick-release fasteners are used at the cowling-fuselage mount attach points to facilitate detachment of the cowling at the firewall. Quick-release fasteners are used along the side parting surfaces to hold cowling segments together. Both cowl segments are constructed from carbon fiber composites.

### 11.2.1 Removal and Installation

- **Required Tools:** Standard metric tools
- **Required Parts:** None
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

Removal and installation of engine cowling is accomplished by releasing the quick-release fasteners at side parting surfaces. Disconnect electrical wiring to landing light in lower cowling (if installed). First remove the upper cowling by disengaging it from the lower cowling at the nose of the cowling, then lift up upper cowling segment. Loosen quick-release fasteners of the lower cowling segment and remove to the front. When installing the cowling, be sure to connect landing light, disconnected during removal.

### 11.2.2 Cleaning and Inspection

Wipe the inner surfaces of the cowling segments with a cloth saturated with cleaning solvent. If the inside surface of the cowling is coated heavily with oil and dirt, allow solvent to soak until foreign material can be removed. Wash painted surfaces of cowling with a solution of mild soap and water and rinse thoroughly. After washing, a coat of wax applied to painted surface is recommended to prolong paint life. After cleaning, inspect cowling for cracks. Repair all defects to prevent spread of damage.

## 11.3 Engine, Description

The ROTAX 912 Series engines are 4-stroke, 4 cylinders horizontally opposed, spark ignition engines, featuring one central camshaft with push rods and OHV (overhead valves). Cylinder heads are liquid cooled. Lubrication system is a dry sump forced type. It is equipped with dual breakerless capacitor discharge ignition and two constant velocity carburetors. Prop drive is via reduction gear with integrated shock absorber and overload clutch. Specific engine data are given in the latest ROTAX Manual.

## 11.3.1 Trouble Shooting

Refer to Rotax 912 UL/S Maintenance Manual, latest issue. This table should be understood as a general guide to locate engine failures.

| Trouble   | Probable Cause  | Remedy   |
|---|---|--|
| Engine will not start.                                      | Fuel tank empty.                                      | Fill with proper grade of gasoline.  |
|   | Improper use of starting procedure.                   | Review starting procedure.   |
|   | Fuel shut-off valve closed.                           | Set shut-off valve "Open".   |
|   | Tank screen or fuel lines plugged.                    | Remove and clean thoroughly. Remove moisture.  |
|   | Engine flooded.                                       | Refer to paragraph 11.11.2   |
|   | Defective ignition system.                            | Refer to paragraph 11.7.1  |
|   | Excessive induction air leaks.                        | Correct the cause of leaks.  |
|   | Defective magneto switch or grounded magneto leads.   | Check continuity. Repair or replace switch or wiring.  |
|   | Defective carburetor.                                 | Repair or replace carburetor.  |
|   | Spark plugs fouled or improperly gapped.              | Remove and clean: Check gaps and insulators. Check cables to persistently fouled plugs. Replace defective plugs. |
|   | Defective magnetos or ignition amplifiers.            | Replace defective parts in accordance with Rotax maintenance manual.   |
|   | Spark plugs loose.                                    | Tighten to specified torque.   |
|   | Water in fuel system.                                 | Drain fuel tank sump, fuel lines and carburetors.  |
|   | Excessive starter slippage.                           | Replace starter motor.   |
| Engine will not run at idling speed.                        | Idle speed incorrectly adjusted.                      | Refer to paragraph 11.5.2  |
|   | Carburetor idling jet plugged.                        | Clean carburetor.  |
|   | Air leak in intake manifold.                          | Tighten loose connections or replace damaged parts.  |
|   | Spark plugs fouled by oil escaping past piston rings. | Top overhaul engine.   |
| Rough idling.   | Idle speed incorrectly adjusted.                      | Refer to paragraph 11.5.2  |
|   | Fouled spark plugs.                                   | Remove and clean, adjust gaps. Test harness cables. If persistent perform top overhaul.                          |
|   | Small air leak into induction system.                 | Tighten connections or replace damaged parts.  |
|   | Defective engine.                                     | Check compression and listen for unusual engine noises. Engine repair is required.                               |
| Engine does not accelerate properly.                        | Cold engine.  | Warm up longer.  |
|   | Restriction in carburetor air intake.                 | Remove restriction and clean filter.   |
|   | Restriction in carburetor jets, low float level.      | Clean and repair carburetor.   |
|   | Incorrect carburetor synchronizing.                   | Synchronize carburetors in accordance to Rotax maintenance manual.   |
|   | Incorrect idle setting.                               | Refer to paragraph 11.5.2  |
| Engine does not shut off with ignition key in off-position. | Broken wiring or defective magneto switch.            | Repair wiring or replace magneto switch.   |

|                                   |  |   |
|-----------------------------------|--|---|
| Engine runs rough at high speed.  | Loose mounting bolts or rubber pads defective.             | Tighten bolts or replace mounting pads.   |
|                                   | Propeller out of balance.                                  | Remove and balance.   |
|                                   | Spark plug gap too large or insulator damaged.             | Replace damaged parts.  |
|                                   | Ignition cable insulation damaged.                         | Test for leakage at high voltage and replace damaged ignition lead.   |
|                                   | Float chamber bleed hoses disconnected or broken.          | Connect or replace bleed hoses.   |
| Sluggish operation and low power. | Throttle not opening completely.                           | Rig per paragraph 11.8.1.1  |
|                                   | Spark plugs fouled or improperly gapped.                   | Remove, clean and regap or install new plugs.   |
|                                   | Incorrect carburetor synchronizing.                        | Synchronize carburetors in accordance to Rotax maintenance manual.  |
|                                   | Incorrect carburetor mixture setting.                      | Adjust carburetors in accordance with Rotax maintenance manual.   |
| High cylinder head temperature.   | Low grade fuel.  | Drain and fill with correct grade of fuel. Refer to Section 2.  |
|                                   | Excessive carbon deposits in cylinder head and on pistons. | Install new cylinders and piston rings or new engine.   |
|                                   | Low water level in cooling system.                         | Refill with suitable coolant and check for leaks.   |
|                                   | Dirt between cylinder fins.                                | Clean thoroughly.   |
| High oil temperature.             | Low oil supply.  | Replenish.  |
|                                   | Oil viscosity too high.                                    | Refer to Section 2 for seasonal grades.   |
|                                   | Oil regulator flap closed.                                 | Set oil regulator flap to open position.  |
|                                   | Prolonged high speed operation on ground.                  | Hold ground running above 2500 rpm to a minimum.  |
| Low oil pressure.                 | Low oil supply.  | Replenish.  |
|                                   | Oil viscosity too low.                                     | Drain and refill with correct seasonal grade. Refer to Section 2.   |
|                                   | Foam in oil due to emulsification of alkaline solids.      | Drain and refill with fresh oil. Refer to Section 2 for seasonal grade.                                     |
|                                   | Defective pressure sensor.                                 | Replace pressure sensor.  |
|                                   | Oil pump defective.  | Remove and inspect. Examine engine. Metal particles from damaged pump may have entered engine oil passages. |
|                                   | Oil pressure line broken, disconnected or pinched.         | Inspect, replace or connect line.   |
|                                   | Internal leak, burned bearings, or damaged gasket.         | Major overhaul.   |
| Oil leak at propeller shaft.      | Damaged propeller driveshaft seal.                         | Replace in accordance with Rotax maintenance manual.  |
| Low compression.                  | Cylinder wall-coating worn.                                | Replace cylinder and rings.   |
|                                   | Intake valves guides worn.                                 | Top overhaul.   |
|                                   | Valves seats and faces worn.                               | Top overhaul.   |
|                                   | Piston rings excessively worn.                             | Top overhaul.   |
|                                   | Valves sticking in guides.                                 | Top overhaul.   |

## 11.3.2 Removal

- **Required Tools:** Standard metric tools, edge cutter, gripper
- **Required Parts:** Insulating tape
- **Level of Maintenance:** Heavy
- **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center

If the engine is to be placed in storage or returned to the manufacturer for overhaul, proper preparatory steps should be taken prior to beginning the removal procedure. Refer to Temporary Storage in Section 2 for preparation of the engine for storage. The following engine removal procedure is based upon the engine being removed from the aircraft with the engine mount attached to the engine and all engine hose and lines being disconnected at the firewall. The reason for engine removal will determine where components are to be disconnected.

|               |  |
|---------------|--|
| ♦ <b>NOTE</b> | Tag each item disconnected to aid in identifying wires, hoses, lines and control cables when engine is being installed. Protect openings, exposed as a result of removing or disconnecting units, against entry of foreign material by installing covers or sealing with tape. |
|---------------|--|

- a. Place all cabin switches and fuel valves in the OFF position.
- b. Remove engine cowlings. (See paragraph 11.1.1)
- c. Open battery circuit by disconnecting battery cable(s) at the battery. Insulate cable terminal(s) as a safety precaution.
- d. Disconnect all wiring at the terminals on the firewall (located in the REMOS Connector-Box on the left-hand side of the firewall).
- e. Disconnect wiring at voltage regulator terminal (located on lower left-hand side of the firewall) and remove cable ties and clamps as required.
- f. Disconnect ground wiring from center of firewall.
- g. Drain oil from engine (refer to the REMOS GX POH, Section 8).
- h. Remove propeller and spinner (see Section 13).
- i. Drain water from the engine cooling system by disconnecting one water radiator hose and opening the expansion tank cap.
- j. Disconnect hose connection to overflow bottle at upper right side of the firewall.
- k. Disconnect throttle and choke control at carburetor and oil-temperature control from regulation flap assembly at oil cooler. Pull these controls free of engine and engine mount, using care not to damage them by bending too sharply.
- l. Disconnect carburetor heat control from arm on carburetor heat air intake housing assembly. Remove cable ties and pull control aft clear of the engine and disconnect cabin heat hose from heater shell at exhaust system.
- m. Disconnect oil hoses from oil tank (located on the right-hand side of the firewall).
- n. Disconnect fuel-, fuel-return- and fuel pressure (if installed) hose from firewall.

- o. Attach a hoist to the inlet manifolds on top of the engine and take up engine weight on hoist.
- p. Remove bolts attaching mount-to-firewall. Note direction of bolt installation and position and numbers of washers. Balance the engine by hand as the last of the bolts are removed.
- q. Disengage exhaust retaining springs and remove exhaust system.
- r. Remove exhaust downpipes from cylinder head (mark each downpipe location for reinstallation).
- s. Unscrew engine-to-mount screws and remove engine mount.
- t. Carefully guide disconnected components out of engine assembly.

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | During the following procedures, remove any clamps or cable ties which secure controls, wires, hose, or lines to the engine, engine mount, or attached brackets, so that they will not interfere with removal of the engine. Omit any of the items which are not present on a particular engine installation. |
|---------------|---|

|                  |  |
|------------------|--|
| <b>▲ WARNING</b> | Residual fuel and oil draining from disconnected lines and hose is a fire hazard. Use care to prevent accumulation of such fuel and oil when lines or hose are disconnected. |
|------------------|--|

|                  |  |
|------------------|--|
| <b>■ CAUTION</b> | Attach a tail stand to the tail before removing the engine. The loss of engine weight will allow the tail to drop. Do not raise engine higher than necessary when removing mount-to-firewall bolts. Raising the engine too high places a strain on the attach bolts and hinders their removal. |
|------------------|--|

|                  |   |
|------------------|---|
| <b>■ CAUTION</b> | Hoist engine slowly and ascertain that all items attaching engine and accessories to airframe are disconnected. |
|------------------|---|

### 11.3.3 Cleaning

The engine may be cleaned with a suitable solvent, then dried thoroughly.

|                  |   |
|------------------|---|
| <b>■ CAUTION</b> | Particular care should be given to electrical equipment before cleaning. Solvent should not be allowed to enter magnetos, starter, alternator and the like. Hence, protect these components before saturating the engine with solvent. Cover any fuel, oil and air openings on the engine and accessories before washing the engine with solvent. Caustic cleaning solutions should be used cautiously and should always be properly neutralized after their use. |
|------------------|---|

### 11.3.4 Accessories Removal

Removal of engine accessories for overhaul or for engine replacement involves stripping the engine of parts, accessories, and components to reduce the engine assembly to the bare engine. During removal, carefully examine removed items and tag defective parts for repair or replacement by a new part.



|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Items easily confused with similar items should be tagged to provide a means of identification when being installed on a new engine. All openings exposed by the removal of an item should be closed by installing a suitable cover or cap over the opening. This will prevent entry of foreign particles. If suitable covers are not available, tape may be used to cover the opening. |
|---------------|---|

### **11.3.5 Inspection**

For specific items to be inspected refer to engine manufacturer's manual.

- a. Visually inspect the engine for loose nuts, bolts, cracks and fin damage.
- b. Inspect brackets for cracks, deterioration and breakage.
- c. Inspect all hoses for internal swelling, chafing through protective plies, cuts, breaks, stiffness, damaged threads and loose connections. Excessive heat on hoses will cause them to become brittle and easily broken. Hoses and lines are most likely to crack or break near the end fittings and support points.
- d. Inspect for color bleaching of the end fittings or severe discoloration of the hoses.
- e. All flexible fluid carrying hoses in the engine compartment should be replaced at engine overhaul or every five years, whichever occurs first.
- f. For major engine repairs, refer to the manufacturer's overhaul and repair manual.

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Avoid excessive flexing and sharp bends when examining hoses for stiffness. |
|---------------|---|

### **11.3.6 Engine Build-Up**

Engine build-up consists of installation of parts, accessories and components to the basic engine to build-up an engine unit ready for installation on the aircraft. All safety wire, lockwashers, pal nuts, elastic stop nuts, gaskets and rubber connections should be new parts.

### **11.3.7 Installation (refer to figure 11-1)**

- **Required Tools:** Standard metric tools
- **Required Parts:** On condition
- **Level of Maintenance:** Heavy
- **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center


Before installing the engine on the aircraft, install any items that were removed from the engine after it was removed from the aircraft.

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Remove all protective covers, plugs, caps and identification tags as each item is connected or installed. |
|---------------|---|

- a. Hoist engine assembly at the inlet manifold on top of the engine.
- b. Install new shock mounts to the engine mount (refer to figure 11-1.)
- c. Place engine mount to the engine brackets and tighten engine-to-mount bolts to a torque value of 40 Nm/350 in.lb. Secure screws by wire, refer to figure 11-1 for installation details.
- d. Install exhaust downpipes and exhaust system, do not tighten retaining screws at that time.
- e. Move complete assembly to firewall and align screw holes of the engine mount-to-firewall.
- f. Install engine-to-firewall screws and tighten to a torque value of 40Nm/350 in.lb.
- g. Remove hoist and stand placed under the tail.
- h. Connect carburetor heat control to arm on carburetor heat air intake housing assembly and secure by cable tie to air intake hose.
- i. Connect oil temperature control to oil regulator flap assembly and secure by cable tie to air intake hose (if fitted).
- j. Route throttle and mixture controls to the carburetor and connect as noted in step “k” of paragraph 11.2.3.
- k. Connect lines and hoses as follows:
  - 1) Fuel- and fuel-return hose at firewall
  - 2) Fuel pressure hose at firewall (if fitted)
  - 3) Oil hoses to oil tank
  - 4) Cooling fluid hose from overflow bottle to expansion tank
  - 5) Cabin heat hose to heater shell on exhaust system
  - 6) Install all clamps attaching lines and hoses to engine, engine mount or attached brackets
- l. Connect wires and cables as follows:
  - 1) Ground wiring to firewall
  - 2) Wiring to voltage regulator at firewall
  - 3) Engine wiring to terminal at Remos Connector-Box on firewall
- m. Install all clamps attaching wires and cables to engine, engine mount or attached brackets
- n. Install propeller and spinner (refer to Section 13).
- o. Make sure that routing of exhaust pipes does not interfere with surrounding components and tighten retaining screws on cylinder heads to a maximum torque value of 26 Nm/230 in.lb.
- p. Service engine with proper grade and quantity of engine oil. Refer to engine manufacturers manual or the REMOS GX Pilot Operating Handbook.
- q. Make sure all switches are in the OFF position, and connect battery cable(s) to battery.
- r. Rig throttle, choke and carburetor heat controls in accordance with paragraph 11.8.1 through 11.8.1.4.
- s. Check engine installation for security, correct routing of controls, lines, hoses and tightness of all components.
- t. Bleed engine oil system in accordance with engine manufacturer maintenance manual.

- u. Clean and install carburetor air filter. Be sure all hot and cold air ducts are installed and connected.
- v. Perform engine run-up and make final adjustments on engine controls.
- w. Install engine cowling.

Figure 11-1



## 11.3.8 Flexible Fluid Hoses

### 11.3.8.1 Leak Test

After each 100 hours of engine operation, all flexible fluid hoses in the engine compartment should be checked for leaks as follows:

- a. Examine the exterior of hoses for evidence of leakage or wetness.
- b. Hoses found leaking should be replaced.
- c. Refer to paragraph 11.2.6 for detailed inspection procedures for flexible hoses.

### 11.3.8.2 Replacement

- a. Hoses should not be twisted on installation. Pressure applied to a twisted hose may cause failure or loosening of the nut.
- b. Provide as large a bend radius as possible.
- c. Hoses should have a minimum of one-half inch clearance from other lines, ducts, hoses or surrounding objects or be butterfly clamped to them.
- d. Rubber hoses will take a permanent set during extended use in service.
- e. Straightening a hose with a bend having a permanent set will result in hose cracking. Care should be taken during removal so that hose is not bent excessively, and during reinstallation to assure hose is returned to its original position.

## 11.3.9 Static Run-Up Procedure

In a case of suspected low engine power, a static RPM run-up should be conducted as follows:

- a. Run-up engine, using take-off power, with the aircraft facing 90° right and then left to the wind direction.
- b. Record the RPM obtained in each run-up position.
- c. Average the result of the RPM obtained. At all models it should be within 100 RPM of 5000 RPM.
- d. If the average results of the RPM obtained are lower than stated above, the following recommended checks may be performed to determine a possible deficiency:
  - 1) Check carburetor heat control for proper rigging. If partially open it would cause a slight power loss.
  - 2) Check choke control for proper rigging.
  - 3) Check spark plugs and ignition harness for settings and conditions.
  - 4) Check both magnetos are working properly.
  - 5) Check condition of induction air filter. Clean if necessary.
  - 6) Perform an engine compression check. (Refer to engine Manufacturer's Manual.)

#### ◆ NOTE

Daily changes in atmospheric pressure, temperature and humidity will have a slight effect on static run-up.

## **11.4 Engine Mount, Description (refer to figure 11-1.)**

The engine mount is composed of sections of tubing welded together and reinforced with welded gussets. The purpose of the engine mount is to support the engine and attach the engine to the airframe. The engine is attached to the mount with shock-mount assemblies which absorb engine vibrations.

### **11.4.1 Removal and Installation**

- **Required Tools:** Standard metric tools
- **Required Parts:** Safetying wire (1.0 mm)
- **Level of Maintenance:** Heavy
- **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center

Removal of the engine mount necessitates removal of the engine, followed by removal of the bolts attaching the engine-to-mount. The engine and engine mount may be removed from the aircraft and then engine removed from the mount. Refer to paragraph 11.2.8 for detailed information.

### **11.4.2 Repair**

Perform engine mount repair as outlined in Section 18. The mount should be painted with heat-resistant grey enamel after welding or whenever original finish has been removed.

### **11.4.3 Shock-Mount Pads**

The rubber shock-mounts are designed to reduce transmission of engine vibrations to the airframe. The rubber parts should be wiped with a clean dry cloth. Inspect rubber parts for swelling, cracking, or pronounced set of the part. Replace with new parts all parts that show evidence of wear or damage.

## **11.5 Engine Oil System, Description**

The Rotax 912 Series engine is provided with a dry sump forced lubrication system with a main oil pump with integrated pressure regulator and oil pressure sensor. The oil pump is driven by the camshaft. The oil pump sucks the motor oil from the oil tank via the oil cooler and forces it through the oil filter to the points of lubrication in the engine. The surplus oil emerging from the points of lubrication accumulates on the bottom of crankcase and is forced back to the oil tank by the blow-by gases. A vent line on the oil tank provides venting of the circuit. An oil temperature sensor for reading of the oil inlet temperature is located on the oil pump housing. Refer also to the latest engine Operators Manual for detailed information.

## 11.5.1 Trouble Shooting

The following listing should be understood as quick reference guide to locate particular trouble which may occur to the engine oil system. For detailed information refer to the latest engine manufacturers Maintenance Manual.

| Trouble               | Probable Cause   | Remedy  |
|-----------------------|--|---|
| No oil pressure.      | No oil in system.  | Fill system with proper grade and quantity of oil. Refer to Section 1.                                    |
|                       | Oil pressure line broken, disconnected or pinched.         | Replace or connect.   |
|                       | Defective oil pressure sensor.                             | Replace oil pressure sensor.  |
|                       | Wiring of oil pressure sensor broken or disconnected.      | Connect or repair wiring.   |
|                       | Oil pump defective.  | Remove and inspect in accordance with the Rotax Maintenance Manual.                                       |
| Low oil pressure.     | Defective oil pressure sensor.                             | Replace oil pressure sensor.  |
|                       | Defective oil pressure gauge.                              | Replace or repair Rotax Flydat.   |
|                       | Low viscosity oil.   | Drain oil and refill with proper grade and quantity of oil.   |
|                       | Oil pump defective.  | Remove and inspect in accordance with the Rotax Maintenance Manual.                                       |
|                       | Oil pump suction tube screen plugged or internal oil leak. | Engine overhaul required.   |
|                       | Secondary result of high oil temperature.                  | Observe oil temperature gauge for high indication. Determine and correct reason for high oil temperature. |
|                       | Oil system not bled correctly.                             | Bleed oil system in accordance with Rotax Maintenance Manual.   |
|                       | Oil filter element not tight.                              | Tighten oil filter in accordance with Rotax Operators Manual.   |
| High oil pressure.    | Defective oil pressure sensor.                             | Replace oil pressure sensor.  |
|                       | Defective oil pressure gauge.                              | Replace or repair Rotax Flydat.   |
|                       | High viscosity oil.  | Drain oil and refill with proper grade and quantity of oil  |
| Low oil temperature.  | Defective oil temperature sensor.                          | Replace oil temperature sensor.   |
|                       | Defective oil temperature gauge.                           | Replace or Repair Rotax Flydat.   |
| High oil temperature. | Excessive rate of climb.                                   | Avoid low airspeed.   |
|                       | Closed oil cooler flap.                                    | Move flap to "open" position.   |
|                       | Defective oil temperature sensor.                          | Replace oil temperature sensor.   |
|                       | Defective oil temperature gauge.                           | Replace or Repair Rotax Flydat.   |
|                       | Low oil supply.  | Refer to Rotax Maintenance Manual.  |
|                       | Oil viscosity too high. Dirty oil.                         | Drain oil and refill with proper grade and quantity of oil.   |
|                       | Prolonged high speed operation on the ground.              | Hold ground running above 2500 rpm to a minimum.  |

## 11.5.2 Filter Element Removal and Installation

- **Required Tools:** Standard metric tools, edge cutter
  - **Required Parts:** Cable ties
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- 
- a. Remove engine cowling as necessary for access.
  - b. Unscrew oil filter from oil pump at the front of the engine. Oil will drain from oil filter as it is removed from engine.
  - c. Inspect engine gasket seat for gouges, deep scratches, wrench marks, and mutilation.
  - d. Lubricate gasket of the new filter and screw to engine, do not overtighten filter element.
  - e. Install parts removed for access, and service the engine with proper grade and quantity of engine oil.
  - f. Start engine and check for proper oil pressure. Check for oil leaks after warming up engine.
  - g. Again check for oil leakage after engine has been run at a high power setting (preferably a flight around the field).

|        |   |
|--------|---|
| ◆ NOTE | Before discarding removed filter element, cut the outer skin and check inside for evidence of internal engine damage such as chips or particles from bearings. In new or newly overhauled engines, some small particles or metallic shavings might be found, these are generally of no consequence and should not be confused with particles produced by impacting, abrasion, or pressure. Evidence of internal engine damage found in the oil filter element justifies further examination to determine the cause. |
|--------|---|

|        |  |
|--------|--|
| ◆ NOTE | When installing a new filter element, it is important that the gasket is clean, lubricated and positioned properly, and that the correct amount of torque is applied to the filter. If the filter is under-torqued, oil leakage will occur. If the filter is over-torqued, the filter can possibly be deformed, again causing oil leakage. |
|--------|--|

Lubricate rubber gasket of new filter element with clean engine oil. A dry gasket can cause a false torque value, again resulting in oil leakage.

## 11.6 Engine Fuel System, Description

The engine is equipped with two carburetors mounted at the upper side of the engine. The carburetors are of the constant velocity type, installed to each manifold of the engine. For overhaul and repair of the carburetors refer to the manufacturer's maintenance and repair manual.

## 11.6.1 Carburetor Removal and Installation

- **Parts required:** Standard metric tools
  - **Required Parts:** Self-locking nut (M6), cable ties, lock screws
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- a. Place fuel shut-off valve in the OFF position.
  - b. Remove engine cowling.
  - c. Disconnect flexible hose from intake airbox.
  - d. Remove manifold temperature sensor from top of the airbox.
  - e. Disconnect throttle and choke controls from arms on carburetor. Note EXACT position and size of bushings for reference on reinstallation.
  - f. Disconnect and plug the fuel and air lines at carburetors.
  - g. Remove screws and clamps that attach the airbox to carburetors and engine bracket and remove airbox.
  - h. Loosen bolts and clamps attaching carburetor to intake manifold. Remove carburetors.
  - i. Reverse the preceding steps for reinstallation.
  - j. Rig controls in accordance with applicable paragraph in this Section.
  - k. Check carburetor throttle arm to idle stop arm attachment for security and proper safetying at each normal engine inspection.

## 11.6.2 Idle Speed Adjustment

- **Parts required:** Standard metric tools
  - **Required Parts:** Lock screw
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- a. Set the throttle stop screws to obtain between 1700 and 1800 rpm, with throttle control pulled full out against idle stop.
  - b. Check that both idle stop screws contact its idle stop brackets at the same time and readjust if necessary.
  - c. Apply lacquer to each idle stop screw to secure proper locking.

|               |   |
|---------------|---|
| ◆ <b>NOTE</b> | Idle speed adjustment should be accomplished after the engine has been warmed up. Engine idle speed may vary among different engines. An engine should idle smoothly, without excessive vibration, and the idle speed should be high enough to maintain idling oil pressure and to preclude any possibility of engine stoppage in flight when the throttle is closed. |
|---------------|---|



### **11.6.3 Carburetor Synchronizing**

Synchronizing the carburetors is essential to achieve a smooth engine operation, free from vibrations. Refer to Rotax maintenance manual for advisory about correct synchronization of carburetors.

### **11.7 Induction Air System, Description**

Ram air to the engine enters the induction airbox through an opening in the forward part of the upper engine cowling nose. The air is filtered through a filter which is located at the inlet of the airbox. From the induction airbox the filtered air is directed to the inlet of each carburetor, mounted on the upper side of the engine, and through the carburetor, where fuel is mixed with the air, to the intake manifold. From the intake manifold, the fuel-air mixture is distributed to each cylinder by separate intake pipes. The intake pipes are attached to the cylinders with a two bolt flange which is sealed with a gasket. A distributor box on the air intake contains a valve, operated by a carburetor heat control in the cabin, which permits air from an exhaust heated source to be selected in the event carburetor icing or filter icing should be encountered.

#### **11.7.1 Removal and Installation**

Remove and install induction airbox system as outlined in paragraph 11.5.1.

### **11.8 Ignition System, Description**

The Rotax 912 Series engines are equipped with a dual ignition unit of a breakerless, capacitor discharge design, with an integrated generator. The ignition unit is completely free of maintenance and needs no external power supply. Two independent charging coils located on the generator stator supply one ignition circuit each. The energy is stored in capacitors of the electronic modules. At the moment of ignition 2 each of the 4 external trigger coils actuate the discharge of the capacitors via the primary circuit of the dual ignition coils.

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | The 5 <sup>th</sup> trigger coil is used for revolution counter signal. |
|---------------|---|

#### **11.8.1 Magneto Removal and Installation**

Magnetos are located at the back side of the engine, and to replace them it is necessary to remove the induction airbox first (refer to paragraph 11.5.1). After removing the protection cover on the engine back, access to the magnetos is enabled. Replace Magnetos in accordance to the engine manufacturer's maintenance manual. Install all items removed for access to the magnetos again.

## 11.8.2 Magneto Check

Because the whole ignition system is designed to need no servicing, it is not possible to adjust timing of the ignition system. Therefore checking proper operation of the system is reduced to the drop in engine speed at specified rpm using each magneto separately.

- a. Start and run engine until the oil and cylinder head temperatures are in the normal operating ranges.
- b. Advance engine speed to 4000 rpm.
- c. Turn the ignition switch to the "R" position and note the rpm drop, then return the switch to the "BOTH" position to clear the opposite set of plugs.
- d. Turn the switch to the "L" position and note the rpm drop, then return the switch to the "BOTH" position.
- e. The rpm drop should not exceed 300 rpm on either magneto.

For more detailed information refer to the engine manufacturer's maintenance manual.

## 11.8.3 Spark Plugs

Two spark plugs are installed in each cylinder. The spark plugs are shielded to prevent spark plug noise in the radio and the spark plugs have an internal resistor to provide longer terminal life. Spark plug life will vary with operating conditions. A spark plug that is kept clean and properly gapped will give better and longer service than one that is allowed to collect lead deposits and is improperly gapped. The correct spark plug and gap setting is given in the latest ROTAX Maintenance Manual.


|               |   |
|---------------|---|
| <b>◆ NOTE</b> | At each 100-hour inspection, remove, clean, inspect, and regap all spark plugs. Install lower spark plugs in upper portion of cylinder and install upper spark plugs in lower portion of cylinder at each 100-hour inspection. Since deterioration of lower spark plugs is usually more rapid than of the upper spark plugs, rotating them helps prolong spark plug life. |
|---------------|---|

## 11.9 Engine Controls, Description

Engine controls of the push-pull type include the throttle, choke, oil temperature regulator and carburetor heat controls. The engine controls are equipped with position-locking devices which prevent vibration-induced "creeping" of the controls.



Figure 11-3



## 11.9.1 Rigging

When adjusting any engine control, it is important to check that the control slides smoothly throughout its full range of travel, that it locks securely if equipped with a locking device, and the arm or lever which it operates moves through its full arc of travel.

### ■ CAUTION

Whenever engine controls are being disconnected, pay particular attention to the exact position, size, and number of attaching washers, spacers or bushings. Be sure to install attaching parts as noted when connecting controls.

### 11.9.1.1 Throttle Control

- **Required Tools:** Standard metric tools
  - **Required Parts:** Lock screw
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- 
- a. Push throttle to full throttle position and check that both actuator arms on carburetor achieve maximum position.
  - b. Adjust locknut at carburetor end of control as required to achieve the maximum travel of each actuator lever.
  - c. Pull throttle control to idle position.
  - d. Check that both idle stop screws contact its idle lock and adjust if required.
  - e. Check idle speed in accordance with paragraph 11.5.2.
  - f. Check carburetor synchronizing in accordance with paragraph 11.5.3.
  - g. Tighten rod end locknuts at carburetor end of control. Be sure to maintain sufficient thread engagement between rod end and control.

### ◆ NOTE

Before rigging throttle control ensure that control cables are in proper condition.

### ◆ NOTE

Refer to the inspection chart in Section 2 for inspection and / or replacement interval for the throttle control.

**11.9.1.2 Choke Control**

- a. Push choke control to off-position.
- b. Check cable tension for proper setting on carburetor end of control, adjust if required (choke arms on each carburetor must touch to its locks in the off-position).
- c. Pull choke control to on-position.
- d. Check that both arms on carburetor achieve their maximum travel at the same time. If required readjust controls at the locknut on carburetor arm.
- e. Tighten rod end locknuts at carburetor end of control. Be sure to maintain sufficient thread engagement between rod end and control.

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | Before rigging choke control ensure that control cables are in proper condition. |
|---------------|--|

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | Refer to the inspection chart in Section 2 for inspection and / or replacement interval for the choke control. |
|---------------|--|

**11.9.1.3 Carburetor Heat Control**

- a. Insert a new control wire to the carburetor heat conduit.
- b. Push the carburetor heat control full in, then pull it out approximately 1/8 inch from panel for cushion.
- c. Bend and engage end of control wire at carburetor heat lever, to fix the full open position of the air intake control flap.

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | Rigging the carburetor heat control is only possible, if a new control is installed to the aircraft. To replace, cut off the control wire at the carburetor heat housing end and pull out the control knob with the attached control wire from its cover tube. |
|---------------|--|

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | Minor adjustments could be done, by loosening the conduit fixing at the carburetor heat housing bracket. Cable ties and a shrink hose is used to reconnect. Refer to the inspection chart in Section 2 for inspection and / or replacement interval for the choke control. |
|---------------|--|

## 11.9.1.4 Oil Temperature Regulator Control

- a. Loosen clamp securing the control to the bracket on the flap assembly.
- b. Push control full in, then pull it out approximately 1/8 inch from panel for cushion.
- c. Shift the control conduit in its clamp so that flap will come to its most downward position and fix the clamp.
- d. Adjust friction of the flap at its hinge bolt to achieve binding-free operation.

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | Before rigging oil temperature regulator control ensure that control cable is in proper condition. |
|---------------|--|

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | Refer to the inspection chart in Section 2 for inspection and / or replacement interval for the choke control. |
|---------------|--|

## 11.10 Starting System, Description

The automatically engaged starting system employs an electric starter motor mounted at the rear of the engine housing. A starter solenoid is activated by the ignition key on the instrument panel. When the solenoid is activated, its contacts close and electrical current energizes the starter motor.

### 11.10.1 Trouble Shooting

| Trouble   | Probable Cause                                    | Remedy  |
|---|---|---|
| Starter will not operate.                         | Defective master switch or circuit.               | Install new switch or wires.                        |
|   | Defective starter switch or switch circuit.       | Install new switch or wires.                        |
|   | Defective starter motor.                          | Remove, repair or install new starter motor.        |
| Starter motor runs, but does not turn crankshaft. | Starter motor shaft broken.                       | Install a new starter motor.                        |
| Starter motor drags.                              | Low battery.                                      | Charge or install a new battery.                    |
|   | Starter switch or relay contacts burned or dirty. | Install serviceable unit.                           |
|   | Defective starter motor power cable.              | Install new cable.                                  |
|   | Loose or dirty connections.                       | Remove, clean and tighten all terminal connections. |
|   | Defective starter motor.                          | Repair or install a new starter motor.              |

### **11.10.2 Removal and Installation**

- **Required Tools:** Standard metric tools
  - **Required Parts:** Insulating tape
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- 
- a. Remove cowling as required for access.
  - b. Disconnect starter power cable at starter. Insulate terminal on power cable to prevent accidental shorting.
  - c. Remove bolts, attaching starter to crankcase.
  - d. Withdraw starter motor from engine housing.
  - e. Reverse preceding steps for reinstallation.
  - f. Torque starter motor retaining bolts to a torque value in accordance to the engine manufacturer's maintenance manual.

### **11.11 Exhaust System, Description**

The exhaust system consists of a muffler with an exhaust pipe from each cylinder to the muffler. The muffler assemblies are enclosed in shrouds which captures ram air to be heated by the exhaust gases in the muffler. This heated air is used to heat the aircraft cabin. A tail pipe from the muffler routes exhaust gases overboard through the lower cowling. The complete exhaust system is manufactured from stainless steel. Refer to figure 11-5 as a general overview of the exhaust system assemblies.

#### **11.11.1 Removal**

- **Required Tools:** Standard metric tools
  - **Required Parts:** Heat resistant silicone
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- 
- a. Remove engine cowling as required for access.
  - b. Disconnect flexible hose from heater shell on muffler assembly.
  - c. Disengage retaining springs from muffler and remove muffler.
  - d. Remove nuts securing the downpipes to the cylinders.
  - e. Carefully remove downpipes and unscrew exhaust probes from each of the downpipes.



## 11.11.2 Inspection

Inspection of the exhaust system must be very thorough because the cabin heating system uses air heated by the heat exchangers of the exhaust system. Since exhaust system of this type are subject to burning, cracking, and general deterioration from alternate thermal stresses and vibration, inspection is very important and should be accomplished every 100-hour of operation. In addition, an inspection of the exhaust system shall be performed anytime exhaust fumes are detected in the cabin area.

- a. Remove engine cowling, and remove muffler and heater shell so that ALL surfaces of the exhaust system can be visually inspected. Especially check areas adjacent to welds. Look for exhaust gas deposits in surrounding areas, indicating that exhaust gas is escaping through a crack or hole.
- b. For a more thorough inspection, or if fumes have been detected in the cabin, the following inspection is recommended.
  - 1) Remove exhaust pipe and mufflers
  - 2) Use rubber expansion plugs to seal openings
  - 3) Using a manometer or gauge, apply approximately 1-1/2 psi air pressure while the mufflers and each exhaust pipe are submerged in water. All leaks will appear as bubbles and can be readily detected.
- c. It is recommended that any exhaust pipe or muffler found defective be replaced with a new part before the next flight.


## 11.11.3 Installation

Reverse procedure outlined in paragraph 11.10.1 to install exhaust system. Apply high-temperature copper grease to each connection of the exhaust system.

### ◆ NOTE

Figure 11-4 shows exhaust silencer with 4 EGT probes with screwed inserts. If aircraft is equipped with DYNON Avionics there are only 2 EGT probes fixed with hose clamps.

Figure 11-4



## **11.12 Extreme Weather Maintenance**

### **11.12.1 Cold Weather**

Generally, an engine service should be carried out before the start of the cold season. For selection of coolant and mixing ratio refer to the Rotax operator manual. For selection of oil refer to Section 1.

Start engine with throttle closed and choke activated (open throttle renders starting carburetor ineffective). As performance of electric starter is greatly reduced when cold, limit starting to periods not longer than 10 seconds and with a well charged battery (adding a second battery will not improve cold starts).

### **11.12.2 Hot Weather**

Engine misfire characterized by weak, intermittent explosions followed by puffs of black smoke from the exhaust are caused by flooding. This situation is more apt to develop in hot weather or when the engine is hot. If it occurs, repeat the starting routine with the throttle full OPEN. As the engine fires, decrease the throttle setting to desired idling speed.

|                |  |
|----------------|--|
| <b>CAUTION</b> | Never operate the starting motor more than 10 seconds at a time. Allow starter motor to cool between cranking periods to avoid shortening the life of the starter. |
|----------------|--|

### **11.12.3 Dusty Conditions**

Dust inducted into the intake system of the engine is probably the greatest single cause of early engine wear. When operating under high dust conditions, the induction air filter should be serviced daily as outlined in paragraph 2.2.4.

### **11.12.4 Seacoast and Humid Areas**

In salt water areas, special care should be taken to keep the engine and accessories clean to prevent oxidation. In humid areas, fuel and oil should be checked frequently and drained of condensed moisture.

## 11.13 Bill of Materials

| Fig. No. | Item No. | Order No. | Part No.          | Qty. per Assy | Description                               | Appl. S/N |
|----------|----------|-----------|-------------------|---------------|---|-----------|
| 11-1     | 1        | 101722    |                   | 5             | Cylinder Head Screw M10x35 vz DIN912 10.9 | All       |
|          | 2        | 102092    |                   | 5             | Washer M10 ISO7090-200HV-A2K              | All       |
|          | 3        | 100226    |                   | 5             | Selflocking Nut M10 DIN 985               | All       |
|          | 4        | 100221    |                   | 4             | Selflocking Nut M6 DIN 985                | All       |
|          | 5        | 100231    |                   | 4             | Washer M6 vz                              | All       |
|          | 6        | 100875    |                   | 4             | Rubber Buffer cylindric 20x20 - M6x15     | All       |
|          | 7        | 100390    | G3-8_EN-20-00-01  | 4             | Engine Mount Rubber Parts Assembly        | All       |
|          | 8        | 100680    | G3-8_EN-10-00-01  | 1             | Engine Mounting                           | All       |
| 11-3     | 1        | 100457    | G3-8_FU-12-01-07  | 1             | Throttle Rod Main                         | All       |
|          | 2        | 103159    |                   | 1             | Adjusting Ring DIN 705A                   | All       |
|          | 3        | 100437    |                   | 2             | Fuselage Throttle Rod Nut M12x1,5         | All       |
|          | 4        | 101966    |                   | 1             | Washer M12 DIN125 Plastic PA6             | All       |
|          | 5        | 100972    |                   | 1             | Cable Bushing 12x20x24                    | All       |
|          | 6        | 100716    | G3-8_FU-12-01-10  | 1             | Throttle Rod Lever Bearing                | All       |
|          | 7        | 100460    | G3-8_FU-12-01-11  | 1             | Throttle Rod Clamping Sleeve              | All       |
|          | 8        | 100459    | G3-8_FU-12-01-12  | 1             | Throttle Rod Locking Screw                | All       |
|          | 9        | 100222    |                   | 1             | Hexagon Nut M6 DIN934                     | All       |
|          | 10       | 100268    |                   | 1             | Toothed Lock Washer M6 DIN6797 Form A     | All       |
|          | 11       | 100458    | G3-8_FU-12-01-13  | 1             | Throttle Lever                            | All       |
|          | 12       | 100717    | G3-8_FU-12-01-08  | 1             | Throttle Rod Second                       | -         |
|          | 13       | 100284    |                   | 1             | Splint 1,6x12 DIN94 Steel vz              | All       |
|          | 14       | 100232    |                   | 1             | Washer M5 DIN125 FormA Steel vz           | All       |
|          | 15       | 100711    | G3-8_FU-12-01-05  | 1             | Throttle Controls Bolt                    | All       |
|          | 16       | 100239    |                   | 1             | Washer M8 DIN126 Steel vz                 | All       |
|          | 17       | 100224    |                   | 1             | Selflocking Nut M8 DIN985 vz              | All       |
|          | 18       | 100703    | G3-8_REP-40-00-00 | 1             | Swivel Bracket 16mm                       | All       |
|          | 19       | 100231    |                   | 1             | Washer M6 DIN125 FormA Steel vz           | All       |
|          | 20       | 100221    |                   | 1             | Selflocking Nut M6 DIN985 vz              | All       |
|          | 21       | 101863    |                   | 1             | Distanzhülse Metall 5,3x6                 | All       |
| 11-4     | 1        | 103548    | G3-8 EN-90-01-04  | 1             | Exhaust manifold front right              | All       |
|          | 2        | 103549    | G3-8 EN-90-01-01  | 1             | Exhaust manifold rear right               | All       |
|          | 3        | 100894    | G3-8 EN-90-00-01  | 1             | Exhaust manifold front left               | All       |
|          | 4        | 103547    | G3-8 EN-90-01-00  | 1             | Exhaust manifold rear left                | All       |
|          | 5        | 100893    |                   | 8             | Extension Spring Exhaust System           | All       |

*Intentionally left blank*

## Section 12

### *Fuel System*

| Table of Contents |  | Section |
|-------------------|--|---------|
| 12.1              | Fuel System Description .....                | 2       |
| 12.1.1            | Precautions .....                            | 2       |
| 12.1.2            | Trouble Shooting .....                       | 3       |
| 12.1.3            | Fuel Tank Description.....                   | 5       |
| 12.1.4            | Fuel Quantity Transmitter .....              | 7       |
| 12.1.5            | Electrical Fuel Pump.....                    | 8       |
| 12.1.6            | Fuel Filter.....                             | 10      |
| 12.1.7            | Fuel Vent and Fuel Return Line.....          | 10      |
| 12.1.8            | Fuel Shut-Off Valve .....                    | 11      |
| 12.1.9            | Fuel Drain Valve .....                       | 13      |
| 12.1.10           | Fuel Distributor System .....                | 14      |
| 12.1.11           | Firewall Ports and Fuel Pressure Gauge ..... | 17      |
| 12.2              | Bill of Materials .....                      | 18      |

## 12.1 Fuel System Description

The fuel flows from the tank via a coarse filter, a fine filter through the electric fuel pump to the fuel shut-off valve. From there it is routed via the mechanical fuel pump to the fuel distributor and passes on to both carburetors. Via a return line, surplus fuel flows back to the fuel tank. An additional line is routed from the distributor block to the fuel pressure gauge inside the cabin. The return line provides a compensating jet to ensure required fuel pressure, which is fitted at the connection return line-to-distributor.

An advanced layout may be installed, containing a fuel flow sensor and a fuel pressure sensor to provide information for a multifunctional display. Refer to figure 12-1 as a general overview.

### 12.1.1 Precautions

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | There are certain general precautions and rules concerning the fuel system which should be observed when performing the operations and procedures in this section. |
|---------------|--|

These are as follows:

- During all fueling, defueling, tank purging, and tank repairing or disassembly, ground the aircraft to a suitable ground stake. Use the engine or negative battery terminal grounding.
- Residual fuel draining from lines and hose constitutes a fire hazard. Use caution to prevent the accumulation of fuel when lines or hoses are disconnected.
- Cap open lines and cover connections to prevent thread damage and the entrance of foreign matter.

## 12.1.2 Trouble Shooting

| Trouble                         | Probable Cause                                    | Remedy   |
|---------------------------------|---|--|
| No fuel to Carburetor.          | Fuel shut-off valve not turned on.                | Turn valve on.   |
|                                 | Fuel tanks empty.                                 | Service with proper grade and amount of fuel.          |
|                                 | Fuel line disconnected or broken.                 | Connect or repair fuel lines.                          |
|                                 | Fuel tank outlet screen plugged.                  | Drain fuel, remove outlet screen and clean thoroughly. |
|                                 | Fuel filter plugged.                              | Replace fuel filter.                                   |
|                                 | Defective shut-off valve.                         | Replace shut-off valve.                                |
|                                 | Fuel line plugged.                                | Clean out or replace fuel line.                        |
|                                 | Defective mechanical fuel pump.                   | Replace fuel pump.                                     |
| No fuel to Carburetor.          |   |  |
|                                 |   |  |
|                                 |   |  |
| Fuel starvation after starting. | Partial fuel flow from the preceding causes.      | Use the preceding remedies.                            |
|                                 | Plugged fuel vent.                                | See paragraph 12.1.7.1.                                |
|                                 | Water in fuel.                                    | Drain fuel tank sumps, fuel lines and carburetors.     |
| No fuel quantity indication.    | Fuel tanks empty.                                 | Service with proper grade and amount of fuel.          |
|                                 | Blown fuse / circuit breaker.                     | Replace fuse / reset circuit breaker.                  |
|                                 | Loose connection or open circuit.                 | Tighten connections, repair or replace wiring.         |
|                                 | Defective fuel quantity indicator or transmitter. | Refer to Section 15.                                   |
| Fuel overflow from carburetor.  | Binding float valve or dirt in floater chamber.   | Clean and repair carburetor.                           |
|                                 | Plugged fuel distributor or fuel return line jet. | Clean fuel distributor thoroughly.                     |
| Pressurized fuel tank.          | Plugged fuel vent.                                | See paragraph 12.1.7.1.                                |




Figure 12-1



### 12.1.3 Fuel Tank Description

A rigid carbon fiber tank is installed behind the right side of the cabin bulkhead inside the fuselage. A fuel tank sump drain valve is provided for draining trapped water and sediment.

Figure 12-2



#### 12.1.3.1 Removal and Installation (refer to figure 12-3)

- **Required Tools:** Standard metric tools, pliers
  - **Required Parts:** Fuel resistant sealant fluid, safetying wire (0.8 mm)
  - **Level of Maintenance:** Heavy
  - **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center
- 
- a. Push up sump drain valve and rotate 90° to lock, to drain fuel completely from the tank. (Observe precautions outlined in paragraph 12.1.1)
  - b. Remove seats and baggage compartment as outlined in Section 3.
  - c. Disconnect electrical leads and ground strap from fuel quantity transmitter.
  - d. Disconnect fuel vent from tank.
  - e. Disconnect fuel filler hose from fuel filler neck at the fuselage.
  - f. Remove plastic adapter tube and rubber sealing from drain valve and unscrew drain valve from the bottom of the tank.
  - g. Unscrew and remove fuel line and fuel hose fitting/screen from the bottom of the fuel tank.
  - h. Remove all tank retaining screws from the tank and withdraw the tank to the front.
  - i. To install tank, reverse the preceding steps. Be sure grounding is secure in accordance with paragraph 12.1.1.

◆ **NOTE**

Apply appropriate liquid sealant to the threads of drain valve and fuel line connector at reassembling.

Figure 12-3

## Fuel Tank Removal and Installation

Step A: Disconnect Fittings, Hoses and fixing Screws as illustrated



Step B: Withdraw tank from bulkhead as shown. Fuel return hose may be bent backwards or removed to ease tank removal





Figure 12-4



## 12.1.4 Fuel Quantity Transmitter

A fuel quantity transmitter is installed in the top of the fuel tank. A complete description, along with procedures for calibration and troubleshooting are contained in Section 15.

### 12.1.4.1 Removal and Installation (refer to figure 12-4 and 12-5)

- **Required Tools:** Standard metric tools
- **Required Parts:** Cable ties
- **Level of Maintenance:** Heavy
- **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center

To remove the fuel quantity transmitter, the fuel tank has to be removed first, refer to paragraph 12.1.3.1 for detailed information. Remove screws attaching transmitter and carefully work transmitter from tank. Do not bend float arm!

Install transmitter by reversing preceding steps. Service fuel tank and check for leaks and correct quantity indication.

Figure 12-5





Figure 12-6



### 12.1.5 Electrical Fuel Pump


An electrical fuel pump is installed to the fuel line, located adjacent to the fuel tank. Power to the pump is provided by a switch at the switch panel.

#### 12.1.5.1 Removal and Installation (refer to figure 12-6)

- **Required Tools:** Standard metric tools
  - **Required Parts:** Hose clamps
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- a. Plug fuel hoses connected to the pump by the use of two hose clamps.
  - b. Disconnect fuel hoses from the pump.
  - c. Disconnect electrical leads and ground strap from fuel pump.
  - d. Loosen the retaining clamp and remove fuel pump.
  - e. To install fuel pump, reverse the preceding steps. Be sure grounding is secure in accordance with paragraph 12.1.1.



Figure 12-7



### **12.1.6 Fuel Filter**

An additional screen type fuel filter is attached to the fuel hose at the inlet of the electrical fuel pump. Refer to Section 2 for replacement intervals of the fuel filter.

#### **12.1.6.1 Removal and Installation (refer to figure 12-6)**

- **Required Tools:** Standard metric tools, clamp tongs
  - **Required Parts:** Hose clamps, fuel filter
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- 
- a. Plug fuel hoses connected to the filter by the use of two hose clamps
  - b. Disconnect fuel hoses from the filter
  - c. Replace filter
  - d. To install filter, reverse the preceding steps. Be sure grounding is secure in accordance with paragraph 12.1.1

### **12.1.7 Fuel Vent and Fuel Return Line**


A vent line is installed to the fuel tank and extends overboard down through the lower fuselage skin. A fuel return line provides a steady fuel flow to avoid vaporization.

#### **12.1.7.1 Checking**

Dirt may cause the fuel vent to become plugged, with possible fuel starvation of the engine or collapse of the fuel tank. The following procedure may be used to check the vent line.

- a. Attach a rubber tube to the end of vent line beneath the fuselage.
- b. Blow into tube to slightly pressurize the tank. If air can be blown into tank, vent line is open.
- c. After tank is slightly pressurized, insert end of rubber tube into a container of water and watch for a continuous stream of bubbles, which indicates the vent line is clear from obstacles.

Figure 12-8



### 12.1.8 Fuel Shut-Off Valve

The fuel shut-off valve is a two-position ON-OFF valve, located in the center section of the cabin in front of the brake lever. It is recommended that the valve be replaced and not repaired.

#### 12.1.8.1 Removal and Installation (refer to figure 12-8)


- **Required Tools:** Standard metric tools, edge cutter
  - **Required Parts:** Fuel line fittings, cable ties
  - **Level of Maintenance:** Heavy
  - **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center
- 
- a. Completely drain all fuel from tank and fuel lines (Observe the precautions in paragraph 12.1.1)
  - b. Remove seats and baggage compartment (refer to Section 3)
  - c. Remove shut-off valve handle, parking brake valve handle and brake reservoir filler cap. Take care that no brake fluid will get contact with painted surfaces.
  - d. Disconnect fuel line at the firewall and at the rear end hose connection.
  - e. Remove access flaps and center cover panel as far as the forward (located beneath the cockpit) side covers of the center tunnel.
  - f. Remove screws attaching shut-off valve.
  - g. Remove securing cable ties as required from the fuel line located inside the center tunnel.
  - h. Withdraw shut-off valve assembly from the center tunnel.
  - i. Disconnect fuel lines from shut-off valve.
  - j. Reverse the preceding steps for installation.



**CAUTION**

For reconnection of fuel line to firewall a new fuel line fitting has to be used, to avoid leakage.

Figure 12-9



## 12.1.9 Fuel Drain Valve

A fuel drain valve is installed to the bottom of the fuel tank. Access is possible from beneath the fuselage adjacent to the main gear. To drain fuel, push up the white plastic tube. If draining of the whole system is required, push up the plastic tube and rotate 90° to lock the open position of the drain valve.


### 12.1.9.1 Removal and Installation (refer to figure 12-9)

- **Required Tools:** Standard metric tools
  - **Required Parts:** Fuel resistant sealant fluid
  - **Level of Maintenance:** Heavy
  - **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center
- 
- a. Push up sump drain valve and rotate 90° to lock, to drain fuel completely from the tank (Observe precautions outlined in paragraph 12.1.1)
  - b. Remove seats and baggage compartment as outlined in Section 3
  - c. Remove plastic adapter tube and rubber sealing from drain valve and unscrew drain valve from the bottom of the tank
  - d. Reverse the preceding steps for installation. Be sure grounding is secure in accordance with paragraph 12.1.1

#### ◆ NOTE

Apply appropriate liquid sealant to the threads of drain valve at reassembling.

Figure 12-10



## 12.1.10 Fuel Distributor System

### 12.1.10.1 Description (refer to figure 12-10 and 12-11.)

A fuel distributor is installed to provide fuel for both carburetors. The fuel distributor is located on top of the engine. Pressurized fuel from the fuel pump is routed to both carburetors while surplus of fuel flows back to the fuel tank through a return hose. A 0.02 inch compensating jet is built into each rearward side-ports of the distributor to ensure the required fuel pressure. A fuel pressure gauge may be connected to check fuel pressure at the opposite side of the return hose connection.

### 12.1.10.2 Removal and Installation

- **Required Tools:** Standard metric tools, wire-cutting pliers
  - **Required Parts:** Lock screw, copper sealings, hose clamps.
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- 
- a. Drain fuel from fuel lines (Observe precautions outlined in paragraph 12.1.1).
  - b. Disconnect hoses from fuel distributor block.
  - c. Remove clamp securing distributor block to engine.
  - d. Unscrew hose fittings from distributor
  - e. Reverse preceding steps for reinstallation (Observe precautions outlined in paragraph 12.1.1)

|                |  |
|----------------|--|
| <b>CAUTION</b> | Remember position of return hose fitting for reinstallation. |
|----------------|--|

|                |   |
|----------------|---|
| <b>CAUTION</b> | Always use new copper sealing for reinstallation of hose fittings and new hose clamps for hose connections. |
|----------------|---|

### 12.1.10.3 Inspection

Inspect fuel distributor for clean condition, especially check jet drillings for return hose and fuel pressure gauge connection to be unplugged. Clean thoroughly before reassembling with hose fittings. Check also the jet provided in the return hose fitting for clean and unplugged condition.

Figure 12-11

## Fuel Distributor System - Basic Assembly





Figure 12-12


## Fuel Distributor System - for DYNON EMS-120



**12.1.11 Firewall Ports and Fuel Pressure Gauge**

The fuel distributor system is connected to fuel lines routed inside the cabin using the ports C1 and C2 (see paragraph 12.1.10). With the basic installation of the aircraft a fuel pressure gauge is provided, connected to port C3.

Figure 12-13



## 12.2 Bill of Materials

| Fig. No. | Item No. | Order No. | Part No.         | Qty. per Assy | Description                             | Appl. S/N |
|----------|----------|-----------|------------------|---------------|---|-----------|
| 12-2     | 1        | 101126    |                  | 1             | Fuel Quantity Transmitter               | All       |
|          | 2        | 700392    | G3-8 FU-04-00-00 | 1             | Tank                                    | All       |
|          | 3        | 101145    |                  | 1             | Hose 8x6x1 Oil-resistant Transparent    | All       |
| 12-4     | 1        | 103237    |                  | 1             | Filler Cap AERO 200 A26NS               | All       |
|          | 2        | 103109    |                  | 1             | Filler Cap Newton Zero 200              | All       |
| 12-5     | 1        | 101126    |                  | 1             | Fuel Quantity Transmitter               | All       |
| 12-7     | 1        | 101135    |                  | 1             | Electric Fuel Pump 7.21440.0            | All       |
|          | 2        | 101714    |                  | 1             | T-Piece Norma TS 8mm                    | All       |
|          | 3        | 101140    |                  | 1             | Non Return Valve                        | All       |
|          | 4        | 101680    |                  | 1             | Fuel Filter                             | All       |
|          | 5        | 101141    |                  | 1             | T-Piece With Screw Joint TS-8           | All       |
|          | 6        | 100734    | G3-8 FU-04-01-51 | 2             | Fuel System Hose Nipple 8xM12x1,5       | All       |
|          | 7        | 100923    |                  | 1             | Fuel Hose WP8; 65mm                     | All       |
|          | 8        | 100923    |                  | 1             | Fuel Hose WP8; 65mm                     | All       |
|          | 9        | 100923    |                  | 1             | Fuel Hose WP8; 180mm                    | All       |
|          | 10       | 100923    |                  | 1             | Fuel Hose WP8; 170mm                    | All       |
|          | 11       | 100923    |                  | 1             | Fuel Hose WP8; 270mm                    | All       |
|          | 12       | 100923    |                  | 1             | Fuel Hose WP8; 250mm                    | All       |
|          | 13       | 101163    |                  | 12            | Hose Clamp 12-22                        | All       |
|          | 14       | 102313    |                  | 1             | Hose Clamp Norma 35                     | All       |
|          | 15       | 100147    |                  | 1             | Cylinder Head Screw M6x35 vz DIN912 8.8 | All       |
|          | 16       | 100231    |                  | 1             | Washer 6,4 DIN125 Form A Steel vz       | All       |
|          | 17       | 100129    |                  | 1             | Cylinder Head Screw M5x16 vz DIN912 8.8 | All       |
|          | 18       | 100249    |                  | 1             | Washer 5,3x15x1,5 DIN522 A2             | All       |
|          | 19       | 100232    |                  | 1             | Washer 5,3 DIN125 Form A Steel vz       | All       |
|          | 20       | 100218    |                  | 1             | Self Locking Nut M5 DIN985              | All       |
|          | 21       | 101820    |                  | 1             | Seal Ring Copper DIN7603 Form C 12x18x2 | All       |
|          | 22       | 100387    |                  | 1             | Ring Nipple RS8-12 DN06 DIN7642         | All       |
|          | 23       | 101820    |                  | 1             | Seal Ring Copper DIN7603 Form C 12x18x2 | All       |
|          | 24       | 100731    |                  | 1             | Fuel Strainer M12x1,5                   | All       |
| 12-8     | 1        | 103227    |                  | 1             | Fuel Hose ID=18mm                       | All       |
|          | 2        | 100878    |                  | 1             | Hose Clamp 20-32                        | All       |
|          | 3        | 100912    |                  | 1             | Seal Ring Copper 10x16x1                | All       |
|          | 4        | 100733    |                  | 1             | Fuel System Hose Nipple 8xR1/8          | All       |
|          | 5        | 100921    |                  | 1             | Hose Clamp 8-16                         | All       |
|          | 6        | 101142    |                  | 1             | Fuel Hose WP6                           | All       |
| 12-9     | 1        | 101145    |                  | 1             | Hose 8x6x1 Oil-resistant Transparent    | All       |
|          | 2        | 102937    |                  | 2             | Straight Screw In Connection G1/8       | All       |
|          | 3        | 102002    |                  | 2             | Support Sleeve C-EH-8/6- MS             | All       |
|          | 4        | 101175    |                  | 1             | Hose Clamp Norma 17                     | All       |
|          | 5        | 101731    |                  | 2             | Countersunk Screw M5x16 DIN7991 A2-70   | All       |
|          | 6        | 100735    | G3-8 FU-04-01-53 | 1             | Fuel Valve Mounting                     | All       |
|          | 7        | 101042    |                  | 1             | Fuel Valve 1/8"                         | All       |
| 12-10    | 1        | 101128    |                  | 1             | Drain Valve 1/8" NPT Bayonet Style      | All       |
|          | 2        | 101127    |                  | 1             | Drain Valve Sleeve                      | All       |
|          | 3        | 101129    | G3-8 FU-04-01-54 | 1             | Fuel System Drain Tube                  | All       |



| Fig. No. | Item No. | Order No. | Part No.         | Qty. per Assy | Description                       | Appl. S/N |
|----------|----------|-----------|------------------|---------------|-----------------------------------|-----------|
| 12-13    | 1        | 100924    |                  | 1             | Hose DN20 Fire Protection 750mm   | All       |
|          | 2        | 100914    |                  | 1             | Hose DN15 Fire Protection 540mm   | All       |
|          | 3        | 101142    |                  | 1             | Fuel Hose WP6 540mm               | All       |
|          | 4        | 100923    |                  | 1             | Fuel Hose WP8 750mm               | All       |
|          | 5        | 100902    |                  | 1             | Ear Clamp D 15,5mm A2             | All       |
|          | 6        | 100901    |                  | 1             | Ear Clamp D 13,8mm A2             | All       |
|          | 7        | 102882    |                  | 3             | Nut M12x1,5 ISO8675 A2K           | All       |
|          | 8        | 101931    |                  | 4             | Washer 12 DIN125-A2K blank        | All       |
|          | 9        | 100733    | G3-8 FU-04-01-50 | 1             | Fuel System Hose Nipple 8xR1/8    | All       |
|          | 10       | 102907    | G3-8 FU-04-01-55 | 1             | Return Flow Passage               | All       |
|          | 11       | 100921    |                  | 2             | Hose Clamp 8-16                   | All       |
|          | 12       | 101142    |                  | 1             | Fuel Hose WP6                     | All       |
|          | 13       | 102002    |                  | 1             | Support Sleeve C-EH-8/6- MS       | All       |
|          | 14       | 102937    |                  | 1             | Straight Screw In Connection G1/8 | All       |
|          | 15       | 100972    |                  | 2             | Cable Passage 12x20x24            | All       |



*Intentionally left blank*

## Section 13


### *Propeller*

| <b>Table of Contents</b> | <b>Section</b>                                  |
|--------------------------|---|
| 13.1                     | Propeller Fixed Pitch ..... 2                   |
| 13.1.1                   | Repair ..... 2                                  |
| 13.1.2                   | Removal (refer to figure 13-2) ..... 2          |
| 13.1.3                   | Installation (refer to figure 13-2) ..... 3     |
| 13.2                     | Propeller Ground Adjustable (Sensenich) ..... 5 |
| 13.2.1                   | Repair ..... 5                                  |
| 13.2.2                   | Removal (refer to figure 13-4) ..... 6          |
| 13.2.3                   | Installation (refer to figure 13-5) ..... 8     |
| 13.2.4                   | Rigging (refer to figure 13-6) ..... 9          |
| 13.3                     | Propeller Ground Adjustable (Neuform) ..... 10  |
| 13.3.1                   | Repair ..... 11                                 |
| 13.3.2                   | Removal (refer to figure 13-7) ..... 11         |
| 13.3.3                   | Installation (refer to figure 13-7) ..... 11    |
| 13.4                     | Bill of Materials ..... 13                      |

## 13.1 Propeller Fixed Pitch

A composite-wood, fixed-pitch propeller, equipped with either aluminum or a plastic spinner, is used on the REMOS GX aircraft.

Figure 13-1



### 13.1.1 Repair

Repair of a wood propeller first involves evaluating the damage and determining whether the repair is to be a major or minor one. In general all damages except defective paint or small dents has to be rated as major repair. Refer also to propeller manufacturer's manual for further instruction.

We strongly recommend to replace propeller if any cracks, deteriorations of the skin or extended dents are determined.

### 13.1.2 Removal (refer to figure 13-2)

- **Required Tools:** Standard metric tools
  - **Required Parts:** Safetying wire (1.0 mm), silicone compound
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- a. Remove spinner by unscrewing its retaining screws.
  - b. Remove safety wire from mounting bolt heads (2).

- c. Remove bolts and pull propeller forward to remove. Use care to avoid damage to bulkheads as propeller is removed.

|                  |  |
|------------------|--|
| <b>▲ WARNING</b> | Be sure master switch is in OFF position and key removed from starter switch before turning propeller. |
|------------------|--|

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | The spinner (1) is attached to the rear bulkhead with a forward supporting bulkhead. These bulkheads are secured by the propeller mounting bolts (2) and will be free by removal of the bolts as the propeller is removed. A pressure plate (5) is used between the forward support bulkhead and the propeller. |
|---------------|---|

### 13.1.3 Installation (refer to figure 13-2)

Clean mating surfaces of propeller, gearbox flange and spinner bulkheads.

- a. Install propeller and spinner bulkheads. The spinner bulkheads must be positioned so propeller blades will emerge from the spinner with ample clearance.
- b. Tighten the mounting bolts (2) evenly to a torque value of 20 Nm / 176 in.lb.
- c. Safety wire propeller mounting bolts (2).
- d. Apply a bead of silicone compound on the rim of the support bulkhead (4).
- e. Install spinner. When installing the plastic (ABS) type spinner, add a collar bush (13) to each of the fixing screws, to prevent the spinner from cracking around it's fixing holes. Do not overtighten the fixing screws. Hand tight is sufficient!

|                  |  |
|------------------|--|
| <b>▲ WARNING</b> | Be sure master switch is in OFF position and key removed from starter switch before turning propeller. |
|------------------|--|

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Tighten the mounting bolts (11) only hand tight or ABS spinner will be damaged. |
|---------------|---|

Figure 13-2






Figure 13-3



### 13.2 Propeller Ground Adjustable (Sensenich)

A carbon fiber, ground adjustable propeller, equipped with either aluminum or a plastic spinner, is used on the REMOS GX aircraft as standard equipment. It is mandatory to maintain the servicing intervals given in the propeller manufacturer's manual. Figure 13-4 gives a general overview of the propeller installation.

Figure 13-4



#### 13.2.1 Repair

Repair of a carbon fiber propeller first involves evaluating the damage and determining whether the repair is to be a major or minor one. In general all damages except defective paint or small dents has to be rated as major repair. Refer also to propeller manufacturer's manual for further instruction.

We strongly recommend to replace propeller blades if any cracks, deteriorations of the skin or extended dents are determined.

## 13.2.2 Removal (refer to figure 13-4)

- **Required Tools:** Standard metric tools
  - **Required Parts:** None
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- 
- a. Remove spinner by unscrewing its retaining screws.
  - b. Remove all bolts on propeller hub and remove hub and blades.
  - c. Remove mounting bolts (3) and pull propeller hub forward to remove. Use care to avoid damage to bulkheads as propeller is removed.

### ▲ WARNING

Be sure master switch is in OFF position and key removed from starter switch before turning propeller.


### ◆ NOTE

The spinner (1) is attached to the rear bulkhead with a forward supporting bulkhead. These bulkheads are secured by the propeller mounting bolts (3) and retaining screws (11) and will be free by removal of the bolts as the propeller is removed. A mounting bracket (4) is used between propeller hub and the forward support bulkhead which is fixed to the hub by the original Sensenich fixing bolts


Figure 13-5

**Ground Adjustable Sensenich Propeller Installation****Step A**

Apply Lock Washer and Propeller Mounting Bolts and torque to 27 Nm/240 in.lb. NO additional washer must be used here!

**Step B**

Install blades as outlined in the propeller manual. Place spasher shims and mounting bracket using the original Sensenich retaining bolts.

**Step C**

Before completing installation with the spinner dome, refer to paragraph 13.2.4 for correct pitch setting. Refer also to figure 13-2 for detailed instructions about installing the spinner dome.



## 13.2.3 Installation (refer to figure 13-5)

- **Required Tools:** Standard metric tools
- **Required Parts:** Silicone compound, Loctite 243 (medium strength)
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

Clean mating surfaces of propeller, gearbox flange and spinner bulkheads.

- a. Install propeller spacer, guide sleeves and rearward spinner bulkhead. The spinner bulkheads must be positioned so propeller blades will emerge from the spinner with ample clearance.
- b. Install lock washer and propeller mounting bolts as shown in figure 13-5.
- c. Tighten the mounting bolts evenly to a torque value of 27 Nm / 240 in.lb.
- d. Apply propeller blades and pitch cylinder as outlined in the propeller manufacturer's manual and install the hub cover half. Do not apply both center clamp bolts yet.
- e. Install the mounting bracket as described in figure 13-5. and tighten clamp bolts to a torque value of 27 Nm / 240 in.lb.
- f. Apply a bead of silicone compound on the rim of the support bulkhead.
- g. Install spinner. When installing the plastic (ABS) type spinner, add a collar bush to each of the fixing screws, to prevent the spinner from cracking around it's fixing holes. Do not overtighten the fixing screws.

|                  |  |
|------------------|--|
| <b>▲ WARNING</b> | Be sure master switch is in OFF position and key removed from starter switch before turning propeller. |
|------------------|--|

|                  |   |
|------------------|---|
| <b>▲ WARNING</b> | Special lock washers are required for all bolts on the propeller hub, in no case additional washers are needed! |
|------------------|---|

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Before proceeding with the next steps, refer to paragraph 13.2.4 for correct pitch setting of the propeller blades. |
|---------------|---|


## 13.2.4 Rigging (refer to figure 13-6)

- **Required Tools:** Standard metric tools
  - **Required Parts:** Silicone compound, Loctite 243 (medium strength)
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- a. If rigging is not done as step of the propeller installation process, propeller spinner dome has to be removed first (refer to paragraph 13.2.2).
  - b. Set pitch to 23.0 +/- 1 deg at radius station 0.66m = 26.0 in and torque all 6 clamp bolts to 27 Nm / 240 in.lb.
  - c. Run the engine without moving the aircraft, applying full throttle position (warm up the engine to normal operation temperature before conducting that procedure). Check that engine speed at sea level is 4.900 RPM.
  - d. Perform a check flight and ensure that engine speed does not exceed 5.800 RPM at never exceed airspeed ( $V_{NE}$ ).
  - e. Adjust pitch if necessary, but not more than +/- 1 deg as per pitch setting procedure above.
  - f. Proceed with installing the spinner dome like described in paragraph 13.3.3.

### ▲ WARNING

Be sure master switch is in OFF position and key removed from starter switch before turning propeller.

Figure 13-6



## 13.3 Propeller Ground Adjustable (Neuform)

A carbon fiber, ground adjustable propeller equipped with a GFRP spinner is used on the REMOS GX. It is mandatory to maintain the servicing intervals given in the propeller manufacturer's manual.

Figure 13-7 (only two blades shown on photo for better overview)




Figure 13-8



## 13.3.1 Repair

Repair of a carbon fiber propeller first involves evaluating the damage and determining whether the repair is to be a major or minor one. In general all damages except defective paint or small dents has to be rated as major repair. Refer also to propeller manufacturer's manual for further instruction.

We strongly recommend to replace propeller blades if any cracks, deteriorations of the skin or extended dents are determined.

## 13.3.2 Removal (refer to figure 13-7)

- **Required Tools:** Standard metric tools
  - **Required Parts:** None
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- a. Remove spinner by unscrewing its retaining screws.
  - b. Remove the M6 bolts first.
  - c. Remove all bolts on propeller hub and remove hub and blades.
  - d. Remove mounting bolts and pull propeller hub forward to remove. Use care to avoid damage to bulkheads as propeller is removed.

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Make sure to remove the M6 bolts first, followed by the M8 bolts. In case the M8 bolts are removed with the small M6 bolts still in place the bolt heads might shear off. |
|---------------|---|

|                  |  |
|------------------|--|
| <b>▲ WARNING</b> | Be sure master switch is in OFF position and key removed from starter switch before turning propeller. |
|------------------|--|

## 13.3.3 Installation (refer to figure 13-7)

- **Required Tools:** Standard metric tools
  - **Required Parts:** Silicone compound, Loctite 243 (medium strength)
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- a. Clean mating surfaces of propeller, gearbox flange and spinner bulkheads.
  - b. The propeller hub comes in two parts. For the delivery it is only loosely screwed with M6 screws. On the outside of each half of the hubs you will find an imprinted number. Both halves must display identical numbers!

- c. Loosen the screws and lift the two halves apart from each other. The delivery consists of 3 or 4 M6 screws respectively, 6 M8 screws, Nordlock lock washers in two sizes as well as 6 M8 lock nuts.
- d. Mounting of the blades into the hub. Put the half of the hub, that shows screw threads, on a table and place the propeller blades in the fitted areas. At this moment the angles of incidence of the blades are not yet of importance. Now place the second half of the hub on the first one. Tighten the M6 bolts just very loose, so that the blade angle can be adjusted, but so tight that they do not shake.
- e. Set pitch to 23.0 +/- 1 deg at radius station 0.62 m = 24.4 in.
- f. Mount the propeller to the engine flange using the M8 screws. Torque is 27 Nm / 240 in.lb. Tighten the M6 bolts to 10 Nm / 90 in.lb.
- g. Adjusting the blade angle is not that simple and requires some patience. Ask somebody to help you in order to simplify the procedure. While tightening the propeller bolts the blade angle may change a little. Make sure the blade angles are identical and correct.

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | The blade angles need to be adjusted very thoroughly in order to avoid aerodynamic unbalanced masses later on. |
|---------------|--|

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | The blade angles need to be adjusted very thoroughly in order to avoid aerodynamic unbalanced masses later on. |
|---------------|--|

## 13.4 Bill of Materials

| Fig. No. | Item No. | Order No. | Part No.            | Qty. per Assy | Description  | Appl. S/N |
|----------|----------|-----------|---------------------|---------------|--|-----------|
| 13-2     | 1        | 100423    | G3-8 PR-20-01-01    | 1             | Spinner Aluminium Fixed Pitch  | -         |
|          |          | 100422    | G3-8 PR-20-01-00-GX | 1             | Spinner ABS Fixed Pitch  | -         |
|          | 2        | 100157    |                     | 6             | Cylinder Head Screw M8x140 vz DIN912 8.8                             | -         |
|          | 3        | 100272    |                     | 6             | Spring Washer 8,1 DIN127 Form B                                      | -         |
|          | 4        | 100418    | G3-8 PR-20-01-05    | 1             | Spinner Front Plate  | -         |
|          | 5        | 100425    | G3-8 PR-20-01-02    | 1             | Spinner Pressure Plate 80 PS   | -         |
|          |          | 100427    | G3-8 PR-20-01-03    | 1             | Spinner Pressure Plate 100 PS  | -         |
|          | 6        | 100426    | G3-8 PR-11-01-01    | 1             | Propeller Tonini 100 PS  | -         |
|          |          | 100424    |                     | 1             | Propeller Tonini 80 PS   | -         |
|          |          | 102373    | G3-8 PR-11-01-01    | 1             | Propeller Woodcomp 100PS   | -         |
|          | 7        | 100419    | G3-8 PR-20-01-04    | 1             | Spinner Rear Bulkhead  | -         |
|          | 8        | 100417    | G3-8 PR-01-00-02    | 6             | Prop-Spacer Guide-Tube long  | -         |
|          | 9        | 100420    | G3-8 PR-01-00-00    | 1             | Propeller Spacer   | -         |
|          | 10       | 100275    |                     | 8             | Washer 4,3x9x0,8 Nylon Natur   | -         |
|          | 11       | 100189    |                     | 8             | Lens Head Screw Hexagon Socket M4x12 vz ISO7380 A2-70                | -         |
|          | 12       | 100212    |                     | 8             | Self Locking Nut M4 DIN985 vz  | -         |
|          | 13       | 101860    |                     | 8             | Collar Bush white 4x15x1,5 Nylon-6                                   | -         |
| 13-4     | 1        | 102540    | G3-8 PR-30-01-04    | 1             | Spinner Alu Ground Adjustable Sensenich                              | -         |
|          |          | 102546    |                     | 1             | Spinner Variable Pitch Sensenich                                     | -         |
|          | 2        | 102158    |                     | 4             | Lens Head Screw Hexagon Socket M6x16 ISO7380 A2                      | -         |
|          | 3        | 100583    | G3-8 PR-30-01-02    | 1             | Spinner Front-Bulkhead Adjustable-Prop                               | -         |
|          | 4        | 101880    |                     | 2             | Securing Washer M8   | -         |
|          | 5        | 102863    |                     | 2             | Washer 8,4x18x2 DIN134 Stahl vz                                      | -         |
|          | 6        | 102518    |                     | 1             | Sensenich Propeller  | -         |
|          | 7        | 102507    | G3-8 PR-01-00-06    | 1             | Propeller Mounting Bracket Sensenich                                 | -         |
|          | 8        | 102326    |                     | 6             | Cylinder Head Screw M8x60 DIN912 10.9                                | -         |
|          | 9        | 101880    |                     | 6             | Securing Washer M8   | -         |
|          | 10       | 102508    | G3-8 PR-01-00-05    | 6             | Propeller Flange Guide Sleeve Sensenich                              | -         |
|          | 11       | 100419    | G3-8 PR-20-01-04    | 1             | Spinner Rear Bulkhead  | -         |
|          | 12       | 100420    | G3-8 PR-01-00-00    | 1             | Propeller Spacer   | -         |
| 13-6     | 1        | 100224    |                     | 6             | Self Locking Nut M8 DIN985 vz  | -         |
|          | 2        | 5632      |                     | 6             | Washer DIN 125 A-140-HV  | -         |
|          | 3        | 5570      |                     | 6             | Head Bushing Aluminium   | -         |
|          | 4        | 7325      |                     | 1             | Propeller Flange Spacer  | -         |
|          | 5        | 0168      |                     | 1             | Spinner Neuform Including Carbon Plate And Intern Spacer             | -         |
|          | 6        | 0171      |                     | 1             | 3 Blade Propeller Neuform Ground Adjustable With Hub, Screws, Manual | -         |
|          | 7        | 5253      |                     | 3             | Hexagon Head Bolt DIN 933 8.8 M6x45                                  | -         |
|          | 8        | 5421      |                     | 3             | Washer Nordlock M6 vz  | -         |
|          | 9        | 7633      |                     | 6             | Hexagon Head Bolt DIN 931 8.8 A2K M8x130                             | -         |
|          | 10       | 5420      |                     | 6             | Washer Nordlock M8 vz  | -         |

*Intentionally left blank*

## Section 14

### *Utility Systems*

| <b>Table of Contents</b>                       | <b>Section</b> |
|--|----------------|
| 14.1 Heating System .....                      | 2              |
| 14.1.1 Description (refer to figure 14-1)..... | 2              |
| 14.1.2 Operation .....                         | 2              |
| 14.1.3 Trouble Shooting .....                  | 2              |
| 14.1.4 Removal, Installation and Repair.....   | 5              |
| 14.2 Ventilating System, Description .....     | 6              |
| 14.2.1 Operation .....                         | 6              |
| 14.2.2 Trouble Shooting .....                  | 6              |
| 14.2.3 Removal, Installation and Repair.....   | 7              |
| 14.3 Sun Visors .....                          | 7              |
| 14.3.1 Installation.....                       | 8              |
| 14.4 Bill of Materials .....                   | 10             |



## **14.1 Heating System**

### **14.1.1 Description (refer to figure 14-1)**

The heating system is comprised of the heat exchange section of the exhaust muffler, a shut-off valve, mounted on the right forward side of the firewall, a push-pull control on the instrument panel, outlets, and flexible ducting connecting the system.

### **14.1.2 Operation**

Ram air is ducted through a heat exchange section of the exhaust muffler, to the shut-off valve into a chamber on the aft side of the firewall, where it is distributed into the cabin. The shut-off valve operated by a push-pull control marked "Warm", located beneath the switch panel, regulates the volume of heated air entering the system. Pulling the control full out supplies maximum flow, and pushing control in gradually decreases flow, shutting off flow completely when the control is pushed full in.

### **14.1.3 Trouble Shooting**

Most of the operational troubles in the heating and ventilating systems are caused by a sticking or binding air valve and its control, damaged air ducting, or defects in the exhaust muffler. In most cases, the valve or control can be freed by proper lubrication. Damaged or broken parts must be repaired or replaced. When checking control, ensure valve respond freely to control movement, that they move in the correct direction, and that they move through their full range of travel and seal properly. Check that hoses are properly secured, and replace hoses that are burned, frayed or crushed. If fumes are detected in the cabin, a thorough inspection of the exhaust system should be accomplished. Refer to applicable paragraph in Section 11 for this inspection. Since any holes or cracks may permit exhaust fumes to enter the cabin, replacement of defective parts is imperative because fumes constitute an extreme danger.

Figure 14-1






Figure 14-2



◆ NOTE

New Warm Air Control shown on right hand side. If plane is equipped with older Warm Air Control, change with new model.

Figure 14-3



◆ NOTE


There is an air jet at the heating valve, which is standard from serial number 378 on. The air jet can be retrofitted.

## 14.1.4 Removal, Installation and Repair

- **Required Tools:** Standard metric tools, riveting pliers
- **Required Parts:** Hoses and hose clamps as required, rivets 3x8mm (3x)
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

Figure 14-1 and 14-6 illustrates the heating and ventilating systems, and may be used as a guide during removal, installation and repair of heating system components. Burned, frayed, or crushed hoses must be replaced with new hoses, cut to length and installed in the original routing. Trim hose winding shorter than the hose to allow clamps to be fitted. A defective air valve must be repaired or replaced. Check for proper operation of valve and its control after repair or replacement.

Figure 14-4



◆ **NOTE**

The push-pull controls for warm and cold air are located in the middle of the standard instrument panel (Figure 14-4) or on the right hand side of the small panel (Figure 14-5), depending on instrument panel installed.

Figure 14-5



## **14.2 Ventilating System, Description**

The ventilating system is comprised of a naca-style fresh air-scoop mounted in the right side of the upper cowling. A shut-off valve is located on the right side of the firewall, operated by a push-pull control marked “Cold”, located beneath the switch panel, regulates the volume of fresh air entering the system.

### **14.2.1 Operation**

Air received from the scoop mounted in the right side of the upper cowling is routed through a distributor located on the aft right side of the firewall to the windshield and bottom of the cabin. As long as the “Warm” control is pushed in, no heated air can enter the firewall duct; therefore, when the “Cold” control is pulled out, only fresh air from the scoop will flow through the distributor into the cabin. As the “Warm” control is gradually pulled out, more and more heated air will blend with the fresh air from the scoop and be distributed into the cabin. Either one or both of the controls may be set at any position from pull open to full closed.

### **14.2.2 Trouble Shooting**

Most of the operational troubles in the ventilating system are caused by sticking or binding of the shut-off valve or its control. In most cases, valve or control can be freed by proper lubrication. Damaged or broken parts must be repaired or replaced. When checking control, ensure valve respond freely to control movement and that it moves through its full range of travel and seal properly.



## 14.2.3 Removal, Installation and Repair

- **Required Tools:** Standard metric tools, riveting pliers
- **Required Parts:** Rivets 3x8mm (2x); cable ties as required
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center


Figure 14-6



## 14.3 Sun Visors

The sun visors are a component of the airplane just above the windshield. (If equipped) There are two sun visors, one for the pilot's side and a second for the passenger's side. Each visor can be lowered to help block light from the sun entering through the windshield. They can also be turned towards the front side passenger window, covering a small part of the window at the top to block sunlight shining on the side of the passenger's face.

Figure 14-7



### 14.3.1 Installation

- **Required Tools:** Standard metric tools
- **Required Parts:** Washers if needed
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

How to install the sun visors:

- a. Check mounting bolts.
- b. There should be no rests of paint. If so: clean mounting bolts with solvent. Do not use abrasive paper.
- c. Roof liner installation with small parts (if ordered): Stamp holes into the roof liner. Mount the roof liner and then the EPDM-windows with O-Rings.
- d. Mount sun visors (RH and LH): Disconnect screw from I-hinge. Grease mounting bolts with Molykote FB 180 (Keep grease away from drill hole). Connect I-hinge to mounting bolts. Provide some Loctite 262 on bolts and screw in. Tighten screws so that there is a torque of 0.6 to 0.7 Nm between mounting bolts and I-hinge. (It is not the tightening torque of the screws). Verify torque moment with the help of a spring balancer. Spring balancer should indicate 250 to 290 gram when I-hinge is moved. Move hinge before verification to provide a lubrication film
- e. Balancing sun visors: Fix both sun visors. If one of the sun visors has a different high, it is possible to balance the parts. If roof liner is installed at least one washer at each sun visor is necessary. A maximum of 4 washers can be used to balance the parts. If balancing is finished, Tenax lower parts have to be removed. Provide them with Loctite 262 and screw them in again.
- f. Foam pads: It is necessary to mount 4 foam pads if there is no roof liner. Foam pads prevent noises of vibration.

### 14.4 Interior Pads

The REMOS GX is equipped with different interior pads that are helpful and embellish the airplane. Refer to the following tables to get further information about the interior pads that can be used.

#### 14.4.1 Earlier Interior Pads

| Item                          | SAP    |
|-------------------------------|--------|
| Seat complete, RH fabric blue | 102494 |
| Seat complete, LH fabric blue | 102492 |
| Floor covering leather, RH    | 102316 |
| Floor covering leather, LH    | 102317 |
| Floor mat (carpet), RH        | 102162 |
| Floor mat (carpet), LH        | 102163 |
| Map-case RH GX                | 102347 |

|                        |        |
|------------------------|--------|
| Map-case LH GX         | 102346 |
| Cover door panel RH GX | 102349 |
| Cover door panel LH GX | 102348 |

**14.4.2 Newer Basic Interior Pads**

| Item                                  | SAP    |
|---------------------------------------|--------|
| Seat shell complete black painted, RH | 102752 |
| Seat shell complete black painted, LH | 102753 |
| Seat fabric/leather RH                | 102758 |
| Seat fabric/leather LH                | 102759 |
| Map-case black leather, RH GX         | 102754 |
| Map-case black leather, LH GX         | 102755 |
| Cover door panel grey fabric, RH      | 102756 |
| Cover door panel grey fabric, LH      | 102757 |
| Floor mat carpet standard large, RH   | 102788 |
| Floor mat carpet standard large, LH   | 102787 |
| Luggage locker carpet standard, RH    | 102762 |
| Luggage locker carpet standard, LH    | 102763 |

**14.4.3 Additional Interior Pads Aviator 2 / Cruiser**

| Item                             | SAP    |
|----------------------------------|--------|
| Cover center console, RH leather | 102770 |
| Cover venter console, LH leather | 102771 |
| Floor covering, RH fabric        | 102772 |
| Floor covering, LH fabric        | 102773 |
| Cover center tunnel leather      | 102774 |
| Cover spar bridge fabric         | 102775 |
| Cover back wall fabric           | 102776 |

**14.4.4 Optional Interior Pads With Leather Seats**

| Item                             | SAP    |
|----------------------------------|--------|
| Seat complete leather RH         | 102764 |
| Seat complete leather LH         | 102765 |
| Floor mat carpet DELUXE, RH      | 102766 |
| Floor mat carpet DELUXE, LH      | 102767 |
| Luggage locker carpet DELUXE, RH | 102768 |
| Luggage locker carpet DELUXE, LH | 102769 |



## 14.4.5 Bill of Materials

| Fig. No. | Item No. | Order No. | Part No.         | Qty. per Assy | Description                | Appl. S/N |
|----------|----------|-----------|------------------|---------------|----------------------------|-----------|
| 14-1     | 1        | 100704    | G3-8 FU-14-00-01 | 1             | Heater Ventilation Flap    | All       |
|          | 2        | 100999    |                  | 1             | Heating Hose 45mm          |           |
|          | 3        | 101013    |                  | 4             | Cable Tie 4,5x290 black    | All       |
| 14-2     | 1        | 100705    | G3-8 FU-14-00-02 | 1             | Warm Air Control           | All       |
| 14-3     | 1        | 103058    | G3-8 FU-14-01-23 | 1             | Air Vent Left Hand Side    | -         |
|          |          | 103059    | G3-8 FU-14-01-24 | 1             | Air Vent Right Hand Side   | -         |
| 14-4     | 1        | 101829    |                  | 1             | Bowden Wire 2108-1108100   | All       |
|          | 2        | 101828    |                  | 1             | Clamp Bowden Wire          | All       |
|          | 3        | 100900    |                  | 3             | Hose Clamp 40-60           | All       |
|          | 4        | 101147    |                  | 1             | Hose Air Flow              | All       |
|          | 5        | 100700    | G3-8 FU-14-01-16 | 1             | Ventilating Clamping Sheet | All       |
| 14-7     | 1        | 103029    | G3-8 FU-19-00-06 | 1             | Sun Visor Left Hand Side   | -         |
|          | 2        | 103030    | G3-8 FU-19-00-06 | 1             | Sun Visor Right Hand Side  | -         |

## Section 15

### *Instruments and Instrument System*

| <b>Table of Contents</b> | <b>Section</b>   |
|--------------------------|--|
| 15.1                     | Preamble ..... 2   |
| 15.2                     | Instrument and Instrument Systems, General..... 2        |
| 15.3                     | Instrument Panel ..... 2                                 |
| 15.3.1                   | Description ..... 2                                      |
| 15.3.2                   | Standard Panel ..... 4                                   |
| 15.3.3                   | Small Panel..... 5                                       |
| 15.3.4                   | Shock Mounts ..... 5                                     |
| 15.3.5                   | Instruments and Avionics..... 6                          |
| 15.3.6                   | Pitot and Static System, Description..... 23             |
| 15.3.7                   | Maintenance ..... 23                                     |
| 15.3.8                   | Static Pressure System Inspection, Leakage Test ..... 23 |
| 15.3.9                   | Pitot System Inspection, Leakage Test ..... 24           |
| 15.3.10                  | Blowing out Lines..... 24                                |
| 15.3.11                  | Removing and Installation of Components ..... 30         |
| 15.3.12                  | Trouble Shooting-Pitot Static System ..... 30            |
| 15.3.13                  | Trouble Shooting Airspeed Indicator ..... 31             |
| 15.3.14                  | Trouble Shooting Altimeter ..... 32                      |
| 15.3.15                  | Trouble Shooting Vertical Speed Indicator ..... 32       |
| 15.4                     | Engine Indicators..... 33                                |
| 15.4.1                   | Rotax FLYdat System..... 33                              |
| 15.4.2                   | Fuel Quantity Indicating System, Description ..... 34    |
| 15.4.3                   | Manifold Temperature Gauge, Description..... 35          |
| 15.5                     | Magnetic Compass, Description..... 36                    |
| 15.6                     | Slip Indicator ..... 36                                  |
| 15.7                     | Bill of Materials Standard Parts ..... 37                |
| 15.8                     | Bill of Materials Instruments ..... 39                   |

## 15.1 *Preamble*

This chapter only deals with the avionics integration and not with the avionics itself. If you need further information about the avionics and its components, please refer to the related manuals.

|             |   |
|-------------|---|
| <b>NOTE</b> | Hereby REMOS approves all publications by the avionics manufacturers. |
|-------------|---|

|             |  |
|-------------|--|
| <b>NOTE</b> | Hereby REMOS approves all software updates and product updates by the avionics manufacturers |
|-------------|--|

Updating software might lead to malfunction or total failure of the component. Only qualified persons shall perform software updates. In doubt contact the manufacturer or REMOS before attempting to update a component or a system.

## 15.2 *Instrument and Instrument Systems, General*

This section describes typical instrument installations and their respective operating systems. Emphasis is placed on trouble shooting and corrective measures only. It does not deal with specific instrument repairs since this usually requires special equipment and data and should be handled by instrument specialists. Malfunctioning instruments are required to be sent to an approved instrument overhaul and repair station or returned to manufacturer for servicing. Our concern here is with preventive maintenance on various instrument systems and correction of system faults which result in instrument malfunctions.

The descriptive material, maintenance and troubleshooting information in this section is intended to help the mechanic determine malfunctions and correct them, up to the defective instrument itself, at which point an instrument technician should be called in. Some instruments, such as fuel quantity and oil pressure gauges, are so simple and inexpensive, repairs usually will be more costly than a new instrument. On the other hand, aneroid and gyro instruments usually are well worth repairing. The word “replace instrument” in the text, therefore, should be taken only in the sense of physical replacement in aircraft. Whether replacement is to be with a new instrument, a refurbished one, or original instrument is to be repaired must be decided on basis of individual circumstances.

## 15.3 *Instrument Panel*

### 15.3.1 *Description*

The instrument panel assembly consists of stationary and shock-mounted panels. The stationary panels are containing switches and LED-gauges, which are not sensitive to vibration. The shock-mounted panels are containing major flight instruments such as airspeed indicator, altitude indicator, EFIS-Systems, avionics components, and horizontal and directional gyros which are affected by vibration. Most of the instruments are bolted on aluminum frame backs.

There are two different instrument panels, a standard panel and a small panel. Refer to figure 15-1 for further information.

Figure 15-1



## 15.3.2 Standard Panel

### 15.3.2.1 Removal and Installation

- **Required Tools:** Standard metric tools, wire cutting pliers, bleed kit
- **Required Parts:** Cable ties, insulating tape.
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

### 15.3.2.2 Switch Panel

The stationary switch panel is located at the center section of the cockpit frame. It consists of an aluminum support frame and a decorative ABS cover. To remove the stationary panels proceed as follows:

- a. Disconnect battery and insulate as safety precaution.
- b. Loosen and unscrew throttle lever knob, clamp nut, friction knob and ignition key union nut.
- c. Unscrew and withdraw switch panel from cockpit frame.
- d. Unplug switch and LED-Indicator wiring.
- e. Reverse preceding steps for reinstallation.

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | <p>Do not overtighten panel fixing screws at reinstallation, because this would cause the ABS decorative cover to crack.</p> <p>Do not tighten more than hand tight. Use Locktite or equivalent for screw fixation rather than tightening.</p> |
|---------------|--|

### 15.3.2.3 Left and Right Panel

The shock mounted panels consist of an aluminum support frame and a decorative ABS cover attached to the cockpit main-frame via rubber shock mounts. To remove a shock-mount panel proceed as follows:

- a. Disconnect battery leads and insulate as safety precaution.
- b. Unscrew retaining screws and remove decorative ABS cover.
- c. Remove shock-mount screws in both upper corners of the aluminum frame.
- d. Pull out upper edge of the frame and lift up to disengage the lower shock-mounts from cockpit main-frame.
- e. Disconnect wiring and hoses and remove panel.
- f. Reverse preceding steps for reinstallation.

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | <p>Do not overtighten panel fixing screws at reinstallation, because this would cause the ABS decorative cover to crack.</p> <p>Do not tighten more than hand tight. Use Locktite or equivalent for screw fixation rather than tightening.</p> |
|---------------|--|

## 15.3.3 *Small Panel*

### 15.3.3.1 *Removal and Installation*

- **Required Tools:** Standard metric tools, wire cutting pliers, bleed kit
- **Required Parts:** Cable ties, insulating tape.
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

### 15.3.3.2 *Panels*

The panels consist of decorative covers that are screwed to shock mounts and fixed at the cockpit frame. To remove the panels proceed as follows:

- Disconnect battery leads and insulate as safety precaution.
- Loosen and unscrew throttle lever knob, clamp nut, friction knob and ignition key union nut.
- Unscrew and withdraw panel from cockpit frame.
- Unplug switch and LED-Indicator wiring.
- Reverse preceding steps for reinstallation.

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | <p>Do not overtighten panel fixing screws at reinstallation, because this would cause the decorative cover to crack.</p> <p>Do not tighten more than hand tight. Use Locktite or equivalent for screw fixation rather than tightening.</p> |
|---------------|--|

## 15.3.4 *Shock Mounts*

Service life of instruments is directly related to adequate shock-mounting of panel. If removal of panel is necessary, check mounts for deterioration.

## 15.3.5 Instruments and Avionics

### 15.3.5.1 Standard Panel

#### 15.3.5.1.1 Left Hand Side

| Configuration TRAVELLER / EXPLORER |  |                                 |                              |
|------------------------------------|--|---------------------------------|------------------------------|
| Serial Number                      | Equipment  | Mounting Frame/<br>Order Number | Cover Panel/<br>Order Number |
| up to SN 297                       | Airspeed indicator<br>Vertical speed indicator<br>Altimeter<br>Slip indicator<br>Rotax FLYdat  | G3-8 CP-10-01-26<br>102260      | G3-8 CP-10-01-66<br>102228   |
| up to SN 297                       | Airspeed indicator<br>Vertical speed indicator<br>Altimeter<br>Slip indicator<br>Analogue engine instruments   | G3-8 CP-10-01-26<br>102260      | G3-8 CP-10-01-65<br>102227   |
| SN 298ff                           | Airspeed indicator<br>Vertical speed indicator<br>Altimeter<br>Slip indicator<br>Analogue engine tachometer  | G3-8 CP-10-01-39<br>102717      | G3-8 CP-10-01-85<br>102704   |
| SN 298ff                           | Airspeed indicator<br>Vertical speed indicator<br>Altimeter<br>Directional gyro<br>Artificial horizon<br>Turn/bank indicator<br>Analogue engine tachometer                               | G3-8 CP-10-01-39<br>102717      | G3-8 CP-10-01-84<br>102703   |
| SN 298ff                           | Airspeed indicator<br>Vertical speed indicator<br>Altimeter<br>Directional gyro<br>Artificial horizon<br>Turn/bank indicator<br>Analogue engine tachometer<br>additional 57mm instrument | G3-8 CP-10-01-39<br>102717      | G3-8 CP-10-01-96<br>102716   |

| Configuration VOYAGER / AVIATOR I |   |   |                              |
|-----------------------------------|---|---|------------------------------|
| Serial Number                     | Equipment   | Mounting Frame/<br>Order Number   | Cover Panel/<br>Order Number |
| up to SN 297                      | Dynon EFIS D-100<br>Rotax FLYdat<br>Airspeed indicator<br>Altimeter                             | G3-8 CP-10-01-21<br>102082<br><br>G3-8 CP-10-01-23<br>102086<br><br>DYNON mounting frame for<br>D100 series (trim as<br>required) | G3-8 CP-10-01-62<br>102077   |
| up to SN 297                      | Dynon EFIS D-100<br>Rotax FLYdat<br>Airspeed indicator<br>Altimeter<br>HS34                     | G3-8 CP-10-01-21<br>102082<br><br>G3-8 CP-10-01-23<br>102086<br><br>DYNON mounting frame for<br>D100 series (trim as<br>required) | G3-8 CP-10-01-62<br>102077   |
| SN 298ff                          | Dynon FlightDEK D-180<br>Airspeed indicator<br>Altimeter  | G3-8 CP-10-01-28<br>102887<br><br>DYNON mounting frame for<br>D100 series (trim as<br>required)                                   | G3-8 CP-10-01-80<br>102699   |
| SN 298ff                          | Dynon FlightDEK D-180<br>Airspeed indicator<br>Altimeter<br>HS 34                               | G3-8 CP-10-01-28<br>102887<br><br>DYNON mounting frame for<br>D100 series (trim as<br>required)                                   | G3-8 CP-10-01-94<br>102714   |
| SN 298ff                          | Dynon FlightDEK D-180<br>Airspeed indicator<br>Altimeter<br>HS 34<br>additional 57mm instrument | G3-8 CP-10-01-28<br>102887<br><br>DYNON mounting frame for<br>D100 series (trim as<br>required)                                   | G3-8 CP-10-01-93<br>102713   |
| SN 298ff                          | Dynon FlightDEK D-180<br>Airspeed indicator<br>Altimeter<br>HS 34<br>AP 74                      | G3-8 CP-10-01-28<br>102887<br><br>DYNON mounting frame for<br>D100 series (trim as<br>required)                                   | G3-8 CP-10-01-29<br>700763   |

From SN298 on the remote compass is installed underneath the stick cover on the right side or in the left wing root.



| Configuration CRUIZER / AVIATOR II |   |   |                              |
|------------------------------------|---|---|------------------------------|
| Serial Number                      | Equipment   | Mounting Frame/<br>Order Number   | Cover Panel/<br>Order Number |
| up to SN297                        | Dynon EFIS D-100<br>Dynon EMS D-120<br>HS34<br>slip indicator<br>optional 57mm instrument | G3-8 CP-10-01-23<br>102086<br><br>G3-8 CP-10-01-20<br>102081<br><br>DYNON mounting frame for<br>D100 series (trim as<br>required) | G3-8 CP-10-01-64<br>102079   |
| SN 298ff                           | Dynon EFIS D-100<br>Dynon EMS D-120<br>HS 34  | G3-8 CP-10-01-20<br>102081<br><br>DYNON mounting frame for<br>D100 series (trim as<br>required)                                   | G3-8 CP-10-01-82<br>102702   |
| SN 298ff                           | Dynon EFIS D-100<br>Dynon EMS D-120<br>HS 34<br>optional 57mm instrument                  | G3-8 CP-10-01-20<br>102081<br><br>DYNON mounting frame for<br>D100 series (trim as<br>required)                                   | G3-8 CP-10-01-81<br>102700   |
| SN 298ff                           | Dynon EFIS D-100<br>Dynon EMS D-120<br>HS 34<br>AP 74                                     | G3-8 CP-10-01-20<br>102081<br><br>DYNON mounting frame for<br>D100 series (trim as<br>required)                                   | G3-8 CP-10-01-30<br>102880   |

From SN298 on the remote compass is installed underneath the stick cover on the right side or in the left wing root.

## 15.3.5.1.2 Center Stack

### 15.3.5.1.2.1 Aircraft up to SN297

Three different center stacks are available, providing space for a GPS, up to two radios, an intercom and a transponder. The following matrix gives an overview of which avionics suite provides which equipment for each model of aircraft.

| equipment                 | Traveller | Explorer | Voyager | Aviator-I | Cruiser | Aviator-II |
|---------------------------|-----------|----------|---------|-----------|---------|------------|
| Garmin GPS 296            | ●         | ●        | ----    | ----      | ----    | ----       |
| Garmin GPS 495            | ○         | ○        | ----    | ----      | ----    | ----       |
| Garmin GPS 496            | ○         | ○        | ●       | ●         | ----    | ●          |
| FlymapL GPS               | ○         | ----     | ○       | ----      | ●       | ----       |
| PM-1000 intercom          | ●         | ●        | ●       | ●         | ●       | ----       |
| Garmin GMA340 Audio Panel | ---       | ----     | ----    | ----      | ----    | ●          |
| Garmin SL30 NAV/COM       | ---       | ----     | ○       | ○         | ●       | ●          |
| Garmin SL40 COM           | ●         | ●        | ●       | ●         | ----    | ●          |
| Garmin GTX327 XPDR        | ----      | ●        | ----    | ●         | ----    | ●          |
| Garmin GTX328 XPDR        | ●         | ----     | ●       | ----      | ●       | ----       |
| Garmin GTX 330 XPDR       | ----      | ○        | ----    | ○         | ----    | ○          |

○ optional      ● basic equipment      --- not available



Center stack, all variants shown

| Equipment   | Mounting Frame<br>Order Number   | Cover Panel<br>Order Number |
|---|--|-----------------------------|
| Flymap L<br>PSE PM 1000<br>SL40 or SL30<br>GTX 327/328/330                | G3-8 CP-10-01-42<br>102084<br><br>G3-8 CP-10-01-43<br>102088<br><br>G3-8 CP-10-01-44<br>102089<br><br>G3-8 CP-10-01-45<br>102090<br><br>G3-8 CP-10-01-46<br>102085<br><br>SL 30 Tray<br><br>GTX 327 Tray                 | G3-8 CP-10-01-71<br>101792  |
| Garmin x96 series<br>PSE PM 1000<br>SL40 or SL30<br>GTX 327/328/330       | G3-8 CP-10-01-42<br>102084<br><br>G3-8 CP-10-01-43<br>102088<br><br>G3-8 CP-10-01-44<br>102089<br><br>G3-8 CP-10-01-45<br>102090<br><br>G3-8 CP-10-01-46<br>102085<br><br>SL 40 Tray<br><br>GTX 327 Tray<br><br>AirGizmo | G3-8 CP-10-01-71<br>101792  |
| Garmin x96 series<br>GMA 340<br>GTX 327/328/330<br><br>SL 40<br><br>SL 30 | G3-8 CP-10-01-42<br>102084<br><br>G3-8 CP-10-01-43<br>102088<br><br>G3-8 CP-10-01-44<br>102089<br><br>G3-8 CP-10-01-45<br>102090   | G3-8 CP-10-01-70<br>101791  |

## 15.3.5.1.2.2 Aircraft from SN298 on

Three different center stacks are available, providing space for a GPS, up to two radios, an intercom and a transponder. The following matrix gives an overview which avionics suite provides which equipment for each model of aircraft.

| equipment                 | Traveller | Explorer | Voyager | Aviator-I | Cruiser | Aviator-II |
|---------------------------|-----------|----------|---------|-----------|---------|------------|
| Garmin GPS 495            | ○         | ○        | ----    | ----      | ----    | ----       |
| Garmin GPS 496            | ●         | ●        | ●       | ●         | ----    | ●          |
| Flymap L GPS              | ○         | ----     | ○       | ----      | ●       | ----       |
| Garmin GMA240 Audio Panel | ●         | ●        | ●       | ●         | ●       | ----       |
| Garmin GMA340 Audio Panel | ---       | ----     | ----    | ----      | ----    | ●          |
| Garmin SL30 NAV/COM       | ---       | ----     | ○       | ○         | ●       | ●          |
| Garmin SL40 COM           | ●         | ●        | ●       | ●         | ----    | ●          |
| Garmin GTX328 XPDR        | ●         | ●        | ●       | ●         | ●       | ●          |
| Garmin GTX 330 XPDR       | ----      | ○        | ----    | ○         | ----    | ○          |

○ optional      ● basic equipment      --- not available



Center stack, all variants shown

| Equipment   | Mounting Frame<br>Order Number   | Cover Panel<br>Order Number |
|---|--|-----------------------------|
| Flymap L<br>SL40 or SL30<br>GTX 327/328/330<br>GMA 240/340          | G3-8 CP-10-01-42<br>102084<br><br>G3-8 CP-10-01-43<br>102088<br><br>G3-8 CP-10-01-44<br>102089<br><br>G3-8 CP-10-01-45<br>102090<br><br>G3-8 CP-10-01-46<br>102085<br><br>G3-8 CP-10-01-47<br>102091 | G3-8 CP-10-01-89<br>102708  |
| Garmin x96 series<br>SL40 or SL30<br>GTX 327/328/330<br>GMA 240/340 | G3-8 CP-10-01-42<br>102084<br><br>G3-8 CP-10-01-43<br>102088<br><br>G3-8 CP-10-01-44<br>102089<br><br>G3-8 CP-10-01-45<br>102090<br><br>G3-8 CP-10-01-46<br>102085                                   | G3-8 CP-10-01-87<br>102706  |
| Garmin x96 series<br>SL40<br>SL30<br>GTX 327/328/330<br>GMA 240/340 | G3-8 CP-10-01-42<br>102084<br><br>G3-8 CP-10-01-43<br>102088<br><br>G3-8 CP-10-01-44<br>102089<br><br>G3-8 CP-10-01-45<br>102090   | G3-8 CP-10-01-88<br>102707  |

## 15.3.5.1.3 Right Hand Side

| Configuration TRAVELLER / EXPLORER |   |                                 |                              |
|------------------------------------|---|---------------------------------|------------------------------|
| Serial Number                      | Equipment   | Mounting Frame/<br>Order Number | Cover Panel/<br>Order Number |
| up to SN 297                       | OAT<br>Fuel gauge<br>Fuel pressure<br>Volt meter<br>Compass<br>optional 57mm instrument | G3-8 CP-10-01-00<br>102080      | G3-8 CP-10-01-11<br>100446   |
| SN 298ff                           | Dynon EMS D-10  | G3-8 CP-10-01-01<br>100853      | G3-8 CP-10-01-92<br>102712   |

| Configuration VOYAGER / AVIATOR I |   |                                 |                              |
|-----------------------------------|---|---------------------------------|------------------------------|
| Serial Number                     | Equipment   | Mounting Frame/<br>Order Number | Cover Panel/<br>Order Number |
| up to SN 297                      | OAT<br>Fuel gauge<br>Fuel pressure<br>Volt meter<br>Compass<br>optional 57mm instrument | G3-8 CP-10-01-00<br>102080      | G3-8 CP-10-01-11<br>100446   |
| SN 298ff                          | Dynon EMS D-10  | G3-8 CP-10-01-01<br>100853      | G3-8 CP-10-01-90<br>102710   |

| Configuration VOYAGER / AVIATOR I |  |                                 |                              |
|-----------------------------------|--|---------------------------------|------------------------------|
| Serial Number                     | Equipment  | Mounting Frame/<br>Order Number | Cover Panel/<br>Order Number |
| up to SN 297                      | Altimeter<br>Airspeed indicator<br>Compass<br>Fuel gauge | G3-8 ET-0100014<br>102080       | G3-8 CP-10-01-11<br>100446   |
| SN 298ff                          | Altimeter<br>Airspeed indicator                          | G3-8 CP-10-01-01<br>100853      | G3-8 CP-10-01-91<br>102711   |

## 15.3.5.2 GXeLITE Panel

### 15.3.5.2.1 Left Hand Side

| Configuration GXeLITE   |                            |
|---|----------------------------|
| Equipment   | Panel / Order Number       |
| DYNON Flight DEK D-180<br>BECKER radio AR6201<br>BECKER transponder BXP6401<br>Intercom ps engineering PM3000 | G3-8 CP-10-01-11<br>100446 |



## 15.3.5.2.2 Center Stack

| Configuration GXeLITE  |  |
|------------------------|--|
| Equipment              | Panel / Order Number                                     |
| Garmin aera 500 series | G3-8 CP-50-01-07<br>103364<br>airGizmo aera 500          |
| Garmin 695/696         | G3-8 CP-50-01-08<br>103365<br>airGizmo 696               |
| Flymap L               | G3-8 CP-50-01-05<br>103363<br>G3-8 CP-50-01-50<br>103311 |



Center stack, all variants shown



## 15.3.5.2.3 Right Hand Side

| Configuration GXeLITE  |                            |
|--|----------------------------|
| Equipment  | Panel / Order Number       |
| Airspeed indicator<br>Altimeter<br>Circuit breakers<br>Fresh and heated air<br>12V receptacle                      | G3-8 CP-50-01-03<br>103264 |
| Airspeed indicator<br>Altimeter<br>Circuit breakers<br>Fresh and heated air<br>12V receptacle<br>ELT remote switch | G3-8 CP-50-01-06<br>103358 |



## 15.3.5.3 GXnXES Panel

### 15.3.5.3.1 Left Hand Side

| Configuration GXnXES                                  |                          |
|---|--------------------------|
| Equipment   | Panel / Order Number     |
| DYNON SV D700   | G3-8 CP-50-01-52         |
| Garmin SL30 or SL40                                   | 103313                   |
| Altimeter   | G3-8 CP-50-01-53         |
| Airspeed indicator                                    | 103314                   |
| Engine power, carburetor heat, choke, oil cooler flap | G3-8 CP-50-01-54         |
|   | 103315                   |
|   | G3-8 CP-50-01-09         |
|   | 103319                   |
| DYNON SV D700   | G3-8 CP-50-01-52         |
| Garmin SL30 or SL40                                   | 103313                   |
| Altimeter   | G3-8 CP-50-01-53         |
| Airspeed indicator                                    | 103314                   |
| Engine power, carburetor heat, choke, oil cooler flap | G3-8 CP-50-01-54 (2 ea.) |
| optional 57mm instrument                              | 103315                   |
|   | G3-8 CP-50-01-09         |
|   | 700950                   |



## 15.3.5.3.2 Center Stack

| Configuration GXnXES   |  |
|------------------------|--|
| Equipment              | Panel / Order Number                                     |
| Garmin aera 500 series | G3-8 CP-50-01-07<br>103364<br>airGizmo aera 500          |
| Garmin 695/696         | G3-8 CP-50-01-08<br>103365<br>airGizmo 696               |
| Flymap L               | G3-8 CP-50-01-11<br>103366<br>G3-8 CP-50-01-50<br>103311 |



Center stack, all variants shown

## 15.3.5.3.3 Right Hand Side

| Configuration GXnXES   |                            |
|------------------------|----------------------------|
| Equipment              | Panel / Order Number       |
| Intercom / Audio Panel | G3-8 CP-50-01-54<br>103315 |
| Circuit breakers       | G3-8 CP-50-01-55<br>103316 |
| Fresh and heated air   | G3-8 CP-50-01-56<br>103317 |
| 12V receptacle         | G3-8 CP-50-01-12<br>700953 |
| DYNON SV D700          | G3-8 CP-50-01-54<br>103315 |
| Intercom / Audio Panel | G3-8 CP-50-01-55<br>103316 |
| Circuit breakers       | G3-8 CP-50-01-56<br>103317 |
| Fresh and heated air   | G3-8 CP-50-01-16<br>700957 |
| 12V receptacle         |                            |
| Intercom / Audio Panel | G3-8 CP-50-01-54<br>103315 |
| Circuit breakers       | G3-8 CP-50-01-55<br>103316 |
| Fresh and heated air   | G3-8 CP-50-01-56<br>103317 |
| 12V receptacle         | G3-8 CP-50-01-13<br>700954 |
| ELT Remote Switch      |                            |
| DYNON SV D700          | G3-8 CP-50-01-54<br>103315 |
| Intercom / Audio Panel | G3-8 CP-50-01-55<br>103316 |
| Circuit breakers       | G3-8 CP-50-01-56<br>103317 |
| Fresh and heated air   | G3-8 CP-50-01-17<br>103320 |
| 12V receptacle         |                            |
| ELT Remote Switch      |                            |

[illegible]

- **Required Tools:** Standard metric tools, wire cutting pliers
- **Required Parts:** Cable ties, self-locking nuts (M4) as required for reinstallation
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

Figure 15-2a

## Instrument System - Removal and Installation

### Step A

Remove Retaining Screws  
and Decorative Panel  
Remove Retaining-  
Screws  
from Support Bracket  
(only applicable at  
Avionics Frame).



### Step B

Remove Support Frame  
Retaining Screws



### Step C

The whole Rack can be  
swung out of the Cockpit  
Main Frame.  
Pull out the Rack and  
Disconnect all Harnesses  
from the installed Devices.



Figure 15-2b





### **15.3.6 Pitot and Static System, Description**

The pitot system conveys ram air pressure to the airspeed indicator. The static system vents vertical speed indicator, altimeter and airspeed indicator to atmospheric pressure through plastic hoses connected to a static port on each side of the fuselage. The system is similar in both panels. Refer to the POH Section 7 for further information about the systems and instruments that are equipped.

### **15.3.7 Maintenance**

Proper maintenance of pitot and static system is essential for proper operation of altimeter, vertical speed and airspeed indicator. Leaks, moisture and obstructions in pitot system will result in false airspeed indications, while static system malfunctions will affect readings of all three instruments. Cleanliness and security are the principal rules for system maintenance. The pitot tube and static ports **MUST** be kept clean and unobstructed.

### **15.3.8 Static Pressure System Inspection, Leakage Test**

The following procedure outlines inspection and testing of static pressure system, assuming the altimeter has been tested and inspected in accordance with current Federal Aviation Regulations.

- a. Ensure static system is free from entrapped moisture and restrictions.
- b. Ensure no alterations or deformations of airframe surface have been made which would affect the relationship between air pressure in static pressure system and true ambient static air pressure for any flight configuration.
- c. Attach a source of suction to one static pressure source opening while covering the static pressure vent on the opposite side of the fuselage.
- d. Slowly apply suction until altimeter indicates a 1000-foot increase in altitude.
- e. Cut off suction source to maintain a “closed” system for one minute. Leakage shall not exceed 100 feet of altitude loss as indicated on altimeter.
- f. If leakage rate is within tolerance, slowly release suction source.
- g. Disconnect static pressure line from airspeed indicator and vertical speed indicator. Use suitable fittings to connect hoses together so altimeter is the only instrument still connected into static pressure system.
- h. Repeat leakage test to check whether static pressure system or the bypassed instruments are cause of leakage. If instruments are at fault, they must be repaired by an “appropriately rated repair station” or replaced. If static pressure system is at fault, use following procedure to locate leakage.
- i. Attach a source of positive pressure to static source opening.
- j. Slowly apply positive pressure until altimeter indicates a 500-foot decrease in altitude and maintain this altimeter indication while checking for leaks. Coat line and static source connections with solution of mild soap and water, watching for bubbles to locate leaks.
- k. Repair or replace parts found defective.
- l. Reconnect airspeed and vertical speed indicators into static pressure system and repeat leakage test per steps c through f.



**■ CAUTION**

When applying or releasing suction, do not exceed range of vertical speed indicator or airspeed indicator.

**◆ NOTE**

If leakage rate exceeds maximum allowable, first check all connections, then repeat leakage test. If leakage rate still exceeds maximum allowable, use following procedure.

**■ CAUTION**

Do not apply positive pressure with airspeed indicator or vertical speed indicator connected to static pressure system.

### **15.3.9 Pitot System Inspection, Leakage Test**

To check pitot system for leaks, fasten a piece of rubber or plastic tubing over pitot tube, close opposite end of tubing and slowly roll up tube until airspeed indicator registers in cruise range. Secure tube and after a few minutes recheck airspeed indicator. Any leakage will have reduced the pressure in system, resulting in a lower airspeed indication. Slowly unroll tubing before removing it, so pressure is reduced gradually. Otherwise instrument may be damaged. If test reveals a leak in system, check all connections.

#### **15.3.10 Blowing out Lines**

Condensation may collect in the system and produce a partial obstruction. To clear hose, disconnect at airspeed indicator. Using low pressure air, blow from indicator end of line toward pitot tube.

**■ CAUTION**

Never blow through pitot or static lines towards instruments.

Like pitot lines, static pressure lines must be kept clear and connected safely. When necessary, disconnect static line at first instrument to which it is connected, then blow line clear with low-pressure air. Check all static pressure line connections. If hose or hose connections are used, check for general condition and security. Replace any hose which has cracked, hardened or show other signs of deterioration.

Figure 15-3




Figure 15-4




Figure 15-5




Figure 15-6








Figure 15-7

## Pitot and Static Air System - Indicator Hose Routing


### Non-Electronic Standard Indicator System



### Dynon EFIS D-100 with Back-Up Indicator System



### Dynon EFIS D-100 + Dynon EMS D-120 Engine Monitor, with Back-Up Indicator System



**15.3.11 Removing and Installation of Components**

- **Required Tools:** Standard metric tools, edge cutter
- **Parts required:** Cable ties, hoses as required.
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

To remove pitot tube, unscrew union nut and withdraw tube from support tube. A pitot line running within the left wing is fixed inside the wing and cannot be removed. A backup line is routed along the pitot line, which may be used if damage to the original pitot line inside the wing is detected. The pitot line is connected to the fuselage adjacent to the root rib, access is possible when the left wing is folded back (refer to Pilot Operating Handbook, Section 8). The unused line is secured by a cable tie inside the wing, access is possible thru a hole in the wing root, while the opposite end of this line is connected to the "static-air" port at the pitot tube (the "static-air" port on the pitot tube is not used in the system). If an advanced instrument system is installed (Dynon Glass Cockpit), the second line is used for the AOA (angle of attack) port with the Dynon AOA pitot tube (refer to figure 15-10).

**15.3.12 Trouble Shooting-Pitot Static System**

| Trouble  | Probable Cause  | Remedy  |
|--|---|---|
| Low or sluggish airspeed indication (normal altimeter and vertical speed). | Pitot tube obstructed, leak or obstruction in pitot line. | Test pitot tube and line for leaks or obstructions. Blow out tube and line, repair or replace damaged line. |
| Incorrect or sluggish response (all three instruments).                    | Leaks or obstructions in static line.                     | Test line for leaks and obstructions. Repair or replace line, blow out obstructed line.                     |

## 15.3.13 Trouble Shooting Airspeed Indicator

|                |   |
|----------------|---|
| <b>CAUTION</b> | In case of exchanged airspeed indicator refer to airspeed speed markings according to POH and current status of notices of continued airworthiness. |
|----------------|---|

| Trouble                                     | Probable Cause   | Remedy   |
|---|--|--|
| Pointer fails to respond.                   | Pitot pressure connection not properly connected to pressure line from pitot tube. | Test line and connection for leaks. Repair or replace damaged line.    |
|   | Pitot or static lines clogged.   | Check line for obstructions. Blow out lines.                           |
| Incorrect indication or pointer oscillates. | Leak in pitot or static lines.   | Test lines and connections for leaks. Repair or replace damaged lines. |
|   | Defective mechanism or leaking diaphragm.  | Substitute known-good indicator and check reading. Replace indicator.  |
| Pointer vibrates.                           | Excessive vibration.   | Check panel shock mounts and replace if required.                      |
|   | Excessive tubing vibration.  | Check clamps, cable ties and line connections for security.            |



**15.3.14 Trouble Shooting Altimeter**

| Trouble                      | Probable Cause  | Remedy   |
|------------------------------|---|--|
| Instrument fails to operate. | Static line plugged.  | Check line for obstructions. Blow out lines.                           |
|                              | Defective mechanism.  | Substitute known-good altimeter and check reading. Replace indicator.  |
| Incorrect indication.        | Pointer not carefully set.                                  | Reset hands with knob.   |
|                              | Leaking diaphragm.  | Substitute known-good altimeter and check reading. Replace indicator.  |
|                              | Pointers out of calibration.                                | Compare reading with known-good altimeter. Replace indicator.          |
| Pointer oscillates.          | Static pressure irregular.                                  | Check lines for obstruction or leaks. Blow out lines.                  |
|                              | Leak in airspeed or vertical speed indicator installations. | Check other instruments and system plumbing for leaks. Blow out lines. |

**15.3.15 Trouble Shooting Vertical Speed Indicator**

| Trouble                      | Probable Cause                 | Remedy   |
|------------------------------|--------------------------------|--|
| Instrument fails to operate. | Static line plugged.           | Check line for obstructions. Blow out lines.                                     |
|                              | Static line broken             | Check line for damage, connections for security. Repair or replace damaged line. |
| Incorrect indication.        | Partially plugged static line. | Check line for obstructions. Blow out line.                                      |
|                              | Ruptured diaphragm.            | Substitute known-good indicator and check reading. Replace indicator.            |
|                              | Pointer off zero.              | Reset pointer to zero.   |
| Pointer oscillates.          | Partially plugged static line. | Check line for obstructions. Blow out lines.                                     |

## 15.4 Engine Indicators

### 15.4.1 Rotax FLYdat System

The FLYdat represents an instrument specially developed for Rotax Aircraft engines for the indication and acquisition of engine operating data readily accessible for the pilot. The FLYdat provides the following indicators:

Engine speed, cylinder head temperature, oil temperature, oil pressure, exhaust gas temperatures, operation hours.

The operating data is being permanently compared with the specific engine operating limit. If the signaled operating data exceeds the stored operating limits, the FLYdat will warn the pilot.

#### 15.4.1.1 Removal and Installation

- **Required Tools:** Standard metric tools, wire-cutting pliers
  - **Parts required:** Cable ties, 4 x self-locking nut (M4)
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- a. Disconnect battery leads and insulate as safety precaution.
  - b. Unscrew retaining screws and remove decorative ABS cover.
  - c. Remove shock-mount screws in both upper corners of the aluminum frame.
  - d. Pull out upper edge of the frame and lift up to disengage the lower shock-mounts from cockpit main-frame.
  - e. Disconnect wiring and hoses and remove panel.
  - f. Unscrew and remove FLYdat.
  - g. Reverse preceding steps for reinstallation.

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Do not overtighten cover fixing screws at reinstallation, because this would cause the ABS decorative cover to crack. |
|---------------|---|

#### 15.4.1.2 Trouble Shooting

| Trouble                  | Probable Cause                 | Remedy  |
|--------------------------|--------------------------------|---|
| FLYdat fails to operate. | Low battery voltage.           | Check, recharge or replace battery. Refer to Section 2. |
|                          | Blown fuse or circuit breaker. | Replace fuse or reset circuit breaker.                  |

|                      |                                      |   |
|----------------------|--------------------------------------|---|
|                      | Defective FLYdat.                    | Substitute known-good FLYdat and check operation. Replace FLYdat. |
| Incorrect Indication | Defective sensor.                    | Replace Sensor.   |
|                      | Improper connection.                 | Check terminals, repair or replace defective parts.               |
| No reading / dashes  | Broken wiring or damaged connectors. | Check wiring and connections, repair or replace defective parts.  |
|                      | Defective FLYdat.                    | Substitute known-good FLYdat and check operation. Replace FLYdat. |

### 15.4.2 Fuel Quantity Indicating System, Description

The electric type fuel quantity indicator is used in conjunction with a float – operated variable – resistance transmitter in the fuel tank. The full position of float produces a maximum resistance (~180 ohms) through transmitter, permitting maximum pointer deflection. As fuel level is lowered, resistance in transmitter is decreased, producing a smaller pointer deflection. The transmitter provides a resistance of ~3 ohms in its lower position (fuel empty).

#### 15.4.2.1 Removal and Installation

- **Required Tools:** Standard metric tools
- **Parts required:** Cable ties
- **Level of Maintenance:** Heavy
- **Certification required:** A&P Mechanic, LSA Repairman, Part 145 Repair Station, REMOS Service Center

To remove the fuel quantity transmitter, the fuel tank has to be removed first, refer to Section 12 for detailed information. Remove screws attaching transmitter and carefully work transmitter from tank. Do not bend float arm!

Install transmitter by reversing preceding steps. Service fuel tank and check for leaks and correct quantity indication.

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | Ensure transmitter is properly grounded in accordance with Section 12. |
|---------------|--|

#### 15.4.2.2 Trouble Shooting

| Trouble              | Probable Cause                                 | Remedy   |
|----------------------|--|--|
| Failure to indicate. | No power to indicator (pointer stays below 0). | Check fuse/circuit breaker and inspect for open circuit. Repair or replace defective wire. |

|                               |  |   |
|-------------------------------|--|---|
|                               | Grounded wire (pointer stays below 0).                 | Check for partial ground between transmitter and gauge. Repair or replace defective wire. |
|                               | Disconnected or broken wire (pointer stays above 1/1). | Inspect wire for partial damage. Inspect terminal connection on gauge and transmitter.    |
|                               | Defective indicator.                                   | Substitute known-good indicator. Replace indicator.                                       |
|                               | Defective transmitter.                                 | Check resistance of transmitter as outlined in paragraph 15.4.2.                          |
| Off calibration.              | Defective indicator.                                   | Substitute known-good indicator. Replace indicator.                                       |
|                               | Defective transmitter.                                 | Substitute known-good indicator. Recalibrate or replace.                                  |
| Sluggish indicator operation. | Defective indicator.                                   | Substitute known-good indicator. Replace indicator.                                       |
| Erratic readings.             | Loose or broken wiring.                                | Inspect circuit wiring. Repair or replace defective wire.                                 |
|                               | Defective indicator or transmitter.                    | Substitute known-good device. Replace indicator or transmitter.                           |

### 15.4.2.3 *Transmitter Calibration*

|                  |  |
|------------------|--|
| <b>▲ WARNING</b> | Use extreme caution while working with electrical components of fuel system. The possibility of electrical sparks around an “empty” fuel tank creates a hazardous situation. |
|------------------|--|

Before installing transmitter, attach electrical wires and place master switch in “ON” position. Allow float arm to rest against lower float arm stop and read indicator. The pointer should be on 0 (empty) position. Raise float until arm is against upper stop and permit indicator pointer to be on 1/1 (full). If any other reading is dedicated, replace transmitter. Check that floater arm moves without friction.

Adjust float arm to a length of 7.5 inch (measured between floater and float arm fixing screw). Note floater orientation before adjusting arm length.

### 15.4.3 *Manifold Temperature Gauge, Description*

An electronic type manifold/outside temperature gauge, featuring a LCD-display is installed on the right cockpit panel. Temperatures are measured by two sensors installed to the airbox (manifold temperature) and beneath the main gear-fairing at the bottom of the fuselage (outside temperature).

Pressing the "in/out" button will alternate the display between outside and manifold temperature. Refer to the manufacturer's user manual for detailed information.

If the aircraft is equipped with an electronic primary flight display system (Dynom Glass Cockpit System), the temperature gauge is contained within the EMS D-120.

#### 15.4.3.1 ***Removal and Installation***

- a. Disconnect battery leads and insulate as safety precaution.
- b. Unscrew retaining screws and remove decorative ABS cover.
- c. Remove shock-mount screws in both upper corners of the aluminum frame.
- d. Pull out upper edge of the frame and lift up to disengage the lower shock-mounts from cockpit main-frame.
- e. Disconnect wiring and hoses and remove panel.
- f. Remove manifold temperature indicator.
- g. Reverse preceding steps for reinstallation.

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Do not overtighten cover fixing screws at reinstallation, because this would cause the ABS decorative cover to crack. |
|---------------|---|

#### 15.4.3.2 ***Trouble Shooting***

| Trouble                      | Probable Cause         | Remedy   |
|------------------------------|------------------------|--|
| Instrument fails to operate. | No power to indicator. | Check fuse/circuit breaker and inspect for open circuit. Repair or replace defective wire. |
| Failure to indicate.         | Defective sensor.      | Replace indicator.   |
|                              | Defective indicator.   | Replace indicator.   |

### 15.5 ***Magnetic Compass, Description***

The magnetic compass is liquid-filled, with expansion provisions to compensate for temperature changes. It is equipped with compensating magnets adjustable from front of case. No maintenance is required on compass except on occasional check on a compass rose for adjustment of compensation.

### 15.6 ***Slip Indicator***

The slip indicator needs no servicing. If damaged, it needs to be replaced

## 15.7 Bill of Materials Standard Parts

| Order No. | Description  | applicable SN or configuration |
|-----------|--|--------------------------------|
| 103139    | Circuit Breaker 3A                                 | GXeLITE, GXnXES                |
| 103142    | Circuit Breaker 25A                                | GXeLITE, GXnXES                |
| 103140    | Circuit Breaker 5A                                 | GXeLITE, GXnXES                |
| 103281    | Circuit Breaker 7,5A                               | GXeLITE, GXnXES                |
| 103137    | Circuit Breaker 1A                                 | GXeLITE, GXnXES                |
| 103133    | Covering Black A= 9.3                              | GXeLITE, GXnXES                |
| 103258    | Covering Black A= 12,8                             | GXeLITE, GXnXES                |
| 103272    | Lever Switch Unipolar (system switches)            | GXeLITE, GXnXES                |
| 103340    | Lens Head Screw V2A ISO7380 M3x10 Painted          | GXeLITE, GXnXES                |
| 103338    | Lens Head Screw V2A ISO7380 M4x6 Painted           | GXeLITE, GXnXES                |
| 100367    | Shock Mount 15x15 Internal Thread M4               | all                            |
| 100234    | Washer 3,2 DIN125 Form A blue vz                   | all                            |
| 100212    | Self-Locking Nut M4 DIN985 vz                      | all                            |
| 100973    | LED Indicator RP3                                  | all                            |
| 103287    | Lens Head Screw Hexagon Socket M3x16 ISO7380 A2-70 | GXeLITE, GXnXES                |
| 103328    | Distance Bush 3,1x5x5 POM                          | GXeLITE, GXnXES                |
| 103280    | Flaps Switch                                       | all                            |
| 100211    | Self-Locking Nut M3 DIN985 vz                      | all                            |
| 102276    | DYNON OAT Sensor                                   | all                            |
| 102076    | 12 Volt Socket With Cover                          | all                            |
| 103273    | Lever Switch bipolar (master and avionic switch)   | GXeLITE, GXnXES                |
| 103249    | Rubber Buffer cylindrical 10x15 M4                 | all                            |
| 103274    | 3,5 mm stereo jack                                 | all                            |
| 103276    | LED Signal Lamp 5mm red                            | GXeLITE, GXnXES                |
| 103275    | Safety Cover for Main Switch                       | GXeLITE, GXnXES                |

| Order No. | Description                               | applicable SN or configuration |
|-----------|---|--------------------------------|
| 103337    | Lens Head Screw V2A ISO 7380 M4x6 painted | GXeLITE, GXnXES                |
| 103341    | Lens Head Screw V2A ISO7380 M4x10 painted | GXeLITE, GXnXES                |
| 101862    | Pitot Tube WINTER                         | all                            |
| 101914    | Pitot Tube DYNON                          |                                |
| 100569    | Clamp Sleeve                              | all                            |
| 101829    | Bowden Cable Choke                        | all                            |
| 101829    | Bowden Cable Warm/Cold Air                | all                            |
| 100570    | Nut Pitot Tube                            | all                            |
| 101025    | circuit breaker 3A                        | all but GXnXES and GXeLITE     |
| 101026    | circuit breaker 10A                       | all but GXnXES and GXeLITE     |
| 101024    | circuit breaker 25A                       | all but GXnXES and GXeLITE     |
| 100969    | trim switch                               | up to SN 297                   |
| 102167    | wire protection 3x5x8                     | all but GXnXES and GXeLITE     |
| 102146    | cockpit light bracket large               | all but GXnXES and GXeLITE     |
| 102147    | cockpit light bracket large               | all but GXnXES and GXeLITE     |
| 102093    | LED stripe 12V/DC red                     | all but GXnXES and GXeLITE     |
| 102153    | sink bolt ISO7380 M4x10                   | all but GXnXES and GXeLITE     |
| 100214    | rivkle M4x7,05x10,5                       | all but GXnXES and GXeLITE     |
| 102131    | round nut M10x0,75                        | all but GXnXES and GXeLITE     |
| 102050    | knob 12/6mm                               | all but GXnXES and GXeLITE     |
| 100116    | sink bolt DIN7991 M4x16                   | all but GXnXES and GXeLITE     |

## 15.8 *Bill of Materials Instruments*

| Order No. | Description               | applicable SN or configuration          |
|-----------|---------------------------|---|
| 100991    | Compass C-2300 L4P North  | up to 297                               |
| 101654    | Compass C-2300 L4P South  | up to 297                               |
| 102777    | Compass C-2400 L4P North  | 298ff                                   |
| 102865    | Compass C-2400 L4P South  | 298ff                                   |
| 102335    | Airspeed Indicator 3-1/8" | Explorer, AVIATOR-I, AVIATOR-II         |
| 103307    | Airspeed Indicator 2-1/4" | GXeLITE, GXnXES                         |
| 103170    | Altimeter 3-1/8"          | Explorer, AVIATOR-I, AVIATOR-II         |
| 103310    | Altimeter 2-1/4"          | GXeLITE, GXnXES                         |
| 102217    | Slip Indicator            | Explorer, AVIATOR-I and -II up to SN297 |
| 102698    | DYNON EMS D-10            | 298ff, Explorer                         |
| 101650    | DYNON EMS D-120           | AVIATOR-II                              |
| 102696    | DYNON FlightDEK D-180     | 298ff, AVIATOR-I                        |
| 101904    | DYNON EFIS D-100          | AVIATOR-II                              |
| 101649    | Remote Compass EDC D-10A  | AVIATOR-I, AVIATOR-II                   |
| 103300    | SkyView SV-D700           | GXnXES                                  |
| 103301    | SkyView SV-ADAHRS-200     | GXnXES                                  |
| 103302    | SkyView SV-EMS-220        | GXnXES                                  |
| 103305    | SkyView SV-BAT-320        | GXnXES                                  |
| 103303    | SkyView SV-GPS-250        | GXnXES                                  |
| 101898    | Garmin SL40               | all but GXeLITE                         |
| 101634    | Becker AR4201             | GXeLITE                                 |
| 101897    | Garmin SL30               | all but GXeLITE                         |
| 101635    | Garmin GTX327             | Explorer, AVIATOR-I, AVIATOR-II         |
| 102010    | Garmin GTX328             | Explorer, AVIATOR-I, AVIATOR-II         |
| 101636    | Garmin GTX330             | Explorer, AVIATOR-I, AVIATOR-II         |
| 101922    | Becker BXP6401-2-(01)     | GXeLITE                                 |
| 103304    | DYNON SV-XPNDR-261        | GXnXES                                  |



| Order No. | Description               | applicable SN or configuration       |
|-----------|---------------------------|--------------------------------------|
| 103537    | ACK A-30                  | Explorer                             |
| 101992    | TCI SSD120                | Explorer                             |
| 101923    | Becker BE-6400-01         | GXeLITE                              |
| 102011    | Garmin GPSMAP 295/296     | all                                  |
| 102340    | Garmin GPSMAP 495/496     | all                                  |
| 103299    | Garmin GPSMAP 695/696     | GXeLITE, GXnXES                      |
| 101014    | VHF Antenna CI121 o.e.    | all                                  |
| 102512    | VHF Antenna CI122 o.e.    | AVIATOR-II                           |
| 102054    | VOR Antenna CI157P o.e.   | all                                  |
| 101006    | XPDR Antenna AV22 o.e.    | all                                  |
| 102697    | Garmin GMA-240            | SN298ff, Explorer, AVIATOR-I, GXnXES |
| 101836    | Garmin GMA-340            | AVIATOR-II                           |
| 101647    | ps-engineering PM-1000    | up to SN297, no AVI-II               |
| 103324    | ps-engineering PM-3000    | GXeLITE                              |
| 103322    | ps-engineering PMA-8000BT | GXnXES                               |
| 102786    | ELT ACK AFE-01            | all                                  |
| 103131    | ELT ARTEX ME406           | all                                  |
| 102786    | ELT KANNAD AF406 compact  | all                                  |
| 102517    | ELT KANNAD AF406 integra  | all                                  |
| 100992    | Flydat US                 | up to SN297 but AVI-II               |
| 103325    | Garmin aera 500           | all                                  |

## Section 16

### Electrical Systems

| Table of Contents | Section   |
|-------------------|---|
| 16.1              | Electrical System, General ..... 3  |
| 16.2              | Electrical Power Supply System, Description..... 3                              |
| 16.2.1            | Master Wiring System ..... 3  |
| 16.2.2            | Switch Panel ..... 3  |
| 16.2.3            | Master Switch ..... 3   |
| 16.2.4            | Avionics Master Switch..... 3   |
| 16.2.5            | Flap Drive Switch..... 3  |
| 16.2.6            | Device Switches ..... 3   |
| 16.2.7            | Ignition and Magneto Switch ..... 4   |
| 16.2.8            | Automatic Circuit Breakers Panel..... 4   |
| 16.2.9            | Optional Equipment ..... 4  |
| 16.2.9.1          | Connecting Optional Instruments ..... 4   |
| 16.2.9.2          | Connecting Avionics Devices ..... 4   |
| 16.3              | Battery Power System, Description ..... 4                                       |
| 16.3.1            | Removal and Installation ..... 5  |
| 16.3.2            | Trouble Shooting Battery Power System ..... 5                                   |
| 16.3.3            | Cleaning the Battery ..... 6  |
| 16.3.4            | Testing the Battery..... 6  |
| 16.3.5            | Charging the Battery..... 6   |
| 16.4              | Alternator Power System, Description..... 6                                     |
| 16.4.1            | Removal and Installation ..... 6  |
| 16.4.2            | Trouble Shooting ..... 6  |
| 16.5              | Voltage Rectifier Regulator, Description ..... 7                                |
| 16.5.1            | Removal and Installation ..... 7  |
| 16.5.2            | Testing the Voltage Regulator ..... 7   |
| 16.5.3            | Trouble Shooting ..... 7  |
| 16.6              | Aircraft Lighting System, Description ..... 7                                   |
| 16.6.1            | Trouble Shooting ..... 8  |
| 16.6.2            | Navigation Lights, Description ..... 9  |
| 16.6.2.1          | Removal and Installation ..... 10   |
| 16.6.3            | Anti Collision Strobe Lights, Description (refer to figure 16-3 & 16-4)..... 10 |

|          |  |    |
|----------|--|----|
| 16.6.3.1 | Removal and Installation .....                         | 10 |
| 16.6.4   | Instrument/Avionics Lighting, Description .....        | 10 |
| 16.6.4.1 | Removal and Installation .....                         | 10 |
| 16.7     | External Receptacle, Description .....                 | 15 |
| 16.7.1   | Removal and Installation .....                         | 15 |
| 16.8     | Emergency Locator Transmitter, Description .....       | 15 |
| 16.8.1   | Removal and Installation .....                         | 15 |
| 16.9     | Landing Light, Description (refer to figure 16-4)..... | 15 |
| 16.9.1   | Removal and Installation .....                         | 16 |
| 16.10    | Tail Light, Description (refer to figure 16-5).....    | 18 |
| 16.10.1  | Removal and Installation .....                         | 18 |
| 16.11    | Electrical Load Analysis Chart.....                    | 19 |
| 16.12    | Bill of Materials .....                                | 19 |

---

## **16.1 Electrical System, General**

This section contains service information necessary to maintain the Aircraft Electrical Power Supply System, Battery, Alternator Power System, Aircraft Lighting System and Electrical Load Analysis.

## **16.2 Electrical Power Supply System, Description**

Electrical energy for the aircraft is supplied by a 14-volt, direct-current, single-wire, negative ground electrical system. A 12-volt battery supplies power for starting and furnishes a reserve source of power in the event of alternator failure. An engine-driven alternator is the normal source of power during flight and maintains a battery charge controlled by a voltage regulator.

### **16.2.1 Master Wiring System**

The aircraft is equipped with a master wiring system (main bus), featuring various terminal connectors to provide an easy installation of additional electric equipment. The master wiring also provides a master power bus and an avionics power bus system. Detailed wiring diagrams on request at [www.remos.com](http://www.remos.com).

### **16.2.2 Switch Panel**

A switch panel is located at the lower center section of the cockpit frame. The switch panel provides all switches including master and avionic master switch, flap drive switch, trim switch, as long as the indicators for flap- and trim tab position, ignition key, charge tell-tale and throttle lever.

### **16.2.3 Master Switch**

The operation of the battery and alternator system is controlled by a master switch. The switch, when operated, connects the battery to the master wiring system, activating the power systems.

### **16.2.4 Avionics Master Switch**

When the avionics master switch is operated, power to the avionics bus system is enabled. The avionics bus system provides power to all electronic devices like radio, intercom, transponder, GPS, attitude indicator, directional indicator, EFIS system (if fitted).

### **16.2.5 Flap Drive Switch**

A 3-position switch located on the switch panel provides power to the flap drive motor. Push down the switch will extend the flaps continuously to the desired angle, indicated on the gauge below. The switch will engage if pushed to upper position, while flaps will be retracted fully.

### **16.2.6 Device Switches**

The switch panel also provides 2-position switches, to control ACL, fuel pump, position lights, instrument lighting and landing light. The right switch is not used with basic equipment.

### **16.2.7 Ignition and Magneto Switch**

A key type switch installed in the switch panel controls the starter motor and both magnetos. Starting the engine is only possible after the master switch is switched on.

|                  |   |
|------------------|---|
| <b>▲ WARNING</b> | Switching off the master switch while engine running will damage the voltage regulator with serious damage to all installed electronic equipment. |
|------------------|---|

### **16.2.8 Automatic Circuit Breakers Panel**

On the lower edge of the right panel a circuit breaker panel is installed. The panel provides automatic circuit breakers for the master- and avionics bus system.

### **16.2.9 Optional Equipment**

#### **16.2.9.1 Connecting Optional Instruments**

The master wiring system of the aircraft provides terminal connectors for various extensions like: Voltage indicator, exhaust gas indicators, oil temperature gauge, oil pressure gauge, rpm gauge, clock and more. Extension wiring systems are available for most instruments.

#### **16.2.9.2 Connecting Avionics Devices**

The avionics wiring system of the aircraft provides terminal connectors for various extensions like: Radio, intercom, transponder, GPS, attitude-gyro, directional-gyro, EFIS-display system, turn indicator. Extension wiring systems are available for most instruments (on request at [www.remos.com](http://www.remos.com)).

## **16.3 Battery Power System, Description**

The 12 V battery is mounted on left hand forward side of the firewall. The factory installed battery (lead or LiFePo4) requires no maintenance.

For aircraft up to S/N 377 with electrical equipment acc. to min. equipment list for Day-VFR operations install min. 13Ah. For aircraft up to S/N 377 with electrical equipment exceeding Day-VFR min. equipment list or equipped acc. to min. equipment list for Night-VFR operations install min. 16Ah. For S/N 378 ff use min. 7Ah for any equipment. Use Battery type HAWKER GENESIS or equivalent. Installation of LiFePO4 battery is approved.

## 16.3.1 Removal and Installation

- **Required Tools:** Standard metric tools
- **Required Parts:** None
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
  - a. Remove top half of cowl.
  - b. Remove the battery retaining strap.
  - c. Disconnect the ground cable from the negative battery terminal.
  - d. Disconnect the cable from the positive terminal of the battery.
  - e. Lift the battery out of the battery box.
  - f. To replace the battery, reverse preceding steps.

|                |   |
|----------------|---|
| <b>CAUTION</b> | When installing or removing battery, always observe the proper polarity with the aircraft electrical system (negative to ground). Reversing the polarity, even momentarily, will result in failure of semiconductor devices installed in avionics such as glass cockpit, COM or NAV/COM, LED devices, etc |
|----------------|---|

## 16.3.2 Trouble Shooting Battery Power System

| Trouble   | Probable Cause      | Remedy   |
|---|---------------------|--|
| Battery will not supply power to electrical system or crank engine. | Battery discharged. | 1. Measure voltage at battery terminal with master switch and suitable load turned on. Normal battery will indicate 11.5 – 12.0 volts. If voltage is low, proceed to step 2. If voltage is normal, proceed to step 3.            |
|   | Battery faulty.     | 2. Charge battery in accordance with charging information found on the battery. If battery voltage drops below 11.5 volts 12 hours after charging, when connected to the aircraft with master switch turned on, replace battery. |
|   | Faulty wiring.      | 3. Check voltage on master fuse/circuit breaker. Voltage shall not indicate more than 0.3 volts below battery voltage. Replace defective wiring, master switch or connectors.  |

### **16.3.3 Cleaning the Battery**

For maximum efficiency the battery and connections should be kept clean at all times.

- a. Remove the battery and connections in accordance with the preceding paragraph.
- b. Wipe the battery cable ends, battery terminals and the entire surface of the battery with a clean cloth moistened with a solution of bicarbonate of soda (baking soda) and water.
- c. Rinse with clear water, wipe off excess water and allow battery to dry.
- d. Brighten up cable ends and battery terminals with emery cloth or a wire brush.
- e. Install the battery according to the preceding paragraphs.
- f. Coat the battery terminals with an ignition spray product to reduce corrosion.

### **16.3.4 Testing the Battery**

When battery is disconnected from the electrical system of the aircraft, voltage measuring should indicate 12.2 volts or above (regular 12.5 volts). If battery voltage is below 12.2 volts, battery needs to be charged. When battery voltage is below 11.8 volts battery has to be replaced.

### **16.3.5 Charging the Battery**

Battery shall be charged only when disconnected from the aircraft. Charge battery in accordance to the charging instructions found on the battery (lead battery) or in accordance with the manufacturers manual (LiFePO4 battery).

## **16.4 Alternator Power System, Description**

The alternator is an integral part of the engine, rated at 14 volts at 20 amperes continuous output. The output signal is fed to an external rectifier regulator to be provided to the aircraft electrical system.

### **16.4.1 Removal and Installation**

Refer to the Rotax maintenance manual for information about removal and installation of the engine alternator system.

### **16.4.2 Trouble Shooting**

Refer to the Rotax maintenance manual for information about trouble shooting of the engine alternator system.

## **16.5 Voltage Rectifier Regulator, Description**

The rectifier regulator is located on the left forward side of the firewall. Feeding wires from the alternator (left side of ignition housing on the engine) are routed directly to the regulator. The resulting dc output is applied to the aircraft battery and master wiring system. To protect the rectifier regulator a 30A slow blowing fuse is used in the regulator-to-battery wiring located adjacent to the regulator case.

### **16.5.1 Removal and Installation**

- **Required Tools:** Standard metric tools
- **Required Parts:** Insulating tape
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
  - a. Remove cowling.
  - b. Disconnect battery leads and insulate as safety precaution.
  - c. Unplug terminal connector on regulator case.
  - d. Unscrew regulator from firewall and remove.
  - e. Reverse preceding steps for reinstallation.

### **16.5.2 Testing the Voltage Regulator**

Measure system voltage on master fuse/circuit breaker (farthest left on fuse panel), and voltage should indicate 14.0 +/- 0.3 volts with engine running.

### **16.5.3 Trouble Shooting**

Refer to the Rotax maintenance manual (latest issue) for information about trouble shooting of the engine alternator system.

## **16.6 Aircraft Lighting System, Description**

The aircraft lighting system consists of navigation lights, a landing light (fitted to right wing), anti-collision strobe lights and an instrument lighting system. All electrical switches to control the lighting system are located on the switch panel as outlined in paragraph 16.2.2.

Following lighting systems are available.

| <b>Item</b>                 | <b>Manufacturer</b> | <b>Model</b>     | <b>R / O / A (*)</b> |
|-----------------------------|---------------------|------------------|----------------------|
| Position Light LH           | REMOS               | G3-8_WG-21-00-01 | R                    |
| Position Light RH           | REMOS               | G3-8_WG-21-00-02 | R                    |
| Taillight                   | Thiessen            | EPL              | R                    |
| Taillight                   | Kuntzleman          | TL-LED           | A                    |
| Anti Collision Light Rudder | Thiessen            | ACL              | R                    |
| Anti Collision Light Belly  | Thiessen            | ACL              | R                    |
| Anti Collision Light Rudder | Thiessen            | ACL3             | A                    |



|                             |          |                    |        |
|-----------------------------|----------|--------------------|--------|
| Anti Collision Light Belly  | Thiessen | ACL3               | A      |
| ACL/NAV Light LH            | AeroLEDs | PULSAR-NS 90 green | A (7*) |
| ACL/NAV Light LH            | AeroLEDs | PULSAR-NS 90 red   | A (7*) |
| ACL/Taillight               | AeroLEDs | Suntail            | A (7*) |
| Landing Light               | Hella    | FF75               | R      |
| Landing Light               | Hella    | 2PT 00 94 96-801   | A      |
| Landing Light               | AeroLEDs | AEROSUN            | A      |
| Cockpit Illumination LH/RH  | REMOS    | G3-8_CP-20-00-00   | R (8*) |
| Cockpit Illumination Center | REMOS    | G3-8_CP-20-00-01   | R (8*) |
| Cockpit Illumination        | divers   | LED-5000MCD        | R (9*) |

(\*) R = required, O = optional, A = alternative

(7\*) in case of AeroLEDs PULSAR-NS 90 position lights, use taillight AeroLEDs SUNTAIL only, and do not use additional anti collision light of any kind in this case

(8\*) in combination with standard cockpit only

(9\*) in combination with eLITE/NXT cockpit only

## 16.6.1 Trouble Shooting

| Trouble             | Probable Cause           | Remedy   |
|---------------------|--------------------------|--|
| Landing light out.  | Landing light turned on? | Turn landing light switch to on position.  |
|                     | Short circuit in wiring. | 1. Inspect fuse/circuit breaker. If open, proceed to step 2. If OK, proceed to step 3.                                 |
|                     | Defective wiring.        | 2. Test each circuit separately until short is located. Repair or replace wiring.                                      |
|                     | Defective switch.        | 3. Check voltage at light with master switch and landing light switch ON. Should read battery voltage. Replace switch. |
| All nav lights out. | Short circuit in wiring. | 1. Inspect fuse/circuit breaker. If open, proceed to step 2. If OK, proceed to step 3.                                 |
|                     | Defective wiring.        | 2. Test each circuit separately until short is located. Repair or replace wiring.                                      |

|                                   |                                     |  |
|-----------------------------------|-------------------------------------|--|
|                                   | Defective switch.                   | 3. Check voltage at nav lights with master switch and nav light switch ON. Should read battery voltage. Replace switch.    |
| One nav light out.                | Lamp burned out.                    | Inspect lamp, replace lamp.  |
|                                   | Open circuit in wiring.             | Test wiring for continuity. Repair or replace wiring.  |
| Anti-collision strobe light out.  | Flash tube burned out.              | Test with new tube, Replace tube.  |
|                                   | Faulty wiring.                      | Test for continuity, Repair or replace.  |
|                                   | Faulty power supply.                | Test with new power supply, Replace power supply.  |
|                                   | Circuit breaker open or fuse blown. | Inspect, reset.  |
|                                   | Faulty switch.                      | Test for continuity, Repair or replace.  |
| Instrument lights will not light. | Short circuit in wiring.            | 1. Inspect fuse/circuit breaker. If open, proceed to step 2. If OK, proceed to step 3.                                     |
|                                   | Defective wiring.                   | 2. Test each circuit separately until short is located. Repair or replace wiring.  |
|                                   | Defective switch.                   | 3. Check voltage at lights with master switch and instrument light switch ON. Should read battery voltage. Replace switch. |
|                                   | Lamps burned out.                   | Inspect lamps, replace lamps.  |

## 16.6.2 Navigation Lights, Description

The navigation lights are located on each wing tip. The lights are controlled by a rocker type switch located on the switch panel.

|               |  |
|---------------|--|
| <b>◆ NOTE</b> | There are two different types of position lights. Refer to figure 16-1 and 16-2 for further information. |
|---------------|--|

## 16.6.2.1 Removal and Installation

- **Required Tools:** Standard metric tools
  - **Required Parts:** None
  - **Level of Maintenance:** Line
  - **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center
- a. Unscrew and remove colored protective cover.
  - b. Unscrew and replace LED Position Light Assembly.
  - c. Reverse preceding steps for reinstallation.

|               |   |
|---------------|---|
| <b>◆ NOTE</b> | Do not overtighten cover fixing screws at reinstallation, to prevent the cover from cracking. |
|---------------|---|

## 16.6.3 Anti Collision Strobe Lights, Description (refer to figure 16-3 & 16-4)

A red LED strobe light is installed on top of the rudder and light is vibration resistant, producing an extremely high intensity flash. A second LED type strobe light is found on the bottom of the fuselage, behind the main gear.

### 16.6.3.1 Removal and Installation

To replace flash lights, unscrew light from top of the rudder or the bottom of the fuselage and disconnect from power leads.

## 16.6.4 Instrument/Avionics Lighting, Description

All installed instruments, which are equipped with internal lights, are connected to the lighting system of the aircraft. Power to the instrument and avionics lights is provided by a rocker-type switch on the switch panel.

Additional the cockpit provides a LED lighting system, which is activated along with the instrument lights. A dim control on the left side of the cockpit allows adjustment of the intensity. Refer to Section 15 for detailed information.

### 16.6.4.1 Removal and Installation

Refer to the appropriate user manuals provided with the instruments and avionics devices for instructions about replacement of instruments and avionics lights.

The LED arrays can be removed easily by unscrewing them from the cockpit frame. Take care to switch of master switch before removal.

Figure 16-1




Figure 16-2




Figure 16-3





Figure 16-4



## **16.7 External Receptacle, Description**

A receptacle for connecting external equipment like GPS is installed to the right side of the cockpit frame. The receptacle provides 12 volt (positive lead on center terminal). The receptacle is of a cigar lighter type. Current is limited to 1 A.

### **16.7.1 Removal and Installation**

- **Required Tools:** Standard metric tools
- **Required Parts:** Cable ties, insulating tape, solder
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

To remove the external receptacle proceed as outlined below.

- a. Disconnect battery leads and insulate as safety precaution.
- b. Unscrew the right hand side option-panel from the cockpit main frame.
- c. Disconnect wiring from the receptacle, note wiring for reinstallation.
- d. Unscrew and remove receptacle
- e. Reverse preceding steps for reinstallation.

## **16.8 Emergency Locator Transmitter, Description**

The ELT is a self-contained, solid state unit, with its own power supply, with an externally mounted antenna. The transmitter is designed to transmit a frequency of 121.5 Megahertz as long as 406 MHz. Alternatively a 121.5 MHz transmitter may be installed too.

Power is supplied to the transmitter by a battery-pack which has the service life of the batteries placarded on the batteries. A switch on the face plate of the ELT is provided to arm or manually operate the system (in example for testing purposes).

### **16.8.1 Removal and Installation**

Open clamp at the transmitter bracket installed on top of the rear cabin bulkhead, unplug antenna cable and remove device from its bracket.

## **16.9 Landing Light, Description (refer to figure 16-4)**

The landing light is mounted to the leading edge of the right wing. The landing light is a LED type lighting system, providing a multiple lens system to facilitate landing and taxiing light contained in one unit. A light cover provides weather protection for the device. The landing and taxi light is controlled by a rocker type switch located on the switch panel.




## 16.9.1 Removal and Installation

- **Parts required:** Standard metric tools
- **Required Parts:** Landing light kit including wiring, terminals and cable clamps
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

To remove the landing light, proceed as outlined below.

- a. Disconnect battery leads and insulate as safety precaution.
- b. Unscrew the light cover from the leading edge of the right wing.
- c. Unscrew and remove landing light.
- d. Disconnect wiring from landing light LED device, note wiring for reinstallation.
- e. Reverse preceding steps for reinstallation.

Figure 16-5



## 16.10 Tail Light, Description (refer to figure 16-5)

The tail light is mounted to a removable tail cover, fixed to the tail cone by two fixing screws. The tail light is a LED type lighting system, providing an angle of 140°. The tail light is controlled by a rocker type switch located on the switch panel (labeled NAV-Light).


### 16.10.1 Removal and Installation

- **Required Tools:** Standard metric tools
- **Required Parts:** Tail light kit including wiring, terminals and cable clamps
- **Level of Maintenance:** Line
- **Certification required:** A&P Mechanic, LSA Repairman, Owner/Operator with Sport Pilot certification or higher, Part 145 Repair Station, REMOS Service Center

To remove the tail light, proceed as outlined below.

- a. Disconnect battery leads and insulate as safety precaution.
- b. Unscrew the tail cover from the tail cone and unplug from terminal. Unscrew and remove tail light.
- c. Reverse preceding steps for reinstallation.

Figure 16-6



## 16.11 Electrical Load Analysis Chart

Refer to the POH to get further information about the load analysis for the REMOS GX flight instrumentation.

## 16.12 Bill of Materials

| Fig. No. | Item No. | Order No. | Part No.         | Qty. per Assy | Description                              | Appl. S/N |
|----------|----------|-----------|------------------|---------------|--|-----------|
| 16-1     | 1        | 100189    |                  | 6             | Flat Head Screw 4x12 ISO-7380-A2         | All       |
|          | 2        | 100808    | G3-8 WG-21-00-02 | 1             | Position Light Cover LED left red        | All       |
|          |          | 100809    | G3-8 WG-21-00-03 | 1             | Position Light Cover LED right green     | All       |
|          | 3        | 700613    | G3-8 WG-21-00-04 | 1             | Wing Position Light LED Assy N-VFR left  | All       |
|          |          | 700614    | G3-8 WG-21-00-05 | 1             | Wing Position Light LED Assy N-VFR right | All       |
|          | 4        | 100189    |                  | 4             | Flat Head Screw 4x12 ISO-7380-A2         | All       |
| 16-2     | 1        | 100189    |                  | 6             | Flat Head Screw 4x12 ISO-7380-A2         | All       |
|          | 2        | 103177    | G3-8 WG-20-01-04 | 1             | Position Light Cover left colorless      | All       |
|          |          | 103178    | G3-8 WG-20-01-05 | 1             | Position Light Cover right colorless     | All       |
|          | 3        | 103113    |                  | 1             | Strobe Light Pulsar NS90 NAV left red    | All       |
|          |          | 103113    |                  | 1             | Strobe Light Pulsar NS90 NAV right green | All       |
|          | 4        | 100189    |                  | 2             | Flat Head Screw 4x12 ISO-7380-A2         | All       |
| 16-3     | 1        | 100189    |                  | 4             | Flat Head Screw 4x12 ISO-7380-A2         | All       |
|          | 2        | 100650    | G3-8 FU-03-01-03 | 1             | Cover Plate ACL                          | All       |
|          | 3        | 100112    |                  | 2             | Cylinder Head Screw M4x10 DIN 912 vz     | All       |
|          | 4        | 101809    |                  | 2             | Countersunk Screw M4x16 A2               | All       |
|          | 5        | 700858    |                  | 1             | Thiessen ACL                             | All       |
|          | 6        | 102549    | G3-8 FU-20-01-05 | 1             | ACL Adapter                              | All       |
| 16-4     | 1        | 100212    |                  | 2             | Self-locking Nut M4 DIN985 vz            | -         |
|          | 2        | 100233    |                  | 2             | Washer M4 DIN 125 vz                     | -         |
|          | 3        | 102554    |                  | 1             | Anticollisionslight ACL 1                | -         |
|          | 4        | 100113    |                  | 2             | Cylinder Head Screw M4x16 DIN 912 vz 8.8 | -         |
| 16-5     | 1        | 100189    |                  | 6             | Lens Head Screw FL M4x12 ISO 7380 A2     | All       |
|          | 2        | 102635    | G3-8 WG-22-01-01 | 1             | Bracket Landing Light Left Hand Side     | All       |
|          | 3        | 100199    |                  | 4             | Lens Head Screw FL M5x16 ISO 7380 A2     | All       |
|          | 4        | 100864    | G3-8 WG-20-01-01 | 1             | Cover Landing Light                      | All       |
|          | 5        | 102614    |                  | 1             | Landing Light Aerosun 1600               | All       |
|          | 6        | 102636    | G3-8 WG-22-01-02 | 1             | Bracket Landing Light Right Hand Side    | All       |
| 16-6     | 1        | 100105    |                  | 2             | Cylinder Head Screw M3x16 DIN 912 vz     | All       |
|          | 2        | 103112    |                  | 1             | Suntail Position Strobe Light            | All       |
|          | 3        | 100234    |                  | 2             | Washer M3 vz                             | All       |
|          | 4        | 100211    |                  | 2             | Self-locking Nut M3 DIN 985 vz           | All       |
|          | 5        | 102497    | G3-8 FU-02-83-02 | 1             | Fuselage Tail End                        | All       |

**REMOS GX**

*Intentionally left blank*

## Section 17

### *Structural Repair*

| <b>Table of Contents</b> | <b>Section</b>   |
|--------------------------|--|
| 17.1                     | Structural Repair Criteria ..... 3                                 |
| 17.1.1                   | General Consideration for Composite Repair ..... 3                 |
| 17.1.2                   | Methods to classify damages ..... 3                                |
| 17.1.3                   | Category of Damage..... 4  |
| 17.1.4                   | Repair Instructions..... 5   |
| 17.2                     | General Repair Instruction..... 5                                  |
| 17.2.1                   | Requirements ..... 5   |
| 17.2.1.1                 | Labor..... 5   |
| 17.2.1.2                 | Personnel..... 5   |
| 17.2.1.3                 | Tools and Work Clothes ..... 5                                     |
| 17.2.1.4                 | Working Conditions Resin/Hardener ..... 5                          |
| 17.2.1.5                 | Processing of Composites..... 5                                    |
| 17.2.1.6                 | Scarf Joints and Laps ..... 6                                      |
| 17.2.1.7                 | Gluing of Composite Parts..... 6                                   |
| 17.2.1.8                 | Gluing of Metal Parts ..... 6                                      |
| 17.2.1.9                 | Materials and Acquisition..... 6                                   |
| 17.2.1.9.1               | Resin/Hardener..... 6  |
| 17.2.1.9.2               | Reinforcing Fiber ..... 8  |
| 17.2.1.9.3               | Aggregates ..... 8   |
| 17.2.1.9.4               | Acquisition (example) ..... 8                                      |
| 17.2.1.9.5               | Top Coat ..... 8   |
| 17.2.1.10                | Laminate Plan..... 8   |
| 17.2.2                   | Typical Cases of Repair ..... 9                                    |
| 17.2.2.1                 | Uncontinuous Hole or Crack in Laminate ..... 10                    |
| 17.2.2.2                 | Continuous Hole in Sandwich Construction ..... 11                  |
| 17.2.2.3                 | Damages in Solid Laminate..... 12                                  |
| 17.2.2.4                 | Cracks in Connections and Bondings between Laminate Plies ..... 12 |
| 17.2.2.5                 | Loose or worn Bushings ..... 12                                    |
| 17.2.2.6                 | Finishing ..... 13   |
| 17.3                     | Firewall Damage, Description..... 13                               |
| 17.3.1                   | Negligible Damage ..... 13   |

|        |   |    |
|--------|---|----|
| 17.4   | Engine Mount, Description .....   | 14 |
| 17.4.1 | General Considerations .....  | 14 |
| 17.4.2 | Damage at Engine Mounting Lugs and Engine Mount to Fuselage Attach Fittings ..... | 14 |
| 17.5   | Residual Torque .....   | 14 |

### 17.1 **Structural Repair Criteria**

Although this section outlines repair permissible on structure of the aircraft, the decision of whether to repair or replace a major unit of structure will be influenced by such factors as time and labor available, and by a comparison of labor costs with the price of replacement assemblies. Past experience indicates that replacement, in many cases, is less costly than major repair. Certainly, when the aircraft must be restored to its airworthy condition in a limited length of time, replacement is preferable. Restoration of a damaged aircraft to its original design strength, shape, and alignment involves careful evaluation of the damage, followed by exacting workmanship in performing the repairs. This section suggests the extent of structural repair practicable on the aircraft, and supplements Federal Aviation Regulation, Part 43. Consult the factory when in doubt about a repair not specifically mentioned here.

#### 17.1.1 **General Consideration for Composite Repair**

All major and structural components of the aircraft are carbon-fiber or glass-fiber construction. We strongly recommend the replacement of components when structural damage is detected or return to factory for repair. Repair to non-structural components may be accomplished using factory specified materials. Observe the resin manufacturer's recommendations concerning mixing and application of the resin. Epoxy resin is mandatory for making repairs, since epoxy compounds are usually more stable and predictable than polyester and, in addition, give better adhesion.

#### 17.1.2 **Methods to classify damages**

Following inspection methods are recommended to detect and classify damages at your plane.

| Damage                          | Inspection Method           |
|---------------------------------|-----------------------------|
| Scratches                       | Visual Inspection           |
| Bump, Blowhole, Pressure Points | Visual Inspection           |
| Loose Bondings                  | Tap Test                    |
| Delamination                    | Tap Test, Visual Inspection |
| Cracks                          | Visual Inspection           |
| Deformation                     | Visual Inspection           |
| Erosion                         | Measurement                 |

Keep following questions in mind when classifying the damage.

- Any noticeable changes of the geometry of the plane or parts of it?
- Rudder, flaps difficult to move?
- Laminate smooth or bumps in laminate?
- Are there any delaminated areas?
- Are there any bumps or cracks in the topcoat?
- Is the GRP structure cracked or broken through?
- Are there any stress whitening?



**17.1.3 Category of Damage**

After classifying the damage it is necessary to put your damage into one of the three categories of damage.

After that you can read if you are allowed to repair your plane by your own or not.

**Class 1:**

Widely damaged areas that need to be repaired

Cracks and holes that are longer than 20 cm - 8"

All damages at flaps, aileron, elevator, and rudder

**Class 2:**

Cracks and holes that are not longer than 20 cm – 8"

It is not allowed that these damages are detected at primary flight controls, such as flaps, aileron, elevator or rudder

**Class 3:**

Small cracks or scratches at the outer GRP-skin of the plane

Small cracks and scratches that are detected in the topcoat

|         | A&P Mechanic                         | LSA Repairman                        | Owner/Operator with Sport Pilot certification | Part 145 Repair Station              | REMOS Service Center                 |
|---------|--------------------------------------|--------------------------------------|---|--------------------------------------|--------------------------------------|
| Class 1 | Individual Repair Instruction needed | Individual Repair Instruction needed | <b>NOT</b> allowed to repair                  | Individual Repair Instruction needed | Individual Repair Instruction needed |
| Class 2 | Allowed repair to                    | Allowed repair to                    | Allowed to repair                             | Allowed repair to                    | Allowed repair to                    |
| Class 3 | Allowed repair to                    | Allowed repair to                    | Allowed to repair                             | Allowed repair to                    | Allowed repair to                    |

For any class 1 damage an individual repair instruction and repair approval issued by REMOS AG is required. This is defined in the regulations (ASTM F2483).

REMOS AG always takes care of its customers and will provide support, documentation and re-certification of the aircraft.

Please keep in mind that without a written repair approval issued by REMOS AG the aircraft is considered not in compliance with the applicable regulations and may be subject to regulatory action by FAA. Therefore the aircraft may not be operated after an unauthorized repair. This is defined in the regulations ASTM F2295).

## 17.1.4 Repair Instructions

Applicable repair methods are written down in the AC 43.13-1B, Rotax Maintenance Manual (latest Issue) and the General Repair Instruction starting at 17.2 in this chapter.

## 17.2 General Repair Instruction

### 17.2.1 Requirements

#### 17.2.1.1 Labor

Laminating of components is only permitted when the person is introduced in working procedures and firm with all tools. Follow all safety instructions to tools and materials. Everybody working with tools or materials has to maintain the safety measures.

#### 17.2.1.2 Personnel

The following repair procedure may be conducted by following personnel:

- A&P mechanic
- LSA Repairman
- Part 145 Repair Station
- REMOS Service Center

#### 17.2.1.3 Tools and Work Clothes

All tools and work clothes that are necessary for repairing need to be free of oil and grease. The vessels, equipment and tools used for the resin and hardener must be clean. The tools and equipment used to handle release agent must be kept separate from the tools and equipment used for the resin and hardener. The risk of contamination can be reduced by covering the resin, hardener and mixtures, Tools should be cleaned after work is done

#### 17.2.1.4 Working Conditions Resin/Hardener

Temperature – The optimal temperature is 20-35°C. Raising the temperature by 10°C halves the pot life and doubles the reactivity.

Important: Larger quantities should not be mixed at higher processing temperatures, above all with highly reactive systems (short pot life less than forty minutes). The mixing vessels exhibits very low heat dissipation, so its contents are very quickly heated by the reaction. This can give rise to temperatures in excess of 200 at which the resin compound burns up emitting a great quantity of smoke. This also affects large volume casts of highly reactive systems.

Air humidity – The relative air humidity during processing should not exceed 70%.

#### 17.2.1.5 Processing of Composites

Attention! It is necessary that all components are free of:

- Fat and Grease
- Release Agent
- Dust
- Liquids
- Silicone. It is very important to protect all surfaces for gluing from silicone!

#### **17.2.1.6 Scarf Joints and Laps**

Scarf joints and laps transmit tensile- and shear forces through different laminate plies. Scarf joints are made by abrading transitions of laminate plies. Avoid concentrations of multi-layer parts. In case of damage, it is necessary to maintain a mounting rate of 1:30 for glass fibers and 1:80 for carbon fibers.

#### **17.2.1.7 Gluing of Composite Parts**

For a good connection between two or more composite parts, following prearrangements are necessary:

- Rough gluing surface with sand paper (grit 80-100)
- NOTE: Gluing surface is ready if there are no shiny spots to see.
- ATTENTION: Front sides and edges must be grinded very careful. Often there is some more paint or a lack of release agent. Bad grinded edges can crack, or they do not connect with resin.
- After preparation of the gluing surface, it is necessary to protect the surface from all the things listed in 1.4 "Processing of Composites".
- Spread gluing surface with normal mixture of resin/hardener before working with mixture of cotton flocks/resin
- Set position of parts by devices that were build before
- Check position of glued parts by devices
- Remove overrun of resin/cotton flocks mixture accurate
- Check adhesion for air inclusions. Rework the adhesion in case of air locks.

#### **17.2.1.8 Gluing of Metal Parts**

The surface of metal parts must be rough for gluing. Sand blast or grind (sand paper grit 100-120) the surface that is needed for gluing. Clean the surface with acetone afterwards. Now it is allowed to spread the metal with resin.

It is wise to connect metal part and parts of the plane with a mixture of resin and cotton flocks. Cotton flocks mixed with resin enhance the tensile, compressive, and flexural strengths as well as the fracture behavior.

#### **17.2.1.9 Materials and Acquisition**

It is not allowed to use different materials than listed in this repair instruction.

Contact the manufacturer if it is not possible to supply materials or tools.

##### **17.2.1.9.1 Resin/Hardener**

All structure parts are made of resin and hardener. We recommend resin L20 and hardener EPH 573 for repairing. This resin/hardener system is specially made for hand lay-ups and has a relative short pot life (ca. 15 min.). Resin L20 and hardener EPH 573 are cold curing, that means that no annealing on higher temperatures is needed. EPH 161 has a longer pot life, if necessary. But notice that EPH 161 must be annealed under some conditions. Resin L285 with hardener EPH 285; EPH286; EPH 287 must be annealed at 80 °C (176 °F) to obtain their full mechanical strength and characteristics.

It is permitted to use equivalent epoxy laminating resin/hardener systems. Refer to the processing information, safety data sheet and technical data sheet to get further information about the

resin/hardener system. It is mandatory to follow the mixing ratios, annealing temperatures and safety information given in this data sheets.

The resin/hardener systems are unequal toxic. The L20 resin with hardener is low toxic and the L285 with hardener is toxic. Handle both with care. Please avoid direct contact to your skin (latex gloves) and protect your eyes. Have a closer look at the safety data sheet of this product for more information.

The resin/hardener mixture must be very exact. More hardener does not mean a faster reaction. More hardener leads to a lower mechanical strength or an imperfect curing.

Epoxy must be post cured at 50-60C for 15hrs per manufacturers specifications.

The resin/hardener mixing ratio for L20/EPH 573:

100 : 23 parts by weight of resin to hardener

100 : 25 parts by volume of resin to hardener

The resin/hardener mixing ratio for L20/EPH 161:

100 : 25 parts by weight of resin to hardener

100 : 29 parts by volume of resin to hardener

The resin/hardener mixing ratio for L285/EPH 285; L285/EPH 286; L285/EPH 287

100 : 40 parts by weight of resin to hardener

100 : 50 parts by volume of resin to hardener

No liability assumed! Check the data sheet for correct mixing ratio before.

Smallest-scale quantities should therefore be dosed according to volume with disposable injectors. At the same time, it is important to note that parts by weight are not the same as parts by volume, because the constituents exhibit different specific gravities (resins about 1.1 g/cm<sup>3</sup>, hardeners about 1.0 g/cm<sup>3</sup>).

The resin and hardener must be mixed with care. The service life (pot life, processing time) of the mixture is defined by the initial quantity (the larger, the faster) and by its history of experienced temperature effects. Larger quantities have an effect. The effects of their exothermal reaction (reaction heat) serve to reduce the open time. They should be transferred to flat dishes to prevent heat accumulation. They must be processed quickly. Small quantities under 100 g have an extended pot life. If the temperature in the mixing vessel should rise noticeably and exceed 40 °C, then the mixture may no longer be used for high-quality laminates. Unvarying quality in the manufacture of laminates can then no longer be guaranteed. Flat mixing vessels with smooth walls and base should be used. Ideal are PE mixing cups. For industrial hygiene reasons, the professional association of chemical workers recommends disposable receptacles. Adherent residue of completely cured resin is environmentally neutral and its disposal is permitted in solid domestic or commercial waste. In principle, reusable plastic receptacles (e.g. of PE) can also be used.

**17.2.1.9.2      Reinforcing Fiber****Glass Fiber**

- Glass fabric 163 g/m<sup>2</sup> (Aero) Interglasnumber: 92110 Twill weave
- Glass fabric 220 g/m<sup>2</sup> (Aero) Interglasnumber: 92145 Unidirectional
- Glass fabric 280 g/m<sup>2</sup> Interglasnumber: 92125 Twill weave

**Carbon Fiber**

- Carbon fabric 200 g/m<sup>2</sup> KDK 8042 or Interglas 98141 Twill weave

**17.2.1.9.3      Aggregates**

The fillers named below enhance the impact and compressive strength, but not the tensile strength. Owing to their ball-bearing effect they improve the flowability of resins when added in low quantities.

- Micro-Airballons
- Cotton flocks
- Spherical fillers
- Micro-Airballons

The fillers named below enhance the tensile, compressive, and flexural strengths as well as the fracture behavior. The weight of filled resin compounds is increased, the flowability reduced.

- Fibrous fillers
- Cotton flocks

**17.2.1.9.4      Acquisition (example)**

R&G Faserverbundwerkstoffe GmbH  
Im Meißel 7 – 13  
D-71111 Waldenbuch  
Telephone: +49-7157-530460  
Fax: +49-7157-530470  
Internet: [www.r-g.de](http://www.r-g.de)

**17.2.1.9.5      Top Coat**

PPG Delfleet 350, Color-Code: 00225

Contact manufacturer for more information about the Top Coat.

Grind the surface with sand paper (grit 320-400) Clean the surface before you start painting the repairing. Keep surface clean of silicone, dust etc. Grind surface with sand paper (grit 320-400). Everything is well grinded if the underground is matt. A higher grid raises stress concentration and the Top Coat will crack.

**17.2.1.10      Laminate Plan**

In case of damage, it is necessary to maintain a mounting rate of 1:30 for glass fibers and 1:80 for carbon fibers. Therefore it is practicable to know the quantity, type and adjustment of all plies to repair.

Refer to the applicable laminate plan. All parts to be repaired should get their full strength afterwards. Quantity, fabrics, type of fabric and adjustment need to be concordant to the original part of the plane.

## 17.2.2 Typical Cases of Repair

Before a repair is started it must be ensured that there is a damage in the material. In a lot of cases a crack appears necessary to be repaired but in most cases it is not. This case happens if cracks are just superficial in the paint, in the filler, priming material or spackling paste. In this case start sanding into the crack and find out, if and where there is a damage. See the two pictures below for examples of cracks where there is no structural damage but only superficial cracks – optical damage only:



superficial crack in elevator leading edge




superficial crack in paintwork

**17.2.2.1      *Uncontinuous Hole or Crack in Laminate***


We recommend following repair method for damages in outer parts of laminate, where the sandwich construction is not damaged:

- Grind the crack manually with dry sand paper (grit 60-80) or an angle grinder. Work feeling and circular till Top Coat is removed. It is necessary to remove Top Coat about 1.2" around the crack.
- Cut off the core material down to the inner laminate to ensure that the inner laminate is not harmed. Cut the core material circular. (If there is no core material, just start preparing a scarf joint)
- Take a piece of support material. Trim the support material a bit smaller than the original. (Up to 0.4" smaller) Clean the surface of the repairing. Now use a resin/Microballons/cotton flocks mixture to glue the support material into the repairing. Fulfill the gaps with some mixture of resin/Microballons/cotton flocks. Wait till the resin hardened.
- Grind transitions again.
- Refer to the laminate plan, cut some plies of carbon or glass for your repairing. Mind the type and adjustment of all plies needed. Cut the plies from big to small. That means that the last ply is smaller than the first ply.
- Spread the repairing with some resin. Take the first ply of carbon or glass (biggest ply first) and put it on the repairing. Attention: Regard adjustment and type of fabric.
- Use resin and impregnate the fabric carefully. Be particularly careful with carbon fabrics. It is very difficult to see an impregnation. Glass fabrics are well impregnated if there are no more white spots.
- If it is impossible to impregnate parts of fabrics, it could be that the fabric got wet. The fabric is no longer useful.
- Do not change the adjustment of the fabric while impregnating.
- Put on other fabrics. Refer to the adjustment and impregnate the fabrics.
- Normally it is not necessary to impregnate the last ply. It should be possible to impregnate the last ply only by dabbing with a laminating brush. The ply takes the resin overrun and so the fiber volume fraction is enhanced. The higher the fiber volume fraction, the higher the solidity.
- Put one peel ply fabric over the repairing, to secure the resin from dust, silicone etc. Fix the position of the repairing with some stress belts, or some weights. Wait until the structure is well cured.
- Take off the peel ply fabric when everything is well cured. (Well cured when outer fibers break off brittle)
- If necessary, grind transitions with sandpaper (grit 180) as long as needed to get a good surface.
- The grinded surface must be a bit deeper than the Top Coat. It could be helpful to proof it with the help of a steel rule.
- Prime and finish if necessary.



## 17.2.2.2 Continuous Hole in Sandwich Construction


- If there are any damages trough the whole sandwich-construction, it is recommendable to rebuild the inner laminate first.
- Cut off the outer laminate and the support material on a length of about 1.2" around the damaged area. Now there should be a 1.2" area of intact inner laminate around the damaged area.
- Rebuild the inner laminate on a plate or form. It is important that the reconstructed laminate has the same form as the original part. Remind the type, adjustment, and quantity of fabrics. If the reconstructed part cured well, it can be glued with a mixture of resin/cotton flocks.
- Glue the support material with a mixture of resin/microballons. Fill the gaps with a mixture of resin/microballons and spread the support material with some resin
- Prepare a scarf joint referring to the part 2.1





### 17.2.2.3 **Damages in Solid Laminate**

- Cracks, breaks etc. in solid laminate shall be grinded with sand paper (grit 60-80) first.
- Prepare a scarf joint. Refer to the mounting rates (glass 1:30; carbon 1:80).
- Do not remove too much damaged laminate. The impregnated fabrics need some underground to keep their form.
- Bigger holes must be prepared with a cured part of laminate. The laminate must have the right size and form. This part is glued at the inside with a mixture of resin/cotton flocks (have a look at the picture). After curing, it is the same procedure as written down in the part "Uncontinuous hole or crack in laminate".



### 17.2.2.4 **Cracks in Connections and Bondings between Laminate Plies**

- Cracks parallel to plies can be fixed with resin injections by syringes.
- Another method is filling the crack with a resin/cotton flock mixture. (If the cracks are bigger)
- It is possible to take and glue a fabric stripe over the repairing for strengthening. When everything cured well, start grinding the repairing.

### 17.2.2.5 **Loose or worn Bushings**

Bushings may get worn with time and even might become loose in the laminate. This might affect the following bushings (for example, this section is not limited to these examples but is valid for all bushings): main landing gear attachment, horizontal tail attachment, lower rudder hinge, etc. Follow these instructions:

- Disassemble the aircraft component affected from the aircraft
- Get the old bushes out of the laminate. Review the condition of the bushings thoroughly and judge if they can be used again or if they need to be replaced by new ones.
- The surface of the bushings must be rough for gluing. Sand blast or grind (sand paper grit 100-120) the surface of the bushings. Clean the surface with acetone afterwards.
- In case the laminate is worn so much, that the bushings cannot be inserted anymore (e.g. the hole is bigger than the collar of the bushing), rebuild the laminate. The original wall thickness shall be achieved. Rule: one layer of 200g/m<sup>2</sup> carbon cloth has a thickness of 0.25mm. Once the new laminate is cured, drill new holes for the bushings.
- For installation of the bushings prepare a mixture of resin and cotton flocks. Apply this mixture on the bushings and insert them into their installation holes.
- Fix and adjust the position of the bushings with the help of the component related with the bushing. Make sure that there is no resin inside the bushes. Clean overrun of resin.

- Let everything cure well.
- Prime and finish if necessary.

## 17.2.2.6 ***Finishing***

- If everything is cured well, start grinding the repairing. Start with grit 180-220. If there are any unwished holes or smaller roughness, it is recommendable to use some filler. Try to rebuild the structure with filler, if it is necessary.
- Prepare the surface for finishing by grinding an area of about 12" around the repairing. Work with a grit of 400 or higher. Lower grits enhance the possibility of cracks in the new finish. The surface is well prepared if everything looks matt.
- The middle of the repairing must be a bit lower than the edge of the original finish. In fact it has to look like a mounting.
- After grinding the surface, everything must be cleaned with silicone remover.
- Mask everything around the matt edge so that it is impossible to paint something else than the repairing.
- Try to paint more finish in the middle of the repairing. Try to paint less finish at the edge.
- Depending on the size of the repairing, it is functional to work from the inside to the outside.
- Clean the spray gun with acetone after painting.
- The finish needs about two days to cure.

### **IF NECESSARY ONLY:**

If the painting is not satisfying it is recommendable to grind the surface with a fine grit.

- Start grinding with grit 600 or 800 (depending on grade of roughness) and refine the finish with grit 1000 or 1200. After finishing the surface, there should be no more edges or transitions.
- If there are concave areas to grind, a piece of plastic could be a good sanding block.
- Remove the dust after grinding, and clean the surface.
- A satisfying finish needs at least a polish.

## 17.3 ***Firewall Damage, Description***

The firewall is an integral part of the fuselage monocoque structure and cannot be replaced separately. The firewall is constructed from carbon- glass- and kevlar-materials, covered by a heat resistant ceramic at the forward side. The ceramic heat and fire protection layer is sealed by an aluminum protection skin.

Damage to the firewall has to be rated as structural to the whole fuselage necessitating a factory repair of the fuselage.

### **17.3.1 *Negligible Damage***

Damage to the aluminum skin of the firewall can be rated as negligible. A damaged aluminum protection skin should be replaced as soon as possible to prevent the ceramic fire protection layer beneath from damage.

## **17.4 Engine Mount, Description**

The mount for the aircraft engine is constructed of 4130 chrome-molybdenum steel tubing, fastened to the firewall at five points. The mounting frame provides four lugs, equipped with rubber shock mounts to hold the engine.

### **17.4.1 General Considerations**

All welding on the engine mount must be of the highest quality since the tendency of vibration is to accentuate any minor defect present and cause fatigue cracks. Engine mount members are preferably repaired by using a larger diameter replacement tube, telescoped over the stub of the original member using fish mouth and rosette type welds. However, reinforced 30- degree scarf welds in place of the fish mouth welds are considered satisfactory for engine mount repair work.

### **17.4.2 Damage at Engine Mounting Lugs and Engine Mount to Fuselage Attach Fittings**

Engine mounting lugs and engine mount-to-fuselage attaching fittings should not be repaired but must be replaced.

## **17.5 Residual Torque**

After bigger repairs at rudder or flaps it is necessary to measure the residual torque. Therefore REMOS provides the static moments, weight and residual torques of all rudders and flaps.

### **Flaps (retracted):**

Weight: 2.00 - 2.40 kg (no mass balance)

Static Moment: 210 - 260 Ncm (no mass balance)

There is no mass balance mounted at the flaps. If the flaps are retracted they are driven to a stop that avoids flutter instability.

### **Aileron:**

Weight: 2.30 - 2.60 Kg (with mass balance)

Static Moment: 0 - 6 Ncm (with mass balance)

Mass balance is mounted at the outer end of the elevator. The weight of the mass balance is 0.65 kg with a lever arm of 160 mm.

### **Elevator:**

Weight: 4.30 - 4.75 Kg (with mass balance)

Static Moment: 35 - 45 Ncm (with mass balance)

Mass balance is mounted at both elevator tips. Each mass balance weights 0.45 kg with a lever arm of 165 mm.

***Rudder:***

Weight: 3.30 - 3.75 Kg (with mass balance)

Static Moment: (-10) - 10 Ncm (with mass balance)

Mass balance of 0.91 kg with a lever arm of 155 mm is mounted in the top of the rudder.

## Section 18

### *Continued Airworthiness and Inspection*

| <b>Table of Contents</b>                         | <b>Section</b> |
|--|----------------|
| 18.1 Maintenance.....                            | 2              |
| 18.1.1 Maintenance Interval.....                 | 2              |
| 18.1.2 Annual Condition Inspection .....         | 2              |
| 18.1.3 Personal .....                            | 2              |
| 18.2 Lifetime Limits .....                       | 3              |
| 18.3 Continued Airworthiness .....               | 3              |
| 18.3.1 Continued Airworthiness System .....      | 4              |
| 18.3.2 Owner/Operator Responsibilities .....     | 5              |
| 18.3.3 Release of Notices to the Public .....    | 6              |
| 18.3.4 Documentation Update .....                | 6              |
| 18.3.5 Modifications or Change of Equipment..... | 6              |
| 18.3.6 Repairs .....                             | 7              |
| 18.3.7 Contact Data .....                        | 8              |
| 18.3.8 Customer Feedback Form .....              | 9              |
| 18.3.9 Customer Commitment Form.....             | 11             |

---

## 18.1 Maintenance

Maintenance shall be performed according to the actual revision of the Service and Maintenance Checklist. This document is published on the website [www.remos.com](http://www.remos.com), which is the central means of communication of REMOS AG to its customers.

### 18.1.1 Maintenance Interval

Maintenance intervals of all REMOS aircraft are 25h for the first maintenance event, followed by 100h inspections. In case that AVGAS 100LL is used for more than 30% of the time, oil change interval is reduced to 50h.

|                   |   |
|-------------------|---|
| <b>ATTENTION!</b> | REMOS AG hereby wants to provide the information that the 100h inspection is mandatory if the aircraft is in commercial use.<br><br>REMOS AG recommends the 100h inspection for aircrafts in private use. |
|-------------------|---|

### 18.1.2 Annual Condition Inspection

Annual Condition Inspection shall be performed according to the actual revision of the Annual Condition Inspection Checklist. This document is published on the website [www.remos.com](http://www.remos.com), which is the central means of communication of REMOS AG to its customers.

### 18.1.3 Personal

REMOS AG hereby defines the following persons that may perform maintenance and repair as defined in the Maintenance Manual including 25h and 100h inspection:

- Owner/operator: with Sport Pilot Certificate or higher:  
preventative maintenance, or line maintenance.
- LSA Repairman Maintenance:  
preventative maintenance, line maintenance, or heavy maintenance.
- A&P Mechanic:  
preventative, maintenance, line maintenance, or heavy maintenance.
- Part 145 Repair Station with appropriate ratings:  
preventative maintenance, line maintenance, or heavy maintenance

REMOS AG hereby defines the following persons that may perform the annual condition inspection:

- LSA Repairman Maintenance
- A&P Mechanic
- Part 145 Repair Station with appropriate ratings

## **18.2 Lifetime Limits**

### **Airframe**

The airframe is not lifetime limited. The aircraft is operated on condition.

### **Control Systems**

The control systems are not lifetime limited. The aircraft is operated on condition.

### **Engine**

For commercial use the engines with SN lower than 4.427.532 have a TBO of 1200h or 10 Years, whatever comes first. Engines with SN between 4.427.533 and 6.775.789 have a TBO of 1,500h or 12 years, whatever comes first. Engines with SN 6.775.790 and higher have a TBO of 2,000h or 15 years, whatever comes first. Engines with SN lower than 6.775.790 may be modified according to ROTAX Service Bulletins so that a TBO of 2,000h/15yrs applies. See individual modification standard and engine documentation.

For private use the engine is operated on condition if maintained according to engine manufacturer's maintenance manual.

### **Propeller**

Neither for commercial use nor for private use a TBO is defined for the different types of propellers, inspections acc. to manual apply.

### **Safety Belts**

The safety belts are not lifetime limited. The aircraft is operated on condition.

### **Tubes and Hoses**

Tubes and hoses on REMOS aircraft are operated on condition. A fixed time interval for replacement is not defined. Nevertheless, the ROTAX maintenance manual claims for replacement every 5 years. The replacement is not mandatory on REMOS aircraft, though recommended.

### **Towing Equipment**

For commercial use the release clutch has a TBO of 4 years, or 2,000 take-offs, or 10,000 operations, whatever comes first. For private use the clutch is operated on condition if maintained according to clutch manufacturer's maintenance manual.

### **Misc. Equipment and Subsystems**

Misc. equipment and subsystems are not lifetime limited. The aircraft is operated on condition.

## **18.3 Continued Airworthiness**

Continued Airworthiness is everything that is required to keep an aircraft in a safe condition to fly. This does not only include the technical part like maintenance and annual condition inspection. It also includes update of documentation, e.g. Pilot Operating Handbook, issuing repair instructions and repair approvals, change on equipment and feedback of the customer to the manufacturer. Especially the latter one is really important as this is the only way that the manufacturer gets to know of potential issues of safety of flight.

In some areas the procedures of the continued airworthiness system of an LSA differ significantly from the ones of a standard category aircraft. This letter shall give guidance to the customer how to act correctly in the continued airworthiness system and how to keep his aircraft airworthy and legal to fly.

### **18.3.1 Continued Airworthiness System**

REMOS AG shall be informed about potential issues of safety of flight or service difficulties by means of the Customer Feedback Form attached to the maintenance manual. Keep in mind that forms are subject to change; therefore check the website [www.remos.com](http://www.remos.com) if there is a revised form available. If a customer does not inform the manufacturer by means of this form, REMOS AG also accepts any way of information as long as it contains at least following information:

- aircraft make and model
- serial number and callsign
- propeller make and model
- total time of aircraft and engine
- use of aircraft: private or commercial
- name and contact data of reporting person
- description of potential issue of safety or service difficulty

If the customer notifies REMOS AG directly, the information will be forwarded immediately to the Head of Design by means of the customer feedback form. Shall the customer opt for e-mail notification via [service@remos.com](mailto:service@remos.com) then this e-mail will immediately be forwarded to the Head of Design.

Based on the information given in the customer feedback form, the Head of Design will perform a risk assessment. In most cases, the Head of Design will contact the customer to collect more and precise information. This includes eventual cooperation with authorities, e.g. in case of an accident. A risk assessment consists of:

- cause of accident/incident by pilot error or technical background
- safety effect determination
- risk assessment evaluation
- decision of required alerting of the public
- decision of corrective action

The continued airworthiness system of REMOS AG does not only cover events that have occurred during operation of the aircraft. Service difficulties, findings during maintenance events or annual condition inspections are also covered by the continued airworthiness system. In case that service staff identifies a potential safety of flight issue or a real service/maintenance problem, a customer feedback form must be filled out and handed forward to the Head of Design.

The customer shall not be afraid of consequences like revoking licenses. This is not the intention and not the job of an aircraft manufacturer. If there is no immediate danger for other customers or the flying public, REMOS AG will never notify authorities.



### **18.3.2 Owner/Operator Responsibilities**

During handover of the aircraft the owner/operator is introduced into the continued airworthiness system of REMOS AG. The customer is informed about the following:

- The maintenance handbook provides all information that the customer needs to comply with the regulations, especially with continued airworthiness and maintenance.
- It is the owner/operator's responsibility to provide the manufacturer with current contact information. Only with current contact information the manufacturer is able to contact the customer in case service bulletins or safety alerts need to be sent out.
- In case a safety of flight issue or significant service difficulty reveals, it is the responsibility of the owner/operator to inform the manufacturer. The owner/operator shall not seek for solutions on his own and modify the aircraft in a way that is not covered by the maintenance manual.
- Shall the manufacturer release a notice of corrective action it is the responsibility of the owner/operator to comply with it. Furthermore the owner/operator has the responsibility to comply with all applicable aviation authority regulations in regard to maintaining the airworthiness of the LSA airplane.
- In case the manufacturer has released a notice of corrective action the owner complete it within the timeframe defined in the notice. If there is no timeframe defined, than the latest time to comply with it is the next annual condition inspection.
- In case the owner/operator does not comply with the maintenance manual and/or releases of corrective action, the LSA is not in compliance with the accepted ASTM consensus standards. This means that the aircraft is not airworthy and operating this aircraft is not legal. In case the responsible aviation authority (in case of the USA this is FAA) gets to know about this the owner/operator may be subject to regulatory action by the authority.

This information is provided by means of the customer commitment form, which is part of the maintenance manual. The owner/operator shall sign this form and send it to REMOS AG. On this form the owner/operator shall also provide the manufacturer with current contact data. Keep in mind that forms are subject to change; therefore check the website [www.remos.com](http://www.remos.com) if there is a revised form available.

If the aircraft is sold to another customer a new customer commitment form needs to be signed, so that REMOS AG is informed about the new owner and is provided with the latest contact data.

### **18.3.3 Release of Notices to the Public**

There are three different levels of notices to the public, each representing a different level of importance:

- **SAFETY ALERT**  
will be issued in case of an urgent safety of flight situations. Potentially an emergency safety of flight action is required in this case. Owner/operators will immediately be informed by postal mail and an immediate action is required. In addition, all safety alerts will be published on the website [www.remos.com](http://www.remos.com)
- **SERVICE BULLETIN**  
will be issued in case a corrective action, a mandatory inspection or a modification of the aircraft is required. Owner/operators must be informed by postal mail. An immediate action is not required but a future action is required or recommended. In addition, all safety alerts will be published on the website [www.remos.com](http://www.remos.com)
- **NOTIFICATION**  
will be issued in case service information is required, but owner/operators will not be informed by postal mail. The public is notified via the website [www.remos.com](http://www.remos.com) only.

### **18.3.4 Documentation Update**

Any documentation update will be released on the website [www.remos.com](http://www.remos.com). Owner/operators will not be informed by postal mail, unless such a documentation update is mandatory for safety of flight and is released by a safety alert or a service bulletin. Examples for documentation updates are new revisions of:

- Pilot Operating Handbook
- Service and Maintenance Checklist
- Annual Condition Inspection Checklist
- Type Design Datasheet

For copyright reasons a new revision of the maintenance handbook is not available on the website, but only on request as hardcopy.

### **18.3.5 Modifications or Change of Equipment**

Certified equipment is listed in the maintenance manual and the actual revision of the Type Design Datasheet (TCDS). The TCDS in its actual revision is available on request or on the website [www.remos.com](http://www.remos.com). Only listed equipment may be installed on the aircraft without notifying REMOS AG. In case equipment that is described in the maintenance manual shall be exchanged on the aircraft, it is required to:

- update equipment list
- weight and balance

Modifying the aircraft or changing equipment may be performed by any competent person. Updating the equipment list and the weight and balance report may only be performed by

- LSA Repairman Maintenance
- A&P Mechanic
- Part 145 Repair Station with appropriate ratings

Any change that is not documented may not be performed on the aircraft without having it certified by REMOS AG. Nevertheless, it is possible to do so. Notify REMOS AG prior to the intended change of the aircraft. Engineering department will then decide which kind of documentation is required and will either prepare them or will ask the customer to have this documentation prepared. Followed by this a Letter of Approval (LOA) will be prepared that needs to be signed by either an A&P Mechanic or a Part 145 Repair Station with appropriate ratings after the work is accomplished. Then this LOA will be signed by REMOS AG and handed out to the customer. This procedure will be performed by e-mail.

The extent of work cannot generally be defined; it is always an individual project. Working hours of the engineering department will be charged by the hour according to actual pricelists.

This procedure is not intended and built up for the manufacturer to make money of it. In contrary, due to running projects within engineering department it usually costs more to prepare the documentation than it is charged for. This procedure is defined in the regulations, in this case ASTM F2483.

Without having updated the equipment list and weight and balance or not having changes approved by the manufacturer that are not part of the maintenance manual, the aircraft is considered not airworthy and unsafe to fly. It is not legal to operate an aircraft without a current equipment list and weight and balance and required approvals by the manufacturer. Make sure the change of equipment is signed off in the aircraft's logbook and is entered in the aircraft's permanent record.

### **18.3.6 Repairs**

Repairs are handled similarly as change of equipment. Any repair that is performed with standard tools by replacing damaged parts may be performed by any competent person. To release the aircraft back to service the repair must be signed off by

- Owner/Operator with at least a Sport Pilot Licence
- LSA Repairman Maintenance
- A&P Mechanic
- Part 145 Repair Station with appropriate ratings

It is recommended to perform a standard maintenance event and an annual condition inspection once a repair has been performed that could affect safety of flight.

Structural repairs that are described in the maintenance manual are handled identically. In case the damage exceeds the described ones, an individual repair instruction is required. In this case notify REMOS AG by means of the customer feedback form. Engineering will then prepare individual and precise repair instructions. Repairing a composite aircraft is completely different from repairing a metal aircraft or a composite boat. Therefore only competent persons may perform the work. REMOS AG hereby defines the following persons that may perform the repair:

- LSA Repairman Maintenance with composite knowledge

- A&P Mechanic with composite knowledge
- Part 145 Repair Station with appropriate ratings

Notify REMOS AG prior to the intended repair. Engineering department will then decide which kind of repair and documentation is required and will either prepare them or will ask the customer to have this documentation prepared. Followed by this a Repair Approval (LOA) will be prepared that needs to be signed by either an A&P Mechanic or a Part 145 Repair Station with appropriate ratings after the work is accomplished. Then this Repair Approval will be signed by the Head of Design of REMOS AG and handed out to the customer. This procedure will be performed by e-mail.

The extent of work cannot generally be defined; it is always an individual project. Working hours of the engineering department will be charged by the hour according to actual pricelists.

This procedure is not intended and built up for the manufacturer to make money of it. In contrary, due to running projects within engineering department it usually costs more to prepare the documentation than it is charged for. This procedure is defined in the regulations, in this case ASTM F2483.

Without having the repair performed and approved according to the manufacturer's instruction the aircraft is considered not airworthy and unsafe to fly. It is not legal to operate an aircraft without current documentation and required approvals by the manufacturer. Make sure the repair is signed off in the aircraft's logbook and is entered in the aircraft's permanent record.

### **18.3.7 Contact Data**

The manufacturer of the REMOS aircraft and the only responsible entity for continued airworthiness is

**REMOS AG**  
Franzfelde 31  
D-17309 Pasewalk  
Tel: +49-3973-225519-0  
Fax: +49-3973-225519-99  
[service@remos.com](mailto:service@remos.com)

To have more practical access to spare parts, assistance and guidance, REMOS has several partners worldwide. These partners, as well as the aircraft dealers, act as interface towards REMOS AG. Refer to the website [www.remos.com](http://www.remos.com).

**18.3.8 Customer Feedback Form**

CFB - \_\_\_\_\_

filled out by Engineering Department  
REMOS AG

Please use this feedback form to report any safety of flight or service difficulties to REMOS aircraft. It is important for the operational safety monitoring system and will guarantee the continued airworthiness of your aircraft.

|  |                        |
|--|------------------------|
| Aircraft Make and Model  | Date                   |
| Call Sign  | Aircraft Serial Number |
| Propeller Make and Model   | Engine Serial Number   |
| TT Engine  | TT Airframe            |
| Use of Aircraft: Private, Commercial, Flight School, Special Use |                        |

|            |        |
|------------|--------|
| Name       | Phone  |
| First Name | Fax    |
| Adress     | e-mail |
| City/State | Web    |

Send either to **REMOS AG**  
Franzfelde 31  
D-17309 Pasewalk, Germany  
Tel: +49-3973-225519-0  
Fax: +49-3973-225519-99  
[service@remos.com](mailto:service@remos.com)

Before sending this form, please check on the website [www.remos.com](http://www.remos.com) if a corresponding Safety Alert, Service Bulletin or Notification has already been released.

Notes and explanation of potential issue of safety or service difficulty items found

**18.3.9 Customer Commitment Form****CCF - \_\_\_\_\_**filled out by Engineering Department  
REMOS AG

Please fill out this commitment form to confirm that you agree with the ASTM announced responsibilities for LSA aircraft owners/operators. This is mandatory to every customer to ensure a proper function of the manufacturer's operational safety monitoring system.

|                          |   |
|--------------------------|---|
| Aircraft Make and Model  | Use of Aircraft (private or commercial) |
| Call Sign                | Aircraft Serial Number                  |
| Propeller Make and Model | Engine Serial Number                    |
| TT Engine                | TT Airframe                             |

|            |        |
|------------|--------|
| Name       | Phone  |
| First Name | Fax    |
| Adress     | e-mail |
| City/State | Web    |

Send to **REMOS AG**  
Franzfelde 31  
D-17309 Pasewalk, Germany  
Tel: +49-3973-225519-0  
Fax: +49-3973-225519-99  
[service@remos.com](mailto:service@remos.com)

Before sending this form, please check on the website [www.remos.com](http://www.remos.com) if an update is available.

**Agreed Owner/Operator Responsibilities**

- The maintenance handbook provides all information that the customer needs to comply with the regulations, especially with continued airworthiness and maintenance.
- It is the owner/operator's responsibility to provide the manufacturer with current contact information. Only with current contact information the manufacturer is able to contact the customer in case service bulletins or safety alerts need to be sent out.
- In case a safety of flight issue or significant service difficulty reveals, it is the responsibility of the owner/operator to inform the manufacturer. The owner/operator shall not seek for solutions on his own and modify the aircraft in a way that is not covered by the maintenance manual.
- Shall the manufacturer release a notice of corrective action it is the responsibility of the owner/operator to comply with it. Furthermore, the owner/operator has the responsibility to comply with all applicable aviation authority regulations with regard to maintaining the airworthiness of the LSA airplane.
- In case the manufacturer has released a notice of corrective action the owner has to complete it within the timeframe defined in the notice. If there is no timeframe defined, then the latest time to comply with it is the next annual condition inspection.
- In case the owner/operator does not comply with the maintenance manual and/or releases of corrective action, the LSA is not in compliance with the accepted ASTM consensus standards. This means that the aircraft is not airworthy and operating this aircraft is not legal. In case the responsible aviation authority (in case of the USA this is FAA) gets to know about this the owner/operator may be subject to regulatory action by the authority.

**Indoctrination**

- Maintenance of an LSA may only be performed by personnel defined in the maintenance manual or in SD-006.
- Only equipment that is mentioned in the maintenance manual may be installed. According to the LSA regulations the installation of any other equipment is recognised as a major modification that needs to be approved by REMOS AG.
- Any repair that is not described in the maintenance manual is considered major according to the LSA regulations and need a repair instruction and an approval by REMOS AG.

I have read and understood the information given above. In case I sell my REMOS aircraft I will inform the future owner and have him signed a new customer commitment form.

---

city, date, name and sign of owner