

Understanding elevator integration in the ATRIUM software



Introduction

Integrating elevator control into ATRIUM allows you to manage up to **256 floors** per account. To do this, convert your main A22K to an A22K-EC, or add an A22K as a sub-controller ([see this article](#)), then convert it into an A22K-EC (see **Converting an A22K** section in this article).

Each A22K-EC adds **two cabs** and can manage up to **128 floors (64 floors per cab)**. Up to **49 A22K-ECs** can be added if more cabs are needed, but the total floors they manage cannot exceed **256**.


Each A22K-EC can have up to **eight CAA-480As** connected to it in a daisy-chain formation through the RS485 Local Bus. An A22K-EC with eight CA-A480-As controls **128 floors**.



Elevator integration requires version 4 or above of the ATRIUM software and firmware.

Wiring Overview

The daisy-chain wiring from an A22K-EC to a CAA-480A, to the next CAA-480A (if used) is shown below.



The diagram below shows the connection of the A22K-EC to a CAA-480A and the cab readers and floors that they manage. It also shows the jumper settings that can be used across all CAA-480As.

The dipswitch settings for floor addressing and the DRM connection diagram are also shown below. For more information on specific settings, consult the [CAA-480A manual](#).

8-Floor Building



READER CAB 1

(Relays on CA-A480-A)

- Relay 1 = Floor 1
- Relay 2 = Floor 2
- Relay 3 = Floor 3
- Relay 4 = Floor 4
- Relay 5 = Floor 5
- Relay 6 = Floor 6
- Relay 7 = Floor 7
- Relay 8 = Floor 8




READER CAB 2

(Relays on CA-A480-A)

- Relay 9 = Floor 1
- Relay 10 = Floor 2
- Relay 11 = Floor 3
- Relay 12 = Floor 4
- Relay 13 = Floor 5
- Relay 14 = Floor 6
- Relay 15 = Floor 7
- Relay 16 = Floor 8



CA-A480-A Relay Module (16)



JUMPER SETTINGS

- EOL = OFF
- BIAS A+ = High
- BIAS B- = High


The above jumper settings can be used on all CA-A480-As.

RS-485

To LAN/WAN

IP Port




A22 EC Elevator Controller



Reader Port Cab 1

Reader Port Cab 2

Floor Addressing




Converting an A22K into an A22K-EC

First, download the A22K-EC firmware files either by [visiting the CDVI website](#) or by getting in touch with our [Tech Support team](#).

The steps below show conversion of an A22K subcontroller. To convert a main controller, select it and continue with the steps below.


In the ATRIUM software, select the A22K from the **Sub-Controllers** menu and click on **Upload Firmware**.




Locate and open the **A22K-EC.cuf** firmware file.




The **A22K-EC.cuf** file must be loaded before the **.pck** file.




When the firmware has finished loading, click **Install**.



The A22K will go offline and **reboot**. When it synchronises, select **Module** on the **Database Mismatch** window.



Open and install the **A22K-EC.pck** firmware file using the same previous steps.



This **Sub-Controller** will now be listed as an **A22K-EC**.



Floors


Floors can be located within the same building or distributed between different buildings. The total number of Floors in the account will be listed from **1** to a maximum of **256**. If any Floors are located in other buildings, you can rename the Floors to make finding them clearer (ex. Building B - Floor 1). Once floors are added you can also find a floor by typing its name into the **Find** box.



From the **Dashboard** tab, click on **Floors**, then **Add** to open the **Floor Properties** menu and add a new floor.




Floor Properties: General Information, Public Access, and **Notes** can be modified here. Click **Save** to keep any changes.



- **Display Name:** Create a display name for the floor.
- **Enabled:** Enable (checked) or Disable (unchecked) the floor.
- **Public Access:** Select a **schedule** for the floor to specify when users have free access to the floor without requiring a Floor Level assigned to them. For more information on specific schedules, [see this article](#).
- **Notes** (tab): Click anywhere inside the box to add notes.

Cabs


From the **Dashboard** tab, click on **Cabs**, then select a cab and click on **Properties** to open the **Cab Properties** menu. Each A22K-EC adds **two elevator cabs**.



Enable	Display Name:	ID	Module Serial #
<input checked="" type="checkbox"/>	A2-20-01-54: Elevator 01	1	A2-20-01-54
<input checked="" type="checkbox"/>	A2-20-01-54: Elevator 02	2	A2-20-01-54

Cab Properties: General

Information, Options, Notes and **Buttons** can be modified here. Click **Save** to keep any changes.



Cab Properties

General Information

Display Name: A2-20-01-54: Elevator 01

Enable

Options

Destination Reporting Module

Card ... and PIN

Keypad code

Reader: Reader 01 (A2-20-01-54)

Button Activation Time (Seconds): 5

Area:

Buttons

Delete Add Properties

Enable	Display Name:	Floor	Relay	Input
--------	---------------	-------	-------	-------

Save Cancel

- **Display Name:** Rename the floor cab.
- **Enable:** Enable (checked) or Disable (unchecked) the cab.
- **Destination Reporting Module:** Enable (checked) or Disable (unchecked) an optional CAA-482P Destination Reporting Module, also known as a DRM.



Without a DRM, when a **User** presents their card at the cab reader for access, every floor the user has access to is enabled for the default activation time of **5 seconds**. The controller will register the **Access Granted** event but will not know which floor(s) the User accessed.

With a DRM, the controller registers which User accessed the elevator and which floor was accessed. Destination Reporting only allows **one floor selection** to be made per presentation of the card.


- **Card, PIN and Keypad Code:** If **Card** or **Keypad Code** are checked off, the User can have access granted using either option. If **...and PIN** is selected, the User will need to present a card and put in a PIN (also known as a keypad code).
- **Reader:** Select a different cab reader here if needed.
- **Button Activation Time:** Modify the elevator button activation time from **1 to 254 seconds**.
- **Area:** Set the **Area** associated to the cab reader.
- **Notes** (tab): Click anywhere inside the box to add notes.

Buttons

Click on the **Buttons** tab then **Add** to enter the **Button Properties** menu.



Create a name then select the **Floor**, **Relay**, and (optional) **DRM Input** for this elevator button. Click anywhere inside the **Notes** box to add a note. Click **OK** to save.



The **Relay** and **DRM Input** names will match up if they are wired in order. (Ex. Relay E01:F01 will correspond with DRM Input E01:F01.)

Floor Levels

Floor Levels function like **Access Levels** ([see this article for more information](#)) except that they apply to an entire floor instead of applying to an **Area**. From the **Dashboard** tab, click on **Floor Levels** to view them.


The screenshot shows a software interface with a top navigation bar containing 'Dashboard', 'Hardware', 'Advanced Configuration', and 'Accounts'. Below this is a toolbar with various icons for 'Users', 'Cards', 'Holidays', 'Schedules', 'Areas', 'Access Levels', 'Access Level Groups', 'Doors', 'Relays', 'Inputs', 'Outputs', 'Cabs', 'Floors', 'Floor Levels', and 'Events'. The 'Floor Levels' icon is highlighted with a red box. Below the toolbar, the 'Floor Levels' section is active, showing buttons for 'Add', 'Properties', 'Delete', and a 'Find' search box. The 'Add' button is also highlighted with a red box. Below the buttons is a table with three rows:

Enable	Display Name	ID
<input checked="" type="checkbox"/>	Floor Level None	1
<input checked="" type="checkbox"/>	Floor Level All	2
<input checked="" type="checkbox"/>	Floor Level Programming	3


There are three default Floor Levels:

- **Floor Level None:** This floor level has **Schedule Never**, so there is no access to any floors assigned to it. This can be modified.
- **Floor Level All:** This floor level has **Schedule Always**, so there is access to every floor assigned to it 24 hours a day, 365 days per year including any programmed **Holidays**. This can be modified.
- **Access Level Programming:** This floor level has the **Learning Mode** schedule, so there is access to every floor assigned to it 24 hours a day, 365 days per year including any programmed **Holidays**. This can be modified.

Click on **Add** to enter the **Floor Level Properties** menu.




- **Display Name:** Create a display name for the floor level.
- **Enabled:** Enable (checked) or disable (unchecked) the floor level.
- **Schedule:** Select a schedule for the floor level to specify when users have access to floors.
- **Floors:** Assign or add floors to specify which floors this floor level has access to. Click **OK** after each selection.



- **Notes** (tab): Click anywhere inside the box to add notes.

Click **Save** to keep your changes.

You can now **Assign** or **Add** Floor Levels to a **User** from the **User Properties** menu ([see this article for more information](#)).





Next, understand the **lockdown function in ATRIUM** and how to use it.



This article applies to the following products:

A22K
A22KPOE
CAA-480A