eTOURNAMENT FISHING
Next Level Events

CHECKLIST TOURNAMENT DAY

Update, check permissions, test in the practice event, then check in with good service.

ONE SIMPLE CHECKLIST FOR EVERY PHONE

- ☐ **Accept ALL permissions when the app or phone asks.** ET needs **Always location, Precise Location, camera and microphone**. The microphone is needed for the release video.
- ☐ **Follow the permission warning.** If a permission is missing, ET flashes a warning telling you to give permissions. Follow it before fishing.
- ☐ **Update before the event.** Update your phone and the ET app ahead of tournament day.
- ☐ **Try the practice event.** Run test submissions so you know what to expect.
- ☐ **Check in with good service.** This lets ET switch to offline mode automatically when coverage is poor.
- ☐ **Charge fully and bring a power bank.** Protect your phone from heat and cold.
- ☐ **Make room for your catches.** Check that your phone has plenty of free space. Delete old videos you don't need—not pending tournament photos or videos.

AFTER YOU SUBMIT: LEAVE ET OPEN

Don't swipe it closed. Let the screen time out on its own. Wake it and refresh periodically. Check that your catch moves from **Being Uploaded** to **Pending Review**.

eTOURNAMENT FISHING
Next Level Events

HOW YOUR PHONE WORKS ON TOURNAMENT DAY

Signal · Permissions · Storage · Battery

PRINT ME · KEEP ME IN THE BOAT

DON'T PUT YOUR PHONE IN AIRPLANE MODE.
Airplane mode cuts off the cellular data ET needs to send your catches.

Your phone, your carrier and eTournament Fishing work together. Weak service, a full phone or a battery-saving setting can interrupt that teamwork. These checks help you get back to fishing. If they don't help, your director and ET support are here for you.

WHAT HAPPENS WHEN SIGNAL IS WEAK?

1 · DELAYED
Photos and video need a working internet connection—not just signal bars.

→

2 · WORK CAN PAUSE
A connection can time out. Background and battery-saving rules can delay or stop work.

Moving between towers, bands or 5G/LTE can change speeds or briefly disrupt a connection. A busy tower can be slow even with strong bars. A working call or text does **not** prove there is enough data service for a video upload.

"BEING UPLOADED"? REFRESH.

1. **LEAVE ET OPEN.** Don't swipe it closed or force-stop it. Let the screen time out on its own.
2. **REFRESH PERIODICALLY.** Tap **refresh (top right)**, **pull down to refresh**, or tap the **green virtual livewell button**. Paused submissions pick back up.
3. **CHECK YOUR STATUS.** In your virtual livewell, **red under "Being Uploaded"** means still sending. When finished, it moves to **"Pending Review" with a green tint**—it made it. Wake the screen and refresh to check.

REFRESH IS NOT STRONGER SERVICE
Refresh can resume the upload process, but it cannot create coverage or remove a carrier speed limit. Give the connection time; don't tap continuously.

OFFLINE IS NOT LOST

Check in while you have good service. If you checked in, ET turns on offline mode automatically when coverage is poor.

Submissions save on your phone and upload once you're back in coverage. Keep ET open, refresh periodically and check that uploads finish.

Still stuck? Contact your director. Directors can enter a catch for you when technical issues arise. Follow their instructions.

STORAGE, CARRIER & POWER
Near-full storage can stop ET—keep **plenty of free phone space** for photo + release video (cloud ≠ phone). Don't delete ET or clear its data; ask support first. **Check your plan** for upload speeds, high-speed data and roaming. **Canada / border waters:** confirm coverage and fees before travel. **Wi-Fi Calling** does not boost ET uploads. Shade in heat; protect in cold. Large backups share the connection. **GPS needs sky, not cell bars. Final check:** iPhone XR+ / iOS 17.4+, or Android 12+ (most devices).

eTOURNAMENT FISHING
Next Level Events

YOU SAW THIS → CHECK THIS → FIX

These are common **possible causes**, not a diagnosis. App or server issues can happen too. If the checks don't resolve it, tell support what happened and what you tried.

YOU SAW THIS	WHAT THE PHONE / NETWORK MAY HAVE DONE	WHAT TO DO
Upload stalled	Weak data, a timeout or background limits paused the work.	Leave ET open. Use any of the three refresh methods on page 2. Refresh and check the livewell: red "Being Uploaded" is still sending; green-tinted "Pending Review" means it made it. Try better coverage when safe.
"I have bars, but it's slow"	The tower is congested, your plan is speed-limited, or the phone is reconnecting.	Check your data allowance. Pause other transfers. Try a known working network. Bars are not an upload-speed test.
App closed itself	The OS may have ended it to reclaim memory; a crash or phone restart is also possible.	Reopen ET and check the livewell. Note any error. If it repeats, contact support—don't assume the catch uploaded.
Won't save or submit	Storage may be too full to save the photo and release video.	Check free storage (page 2). Free unrelated files safely. Also check permissions and Angler role. Capture must happen during tournament hours; uploading can finish later.
Location is wrong	Approximate permission, blocked satellite view or reflected GPS signals reduced accuracy.	Accept the location permission when asked (**Always + Precise**). Safely seek an open sky view and allow time for a fix. Tell your director if the position remains wrong.
Photo is blurry / fogged	Water, condensation, a dirty lens, movement or a pouch/case obstructed the camera.	Dry and clean the lens with a soft microfiber cloth. Check the pouch window; keep the phone dry and steady. Check the image before continuing.
Camera / video won't work	Permission denied, a privacy switch is off, storage is full or the phone is too hot.	Accept camera/microphone permissions when asked; follow ET's warning. Check free space and temperature. Use ET's in-app camera and confirm the recording timer runs.
App or phone is slow	Network delay, low storage, heat or aging hardware may be involved.	Check those first. ET's guide recommends restarting a laggy phone, then logging back in. Don't interrupt an active capture; ask for help if uploads are pending.
Phone died / screen went dark	Battery depletion, cold or heat protection may have shut it down; a screen timeout alone is normal.	Check power and temperature. Charge when safe and within the phone's temperature limits. Reopen ET and check submission status.
Missed a message	Loss of service may have delayed it, or the phone may not have alerted you.	Accept notification permission when asked. Check ET and your director's instructions directly when service returns.

Protect unuploaded catches: don't delete or reinstall ET, clear its app storage/data, or delete tournament media to troubleshoot. Ask support first.

NEED HELP?

Contact your director first on tournament day.

Call or text support: 720-507-4099

Email: support@etournamentfishing.com

HOW-TO GUIDE
etournamentfishing.com/how-to-instructions-1

CONTACT US
etournamentfishing.com/contact-us