SUNBEAM



VOLTMETER — SUNBEAM

Part No. ABV2220-26C

Type: 12 Volt Electric
Range: 11-17 Volts
Scale: Arc
Dia: 52mm
Bezel: Chrome 1/2 "V"
Incandescent Lighting
Obsolete - replaced by ABV2220-26CB

Fitting Instructions



VOLTMETER — SUNBEAM

Part No. ABV2220-26CB

Type: Stepping Motor Electric
Range: 11-17 Volts
Scale: Arc
Dia: 52mm
Bezel: Chrome 1/2 "V"
LED Lighting
Replaces ABV2220-26C

Fitting Instructions



Representative Image

VOLTMETER — SUNBEAM

Part No. ABV2220-27C

Type: 12 Volt Electric
Range: 11-17 Volts
Scale: Arc
Dia: 52mm
Bezel: Chrome Full "V"
Incandescent Lighting
Obsolete - replaced by ABV2220-27CB

Fitting Instructions



VOLTMETER — SUNBEAM

Part No. ABV2220-27CB

Type: Stepping Motor Electric
Range: 11-17 Volts
Scale: Arc
Dia: 52mm
Bezel: Chrome 1/2 "V"
LED Lighting
Replaces ABV2220-27C

Fitting Instructions



Representative Image

CLOCK — SUNBEAM

Part No. CTE3107-04C

Type: 12 Volt Electric
Scale: Full
Dia: 60mm
Bezel: Chrome Full "V"
Incandescent Lighting

Fitting Instructions



FUEL GAUGE — SUNBEAM

Part No. BF2242-06C

Type: Bimetal Electric
Range: E-1/2-F
Scale: Arc
Dia: 52mm
Bezel: Chrome Full "V"
Incandescent Lighting
Use 6 hole Sender TB9011KIT Top Mount or TB9013KIT Side mount. 5 Hole TA9030-000 Top Mount

Fitting Instructions



OIL PRESSURE — SUNBEAM

Part No. PL2303-05

Type: Mechanical
Range: 0-100 PSI/7kgcm2
Scale: Arc
Dia: 52mm
Bezel: Chrome Full "V"
Incandescent Lighting
Does not include LK-2 or HF22000-00-084 oil line kit

Fitting Instructions



SPEEDOMETER — SUNBEAM

Part No. SN5321-14

Type: Mechanical
Range: 0-225 kmh
Scale: Full
Dia: 100mm
Bezel: Chrome Full "V"
Incandescent Lighting

Fitting Instructions



TACHOMETER — SUNBEAM

Part No. RVI2812-03CB

Type: Stepping Motor Electric
Range: 0-7000 RPM
Scale: Full
Dia: 100mm
Bezel: Chrome Full "V"
Incandescent Lighting

Fitting Instructions



WATER TEMPERATURE — SUNBEAM

Part No. BT2201-02

Type: Bimetal Electric
Range: 30-110°C
Scale: Arc
Dia: 52mm
Bezel: Chrome Full "V"
Incandescent Lighting
Use sender TT4201-00A

Fitting Instructions

