

Continue

Ozark trail 10 person tent manual

W843.2 - 10 PERSON MODIFIED DOME TENT W/ SCREEN PORCHABCDESCRIPTION PART NO.QTYREQKEYNO.Main PoleSide PoleScreen Porch PoleComplete FrameReplacement FlyGuy RopeSteel StakeW843.2MW843.2SW843.2PW843.2STW843.2FA1001PIN STAKE22111823AABBCASSEMBLY INSTRUCTIONSCAREREPLACEMENT PARTSDO NOT LEAVE YOUR TENT SET UP IN DIRECT SUNLIGHT LONGER THAN NECESSARY. THE SUN'S ULTRAVIOLET (UV) LIGHT DEGRADES ALMOST EVERY FABRIC AND MATERIAL. IF LEFT IN SUNLIGHT FOR PROLONGED PERIODS OF TIME, FABRIC WILL FADE AND WEAKEN. DO NOT STORE TENT ON CONCRETE FLOOR. DO NOT SPRAY THE TENT WITH INSECTICIDE.Your tent is water repellent, however, it is not waterproof. During heavy rain, some leakage may occur. Keep objects from touching the inside of the tent. Such objects may cause leakage at point of contact. If seam leakage occurs, it can be controlled by applying a seam sealer compound.EXERCISE CARE WHEN USING ELECTRIC DEVICES IN AND NEAR TENTS. Although our tents and screen houses are constructed to rigid specifications, periods of wind or rain soaking the ground may loosen the stakes and cause the uprights to sink into the ground. This will weaken the rigidity of the overall structure. Water pockets may also form in the roof if the unit is not assembled taut, possibly causing broken frames and torn fabric.If you have questions or need to order a part, call 1-800-325-4121 or send an email to contactus@wenzelco.com. Have your model number or part number ready when you call. DO NOT ORDER BY REFERENCE KEY NUMBER.Send your request for parts to:Exxel Outdoors, LLC.1 International Ct.Broomfield, CO 80021SAFETY WARNING - DOs AND DO NOTsEVERYONE WHO USES THIS TENT SHOULD READ THIS MANUAL AND BECOME FAMILIAR WITH ALL SAFETY WARNINGS AND PRECAUTIONS FOR SAFE USE, ASSEMBLY, CARE, MAINTENANCE, AND STORAGE. KEEP THIS MANUAL SO YOU CAN REFER TO IT LATER. CARBON MONOXIDE GAS WILL KILL YOUStoves, heaters, grills, lantern, candles, and other fuel-burning devices that burn propane, natural gas, charcoal, kerosene, coal, or other fuels produce a toxic gas called carbon monoxide. Because carbon monoxide gas is invisible, odorless, and colorless, a dangerous level of carbon monoxide gas can accumulate in a tent which cannot be detected by sight, smell, or taste. For these reasons: • DO NOT use matches, lighters, stoves, heaters, grills, lanterns, candles, cooking equipment, or other fuel-burning devices inside or near a tent. • DO NOT build fires inside or near a tent. • DO NOT leave campfires unattended.Your failure to follow this warning will cause death, serious injury, or permanent disability to you or others. viva questions on conductometric titration PROTECT YOUR CHILDREN • DO NOT leave children unattended inside a tent or in camp. • DO NOT allow children to assemble a tent.

• DO NOT allow children to enter or exit a tent except through the door. • DO NOT allow children to remain in a closed-up tent on hot days.Your failure to follow this warning will cause death, serious injury, or permanent disability to your children. FLAMMABILITY WARNING KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC This tent is made with flame resistant fabric which meets CPAI-84 specification.

IT IS NOT FIREPROOF. The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.Your failure to follow this warning will cause death, serious injury, or permanent disability to you or others.CAMPING DO'S AND DON'TS DO NOT... 1. Do not pitch tent near open fire. 2. Do not leave campfire unattended. 3. Do not leave children unattended inside a tent.

4. Do not use heating, lighting or cooking equipment with open flames in or near tents. 5. Do not use other than recommended water repellent compounds on your tent. 6. Do not spray the tent with insecticide. 7. android_one_hand_mode_huawei.pdf Do not store tent on concrete floor. DO... 1.

Always extinguish campfire before leaving area. 2. Exercise care when using electricity and lighting in and near tents. 3. Make certain your tent is properly ventilated in all weather conditions. In extreme weather conditions, snow could obstruct airflow and cause asphyxiation unless cleared frequently. 4. Anchor your tent securely to provide additional security from changing climatic conditions. Snow pegs, skis and/or heavy rocks may be necessary to supplement tent stakes and guy cords.

5. Take your tent down and store properly after camping.DANGERDANGERWARNINGMODEL W843.2 - 10 PERSON MODIFIED DOME TENT W/ SCREEN PORCH ASSEMBLY INSTRUCTIONSMODEL WMT922.2B 10-Person 20' x 11' TentCAREREPLACEMENT PARTSDO NOT LEAVE YOUR TENT SET UP IN DIRECT SUNLIGHT LONGER THAN NECESSARY. THE SUN'S ULTRAVIO-LET (UV) LIGHT DEGRADES ALMOST EVERY FABRIC AND MATERIAL.

IF LEFT IN SUNLIGHT FOR PROLONGED PERIODS OF TIME, FABRIC WILL FADE AND WEAKEN. DO NOT STORE TENT ON CONCRETE FLOOR. DO NOT SPRAY THE TENT WITH INSECTICIDE.Your tent is water repellent, however, it is not waterproof. razegoramomagogaxa.pdf During heavy rain, some leakage may occur. Keep objects from touching the inside of the tent. Such objects may cause leakage at point of contact. If seam leakage occurs, it can be controlled by applying a seam sealer compound.EXERCISE CARE WHEN USING ELECTRIC DEVICES IN AND NEAR TENTS.Although our tents and screen houses are constructed to rigid specifications, periods of wind or rain soaking the ground may loosen the stakes and cause the uprights to sink into the ground. This will weaken the rigidity of the overall structure. Water pockets may also form in the roof if the unit is not assembled taut, possibly causing broken frames and torn fabric.SAFETY WARNING - DOs AND DO NOTsEVERYONE WHO USES THIS TENT SHOULD READ THIS MANUAL AND BECOME FAMILIAR WITH ALL SAFETY WARNINGS AND PRECAUTIONS FOR SAFE USE, ASSEMBLY, CARE, MAINTENANCE, AND STORAGE. KEEP THIS MANUAL SO YOU CAN REFER TO IT LATER. CARBON MONOXIDE GAS WILL KILL YOUStoves, heaters, grills, lantern, candles, and other fuel-burning devices that burn propane, natural gas, charcoal, kerosene, coal, or other fuels produce a toxic gas called carbon monoxide. Because carbon monoxide gas is invisible, odorless, and colorless, a dangerous level of carbon monoxide gas can accumulate in a tent which cannot be detected by sight, smell, or taste. For these reasons: • DO NOT use matches, lighters, stoves, heaters, grills, lanterns, candles, cooking equipment, or other fuel-burning devices inside or near a tent. • DO NOT build fires inside or near a tent. • DO NOT leave campfires unattended.Your failure to follow this warning will cause death, serious injury, or permanent disability to you or others. PROTECT YOUR CHILDREN • DO NOT leave children unattended inside a tent or in camp. • DO NOT allow children to assemble a tent. • DO NOT allow children to enter or exit a tent except through the door.

• DO NOT allow children to remain in a closed-up tent on hot days.Your failure to follow this warning will cause death, serious injury, or permanent disability to your children. FLAMMABILITY WARNING KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC This tent is made with flame resistant fabric which meets CPAI-84 specification. IT IS NOT FIREPROOF. The fabric will burn if left in continuous contact with any flame source. young and freedman university physics answers The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.Your failure to follow this warning could cause death, serious injury, or permanent disability to you or others.CAMPING DO'S AND DON'TS DO NOT... 1. Do not pitch tent near open fire. 2.

Do not leave campfire unattended. 3. Do not leave children unattended inside a tent. 4. Do not use heating, lighting or cooking equipment with open flames in or near tents. 5. Do not use other than recommended water repellent compounds on your tent. 6. Do not spray the tent with insecticide. 7. Do not store tent on concrete floor. fisher paykel refrigerator repair manual DO... 1. Always extinguish campfire before leaving area. 2.

Exercise care when using electricity and lighting in and near tents. android tv box banja luka 3. Make certain your tent is properly ventilated in all weather conditions. In extreme weather conditions, snow could obstruct airflow and cause asphyxiation unless cleared frequently. 4. Anchor your tent securely to provide additional security from changing climatic conditions. Snow pegs, skis and/or heavy rocks may be necessary to supplement tent stakes and guy cords. 5. the wicked king pdf read Take your tent down and store properly after camping.DANGERDANGERWARNINGB - Fiberglass Side Room PoleA - Fiberglass Tent PoleD - Steel Tent PoleE - Steel Canopy PoleC - Plastic Corner JointBDDIf you have questions or need to order a part, call 1-800-325-4121 or send an email to contactus@wenzelco.com. Have your model number or part number ready when you call. DO NOT ORDER BY REFERENCE KEY NUMBER.Send your request for parts to:Exxel Outdoors, LLC.1 International Ct.Broomfield, CO 80021KEYNO.QTYREQ244211610182PART NO.MODEL NO. WMT922.2B 10-Person 20' x 11' TentDESCRIPTIONABCDEFiberglass Tent PoleFiberglass Side Room PolePlastic Corner JointSteel Tent PoleSteel Canopy PoleComplete FrameReplacement FlyGuy RopePin StakesPlastic Stakes050033040053CM15-47080012080013WMT922.1FRWMT922.2BFLA10017.25 STAKEPINSTAKE