

# Window Film Application Instructions

## Premium Range – Static Film ONLY

### Please read instructions fully before installation.

Most residential window films are applied directly to the inside glass surface.

Apply the film anytime other than in direct sunlight but the temperature should be between 15°C (59°F) and 25°C (77°F). In cold temperature, the strength of Pressure Sensitive Adhesive (PSA) may be weakened.

### TOOLS NEEDED:

- Squeegee or a Credit Card wrapped with a layer of lint-free cloth (new).
- Break-away utility knife for cutting film
- Tape measure or ruler and a pen
- Lint-free cloth.
- A spray bottle of clean water

Large windows are best filmed by two people working together to remove the liner, install, and trim the film.



1. Clean the windows thoroughly with water. Make the surface dry and free of dust and dirt. Even though the window looks clean, it is not in fact in most cases.
2. Measure the dimensions of your window carefully before unrolling and cutting the film
3. Cut the film oversize by at least 2 cm on all sides. This will then allow you to apply the film to the glass and trim down as required on all sides. When trimming the film on all sides, use a straight rule and a sharp blade. Also allow a small gap (up to 1 mm) between the film edge and the window frame. This will give you a neater cut and the gap will not be noticeable.
4. Spray a generous amount of clean water on the glass



5. Slowly **remove the backing/liner off the film** using your finger nails at a corner to peel the paper/liner from the film. Be careful not to allow the static film to fold onto itself. You might require an assistant to hold the film while you peel off the backing/liner.



**Remember to remove the backing liner from the film.**

6. Apply the film to the glass.

Clear plastic backing



Film

7. Before squeegeeing out the water and bubbles with a Credit Card or alike, try to smooth the film out as much as possible with your hand as this will minimise the risk of damaging to the film. Also spray a mist of water on film before squeegee.
8. Slowly squeegee over the film surface from centre to the edges with the squeegee/Credit Card to remove any air/water bubbles completely between the film and the glass. Do this slowly and repeat it a few times until all the water has been squeezed out.

9.

Squeegee at an angle.



10. Trim the film as described in Point 3. Continue to squeegee until there are no more bubbles and all water has been removed



**NOTE:** As this is static film, it can be removed and re-applied as required. The drying process for the moisture between the film and glass may take up to 2 to 4 weeks.