

## **Installation Instructions**

**NOTE: FOR USE WITH HARLEY-DAVIDSON AND INDIAN MOTORCYCLES  
METRIC, ISO & H-D TAPERED BOARD INSTRUCTIONS INCLUDED WITH PART**

For safety, always wear boots. If shoes are worn, tuck in shoe strings.

NOTE: Some of the following pictures show the footboard removed from the motorcycle. However, it is not necessary to completely remove the footboard to perform the installation.

### INSTALLATION

#### Tools

- Drill and 1/4" bit
- 5/32 Hex Key (included)
- 7/16" Wrench
- Needle Nose Pliers

1. Use needle nose pliers to loosen footboard cover and rotate forward out of the way.



2. Using the **HEEL GUARD** as a template, place in rear corner of metal base plate. Be careful to align the rod with the inside edge of the base plate. Mark the holes first.



3. Drill 1/4" holes.



4. Use the enclosed bolts and locking nuts to secure the **HEEL GUARD**.



3. Reinstall the footboard cover.

