

Hotshot Steering Upgrade

Due to the difficulties in sourcing the long discontinued Team Associated bellcrank, we have devised our own to be included at no charge. It is a very simple yet effective setup. To assemble this you will need (2) 1/4x3/8 flanged bearings. The easiest way to search these is by their industry part number FR168ZZ. We like Avid or Fast Eddy for inexpensive bearings.

Assemble as shown. Do NOT overtighten the flanged post. Doing so will cause the plastic to expand and the bearings will fit too tightly. Note that the colors of the parts have changed but the assembly remains the same.



Parts laid out in order



Note bearing flange oriented up



Second bearing pressed into crank



crank installed onto post. Second flange up also