

# Powder Measure QD Tab

## For Dillon Powder Measures †

(Item #T1720)

### Installation Instructions

- 1) Remove both Collar Clamp Screws (#14037) and remove Collar Clamp (#13939).
- 2) Remove the Nylock nuts from the screws of the Powder Measure QD Tab, then position QD Tab in place of the Collar Clamp. The QD Tab should be oriented with the logo on top and the finger grip hook on the bottom.
- 3) Thread the screws into the Powder Measure Body Collar (#21275). Using a 5/32" hex wrench, continue turning the screws until the top of the screw heads are just flush with the top of the holes in the QD Tab.
- 4) Thread the Nylock nuts onto the ends of the screws. Use the 5/32" hex wrench to prevent the screws from turning while using a 3/8" wrench to tighten the nuts.

### Using the Powder Measure QD Tab

- 1) To remove the Powder Measure, hold the Powder Measure with your left hand and with your right hand pull the QD Tab out firmly and then lift the powder measure off of the Powder Die. You will need to pull the QD Tab outward approximately 3/16" to disengage it from the powder die.

NOTE: Refer to the Instruction Manual for your press to find the location of parts referenced above.

QD = Quick Disconnect

† Fits Dillon Powder Measures for 550, 650, 750, 900, 1050 and 1100 presses.  
Will NOT fit the Square Deal B (SDB) Powder Measure.