



Mailbox arrives unpainted with a frosted white, extreme detail finish only.

Finish Instructions:

1. Spray the whole mailbox with a royal blue plastic paint. I use Rustoleum 2x ultra cover.
2. After paint dries, paint the base with a concrete colored acrylic paint and small brush..
3. Print this file page on glossy photo paper.
4. Cut out the number of emblems you need and simply glue them to each side of the box using a white, clear drying glue. I use Elmer's white glue with a mini Q-Tip. All of the emblems are the same and sized to fit an HO scale 1:87 mailbox