

# Instructions for attaching the Add-a-Room

- Awning - Zip or Velcro (whichever model you have) on the awning & set up with the poles & ropes. *(For easier setup - Lower, the awning poles to a comfortable working height). Remove room from the storage bag making sure the folded panels are on the outside nearest to you & attach the room as instructed below.*

[OBJ]

*(Room is folded in one panel for easy set-up & dismantling)*

- Facing the tent - lift each grommet of the awning, place the room grommet on the pole, then replace the awning grommet (the awning grommet should be on top) - slip the support rope back over the pole end.
- Repeat this process for the other 2 grommets remaining on the awning & room.
- Press together the awning and the room velcro.
- Raise the 3 poles up to desired height.
- Detach each side panel that is attached to the velcro on the outside front panel & wrap around the outside of each side pole.
- Attach to the outer edge to the drip-rail on the tent *(There will be an 8" gap where the room drops down to join the skirt)*
- Press the awning and the room velcro together along the walls of room.
- Repeat for the other side of the room.
- The snaps are reference points only to assist in placement of the 'skirt' and "walls of the room".
- The 'skirt' attaches to the velcro on underside of the tent, over the wheel well, to fully enclose the room.
- The sides of the room can be rolled back and tied open at the poles for more freedom, the center can also be rolled up & tied.
- A piece of astro turf always adds a nice touch to the inside of your room.
- To close down your room simply reverse the process by placing the side panels across the front the way it originally was. Place room & skirt back into the storage bag.



**Remember – you do not need to remove the awning when closing down the tent - simply flip it back across the roof and secure to the stainless steel canopy arms at each end of the awning.**

---