

Installing the AC Kit on the Excel II Tent Trailer

You will need:

- 2 Mounting Brackets
- 8 Self Tapping Screws-Provided
- Drill with Phillips Bit
- Tape Measure

****Remove Front Pod before Installing AC Kit Bracket Assembly****



To Install the Mounting Plates:

- Measure 7 ½” inches from the edge of the drawbar to the left.
- Hold the Mounting bracket against the trailer frame, flush with the bottom.
- Use a drill and 4 Self tapping screws to fasten the Mounting Bracket to the trailer frame
- Repeat steps to fasten Mounting Plate on the Right.



To Setup the AC Kit:

- Place the poles in the mounting brackets.
- Slide the top plate onto the poles and gently tighten the set screws to secure the top plate.
- Place your Air Conditioner onto plate and Secure the “sock” to the AC unit using the Velcro closures. Attach “sock” to the Velcro on the front window.
- Roll up the front window fabric and secure with the Velcro loops inside the tent.



Tips:

- Double sided tape can assist in holding the mounting plate to the trailer frame while fastening the self tapping screws.
- Extra holes can be drilled in the top plate to provide an anchor point for a bungee cord to secure the AC if required.
- The AC kits can be dismantled and stored in the front pod, aluminum box, or inside the trailer for transport.
- AC kit must be dismantled and stowed while in transit.