

Pinch Bead Installation:

Remove all old bead (of what's left).

Start at the top edge of the lid (which is the floor for this installation).



It will be tough to start but it is SUPPOSED to be tight (friction fit).

Use a rubber mallet to install inch by inch fit the pinch bead on.



NOTE: Do not try to measure ahead and cut to size. Work your way around the entire lid to the other end...then cut to EXACT size. Again this is a **friction fit** and simple patience is required to gently force the bead into place in one piece