

The Active Charged Dampening Attachment Installation Guide

1. Ensure all pressure is off cylinder rods.
2. Removed female end of hydraulic hose that is attached to the adapter on the rod end of cylinder.
3. Screw T end of AJ Adapter kit onto the existing adapter, connecting loosely.



4. Reconnect original hydraulic hose to the open end of the T fitting, connect loosely.
5. Route hose along cylinder toward center of tractor. Tie band as shown.



6. Repeat on each side.
7. The “Y” of the AJ Adapter kit should be centered on the tractor. Tie band as needed.
8. Route the supply hose from the center of tractor to hose clamp on the left side of tractor by removing the grease hose and inserting the supply hose in hose clamp.
9. Route grease hose as before using tie bands to clamp to new hose rather than thru hose clamp.
10. Route supply hose with original hydraulic hose and tie band every 18 inches.
11. Plug supply hose into the Diagnostic receptacle (“P” Port) on top of SCV stack.
12. Tighten all fittings to ensure no leakage of hydraulic fluid.
13. Assure clearance with tractor frame before operating.

