



STEP 1 -
CENTER PUNCH 2 MOUNTING HOLES AS MARKED.

STEP 2 -
CENTER PUNCH CENTER OF 2.25" HOLE

STEP 3 -
DRILL 2 MOUNTING HOLES WITH A 13/64" DRILL BIT.

STEP 4 -
DRILL A 1/8" HOLE IN THE CENTER (TO BE USED FOR CENTERING HOLE SAW)

STEP 5 -
USE A 2.25" HOLE SAW AND CENTER IT ON THE 1/8" HOLE IN MIDDLE

STEP 6 -
USE SUPPLIED HARDWARE AND MOUNT PLATE TO FIREWALL.

DUAL DATA & CHARGING PORT USB BULKHEAD