

*Hanging instructions for standard plaques with a keyhole hanger or metal keyhole hanger.*

*Drill holes in the mounting surface with or without using a wall anchor.*

*Use the appropriate length and type of screw and the appropriate wall anchor (not included).*

*Spread silicone, epoxy or quickset cement adhesive onto the back of the plaque — careful not to put too much or get too close to edges, or it will sep out at the edges.*

*Carefully hang the plaque on the screw. Level the plaque and press firmly into place.*

*Re-check the plaque for level and adjust as necessary.*

*Allow the adhesive to cure, usually 30 - 60 minutes.*

