


### Step 1:


- Install must be done by professional mechanic, let exhaust cool, Remove power plug and 3, 8mm nuts.



- Remove motor and spring, set aside for later, if spring falls off look at the photo on page 3 to see how it should look when reinstalled.

### Step 2:

- Make sure AEV is at 2 o'clock full open.



### Step 3:

- Install MFER-1 or the MFER-1-EXTREME put on 3, 8mm locknuts, must use blue thread locker on all studs and set screws , Tighten but not over tight.
  - DON'T USE RED THREAD LOCKER.