



MFER-1



MFER-1-EXTREME

Step 4:

- No lock washers used. Next Install 3, 8mm standoff nuts, tighten but not over tight. Now install 3 set screws with 2.5mm allen wrench.



Next install 3 small flat washers, then 3 serrated washers with lines facing out.