

- Next install motor and spring, make sure spring is hooked to back of motor and positioned like the photo below, if not hook up power to motor for 5 seconds and remove power repeat till spring position matches close to photo can take a couple power cycles 2-5 to match. Slide over 3 set screws, hold motor against MFER-1 or MFER-1-EXTREME with one hand, tighten 3, 8mm nuts with other hand, now tighten with wrench.
- Check and make sure all bolts are tight, Now hook up power on that motor and repeat the same steps on other side.  
PLEASE CHECK YOUR WORK, make sure springs are on right.

