

SKID PLATE INSTALLATION INSTRUCTIONS

The safety and functionality of your product depends on its correct installation. Please follow these instructions carefully, as 6 Monkeys LLC is not liable for any damages or injuries, including death, as a result of faulty installation. Please install this product according to these instructions and use this product as intended. Technicians are advised to contact us with any questions prior to installation.

1. Only install this product on 2011 - 2021 Jeep Grand Cherokee models.

DO NOT INSTALL THIS PRODUCT ON A DIFFERENT MODEL VEHICLE.

2. PARTS LIST:

A. Skid Plate(s) with predrilled mounting holes.

B. Important Note: Mounting hardware is not included because you will be using bolts that are already on your vehicle from the manufacturer.

3. Carefully remove the factory sound deadeners on your vehicle. Skid plates **replace** factory sound deadeners. Place all hardware in a safe location (you will be using this hardware to mount your new skid plate). You may choose to store your factory deadeners for future use or dispose of them completely. They are not used in conjunction with 6 Monkeys Skid Plates.

4. Fit your skid plate in place by lining up the predrilled skid plate mounting holes with the factory sound deadener mounting holes already on your vehicle. Working back to front, carefully thread each bolt into the mounting holes to hold the skid plate in place. **Do not tighten yet. Careful not to cross-thread your bolts during the mounting process.**

5. Once all bolts are carefully threaded in place and the skid plate appears even, work back to front while tightening each bolt to permanently secure your skid plate in place.

6. Repeat this process for each skid plate you intend to install.

7. Enjoy your new 6 Monkeys Skid Plate!