

### SVT COBRA - VENOM COOLER INSTRUCTIONS

Upper hose installed as viewed can vary left to right  $\frac{3}{8}$  inch. Do not over tighten clamps – cooler line will push in approximately  $\frac{3}{8}$  inch.

Lower hose measurement is critical along with fitting placement.

Please view pictures closely and build exactly to pictures.

New cobra kits will have the  $2\frac{3}{4}$  inch lower hose end already installed, just reuse your clamp.

Kit comes with a heat shield for hoses and you can add heat shrink to ends for a better finish.

Use black Venom Cooler line on bottom. It is more heat resistant. Colored line on top. Heat shield is optional.

Run a 50-50 coolant mix in system – more water will cool better. For additional information call 636-949-2275.

**ATTENTION!! CUT NEEDS TO BE MADE AT 5 3/8 INCHES ON BEND OF HOSE.**



**ANGLE IS CRITICAL!!**

